

**TECHNICAL MANUAL
 MAINTENANCE INSTRUCTIONS
 DIRECT SUPPORT AND GENERAL SUPPORT**

**M977 SERIES, 8 x 8 HEAVY
 EXPANDED MOBILITY
 TACTICAL TRUCKS (HEMTT)**

MODEL	NSN
TRUCK, CARGO, WITH WINCH M977	2320-01-097-0260
TRUCK, CARGO, WITHOUT WINCH M977	2320-01-099-6426
TRUCK, TANK, FUEL, WITH WINCH M978	2320-01-097-0249
TRUCK, TANK, FUEL, WITHOUT WINCH M978	2320-01-100-7672
TRUCK, TRACTOR, WITH WINCH, WITHOUT CRANE M983	2320-01-097-0247
TRUCK, TRACTOR, WITH WINCH, WITH CRANE M983	2320-01-099-6421
TRUCK, WRECKER-RECOVERY M984	2320-01-097-0248
TRUCK, WRECKER-RECOVERY M984E1	2320-01-195-7641
TRUCK, CARGO, WITH WINCH M985	2320-01-097-0261
TRUCK, CARGO, WITHOUT WINCH M985	2320-01-100-7673
TRUCK, CARGO, WITH WINCH M985E1	2320-01-1 94-7032
TRUCK, CARGO, WITHOUT WINCH M985E1	2320-01-194-7031

Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY

3 JUNE 1987

**TABLE OF CONTENTS
 PAGE i**

**M977 AND M985
 CRANE MAINTENANCE
 PAGE 17-1**

**POWER TAKEOFF (PTO)
 AND HYDRAULIC PUMP
 MAINTENANCE
 PAGE 19-1**

**HYDRAULIC SYSTEM
 MAINTENANCE
 PAGE 20-1**

**ENGINE ARCTIC HEATER
 KIT MAINTENANCE
 PAGE 21-1**

**M978 TANKER
 MAINTENANCE
 PAGE 22-1**

**SPECIAL PURPOSE
 KIT MAINTENANCE
 PAGE 23-1**

**APPENDIX D
 TORQUE LIMITS
 PAGE D-1**

**ALPHABETICAL
 INDEX
 PAGE INDEX 1**

CHANGE

NO. 3

**HEADQUARTERS
DEPARTMENT OF THE ARMY**
Washington, D. C., 15 December 1998

TECHNICAL MANUAL

MAINTENANCE INSTRUCTIONS

DIRECT SUPPORT AND GENERAL SUPPORT

**M977 SERIES, 8 X 8 HEAVY EXPANDED MOBILITY
TACTICAL TRUCKS (HEMTT)**

MODEL	NSN
TRUCK, CARGO, WITH WINCH, M977	2320-01-097-0260
TRUCK, CARGO, WITHOUT WINCH, M977	2320-01-099-6426
TRUCK, TANK, FUEL, WITH WINCH, M978	2320-01-097-0249
TRUCK, TANK, FUEL, WITHOUT WINCH, M978	2320-01-100-7672
TRUCK, TRACTOR, WITH WINCH, WITHOUT CRANE, M983	2320-01-097-0247
TRUCK, TRACTOR, WITH WINCH, WITH CRANE, M983	2320-01-099-6421
TRUCK, WRECKER-RECOVERY, M984	2320-01-097-0248
TRUCK, WRECKER-RECOVERY, M984E1	2320-01-195-7641
TRUCK, CARGO, WITH WINCH, M985	2320-01-097-0261
TRUCK, CARGO, WITHOUT WINCH, M985	2320-01-100-7673
TRUCK, CARGO, WITH WINCH, M985E1	2320-01-194-7032
TRUCK, CARGO, WITHOUT WINCH, M985E1	2320-01-194-7031

Approved for public release; distribution is unlimited.

TM 9-2320-279-34-3, 3 June 1987, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.
3. Minor changes to illustrations are indicated by a miniature pointing hand.
4. Illustrations that are new or that have major revisions are indicated by a vertical bar adjacent to the illustration.
5. Changes on cover are: Removed VOLUME NO. 3, deleted destruction notice, and changed distribution statement.

Remove Pages

c/(d blank)

i and ii

iii and iv

17-1 and 17-2

Insert Pages

c/(d blank)

i and ii

iii and iv

17-1 and 17-2

Remove Pages

17-34.1 thru 17-34.4
17-39 and 17-40
17-49 and 17-50
17-50.1 and 17-50.2
17-50.3 thru 17-50.10
17-72.1 thru 17-72.3/(17-72.4 blank)
17-73 and 17-74
none
17-75 and 17-76
none
17-93 and 17-94
none
17-95 and 17-96
17-96.1 thru 17-96.3/(17-96.4 blank)
17-114.7/(17-114.8 blank)
17-115 and 17-116
17-116.1 and 17-116.2
17-145 and 17-146
17-146.1 and 17-146.2
17-150.5/(17-150.6 blank)
17-151 and 17-152
17-152.1 thru 17-152.6
17-165 and 17-168
none
17-170.1 thru 17-170.4
none
19-1 and 19-2
19-5 and 19-6
19-7 and 19-8
19-11 and 19-12
19-12.1 and 19-12.2
19-12.9 and 19-12.10
19-13 thru 19-23/(19-24 blank)
21-1 thru 21-18

22-1 and 22-2
22-17 thru 22-24
none
22-25 and 22-26
22-33 and 22-34
22-53 and 22-54
22-67 thru 22-70
22-73 and 22-74
none
22-75 and 22-76
22-81 and 22-82
22-105 and 22-106
23-1 thru 23-24

Insert Pages

17-34.1 thru 17-34.4
17-39 and 17-40
17-49 and 17-50
17-50.1/(17-50.2 blank)
17-50.3 thru 17-50.14
17-72.1 thru 17-72.4
17-73 and 17-74
17-74.1/(17-74.2 blank)
17-75 and 17-76
17-92.1 thru 17-92.11/(17-92.12 blank)
17-93 and 17-94
17-94.1/(17-94.2 blank)
17-95 and 17-96
17-96.1 thru 17-96.6
17-114.7/(17-114.8 blank)
17-115 and 17-116
17-116.1 and 17-116.2
17-145 and 17-146
17-146.1 and 17-146.2
17-150.5 and 17-150.6
17-151 and 17-152
17-152.1 thru 17-152.7/(17-152.8 blank)
17-165 and 17-168
17-168.1/(17-168.2 blank)
17-170.1 thru 17-170.4
17-170.4.1/(17-170.4.2 blank)
19-1 and 19-2
19-5 and 19-6
19-7 and 19-8
19-11 and 19-12
19-12.1 and 19-12.2
19-12.9 thru 19-12.11/(19-12 blank)
19-13 thru 19-25/(19-26 blank)
21-1 thru 21-11/(21-12 blank)
(21-12 thru 21-18 deleted)

22-1 and 22-2
22-17 thru 22-24
22-24.1/(22-24.2 blank)
22-25 and 22-26
22-33 and 22-34
22-53 and 22-54
22-67 thru 22-70
22-73 and 22-74
22-74.1/(22-74.2 blank)
22-75 and 22-76
22-81 and 22-82
22-105 thru 22-110
23-1 thru 23-20/(23-21 thru 23-24 deleted)

Remove Pages

FP-3/(FP-4 blank)
FP-5/(FP-6 blank)
FP-S/(FP-10 blank)
Cover
23-75 and 23-76
A-1 and A-2
B-1 thru B-4
B-15 thru B-18
C-1 thru C-5/(C-6 blank)
DA 2028 sample F & B
DA 2028 F & B
DA 2028 F & B
DA 2028 F & B
Cover

Insert Pages

FP-3/(FP-4 blank)
FP-5/(FP-6 blank)
FP-9/(FP-10 blank)
Cover
23-75 and 23-76
A-1 and A-2
B-1 thru B-4
B-15 thru B-21/(B-22 blank)
C-1 thru C-6
DA 2028 sample F & B
DA 2028 F & B
DA 2028 F & B
DA 2028 F & B
Cover

File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

DENNIS J. REIMER
General, United States Army
Chief of Staff

Official:



JOEL B. HUDSON

Administrative Assistant to the
Secretary of the Army
05644

DISTRIBUTION: To be distributed in accordance with the Initial Distribution Number (IDN) 380653, requirements for TM 9-2320-279-34-3.

CHANGE

NO. 2

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington D.C., 30 April 1990

TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
DIRECT SUPPORT AND GENERAL SUPPORT
M977 SERIES, 8 X 8 HEAVY EXPANDED MOBILITY
TACTICAL TRUCKS (HEMTT)

MODEL	NSN
TRUCK, CARGO, WITH WINCH, M977	2320-01-097-0260
TRUCK, CARGO, WITHOUT WINCH, M977	2320-01-099-6426
TRUCK, TANK, FUEL, WITH WINCH, M978	2320-01-097-0249
TRUCK, TANK, FUEL, WITHOUT WINCH, M978	2320-01-100-7672
TRUCK, TRACTOR, WITH WINCH, WITHOUT CRANE, M983	2320-01-097-0247
TRUCK, TRACTOR, WITH WINCH, WITH CRANE, M983	2320-01-099-6421
TRUCK, WRECKER-RECOVERY, M984	2320-01-097-0248
TRUCK, WRECKER-RECOVERY, M984E1	2320-01-195-7641
TRUCK, CARGO, WITH WINCH, M985	2320-01-097-0261
TRUCK, CARGO, WITHOUT WINCH, M985	2320-01-100-7673
TRUCK, CARGO, WITH WINCH, M985E1	2320-01-194-7032
TRUCK, CARGO, WITHOUT WINCH, M985E1	2320-01-194-7031

TM 9-2320-279-34-3,3 June 1987, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.
3. Minor changes to illustrations are indicated by a miniature pointing hand.
4. Illustrations that are new or that have major revisions are indicated by a vertical bar adjacent to the illustration identification number.

Remove Pages

17-1 and 17-2
17-49 and 17-50
17-55 and 17-56
17-58.1 and 17-58.2
17-62.1 and 17-62.2
17-67 and 17-68
17-71 and 17-72

Insert Pages

17-1 and 17-2
17-49 and 17-50
17-55 and 17-56
17-58.1 and 17-58.2
17-62.1 and 17-62.2
17-67 and 17-68
17-71 and 17-72

Remove Pages

17-72.3/(17-72.4 blank)
17-75 and 17-76
17-78.1 and 17-78.2
17-79 and 17-80
17-83 thru 17-86.2
17-89 thru 17-90.2
17-90.5 and 17-90.6
17-93 thru 17-96
17-99 and 17-100
17-113 and 17-114
17-157 thru 17-160
17-173 thru 17-176
19-17 thru 19-22
23-67 and 23-68
23-73 and 23-74
A-1 and A-2
C-3 and C-4
Index 3 and Index 4
Index 13 thru Index 16

Insert Pages

17-72.3/(17-72.4 blank)
17-75 and 17-76
17-78.1 and 17-78.2
17-79 and 17-80
17-83 thru 17-86.2
17-89 thru 17-90.2
17-90.5 and 17-90.6
17-93 thru 17-96
17-99 and 17-100
17-113 and 17-114
17-157 thru 17-160
17-173 thru 17-179/(17-180 blank)
19-17 thru 19-22
23-67 and 23-68
23-73 and 23-74
A-1 and A-2
C-3 and C-4
Index 3 and Index 4
Index 13 thru Index 16

File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

Official:

WILLIAM J. MEEHAN II
Brigadier General United States Army
The Adjutant General

CARL E. VUONO
General, United States Army
Chief of Staff

Distribution:

To be distributed in accordance with DA Form 12-38 (Block No. 268), Direct Support and General Support maintenance requirements for Truck, Cargo, 10-ton, 8x8, Heavy Expanded Mobility Tactical Truck, HEMTT, M977, M978, M983, M984, M985.

CHANGE
NO. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 23 August 1989

MAINTENANCE INSTRUCTIONS

DIRECT SUPPORT AND GENERAL SUPPORT

M977 SERIES, 8 X 8 HEAVY EXPANDED MOBILITY
TACTICAL TRUCKS (HEMTT)

MODEL	NSN
TRUCK, CARGO, WITH WINCH M977	2320-01-097-0260
TRUCK, CARGO, WITHOUT WINCH M977	2320-01-099-6426
TRUCK, TANK, FUEL, WITH WINCH M978	2320-01-097-0249
TRUCK, TANK, FUEL, WITHOUT WINCH M978	2320-01-100-7672
TRUCK, TRACTOR, WITH WINCH, WITHOUT CRANE M983	2320-01-097-0247
TRUCK, TRACTOR, WITH WINCH, WITH CRANE M983	2320-01-099-6421
TRUCK, WRECKER-RECOVERY M984	2320-01-097-0248
TRUCK, WRECKER-RECOVERY M984E1	2320-01-195-7641
TRUCK, CARGO, WITH WINCH M985	2320-01-097-0261
TRUCK, CARGO, WITHOUT WINCH M985	2320-01-100-7673
TRUCK, CARGO WITH WINCH M985E1	2320-01-194-7032
TRUCK, CARGO, WITHOUT WINCH M985E1	2320-01-194-7031

TM 9-2320-279-34-3, 3 June 1987, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.

Remove Pages

iii and iv
B-1 through B-10

Insert Pages

iii and iv
B-1 through B-18

File this change sheet in the front of the publication for reference purposes.

By Order of the Secretary of the Army:

Official:

CARL E. VUONO
General, United States Army
Chief of Staff

WILLIAM J. MEEHAN II
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-38-R, Direct Support and General Support maintenance requirements for Truck, Cargo, 10-Ton, 8x8, Heavy Expanded Mobility Tactical Truck, HEMTT: M977, M978, M983, M984, M985.

WARNING**CARBON MONOXIDE (EXHAUST GAS) CAN CAUSE DEATH.**

Carbon monoxide is without color or smell, but can cause death. Breathing air with carbon monoxide produces symptoms of headache, dizziness, loss of muscular control, a sleepy feeling, and coma. Brain damage or death can result from heavy exposure. Carbon monoxide occurs in the exhaust fumes of fuel-burning heaters and internal combustion engines. Carbon monoxide can become dangerously concentrated under conditions of no ventilation. Precautions must be followed to ensure crew safety when the arctic engine heater or engine of any vehicle is operated for any purpose.

1. DO NOT operate arctic engine heater or engine of vehicle in a closed place without proper ventilation.
2. DO NOT drive any vehicle with inspection plates, cover plates, or engine compartment covers removed unless necessary for maintenance purposes.
3. BE ALERT at all times during vehicle operation for exhaust odors and exposure symptoms. If either are present, IMMEDIATELY VENTILATE personnel compartments. If symptoms persist, remove affected crew to fresh air and keep warm. DO NOT PERMIT PHYSICAL EXERCISE. If necessary, give artificial respiration and get immediate medical attention. For artificial respiration, refer to FM 21-11.
4. BE AWARE that the gas particulate filter unit or the field protection mask for nuclear-biological-chemical protection WILL NOT offer safety from carbon monoxide poisoning.

THE BEST DEFENSE AGAINST CARBON MONOXIDE POISONING IS GOOD VENTILATION.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

WARNING

Never use the parking brake for normal braking or wheels will lock up causing severe skid. Skidding vehicle could result in serious injury or death.

WARNING

Fuel is very flammable and can explode easily. To avoid serious injury or death, keep fuel away from open fire and keep fire extinguisher within easy reach when working with fuel. Do not work on fuel system when engine is hot. Fuel can be ignited by hot engine. When working with fuel, post signs that read NO SMOKING WITHIN 50 FEET of vehicle.

WARNING

Remove rings, bracelets, wristwatches, neck chains, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury, or may short across an electrical circuit and cause severe burns or electrical shock.

WARNING

The radiator is very hot and pressurized during vehicle operation. Let radiator cool before removing cap. Failure to do so can result in serious burns.

WARNING

The exhaust pipe and muffler can become very hot during vehicle operation. Be careful not to touch these parts with bare hands, or allow body to come in contact with pipe or muffler. Exhaust system parts can become hot enough to cause serious burns.

WARNING

Do not use trailer brakes as parking brake. Trailer brakes may not hold a loaded vehicle and trailer on a grade. A runaway vehicle may cause severe personal injury or death.

WARNING

Always use seatbelts when operating vehicle. Failure to use seatbelt can result in serious injury in case of accident.

WARNING

Avoid quick, jerking, winch operation. Keep other personnel well away from vehicles involved in winching operations. A snapped cable or shifting load can cause serious injury or death.

WARNING

Always wear heavy gloves when handling winch cables. Never let cable run through hands; frayed cables can cut. Never operate winch with less than five wraps of cable on winch drum.

WARNING

If operating crane under powerlines, do not allow vehicle to contact high-voltage connections. Death on contact can result. If possible, keep one hand away from equipment to reduce the hazard of current flowing through vital organs of the body.

WARNING

When working inside the vehicle with power off, be sure to ground every capacitor likely to hold a dangerous voltage potential.

WARNING

Never work on electronic equipment unless there is another person nearby who is familiar with the operation and hazards of the equipment.

WARNING

Be careful when working on or with electrical equipment. Do not be misled by the term "low voltage". Voltages as low as 50 volts may cause death. For artificial respiration, refer to FM 21-11.

WARNING

Be careful not to short out battery terminals. Do not smoke or use open flame near batteries. Batteries may explode from a spark. Battery acid is harmful to skin and eyes.

WARNING

Brake shoes may be coated with dust. Breathing this dust may be harmful to your health. Do not use compressed air to clean brake shoes. Wear a filter mask approved for use against brake dust. Failure to comply may result in injury or death to personnel.

WARNING

Starting fluid is toxic and flammable. Do not store in cab and do not breathe fumes. Do not puncture or burn containers. Dispose of container following manufacturer's recommendations on the container.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

WARNING

After Nuclear, Biological, or Chemical (NBC) exposure of vehicle, all air filters shall be handled with extreme caution. Unprotected personnel can experience injury or death if residual toxic agents or radioactive material are present. If vehicle is exposed to chemical or biological agents, servicing personnel shall wear protective mask, hood, protective overgarments, and chemical protective gloves and boots in accordance with TM 10-277. All contaminated air filters shall be placed in double-lined plastic bags and moved swiftly to a segregation area away from the worksite. The same procedure applies for radioactive dust contamination. The Company NBC team should measure the radiation prior to filter removal to determine the extent of safety procedures required per the NBC Annex to the unit Standard Operating Procedures (SOP). The segregation area in which the contaminated air filters are temporarily stored shall be marked with appropriate NBC placards. Final disposal of contaminated air filters shall be in accordance with local SOP. Decontamination operation shall be in accordance with FM 3-5 and local SOP.

WARNING

DO NOT grind or sand painted equipment without high-efficiency air purifying respirators in use.

WARNING

Use extreme care when removing or installing spring retainers. Spring retainers are under tension and can act as projectiles when released suddenly. Ensure proper eye protection is worn to prevent injury to personnel.

WARNING

Use extreme care when compressing, releasing, removing, or installing springs. Springs are under tension and can act as projectiles when released. Ensure proper eye protection is worn to prevent injury to personnel.

TECHNICAL MANUAL

**HEADQUARTERS
DEPARTMENT OF THE ARMY**
Washington, DC, 3 June 1987

No. 9-2320-279-34-3

**MAINTENANCE INSTRUCTIONS
DIRECT SUPPORT AND GENERAL SUPPORT
M977 SERIES, 8 x 8 HEAVY EXPANDED MOBILITY
TACTICAL TRUCKS (HEMTT)**

MODEL	NSN
TRUCK, CARGO, WITH WINCH, M977	2320-01-097-0260
TRUCK, CARGO, WITHOUT WINCH, M977	2320-01-099-6426
TRUCK, TANK, FUEL, WITH WINCH, M978	2320-01-097-0249
TRUCK, TANK, FUEL, WITHOUT WINCH, M978	2320-01-100-7672
TRUCK, TRACTOR, WITH WINCH, WITHOUT CRANE, M983	2320-01-097-0247
TRUCK, TRACTOR, WITH WINCH, WITH CRANE, M983	2320-01-099-6421
TRUCK, WRECKER-RECOVERY, M984	2320-01-097-0248
TRUCK, WRECKER-RECOVERY M984E1	2320-01-195-7641
TRUCK, CARGO, WITH WINCH, M985	2320-01-097-0261
TRUCK, CARGO, WITHOUT WINCH, M985	2320-01-100-7673
TRUCK, CARGO, WITH WINCH, M985E1	2320-01-194-7032
TRUCK, CARGO, WITHOUT WINCH, M985E1	2320-01-194-7031

Approved for public release; distribution is unlimited.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this Technical Manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail a letter or your DA Form 2028 (Recommended Changes to Publications and Blank Forms) directly to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-AC-NML, Rock Island, IL 61299-7630. You can also provide information to TACOM via datafax or e-mail. TACOM's datafax number is: DSN 793-0726 or (309) 782-0726. E-mail address: amsta-ac-nml@ria-emh1.army.mil

M983 with crane and M985E1 without winch are no longer in the fleet. Ignore all references to these vehicles. The M984E1 and M984A1 are the same vehicle. All references to M984E1 shall be interpreted as the M984A1 model.

TABLE OF CONTENTS

	Page
CHAPTER 17 M977, M984E1, AND M985 CRANE MAINTENANCE	17-1
Section I Introduction	17-2
Section II Crane, Subframe, and Swing Drive	17-2.1
Section III Boom, Mast, and Extensions	17-50.14
Section IV Cylinders	17-68
Section V Hoist	17-91
Section VI Crane Control Systems	17-117
Section VII Outriggers	17-153

	Page
CHAPTER 18 Deleted	
CHAPTER 19 POWER TAKEOFF (PTO) AND HYDRAULIC PUMP MAINTENANCE	19-1
Section I Introduction	19-1
Section II Power Takeoff (PTO)	19-1
Section III Hydraulic Pump	19-12.11
CHAPTER 20 HYDRAULIC SYSTEM MAINTENANCE	20-1
Section I Introduction	20-1
Section II Hydraulic Hand Pump	20-1
Section III Hydraulic Control Valves	20-5
■ CHAPTER 21 ARCTIC HEATER KIT MAINTENANCE	21-1
Section I Introduction	21-1
■ Section II Arctic Heater Kit	21-1
CHAPTER 22 M978 TANKER MAINTENANCE	22-1
Section I Introduction	22-1
Section II Service and Inspection	22-2
Section III Pump, Pump Motor, and Auxiliary Pump	22-10
Section IV Flow Meter	22-31
Section V Air Eliminator	22-44
Section VI Valves..	22-47
Section VII Fuel Service Nozzle	22-105
CHAPTER 23 SPECIAL PURPOSE KIT INSTALLATION	23-1
Section I Introduction	23-1
Section II Arctic Heater Kit	23-1
Section III Armament Equipment	23-25
Section IV Radio	23-33
Section V Chemical, Biological, and Radiological (CBR) Equipment	23-40
APPENDIXES	
A REFERENCES	A-1
B ILLUSTRATED LIST OF MANUFACTURED ITEMS	B-1
C EXPENDABLE SUPPLIES AND MATERIALS LIST	C-1
D TORQUE LIMITS	D-1
INDEX	Index 1

LIST OF ILLUSTRATIONS

Figure	Title	Page
17-1	Hoist Hoses and Tubes (Left Side)	17-5
17-2	Hoist Hoses and Tubes (Right Side)	17-6
17-3	Telescoping Cylinders, Hoses, and Tubes.	17-7
17-4	Telescoping Cylinders, Hoses, and Tubes.	17-8
17-5	Boom Cylinders, Hoses, and Tubes	17-9
17-6	Boom Cylinders, Hoses, and Tubes	17-10
17-7	Mast Erection Cylinders, Hoses, and Tubes.	17-11
17-8	Swing Drive Hoses and Tubes.	17-12
17-9	Main Hydraulic Hoses and Tubes	17-13
17-10	Main Control Valve	17-15
17-11	Overload Solenoid (M977 Only)	17-16
17-12	Hoist Hoses and Tubes (Left Side)	17-16.4
17-13	Hoist Hoses and Tubes (Right Side)	17-16.5
17-14	Lift Cylinder	17-16.6
17-15	Swing Drive	17-16.7
17-16	Main Lines	17-16.8
17-17	Shutdown Valves	17-16.9
17-18	Shutdown Valves	17-16.10
17-19	Accumulator	17-16.11
17-20	Control Valve	17-16.12
17-21	Control Valve	17-16.13
17-22	Control Valve	17-16.14
17-23	Left Hand Valve	17-16.15
17-24	Outrigger Manifold	17-16.16
17-25	Outrigger Cylinders	17-16.17
18-1	Extensions No. 3 and No. 4 Hoses and Tubes (Hose Reel Side)	18-76
18-2	Extensions No. 3 and No. 4 Hoses and Tubes (Hose Reel Side)	18-77
18-3	Extensions No. 1 and No. 2 Hoses and Tubes (Hose Reel Side)	18-78
18-4	Extensions No. 1 and No. 2 Hoses and Tubes (Hoist Cable Tiedown Block Side).	18-79
18-5	Extensions No. 1 and No. 2 Hoses and Tubes	18-80
18-6	Hoist Hoses and Tubes (Hose Reel Side)	18-81
18-7	Hoist Hoses and Tubes (Hose Reel Side)	18-82
18-8	Hoist Hoses and Tubes (Hoist Cable Tiedown Block Side)	18-83
18-9	Inner Boom Hoses and Tubes	18-84
18-10	Unfolding Cylinders Hoses and Tubes	18-85
18-11	Main Hydraulic Tubes	18-86
18-12	Slewing System Tubes	18-87
18-13	Outrigger Control Tubes	18-88
18-14	Outrigger Hoses and Tubes	18-89
18-15	Main Control Valve Ports	18-90
22-1	Tanker External Components	22-5
22-2	Tanker Filter and Manual Dispensing Components	22-6
22-3	Tanker Dispensing Components-Valves	22-7
22-4	Tanker Loading and Unloading Components.	22-8
22-5	Tanker Gages, Air, and Electrical Components	22-9
B-1	Lifting Eyes (PN 2BH944).	B-2
B-2	Shims	B-2
B-3	Detent Ball Compression Tool (Heavy-Duty Winch) (PN IPP161)	B-3
B-4	Crane Hoist Drive Unit Pressure Plate Removal/Instaliation Tool (M983)	B-3
B-5	Arctic Heater Test Set	B-4
B-6	Hydraulic Hand Pump Tool (M983) (PN 2CS30)	B-6
B-7	Hydraulic Hand Pump Tool (M983) (PN 2CS31)	B-7
B-8	V5 Air Actuated Valve Spring Compression Tool (M978) (PN 2SK886)	B-9
B-9	UnloaderBoreBushing Tool	B-10
B-10	Air compressor Cylinder Head Removal Tool (PN 2AH762).	B-10
B-11	Spanner Socket	B-10
B-12	Hoses and Hose Assemblies	B-14
B-13	Locking Strips	B-17
B-14	Locking Channel	B-18
B-15	Harness Wire	B-18
FO-1	Hydraulic Schematic	FP-1
FO-2	Crane Wiring Diagrams	FP-23
FO-3	Crane Electrical Schematic	FP-29

LIST OF TABLES

Number	Title	Page
17-1	Hoist Hoses and Tubes (Left Side)	17-5
17-2	Hoist Hoses and Tubes (Right Side)	17-6
17-3	Telescoping Cylinders, Hoses, and Tubes	17-7
17-4	Telescoping Cylinders, Hoses, and Tubes	17-8
17-5	Boom Cylinders, Hoses, and Tubes	17-9
17-6	Boom Cylinders, Hoses, and Tubes	17-10
17-7	Mast Erection Cylinders, Hoses, and Tubes	17-11
17-8	Swing Drive Hoses and Tubes	17-12
17-9	Main Hydraulic Hoses and Tubes	17-13
17-10	Main Control Valve	17-14
17-11	Overload Solenoid (M977 Only)	17-16
17-12	Hoist Hoses and Tubes (Left Side)	17-16.3
17-13	Hoist Hoses and Tubes (Right Side)	17-16.5
17-14	Lift Cylinder	17-16.6
17-15	Swing Drive	17-16.7
17-16	Main Lines	17-16.8
17-17	Shutdown Valves	17-16.9
17-18	Shutdown Valves	17-16.10
17-19	Accumulator	17-16.11
17-20	Control Valve	17-16.12
17-21	Control Valve	17-16.13
17-22	Control Valve	17-16.14
17-23	Left Hand Valve	17-16.15
17-24	Outrigger Manifold	17-16.16
17-25	Outrigger Cylinders	17-16.17
18-1	Extensions No. 3 and No. 4 Hoses and Tubes (Hose Reel Side)	18-76
18-2	Extensions No. 3 and No. 4 Hoses and Tubes (Hose Reel Side)	18-77
18-3	Extensions No. 1 and No. 2 Hoses and Tubes (Hose Reel Side)	18-78
18-4	Extensions No. 1 and No. 2 Hoses and Tubes (Hoist Cable Tiedown Block Side)	18-79
18-5	Extensions No. 1 and No. 2 Hoses and Tubes	18-80
18-6	Hoist Hoses and Tubes (Hose Reel Side)	18-81
18-7	Hoist Hoses and Tubes (Hose Reel Side)	18-82
18-8	Hoist Hoses and Tubes (Hoist Cable Tiedown Block Side)	18-83
18-9	Inner Boom Hoses and Tubes	18-84
18-10	Unfolding Cylinders Hoses and Tubes	18-85
18-11	Main Hydraulic Tubes	18-86
18-12	Slewing System Tubes	18-87
18-13	Outrigger Control Tubes	18-88
18-14	Outrigger Hoses and Tubes	18-89
18-15	Main Control Valve Ports	18-90
B-1	Hoses and Hose Assemblies	B-14
B-2	Locking Strips	B-17
B-3	Locking Channel	B-18
B-4	Harness Assembly	B-18
B-5	M1977-CBT Components	B-21
D-1	Torque Limits for Dry Fasteners	D-2
D-2	Torque Limits for Wet Fasteners	D-3
D-3	Dry Torque Limits for M983 Crane (Metric)	D-4

CHAPTER 17

M977, M985, and M984E1 CRANE MAINTENANCE

Contents	Para	Page
General	17-1	17-2
Hydraulic Hoses, Tubes, and Fittings Removal/Installation	17-2	17-2.1
Hydraulic Hoses, Tubes, and Fittings Removal/Installation (M984E1)	17-2.1	17-16
Crane Removal/Installation	17-3	17-17
Crane Removal/Installation	17-3.1	17-20
Subframe Removal/Installation	17-4	17-20.4
Turntable and Bearing Removal/Installation	17-5	17-22
Turntable and Bearing Removal/Installation (M984E1)	17-5.1	17-26
Turntable Stop Removal/Installation (M984E1)	17-5.2	17-26.3
Swing Drive Valve Removal/Repair/Installation	17-6	17-26.4
Swing Drive Valve Removal/Repair/Installation (M984E1)	17-6.1	17-28.1
Swing Drive Motor Removal/Repair/Installation	17-7	17-29
Swing Drive Motor Removal/Repair/Installation (M984E1)	17-7.1	17-34.1
Swing Drive Brake Removal/Repair/Installation	17-8	17-35
Swing Drive Brake Removal/Repair/Installation (M984E1)	17-8.1	17-38.1
Swing Drive Removal/Repair/Installation	17-9	17-39
Swing Drive Removal/Repair/Installation (M984E1)	17-9.1	17-50.3
Boom Removal/Installation	17-10	17-50.14
Boom Removal/Installation (M984E1)	17-10.1	17-56
Mast and Bushings Removal/Installation	17-11	17-56.4
Mast and Bushings Removal/Installation (M984E1)	17-11.1	17-58.1
Extension No. 1 and Wear Pads Removal/Installation	17-12	17-59
Extension No. 1 and Wear Pads Removal/Installation (M984E1)	17-12.1	17-62.1
Extension No. 2 and Wear Pads Removal/Installation	17-13	17-63
Extension No. 2 and Wear Pads Removal/Installation (M984E1)	17-13.1	17-68
Erection Cylinder Removal/Installation (M977, M985)	17-14	17-68.4
Erection Cylinder Removal/Installation (M984E1)	17-14.1	17-72
Erection Cylinder Repair	17-15	17-72.3
Lift Cylinder Removal/Installation	17-16	17-76
Lift Cylinder Removal/Installation (M984E1)	17-16.1	17-78.1
Lift Cylinder Repair	17-17	17-79
Extension No. 1 and No. 2 Cylinder and Wear Pads Removal/Installation	17-18	17-83
Extension No. 1 and No. 2 Cylinder and Wear Pads Removal/Installation (M984E1) ..	17-18.1	17-86
Extension Cylinder Repair	17-19	17-86.2
Extension Cylinder Repair (M984E1)	17-19.1	17-90.1
Tension Cylinder Removal/Repair/Installation (M984E1)	17-19.2	17-90.6
Hoist Assembly and Pivot Bushings Removal/Installation	17-20	17-91
Hoist Cable Follower Repair (M977, M985)	17-20.1	17-92.1
Hoist Cable Guide Removal/Installation (M977, M985)	17-20.2	17-92.8
Hoist Drive Motor Control Valve Removal/Repair/Installation	17-21	17-93
Hoist Motor Valve Assembly Removal/Repair/Installation (M984E1)	17-21.1	17-96.1
Hoist Drive Motor Removal/Repair/Installation	17-22	17-96.6
Hoist Drive Motor Removal/Repair/Installation (M984E1)	17-22.1	17-100
Hoist Assembly Repair	17-23	17-100.5
Hoist Brake Removal/Repair/Installation	17-24	17-106
Hoist Brake Removal/Repair/Installation (M984E1)	17-24.1	17-114
Hoist Adjustment (M977 and M985)	17-25	17-114.7
Hoist Adjustment (M984E1)	17-25.1	17-116.1
Eight Bank Valve Body and Mounting Bracket Removal/Installation	17-26	17-117
Eight Bank Valve Body Mounting Bracket Removal/Installation	17-27	17-120
Eight Bank Valve Body Repair	17-28	17-123
Right Hand Control Valves Mounting Bracket Removal/Installation (M984E1)	17-28.1	17-138
Left Hand Control Valve Body Removal/Repair/Installation (M984E1)	17-28.2	17-138.1

Contents	Para	Page
Right Hand Rear Control Valve Body Removal/Repair/Installation (M984E1)	17-28.3	17-138.6
Right Hand Front Control Valve Body Removal/Repair/Installation (M984E1)	17-28.4	17-138.12
Solenoid Removal/Installation	17-29	17-138.25
Solenoid Removal/Installation (M984E1)	17-29.1	17-140
Accumulator Removal/Repair/Charging/Installation	17-30	17-140.2
Main Hydraulic Pressure Adjustment	17-31	17-144
Main Hydraulic Pressure Adjustment (M984E1)	17-31.1	17-146
Lift Down and Shut Down Solenoids Removal/Repair/Installation	17-32	17-146.2
Lift Down and Shut Down Solenoids Removal/Repair/Installation (M984E1)	17-32.1	17-150
Overload Sensor Switch Adjustment	17-33	17-150.5
Overload Sensor Switches Adjustment (M984E1)	17-33.1	17-152.1
Outrigger Removal/Installation	17-34	17-153
Outrigger Leg Cylinder Removal/Installation	17-35	17-155
Outrigger Leg Cylinder Repair	17-36	17-157
Outrigger Leg Cylinder Removal/Installation (M984E1)	17-36.1	17-161
Outrigger Leg Cylinder Repair (M984E1)	17-36.2	17-162
Outrigger Extensions Removal/Installation	17-37	17-162.4
Outrigger Extension Cylinder Removal/Installation	17-38	17-165
Outrigger Outer Beam and Extension Cylinder Removal/Installation (M984E1)	17-38.1	17-168
Outrigger Inner Beam Removal/Installation (M984E1)	17-38.2	17-170.5
Outrigger Extension Cylinder Repair	17-39	17-170.7
Outrigger Inner Beam Extension Cylinder Removal/Installation (M984E1)	17-40	17-172
Outrigger Inner and Outer Beam Cylinder Repair (M984E1)	17-41	17-174
Crane Cylinder Test	17-42	17-177

Section I. INTRODUCTION

17-1. GENERAL. This chapter contains maintenance instructions for removing, installing, and repairing the M977 and M985 crane components at the direct support and general support maintenance level. The subassemblies and parts which must be removed before the crane components can be removed are referenced to other paragraphs or chapters of this manual or TM 9-2320-279-20.

Section II. CRANE, SUBFRAME, AND SWING DRIVE

M977, M985, and M984E1 Crane Maintenance Instructions

17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION.

This task covers:

- | | |
|--|--|
| <ul style="list-style-type: none"> a. Disconnect Quick Couplings b. Connect Quick Couplings c. Disconnect Hydraulic Hoses and Tubes d. Connect Hydraulic Hoses and Tubes e. Type 1 Clamp Removal f. Type 1 Clamp Installation g. Type 2 Clamp Removal h. Type 2 Clamp Installation | <ul style="list-style-type: none"> i. Type 3 Clamp and Bracket Removal j. Type 3 Clamp and Bracket Installation k. Type 4 Clamp Removal l. Type 4 Clamp Installation m. Type 5 Clamp Removal n. Type 5 Clamp Installation o. Hydraulic Hose and Tube Removal/Installation p. Follow-on Maintenance |
|--|--|

INITIAL SETUP

Models

M977, M985

Test Equipment

None

Special Tools

None

Supplies

Tags, identification, Item 60, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

TM 9-2320-279-10 Crane in operating position and supported by suitable lifting device.

TM 9-2320-279-10 Shut off engine.

Special Environmental Conditions

None

General Safety Instructions


None

Level of Maintenance

Direct Support

NOTE

- Subparagraphs a through n show all typical connections and clamps used on the M977 and M985 cranes.
- This procedure is for reference only to show location of hoses, tubes, and fittings used on the M977 and M985 cranes. It will never be necessary to remove all hydraulic hoses at one time. Individual procedures will indicate the area where hoses are to be removed and installed.



a. *Disconnect Quick Couplings.* Push ring (1) away from hose fitting (2) and pull hose free.

b. *Connect Quick Couplings.* Push ring (1) away from hose fitting (2) and push hose in until seated. Release ring (1) while holding pressure on hose fitting (2).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE



Some hoses and tubes will not have preformed packings.

c. *Disconnect Hydraulic Hoses and Tubes.* Loosen fitting (1). Remove preformed packing (2) and hose (3).

d. *Connect Hydraulic Hoses and Tubes.* Connect fitting (1) with preformed packing (2) and tighten.


e. *Type 1 Clamp Removal.* Remove screw (1), spacer (2), and clamps (3).

f. *Type 1 Clamp Installation.* Install clamps (3) and spacer (2) with screw (1).




g. *Type 2 Clamp Removal.* Remove two screws (1), spacers (2), and clamps (3).

h. *Type 2 Clamp Installation.* Install clamps (3) and spacers (2) with two screws (1).



i. *Type 3 Clamp and Bracket Removal.* Remove nut (1), lockwasher (2), washer (3), clamp (4), and bracket (5) from stud (6).


j. *Type 3 Clamp and Bracket Installation.* Install bracket (5) and clamp (4) on stud (6) with washer (3), lockwasher (2), and nut (1).



17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (CONT).

k. *Type 4 Clamp Removal.* Remove screw (1), lockwasher (2), clamp (3), and two washers (4).

l. *Type 4 Clamp Installation.* Install two washers (4), clamp (3), and lockwasher (2) with screw (1).




TA190204

NOTE

Do not remove screw. Screw holding clamp also holds hoist pivot pin in place.

m. *Type 5 Clamp Removal.* Remove nut (1) and clamp (2) from screw (3).

n. *Type 5 Clamp Installation.* Install clamp (2) on screw (3) with nut (1).



TA190205

o. *Hydraulic Hose and Tube Removal/installation.*


NOTE

- This part consists of Hydraulic Hose and Tube Indexes, Tables 17-1 through 17-10, and Figures 17-1 through 17-10, to help locate hydraulic hoses and tubes.
- Tag all hoses and components during removal.
- This paragraph does not cover outrigger hoses, tubes, and fittings. See paragraph 17-36 for outrigger leg and paragraphs 17-38 and 17-39 for outrigger extension cylinder and internal routing.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-1. Hoist Hoses and Tubes (Left Side)

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
A	Elbow (1)	17-1	Elbow (11)	17-2
B	Elbow (2)	17-1	Elbow (12)	17-2
C	Valve (3)	17-1	Tube End (4)	17-1
D	Valve (3)	17-1	Tube End (5)	17-1
E	Tube End (4)	17-1	Tube End (6)	17-1
F	Tube End (5)	17-1	Elbow (7)	17-1
G	Elbow (7)	17-1	Tube End 16)	17-2
H	Tube End (6)	17-1	Joint (8)	17-1
I	Joint (8)	17-1	Joint (9)	17-1
J	Joint (9)	17-1	Hose End 10)	17-1
K	Hose End (10)	17-1	Hoist Port A (57)	17-10



TA190206


Figure 17-1. Hoist Hoses and Tubes (Left Side).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (CONT).

Table 17-2. Hoist Hoses and Tubes (Right Side)

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
L	Valve (13)	17-2	Tube End (14)	17-2
M	Tube End (14)	17-2	Hose End (15)	17-2
N	Tube End (16)	17-2	Joint (17)	17-2
O	Joint (17)	17-2	Joint (18)	17-2
P	Joint (18)	17-2	Hose End (19)	17-2
Q	Hose End (19)	17-2	Hoist Port B (58)	17-10
R	Hose End (15)	17-2	Tee (48)	17-8



TA190207


Figure 17-2. Hoist Hoses and Tubes (Right Side).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (CONT).

Table 17-4. Telescoping Cylinders, Hoses, and Tubes

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
X	Connector (26)	17-4	Joint (27)	17-4
Y	Joint (27)	17-4	Joint (28)	17-4
Z	Joint (28)	17-4	Elbow (29)	17-4
AA	Elbow (23)	17-4	Hose End (24)	17-4
AB	Elbow (29)	17-4	Hose End (25)	17-4



(REAR VIEW)

(RIGHT SIDE VIEW)


TA190212

Figure 17-4. Telescoping Cylinders, Hoses, and Tubes.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-5. Boom Cylinders, Hoses, and Tubes

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AC	Elbow (30)	17-5	Elbow (31)	17-5
AD	Connector (32)	17-5	Connector (33)	17-5
AE	Connector (34)	17-5	Connector (35)	17-5
AF	Connector (36)	17-5	Elbow (37)	17-5
AG	Elbow (37)	17-5	Boom Port A (59)	17-10



TA190210

Figure 17-5. Boom Cylinders, Hoses, and Tubes.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (CONT).

Table 17-6. Boom Cylinders, Hoses, and Tubes

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AH	Connector (38)	17-6	Elbow (39)	17-6
AI	Elbow (39)	17-6	Boom Port B (60)	17-10





Figure 17-6. Boom Cylinders, Hoses, and Tubes.

TA190211

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-7. Mast Erection Cylinders, Hoses, and Tubes

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AJ	Connector (40)	17-7	Reducer (41)	17-7
AK	Elbow (42)	17-7	Elbow (43)	17-7
AL	Tee (44)	17-7	Mast Port A (67)	17-10
AM	Elbow (45)	17-7	Mast Port B (68)	17-10



TA190209


Figure 17-7. Mast Erection Cylinders, Hoses, and Tubes.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (CONT).

Table 17-8. Swing Drive Hoses and Tubes

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AN	Elbow (46)	17-8	Elbow (47)	17-8
R	Tee (48)	17-8	Hose End (15)	17-2
AO	Tee (48)	17-8	Connector (50)	17-9
AP	Swing Drive Brake Valve (49)	17-8	Swing Port B (66)	17-10
AQ	Swing Drive Brake Valve (49)	17-8	Swing Port A (65)	17-10




TA190213

Figure 17-8. Swing Drive Hoses and Tubes.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-9. Main Hydraulic Hoses and Tubes

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AO	Connector (50)	17-9	Tee (48)	17-8
AR	Fitting (51)	17-9	Solenoid (52)	17-9
AS	Quick Coupling (53)	17-9	Tank Port T (61)	17-10
AT	Tee (54)	17-9	Solenoid (52)	17-9
AU	Tee (54)	17-9	Pressure Port P (62)	17-10
AV	Accumulator (55)	17-9	Tee (56)	17-9




TA190214

Figure 17-9. Main Hydraulic Hoses and Tubes.

17-2. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (CONT).

Table 17-10. Main Control Valve

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
J	Hoist Port A (57)	17-10	Hose End (10)	17-1
Q	Hoist Port B (58)	17-10	Hose End (19)	17-2
AG	Boom Port A (59)	17-10	Fitting (37)	17-5
AI	Boom Port B (60)	17-10	Fitting (39)	17-6
AS	Tank Port T (61)	17-10	Quick Coupling (53)	17-9
AU	Pressure Port P (62)	17-10	Tee (54)	17-9
W	Telescoping Port A (63)	17-10	Hose End (25)	17-3
V	Telescoping Port B (64)	17-10	Hose End (24)	17-3
AQ	Swing Port A (65)	17-10	Swing Drive Brake Valve (49)	17-8
AP	Swing Port B (66)	17-10	Swing Drive Brake Valve (49)	17-8
AL	Mast Port A (67)	17-10	Tee (44)	17-7
AM	Mast Port B (68)	17-10	Elbow (45)	17-7



TA190215

NOTE

Hoses and tubes not shown for clarity.

Figure 17-10. Main Control Valve.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-11. Overload Solenoid (M977 Only)

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AW	Solenoid Fitting (69)	17-11	Boom Port (60)	17-10
AX	Solenoid Fitting (70)	17-11	Lift Cylinder Fitting (71)	17-11




Figure 17-11. Overload Solenoid (M977 Only).

p. *Follow-on Maintenance.* Remove lifting device and return crane to transport position (TM 9-2320-279-10).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cent)

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1).

This task covers:

- | | |
|---|---|
| <ul style="list-style-type: none"> a. Disconnect Hydraulic Hoses and Tubes b. Connect Hydraulic Hoses and Tubes c. Type 1 Clamp Removal d. Type 1 Clamp Installation e. Type 2 Clamp Removal f. Type 2 Clamp Installation | <ul style="list-style-type: none"> g. Type 3 Clamp and Bracket Removal h. Type 3 Clamp and Bracket Installation i. Type 4 Clamp Removal j. Type 4 Clamp Installation k. Hydraulic Hose and Tube Removal/Installation l. Follow-on Maintenance |
|---|---|

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

Tags, identification, Item 60, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

TM 9-2320-279-10 Crane in operating position and supported by suitable lifting device.

TM 9-2320-279-10 Shut off engine.

Special Environmental Conditions

None

General Safety Instructions

None

Level of Maintenance

Direct Support

NOTE


- Subparagraphs a through i show all typical connections and clamps used on the M984E1 crane.
- This procedure is for reference only to show location of hoses, tubes, and fittings used on the M984E1 crane. It will never be necessary to remove all hydraulic hoses at one time. Individual procedures will indicate the area where hoses are to be removed and installed.
- Some hoses and tubes will not have preformed packings.

a. *Disconnect Hydraulic Hoses and Tubes.* Loosen fitting (1). Remove preformed packing (2) and hose (3).


b. *Connect Hydraulic Hoses and Tubes.* Connect fitting (1) with preformed packing (2) and tighten.

c. *Type 1 Clamp Removal.* Remove screw (1), spacer (2), and clamps (3).

d. *Type 1 Clamp Installation.* Install clamps (3) and spacer (2) with screw (1).



TA190200




TA190201

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


e. *Type 2 Clamp Removal.* Remove two screws (1), spacers (2), and clamps (3).

f. *Type 2 Clamp Installation.* Install clamps (3) and spacers (2) with two screws (1).



g. *Type 3 Clamp Removal.* Remove screw (1), lockwasher (2), and clamp (3).

h. *Type 3 Clamp Installation.* Install clamp (3) and lockwasher (2) with screw (1).




NOTE

Do not remove screw. Screw holding clamp also holds hoist pivot pin in place.

i. *Type 4 Clamp Removal.* Remove nut (1) and clamp (2) from screw (3).

j. *Type 4 Clamp Installation.* Install clamp (2) on screw (3) with nut (1).



17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)

k. Hydraulic Hose and Tube Removal/Installation.

NOTE

- This part consists of Hydraulic Hose and Tube Indexes, Tables 17-12 through 17-25, and Figures 17-12 through 17-25, to help locate hydraulic hoses and tubes.
- Tag all hoses and components during removal.
- This paragraph does not cover outrigger hoses, tubes, and fittings. See paragraphs 17-37 and 17-38 for outrigger leg and outrigger extension cylinder and internal routing.

Table 17-12. Hoist Hoses and Tubes (Left Side)

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
A	Elbow (1)	17-12	Elbow (15)	17-13
B	Elbow (2)	17-12	Elbow (16)	17-13
C	Valve (3)	17-12	Tube End (4)	17-12
D	Valve (3)	17-12	Tube End (5)	17-12
E	Tube End (4)	17-12	Tube End (6)	17-12
F	Tube End (5)	17-12	Elbow (7)	17-12
G	Elbow (7)	17-12	Tube End (20)	17-13
H	Tube End (6)	17-12	Joint (8)	17-12
I	Joint (8)	17-12	Joint (9)	17-12
J	Joint (9)	17-12	Hose End (10)	17-12
K	Hose End (10)	17-12	Hoist Port (65)	17-20
L	Fitting (11)	17-12	Joint (12)	17-12
M	Joint (12)	17-12	Joint (13)	17-12
N	Joint (13)	17-12	Hose End (14)	17-12
O	Hose End (14)	17-12	Telescope Port (64)	17-20

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)




Figure 17-12. Hoist Hoses and Tubes (Left Side).


TA476840

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)
(CONT).

Table 17-13. Hoist Hoses and Tubes (Right Side)

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
P	Valve (17)	17-13	Tube End (18)	17-13
Q	Tube End (18)	17-13	Hose End (19)	17-13
R	Hose End (19)	17-13	Tee (39)	17-15
S	Tube End (20)	17-13	Joint (21)	17-13
T	Joint (21)	17-13	Joint (22)	17-13
U	Joint (22)	17-13	Hose End (23)	17-13
V	Hose End (23)	17-13	Solenoid (49)	17-18
W	Fitting (24)	17-13	Joint (25)	17-13
X	Joint (25)	17-13	Joint (26)	17-13
Y	Joint (26)	17-13	Hose End (27)	17-13
Z	Hose End (27)	17-13	Solenoid (51)	17-18



TA476841

Figure 17-13. Hoist Hoses and Tubes (Right Side).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-14. Lift Cylinder

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
AA	Elbow (28)	17-14	Elbow (29)	17-14
BB	Elbow (30)	17-14	Elbow (31)	17-14
CC	Elbow (32)	17-14	Elbow (33)	17-14
DD	Elbow (34)	17-14	Solenoid (52)	17-18
EE	Elbow (35)	17-14	Solenoid (49)	17-18
FF	Elbow (36)	17-14	Valve Fitting (47)	17-17
GG	Valve (37)	17-14	Mast Port (69)	17-21
HH	Elbow (38)	17-14	Mast Port (68)	17-21





Figure 17-14. Lift Cylinder.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)
(CONT).

Table 17-15. Swing Drive

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
II	Elbow (40)	17-15	Elbow (41)	17-15
JJ	Fitting (42)	17-15	Swing Port (62)	17-20
KK	Fitting (43)	17-15	Swing Port (63)	17-20
LL	Tee (39)	17-15	Return Line (TT)	17-16



TA476843

Figure 17-15. Swing Drive.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-16. Main Lines

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
MM	Truck Return (44)	17-16	R.H.F. Valve Port (56)	17-20
NN	Truck Supply (45)	17-16	R.H.F. Valve Port (55)	17-20
OO	Main Line MM	17-16	Override Solenoid (48)	17-17
PP	Main Line NN	17-16	Override Solenoid (48)	17-17
QQ	Line OO	17-16	R.H.R. Valve Port (78)	17-22
RR	Line PP	17-16	R.H.R. Valve Port (77)	17-22
SS	Main Line MM	17-16	Lift Cylinder Check Valve Fitting (46)	17-17
TT	Main Line MM	17-16	Swing Drive Tee (39)	17-15
UU	Main Line MM	17-16	L.H. Valve Port	17-24
VV	Main Line NN	17-16	L.H. Valve Port	17-23




Figure 17-16. Main Lines.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)

Table 17-17. Shutdown Valves

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
FF	Valve Fitting (47)	17-17	Elbow (36)	17-14
SS	Valve Fitting (46)	17-17	Main Line MM	17-16
OO	Valve (48)	17-17	Main Line MM	17-16
PP	Valve (48)	17-17	Main Line NN	17-16





Figure 17-17. Shutdown Valves.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-18. Shutdown Valves

NOTE
Fittings on solenoids are on back side.

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
QQ	Solenoid (49)	17-18	R.H.F. Valve Port (57)	17-20
RR	Solenoid (50)	17-18	R.H.F. Valve Port (58)	17-20
SS	Solenoid (51)	17-18	R.H.F. Valve Port (59)	17-20
EE	Solenoid (49)	17-18	Elbow (35)	17-14
V	Solenoid (50)	17-18	Hose End (23)	17-13
Z	Solenoid (51)	17-18	Hose End (27)	17-13
DD	Solenoid (52)	17-18	Elbow (34)	17-14
TT	Solenoid (52)	17-18	R.H.F. Valve Port (60)	17-20



TA476846


Figure 17-18. Shutdown Valves.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)

Table 17-19. Accumulator

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
UU	Tee Fitting (53)	17-19	Accumulator (54)	17-19




TA476847

Figure 17-19. Accumulator.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-20. Control Valve

Hose Or Tube	From		10	
	Component	Figure	Component	Figure
MM	Port (56)	17-20	Truck Return (44)	17-16
NN	Port (55)	17-20	Truck Supply (45)	17-16
QQ	Port (57)	17-20	Solenoid (49)	17-18
RR	Port (58)	17-20	Solenoid (50)	17-18
SS	Port (59)	17-20	Solenoid (51)	17-18
TT	Port (60)	17-20	Solenoid (52)	17-18
VV	Port (61)	17-20	R.H.R. Port (75)	17-22
JJ	Port (62)	17-20	Fitting (42)	17-15
KK	Port (63)	17-20	Fitting (43)	17-15
O	Port (64)	17-20	Hose End (14)	17-12
K	Port (65)	17-20	Hose End (10)	17-12



TA476848


Figure 17-20. Control Valve.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)

Table 17-21. Control Valve

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
WW	Port (66)	17-21	Manifold (87)	17-24
XX	Port (67)	17-21	Manifold (88)	17-24
HH	Port (68)	17-21	Elbow (38)	17-14
GG	Port (69)	17-21	Valve (37)	17-14
YY	Port (70)	17-21	Valve (91)	17-25
ZZ	Port (71)	17-21	Valve (92)	17-25
AAA	Port (72)	17-21	Manifold (89)	17-24
BBB	Port (73)	17-21	Manifold (90)	17-24
CCC	Port (74)	17-21	To Retrieval System	



TA476849

Figure 17-21. Control Valve.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-22. Control Valve

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
VV	Port (75)	17-22	Port (61)	17-20
DDD	Port (76)	17-22	L.H. Port (79)	17-23
RR	Port (77)	17-22	Main Line (PP)	17-16
QQ	Port (78)	17-22	Main Line (OO)	17-16





Figure 17-22. Control Valve.

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)

Table 17-23. Left Hand Valve

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
DDD	Port (79)	17-23	Port (76)	17-22
EEE	Port (80)	17-23	Manifold Elbow (92)	17-24
FFF	Port (81)	17-23		
GGG	Port (82)	17-23	Valve (93)	17-25
HHH	Port (83)	17-23	Valve (94)	17-25
III	Port (84)	17-23	Manifold Elbow (89)	17-24
JJJ	Port (85)	17-23	Manifold Elbow (90)	17-24
KKK	Port (86)	17-23	Port (76)	17-22




TA476851

Figure 17-23. Left Hand Valve.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Table 17-24. Outrigger Manifold

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
XX	Manifold Elbow (88)	17-24	Port (66)	17-21
BBB	Manifold Elbow (90)	17-24	Port (73)	17-21
AAA	Manifold Elbow (89)	17-24	Port (72)	17-21
WW	Manifold Elbow (87)	17-24	Port (66)	17-21
EE	Elbow (35)	17-3	Elbow (92)	17-24
III	Manifold Tee (89)	17-24	Port (84)	17-23
JJJ	Manifold Elbow (90)	17-24	Port (85)	17-23




TA476852

Figure 17-24. Outrigger Manifold.

17-2.1. HYDRAULIC HOSES, TUBES, AND FITTINGS REMOVAL/INSTALLATION (M984E1)
(CONT).

Table 17-25. Outrigger Cylinders

Hose Or Tube	From		To	
	Component	Figure	Component	Figure
YY	Valve (91)	17-25	Port (70)	17-21
ZZ	Valve (92)	17-25	Port (71)	17-21
GGG	Valve (93)	17-25	Port (82)	17-23
HHH	Valve (94)	17-25	Port (83)	17-23



TA476853

Figure 17-25. Outrigger Cylinders.

I. Follow-on Maintenance. Check for leaks.


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-3. CRANE REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
Models M977, M985	Equipment Condition
Test Equipment None	TM or Para Para 17-2
Special Tools None	Condition Description Outrigger hoses and tubes disconnected.
Supplies None	Para 17-2 Main hydraulic lines removed.
Personnel Required MOS 63W, Wheel vehicle repairer (2)	TM 9-2320-279-20 Taillight wiring harness removed.
References None	Special Environmental Conditions None
	General Safety Instructions None
	Level of Maintenance Direct Support

a. Removal.


(1) Disconnect cable (1) from connector (2).



NOTE

Tag and mark wires and connectors.

(2) Disconnect three wires (3) at connectors (4).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-3. CRANE REMOVAL/INSTALLATION (CONT).

WARNING


Keep out from under heavy parts. Falling parts may cause serious injury or death.

(3) Attach suitable lifting device to crane (5).



TA190281


- (4) Remove screw (6) and nut (7) from cable guide (8).
- (5) Soldier A removes four screws (9), washers (10), and spacers (11) while Soldier B removes nuts (12), washers (13), and spacers (14).
- (6) Repeat step (5) for other side.
- (7) Remove crane (5).



TA190282

b. Installation.


(1) Aline and install crane (1).



TA190283


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (2) Soldier A installs four spacers (2), washers (3), and screws (4) while Soldier B installs four spacers (5), washers (6), and nuts (7).
- (3) Tighten screws (4).
- (4) Install screw (8) and nut (9) in cable guide (10).
- (5) Repeat steps (2) and (3) for other side.



TA190284

- (6) Connect three wires (11) at connectors (12).




TA190285

- (7) Connect cable (13) to connector (14).

c. Follow-on Maintenance.

- (1) Connect outrigger hoses and tubes (para 17-2).
- (2) Connect main hydraulic lines (para 17-2).
- (3) Connect taillight wiring harness (TM 9-2320-279-20).




TA357261

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-3.1. CRANE REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
Models M984E1	Equipment Condition
Test Equipment None	<i>TM or Para</i> <i>Condition Description</i> TM 9-2320-279-10 Cargo body removed. TM 9-2320-279-20 Fenders removed. TM 9-2320-279-20 Crane lockpin removed.
Special Tools None	Special Environmental Conditions None
Supplies None	General Safety Instructions None
Personnel Required MOS 63W, Wheel vehicle repairer	Level of Maintenance Direct Support
References None	

a. **Removal.**



- (1) Disconnect two hydraulic lines (1).
- (2) Disconnect connector (2) at high idle box (3).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476448


- (3) Disconnect hydraulic line (4) from valve body (5).
- (4) Attach a suitable lifting device to crane (6).

- (5) Remove nine nuts (7), washers (8), spacers (9), screws (10), washers (8) and spacers (9).
- (6) Repeat step (4) for other side.



TA476449

- (7) Remove crane (6) from truck (10).




TA476450


17-3.1. CRANE REMOVAL/INSTALLATION (CONT).

b. Installation.

(1) Position crane (1) on truck (2).




TA476451



TA476452

(2) Install nine screws (3), washers (4), and spacers (5) with spacers (5), washers (4), and nuts (6).


(3) Repeat step (2) for other side.



TA476453


(4) Connect connector (7) to high idle box (8).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476454

(5) Connect two hydraulic lines (9).



TA476455

(6) Connect hydraulic line (10) to valve body (11).

c. *Follow-on Maintenance.*


- (1) Install cargo body (TM 9-2320-279-10).
- (2) Install fenders (TM 9-2320-279-20).
- (3) Install crane lockpin (TM 9-2320-279-20).
- (4) Check for leaks.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-4. SUBFRAME REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i>
<i>Test Equipment</i> None	<i>TM or Para</i> <i>Condition Description</i>
<i>Special Tools</i> None	TM 9-2320-279-20 Fenders removed. TM 9-2320-279-20 Clearance light wiring harness removed.
<i>Supplies</i> None	Para 17-10 Boom removed. Para 17-5 Turntable removed. Para 17-9 Swing drive removed. Para 6-11 Junction box removed.
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)	<i>Special Environmental Conditions</i> None
<i>References</i> None	<i>General Safety Instructions</i> None
	<i>Level of Maintenance</i> Direct Support

a. Removal.




- (1) Remove screw (1) and nut (2) from cable guide (3).
- (2) Soldier A removes four screws (4), washers (5), and spacers (6) while Soldier B removes four nuts (7), washer (8), and spacer (9).
- (3) Repeat step (2) for other side.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.


- (4) Attach suitable lifting device and remove subframe (10).
- (5) Remove two screws (11), stop pin (12), and stop (13).



TA189738

b. *Installation.*

- (1) Install stop (1), stop pin (2), and two screws (3).
- (2) Aline and install subframe (4).




TA189741

- (3) Soldier A installs four spacers (5), washers (6), and screws (7) while Soldier B installs four spacers (8), washers (9), and nuts (10).
- (4) Repeat step (3) for other side.
- (5) Install screw (11) and nut (12) in cable guide (13).

c. *Follow-on Maintenance.*

- (1) Install junction box (para 6-11).
- (2) Install swing drive (para 17-9).
- (3) Install turntable (para 17-5).
- (4) Install boom (para 17-10).
- (5) Connect clearance light wiring harness (TM 9-2320-279-20).
- (6) Install fenders (TM 9-2320-279-20).




TA189742

END OF TASK

17-5. TURNTABLE AND BEARING REMOVAL/INSTALLATION.		
This task covers:		
a. Removal	c. Follow-on Maintenance	
b. Installation		
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
M977, M985	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 17-16	Lift cylinders removed.
None	Para 17-14	Erection cylinders removed.
<i>Special Tools</i>	Para 17-10	Boom removed.
None	Para 17-11	Mast removed.
<i>Supplies</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Personnel Required</i>	<i>General Safety Instructions</i>	
MOS 63W, Wheel vehicle repairer	None	
<i>References</i>	<i>Level of Maintenance</i>	
None	Direct Support	


a. Removal.



- (1) Remove nut (1) and hydraulic line (2) from turntable (3).
- (2) Repeat step (1) for other side.


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3) Remove 14 screws (4) and washers (5).
- (4) Remove four screws (6) and washers (7).




TA189829

- (5) Attach suitable lifting device.
- (6) Remove turntable (3).



TA189830

- (7) Remove 16 screws (8) and washers (9).
- (8) Remove bearing (10) from subframe (11).




TA189831

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-5. TURNTABLE AND BEARING REMOVAL/INSTALLATION (CONT).

- (9) Remove two dust seals (12) and grease fitting (13) from bearing (10).




b. Installation.

NOTE

Ridge end of seal is installed in bearing.
Cut off excess seal.


- (1) Install two dust seals (1) and grease fitting (2) in bearing (3).



NOTE


- Letter G stamped on bearing faces down and centered on subframe.
- Replace turntable bearing bolts with new bolts any time they are removed.

- (2) Aline and install bearing (3) on subframe (4).
(3) Install 16 screws (5) and washers (6).



M977, M985, and M984E1 Crane Maintenance Instructions (Cent)

(4) Aline and install turnable (7).




TA189835

(5) Install 14 screws (8) and washers (9) in turntable (7).

NOTE

Screws are installed in inside corners.

(6) Install four screws (10) and washers (11).



TA189836

(7) Install hydraulic line (12) and nut (13).

(8) Repeat step (7) for other side.

c. Follow-on Maintenance.


(1) Install erection cylinders (para 17-14).

(2) Install lift cylinders (para 17-16).

(3) Install mast (para 17-11).

(4) Install boom (para 17-10).

END OF TASK




TA189837

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-5.1. TURNTABLE AND BEARING REMOVAL/INSTALLATION (M984E1).		
This task covers:		
a. Removal	c. Follow-on Maintenance	
b. Installation		
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
M984E1	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 17-10.1	Boom removed.
None	Para 17-16.1	Lift cylinders removed.
<i>Special Tools</i>	Para 17-14.1	Erection cylinders removed.
None	Para 17-11.1	Mast removed.
<i>Supplies</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Personnel Required</i>	<i>General Safety Instructions</i>	
MOS 63W, Wheel vehicle repairer	None	
<i>References</i>	<i>Level of Maintenance</i>	
None	Direct Support	

a. Removal.



TA476456

- (1) Remove two screws (1), clamp (2), spacers (3), and hydraulic line (4) from turntable (5).
- (2) Repeat step (1) for other side.


NOTE

Mark position of screws, washers, and turntable.

- (3) Remove 12 screws (6) and washers (7).
- (4) Remove four screws (8) and washers (9).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (5) Attach suitable lifting device to turntable (5).
- (6) Remove turntable (5)




TA476457

- (7) Remove 23 screws (10) and washers (11)
- (8) Remove bearing (12) from subframe (13)



TA476458

- (9) Remove two dust seals (14) and grease fitting (15) from bearing (12).



TA476459

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-5.1. TURNTABLE AND BEARING REMOVAL/INSTALLATION (M984E1) (CONT).

b. Installation.

NOTE

Ridge end of seal is installed in bearing. Cut off excess seal.

- (1) Install two dust seals (1) and grease fitting (2) in bearing (3).




TA476460



NOTE

- Letter 'G' stamped on bearing faces down and centered on sub frame.
- Replace turntable bearing bolts with new bolts any time they are removed.

- (2) Aline and install bearing (3) on subframe (4).
- (3) Install 23 screws (5) and washers (6).



TA476461



TA476462

- (4) Aline and install turntable (7) on bearing (3).
- (5) Install 12 screws (8) and washers (9) in turntable (7).
- (6) Install four screws (10) and washers (11).
- (7) Install hydraulic line (12) with clamp (13), two spacers (14), and screws (15).
- (8) Repeat step (7) for other side.


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- c. *Follow-on Maintenance.*
 - (1) Install erection cylinders (para 17-14).
 - (2) Install lift cylinders (para 17-16.1).
 - (3) Install mast (para 17-11.1).
 - (4) Install boom (para 17-10.1).

END OF TASK

17-5.2. TURNTABLE STOP REMOVAL/INSTALLATION (M984E1).	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M984E1	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> <i>TM or Para</i> <i>Condition Description</i> Para 17-5.1 Turntable removed.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> None	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support

- a. *Removal.*
 - (1) Remove cotter pin (1) and pin (2).
 - (2) Remove pin (3) and stop (4).
- b. *Installation.*
 - (1) Install stop (4) and pin (3).
 - (2) Install pin (2) and cotter pin (1).
- c. *Follow-on Maintenance.*
Install turntable (para 17-5.1)



TA476463


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-6. SWING DRIVE VALVE REMOVAL/REPAIR/INSTALLATION.		
This task covers:		
a. Removal	d. Installation	
b. Disassembly	e. Follow-on Maintenance	
c. Assembly		
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
M977, M985	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 17-2	Swing drive valve hydraulic hoses and tubes removed.
None		
<i>Special Tools</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Supplies</i>	<i>General Safety Instructions</i>	
None	None	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheel vehicle repairer	Direct Support	
<i>References</i>		
None		


a. Removal.

- (1) Remove four screws (1) and lockwashers (2).
- (2) Remove valve (3) from motor (4).
- (3) Remove two preformed packings (5).




b. Disassembly.

- (1) Remove two relief valves (1), preformed packings (2), backup rings (3), and preformed packings (4) from valve (5).
- (2) Remove two fittings (6) and preformed packings (7) from valve (5).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3) Remove elbow (8) and preformed packing (9) from valve (5).
- (4) Remove two check valves (10), preformed packings (11), springs (12), valve seats (13), and preformed packings (14) from valve (5).




TA190310



TA190311

- (5) Remove two plugs (15), two plugs (16), and two plugs (17) from valve (5).

c. Assembly.




TA190312

- (1) Install two plugs (1), two plugs (2), and two plugs (3) in valve (4).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-6. SWING DRIVE VALVE REMOVAL/REPAIR/INSTALLATION (CONT).

- (2) Install two preformed packings (5), valve seats (6), springs (7), preformed packings (8), and check valves (9) in valve (4).
- (3) Install preformed packing (10) and elbow (11) in valve (4).



TA190313


- (4) Install two preformed packings (12) and fittings (13) in valve (4).
- (5) Install two preformed packings (14), backup rings (15), and preformed packings (16) in valve (4).
- (6) Install two relief valves (17) in valve (4).



TA190314

d. Installation.

- (1) Install two preformed packings (1) in motor (2).
- (2) Install valve (3) with four screws (4) and lockwashers (5).



TA190315

- e. Follow-on Maintenance.* Install swing drive valve hydraulic hoses and tubes (para 17-2).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-6.1. SWING DRIVE VALVE REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Para 17-2.1

Condition Description

Swing drive valve hydraulic hoses and tubes removed.

Special Environmental Conditions

None



General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal.




TA476464

- (1) Remove four screws (1) and lockwashers (2).
- (2) Remove valve (3) from motor (4).
- (3) Remove two preformed packings (5).

17-6.1. SWING DRIVE VALVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT):


b. Disassembly.

- (1) Remove two relief valves (1).
- (2) Remove two preformed packings (3), retainers (2), and preformed packings (4) from valve (1).
- (3) Remove two fittings (6) and preformed packings (7) from valve (5).




TA476465

- (4) Remove elbow (8) and preformed packing (9) from valve (5).
- (5) Remove two check valves (10), preformed packings (11), springs (12), valve seats (13), and preformed packings (14) from valve (5).



TA476466

- (6) Remove two plugs (14), two plugs (15), and two plugs (16) from valve (5).



TA47646

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in drv cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.


d. *Assembly.*

- (1) Apply compound and install two plugs (1), two plugs (2), and two plugs (3) in valve (4).



TA476468


- (2) Install two preformed packings (5), valve seats (6), springs (7), preformed packings (8), and check valves (9) in valve (4).
- (3) Install preformed packing (10) and elbow (11) in valve (4).



TA476469


17.6.1. SWING DRIVE VALVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT)

- (4) Install two preformed packings (12) and fittings (13) in valve (4).
- (5) Install two preformed packings (14), preformed packings (15), and retainers (16) on relief valves (17).
- (6) Install two relief valves (17) in valve (4).



TA476470

e. Installation.



TA476471

- (1) Install two preformed packings (1) in motor (2).
- (2) Install valve (3) with four screws (4) and lockwashers (5).


f. Follow-on Maintenance. Install swing drive valve hydraulic hoses and tubes (para 17-2.1).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-7. SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION.	
This task covers:	
a. Removal b. Disassembly c. Cleaning/Inspection	d. Assembly e. Installation f. Follow-on Maintenance
INITIAL SETUP	
Models M977, M985	Equipment Condition
Test Equipment None	TM or Para Para 17-6 Para 17-2
Special Tools None	Condition Description Swing drive valve body removed. Swing drive motor hydraulic hoses and tubes removed.
Supplies Compound, sealing and thread locking, Item 26, Appendix C Solvent, dry cleaning, Item 57, Appendix C	Special Environmental Conditions None
Personnel Required MOS 63W, Wheel vehicle repairer	General Safety Instructions None
References None	Level of Maintenance Direct Support

a. Removal.




- (1) Remove two screws (1) and lockwashers (2).
- (2) Remove motor (3) from brake (4).

17-7. SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (CONT).


b. Disassembly.

- (1) Remove tee fitting (1) and preformed packing (2).
- (2) Remove seven screws (3), six washers (4), and tag (5).
- (3) Remove end cap (6) and preformed packing (7) from gerotor (8).




TA189934

- (4) Remove gerotor (8) and preformed packing (9) from plate (10).
- (5) Remove star (11) from gerotor (8).




TA189935



TA189936


- (6) Remove plate (10) and preformed packing (12).
- (7) Remove bearing (13), shaft (14), and spring (15) from motor (16).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA189937

(8) Remove shaft (17), bearing (18), and thrust washer (19) from motor (16).



TA189938

(9) Remove six screws (20), lockwashers (21), flange cover (22), and preformed packing (23).
 (10) Remove shaft seal (24) and dust seal (25) from flange cover (22).

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.


17-7. SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (CONT).

d. Assembly.




TA189939

- (1) Install shaft seal (1) and dust seal (2) in flange cover (3).
- (2) Install preformed packing (4), flange cover (3), six lockwashers (5), and screws (6) in motor (7).



TA189940

- (3) Install bearing (8) and thrust washer (9) on shaft (10).




TA189941


- (4) Aline and install shaft (10) alining any open slot in shaft with timing hole in motor (7).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (5) Install spring (11), shaft (12), bearing (13), preformed packing (14), and plate (15).



TA189942



TA189943

- (6) Install star (16) in gerotor (17).
 (7) Install preformed packing (18).
 (8) Aline the most closed star tip in gerotor (17) with timing hole in motor (7).

NOTE

Gerotor may be rotated clockwise 1/2 turn to aline bolt holes.


- (9) Rotate gerotor (17) clockwise two teeth of shaft (12) and install.
 (10) Install preformed packing (19) and end plate (20).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (11) Apply sealing and thread locking compound to seven screws (21).
 (12) Install six washers (22), tag (23), and seven screws (21).

17-7. SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (CONT).



(13) Install preformed packing (24) and tee fitting (25) in end plate (20) on motor (7).



e. *Installation.* Install motor (1) with two lockwashers (2) and screws (3),

f. *Follow-on Maintenance.*

(1) Install swing drive valve body (para 17-6).

(2) Connect hydraulic hoses and tubes to swing drive motor (para 17-2).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-7.1 SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

Compound, sealing and thread locking, Item 26, Appendix C

Adhesive-sealant, silicone, Item 6, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Para 17-2.1

Condition Description

Swing drive motor hydraulic hoses and tubes removed.

Special Environmental Conditions

None



General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal.




- (1) Remove two screws (1) and lockwashers (2)
- (2) Remove motor (3) from brake (4).

17-7.1. SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).


b. Disassembly

NOTE

There are two models of swing drive motors. Model B has a back-up ring and no spacer on gear shaft. Model B motor is equal in size and functional performance and fully interchangeable with Model A. Some internal parts are also interchangeable. refer to TM 9-2320-279-24P for proper identification of parts.




- (1) Remove counterbalance valve (para 17-6.1).
- (2) Remove tee fitting (1) from elbow (2).
- (3) Remove elbow (2) and preformed packing (3) from end plate (4).
- (4) Remove seven screws (5), washers (6), end plate (4), and preformed packing (7) from gear assembly (8).
- (5) Remove gear assembly (8) and preformed packing (9) from plate (10).
- (6) Remove star (11) from gear assembly (8).



NOTE


Model B motor has no spacer. Skip step (7) for Model B.

- (7) Remove spacer (12) from gear shaft (14).
- (8) Remove plate (10), preformed packing (13), and gear shaft (14) from motor (15).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (9) Remove shouldered shaft (16) and thrust bearing (17) from motor (15).




- (10) Remove four screws (18), mounting flange (19), and preformed packing (20) from motor (15).

NOTE

Model B has a backup ring. Do step 11.1 for Model B.

- (11) Remove thrust washer (21), seal (22) and seal (23) from mounting flange (19).
- (11.1) Remove thrust washer (21), seal (22), back-up ring (22.1), and seal (23) from mounting flange (19).



c. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in drycleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

d. Assembly

NOTE


There are two models of swing drive motors. Model B has a backup ring and no spacer on gearshaft.

- (1) Install preformed packing (1) and plug (2) in motor (3).

NOTE


Model B has a backup ring. Do step (2.1) for Model B

- (2) Install seal (4) and seal (5), and thrust washer (6) in mounting flange (7).
- (2.1) Install backup ring (3.1), seal (4), seal (5) and thrust washer (6) in mounting flange (7).
- (3) Install preformed packing (8), mounting flange (7) and four screws (9) on motor (3).




17-7.1. SWING DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).


- (4) Install thrust bearing (10) on shouldered shaft (11).
- (5) Install shouldered shaft (11) in motor (3).



- (6) Install gear shaft (12), preformed packing (13), and plate spacer (14) on motor (3).
- (7) Align timing mark on gear shaft (12) with timing mark on shouldered shaft (11).



- (8) Install star (15) in gear assembly (16).
- (9) Install preformed packing (17), gear assembly (16) and align any star tip with timing mark on gear shaft (12).




NOTE

Model B has no spacer. Skip step (10) for Model B.


- (10) Install spacer (18) in motor (3).
- (11) Install preformed packing (19) and end plate (20).
- (12) Apply thread locking and sealing compound to seven screws (21).
- (13) Install seven washers (22) and screws (21).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476482

- (14) Install preformed packing (23), elbow (24) and tee fitting (25) in end cap (20).
- (15) Install counterbalance valve (para 17-6. 1).



TA476483

- e. *Installation.* Apply silicone and install motor (1) with two lockwashers (2) and screws (3).
- f. *Follow-on Maintenance.* Connect hydraulic hoses and tubes to swing drive motor (para 17-2.1).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-8. SWING DRIVE BRAKE REMOVAL/REPAIR/INSTALLATION.		
This task covers:		
a. Removal	d. Assembly	
b. Disassembly	e. Installation	
c. Cleaning/Inspection	f. Follow-on Maintenance	
INITIAL SETUP		
Models M977, M985	References None	
Test Equipment None	Equipment Condition	
Special Tools None	TM or Para Para 17-7 Para 17-2	Condition Description Swing drive motor removed. Swing drive brake hydraulic line removed.
Supplies Compound, sealing and thread locking, Item 26, Appendix C Adhesive-sealant, silicone, Item 6, Appendix C Compound, sealing, pipe thread, Item 29, Appendix C Solvent, dry cleaning, Item 57, Appendix C	Special Environmental Conditions None General Safety Instructions None	
Personnel Required MOS 63W, Wheel vehicle repairer	Level of Maintenance Direct Support	


a. Removal.

- (1) Remove four screws (1), washer (2), and two brackets (3) from brake (4).

NOTE

Disc and stators may drop down when brake is removed.


- (2) Remove brake (4) from swing drive unit (5).



TA189813

17-8. SWING DRIVE BRAKE REMOVAL/REPAIR/INSTALLATION (CONT).


- (3) Remove stator (6), disc (7), stator (8), and disc (7) from swing drive unit (5).



TA189814


b. Disassembly.

- (1) Remove elbow (1).
- (2) Remove piston head assembly (2) and six springs (3) from brake (4).



TA189815

- (3) Remove backup ring (5) and preformed packing (6) from head (2).
- (4) Remove head (2) from piston (7).
- (5) Remove backup ring (8) and preformed packing (9) from piston (7).
- (6) Remove backup ring (10) and preformed packing (11).



TA189816

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Inspect stator thickness. If stator is under 0.225 in. (5.71 mm), replace stator.
- (5) Inspect stator thickness. If stator is under 0.118 in. (2.99 mm), replace stator.
- (6) Inspect disc thickness. If disc is under 0.210 in. (5.33 mm), replace disc.
- (7) Inspect spring for length. If length is under 0.938 in. (23.8 mm), replace spring.

d. *Assembly.*

- (1) Install backup ring (1) and preformed packing (2) in piston (3).
- (2) Install head (4) on piston (3).
- (3) Install two preformed packings (5) and backup rings (6).



NOTE


On M985, leave one hole empty between every two springs.

- (4) Install piston head assembly (4) and six springs (7) in brake (8).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (5) Apply pipe thread sealing compound, and install elbow (9).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-8. SWING DRIVE BRAKE REMOVAL/REPAIR/INSTALLATION (CONT).

e. *Installation.*



TA189819

NOTE


Thick stator is installed first.

- (1) Install disc (1) inswing drive unit (2).
- (2) Install stator (3), disc (1), and stator (4).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (3) Apply adhesive-sealant to brake (5).
- (4) Aline and install brake (5).
- (5) Apply sealing and thread locking compound to four screws (6).
- (6) Install two brackets (7) with four screws (6) and washers (8).



TA189820

f. *Follow-on Maintenance.*


- (1) Install swing drive motor (para 17-7).
- (2) Install swing drive brake hydraulic line (para 17-2).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-8.1. SWING DRIVE BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1).		
This task covers:		
a. Removal	d. Assembly	
b. Disassembly	e. Installation	
c. Cleaning/Inspection	f. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
M984E1	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
None	<i>TW or Para</i>	<i>Condition Description</i>
<i>Special Tools</i>	Para 17-7.1	Swing drive motor removed.
None	Para 17-2.1	Swing drive brake hydraulic line removed.
<i>Supplies</i>	<i>Special Environmental Conditions</i>	
Compound sealing and thread locking, Item 26, Appendix C	None	
Adhesive sealant silicone, Item 5, Appendix C	<i>General Safety Instructions</i>	
Compound sealing pipe thread, Item 29, Appendix C	None	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheel vehicle repairer	Direct Support	

a. Removal.



NOTE

TA476484

Matchmark cylinder housing before removal.

(1) Remove four screws (1), washer (2), and two drive assembly stops (3) from cylinder housing (4).

CAUTION


Disc and stators may drop down when brake is removed.

(2) Remove cylinder housing (4) from end cover (5).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17.8.1. SWING DRIVE BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).


- (3) Remove stator (6), disc (7), stator (8), and disc (7) from end cover (5).



TA476485


b. Disassembly.

- (1) Remove elbow (1).
 (2) Remove piston assembly (2) and six springs (3) from cylinder housing (4).



TA476486

- (3) Remove packing retainer (5) and preformed packing (6) from piston (2).
 (4) Remove piston (2) from cylinder head (7).
 (5) Remove packing retainer (8) and preformed packing (9) from cylinder head (7).
 (6) Remove packing retainer (10) and preformed packing (11) from cylinder head (7).



TA476487

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Inspect inner stator for thickness. If stator is under 0.225 in. (5.71 mm), replace stator.
- (5) Inspect outer stator for thickness. If stator is under 0.118 in. (2.99 mm), replace stator.
- (6) Inspect disc thickness. If disc is under 0.210 in. (5.33 mm), replace disc.
- (7) Inspect spring for length. If length is under 0.938 in. (23.8 mm), replace spring.

d. *Assembly.*

- (1) Install packing retainer (1) and preformed packing (2) in cylinder head (3).
- (2) Install packing retainer (4) and preformed packing (5) on cylinder head (3).
- (3) Install piston brake (6) in cylinder head (3).
- (4) Install preformed packing (7) and packing retainer (8) on piston brake (6).




TA476488

NOTE

Leave one hole empty between every two springs.

- (5) Install piston brake (4) and six springs (9) in cylinder housing (10).
- (6) Apply pipe sealing compound, and install elbow (11).



TA476489


17-8.1 SWING DRIVE BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT)

e. Installation.

NOTE


Thick stator is installed first.

- (1) Install disc (1) in end cover (2).
- (2) Install stator (3), disc (1), and stator (4).



TA476490

- (3) Apply silicone sealant to brake (5).
- (4) Aline and install brake (5).
- (5) Apply thread locking compound to four screws (6).
- (6) Install two brackets (7) with four screws (6) and washers (8).



TA476491

f. Follow-on Maintenance. Install swing drive motor (para 17-7.1).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION.

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models
M977, M985

Personnel Required
MOS 63W, Wheel vehicle repairer (2)
MOS 44B, Metal worker repairer

Test Equipment
None

References
None

Special Tools
None

Equipment Condition
TM or Para *Condition Description*
Para 17-8 Swing drive brake removed.

Fabricated Tools
Spanner Socket, Appendix B, Figure 11

Supplies
Adhesive-sealant, silicone, Item 6, Appendix C
Compound, sealing and thread locking, Item 26, Appendix C
Compound, sealing, pipe thread, Item 29, Appendix C
Solvent, drycleaning, Item 57, Appendix C


Special Environmental Conditions
None

General Safety Instructions
None

Level of Maintenance
Direct Support

a. Removal.

- (1) Attach suitable lifting device.
- (2) Remove nine screws (1) and washers (2).
- (3) Remove swing drive (3).




WARNING

DO NOT grind or sand painted equipment without high-efficiency air purifying respirators in use.

NOTE

If new swing drive is to be used, wedges must be ground off and rewelded. If existing swing drive is to be repaired, wedges do not need to be removed.


- (4) Using a grinder to remove weld, remove two wedges (4) from frame ring (5).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (CONT).

b. Disassembly.



- (1) Remove two plugs (1). Drain oil in suitable container.
- (2) Remove cap (2), pipe (3), elbow (4), and pipe (6) from swing drive (6).




NOTE

Amount of shims required may vary from one swing drive to another.

- (3) Remove 16 screws (7) and lockwashers (8).
- (4) Remove end cover (9) and shims (10).
- (5) Remove oil seal (11) from end cover (9).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (6) Remove race (12), bearing (13), race (14), and spacer (15).
- (7) Remove sun gear (16) and preformed packing (17) from swing drive (6).




NOTE

- M985 has two planetary assemblies. M977 has one.
- Steps (8) through (16) are for M985 only.
 - (8) Remove planetary assembly (18) from swing drive (6).




- (9) Drive roll pin (19) into pin (20).
- (10) Remove pin (20), gear (21), and two spacers (22).
- (11) Remove roll pin (19) from pin (20).
- (12) Remove bearing (23) from gear (21).
- (13) Repeat steps (9) through (12) for other two assemblies.
- (14) Remove center spacer (24) from carrier (25).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (CONT).


- (15) Remove race (26), bearing (27), and race (28).
- (16) Remove secondary sun gear (29).



- (17) Remove planetary assembly (30) from swing drive (6).



- (18) Drive roll pin (31) into pin (32).
- (19) Remove pin (32), gear (33), and two spacers (34).
- (20) Remove roll pin (31) from pin (32).
- (21) Remove bearing (35) from gear (33).
- (22) Repeat steps (18) through (21) for other two assemblies.
- (23) Remove center spacer (36) from carrier (37).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


NOTE

Matchmark ring gear and hub.


(24) Remove ring gear (38) and preformed packing (39) from hub (40).



(25) Bend down tang of lockwasher (41).
 (26) Remove nut (42) with spanner socket and lockwasher (41).




(27) Remove two screws (43), plate (44), gear (45), and spacer (46) from hub (40).



17.9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (CONT.)

- (28) Remove seal (47), shaft (48), and bearing (49) from hub (40).
- (29) Remove bearing (49) from shaft (48).




- (30) Remove bearing (50) from hub (40).
- (31) Remove two races (51).

c. *Cleaning/Inspection.*

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.




d. *Assembly.*


- (1) Install two races (1) in hub (2).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)




- (2) Install bearing (3) on shaft (4).
- (3) Install shaft (4) and bearing (3) in hub (2).
- (4) Install seal (5) in hub (2).



- (5) Install bearing (6).
- (6) Install lockwasher (7) and nut (8).
- (7) Tighten nut (8) until shaft (4) starts to turn.
- (8) Hold shaft (4) and tighten nut (8) until one tang on lockwasher (7) aligns with slot in nut (8).
- (9) Bend tang of lockwasher (7) up in slot of nut (8).

17-9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (CONT).




(10) Install spacer (9), gear (10), and plate (11) on hub (2).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(11) Apply sealing and thread locking compound and install two screws (12).




(12) Apply adhesive-sealant and install preformed packing (13).

(13) Install ring gear (14).


M977, M98S, and M984E1 Crane Maintenance Instructions (Cont)

- (14) Install bearing (15) in gear (16).
- (15) Install gear (16), two spacers (17), with pin (18), and roll pin (19).
- (16) Repeat steps (14) and (15) for other two assemblies.
- (17) Install center spacer (20).



TA190257


- (18) Install planetary assembly (21) in swing drive (22).



TA190258

NOTE

- M985 uses two planetary assemblies. M977 uses only one.
- Steps (19) through (24) are for M985 only.
- (19) Install sun gear (23), race (24), bearing (25), and race (26).




TA190259

17-9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (CONT).


- (20) Install bearing (27) in gear (28).
- (21) Install gear (28) and two spacers (29), with pin (30), and roll pin (31).
- (22) Repeat steps (20) and (21) for other two assemblies.
- (23) Install center spacer (32).

(M985 ONLY)



- (24) Install planetary assembly (33) in swing drive (22).

(M985 ONLY)



WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (25) Apply silicone adhesive-sealant and install preformed packing (34).


NOTE

Install thin race first.

- (26) Install race (35), bearing (36), and race (37).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



(27) Install end cover (38) loosely.

NOTE

Movement is checked through hole in end cover.

(28) Check for free movement by raising planetary assembly up and down.


(29) If no movement is felt, install shims in progressions of 0.002 in. (0.06 mm) until movement is felt.

(30) Remove end cover (38) and install oil seal (39).

(31) Install sun gear (40) and spacer (41).

(32) Install end cover (38).

(33) Apply sealing and thread locking compound and install 16 lockwashers (42) and screws (43).




(34) Apply pipe thread sealing compound and install two plugs (44).

(35) Apply pipe thread sealing compound and install pipe (45), elbow (46), pipe (47), and cap (48).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (CONT).

e. Installation.



- (1) Align swing drive (1).
- (2) Adjust swing drive (1) backlash to 0.005 in. (0.127 mm).

NOTE

If wedges were not removed, go to step (8).

- (3) Install two screws (2) and washers (3). Tighten screws. Do not remove lifting device.

CAUTION

Disconnect battery cables and electrical connectors from all sensitive electrical components prior to electric welding. Electrical current from welder may cause damage to equipment.

- (4) Disconnect battery cables and electrical connectors from all electrical equipment.

WARNING

Unsafe welding practices can cause serious injury from fire, explosions, or harmful agents. Allow only authorized personnel to weld or cut metals and follow safety precautions in TM 9-237. Protective clothing and goggles must be worn; adequate protective equipment used, a suitable fire extinguisher kept nearby, and requirements of TM 9-237 strictly followed.

- (5) With the aid of a welder, tack-weld two wedges (4) to frame ring (5).
- (6) Remove two screws (2), washers (3), and swing drive (1).
- (7) With the aid of a welder, weld two wedges (4) to frame ring (5).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (8) Apply sealing and thread locking compound to nine screws (2).
- (9) Install swing drive (1) with nine screws (2) and washers (3).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE

Skip step (10) if wedges were not welded.

(10) Reconnect electrical connectors and battery cables.

f. Follow-on Maintenance.

- (1) Install swing drive brake (para 17-8).
- (2) Fill swing drive with oil (LO 9-2320-279-12).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9.1. SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Personnel Required

MOS 63W, Wheel vehicle repairer (2)
MOS 44B, Metal worker repairer

Test Equipment

None

References

None

Special Tools

None

Equipment Condition

<i>TM or Pam</i>	<i>Condition Description</i>
Para 17-8.1	Swing drive brake removed.
TM 9-2320-279-20	No. 4 left air brake lines removed.
TM 9-2320-279-20	Left gladhand bracket removed.

Fabricated Tools

Spanner Socket, Appendix B, Figure 11

Supplies

Adhesive-sealant, silicone, Item 5, Appendix C
Compound, sealing and thread locking, Item 26, Appendix C
Compound, sealing, pipe thread, Item 29, Appendix C
Solvent, drycleaning, Item 57, Appendix C

Special Environmental Conditions

None

General Safety Instructions


None

Level of Maintenance

Direct Support

a. Removal.

- (1) Attach suitable lifting device.
- (2) Remove nine screws (1) and washers (2).
- (3) Remove swing drive (3).




WARNING

DO NOT grind or sand painted equipment without high-efficiency air purifying respirators in use.

NOTE



If new swing drive is to be used, wedges must be ground off and rewelded. If existing swing drive is to be repaired, wedges do not need to be removed.

- (4) Using a grinder to remove weld, remove two wedges (4) from frame rings (5).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9.1 SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).



b. Disassembly.

- (1) Remove two plugs (1) and drain oil in suitable container.
- (2) Remove cap (2), pipe (3), elbow (4), and pipe (5) from swing drive (6).
- (3) Remove 16 screws (7) and lockwashers (8).


NOTE

Amount of shims may vary from swing drive to swing drive.


- (4) Remove end cover (9) and shims (10).
- (5) Remove oil seal (11) from end cover (9).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (6) Remove race (12), bearing (13), race (14), and spacer (15).
- (7) Remove sun gear (16) and preformed packing (17) from swing drive (6).



- (8) Remove planetary assembly (18) from swing drive (6).




- (9) Drive roll pin (19) into pin (20).
- (10) Remove pin (20), gear (21) and two spacers (22).
- (11) Remove roll pin (19) from pin (20).
- (12) Remove bearing (23) from gear (21).
- (13) Repeat steps (9) thru (13) for other two assemblies.
- (14) Remove center spacer (24) from carrier (25).




M977, M995, and M984E1 Crane Maintenance Instructions (Cont)

17-9.1 SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).


- (15) Remove race (26), bearing (27), and race (28).
- (16) Remove secondary sun gear (29).



- (17) Remove planetary assembly (30) from swing drive (6).



- (18) Drive roll pin (31) into pin (32).
- (19) Remove pin (32), gear (33), and two spacers (34).
- (20) Remove roll pin (31) from pin (32).
- (21) Remove bearing (35) from gear (33).
- (22) Repeat steps (18) thru (21) for other two assemblies.
- (23) Remove center spacer (36) from planetary assembly (30).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


NOTE

Matchmark ring gear with hub.


- (24) Remove ring gear (37) and preformed packing (38) from hub (39).



- (25) Bend down tang of lockwasher (40).
- (26) Remove nut (41) with spanner socket and lockwasher (40).




- (27) Remove two screws (42), plate (43), gear (44), and spacer (45) from hub (39).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9.1 SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (28) Remove seal (46), shaft (47) and bearing (48) from hub (39).
- (29) Remove bearing (48) from shaft (47).



- (30) Remove bearing (49) from hub (39).
- (31) Remove two races (50).



c. Cleaning/Inspection.


WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
 - Compressed air used for cleaning purposes will not exceed 30 psi. Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc.).
- (1) Clean all metal parts in drycleaning solvent.
 - (2) Inspect each part for damage.
 - (3) Replace damaged parts.


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

d. Assembly.


(1) Install two races (1) in hub (2).




(2) Install bearing (3) on shaft (4).
 (3) Install shaft (4) and bearing (3) in hub (2).
 (4) Install seal (5) in hub (2).



(5) Install bearing (6).
 (6) Install lockwasher (7) and nut (8).
 (7) Tighten nut (8) until shaft (4) starts to turn.
 (8) Hold shaft (4) and tighten nut (8) to 100 lb-ft (135.6 N•m) and align one tang on lockwasher (7) with slot in nut (8).
 (9) Bend tang of lockwasher (7) up in slot of nut (8).




(10) Install spacer (9), gear (10), and plate (11) on hub (2).
 (11) Apply thread locking and sealing compound and install two screws (12).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9.1 SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).


- (12) Apply adhesive sealant and install preformed packing (13).
- (13) Install ring gear (14).



- (14) Install bearing (15) in gear (16).
- (15) Install gear (16) and two spacers (17) with pin (18) and roll pin (19).
- (16) Install center spacer (20).
- (17) Repeat steps (14) and (15) for other two assemblies.



- (18) Install planetary assembly (21) in swing drive (22).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


NOTE

Install thicker race first.


- (19) Install secondary sun gear (23), race (24), bearing (25), and race (26).



- (20) Install bearing (27) in gear (28).
- (21) Install gear (28) and two spacers (29) with pin (30) and roll pin (31).
- (22) Install center spacer (32).
- (23) Repeat steps (20) and (21) for other two assemblies.




- (24) Install planetary assembly (33) in swing drive (22).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-9.1 SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (25) Apply adhesive sealant and install preformed packing (34).
- (26) Install race (35), bearing (36), and race (35).




- (27) Install end cover (37) loosely.


NOTE

Movement is checked through hole in end cover.


- (28) Check for free movement by raising planetary assembly up and down.
- (29) If no movement is felt, install shims in progression of 0.002 in. (0.0005 mm) until movement is felt.
- (30) Remove end cover (37) and install oil seal (38).
- (31) Install sun gear (39) and spacer (40).
- (32) Install end cover (37).
- (33) Apply thread locking and sealing compound and install 16 lockwashers (41) and screws (42).



- (34) Apply pipe thread sealing compound and install two plugs (43).
- (35) Apply pipe thread and sealing compound and install pipe (44), elbow (45), pipe (46), and cap (47).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

e. *Installation.*

- (1) Aline swing drive (1).
- (2) Adjust swing drive (1) backlash to 0.005 in. (0.127 mm).

NOTE

If wedges were not removed, go to step (8).

- (3) Install two screws (2) and washers (3). Tighten screws. Do not remove lifting device.

CAUTION

Disconnect battery cables and electrical connectors from all sensitive electrical components prior to electric welding. Electrical current from welder may cause damage to equipment.

- (4) Disconnect battery cables and electrical connectors from all electrical equipment.

WARNING

Unsafe welding practices can cause serious injury from fire, explosions, or harmful agents. Allow only authorized personnel to weld or cut metals and follow safety precautions in TM 9-237. Protective clothing and goggles must be worn; adequate protective equipment used, a suitable fire extinguisher kept nearby, and requirements of TM 9-237 strictly followed.

- (5) With the aid of a welder, tack weld two wedges (4) to frame ring (5).
- (6) Remove two screws (2), washers (3), and swing drive (1).
- (7) With the aid of a welder, weld two wedges (4) to frame ring (5).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (8) Apply sealing and thread locking compound to nine screws (2).
- (9) Install swing drive (1) with nine screws (2) and washers (3).

M977, M985, and M984E1 Crane Maintenance instructions (Cont)

17-9.1 SWING DRIVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

NOTE

Skip step (10) if wedges were not welded.

(10) Reconnect electrical connectors and battery cables.

f. follow-on Maintenance.


- (1) Install swing drive brake (para 17-8).
- (2) Fill swing drive with oil (LO 9-2320-279-12).

Section III. BOOM, MAST, AND EXTENSIONS

17-10. BOOM REMOVAL/INSTALLATION.	
This task covers:	
<ul style="list-style-type: none"> a. Removal b. Cleaning/Inspection 	<ul style="list-style-type: none"> c. Installation d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i>
<i>Special Tools</i> None	<i>TM or Para</i> <i>Condition Description</i>
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Solvent, drycleaning, Item 57, Appendix C Ties, cable, plastic, Item 65, Appendix C Tags, identification, Item 60, Appendix C	TM 9-2320-279-10 Shut off engine. TM 9-2320-279-20 Overload protection switches disconnected (M977 only).
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)	<i>Special Environmental Conditions</i> None <i>General Safety Instructions</i> None <i>Level of Maintenance</i> Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Removal.




NOTE

- Remove plastic cable ties and clamps.
- Tag and mark wires and hydraulic lines before removal.

(1) Disconnect three wires (1) and remove from boom (2).


(2) Disconnect two hydraulic lines (3).



WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.


(3) Attach suitable lifting device to boom (2).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-10. BOOM REMOVAL/INSTALLATION (CONT).

- (4) Remove four screws (4), washers (5), locking pins (6), and bushings (7).




TA190881

- (5) Remove two pins (8) and pin (9).



TA190882

- (6) Disconnect hydraulic line (10).
- (7) Remove screw (11), spacer (12), and two clamp halves (13). Pull line (10) from boom (2).



TA190883

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (8) Raise boom (2) enough to remove two hydraulic lines (14).
- (9) Remove boom (2).

b. Cleaning/Inspection.


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

c. Installation.

- (1) Attach suitable lifting device and install boom (1).




TA190884



TA190885

- (2) Soldier A operates lifting device and lowers boom (1) enough to connect two hydraulic lines (2) while Soldier B connects lines.




TA190886

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-10. BOOM REMOVAL/INSTALLATION (CONT).

- (3) Soldier A operates lifting device while Soldier B aligns and installs two pins (3) and pin (4).




TA190887

- (4) Install four locking pins (5), bushings (6), and washers (7).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (5) Apply thread locking and sealing compound and install screws (8).
- (6) Connect hydraulic line (9).
- (7) Install clamp halves (10) with screw (11) and spacer (12).




TA190888




TA190889

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



(8) Connect two hydraulic lines (13).



NOTE

Install plastic cable ties and clamps as necessary.

(9) Connect three wires (14).


d. Follow-on Maintenance. Connect overload protection switches (M977 only) (TM 9-2320-279-20).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-10.1. BOOM REMOVAL/INSTALLATION (M984E1).	
This task covers:	
a. Removal	c. Installation
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>Equipment Condition</i>
M984E1	<i>TM or Para</i> <i>Condition Description</i>
<i>Test Equipment</i>	TM9-2320-279-10 Outrigger extended.
None	Para 6-12.1 Overload sensor switches disconnected.
<i>Special Tools</i>	TM 9-2320-279-10 Hook block released.
None	TM 9-2320-279-10 Raise boom 15°.
<i>Supplies</i>	<i>Special Environmental Conditions</i>
Compound, sealing and thread locking, Item 26, Appendix C	None
<i>Personnel Required</i>	<i>General Safety Instructions</i>
MOS 63W, Wheel vehicle repairer (2)	None
<i>References</i>	<i>Level of Maintenance</i>
None	Direct Support


a. Removal.



TA476867


- (1) Attach suitable lifting device to boom (1).
- (2) Disconnect hydraulic hose (2) from line (3).
- (3) Remove two screws (4), spacers (5), and four clamp halves (6).
- (4) Move line (3) to clear cylinder (7).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476868

- (5) Disconnect four hydraulic lines (8).
- (6) Remove two screws (9), washers (10), lockpins (11), and spacers (12).
- (7) Repeat step (6) for other side.
- (8) Remove two pins (13) and pin (14).




TA476869

- (9) Soldier A and Soldier B remove boom (1) from crane (15).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-10.1. BOOM REMOVAL/INSTALLATION (M984E1) (CONT).

b. Installation.



TA476870


(1) Soldier A and Soldier B position boom (1) on crane (2).



TA476871

- (2) Soldier A align while Soldier B installs two pins (3) and pin (4).
- (3) Install two lockpins (5) and spacers (6).
- (4) Apply sealing and thread locking compound and install two washers (7) and screws (8).
- (5) Repeat steps (3) and (4) for other side.
- (6) Attach four hoses (9).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



- (7) Connect hydraulic hose (10) to line (11).
- (8) Install four clamp halves (12) with two spacers (13) and screws (14).

c. Follow-on Maintenance.

- (1) Install overload protection switches (TM 9-2320-279-20).
- (2) Crane in stowed position (TM 9-2320-279-10).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-11. MAST AND BUSHINGS REMOVAL/INSTALLATION.	
This task covers:	
a. Removal	c. Installation
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> TM or Para Condition Description Para 17-10 Boom removed.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Solvent, dry cleaning, Item 57, Appendix C Ties, cable, plastic, Item 65, Appendix C	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)	<i>Level of Maintenance</i> Direct Support


a. Removal.

- (1) Attach suitable lifting device and raise mast (1).
- (2) Disconnect four hydraulic lines (2).

NOTE

Remove plastic cable ties as necessary.

- (3) Remove two screws (3), clamps (4), and spacers (5).
- (4) Remove nut (6), washer (7), and clamp (8).




TA189903

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (5) Remove screw (9), washer (10), spacer (11), and lockpin (12).
- (6) Repeat step (5) for other side.
- (7) Remove pin (13) enough to clear mast (1).
- (8) Remove mast (1).




- (9) Remove four grease fittings (14).
- (10) Remove four bushings (15) from mast (1).

b. Cleaning/Inspection.

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check bushing inside diameter. If diameter is larger than 2.015 in. (51.18 mm), replace bushing.



c. Installation.

- (1) Install four bushings (1) in mast (2).
- (2) Install four grease fittings (3).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-11. MAST AND BUSHINGS REMOVAL/INSTALLATION (CONT).


(3) Soldier A operates lifting device while Soldier B aligns and installs mast (2) and installs pin (4) through mast (2).

(4) Install two lockpins (5) and spacers (6).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(5) Apply sealing and thread locking compound and install screw (7) and washer (8).



(6) Install clamp (9), washer (10), and nut (11).


(7) Install two spacers (12), clamps (13), and screws (14).

(8) Install four hydraulic lines (15).

(9) Lower mast (2) and remove suitable lifting device.

d. Follow-on Maintenance. Install boom (para 17-10).

END OF TASK



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-11.1 MAST AND BUSHINGS REMOVAL/INSTALLATION (M984E1).



This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | c. Installation |
| b. Cleaning/Inspection | d. Follow-on Maintenance |

INITIAL SETUP

Models	Equipment Condition	
M984E1	TM or Para	Condition Description
Test Equipment	Para 17-10.1	Boom removed.
None	Para 17-14.1	Erection cylinder disconnected.
Special Tools	Special Environmental Conditions	
None	None	
Supplies	General Safety Instructions	
Compound, sealing and thread locking, Item 26, Appendix C	None	
Personnel Required	Level of Maintenance	
MOS 63W, Wheel vehicle repairer	Direct Support	
References		
None		

a. Removal.



TA476874

- (1) Attach suitable lifting device to mast (1).
- (2) Raise mast (1).

NOTE


Remove all ties as necessary

- (3) Disconnect four hydraulic lines (2).
- (4) Remove two screws (3), clamps (4) and pull hose (5) clear of mast (1).
- (5) Remove screw (6), washer (7), spacer (8), and lockpin (9).
- (6) Remove pin (10) and mast (1) from crane (11).

17-11.1. MAST AND BUSHINGS REMOVAL/INSTALLATION (M984E1) (CONT).

- (7) Remove four grease fittings (12).
- (8) Remove two bushings (13) from mast (1).

b. *Cleaning/Inspection.*



TA476875


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.



- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check bushing inside diameter. If diameter is larger than 2.015 in. (50.82 mm), replace bushing.

c. *Installation.*

- (1) Install two bushings (1) in mast (2).
- (2) Install four grease fittings (3).



TA476876



TA476878

- (3) Align and install mast (2) on crane (4).
- (4) Install pin (5), lockpin (6), and spacer (7).
- (5) Apply thread locking compound and install washer (8) and screw (9).
- (6) Connect four hydraulic lines (10).
- (7) Install hose (11) with two clamps (12) and screws (13).
- (8) Lower mast (2).

d. *Follow-on Maintenance.*


- (1) Connect erection cylinder (para 17-10.1).
- (2) Install boom (para 17-14.1).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-12. EXTENSION NO. 1 AND WEAR PADS REMOVAL/INSTALLATION.	
This task covers:	
a. Removal	c. Installation
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>References</i>
M977, M985	None
<i>Test Equipment</i>	<i>Equipment Condition</i>
None	<i>TM or Para</i> <i>Condition Description</i>
<i>Special Tools</i>	TM 9-2320-279-20 Hoist cable removed.
None	TM 9-2320-279-10 Extension No. 1 extended.
<i>Supplies</i>	<i>Special Environmental Conditions</i>
Compound, sealing and thread locking, Item 26, Appendix C	None
Solvent, dry cleaning, Item 57, Appendix C	<i>General Safety Instructions</i>
<i>Personnel Required</i>	None
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>
	Direct Support

a. Removal.



TA191031


- (1) Remove four cotter pins (1) and two pins (2).
- (2) Remove two screws (3) and stop (4).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-12. EXTENSION NO. 1 AND WEAR PADS REMOVAL/INSTALLATION (CONT).

(3) Raise extension No. 1 and remove two wear pads (5) from extension No. 2 (6).

(EXTENSION NO. 1 REMOVED FOR CLARITY)




TA191030

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

(4) Attach suitable lifting device and remove extension No. 1 (7) from extension No. 2 (6).



TA190448


(5) Remove two screws (8) and wear pads (9).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Inspect wear pad thickness. If wear pad is under 0.250 in. (6.35 mm) replace pad.



TA190449

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


c. Installation.

(1) Install two wear pads (1).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(2) Apply sealing and thread locking compound and install two screws (2).




TA190450



TA190451

(3) Attach suitable lifting device and install extension No. 1 (3) in extension No. 2 (4).




TA190452

(4) Aline holes and install two pins (5) and four cotter pins (6).


17-12. EXTENSION NO. 1 AND WEAR PADS REMOVAL/INSTALLATION (CONT).

(EXTENSION NO. 1 REMOVED FOR CLARITY)



TA190453

(5) Raise extension No. 1 and install two wear pads (7) in extension No. 2 (4).



TA190454

(6) Install stop (8) and two screws (9).

d. *Follow-on Maintenance.*

(1) Retract extensions (TM 9-2320-279-10).

(2) Telescope boom out and in (TM 9-2320-279-10).

(3) Install hoist cable (TM 9-2320-279-20).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Section IV. BOOM MAINTENANCE

17-12.1. EXTENSION ONE AND WEAR PADS REMOVAL/INSTALLATION (M984E1).

This task covers:

- a. Removal
- b. Cleaning/Inspection
- c. Installation
- d. Follow-on Maintenance

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

Compound, sealing and thread locking,
Item 26, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer (2)

References

None

Equipment Condition

TM or Para	Condition Description
TM 9-2320-279-20	Hoist cable removed.
TM 9-2320-279-10	Extension one extended.

Special Environmental Conditions

None



General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal.



TA476879


- (1) Remove four cotter pins (1) and two pins (2).
- (2) Remove nut (3) and setscrew (4).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-12.1. EXTENSION ONE AND WEAR PADS REMOVAL/INSTALLATION (M984E1) (CONT).

(3) Raise extension one and remove two wear pads (5) from extension two (6).

EXTENSION ONE REMOVED FOR CLARITY




TA476880

WARNING


Keep out from under heavy parts. Falling parts may cause serious injury or death.

(4) Soldier A and Soldier B attach suitable lifting device and remove extension one (7) from extension two (6).



TA476881

(5) Remove two screws (8) and wear pads (9).



TA476882

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


b. *Cleaning/Inspection.***WARNING**

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Inspect wear pad thickness. If wear pad is under 0.250 in. (6.35 mm) replace pad.


c. *Installation.*

- (1) Install two wear pads (1).
- (2) Apply sealing and thread locking compound and install two screws (2).




TA476883

- (3) Soldier A and Soldier B attach suitable lifting device and install extension one (3) in extension two (4).




TA476884

17-12.1. EXTENSION ONE AND WEAR PADS REMOVAL/INSTALLATION (M984E1) (CONT).



TA476885

- (4) Aline holes and install two pins (5) and four cotter pins (6).
- (5) Raise extension one and install two wear pads (7) in extension two (4).




- (6) Install setscrew (8) and nut (9).
 - (7) Adjust setscrew 1/8 in. (3.17 mm) from extension no. one.
- d. Follow-on Maintenance.**
- (1) Return extensions (TM 9-2320-279-10).
 - (2) Install hoist cable (TM 9-2320-279-10).
 - (3) Telescope boom out and in (TM 9-2320-279-10).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-13. EXTENSION NO. 2 AND WEAR PADS REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Cleaning/Inspection	c. Installation d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i>
<i>Special Tools</i> None	<i>TM or Para</i> <i>Condition Description</i> Para 17-12 Extension No. 1 removed.
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Solvent, dry cleaning, Item 57, Appendix C	<i>Special Environmental Conditions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)	<i>General Safety Instructions</i> None
	<i>Level of Maintenance</i> Direct Support

a. Removal.




TA189910

(1) Remove four nuts (1), lockwashers (2), and cover (3).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-13. EXTENSION NO. 2 AND WEAR PADS REMOVAL/INSTALLATION (CONT).

- (2) Disconnect two hydraulic lines (4).
- (3) Remove four screws (5) and washers (6).




- (4) Remove two screws (7), stop (8), and spacer (9).




- (5) Raise extension No. 2 and remove two wear pads (10) from boom (11).

(EXTENSION NO. 2 REMOVED FOR CLARITY)



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)




TA189909

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (6) Attach suitable lifting device and remove extension No. 2 (12).
- (7) Remove two screws (13) and wear pads (14).



TA189913

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check wear pad thickness. If wear pad is below 0.250 in. (6.35 mm) replace wear pads.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-13. EXTENSION NO. 2 AND WEAR PADS REMOVAL/INSTALLATION (CONT).


c. *Installation.*

(1) Install two wear pads (1).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


(2) Apply sealing and thread locking compound and install two screws (2).



TA189914

(3) Attach suitable lifting device around extension No. 2 (3).


(4) Install extension No. 2 (3) in boom (4).



TA189915

(5) Raise extension No. 2 and install two wear pads (5) in boom (4).


(EXTENSION NO. 2 REMOVED FOR CLARITY)



TA189916


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

(6) Install spacer (6), stop (7), and two screws (8).



TA189917

(7) Install four washers (9) and screws (10).
 (8) Connect two hydraulic lines (11).




TA189918

(9) Install cover (12), lockwashers (13), and four nuts (14).

d. *Follow-on Maintenance.* Install extension No. 1 (para 17-12).

END OF TASK




TA189919

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-13.1. EXTENSION TWO AND WEAR PADS REMOVAL/INSTALLATION (M984E1).		
This task covers:		
a. Removal	c. Installation	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models	References	
M984E1	None	
Test Equipment	Equipment Condition	
None	TM or Para	Condition Description
Special Tools	Para 17-12.1	Extension one removed.
None	Special Environmental Conditions	
Supplies	None	
Compound, sealing and thread locking, Item 26, Appendix C	General Safety Instructions	
Personnel Required	None	
MOS 63W, Wheel vehicle repairer (2)	Level of Maintenance	
	Direct Support	

a. Removal.




TA476887

- (1) Remove four nuts (1), lockwashers (2), and cover (3).
- (2) Disconnect two hydraulic lines (4).
- (3) Remove four screws (5) and washers (6).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

(4) Remove setscrew (7) and nut (8) from boom (9).




TA476888

WARNING

Do not use fingers to remove wear pads. Personal injury may incur.

(5) Raise extension two and remove two wear pads (10) from boom (9).




**EXTENSION TWO
REMOVED
FOR CLARITY**

TA476889

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

(6) Soldier A and Soldier B attach a suitable lifting device to extension two (11). Soldier A operates lifting device while Soldier B guides extension two from boom (9).



TA476890

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-13.1. EXTENSION TWO AND WEAR PADS REMOVAL/INSTALLATION (M984E1) (CONT).

(7) Remove two screws (12) and wear pads (13) from extension two (11).

b. *Cleaning Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check wear pad thickness. If wear pad is below 0.250 in. (6.35 mm), replace wear pads.

c. *Installation.*

(1) Apply thread locking compound to screws (1) and install two wear pads (2) on extension two (3).




TA476891



TA476892

(2) Install extension two (3) in boom (4).




TA476893

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

WARNING

Do not use fingers to install wear pads. Personal injury may incur.


- (3) Install two wear pads (5) in boom (4).



**EXTENSION TWO
REMOVED
FOR CLARITY**


TA476894

- (4) Install setscrew (6) and nut (7) in boom (4).
- (5) Adjust setscrew (6) until 1/8 in. (3.17 mm) clearance between setscrew and extension two.
- (6) Tighten nut (7).



TA476895

- (7) Install four washers (8) and screws (9).
- (8) Connect two hydraulic lines (10).
- (9) Install cover (11) with four lockwashers (12) and nuts (13).



TA476896

d. *Follow-on Maintenance.* Install extension one (para 17-12.1).


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Section IV. CYLINDERS

17-14. ERECTION CYLINDER REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Cleaning/Inspection	c. Installation d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i>
<i>Test Equipment</i> None	TM 9-2320-279-10 Crane in operating condition, extensions 1 and 2 fully extended and lowered to the ground.
<i>Special Tools</i> None	TM 9-2320-279-10 Shut off engine.
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Solvent, dry cleaning, Item 57, Appendix C Tags, identification, Item 60, Appendix C	TM 9-2320-279-10 Cargo body rear panel removed.
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)	<i>Special Environmental Conditions</i> None
<i>References</i> None	<i>General Safety Instructions</i> None
	<i>Level of Maintenance</i> Direct Support

a. Removal.



TA189897


NOTE

- Right and left cylinders are removed the same way. Left cylinder has two lines and two plugs instead of four lines.
- Tag and mark lines before disconnecting.



(1) Disconnect four hydraulic lines (1) from cylinder (2).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (2) Remove screw (3), washer (4), spacer (5), and lockpin (6).
- (3) Repeat step (2) for other side.
- (4) Drive pin (7) in far enough to clear cylinder (2).
- (5) Lower end of cylinder (2).



- (6) Remove screw (8), washer (9), spacer (10), and lockpin (11).
- (7) Soldier A removes pin (12) while Soldier B holds and removes cylinder (2).



NOTE

Left cylinder does not have tee fitting.

- (8) Remove tee fitting (13) and preformed packing (14).
- (9) Remove two elbows (15) and preformed packings (16).
- (10) Remove two grease fittings (17) from each end of cylinder (2).

17-14. ERECTION CYLINDER REMOVAL/INSTALLATION (CONT).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

c. Installation.

NOTE

Right and left cylinders are installed the same way. Left cylinder does not have tee fitting.

- (1) Install two grease fittings (1) on each end of cylinder (2).
- (2) Install preformed packing (3) and tee fitting (4).
- (3) Install two preformed packings (5) and elbows (6).




TA357194

- (4) Soldier A aligns and installs cylinder (2) while Soldier B installs pin (7), lockpin (8), and bushing (9).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA189900

- (5) Apply sealing and thread locking compound and install screw (10) and washer (11).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



- (6) Aline cylinder (2).
- (7) Drive pin (12) through cylinder (2).
- (8) Install lockpin (13) and spacer (14).
- (9) Apply sealing and thread locking compound and install screw (15) and washer (16).
- (10) Repeat steps (8) and (9) for other side.



- (11) Connect four hydraulic lines (17).



d. *Follow-on Maintenance.* Install cargo body rear panel (TM 9-2320-279-10).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-14.1. ERECTION CYLINDER REMOVAL/INSTALLATION (M984E1).	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
Models M984E1	Equipment Condition
Test Equipment None	TM or Para TM 9-2320-279-10
Special Tools None	Condition Description Crane in operating condition extensions 1 and 2 fully extended and lowered to ground. TM 9-2320-279-10 Shut off engine.
Supplies Compound, sealing and thread locking, Item 26, Appendix C	Special Environmental Conditions None
Personnel Required MOS 63W, Wheel vehicle repairer (2)	General Safety Instructions None
References None	Level of Maintenance Direct Support

a. Removal.



TA476897


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (1) Remove screw (1), washer (2), spacer (3), and lockpin (4).
- (2) Repeat step (1) for other side.

NOTE


Pin must be driven from right to left side.

- (3) Drive pin (5) in far enough to clear cylinder (6).
- Disconnect two hydraulic lines (7).
- (5) Remove elbow (8) and preformed packing (9).
- (6) Remove elbow (10) and preformed packing (11).
- (7) Remove plug (12) and preformed packing (13).



TA476898

- (8) Remove screw (14), washer (15), spacer (16), and lockpin (17).
- (9) Remove pin (18) and cylinder (6) from crane (19).




TA476899

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-14.1 ERECTION CYLINDER REMOVAL/INSTALLATION (M984E1) (CONT).

b. Installation.

- (1) Install cylinder (1) in crane (2).
- (2) Install pin (3), lockpin (4), and spacer (5).
- (3) Apply sealing and thread locking compound and install washer (6) and screw (7).



- (4) Aline cylinder (1) and drive pin (8) back through cylinder (1).
- (5) Install lockpin (9) and spacer (10).
- (6) Apply sealing and thread locking compound and install washer (11) and screw (12).



- (7) Install preformed packing (13) and plug (14).
- (8) Install preformed packing (15) and elbow (16).


NOTE

Standard elbow (on side of manifold) has been replaced by an elbow with an orifice. Refer to TM 9-2320-279-24P

- (9) Install preformed packing (17) and elbow (18).
- (10) Connect two hydraulic lines (19).

c. Follow-on Maintenance.

- (1) Return crane to stowed position (TM 9-2320-279-10).
- (2) Check operation (TM 9-2320-279-10).
- (3) Check for leaks.



END OF TASK


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-15. ERECTION CYLINDER REPAIR	
This task covers:	
a. Disassembly	c. Assembly
c. Cleaning/Inspection	
INITIAL SETUP	
<i>Models</i> M977, M984E1, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> TM or Para
<i>Special Tools</i> None	<i>Condition Description</i> Erection cylinder on clean work surface.
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Oil, lubricating, Item 47.1, Appendix C Solvent, drycleaning, Item 57, Appendix C	<i>Special Environmental Conditions</i> None
<i>Personnel Required</i> MOS 63W, Heavy wheel vehicle mechanic (2)	<i>General Safety Instructions</i> None
	<i>Level of Maintenance</i> General Support

a. Disassembly.

NOTE

- Right and left cylinders are disassembled the same way.
 - There are two models of erection cylinders. Model A is used on M977 and M985 vehicles and includes setscrews and a spacer. Model B is used on M984E1 vehicles.
- (1) Remove holding valve (1), backup ring (2), preformed packing (3), backup ring (2), preformed packing (4), backup ring (5), and preformed packing (6).
 - (2) Remove two grease fittings (7).
 - (2.1) Remove two bushings (8) from each end of cylinder (9).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-15. ERECTION CYLINDER REPAIR (CONT).

- (3) Remove setscrew (10) and loosen retaining ring (11).
- (4) Remove rod assembly (12) from cylinder (9).

NOTE

Do steps (4.1) and (4.2) for Model A only.

- (4.1) Remove two grease fittings (12.1) from rod assembly (12).
- (4.2) Remove setscrew (12.2) and rod cap (12.3) from rod (12).



NOTE


Do step (5) for Model B cylinder.

- (5) Remove locknut (13) from rod (14).
- (6) Remove wear ring (15), two backup rings (16), preformed packing (17), and wear ring.

NOTE

Do step (6.1) for Model A cylinder.


- (6.1) Remove setscrew (17.1) from piston (18).
- (7) Remove piston (18), backup ring (19), preformed packing (20), and backup ring from rod (14).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)**NOTE**

Do step (7.1) for Model A cylinder.

- (7.1) Remove spacer (19.1) from rod (14).
- (8) Remove backup ring (21) and preformed packing (22) from head (23).
- (9) Remove head (23) from rod (14).
- (10) Remove backup ring (24), seal (25), and wear ring (26) from head (23).



- (11) Remove retaining ring (12) from rod (14).
- (12) Remove wiper ring (27) from retaining ring (12).


**b. Cleaning/Inspection.****WARNING**

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in drycleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check cylinder bushing end. If diameter is larger than 2.015 in. (51.18 mm), replace bushing.
- (5) Check rod end bushing (M984E1 only). If diameter is larger than 1.515 in. (38.48 mm), replace bushing.

17-15. ERECTION CYLINDER REPAIR (CONT).

c. Assembly.



- (1) Install wiper ring (1) in retaining ring (2).
- (2) Install retaining ring (2) on rod (3).



- (3) Install wear ring (4), seal (5), and backup ring (6) in head (7).
- (4) Install head (7) on rod (3).
- (5) Install preformed packing (8) and backup ring (9) on head (7).

NOTE

Do step (5.1) for Model A only.

- (5.1) Install spacer (8.1) on rod (3).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (6) Install backup ring (10), preformed packing (11), and backup ring (10) in piston (12).
- (7) Install piston (12) on rod (3).

NOTE


Do step (7.1) for Model A cylinder.

- (7.1) Install setscrew (12.1) on piston (12).
- (8) Install wear ring (13), preformed packing (14), two backup rings (15), and wear ring (13) on piston (12).

NOTE

Do step (9) for Model B cylinder.



- (9) Install nut (16) on rod (3).



NOTE

Do steps (9.2) and (9.3) for Model A cylinder.

- (9.2) Install rod cap (16.2) and two setscrews (16.3) to rod (3).
- (9.3) Install two grease fittings (16.4) in rod cap (16.2).
- (10) Install rod assembly (3) in cylinder (17).
- (11) Apply sealing and thread locking compound and install retaining ring (2).
- (12) Install setscrew (18).



- (13) Install two bushings (19) and grease fittings (20) on each end of cylinder (17).

NOTE

Apply lubricant to preformed packings before installing.

- (14) Install preformed packings (21 and 22), backup ring (23), preformed packing (24), and two backup rings (25).
- (15) Install holding valve (26).


d. Follow-on Maintenance. None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-16. LIFT CYLINDER REMOVAL/INSTALLATION	
This task covers:	
a. Removal	c. Installation
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i>
<i>Special Tools</i> None	<i>TM or Para</i> <i>Condition Description</i>
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Tags, identification, Item 60, Appendix C Solvent, dry cleaning, Item 67, Appendix C Wood, stock, Item 68, Appendix C	Para 17-2 Hoist drain lines removed. TM 9-2320-279-10 Cargo body rear panel removed.
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Special Environmental conditions</i> None
	<i>General Safety Instructions</i> None
	<i>Level of Maintenance</i> Direct support

a. Removed



NOTE

Wooden block is approximately 4 x 4 x 12 in. (102 x 102 x 306 mm). Right and left cylinders are removed the same way.

(1) Raise boom (1) and support with wooden block.


NOTE

Tag and mark hydraulic lines before disconnecting.

(2) Disconnect four hydraulic lines (2).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3) Attach suitable lifting device to cylinder (3).
- (4) Remove screw (4), washer (5), spacer (6), and lockpin (7).
- (5) Remove pin (8).
- (6) Remove screw (9), washer (10), spacer (11), and lockpin (12).
- (7) Repeat step (6) for other side.
- (8) Drive pin (13) in far enough to clear cylinder (3).
- (9) Remove cylinder (3).



TA189923


- (10) Remove three fittings (14) and preformed packings (15).
- (11) Remove elbow (16), preformed packing (17), plug (18), preformed packing (19), plug (20), and preformed packing (21).
- (12) Remove two grease fittings (22) from each end of cylinder (3).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.




TA357243

17-16. LIFT CYLINDER REMOVAL/INSTALLATION (CONT).

c. Installation.

- (1) Install two grease fittings (1) in each end of cylinder (2).
- (2) Install plug (3), preformed packing (4), preformed packing (5), and plug (6).
- (3) Install elbow (7) and preformed packing (8).
- (4) Install three fittings (9) and preformed packings (10).




TA357244

- (5) Align and install cylinder (2).
- (6) Drive pin (11) through cylinder (2).
- (7) Align hole in pin (11) and install two lockpins (12) and spacers (13).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA189924

- (8) Apply sealing and thread locking compound to two screws (14) and install washers (15) and screws.
- (9) Align cylinder (2) and install pin (16), lockpin (17), and spacer (18).
- (10) Apply sealing and thread locking compound to screw (19) and install washer (20) and screw.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (11) Connect four hydraulic lines (21).
- (12) Raise boom (22) and remove wood block.



TA189926



- d. *Follow-on Maintenance.*
 - (1) Install hoist drain lines (para 17-2).
 - (2) Install cargo body rear panel (TM 9-2320-279-10).

END OF TASK

17-16.1. LIFT CYLINDER REMOVAL/INSTALLATION (M984E1).	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M984E1	<i>Equipment Condition</i>
<i>Test Equipment</i> None	TM 9-2320-279-1 0 Recovery system lowered. TM 9-2320-279-1 0 Crane in operating position, extension 1 and 2 fully extended and lowered to ground.
<i>Special Tools</i> None	TM 9-2320-279-1 0 Shut off engine.
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C	<i>Special Environmental Conditions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>General Safety Instructions</i> None
<i>References</i> None	<i>Level of Maintenance</i> Direct Support

17-16.1. LIFT CYLINDER REMOVAL/INSTALLATION (M984E1) (CONT).

a. Removal.




TA476911

NOTE

Right and left cylinders are removed the same. Steps (1) and (2) must be done before removing left cylinder.

- (1) Remove two screws (1), spacers (2), and two clamp halves (3).
- (2) Disconnect hydraulic line (4) and move to clear cylinder (5).
- (3) Attach suitable lifting device to cylinder (5).
- (4) Remove screw (6), washer (7), lockpin (8), spacer (9), and pin (10).
- (5) Start engine and retract lift cylinder (TM 9-2320-279-10).




TA476912

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


NOTE

Right cylinder has only four lines.

- (6) Disconnect five hydraulic lines (11).
- (7) Remove screw (12), washer (13), lockpin (14), spacer (15), and pin (16).
- (8) Remove cylinder (5) from crane (17).



TA476913




TA476914

- (9) Remove two elbows (18), elbow (19), and three preformed packings (20).
- (10) Remove fitting (21), preformed packing (22), plug (23), preformed packing (24), plug (25), and preformed packing (26).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-16.1. LIFT CYLINDER REMOVAL/INSTALLATION (M984E1) (CONT).

b. Installation.




TA476915

- (1) Install plug (1), preformed packing (2), preformed packing (3), and plug (4).
- (2) Install fitting (5) and preformed packing (6).
- (3) Install two elbows (7), elbow (8), and three preformed packings (9).
- (4) Aline and install cylinder (10) in crane (11).
- (5) Install pin (12), lockpin (13), and spacer (14).
- (6) Apply sealing and thread locking compound and install washer (15) and screw (16).

NOTE

Right cylinder has only four lines.


- (7) Connect five hydraulic lines (17).



TA476916

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (8) Start engine (TM 9-2320-279-10).
- (9) Aline cylinder (10) and install pin (18), lockpin (19), and spacer (20).
- (10) Apply sealing and thread locking compound and install washer (21) and screw (22).



- (11) Connect hydraulic line (23).
- (12) Install two clamp halves (24), spacers (25), and screws (26) on line (23).

c. Follow-on Maintenance.

- (1) Check for leaks.
- (2) Return crane to stowed position (TM 9-2320-279-10).
- (3) Return recovery system to stowed position (TM 9-2320-179-10).



END OF TASK


17-17. LIFT CYLINDER REPAIR.	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>References</i>
M977, M984E1, M985	None
<i>Test Equipment</i>	<i>Equipment Condition</i>
None	<i>TM or Para</i>
<i>Special Tools</i>	<i>Condition Description</i>
None	Lift cylinder on clean work surface.
<i>Supplies</i>	<i>Special Environmental Conditions</i>
Compound, sealing and thread locking, Item 26, Appendix C	None
Oil, lubricating, Item 47.1, Appendix C	<i>General Safety Instructions</i>
Solvent, dry cleaning, Item 57, Appendix C	None
<i>Personnel Required</i>	<i>Level of Maintenance</i>
MOS 63W, Wheel vehicle repairer	General Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-17. LIFT CYLINDER REPAIR (CONT).

a. Disassembly.

- (1) Remove holding valve (1).
- (2) Remove two backup rings (2), preformed packing (3), two backup rings (4), and preformed packings (5 and 6).
- (3) Remove two grease fittings (7) and bushings (8) from each end of cylinder (9).




TA476919

NOTE


Retaining ring may require heat for disassembly.

- (4) Remove setscrew (10) and loosen retaining ring (11).
- (5) Remove rod assembly (12) from cylinder (9).



TA189854


- (6) Remove nut (13) from rod (12).
- (7) Remove wear ring (14), two backup rings (15), preformed packing (16), and wear ring (14).
- (8) Remove piston (17).
- (9) Remove backup ring (18), preformed packing (19), and backup ring (18) from piston (17).



TA357250

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (10) Remove spacer (20).
- (11) Remove preformed packing (21) and backup ring (22).
- (12) Remove head (23) from rod (12).
- (13) Remove wear ring (24), backup ring (25), and seal (26) from head (23).



TA357251


- (14) Remove retaining ring (11) and wiper ring (27) from rod (12).

b. Cleaning/Inspection.

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check bushing inside diameter. If diameter is larger than 2.020 in. (51.30 mm), replace bushing.



TA189857

c. Assembly.




TA189858

- (1) Install wiper ring (1) in retaining ring (2).
- (2) Install retaining ring (2) on rod (3).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-17. LIFT CYLINDER REPAIR (CONT).

- (3) Install wear ring (4), seal (5), and backup ring (6) in head (7).
- (4) Install backup ring (8) and preformed packing (9) on head (7).
- (5) Install head (7) and spacer (10) on rod (3).




- (6) Install backup ring (11), preformed packing (12), and backup ring (11) in piston (13).
- (7) Install piston (13) on rod (3).
- (8) Install wear ring (14), preformed packing (15), two backup rings (16), and wear ring (14).
- (9) Install and tighten nut (17) to 100 lb-ft (135.6 N•m).



- (10) Install rod assembly (3) in cylinder (18).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.



- (11) Apply sealing and thread locking compound and install retaining ring (2).
- (12) Install setscrew (19).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont



(13) Install two bushings (20) and grease fittings (21) in each end of cylinder (18).

NOTE

Apply lubricant to preformed packings before installing.

- (14) Install preformed packing (22).
- (15) Install preformed packing (23) and two backup rings (24).
- (16) Install preformed packing (25) and two backup rings (26).
- (17) Install holding valve (27).

d. Follow-on Maintenance. None.


END OF TASK

17-18. EXTENSION NO. 1 AND NO. 2 CYLINDER AND WEAR PADS REMOVAL/INSTALLATION.	
This task covers:	
a. Removal	c. Installation
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>References</i>
M977, M985	None
<i>Test Equipment</i>	<i>Equipment Condition</i>
None	<i>TM or Para</i> <i>Condition Description</i>
<i>Special Tools</i>	Para 17-13 Extension No. 2 removed.
None	<i>Special Environmental Conditions</i>
<i>Supplies</i>	None
Compound, sealing and thread locking, Item 26, Appendix C	<i>General Safety Instructions</i>
Solvent, dry cleaning, Item 57, Appendix C	None
<i>Personnel Required</i>	<i>Level of Maintenance</i>
MOS 63W, Wheel vehicle repairer (2)	Direct Support

17-18. EXTENSION NO. 1 AND NO. 2 CYLINDER AND WEAR PADS
REMOVAL/INSTALLATION (CONT).

a. Removal.

- (1) Remove two screws (1) and lockwashers (2).



TA189927

- (2) Soldier A lifts front of cylinder (3) while Soldier B lifts rear of cylinder (3).
- (3) Remove cylinder (3) through rear of extension No. 2 (4).



TA189928


- (4) Remove two screws (5) and wear pads (6) from cylinder (3).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Inspect wear pad thickness. If upper wear pad is under 0.438 in. (11.1 mm) replace pad. If lower pad is under 0.500 in. (12.7 mm) replace pad.



TA189929

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


c. *Installation.*

(1) Install two wear pads (1).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(2) Apply sealing and thread locking compound and install two screws (2).



TA189930


(3) Soldier A and Soldier B install cylinder (3) in extension No. 2 (4) .



TA189931

Be sure block is positioned below screw holes.

(4) Install two screws (5) and lockwashers (6).



TA189932

d. *Follow-on Maintenance.* Install extension No. 2 (para 17-13).


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-18.1. EXTENSION ONE & TWO CYLINDER AND WEAR PADS REMOVAL/INSTALLATION (M984E1).	
This task covers:	
<p>a. Removal b. Cleaning/Inspection</p>	<p>c. Installation d. Follow-on Maintenance</p>
INITIAL SETUP	
<p><i>Models</i> M984E1</p> <p><i>Test Equipment</i> None</p> <p><i>Special Tools</i> None</p> <p><i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C</p> <p><i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)</p>	<p><i>References</i> None</p> <p><i>Equipment Condition</i> <i>TM or Para</i> <i>Condition Description</i> Para 17-13.1 Extension two removed.</p> <p><i>Special Environmental Conditions</i> None</p> <p><i>General Safety Instructions</i> None</p> <p><i>Level of Maintenance</i> Direct Support</p>


a. Removal.

(1) Remove screw (1) and retainer (2).



(2) Soldier A lifts front of cylinder (3) while
Soldier B lifts rear of cylinder (3).

(3) Remove cylinder (3) through rear of
extension two (4).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (4) Remove two screws (5) and wear pads (6) from cylinder (3).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Inspect wear pad thickness. If upper wear pad is under 0.438 in. (11.1 mm) replace pad. If lower pad is under 0.500 in. (12.7 mm) replace pad.



TA476923

c. *Installation.*

- (1) Install two wear pads (1).
- (2) Apply thread locking sealing compound and install two screws (2).



TA476924

- (3) Soldier A and Soldier B install cylinder (3) in extension two (4) through rear of extension.



TA476925


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-18.1. EXTENSION ONE & TWO CYLINDER AND WEAR PADS REMOVAL/INSTALLATION (M984E1) (CONT).

(4) Install retainer (5) and screw (6) in extension two (4).

d. Follow-on Maintenance. Install extension two (para 17-13.1).

END OF TASK



17-19. EXTENSION CYLINDER REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection

- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

M977, M985

References

None

Test Equipment

None

Equipment Condition

TM or Para	Condition Description
Para 17-18	Extension cylinders removed.

Special Tools

None

Special Environmental Conditions

None

Supplies

- Compound, sealing and thread locking, Item 26, Appendix C
- Oil, lubricating, Item 47.1, Appendix C
- Solvent, dry cleaning, Item 57, Appendix C

General Safety Instructions

None

Personnel Required


MOS 63W, Wheel vehicle repairer

Level of Maintenance

General Support


a. Disassembly.

- (1) Remove two fittings (1) and preformed packing (2).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (2) Remove holding valve (3).
- (3) Remove two backup rings (4), preformed packings (5 and 6), backup ring (7), and preformed packing (8).




TA190427

NOTE


Both ends of cylinder are disassembled the same way.

- (4) Remove four screws (9) and slide end cap (10) back.
- (5) Remove rod assembly (11) from cylinder (12).




TA190428

- (6) Remove wear ring (13), backup ring (14), backup ring (15), preformed packing (16), and wear ring (17).
- (7) Remove setscrew (18).



TA190429

- (8) Remove piston (19), backup ring (20), preformed packing (21), and backup ring (22).
- (9) Remove spacer (23) from rod (11).




TA190430

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-19. EXTENSION CYLINDER REPAIR (CONT).

- (10) Remove preformed packing (24), backup ring (25), and head (26) from rod (11).
- (11) Remove backup ring (27), seal (28), and two wear rings (29).



TA190431


- (12) Remove end cap (10) from rod (11).
- (13) Remove dust seal (30) from end cap (10).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.




TA190432

c. *Assembly.*

NOTE

Both ends of cylinder are assembled the same way.


- (1) Install dust seal (1) in end cap (2).
- (2) Install end cap (2) on rod (3).



TA190433

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3) Install two wear rings (4), seal (5), and backup ring (6) in head (7).
- (4) Install head (7) on rod (3).
- (5) Install backup ring (8) and preformed packing (9).




TA190434

- (6) Install spacer (10) on rod (3).
- (7) Install backup ring (11), preformed packing (12), and backup ring (13).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA190435

- (8) Apply sealing and thread locking compound and install piston (14).
- (9) Install setscrew (15).
- (10) Install wear ring (16), backup ring (17), preformed packing (18), backup ring (19), and wear ring (20).




TA190436

- (11) Install rod assembly (3) in cylinder (21).
- (12) Aline end cap (2) and install four screws (22).



TA190437

17-19. EXTENSION CYLINDER REPAIR (CONT).




TA190441

NOTE

Apply lubricant to preformed packings before installing.

- (13) Install preformed packing (23), backup ring (24), preformed packing (25), backup ring (26), preformed packing (27), and backup ring (28).
- (14) Install holding valve (29).



TA190438

- (15) Install two fittings (30) and preformed packings (31).

d. *Follow-on Maintenance.* Install extension cylinders (para 17-18).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-19.1. EXTENSION CYLINDER REPAIR (M984E1).

This task covers:

- | | |
|------------------------|--------------------------|
| a. Disassembly | c. Assembly |
| b. Cleaning/Inspection | d. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

Compound, sealing and thread locking,
Item 26, Appendix C
Oil, lubricating, Item 47.1, Appendix C
Solvent, dry cleaning, Item 57, Appendix C

Personnel Required

MOS 63S, Wheel vehicle repairer (2)

References

None

Equipment Condition

TM or Para

Para 17-18.1

Condition Description

Extension cylinder removed.

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support

- a. *Disassembly.*
(1) Remove two fittings (1) and preformed packings (2).




TA476927

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-19.1. EXTENSION CYLINDER REPAIR (M984E1) (CONT).


- (2) Remove holding valve (3).
- (3) Remove two backup rings (4), preformed packing (5), preformed packing (6), backup ring (7), and preformed packing (8) from valve (3).




NOTE

Both ends of cylinder are disassembled the same way.

- (4) Remove four screws (9) and slide end cap (10) back.
- (5) Soldier A and Soldier B remove rod assembly (11) from cylinder (12).




- (6) Remove wear ring (13), two backup rings (14), preformed packing (15), and wear ring (13).
- (7) Remove setscrew (16).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (8) Remove piston (17), backup ring (18), preformed packing (19), and backup ring (18).
- (9) Remove spacer (20) from rod (11).




TA476931

- (10) Remove preformed packing (21) and backup ring (22) from head (23).
- (11) Remove head (23) from rod (11).
- (12) Remove backup ring (24), seal (25), and wear ring (26).



TA476932

- (13) Remove end cap (10) from rod (11).
- (14) Remove dust seal (27) from end cap (10).



TA476933

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.


17-19.1. EXTENSION CYLINDER REPAIR (M984E1) (CONT.)

c. Assembly.

NOTE


Both ends of cylinder are assembled the same.

- (1) Install dust seal (1) in end cap (2).
- (2) Install end cap (2) on rod (3).




TA476934

- (3) Install wear ring (4), seal (5), and backup ring (6) in head (7).
- (4) Install head (7) on rod (3).
- (5) Install backup ring (8) and preformed packing (9).




TA476935

- (6) Install spacer (10) on rod (3).
- (7) Install backup ring (11), preformed packing (12), and backup ring (11).
- (8) Apply thread locking sealing compound and install piston (13).



TA476936


- (9) Install setscrew (14).
- (10) Install wear ring (15), preformed packing (17), two backup rings (16), and wear ring (15).



TA476937

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (11) Soldier A and Soldier B install rod assembly (3) in cylinder (18).
- (12) Aline end cap (2) and install four screws (19).




TA476938

NOTE

Apply lubricant to preformed packings before installing.

- (13) Install preformed packing (20), backup ring (21), preformed packing (22), backup ring (23), preformed packing (24), and backup ring (23).
- (14) Install holding valve (25).




TA476939

- (15) Install two fittings (26) and preformed packings (27).

d. *Follow-on Maintenance.* Install extension cylinder (para 17-18.1).

END OF TASK




TA476940

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-19.2. TENSION CYLINDER REMOVAL/REPAIR/INSTALLATION (M984E1).	
This task covers:	
a. Removal	d. Assembly
b. Disassembly	e. Installation
c. Cleaning/Inspection	f. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>Equipment Condition</i>
M984E1	<i>TM or Para</i> <i>Condition Description</i>
<i>Test Equipment</i>	TM 9-2320-279-10 Recovery system lowered.
None	TM 9-2320-279-10 Crane in operating condition with extensions 1 and 2 fully extended and lowered to ground.
<i>Special Tools</i>	TM 9-2320-279-10 Shut off engine.
None	
<i>Supplies</i>	<i>Special Environmental Conditions</i>
Compound, sealing and thread locking, Item 26, Appendix C	None
<i>Personnel Required</i>	<i>General Safety Instructions</i>
MOS 63W, Wheel vehicle repairer	None
<i>References</i>	<i>Level of Maintenance</i>
None	Direct Support

a. Removal.



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE


Right and left cylinders are removed the same.

- (1) Remove screw (1), washer (2), spacer (3), and lockpin (4).
- (2) Repeat step (1) for other side.

WARNING

Do not drive pin out of erection cylinder.

- (3) Drive pin (5) in far enough to clear cylinder (6).
- (4) Remove screw (7), washer (8), spacer (9), and lockpin (10).
- (5) Repeat step (4) for other side.
- (6) Drive pin (11) in far enough to clear cylinder (6).
- (7) Remove cylinder (6) from crane (12).



TA476942


b. Disassembly.

- (1) Remove two setscrews (1) from cylinder (2).
- (2) Remove four grease fittings (3) and bushings (4) from rod assembly (5).

c. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA476943

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check bushing diameter. Diameter must not exceed 2.015 in. (50.82 mm).

17-19.2. TENSION CYLINDER REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

d. Assembly.

- (1) Install four bushings (1) and grease fittings (2) in rod assembly (3).
- (2) Install two setscrews (4) in cylinder (5).




TA476944

e. Installation.

NOTE

Both cylinders are installed the same.

- (1) Soldier A installs cylinder (1) in crane (2).
- (2) Soldier B drives pin (3) back in cylinder (1).
- (3) Install lockpin (4) and spacer (5).
- (4) Apply compound and install washer (6) and screw (7).
- (5) Repeat steps (3) and (4) for other side.




TA476945

- (6) Soldier A aligns cylinder (1) and Soldier B drives pin (8) back through cylinder (1).
- (7) Install lockpin (9) and bushing (10).
- (8) Apply compound and install washer (11) and screw (12).
- (9) Repeat steps (7) and (8) for other side.

f. Follow-on Maintenance. Return crane to stowed position (TM 9-2320-279-10).

END OF TASK



TA476946

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Section V. HOIST

17-20. HOIST ASSEMBLY AND PIVOT BUSHINGS REMOVAL/INSTALLATION.

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | c. Installation |
| b. Cleaning/Inspection | d. Follow-on Maintenance |

INITIAL SETUP

Models

M977, M984E1 , M985

Test Equipment

None

Special Tools

None

Supplies

Solvent, dry cleaning, Item 57, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer (2)

References

None

Equipment Condition

TM or Para

Condition Description

TM 9-2320-279-20	Hoist cable removed.
Para 17-2	Hoist hoses disconnected.
TM 9-2320-279-10	Boom raised about 1 ft (30 cm).

Special Environmental Conditions

None

General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal.

- (1) Attach suitable lifting device to hoist assembly (1).

NOTE


Spring washers are sealed in paper. Do not remove paper.

- (2) Remove nut (2), jamnut (3), washer (4), spacer (5), disc spring package (6), sleeve (7), and screw (8).
 (3) Remove nut (9), clamp (10), hoses (11), and screw (12).

WARNING


Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (4) Soldier A removes pin (13) and hoist assembly (1) while Soldier B operates lifting device.



TA189821

17-20. HOIST ASSEMBLY AND PIVOT BUSHINGS REMOVAL/INSTALLATION (CONT).



(5) Remove two bushings (14).


b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check bushings for wear. Bushing inside diameter must not exceed 1.010 in. (25.65 mm).


c. *Installation.*



(1) Install two bushings (1).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (2) Soldier A aligns hoist assembly (2) and installs screw (3), sleeve (4), disc spring package (5), spacer (6), washer (7), jamnut (8), and nut (9) while Soldier B operates lifting device.
- (3) Install pin (10).
- (4) Install screw (11), clamp (12), hoses (13), and nut (14).
- (5) Adjust screw (3) and nut (9) until screw is 0.62 in. (15.75 mm) below the end of nut.




d. Follow-on Maintenance.

- (1) Connect hoist hoses and tubes (para 17-2).
- (2) Install hoist cable (TM 9-2320-279-20).
- (3) Adjust overload switches (para 17-33.1).

17-20.1 HOIST CABLE FOLLOWER REPAIR (M977, M985).	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i> TM or Para Para 17-20 <i>Condition Description</i> Hoist assembly removed.
<i>Test Equipment</i> None	<i>Special Environmental Conditions</i> None
<i>Special Tools</i> None	<i>General Safety Instructions</i> None
<i>Supplies</i> Solvent, drycleaning, Item 57, Appendix C Compound, sealing and thread locking, Item 26, Appendix C	<i>Level of Maintenance</i> Direct Support
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	
<i>References</i> None	

17-20.1. HOIST CABLE FOLLOWER REPAIR (M977 AND M985) (CONT).

a. *Disassembly.***WARNING**

When second spring is released, cable follower may fly up against bracket. Keep hands and face away from this area, or injury to personnel may result.

NOTE

Remove spring on side with extra block first.


- (1) Hold cable follower (1) up and install small wooden block (2) to aid disassembly. Pry ends of two springs (3) down to remove spring pressure on cable follower.
- (2) Remove two screws (4), four thrust washers (5), and cable follower (1) from bracket (6) and separate two springs (3).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE


Perform steps (3) through (9) only if cable follower assembly is damaged.

- (3) Remove two nuts (7) and separate left lever arm foot (8), roller assembly (9), spacer (10), block (11), spacer (12), block (13), right lever arm foot (14), and two screws (15).
- (4) Remove two screws (16), washers (17), and spring support tubes (18) from lever arm feet (8) and (14).



17-20.1. HOIST CABLE FOLLOWER REPAIR (M977 AND M985) (CONT).

- (5) Remove screw (19), end cap (20), thrust washer (21), roller (22), and thrust washer (23) from support plate (24), and roller shaft (25).
- (6) Remove bushing (26) from support plate (24).
- (7) Remove screw (27), end cap (28), thrust washer (29), roller (30), and thrust washer (31) from roller shaft (25).
- (8) Remove spring pin (32) from bushing (33).
- (9) Remove bushing (33), support plate (34), and two thrust washers (35) from roller shaft.
- (10) Remove roller (36) from roller shaft (25).
- (11) Remove three bearings (37) from rollers (22), (30), and (36).



b. Cleaning/Inspection

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in drycleaning solvent.
- (2) Dry parts with cleaning cloth.
- (3) Inspect each part for cracks, breaks, gouges, pitting, and stripped threads.
- (4) Replace damaged parts.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

*c. Assembly***NOTE**

Perform steps (1) through (9) only if cable follower assembly was disassembled.

- (1) Install three bearings (1) in rollers (2), (3), and (4).
- (2) Position roller (4) and two thrust washers (5) on roller shaft (6).
- (3) Install bushing (7) in support plate (8).
- (4) Install bushing (7), thrust washer (9), roller (3), thrust washer (10), end cap (11), and screw (12) on roller shaft (6). Tighten screw to 72 lb-in. (8 N•m)
- (5) Install spring pin (13) in bushing (7) and roller shaft (6).
- (6) Install bushing (14) in support plate (15).
- (7) Install bushing (14), thrust washer (16), roller (2), thrust washer (17), end cap (18) and screw (19) on roller shaft (6). Tighten screw to 72 lb-in. (8 N•m).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-20.1. HOIST CABLE FOLLOWER REPAIR (M977 AND M985) (CONT.).

- (8) Install spring support tubes (20) on lever arm feet (8) and (15) with two washers (21) and screws (22). Tighten screws to 68 lb-ft (92 N•m).

NOTE

Two screws attaching spring holders to roller assembly are installed diagonally.

- (9) Install left spring holder (81, roller assembly (23), spacer (24), block (25), spacer (26), block (27), right spring holder (15), two screws (28), and nuts (29). Tighten screws to 16 lb-ft (22 N•m).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (10) Apply thread sealing compound on threads of two screws (30).
- (11) Position springs (31) and install cable follower (32) on bracket (33) with four thrust washers (35) and two screws (30). Tighten screws to 87 lb-ft (118 N•m).
- (12) Hold cable follower (32) up while prying ends of two springs (31) up to fully install two springs.

d. Follow-on Maintenance. Install hoist assembly (para 17-20).

END OF TASK



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-20.2 HOIST CABLE GUIDE REMOVAL/INSTALLATION (M977, M985).

This task covers:

- a. Removal
- b. Installation
- c. Follow-on Maintenance

INITIAL SETUP

Models

M977, M985

Test Equipment

None

Special Tools

None

Supplies

Compound, sealing and thread locking,
Item 26, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Para 17-21

Condition Description

Hoist control valve
removed

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal




- (1) Remove four nuts (1), lockwashers (2), screws (3), and bracket assembly (4) from Plates (5)
- (2) Remove four screws (7), lockwashers (8), and washers (9) from bar assembly (10) and Plates (5) and (6).
- (3) Remove four screws (11), lockwashers (12), bar assembly (10), and Plates (5) and (6) from hoist assembly (13).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-20.2. HOIST CABLE GUIDE REMOVAL/INSTALLATION (M977, M985) (CONT.)

- (4) Remove two screws (14) and wear pad (15) from bracket assembly (4).
- (5) Remove two screws (16), lockwashers (17), weld pin (18), four thrust washers (19), and two roller assemblies (20) from bracket assembly (4).




b. Installation.

- (1) Install two roller assemblies (1), four thrust washers (2), and weld pin (3) in bracket assembly (4).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (2) Coat two screws (5) with sealing compound.
- (3) Install two lockwashers (6) and screws (5) in bracket assembly (4). Torque screws to 14 lb-ft (20 N•m).
- (4) Coat two screws (7) with sealing compound.
- (5) Install wear pad (8) on bracket assembly (4) with two screws (7).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



- (6) Coat four screws (9) with sealing compound.
- (7) position plates (10) and (11) with four lockwashers (12) and screws (9) on hoist assembly (13).
- (8) Coat four screws (14) with sealing compound.

NOTE


Hex socket screw on one end of bar assembly is positioned in long slot of plate.

- (9) Position bar assembly (15) on plates (10) and (11) with four lockwashers (16), washers (17), and screws (14). Do not tighten screws.
- (10) Tighten four screws (9) on plates (10) and (11) to 68 lb-ft (92 N•m).
- (11) Adjust gap between bar assembly (15) and drum flange (18) to 0.06 in. (1.52 mm). Tighten four screws (14) to 30 lb-ft (41 N•m).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (12) Coat four screws (19) with sealing compound.
- (13) Install bracket assembly (4) on plates (10) and (11) with four lockwashers (20), screws (19), and nuts (21).



c. Follow-On Maintenance.

- (1) Fill hydraulic reservoir (LO 9-2320-279-12).
- (2) Check operation (TM 9-2320-279-10).


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-21. HOIST DRIVE MOTOR CONTROL VALVE REMOVAL/REPAIR/INSTALLATION.	
This task covers:	
a. Removal	d. Assembly
b. Disassembly	e. Installation
c. Cleaning/Inspection	f. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> TM or Para <i>Condition Description</i> TM 9-2320-279-10 Shut off engine. Para 17-2 Hoist control valve hoses and tubes disconnected.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> Compound, sealing and thread locking, Item 25, Appendix C Pipe thread sealing compound, Item 29, Appendix C Solvent, drycleaning, Item 57, Appendix C Oil, lubricating, Item 46, Appendix C	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-21. HOIST DRIVE MOTOR CONTROL VALVE REMOVAL/REPAIR/INSTALLATION (CONT).




NOTE

There are two models of control valves. Model A (Snap-Tite, no longer available as an assembly) has an SAE #4 brake port. Model B (Dana) has an SAE #6 brake port. Removal procedures are identical for both.

a. **Removal.** Remove four screws (1), lockwashers (2), control valve (3), and two preformed packings (4).

b. **Disassembly.**



NOTE

Perform steps (1) through (3) for Model A. Perform steps (3.1) through (3.5) for Model B.

- (1) Remove two fittings (1) and preformed packings (2).
- (2) Remove elbow (3) and preformed packing (4).
- (3) Remove three plugs (5).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3.1) Remove two fittings (1) and preformed packings (2) from housing (3).

NOTE


Matchmark position of elbow prior to removal.

- (3.2) Remove elbow (4) and preformed packing (5) from housing (3).


NOTE

Perform step (3.3) if plugs are damaged.


- (3.3) Remove two plugs (6) and preformed packings (7) from housing (3).
- (3.4) Remove safety valve (8) and preformed packing (9) and orifice (10) from housing (3).



- (3.5) Remove preformed packing (11), backup ring (12), preformed packing (13), and two backup rings (14) from safety valve (8).



- (4) Remove holding valve (6) from control valve (7).
- (5) Remove preformed packing (8), backup ring (9), two backup rings (10), preformed packing (11), and preformed packing (12) from holding valve (6).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

c. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in drycleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

d. *Assembly.*


NOTE

Perform steps (1) through (3) for Model A.
 Perform steps (4) through (11) for Model B

- (1) Install preformed packing (1), preformed packing (2), two backup rings (3), backup ring (2), and preformed packing (5) on holding valve (6).
- (2) Install holding valve (6) in control valve (7).
- (3) Apply pipe thread sealing compound and install three plugs (8)1, preformed packing (9), elbow (10), two preformed packings (11), and fittings (12).




MODEL A



MODEL A

- (4) Apply hydraulic oil to preformed packings (13) and (9) and backup rings (14) and (12).
- (5) Install two backup rings (14), preformed packing (13), backup ring (12), and preformed packing (11) on safety valve (8).
- (6) Install orifice (10), preformed packing (9), and safety valve (8) in housing (3).



MODEL B


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-21. HOIST DRIVE MOTOR CONTROL VALVE REMOVAL/REPAIR/INSTALLATION (CONT).

NOTE

Perform steps (7) and (8) if plugs were removed.


- (7) Coat threads of two plugs (6) and elbow (5) with pipe thread sealing compound.
- (8) Install two plugs (6) and preformed packings (7) in housing (3).
- (9) Apply hydraulic oil to preformed packings (4) and (2).
- (10) Install preformed packing (4) and elbow (5) in housing (3).
- (11) Install two preformed packings (2) and fittings (1) in housing (3).



e. Installation.

NOTE:

There are two models of control valves. Model A (Snap-Tite, no longer available as an assembly) has an SAE #4 brake port. Model B (Dana) has an SAE #6 brake port. Installation procedures are identical for both. However, if replacing Model A with Model B, elbow located between hoist motor control valve and brake port hose must be replaced (step b, substep (3.2)).



- (1) Install two preformed packings (1) and control valve (2).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (2) Apply sealing and thread locking compound and install four lockwashers (3) and screws (4).

f. Follow-on Maintenance. Install hoist hydraulic hoses and tubes (para 17-2).


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

<p>17-21.1 HOIST MOTOR VALVE ASSEMBLY REMOVAL/REPAIR/INSTALLATION (M984E1)</p>											
<p>This task covers:</p> <table border="0"> <tr> <td>a. Removal</td> <td>d. Assembly</td> </tr> <tr> <td>b. Disassembly</td> <td>e. Installation</td> </tr> <tr> <td>c. Cleaning/Inspection</td> <td>f. Follow-on Maintenance</td> </tr> </table>		a. Removal	d. Assembly	b. Disassembly	e. Installation	c. Cleaning/Inspection	f. Follow-on Maintenance				
a. Removal	d. Assembly										
b. Disassembly	e. Installation										
c. Cleaning/Inspection	f. Follow-on Maintenance										
<p>INITIAL SETUP</p> <table border="0"> <tr> <td> <p><i>Models</i> M984E1</p> <p><i>Test Equipment</i> None</p> <p><i>Special Tools</i> None</p> <p><i>Supplies</i> Compound, sealing and thread locking, Item 22, Appendix C Pipe thread sealing compound, Item 26, Appendix C Oil, lubricating, Item 46, Appendix C</p> <p><i>Personnel Required</i> MOS 63W, Wheel vehicle repairer</p> </td> <td> <p><i>References</i> None</p> <p><i>Equipment Condition</i></p> <table border="0"> <tr> <td><i>TM or Para</i></td> <td><i>Condition Description</i></td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane positioned for access.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Shut off engine.</td> </tr> <tr> <td>Para 17-2.1</td> <td>Hoist control valve hoses and tubes disconnected.</td> </tr> </table> <p><i>Special Environmental Conditions</i> None</p> <p><i>General Safety Instructions</i> None</p> <p><i>Level of Maintenance</i> Direct Support</p> </td> </tr> </table>		<p><i>Models</i> M984E1</p> <p><i>Test Equipment</i> None</p> <p><i>Special Tools</i> None</p> <p><i>Supplies</i> Compound, sealing and thread locking, Item 22, Appendix C Pipe thread sealing compound, Item 26, Appendix C Oil, lubricating, Item 46, Appendix C</p> <p><i>Personnel Required</i> MOS 63W, Wheel vehicle repairer</p>	<p><i>References</i> None</p> <p><i>Equipment Condition</i></p> <table border="0"> <tr> <td><i>TM or Para</i></td> <td><i>Condition Description</i></td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane positioned for access.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Shut off engine.</td> </tr> <tr> <td>Para 17-2.1</td> <td>Hoist control valve hoses and tubes disconnected.</td> </tr> </table> <p><i>Special Environmental Conditions</i> None</p> <p><i>General Safety Instructions</i> None</p> <p><i>Level of Maintenance</i> Direct Support</p>	<i>TM or Para</i>	<i>Condition Description</i>	TM 9-2320-279-10	Crane positioned for access.	TM 9-2320-279-10	Shut off engine.	Para 17-2.1	Hoist control valve hoses and tubes disconnected.
<p><i>Models</i> M984E1</p> <p><i>Test Equipment</i> None</p> <p><i>Special Tools</i> None</p> <p><i>Supplies</i> Compound, sealing and thread locking, Item 22, Appendix C Pipe thread sealing compound, Item 26, Appendix C Oil, lubricating, Item 46, Appendix C</p> <p><i>Personnel Required</i> MOS 63W, Wheel vehicle repairer</p>	<p><i>References</i> None</p> <p><i>Equipment Condition</i></p> <table border="0"> <tr> <td><i>TM or Para</i></td> <td><i>Condition Description</i></td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane positioned for access.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Shut off engine.</td> </tr> <tr> <td>Para 17-2.1</td> <td>Hoist control valve hoses and tubes disconnected.</td> </tr> </table> <p><i>Special Environmental Conditions</i> None</p> <p><i>General Safety Instructions</i> None</p> <p><i>Level of Maintenance</i> Direct Support</p>	<i>TM or Para</i>	<i>Condition Description</i>	TM 9-2320-279-10	Crane positioned for access.	TM 9-2320-279-10	Shut off engine.	Para 17-2.1	Hoist control valve hoses and tubes disconnected.		
<i>TM or Para</i>	<i>Condition Description</i>										
TM 9-2320-279-10	Crane positioned for access.										
TM 9-2320-279-10	Shut off engine.										
Para 17-2.1	Hoist control valve hoses and tubes disconnected.										

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-21.1. HOIST MOTOR VALVE ASSEMBLY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).



NOTE

There are two models of control valves. Model A (Snap-Tite, no longer available as an assembly) has an SAE #4 brake port. Model B (Dana) has an SAE #6 brake port. Removal procedures are identical for both.


a. Removal. Remove four screws (1), lockwashers (2), control valve (3), and two preformed packings (4).

b. Disassembly.


NOTE

Perform steps (1) through (5) for Model A.
Perform steps (6) through (10) for Model B.

- (1) Remove two fittings (1) and preformed packings (2).
- (2) Remove elbow (3) and preformed packing (4).
- (3) Remove three plugs (5).



- (4) Remove holding valve (6) from control valve (7).
- (5) Remove preformed packing (8), backup ring (9), two backup rings (10), preformed packing (11), and preformed packing (12) from holding valve (6).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (6) Remove two fittings (1) and preformed packings (2) from housing (3).

NOTE

Matchmark position of elbow prior to removal.

- (7) Remove elbow (4) and preformed packing (5) from housing (3).

NOTE

Perform step (8) if plugs are damaged.

- (8) Remove two plugs (6) and preformed packing (7) from housing (3).

- (9) Remove safety valve (8), preformed packing (9), and orifice (10) from housing (3).
- (10) Remove preformed packing (11), backup ring (12), preformed packing (13), and two backup rings (14) from safety valve (8).

c. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.



- (1) Clean all metal parts in drycleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

d. Assembly.

NOTE

Perform steps (1) through (3) for Model A. Perform steps (4) through (11) for Model B.


- (1) Install preformed packing (1), preformed packing (2), two backup rings (3), backup ring (4), and preformed packing (5) on holding valve (6).
- (2) Install holding valve (6) in control valve (7).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-21.1 HOIST MOTOR VALVE ASSEMBLY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (3) Apply pipe thread sealing compound and install three plugs (8), preformed packing (9), elbow (10), two preformed packings (11), and fittings (12).



- (4) Apply hydraulic oil to preformed packings (13) and (9) and backup rings (14) and (12).
- (5) Install two backup rings (14), preformed packing (13), backup ring (12), and preformed packing (11) on safety valve (8).
- (6) Install orifice (10), preformed packing (9), and safety valve (8) in housing (3).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE


Perform steps (7) and (8) if plugs were removed.

- (7) Coat threads of two plugs (6) and elbow (5) with pipe thread sealing compound.
- (8) Install two plugs (6) and preformed packings (7) in housing (3).
- (9) Apply hydraulic oil to preformed packings (4) and (2).
- (10) Install preformed packing (4) and elbow (5) in housing (3).
- (11) Install two preformed packings (2) and fittings (1) in housing (3).



NOTE

There are two models of control valves. Model A (Snap-Tite, no longer available as an assembly) has an SAE #4 brake port. Model B (Dana) has an SAE #6 brake port. Installation procedures are identical for both. However, if replacing Model A with Model B, elbow located between hoist motor control valve and brake port hose must be replaced (step 6, substep (7)).



e. Installation.

- (1) Install two preformed packings (1) and control valve (2).
- (2) Apply sealing and thread locking compound and install four lockwashers (3) and screws (4).

f. Follow-on Maintenance. Install hoist control valve hydraulic hoses and tubes (para 17-2.1).

END OF TASK

17-22. HOIST DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION.

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models

M977, M985

Test Equipment

None

Special Tools

None

Supplies

Compound, sealing and thread locking,
Item 26, Appendix C
Solvent, drycleaning, Item 57, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para	Condition Description
Para 17-21	Hoist drive motor control valve removed.
Para 17-2	Hydraulic drive motor hose and tubes disconnected.

Special Environmental Conditions

None

General Safety Instructions


None

Level of Maintenance

Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-22. HOIST DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (CONT).




a. *Removal.* Remove two screws (1), lockwashers (2), motor (3), and gasket (4) from drum (5).

b. *Disassembly.*

- (1) Remove elbow (1) and preformed packing (2).
- (2) Remove seven screws (3), washers (4), end cap (5), and preformed packing (6) from motor (7).




- (3) Remove geroler (8), star (9), and seven rollers (10).
- (4) Remove preformed packing (11), plate (12), shaft (13), and preformed packing (14) from motor (7).



17-22. HOIST DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (CONT).

- (5) Remove shaft (15) and bearing (16) from motor (7).



TA190933


- (6) Remove four screws (17) and flange cap (18).
- (7) Remove race (19) from motor (7).
- (8) Remove preformed packing (20) and dust seal (21) from flange cap (18).

c. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.



TA190934


d. Assembly.

- (1) Install dust seal (1) and preformed packing (2) in flange cap (3).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (2) Apply sealing and thread locking compound to four screws (4).
- (3) Install race (5), flange cap (3), and four screws (4) to motor (6).




TA190937

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (4) Install bearing (7) and shaft (8) in motor (6).
- (5) Install preformed packing (9) and shaft (10).
- (6) Align timing mark on shaft (10) with timing mark on shaft (8).
- (7) Install spacer plate (11).
- (8) Install seven rollers (12), star (13), and preformed packing (14) in geroler (15).
- (9) Install geroler (15) and align any star point with timing mark on shaft (10).



- (10) Install preformed packing (16), end cap (17), seven washers (18), and screws (19).
- (11) Install preformed packing (20) and elbow (21).



e. *Installation.* Install gasket (1), motor (2), two lockwashers (3), and screws (4).





f. *Follow-on Maintenance.*

- (1) Install hoist drive motor control valve (para 17-21).
- (2) Connect hydraulic drive motor hose and tubes (para 17-2).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-22.1. HOIST DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (M984E1).	
This task covers:	
a. Removal	d. Assembly
b. Disassembly	e. Installation
c. Cleaning/Inspection	f. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>Equipment Condition</i>
M984E1	<i>TM or Para</i>
<i>Test Equipment</i>	Para 17-21.1
None	Para 17-2.1
<i>Special Tools</i>	TM 9-2320-279-10
None	Position crane for access.
<i>Supplies</i>	<i>Special Environmental Conditions</i>
Compound, sealing and thread locking, Item 26, Appendix C	None
<i>Personnel Required</i>	<i>General Safety Instructions</i>
MOS 63W, Wheel vehicle repairer	None
<i>References</i>	<i>Level of Maintenance</i>
None	Direct Support




TA476953

a. Removal. Remove two screws (1), lockwashers (2), motor (3), and gasket (4) from drum (5).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


b. *Disassembly.*

- (1) Remove elbow (1) and preformed packing (2) from end cap (3).
- (2) Remove seven screws (4), end cap (3), and preformed packing (5) from motor (6).




TA476954

- (3) Remove geroler (7), star (8), and seven rollers (9).
- (4) Remove preformed packing (10), plate (11), gear shaft (12), and preformed packing (13) from motor (6).



TA4769:


- (5) Remove shaft (14) and bearing (15) from motor (6).



TA476956


17-22.1 HOIST DRIVE MOTOR REMOVAL/REPAIR INSTALLATION (M984E1) (CONT)

- (6) Remove four screws (16) and flange cap (17) from motor (6).
- (7) Remove race (18) from motor (6).



TA476957

- (8) Remove preformed packing (19) and dust seal (20) from flange cap (17).



TA476958

c. *Cleaning/Inspection.*

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


d. Assembly.

- (1) Install dust seal (1) and preformed packing (2) in flange cap (3).



TA476959

- (2) Apply thread locking and sealing compound to four screws (4).
- (3) Install race (5), flange cap (3), and four screws (4) to motor (6).




TA476960

NOTE

Be sure race is fully seated.


- (4) Install bearing (7) and shaft (8) in motor (6).
- (5) Install preformed packing (9) and gear shaft (10).
- (6) Align timing mark on gear shaft (10) with timing mark on shaft (8).
- (7) Install spacer plate (11).
- (8) Install seven rollers (12), star (13), and preformed packing (14) in geroler (15).
- (9) Install geroler (15) and align any star tip with timing mark on gear shaft (10).




TA476961

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-22.1. HOIST DRIVE MOTOR REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).



- (10) Install preformed packing (16), and end cap (17) with seven screws (18).
- (11) Install preformed packing (19) and elbow (20).




- e. *Installation.* Install gasket (1), motor (2), two lockwashers (3) with screws (4).
- f. *Follow-on Maintenance.*
 - (1) Install hoist drive motor control valve (para 17-21.1).
 - (2) Connect hydraulic drive motor hose and tubes (para 17-2.1).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-23. HOIST ASSEMBLY REPAIR		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
M977, M984E1 , M985	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
None	<i>TM or Para</i>	<i>Condition Description</i>
<i>Special Tools</i>	Para 17-20	Hoist assembly removed.
None	Para 17-24	Hoist brake removed.
<i>Supplies</i>	<i>Special Environmental Conditions</i>	
Compound, sealing and thread locking, Item 26, Appendix C	None	
Adhesive-sealant, silicone, Item 6, Appendix C	<i>General Safety Instructions</i>	
Solvent, dry cleaning, Item 57, Appendix C	None	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheel vehicle repairer	General Support	

a. Disassembly.




- (1) Remove five screws (1), lockwashers (2), and end cap (3).
- (2) Remove drum assembly (4) from bracket (5).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-23. HOIST ASSEMBLY REPAIR (CONT).

- (3) Remove coupling (6).
- (4) Remove retaining ring (7).
- (5) Remove six screws (8), lockwashers (9), and drum end (10) from ring gear (11).




TA189764

- (6) Remove preformed packing (12), oil seal (13), and bearing (14).
- (7) Remove two plugs (15).



TA189765

- (8) Remove sun gear (16) and carrier (17).
- (9) Remove carrier (18) from ring gear (11).




TA189766


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-23. HOIST ASSEMBLY REPAIR (CONT.)


- (10) Remove lockring (19), pin (20), two washers (21), gear (22), and 17 rollers (23).
- (11) Repeat step (10) for other two assemblies.
- (12) Remove retaining ring (24) and drive gear (25) from carrier (17).
- (13) Remove retaining ring (26) from drive gear (25).



- (14) Remove lockring (27), pin (28), two washers (29), gear (30), 34 rollers (31), and separator (32) from carrier (18).
- (15) Repeat step (14) for other two assemblies.
- (16) Remove washer (33).



- (17) Remove eight screws (34) and lockwashers (35).
- (18) Remove drum end (36) from ring gear (11).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (19) Remove preformed packing (37).
- (20) Remove oil seal (38) and bearing (39) from drum end (36).

b. *Cleaning/Inspection.*

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Inspect bearings for grooves, pits, or cracks.
- (4) Inspect gears for chipping, pitting, or wear.
- (5) Replace damaged parts.



TA189770

c. *Assembly.*



TA189771

NOTE

Large slot in bearing faces down.

- (1) Install bearing (1) and oil seal (2).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (2) Apply silicone sealant to drum end (3) and install preformed packing (4).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-23. HOIST ASSEMBLY REPAIR (CONT).


- (3) Apply sealing and thread locking compound to eight screws (5).
- (4) Install drum end (3) with eight lockwashers (6) and screws (5) to ring gear (7).



- (5) Install washer (8).
- (6) Install 34 rollers (9) and separator (10) in gear (11).
- (7) Install gear (11) and two washers (12) in carrier (13).
- (8) Align and install pin (14) and lockring (15).
- (9) Repeat steps (6) through (8) for other two assemblies.




- (10) Install retaining ring (16), drive gear (17), and retaining ring (18).
- (11) Install 17 rollers (19) in gear (20).
- (12) Install gear (20) and two washers (21) in carrier (22).
- (13) Align and install pin (23) and lockring (24).
- (14) Repeat steps (11) through (13) for other two assemblies.



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (15) Install carrier (13), carrier (22), and sun gear (25) in ring gear (7).




TA189775

NOTE

Large slot in bearing faces out.

- (16) Install bearing (26) and oil seal (27) in drum end (28).
- (17) Apply silicone sealant to drum end face (28) and install preformed packing (29).
- (18) Install two plugs (30).




TA189776

- (19) Apply sealing and thread locking compound to six screws (31).
- (20) Install drum end (28) with six lockwashers (32) and screws (31).

NOTE

Do not tip, drum coupling will fall out. Coupling is installed on brake spline.


- (21) Install retaining ring (33) and place coupling (34) in drum end (28).



TA189777

17-23. HOIST ASSEMBLY REPAIR (CONT).


- (22) Install drum assembly (35) in bracket (36).
- (23) Install end cap (37) with five lockwashers (38) and screws (39).
- d. Follow-on Maintenance.
 - (1) Install hoist brake (para 17-24).
 - (2) Install hoist assembly (para 17-20).
 - (3) Fill hoist assembly with oil (LO 9-2320-279-12).



END OF TASK

17-24. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION.		
This task covers:		
a. Removal	d. Assembly	
b. Disassembly	e. Installation	
c. Cleaning/Inspection	f. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
M977, M985	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
None	<i>TM or Para</i>	<i>Condition Description</i>
<i>Special Tools</i>	Para 17-2	Hoist brake hydraulic hose and tubes removed.
None	<i>Special Environmental Conditions</i>	
<i>Supplies</i>	None	
Compound, sealing and thread locking, Item 25, Appendix C	<i>General Safety Instructions</i>	
Compound, sealing, pipe thread, Item 29, Appendix C	None	
Solvent, dry cleaning, Item 57, Appendix C	<i>Level of Maintenance</i>	
<i>Personnel Required</i>	Direct Support	
MOS 63W, Wheel vehicle repairer		


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA189787

a. Removal. Remove five screws (1), lockwashers (2), and brake assembly (3).


b. Disassembly.



TA189788


- (1) Remove two elbows (1) and preformed packings (2) from hoist brake (3).
- (2) Remove check valve (4), fitting (5), spring (6), retainer (7), and ball (8).
- (3) Remove plug (9) and bleeder valve (10).

17-24. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (CONT).



TA189789

- (4) Matchmark hoist brake (3) and remove six screws (11), lockwashers (12), and end cap (13).
- (5) Remove two oil seals (14) and preformed packing (15) from hoist brake (3).
- (6) Remove eight stators (16) and seven discs (17).




TA189997

- (7) Remove six screws (18) and lockwashers (19) from end cap (20).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (8) Remove ring gear (21) from end cap (20).
- (9) Remove preformed packing (22) from ring gear (21).
- (10) Remove clutch assembly (23).




TA189790

- (11) Remove retaining ring (24), gear (25), key (26), and retaining ring (27) from shaft (28).



TA189791

- (12) Remove preformed packing (29) from piston (30).
- (13) Remove piston (30) and six springs (31) from end cap (20).



TA189792

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-24. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (CONT).

(14) Remove preformed packing (32), retaining ring (33), and bearing (34) from end cap (20).

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check stators for wear. If stator is under 0.064 in. (1.62 mm) thick, replace stator.
- (5) Check disc for wear. If disc is under 0.057 in. (1.44 mm) thick, replace disc.

d. *Assembly.*

(1) Install bearing (1), retaining ring (2), and preformed packing (3) in end cap (4).




TA189793



TA189794

(2) Install preformed packing (5) on piston (6).
 (3) Install piston (6) and six springs (7) on end cap (4).




TA189795

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


NOTE

Holes in gear face spline end of shaft.


- (4) Install retaining ring (8), key (9), gear (10), and retaining ring (11) on shaft (12).



- (5) Install preformed packing (13) in ring gear (14).
- (6) Install ring gear (14) on end cap (4).



TA189797



TA189798

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (7) Apply sealing and thread locking compound and install six screws (15) and lockwashers (16) in end cap (4).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-24. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (CONT.)

NOTE

Do not seat clutch assembly.

(8) Install clutch assembly (17) in ring gear (14).





(9) Install seven discs (18) and eight stators (19) alternately in hoist brake (20).

(10) Install preformed packing (21) and two oil seals (22).

(11) Apply sealing and thread locking compound and install six screws (23) and lockwashers (24) in end cap (25).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (12) Apply pipe thread sealing compound and install bleeder valve (26) and plug (27) in hoist brake (20).
- (13) Install ball (28), retainer (29), spring (30), and fitting (31) in check valve (32).
- (14) Apply pipe thread sealing compound and install check valve (32).
- (15) Install two preformed packings (33) and elbows (34).



NOTE

Aline brake with coupling in hoist assembly.

- e. **Installation.** Install brake assembly (1) with five lockwashers (2) and screws (3).
- f. *Follow-on Maintenance.*
 - (1) Fill hoist brake with oil (LO 9-2320-279-12).
 - (2) Connect hoist brake hoses and tubes (para 17-2).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-24.1. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

Compound, sealing and thread locking, Item 26, Appendix C
 Compound, sealing pipe thread, Item 29, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

<i>TM or Para</i>	<i>Condition Description</i>
Para 17-2.1	Hoist brake hydraulic hose and tubes removed.
TM 9-2320-279-10	Position crane for access.

Special Environmental Conditions


None

General Safety Instructions

None

Level of Maintenance

Direct Support




TA476964

a. Removal. Remove five screws (1), washers (2), and hoist brake assembly (3).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

b. Disassembly.


- (1) Remove two elbows (1) and preformed packings (2) from hoist brake (3).
- (2) Remove check valve (4), fitting (5), spring (6), retainer (7), and ball (8).
- (3) Remove plug (9) and bleeder valve (10).



- (4) Matchmark hoist brake (3) and remove six screws (11), lockwashers (12), and end cap (13).
- (5) Remove two oil seals (14) and preformed packing (15) from hoist brake (3).
- (6) Remove eight stators (16) and seven discs (17).



- (7) Remove six screws (18) and lockwashers (19) from end cap (20).




TA476966

TA476967


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-24.1. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).


- (8) Remove ring gear (21) from end cap (20).
- (9) Remove preformed packing (22) from ring gear (21).
- (10) Remove clutch assembly (23) from end cap (20).



- (11) Remove retaining ring (24), gear (25), key (26), and retaining ring (27) from shaft (28).




- (12) Remove preformed packing (29) from piston (30).
- (13) Remove piston (30) and six springs (31) from end cap (20).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (14) Remove preformed packing (32), retaining ring (33), and bearing (34) from end cap (20).



TA476971

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Check stators for wear. If stator is under 0.064 in. (1.64 mm) thick, replace stator.
- (5) Check disc for wear. If disc is under 0.057 in. (1.45 mm) thick, replace disc.
- (6) Measure spring length. If spring is under 1.375 in. (34.9 mm), replace spring.

d. *Assembly.*

- (1) Install bearing (1), retaining ring (2), and preformed packing (3) in end cap (4).




TA476972

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-24.1. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (2) Install preformed packing (5) on piston (6).
- (3) Install piston (6) and six springs (7) on end cap (4).




TA476973

NOTE


Holes in gear, face spline end of shaft.

- (4) Install retaining ring (8), key (9), gear (10), and retaining ring (11) on shaft (12).



TA476974


- (5) Install preformed packing (13) in ring gear (14).
- (6) Install ring gear (14) on end cap (4).



TA476975

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (7) Apply thread locking and sealing compound and install six screws (15) and lockwashers (16) in end cap (4).




NOTE

Do not seat clutch assembly.

- (8) Install clutch assembly (17) in ring gear (14).




- (9) Install seven discs (18) and eight stators (19) alternately in hoist brake (20).
 (10) Install clutch assembly (17) until flush with top stator (19).
 (11) Install preformed packing (21) and two oil seals (22).
 (12) Apply thread locking and sealing compound and install six screws (23), lockwashers (24), and end cap (25).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-24.1. HOIST BRAKE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (13) Apply pipe thread sealing compound and install bleeder valve (26) and plug (27) in hoist brake (20).
- (14) Install ball (28), retainer (29), spring (30), and fitting (31) in valve (32).
- (15) Apply pipe thread sealing compound and install valve (32).
- (16) Install two preformed packings (33) and elbows (34).
- (17) Seat clutch assembly (17).




TA476979

NOTE

Align brake with coupling in hoist assembly.

e. Installation. Install hoist brake assembly (1) with five washers (2) and screws (3).



TA476980

f. Follow-on Maintenance.


- (1) Fill brake with oil (LO 9-2320-279-12).
- (2) Connect hoist brake hoses and tubes (para 17-2.1).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

7-25. HOIST ADJUSTMENT (M977 AND M985).	
This task covers:	
a. Adjustment	b. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i> TM or Para TM 9-2320-279-10 Shut off engine.
<i>Test Equipment</i> None	TM 9-2320-279-10 Outriggers extended.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> None	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support
<i>References</i> None	

a. Adjustment.




NOTE

Crane must be at normal operating temperature for adjustment.

- (1) Remove cap (1) and attach suitable pressure gage to test port (2).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (2) Loosen screw (3) and remove plug (4) and seal (5).
- (3) Remove plug (6) and preformed packing (7).




- (4) Put crane in operating condition (TM 9-2320-279-10).


CAUTION

Do not operate crane with boom below horizontal when there is a load on hook.

- (5) Attach crane hook (8) to an immovable object (9).




- (6) While operating HOIST control lever (10) UP, adjust internal screw (11) until gage reads between 1900 psi (13 100 kPa) and 2100 psi (14 480 kPa) for M977 or between 2100 psi (14 480 kPa) and 2300 psi (15 858 kPa) for M985.




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-25. HOIST ADJUSTMENT (M977 AND M985) (CONT).


- (7) Remove crane hook (8) from immovable object (9).
- (8) Return crane to stowed position (TM 9-2320-279-10).



- (9) Install preformed packing (7) and plug (6).
- (10) Install seal (5) and plug (4) and tighten screw (3).



- (10) Remove gage from test port (2).
- (12) Install cap (1).



b. Follow-on Maintenance. None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-25.1 HOIST ADJUSTMENT (M984E1).

This task covers:

- a. Adjustment
- b. Follow-on Maintenance

INITIAL SETUP

Models
M984E1

References
None

Test Equipment
None

Equipment Condition

<i>TM or Para</i>	<i>Condition Description</i>
TM 9-2320-279-10	Shut off engine.
TM 9-2320-279-10	Outriggers extended.

Special Tools
None

Special Environmental Conditions
None

Supplies
None

General Safety Instructions
None

Personnel Required
MOS 63W, Wheel vehicle repairer (2)


Level of Maintenance
Direct Support

a. Adjustment.

NOTE

Crane must be at normal operating temperature for adjustment.

- (1) Remove cap (1) and attach suitable pressure gage to test port (2).
- (2) Loosen screw (3) and remove plug (4) and seal (5).



NOTE


Plug and internal screw are located in lower right corner of valve body.

- (3) Remove plug (6) and preformed packing (7).
- (4) Push up and hold solenoid valve button (8).
- (5) Put crane in operating condition (TM 9-2320-279-10).

CAUTION

Do not operate crane with boom below horizontal when there is a load on hook.

- (6) Attach crane (9) to an immovable object (10).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-25.1 HOIST ADJUSTMENT (M984E1) (CONT).


CAUTION

Be sure crane is engaged in high idle. Low idle may cause damage to crane.


- (7) While operating hoist up lever (11), adjust internal screw (12) until gage reads between 1700 psi (11721.5 kPa) and 1900 psi (13 100 kPa).



- (8) Remove crane (9) from immovable object (10).
- (9) Return crane to stowed position (TM 9-2320-279-10).



- (10) Release solenoid valve button (8).
- (11) Install preformed packing (7) and plug (6).
- (12) Install seal (5) and plug (4), and tighten screw (3).
- (13) Remove gage from test port (2).
- (14) Install cap (1).



b. Follow-on Maintenance. None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Section VI. CRANE CONTROL SYSTEMS

17-26. EIGHT BANK VALVE BODY AND MOUNTING BRACKET REMOVAL/INSTALLATION.

This task covers:

- a. Removal
- b. Installation
- c. Follow-on Maintenance

INITIAL SETUP


Models M977, M985	Equipment Condition TM or Para Para 17-2	Condition Description Outrigger and mast hydraulic hoses removed from main control valve. Main hydraulic lines disconnected.
Test Equipment None	Para 17-2	
Special Tools None	Para 17-2	
Supplies Tags, identification, Item 60, Appendix C	Special Environmental Conditions None	
Personnel Required MOS 63W, Wheel vehicle repairer	General Safety Instructions None	
References None	Level of Maintenance Direct Support	

a. Removal.

- (1) Remove four screws (1) and cover (2) from valve body and mounting bracket (3).
- (2) Remove four clips (4).

NOTE

- M977 crane has 10 connectors.
- M985 crane has nine connectors.
- (3) Loosen nine screws (5) and remove connectors (6) and seals (7).




TA189537

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-26. EIGHT BANK VALVE BODY AND MOUNTING BRACKET REMOVAL/INSTALLATION (CONT).

- (4) Attach suitable lifting device to valve body and mounting bracket (3).




TA189538

NOTE

Note position of screws.

- (5) Remove four screws (8), washers (9), and nuts (10).
- (6) Move valve body and mounting bracket (3) away from crane (11).




TA189539

NOTE

Tag and mark hoses before disconnecting.

- (7) Disconnect nine hoses (12) from valve body (13).
- (8) Loosen three screws (14) and remove three connectors (15) and seals (16).




TA189540


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

b. *Installation.*

(1) Aline valve body and mounting bracket (1).



TA189541




TA189542

(2) Connect nine hoses (2) to valve body (3).

(3) Install three seals (4), connectors (5), and tighten screws (6).

(4) Install four screws (7), washers (8), and nuts (9).




TA189543

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-26. EIGHT BANK VALVE BODY AND MOUNTING BRACKET REMOVAL/INSTALLATION (CONT).

NOTE

- M977 crane has 10 connectors.
 - M985 crane has nine connectors.
- (5) Install nine seals (10) and connectors (11).
 - (6) Tighten nine screws (12).
 - (7) Install four clips (13).
 - (8) Install cover (14) with four screws (15).
- c. Follow-on Maintenance.
- (1) Install outrigger and mast hydraulic hoses to main control valve (para 17-2).
 - (2) Connect main hydraulic lines (para 17-2).



END OF TASK

TA189544

17-27. EIGHT BANK VALVE BODY MOUNTING BRACKET REMOVAL/INSTALLATION.

This task covers:

- a. Removal
- b. Installation
- c. Follow-on Maintenance

INITIAL SETUP

Models

M977, M985

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Para 17-26

Para 17-30

TM 9-2320-279-20

Condition Description

Eight bank valve body and mounting bracket removed.

Accumulator removed.

Crane controls removed.

Special Environmental Conditions

None

General Safety Instructions

None


Level of Maintenance

Direct Support


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Removal.


(1) Disconnect two hydraulic lines (1).



(2) Remove four screws (2) and lockwashers (3).
 (3) Remove four screws (4) and lockwashers (5).



(4) Remove mounting bracket (6) from valve body (7).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-27. EIGHT BANK VALVE BODY MOUNTING BRACKET REMOVAL/INSTALLATION (CONT).

b. Installation.

- (1) Aline and install mounting bracket (1) on valve body (2).




- (2) Install four screws (3) and lockwashers (4).
- (3) Install four screws (5) and lockwashers (6).



- (4) Connect two hydraulic lines (7).

c. Follow-on Maintenance.

- (1) Install eight bank valve body and mounting bracket (para 17-26).
- (2) Install accumulator (para 17-30).
- (3) Install crane controls (TM 9-2320-279-20).



END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28. EIGHT BANK VALVE BODY REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

M977, M985

Test Equipment

None

Special Tools

None

Supplies

Solvent, dry cleaning, Item 57, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

Eight bank valve body on clean work surface.

Para 17-27

Eight bank valve body mounting bracket removed.

Special Environmental Conditions

None

General Safety Instructions

None

Level of Maintenance


General Support

a. Disassembly.


NOTE

All four pilot valves are disassembled the same way.

- (1) Remove four caps (1), screws (2), and pilot valve assembly (3).
- (2) Remove four preformed packings (4) and plate (5).



- (3) Remove eight screws (6), two solenoids (7), and preformed packings (8).
- (4) Remove spool (9) from pilot valve (10).



TA189864

TA189865


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).


NOTE

All four top directional valves are disassembled the same way.

- (5) Remove three caps (11), four screws (12), and directional valve (13).
- (6) Remove five preformed packings (14) and two preformed packings (15).



TA189866




TA189867

NOTE


Gear may be assembled for right or left hand use.

- (7) Remove screw (16) and seal washer (17).
- (8) Remove fitting (18) and preformed packing (19).
- (9) Matchmark position of gear (20) and remove.
- (10) Remove two backup rings (21) and two preformed packings (22) from gear (20).
- (11) Remove four screws (23), cap (24), and preformed packing (25) from directional valve (13).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)




- (12) Remove four screws (26), cap (27), and preformed packing (28).
- (13) Remove spool (29) from directional valve (13).
- (14) Remove screw (30), spring seat (31), spring (32), backup ring (33), and spring seat (34) from Spool (29).



- (15) Remove four caps (35), two screws (36), two screws (37), valve body (38), two preformed packings (39), and two preformed packings (40).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).



TA189870


- (16) Remove plug (41), preformed packing (42), orifice (43), and preformed packing (44).
- (17) Remove valve (45), preformed packing (46), preformed packing (47), and spring (48).
- (18) Remove four screws (49), end cap (50), preformed packing (51), and spool (52) from valve body (38).



TA189871

- (19) Remove nine plugs (53) and preformed packings (54).
- (20) Remove eight fittings (55) and preformed packings (56).
- (21) Remove fitting (57) and preformed packing (58).
- (22) Remove elbow (59) and preformed packing (60) from valve body (61).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



NOTE

- A standard 4-40 x 2 screw can be threaded into the end of the shuttle valves to aid in disassembly.
- All three valve body shuttle valves are disassembled the same way.

(23) Remove plug (62), preformed packing (63), and shuttle valve (64).

NOTE

Preformed packings and backup ring may stay in valve body.

(24) Remove two preformed packings (65) and backup ring (66).

NOTE

Both shuttle block valves are removed the same way.


(25) Remove two screws (67), shuttle block (68), and three preformed packings (69) from valve body (61).

(26) Remove plug (70), preformed packing (71), shuttle valve (72), two preformed packings (73), and backup ring (74).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).

- (27) Remove cap (75), tee (76), fitting (77), and preformed packing (78).




TA189873

NOTE

All bottom directional valves are removed the same way.

- (28) Remove two fittings (79) and preformed packings (80).
- (29) Remove four screws (81), directional valve (82), three preformed packings (83), and two preformed packings (84).




TA189874

NOTE


Gear may be assembled for right or left hand use.

- (30) Remove screw (85) and seal washer (86).
- (31) Remove fitting (87) and preformed packing (88).
- (32) Matchmark position of gear (89) and remove.
- (33) Remove two backup rings (90) and preformed packings (91) from gear (89).
- (34) Remove four screws (92), cap (93), and preformed packing (94) from directional valve (82).




TA189875

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA189876

- (35) Remove four screws (95), cap (96), and preformed packing (97).
- (36) Remove spool (98) from directional valve (82).
- (37) Remove screw (99), spring seat (100), spring (101), backup ring (102), and spring seat (103) from SPOOL (98).



TA189877


NOTE

All three solenoids are disassembled the same way.

- (38) Remove nut (104), plate (105), cover (106), solenoid (107), and end cap (108) from valve (109).

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).

(39) Remove valve (109), preformed packing (110), backup ring (111), and preformed packing (112) from valve body (61).



TA189878

(40) Remove plug (113) and preformed packing (114).


(41) Remove adjustment screw (115), spring (116), and relief valve (117) from valve body (61).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.




TA189879

c. *Assembly.*

NOTE

All three solenoids are assembled the same way.

- (1) Install preformed packing (1), backup ring (2), preformed packing (3), and valve (4) in valve body (5).




TA189880

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


NOTE

Beveled end of end cap faces down.

- (2) Install end cap (6), solenoid (7), cover (8), plate (9), and nut (10) on valve (4).



TA189881



TA189882


- (3) Install spring seat (11), backup ring (12), spring (13), spring seat (14), and screw (15) to spool (16).
 (4) Install spool (16) in directional valve (17).
 (5) Install preformed packing (18) and cap (19) with four screws (20).

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).


NOTE

Gear may be assembled for right or left hand use.


- (6) Install preformed packing (21) and cap (22) with four screws (23).
- (7) Install two preformed packings (24) and backup rings (25) on gear (26). Aline gear in cap (22).
- (8) Install preformed packing (27) and fitting (28).
- (9) Install seal washer (29) and screw (30) in cap (22).




- (10) Install two preformed packings (31) and three preformed packings (32).
- (11) Install directional valve (17) with four screws (33) in valve body (5).
- (12) Install two preformed packings (34) and fittings (35).



- (13) Install preformed packing (36), fitting (37), tee (38), and cap (39) in valve body (5).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA189886

NOTE

Both shuttle block valves are assembled the same way.

- (14) Install two preformed packings (40), backup ring (41), shuttle valve (42), preformed packing (43), and plug (44) in shuttle block (45).
- (15) Install three preformed packings (46) and shuttle block (45) with two screws (47).


NOTE

All three valve body shuttle valves are assembled the same way.

- (16) Install two preformed packings (48), backup ring (49), shuttle valve (50), preformed packing (51), and plug (52) in valve body (5).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).



TA189887


- (17) Install preformed packing (53) and elbow (54).
- (18) Install preformed packing (55) and fitting (56).
- (19) Install eight preformed packings (57) and fittings (58).
- (20) Install nine preformed packings (59) and plugs (60) in valve body (5).



TA189888


- (21) Install spool (61), preformed packing (62), end cap (63), and four screws (64) in valve body (65).
- (22) Install spring (66), preformed packing (67), preformed packing (68), and valve (69).
- (23) Install preformed packing (70), orifice (71), preformed packing (72), and plug (73).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA189889

- (24) Install two preformed packings (74) and two preformed packings (75) in valve body (65).
- (25) Install valve body (65), two screws (76), two screws (77), and four caps (78).



TA189890


- (26) Install spring seat (79), backup ring (80), spring (81), spring seat (82), and screw (83) on spool (84).
- (27) Install spool (84) in directional valve (85).
- (28) Install preformed packing (86) and cap (87) with four screws (88).

17-28. EIGHT BANK VALVE BODY REPAIR (CONT).

NOTE

Gear may be assembled for right or left hand use.

- (29) Install preformed packing (89), cap (90), and four screws (91) on directional valve (85).
- (30) Install two preformed packings (92) and two backup rings (93) on gear (94).
- (31) Aline and install gear (94) in cap (90).
- (32) Install preformed packing (95) and fitting (96).
- (33) Install seal washer (97) and screw (98).




TA189891

- (34) Install two preformed packings (99) and five preformed packings (100) in valve body (5).

NOTE


All four top directional valves are assembled the same way.

- (35) Install directional valve (85) on valve body (5) with four screws (101) and three caps (102).




TA189892

- (36) Install spool (103) in pilot valve (104).
- (37) Install two preformed packings (105) and solenoids (106) with eight screws (107) on pilot valve (104).



TA189893

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)




(38) Install plate (108) and four preformed packings (109) on directional valve (85).

NOTE

- All four pilot valves are assembled the same way.
- Be sure to aline port holes in pilot valve assembly with port holes in directional valve.

(39) Install pilot valve assembly (110) with four screws (111) and caps (112)



(40) Install relief valve (113), spring (114), and adjustment screw (115) in valve body (5).

(41) Install preformed packing (116) and plug (117).

d. Follow-on Maintenance.

- (1) Install eight bank valve body (para 17-27).
- (2) Adjust hoist relief valve (para 17-25).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.1. RIGHT HAND CONTROL VALVES MOUNTING BRACKET REMOVAL/INSTALLATION (M984E1).		
This task covers:		
a. Removal	c. Follow-on Maintenance	
b. Installation		
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
M984E1	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 17-28.3	Right hand rear control valve removed.
None	Para 17-28.4	Right hand front control valve removed.
<i>Special Tools</i>	Para 17-32.1	Liftdown and shutdown solenoids removed.
None	Para 17-30	Accumulator removed.
<i>Supplies</i>	Para 6-11.1	Junction box removed.
None		
<i>Personnel Required</i>	<i>Special Environmental Conditions</i>	
MOS 63W, Wheel vehicle repairer	None	
<i>References</i>	<i>General Safety Instructions</i>	
None	None	
	<i>Level of Maintenance</i>	
	Direct Support	

a. Removal.


- (1) Remove two hydraulic lines (1).
- (2) Attach a suitable lifting device to bracket (2).
- (3) Remove six nuts (3), lockwashers (4), screws (5), and bracket (2) from crane bracket (6).

b. Installation.

- (1) Aline and install bracket (2) on crane bracket (6).
- (2) Install six screws (5), lockwashers (4), and nut (3).
- (3) Install two hydraulic lines (1).

c. Follow-on Maintenance.

- (1) Install right hand rear control valve (para 17-28.3).
- (2) Install right hand front control valve (para 17-28.4).
- (3) Install liftdown and shutdown solenoids (para 17-32.1).
- (4) Install accumulator (para 17-30).
- (5) Install junction box (para 6-11.1).



END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.2. LEFT HAND CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|------------------------|--------------------------|
| a. Removal | d. Assembly |
| b. Disassembly | e. Installation |
| c. Cleaning/Inspection | f. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

TM 9-2320-279-20

Para 17-2

Condition Description

Crane control handles removed.

Hydraulic hoses and tubes removed.

Special Environmental Conditions

None



General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal.




TA476584

- (1) Loosen four screws (1) and remove cover (2) from mounting bracket (3).
- (2) Remove four washers (4), screws (1), and washers (5) from cover (2).
- (3) Remove four clips (6) from bracket (3).

17-28.2. LEFT HAND CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1)


- (4) Remove elbow (7) and preformed packing (8) from valve (9).
- (5) Remove three screws (10), lockwashers (11), and valve (9) from bracket (3).



TA476585

b. Disassembly.

- (1) Remove two fittings (1) and preformed packings (2) from valve body (3).




TA476586

NOTE

All directional valves are removed and repaired the same. Matchmark valve to body.

- (2) Remove two fittings (4) and preformed packings (5).
- (3) Remove four caps (6), screws (7), and directional valve (8) from valve body (3).
- (4) Remove three preformed packings (9) and two preformed packings (10).




TA476587

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE


Gear may be installed for right or left hand use.

- (5) Remove screw (11) and seal washer (12).
- (6) Matchmark position of gear (13).
- (7) Remove four screws (14), cap (15), and preformed packing (16) from directional valve (8).



TA476588

- (8) Remove four screws (17), cap (18), and preformed packing (19).
- (9) Remove spool (20) from directional valve (8).
- (10) Remove screw (21), seat (22), spring (23), and seat (24) from spool (20).



TA476589

- (11) Remove two plugs (25) and preformed packings (26).
- (12) Remove plug (27) and preformed packing (28).
- (13) Remove two plugs (29) and preformed packings (30).

NOTE


A standard 4-40 x 2 screw will aid in removal of shuttle valves. Valves may separate on removal. Replace valves if separated.

- (14) Remove two plugs (31), preformed packings (32), and shuttle valves (33) from valve body (3).

NOTE

Preformed packings and backup ring may stay in body.

- (15) Remove two preformed packings (34) and backup ring (35) from shuttle valves (33).



TA476590

17-28.2. LEFT HAND CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1)

c. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect all parts for damage.
- (3) Replace damaged parts.
- (4) Replace centering spring if under 0.940 in. (23.0 mm).


d. *Assembly.*

- (1) Install two preformed packings (1) and backup ring (2) on shuttle valve (3).
- (2) Install shuttle valve (3), preformed packings (4), and two plugs (5) in valve body (6).
- (3) Install two preformed packings (7) and plugs (8).
- (4) Install preformed packing (9), plug (10), two preformed packings (11), and plugs (12).



TA476591


- (5) Install seat (13), spring (14), seat (15), and screw (16) on spool (17).
- (6) Install spool (17) in valve (18).
- (7) Install preformed packing (19), cap (20) with four screws (21).



TA476592


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (8) Align and install preformed packing (22), cap (23) with four screws (24) on valve (18).
- (9) Install seal washer (25) and screw (26).




TA476593

- (10) Install two preformed packings (27) and three preformed packings (28) in directional valve (18).
- (11) Install valve (18) with four screws (29) and caps (30).
- (12) Install six preformed packings (31) and fittings (32).



TA476594

- (13) Install two preformed packings (33) and fittings (34) in valve body (6).




TA476595

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.2. LEFT HAND CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1)

e. *Installation.*


- (1) Install valve body (1) in bracket (2) with three lockwashers (3) and screws (4).
- (2) Install preformed packing (5) and elbow (6).



- (3) Install four clips (7).
- (4) Install eight washers (8) with four screws (9) in cover (10).
- (5) Install cover (10).

f. *Follow-on Maintenance.*

- (1) Install hydraulic lines (para 17-2).
- (2) Install control handles (TM 9-2320-279-20).
- (3) Check crane operation (TM 9-2320-279-10).



END OF TASK

17-28.3. RIGHT HAND REAR CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- a. Removal
- b. Disassembly
- c. Cleaning/Inspection
- d. Assembly
- e. Installation
- f. Follow-on Maintenance

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

TM 9-2320-279-20 Crane control handles removed.

Special Environmental Conditions

None

General Safety Instructions



None

Level of Maintenance

Direct Support


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Removal.




TA476598

- (1) Loosen four screws (1) and cover (2) from bracket (3).
- (2) Remove four washers (4), screws (1), and washer (5) from cover (2).
- (3) Remove four clips (6) from bracket (3).
- (4) Disconnect eleven hydraulic hoses (7).
- (5) Disconnect two hydraulic lines (8).



TA476599

- (6) Remove two screws (9), lockwashers (10), screw (11), and lockwasher (12) from each side of bracket (3).
- (7) Remove valve body (13) from bracket (3).



TA476600

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-28.3. RIGHT HAND REAR CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

b. Disassembly.

NOTE

All four top directional valves are removed and repaired the same way. Matchmark valve to control body.

- (1) Remove elbow (1), preformed packing (2), fitting (3), and preformed packing (4).
- (2) Remove four caps (5), four screws (6), and directional valve (7).
- (3) Remove three preformed packings (8) and two preformed packings (9).




- (4) Remove screw (10) and seal washer (11).


NOTE

A 1/4 in. (6.3 mm) allen wrench will have to be cut down approximately 1/2 in. (12.7 mm).


- (5) Remove four screws (12), cap (13), and preformed packing (14) from directional valve (7).



- (6) Remove four screws (15), cap (16), and preformed packing (17).
- (7) Remove spool (18) from valve (7).
- (8) Remove screw (19), spring seat (20), spring (21), and spring seat (20) from spool (18).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476604

- (9) Remove seven plugs (22) and preformed packings (23) from valve body (24).
 (10) Remove two fittings (25), preformed packings (26), fitting (27), and preformed packing (28).
 (11) Remove fitting (29), preformed packing (30), elbow (31), and preformed packing (32).

NOTE

- A standard 4-40x2 screw will thread into the end of the shuttle valves to aid in removal.
 - Valves may separate. Replace valve if separated.
 - Preformed packings and backup ring may stay in body.
- (12) Remove plug (33), preformed packing (34), shuttle valve (35), two preformed packings (36), and backup ring (37).
 (13) Repeat step (12) for other three shuttle valves.

c. *Cleaning/Inspection.*WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Replace centering spring if under 0.940 in. (23.0 mm).

17-28.3. RIGHT HAND REAR CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

d. Assembly.

- (1) Install two preformed packings (1) and backup ring (2) on shuttle valve (3).
- (2) Install shuttle valve (3), preformed packing (4), and plug (5) in valve body (6).
- (3) Repeat steps (1) and (2) for other three shuttle valves.
- (4) Install preformed packing (7), elbow (8), preformed packing (9), and fitting (10).
- (5) Install preformed packing (11), fitting (12), two preformed packings (13), and fittings (14).
- (6) Install seven preformed packings (15) and plugs (16).




TA476605

NOTE


All four directional valves are assembled and installed the same.

- (7) Install spring seat (17), spring (18), spring seat (17), and screw (19) on spool (20).
- (8) Install spool (20) in valve (21).
- (9) Install preformed packing (22) and end cap (23) with four screws (24).



TA476606


- (10) Install preformed packing (25) and end cap (26) on valve (21) with four screws (27).
- (11) Install seal washer (28) and screw (29).



TA476607

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (12) Install two preformed packings (30) and three preformed packings (31) in valve (21).
- (13) Install valve (21) with four screws (32) and caps (33).
- (14) Install preformed packing (34), fitting (35), preformed packing (36), and elbow (37).



TA476608


e. Installation.

- (1) Install valve body (1) in bracket (2) with two screws (3), lockwashers (4), screw (5), and lockwasher (6).
- (2) Repeat step (1) for other side.



TA476609

- (3) Install two hydraulic lines (7).
- (4) Connect 11 hydraulic hoses (8).




TA476610

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.3. RIGHT HAND REAR CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (5) Install four clips (9) on bracket (2).
- (6) Install four screws (10), washers (11), and washers (12) in cover (13).
- (7) Install cover (13) on bracket (2).
- f. *Follow-on Maintenance.*
 - (1) Replace crane handles (TM 9-2320-279-20).
 - (2) Check operation of controls (TM 9-2320-279-20).
 - (3) Check for leaks.



END OF TASK

17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|--|--|
| <ul style="list-style-type: none"> a. Removal b. Disassembly c. Cleaning/Inspection | <ul style="list-style-type: none"> d. Assembly e. Installation f. Follow-on Maintenance |
|--|--|

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

TM 9-2320-279-20 Crane control handles removed.

Special Environmental Conditions

None

General Safety Instructions



None

Level of Maintenance

Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Removal.




TA476612

- (1) Loosen four screws (1) and remove cover (2) from bracket (3).
- (2) Remove four washers (4), screws (1), and washers (5) from cover (2).
- (3) Remove four clips (6) from bracket (3).

NOTE

To remove right rear hand plug do step (6) only.
Do steps (4) and (5) for other six plugs.

- (4) Loosen three screws (7) and remove one screw (7) from each solenoid (8).
- (5) Turn solenoid (8) to remove plug (9).
- (6) Loosen 8 screws (10) and remove plugs (9) and seals (11).



TA476613


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

NOTE

Tag and mark all hydraulic hoses and lines.

- (7) Disconnect nine hydraulic hoses (12) and three hydraulic lines (13).




TA476614

- (8) Remove two screws (14), lockwashers (15), screw (16), and lockwasher (17) from bracket (3).

- (9) Repeat step (8) for other side.
- (10) Remove valve body (18) from bracket (3).

RIGHT HAND REAR CONTROL VALVE BODY SHOWN REMOVED FOR CLARITY




TA476615

b. Disassembly.

NOTE

All four pilot valves are removed and repaired the same.


- (1) Remove four caps (1), screws (2), and pilot valve assembly (3).
- (2) Remove three preformed packings (4), preformed packing (5), and plate (6).



TA476616

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3) Remove six screws (7), two solenoids (8), and preformed packings (9).
- (4) Remove spool (10) from pilot valve (3).




TA476617

NOTE


All four top directional valves are removed and repaired the same way. Matchmark valve to body.

- (5) Remove three caps (11), four screws (12), and directional valve (13).
- (6) Remove five preformed packings (14) and two preformed packings (15).



TA476618

- Mark position of gear to cap.
- A 1/4 in. (6.3 mm) allen wrench will have to be cut down approximately 1/2 in. (12.7 mm).
- (7) Remove screw (16) and seal washer (17).
- (8) Remove four screws (18), cap (19), and preformed packing (20) from directional valve (13).




TA476619

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (9) Remove four screws (21), cap (22), and preformed packing (23).
- (10) Remove spool (24) from valve (13).
- (11) Remove screw (25), seat (26), backup ring (27), spring (28), and seat (29) from spool (24).




TA476620

- (12) Remove two caps (30) and caps (31).
- (13) Remove two screws (32), screws (33), and valve (34).
- (14) Remove two preformed packings (35) and two preformed packings (36) from valve body (37).



TA476621



- (15) Remove plug (38), preformed packing (39), screw (40), and preformed packing (41).
- (16) Remove valve (42), preformed packings (43), preformed packing (44), washer (45), and spring (46).
- (17) Remove four screws (47), end cap (48), preformed packing (49), and spool (50) from valve (34).



TA476622

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (18) Remove six plugs (51) and preformed packings (52).
- (19) Remove six fittings (53) and preformed packings (54).
- (20) Remove two fittings (55) and preformed packing (56).
- (21) Remove two fittings (57) and preformed packing (58).
- (22) Remove three plugs (59) and preformed packing (60) from valve body (37).



NOTE

- A standard 4-40x2 screw will thread into the end of the shuttle valves to aid in removal.
- Valves may separate. Replace valves if separated.
- Both valve body shuttle valves are removed the same.

- (23) Remove plug (61), preformed packing (62), and shuttle valve (63).

NOTE

Preformed packings and backup ring may stay in body.

- (24) Remove two preformed packings (64) and backup ring (65).


NOTE

Both shuttle block valves are removed the same.

- (25) Remove two screws (66), shuttle block (67), and three preformed packings (68) from valve body (37).
- (26) Remove plug (69), preformed packing (70), shuttle valve (71), two preformed packings (72), and backup ring (73).


17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (27) Remove fitting (74) and preformed packing (75).
- (28) Remove cap (76), tee fitting (77), fitting (78), and preformed packing (79) from valve body (37).



TA476628

- (29) Remove cap (80), and preformed packing (81).
- (30) Remove setscrew (82), spring (83), and relief valve (84) from valve body (37).



TA476625

c. Cleaning/Inspection.


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Replace centering spring if free length is under 0.940 in. (23.0 mm).
- (5) Replace valve springs if under 0.800 in. (20.0 mm).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

d. Assembly.



TA476626

- (1) Install relief valve (1), spring (2), and setscrew (3) in valve body (4).
- (2) Install preformed packing (5) and plug (6).




TA476627

- (3) Install preformed packing (7) and fitting (8) in valve body (4).
- (4) Install preformed packing (9), fitting (10), tee fitting (11), and cap (12).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).



TA476629

NOTE


Both shuttle block valves are installed the same. Be sure shuttle valve is seated.

- (5) Install two preformed packings (13), backup ring (14), shuttle valve (15), preformed packing (16), and cap (17) in shuttle block (18).
- (6) Install three preformed packings (19) and shuttle block (18) with two screws (20).

NOTE


Both valve body shuttle valves are installed the same.

- (7) Install two preformed packings (21), backup ring (22), shuttle valve (23), preformed packing (24), and plug (25) in valve body (4).
- (8) Install three preformed packings (26) and plugs (27).
- (9) Install two preformed packings (28) and fittings (29).
- (10) Install six preformed packings (30) and fittings (31).
- (11) Install two preformed packings (32) and fittings (33).
- (12) Install six preformed packings (34) and plugs (35) in valve body (4).



TA476630


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476631

- (13) Install spool (36), preformed packing (37), end cap (38), and four screws (39) in valve (40).
- (14) Install spring (41), washer (42), preformed packing (43), preformed packing (44), and valve (45).
- (15) Install preformed packing (46), screw (47), preformed packing (48), and plug (49).

- (16) Install two preformed packings (50) and two preformed packings (51) in valve (40).
- (17) Install valve (40), two screws (52), two screws (53), two caps (54), and two caps (55).




TA476632

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (18) Install seat (56), spring (57), backup ring (58), seat (59), and screw (60) on spool (61).
- (19) Install spool (61) in directional valve (62).
- (20) Install preformed packing (63) and end cap (64) with four screws (65).




TA476633

NOTE


A 1/4 in. (6.3 mm) allen wrench will have to be cut down approximately 1/2 in. (12.7 mm).

- (21) Install preformed packing (66), cap (67), and four screws (68).
- (22) Install seal washer (69) and screw (70) in cap (67).



TA476634


- (23) Install two preformed packings (71) and five preformed packings (72) in valve body (4).
- (24) Install directional valve (62) to valve body (4) with four screws (73) and three caps (74).



TA476635

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (25) Install spool (75) in pilot valve (76).
- (26) Install two preformed packings (77), solenoid (78) with eight screws (79) to pilot valve (76). Do not tighten screws.




TA476636

- (27) Install plate (80), three preformed packings (81), and preformed packing (82) on directional valve (62).

NOTE

Be sure to align port holes in pilot valve assembly with port holes in directional valve.


- (28) Install pilot valve assembly (76) with four screws (83) and caps (84).



TA476637

e. Installation.

- (1) Install valve body (1) in bracket (2) with two screws (3), lockwashers (4), screw (5), and lockwasher (6).
- (2) Repeat step (1) for other side.




TA476638

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-28.4. RIGHT HAND FRONT CONTROL VALVE BODY REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- (3) Connect nine hydraulic hoses (7) and three hydraulic lines (8).




TA476639

NOTE

Do not remove screw from right rear plug.

- (4) Remove seven screws (9) from each solenoid (10).
- (5) Turn seven solenoids (10) up.
- (6) Install eight seals (11), plugs (12), and screws (13).
- (7) Turn seven solenoids (10) down and install seven screws (9).
- (8) Tighten 32 screws (9) on eight solenoids (10).




TA476640

- (9) Install four screws (14) with eight washers (15) in cover (16).
- (10) Install four clips (17) on bracket (2).
- (11) Install cover (16) on bracket (2) with four screws (14).

f. Follow-on Maintenance.

- (1) Install control handles (TM 9-2320-279-20).
- (2) Check crane operation (TM 9-2320-279-10).
- (3) Check for leaks.

END OF TASK




TA476641

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-29. SOLENOID REMOVAL/INSTALLATION.	
This task covers:	
a. Removal	c. Follow-on Maintenance
b. Installation	
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i> TM or Para Condition Description TM 9-2320-279-10 Shut off engine.
<i>Test Equipment</i> None	<i>Special Environmental Conditions</i> None
<i>Special Tools</i> None	<i>General Safety Instructions</i> None
<i>Supplies</i> None	<i>Level of Maintenance</i> Direct Support
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	
<i>References</i> None	

a. Removal.




NOTE

All solenoids are removed the same way.

- (1) Loosen four screws (1) and remove cover (2).
- (2) Loosen screw (3). Remove connector (4) and seal (5).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



(3) Remove four screws (6), solenoid (7), and preformed packing (8).

NOTE

Spool may be up in shift block. Pull handle to release spool.


(4) Remove spool (9) from block (10).

b. Installation.

NOTE

All solenoids are installed the same way.


- (1) Install spool (1) in block (2).
- (2) Install preformed packing (3) and solenoid (4) with four screws (5).



- (3) Install seal (6), connector (7), and screw (8).
- (4) Aline and install cover (9) with four screws (10).


c. Follow-on Maintenance. None.

END OF TASK



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-29.1. SOLENOID REMOVAL/INSTALLATION (M984E1).	
This task covers:	
a. Removal	c. Follow-on Maintenance
b. Installation	
INITIAL SETUP	
<i>Models</i>	<i>References</i>
M984E1	None
<i>Test Equipment</i>	<i>Equipment Condition</i>
None	<i>TM or Para</i> <i>Condition Description</i>
<i>Special Tools</i>	TM 9-2320-279-10 Shut off engine.
None	<i>Special Environmental Conditions</i>
<i>Supplies</i>	None
None	<i>General Safety Instructions</i>
<i>Personnel Required</i>	None
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>
	Direct Support



TA476579

a. Removal.

(1) Loosen four screws (1) and remove cover (2).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE


All solenoids are removed and installed the same.

- (2) Remove four screws (3), solenoid (4), and preformed packing (5).
- (3) Loosen screw (6), remove plug (7), and seal (8).

NOTE

Spool may be up in shift block. Pull handle to release spool.


- (4) Remove spool (9) from block (10).



TA476581

b. Installation.

- (1) Install seal (1), plug (2), and screw (3).
- (2) Install spool (4) in block (5).
- (3) Install preformed packing (6) and solenoid (7) with four screws (8).




TA476580

- (4) Aline and install cover (9) with four screws (10).

c. Follow-on Maintenance.

- (1) Check operation of crane controls (TM 9-2320-279-20).
- (2) Check for leaks.




TA476582

END OF TASK


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-30. ACCUMULATOR REMOVAL/REPAIR/CHARGING/INSTALLATION.	
This task covers:	
a. Removal	e. Charging
b. Disassembly	f. Installation
c. Cleaning/Inspection	g. Follow-on Maintenance
d. Assembly	
INITIAL SETUP	
<i>Models</i> M977, M985, M984E1	<i>References</i> None
<i>Support Equipment</i> Accumulator charging assembly 10870344	<i>Equipment Condition</i> <i>TM or Para</i> <i>Condition Description</i> TM 9-2320-279-10 Shut off engine.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Solvent, dry cleaning, Item 57, Appendix C	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support

a. Removed.




- (1) Remove hydraulic line (1).
- (2) Remove two nuts (2), lockwashers (3), accumulator (4), U-bolt (5), and bracket (6).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

b. Disassembly.

- (1) Remove elbow (1) and preformed packing (2) from accumulator (3).





- (2) Remove two screws (4), lockwashers (5), and guard (6).
- (3) Remove cap (7) from valve (8).




WARNING

Accumulator is under 800 psi (5 516 kPa) pressure. Removal of any parts without releasing pressure may cause personal injury or death.

- (4) Release pressure from valve (8).
- (5) Remove valve stem (9).
- (6) Remove valve (8) and preformed packing (10) from accumulator (3).



- (7) Remove head (11) from accumulator (3).
- (8) Remove backup ring (12) and preformed packing (13).



17-30. ACCUMULATOR REMOVAL/REPAIR/CHARGING/INSTALLATION (CONT).

- (9) Remove piston (14) from accumulator (3).
- (10) Remove wear ring (15), two backup rings (16), preformed packing (17), and wear ring (18).

c. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

d. *Assembly.*




- (1) Install wear ring (1), preformed packing (2), two backup rings (3), and wear ring (4) on piston (5).
- (2) Install piston (5) in accumulator (6).

- (3) Install preformed packing (7) and backup ring (8) on head (9).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (4) Apply sealing and thread locking compound on threads of head (9) and install in accumulator (6).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (5) Install preformed packing (10) and valve (11) in accumulator (6).



- (6) Install valve stem (12) in valve (11).




- (7) Install preformed packing (13) and elbow (14) in accumulator (6).



e. Charging.


- (1) Attach charging device to accumulator (1) and charge with liquid nitrogen to 800 psi (5 516 kPa).



WARNING

Accumulator is under 800 psi (5 516 kPa) pressure. Removal of any parts without releasing pressure may cause personal injury or death.

- (2) Install cap (2) on valve (3).
 (3) Install guard (4) with two lockwashers (5) and screws (6).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-30. ACCUMULATOR REMOVAL/REPAIR/CHARGING/INSTALLATION (CONT).

f. Installation.

- (1) Install bracket (1), U-bolt (2), two lockwashers (3), and nuts (4).
- (2) Install accumulator (5).
- (3) Tighten two nuts (4).



- (4) Install hydraulic line (6).



g. Follow-on Maintenance. None.

END OF TASK

17-31. MAIN HYDRAULIC PRESSURE ADJUSTMENT.	
This task covers:	
a. Adjustment	b. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i> TM or Para Condition Description TM 9-2320-279-10 Shut off engine. TM 9-2320-279-10 Crane in stowed position.
<i>Test Equipment</i> None	<i>Special Environmental Conditions</i> None
<i>Special Tools</i> None	<i>General Safety Instructions</i> None
<i>Supplies</i> None	<i>Level of Maintenance</i> Direct Support
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	
<i>References</i> None	


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Adjustment.


NOTE

Crane must be at normal operating temperature for adjustment.


- (1) Remove cap (1) and attach suitable pressure gage to test port (2).
- (2) Put crane in operating position (TM 9-2320-279-10).



- (3) Operate BOOM control lever (3) DOWN.
- (4) Check pressure reading. Reading should be between 3000 psi (20 685 kPa) and 3200 psi (22 064 kPa).
- (5) If reading is less than 3000 psi (20 685 kPa) or more than 3200 psi (22 064 kPa), do steps (6) through (10). If reading is between 3000 psi (20 685 kPa) and 3200 psi (22 064 kPa), do steps (9) and (10).




- (6) Loosen locknut (4) and adjust screw (5) to lower pressure while operating BOOM control lever (3) DOWN.
- (7) Adjust screw (5) to set pressure between 3000 psi (20 685 kPa) and 3200 psi (22 064 kPa).
- (8) Tighten locknut (4).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

117-31. MAIN HYDRAULIC PRESSURE ADJUSTMENT (CONT).



- (9) Shut off engine (TM 9-2320-279-10).
- (10) Remove gage and install cap (1).


b. Follow-on Maintenance. None.

END OF TASK

17-31.1. MAIN HYDRAULIC PRESSURE ADJUSTMENT (M984E1).							
This task covers:							
<ul style="list-style-type: none"> a. Adjustment b. Follow-on Maintenance 							
INITIAL SETUP							
<i>Models</i>	<i>Equipment Condition</i>						
M984E1	<table border="0"> <tr> <td><i>TM or Para</i></td> <td><i>Condition Description</i></td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Shut off engine.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane in operating condition.</td> </tr> </table>	<i>TM or Para</i>	<i>Condition Description</i>	TM 9-2320-279-10	Shut off engine.	TM 9-2320-279-10	Crane in operating condition.
<i>TM or Para</i>	<i>Condition Description</i>						
TM 9-2320-279-10	Shut off engine.						
TM 9-2320-279-10	Crane in operating condition.						
<i>Test Equipment</i>							
None							
<i>Special Tools</i>	<i>Special Environmental Conditions</i>						
None	None						
<i>Supplies</i>	<i>General Safety Instructions</i>						
None	None						
<i>Personnel Required</i>	<i>Level of Maintenance</i>						
MOS 63W, Wheel vehicle repairer	Direct Support						
<i>References</i>							
None							

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Adjustment.




TA476722

- (1) Remove cap (1) and attach suitable pressure gage to test port (2).
- (2) Put crane in operating condition and engage high idle (TM 9-2320-279-10).
- (3) Operate mast up handle (3).

NOTE

If reading is not 3000 psi (20 685 kpa) do steps (5) through (9). If reading is 3000 psi (20 685 kpa) do steps (8) and (9).


- (4) Check pressure reading. Reading should be 3000 psi.
- (5) Loosen locknut (4) and adjust screw (5) to lower pressure while operating mast up function.
- (6) Adjust screw to bring pressure up to 3000 psi.
- (7) Tighten locknut (4).



TA476723

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-31.1. MAIN HYDRAULIC PRESSURE ADJUSTMENT (M984E1) (CONT).



- (8) Shut off engine (TM 9-2320-279-10).
- (9) Remove gage and install cap (1).


b. Follow-on Maintenance. Stow crane (TM 9-2320-279-10)

END OF TASK

17-32. Lift DOWN AND SHUT DOWN SOLENOIDS REMOVAL/REPAIR/INSTALLATION.	
This task covers:	
<ul style="list-style-type: none"> a. Removal b. Disassembly c. Assembly 	<ul style="list-style-type: none"> d. Installation e. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> <i>TM or Para</i> <i>Condition Description</i> TM 9-2320-279-10 Shut off engine.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> None	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

a. Removal.




TA189549

NOTE

M977 has two solenoids for dual range operations. Both solenoids are removed the same way.

- (1) Loosen screw (1) and remove connector (2) and seal (3).




TA189550

- (2) Disconnect two hydraulic lines (4).
- (3) Remove two screws (5) and eight washers (6).
- (4) Remove solenoid (7).


17-32. LIFT DOWN AND SHUT DOWN SOLENOIDS REMOVAL/REPAIR/INSTALLATION (CONT).

b. Disassembly.

(1) Remove two fittings (1) and preformed packings (2)(2) from solenoid (3).




(2) Remove nut (4), end cap (5), and solenoid coil (6) from block (7).



(3) Remove valve (8) from block (7).


(4) Remove backup ring (9), preformed packing (10), and preformed packing (11) from block (7).




c. Assembly.

(1) Install preformed packing (1), preformed packing (2), and backup ring (3) on valve (4).

(2) Install valve (4) in block (5).




(3) Install solenoid coil (6), end cap (7), and nut (8) on block (5).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

(4) Install two preformed packings (9) and fittings (10) in block (5).




d. Installation.


NOTE

M977 has two solenoids for dual range operations. Both solenoids are installed the same way.

- (1) Install solenoid (1) with two screws (2) and eight washers (3).
- (2) Connect two hydraulic lines (4).



(3) Install seal (5), connector (6), and screw (7).



e. Follow-on Maintenance. None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-32.1. LIFT DOWN AND SHUT DOWN SOLENOIDS AND VALVE
REMOVAL/REPAIR/INSTALLATION (M984E1).

This task covers:

- | | |
|--|------------------------------------|
| a. Removal Boom Up Solenoid | f. Installation Shut Down Solenoid |
| b. Installation Boom Up Solenoid | g. Removal Boom Valve |
| c. Removal Boom Down, Hoist, and Telescope Solenoid | h. Installation Boom Valve |
| d. Installation Boom Down, Hoist, and Telescope Solenoid | i. Disassembly |
| e. Removal Shut Down Solenoid | j. Cleaning/Inspection |
| | k. Assembly |
| | l. Follow-on Maintenance |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

TM 9-2320-279-10
Para 17-28.3

Condition Description

Shut off engine.
Cover removed (only for shut down solenoid).

NOTE

All solenoids are repaired the same.

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support

- a. *Removal Boom Up Solenoid.*
 (1) Loosen screw (1) and remove plug (2) and seal (3).
 (2) Disconnect two hydraulic lines (4) from solenoid (5).
 (3) Remove two screws (6), lockwashers (7), washers (8), and solenoid (5).
- b. *Installation Boom Up Solenoid.*
 (1) Install solenoid (5) with two washers (8), lockwashers (7), and screws (6).
 (2) Connect two hydraulic lines (4).
 (3) Install seal (3), plug (2), and screw (1).




TA476642

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

c. Removal Boom Down, Hoist, and Telescope Solenoids.

- (1) Loosen three screws (1) and remove three plugs (2) and seals (3).
- (2) Disconnect six hydraulic lines (4) from three solenoids (5).
- (3) Remove two screws (6), lockwashers (7), washer (8), cover (9), and three solenoids (5).




TA476643

d. Installation Boom Down, Hoist, and Telescope Solenoids.

- (1) Install three solenoids (5), with cover (9), two washers (8), lockwashers (7), and screws (6).
- (2) Connect six hydraulic lines (4).
- (3) Install three seals (3), plugs (2), and screws (1).

e. Removal Shut Down Solenoid.

- (1) Loosen screw (1) and remove plug (2) and seal (3).
- (2) Disconnect two hydraulic lines (4).
- (3) Remove two nuts (5), lockwashers (6), washers (7), screws (8), washers (9), and solenoid (10).



TA476644


f. Installation Shut Down Solenoid.

- (1) Install solenoid (10) with two washers (7), lockwashers (6), and nuts (5).
- (2) Connect two hydraulic lines (4).
- (3) Install seal (3), plug (2), and screw (1).

17-32.1. LIFT DOWN AND SHUT DOWN SOLENOIDS AND VALVE REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).

- g. Removal Boom Valve.*
 (1) Disconnect two hydraulic lines (1).
 (2) Remove screw (2), lockwasher (3), and valve (4).


- h. Installation Boom Valve.*
 (1) Install valve (4) with lockwasher (3) and screw (2).
 (2) Connect two hydraulic lines (1).



NOTE

All five solenoids are repaired the same.


- i. Disassembly.*
 (1) Remove elbow (1), preformed packing (2), fitting (3), and preformed packing (4) from solenoid (5).



NOTE


Front center solenoid has end cap. Other four solenoids do not.

- (2) Remove nut (6), end cap (7), and coil (8) from solenoid (5).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (3) Remove valve (9) from solenoid (5).
- (4) Remove backup ring (10), preformed packing (11), and preformed packing (12) from valve (9).



TA476648

- (5) Remove elbow (13) and preformed packing (14) from valve (15).
- (6) Remove fitting (16) and preformed packing (17).
- (7) Remove cartridge (18) from valve (15).
- (8) Remove preformed packing (19), backup ring (20), backup ring (21), and preformed packing (22) from cartridge (18).



TA476649

j. Cleaning/Inspection.


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.

k. Assembly.

- (1) Install preformed packing (1), backup ring (2), backup ring (3), and preformed packing (4) on cartridge (5).
- (2) Install cartridge (5) in valve (6).
- (3) Install preformed packing (7) and fitting (8).
- (4) Install preformed packing (9) and elbow (10).




TA476650

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


**17-32.1. LIFT DOWN AND SHUT DOWN SOLENOIDS AND VALVE
REMOVAL/REPAIR/INSTALLATION (M984E1) (CONT).**

- (5) Install preformed packing (11), preformed packing (12), and backup ring (13) on valve (14).
- (6) Install valve (14) in solenoid (15).



TA476651

- (7) Install coil (16), end cap (17), and nut (18) on solenoid (15).




TA476652

- (8) Install preformed packing (19), elbow (20), preformed packing (21), and fitting (22) in solenoid (15).

I. Follow-on Maintenance.

- (1) Install cover (if removed).
- (2) Check operation of controls.
- (3) Check for leaks.

END OF TASK



TA476653

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-33. OVERLOAD SENSOR SWITCH ADJUSTMENT.

This task covers:

- a. M985 and M977
Overload Sensor Switch Adjustment
- b. Follow-on Maintenance

INITIAL SETUP

Models
M977, M985

References
None

Test Equipment
None

Equipment Condition
TM or Para
Para 6-12
Condition Description
Overload sensor switches installed.

Special Tools
None

TM 9-2320-279-10 Crane in operating position.

Supplies
M985 - 6200 lb (2815 kg) Weight
M977 - 5400 lb (2452 kg) Weight
M977 - 3200 lb (1453 kg) Weight

Special Environmental Conditions
None

General Safety Instructions
None


Personnel Required
MOS 63W, Wheel vehicle repairer

Level of Maintenance
Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-33. OVERLOAD SENSOR SWITCH ADJUSTMENT (CONT).

a. *M985 and M977 Overload Sensor Switch Adjustment.*



- (1) Measure the distance between the end of screw (1) and the face of nut (2). If measurement is 0.062 in. (1.58 mm), go to step (3). If measurement is not 0.062 in. (1.58 mm), go to step (2).
- (2) Loosen nut (2) and adjust screw (1) with nut (3) to get a measurement of 0.062 in. (1.58 mm). Tighten nut (2).

CAUTION

Be sure proper weight is used to adjust M985 or M977 crane, or equipment may be damaged.

NOTE

- M985 has one overload sensor switch. M977 has two overload sensor switches.
- For M977 main overload sensor switch (A) adjustment, position boom at maximum boom angle before weight is attached.
- For M977 reduced overload sensor switch (B) adjustment, boom must be 10° above horizontal.
- For M977 main and reduced overload sensor switch adjustments, extend boom so that cable is spooling onto right side of drum, looking from boom nose.

For M985 overload sensor switch adjustment, extend boom so that cable is spooling onto left side of drum, looking from boom nose.

- (3) Position load hook (4) over weight and attach weight.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)**CAUTION**

- Use only HOIST control to lift and lower weight or damage to equipment could result.
- Do not operate crane with boom below horizontal when there is a load on hook.
- Use 6200 lb (2815 kg) weight for M985 overload switch (B) adjustment.
- Use 5400 lb (2452 kg) weight for M977 main overload switch (A) adjustment.
- Use 3200 lb (1453 kg) weight for M977 reduced overload switch (B) adjustment.

NOTE

Operate hoist smoothly and slowly when performing test.

(4) Lift weight.

NOTE

- If hoist attempts to lift weight and stops, do steps (5) through (9).
- If hoist lifts weight and does not stop, do steps (10) through (14).

(5) Lower weight.

(6) Loosen nut (5) 1/4 turn. Push switch (6) in toward plate.

(7) Tighten nut (7).

(8) Attempt to lift weight. Repeat steps (5) through (7) until weight can be lifted.

(9) Loosen nut (7) 1/4 turn. Tighten nut (5). Overload sensor switch is adjusted.

(10) Lower weight.

(11) Loosen nut (7) 1/4 turn. Push switch (6) away from plate.

(12) Tighten nut (5).

(13) Attempt to lift weight, Repeat steps (10) through (12) until weight cannot be lifted.

(14) Loosen nut (5) 1/4 turn. Tighten nut (7). Overload sensor switch is adjusted.


b. Follow-on Maintenance. Stow crane (TM 9-2320-279-10).

END OF TASK

M977, M905, and M984E1 Crane Maintenance Instructions (Cont)

17-33. OVERLOAD SENSOR SWITCH ADJUSTMENT (CONT).

b. Adjustment Main Overload (M977 Only).



TA190236

NOTE

Main overload switch is located on left side of hoist looking from boom nose.

- (1) Position hoist (1) at maximum boom angle over weight (2) and attach.

NOTE

- If hoist attempts to lift weight and stops, do steps (4) through (9).
 - If hoist lifts weight and does not stop, do steps (12) through (16).
- (2) Lift weight.
 - (3) If hoist attempts to lift weight and stops, do steps (4) through (9).
 - (4) Wait six seconds and lower weight.
 - (5) Loosen nut (3) 1/4 turn. Push switch (4) in toward plate.
 - (6) Tighten nut (5).
 - (7) Repeat steps (2) through (5) until weight can be lifted.
 - (8) Loosen nut (3) 1/4 turn. Tighten nut (5).
 - (9) Overload sensor switch is adjusted.
 - (10) Lift weight.
 - (11) If hoist lifts weight and does not stop, do steps (12) through (16).
 - (12) Lower weight.
 - (13) Loosen nut (5) 1/4 turn. Push switch (4) away from plate.
 - (14) Tighten nut (3).
 - (15) Repeat steps (8) through (10) until weight cannot be lifted.
 - (16) Loosen nut (5) 1/4 turn. Tighten nut (3). Overload sensor switch is adjusted.

c. Follow-on Maintenance. None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-33.1 OVERLOAD SENSOR SWITCHES ADJUSTMENT (M984E1).

This task covers:

- | | |
|-------------------------|--------------------------|
| a. 7300 lb Adjustment | d. 16,700 lb Adjustment |
| b. 10,000 lb Adjustment | e. Follow-on Maintenance |
| c. 14,800 lb Adjustment | |

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

- 7300 lb (3314 kg) Weight
- 10,000 lb (4540 kg) Weight
- 14,800 lb (6719 kg) Weight
- 16,700 lb (7582 kg) Weight

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

<i>TM or Para</i>	<i>Condition Description</i>
TM 9-2320-279-10	Crane in operating condition on level ground.
TM 9-2320-279-10	Connect remote control.
TM 9-2320-279-10	Recovery system lowered.
Para 6-12.1	Boom angle switches adjusted.

Special Environmental Conditions

None

General Safety Instructions

None


Level of Maintenance

Direct Support

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-33.1. OVERLOAD SENSOR SWITCHES ADJUSTMENT (M984E1) (CONT).

a. 7300 lb Weight Adjustment.



- (1) Measure the distance between the end of screw (0.1) and the face of nut (0.2). If measurement is 0.180 in. (4.57 mm), go to step (1.21). If measurement is not 0.180 in. (4.57 mm), go to step (1.1).
- (1.1) Loosen nut (0.2) and adjust screw (0.1) with nut (0.3) to get a measurement of 0.180 in. (4.57 mm). Tighten nut (0.2).

CAUTION

- Be sure proper weight is used to adjust M984E1 crane, or equipment may be damaged.
- Do not operate crane with boom below horizontal when there is a load on hook.
- Use only HOIST control to lift and lower weight or damage to equipment could result.

NOTE

- Boom must be positioned between 0° and 25° during adjustment.
- Boom must be extended so that when the weight is lifted, cable is on fourth layer, against the right side of the drum (viewed from hook end of boom).

- (1.2) Position hook block (1) over weight and attach.
- (2) Deleted.
- (3) Deleted.
- (4) Lift weight.

NOTE

If hoist attempts to lift weight and stops, do steps (5) through (9).

If hoist lifts weight and does not stop do steps (12) through (17).

Operate hoist smoothly and slowly when performing test.

- (5) Lower weight.
- (6) Loosen nut (6) 1/8 to 1/4 turn. Push switch A in toward plate (7).
- (7) Tighten nut (8).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (8) Repeat steps (4) through (7) until weight can be lifted.
- (9) Loosen nut (8) 1/8 to 1/4 turn and tighten nut (6). Overload sensor switch A is adjusted.
- (10) Deleted.
- (11) Deleted.
- (12) Lower weight.
- (13) Loosen nut (8) 1/8 to 1/4 turn. Push switch A away from plate (7).
- (14) Tighten nut (6).
- (15) Attempt to lift weight. Repeat steps (12) through (14) until weight cannot be lifted.
- (16) Loosen nut (6) 1/8 to 1/4 turn. Tighten nut (8). Overload sensor switch is adjusted.
- (17) Deleted.

b. 10,000 lb Weight Adjustment.**CAUTION**

- Be sure proper weight is used to adjust M984E1 crane, or equipment may be damaged.
- Do not operate crane with boom below horizontal when there is a load on hook.
- Use only HOIST control to lift and lower weight or damage to equipment could result.

NOTE

- Boom must be positioned between 25° and 30° during adjustment.
 - Boom must be extended so that when the weight is lifted, cable is on fourth layer, against the left side of the drum (viewed from hook end of boom).
- (1) Position hook block (1) over weight and attach.
 - (2) Deleted.
 - (3) Deleted.
 - (4) Lift weight.




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-33.1. OVERLOAD SENSOR SWITCHES ADJUSTMENT (M984E1) (CONT).

NOTE

- If hoist attempts to lift weight and stops, do steps (5) through (9).
- If hoist lifts weight and does not stop, do steps (12) through (17).
- Operate hoist smoothly and slowly when performing test.

- (5) Lower weight.
- (6) Loosen nut (6) 1/8 to 1/4 turn. Push switch B in toward plate (7).
- (7) Tighten nut (8).
- (8) Repeat steps (4) through (7) until weight can be lifted.
- (9) Loosen nut (8) 1/8 to 1/4 turn and tighten nut (6). Overload sensor switch B is adjusted.
- (10) Deleted.
- (11) Deleted.
- (12) Lower weight.
- (13) Loosen nut (8) 1/8 to 1/4 turn. Push switch B away from plate (7).
- (14) Tighten nut (6).
- (15) Attempt to lift weight. Repeat steps (12) through (14) until weight cannot be lifted.
- (16) Loosen nut (6) 1/8 to 1/4 turn. Tighten nut (8). Overload sensor switch B is adjusted.
- (17) Deleted.



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

c. 14,800 lb Weight Adjustment,


CAUTION

- Be sure proper weight is used to adjust M984E1 crane, or equipment may be damaged.
- Do not operate crane with boom below horizontal when there is a load on hook.
- Use only HOIST control to lift and lower weight or damage to equipment could result.

NOTE

- Boom must be positioned between 30° and 40° during adjustment.
- Boom must be extended so that when the weight is lifted, cable is on fifth layer, against the right side of the drum (viewed from hook end of boom).

- (1) Position hook block (1) over weight and attach.
- (2) Deleted.
- (3) Deleted.
- (4) Lift weight.




NOTE

If hoist attempts to lift weight and stops, do steps (5) through (9).

If hoist lifts weight and does not stop, do steps (13) through (18).

Operate hoist smoothly and slowly when performing test.

- (5) Lower weight.
- (6) Loosen nut (6) 1/8 to 1/4 turn. Push switch C in toward plate (7).
- (7) Tighten nut (8).
- (8) Attempt to lift weight. Repeat steps (5) through (7) until weight can be lifted.
- (9) Loosen nut (8) 1/8 to 1/4 turn and tighten nut (6). Overload sensor switch C is adjusted.
- (10) Deleted.
- (11) Deleted.
- (12) Deleted.
- (13) Lower weight.
- (14) Loosen nut (8) 1/8 to 1/4 turn. Push switch C away from plate (7).
- (15) Tighten nut (6).
- (16) Attempt to lift weight. Repeat steps (13) through (15) until weight cannot be lifted.
- (17) Loosen nut (6) 1/8 to 1/4 turn. Tighten nut (8). Overload sensor switch C is adjusted.
- (18) Deleted.



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-33.1. OVERLOAD SENSOR SWITCHES ADJUSTMENT (M984E1) (CONT).

d. 16,700 lb Weight Adjustment.


CAUTION

- Be sure proper weight is used to adjust M984E1 crane, or equipment may be damaged.
- Do not operate crane with boom below horizontal when there is a load on hook.
- Use only HOIST control to lift and lower weight or damage to equipment could result.

NOTE

- Boom must be positioned between 40° and maximum boom angle during adjustment.
- Boom must be extended so that when the weight is lifted, cable is on fourth layer, against the left side of the drum (viewed from hook end of boom).

- (1) Position hook block (1) over weight and attach.
- (2) Deleted.
- (3) Deleted.
- (4) Lift weight.




NOTE

- If hoist attempts to lift weight and stops, do steps (5) through (9).
- If hoist lifts weight and does not stop, do steps (12) through (17).

Operate hoist smoothly and slowly when performing test.

- (5) Lower weight.
- (6) Loosen nut (6) 1/8 to 1/4 turn. Push switch D in toward plate (7).
- (7) Tighten nut (8).
- (8) Repeat steps (4) through (7) until weight can be lifted.
- (9) Loosen nut (8) 1/8 to 1/4 turn. Tighten nut (6). Overload sensor switch D is adjusted.
- (10) Deleted.
- (11) Deleted.
- (12) Lower weight.
- (13) Loosen nut (8) 1/8 to 1/4 turn. Push switch D away from plate (7).
- (14) Tighten nut (6).
- (15) Attempt to lift weight. Repeat steps (12) through (14) until weight cannot be lifted.
- (16) Loosen nut (6) 1/8 to 1/4 turn. Tighten nut (8). Overload sensor switch D is adjusted.
- (17) Deleted.



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

e. *Follow-on Maintenance.*

- (1) Disconnect remote control (TM 9-2320-279-10).
- (2) Stow crane (TM 9-2320-279-10).
- (3) Deleted.
- (4) Return recovery system to stowed position (TM 9-2320-279-10).


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

Section VII. OUTRIGGERS

17-34. OUTRIGGER REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
Models M977, M985	Equipment Condition
Test Equipment None	TM or Para Para 17-2
Special Tools None	Condition Description Outrigger hydraulic hoses and tubes disconnected. TM 9-2320-279-20 Rear fenders removed. TM 9-2320-279-20 Rear cable guide removed.
Supplies None	Special Environmental Conditions None
Personnel Required MOS 63W, Wheel vehicle repairer (2)	General Safety Instructions None
References None	Level of Maintenance Direct Support

a. Removal.



(1) Position suitable lifting device to support outrigger assembly (1).

17-34. OUTRIGGER REMOVAL/INSTALLATION (CONT.)


WARNING

Keep out from under heavy parts.
Falling parts may cause serious injury or death.

NOTE

Right and left side outrigger mounting hardware is removed the same way.
Right side is shown.


- (2) Soldier A removes four screws (2), washers (3), and spacers (4) while Soldier B removes four nuts (5), washers (6), and spacers (7) from mounting bracket (8).
- (3) Repeat step (2) for other side.
- (4) Remove outrigger assembly (1).



TA190301

b. Installation.

- (1) Position outrigger assembly (1).



TA190302


NOTE

Right and left side outrigger mounting hardware is installed the same way.
Right side is shown.

- (2) Soldier A installs outrigger assembly (1) on mounting bracket (2) with four spacers (3), washers (4), and screws (5) while Soldier B installs four spacers (6), washers (7), and nuts (8).
- (3) Repeat step (2) for other side.

c. Follow-on Maintenance.

- (1) Install cable guide (TM 9-2320-279-20).
- (2) Install rear fenders (TM 9-2320-279-20).
- (3) Connect outrigger hydraulic hoses and tubes (para 17-2).




TA190303

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-35. OUTRIGGER LEG CYLINDER REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>Equipment Condition</i> TM or Para Condition Description TM 9-2320-279-10 Shut off engine.
<i>Test Equipment</i> None	<i>Special Environmental Conditions</i> None
<i>Special Tools</i> None	<i>General Safety Instructions</i> None
<i>Supplies</i> None	<i>Level of Maintenance</i> Direct Support
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	
<i>References</i> None	

a. Removal.



NOTE


- Left and right cylinders are removed the same way.
- Remove all clamps as necessary.

- (1) Remove two screws (1) and bracket (2).
- (2) Remove two hydraulic lines (3).
- (3) Attach suitable lifting device to cylinder (4).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-35. OUTRIGGER LEG CYLINDER REMOVAL/INSTALLATION (CONT.)

- (4) Remove two screws (5) and two screws (6).
- (5) Remove cylinder (4).




b. Installation.

NOTE

Left and right cylinders are installed the same way.


- (1) Attach suitable lifting device to cylinder (1).




NOTE

Install clamps as necessary.

- (2) Install cylinder (1) with two screws (2) and two screws (3).
- (3) Install two hydraulic lines (4).



- (4) Install bracket (5) and two screws (6).



c. Follow-on Maintenance. None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-36. OUTRIGGER LEG CYLINDER REPAIR.	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M977, M985	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> <i>TM or Para</i> <i>Condition Description</i> Outrigger leg cylinder on clean work surface.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> Compound, sealing and thread locking, Item 26, Appendix C Oil, lubricating, Item 47.1, Appendix C Solvent, dry cleaning, Item 57, Appendix C	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> General Support



a. Disassembly.

NOTE

Backup ring may stay in cylinder.

- (1) Remove two screws (1), plate (2), and backup ring (3) from cylinder (4).
- (2) Remove wiper ring (5) from plate (2).


- (3) Remove holding valve (6) from cylinder (4).
- (4) Remove two backup rings (7) and preformed packing (8).
- (5) Remove backup ring (9) and preformed packing (10).
- (6) Remove preformed packing (11).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-36. OUTRIGGER LEG CYLINDER REPAIR (CONT.)


(7) Remove rod assembly (12) from cylinder (4).




(8) Remove head (13) from rod (12).
(9) Remove backup ring (14) and preformed packing (15)



(10) Remove seal (16) and wear ring (17) from head (13).



(11) Remove wear ring (18), two backup rings (19), preformed packing (20), and wear ring (21) from piston (22).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


- (12) Remove setscrew (23).
- (13) Remove piston (22) from rod (12).
- (14) Remove two backup rings (24) and preformed packing (25).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.





c. *Assembly.*

- (1) Install preformed packing (1) and two backup rings (2) on rod (3).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (2) Apply sealing and thread locking compound and install piston (4).
- (3) Install setscrew (5).



- (4) Install wear ring (6), preformed packing (7), two backup rings (8), and wear ring (9) on piston (4).


17-36. OUTRIGGER LEG CYLINDER REPAIR (CONT).

- (5) Install wear ring (10) and seal (11) in head (12).
- (6) Install preformed packing (13) and backup ring (14).
- (7) Install head (12) on rod (3).



TA189569

- (8) Install rod assembly (3) in cylinder (15).




TA189570

NOTE

Apply lubricant to preformed packings before installing.

- (9) Install preformed packing (16), two backup rings (17), preformed packing (18), backup ring (19), and preformed packing (20).
- (10) Install holding valve (21) in cylinder (15).




TA189571

- (11) Install wiper ring (22) in plate (23).
- (12) Install backup ring (24), plate (23), and two screws (25).

d. Follow-on Maintenance. None.

END OF TASK




TA189572

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-36.1. OUTRIGGER LEG CYLINDER REMOVAL/INSTALLATION (M984E1).	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M984E1	<i>Equipment Condition</i>
<i>Test Equipment</i> None	TM 9-2320-279-10 Shut off engine. TM 9-2320-279-10 Outrigger pad removed. TM 9-2320-279-10 Crane positioned for access. Para 17-2.1 Leg cylinder hydraulic hoses removed.
<i>Special Tools</i> None	
<i>Supplies</i> None	<i>Special Environmental Conditions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>General Safety Instructions</i> None
<i>References</i> None	<i>Level of Maintenance</i> Direct Support

a. Removal.




NOTE

Left and right cylinders are removed the same way.

- (1) Remove two screws (1), washers (2), and strap (3).
- (2) Attach suitable lifting device to cylinder (4).
- (3) Remove fitting (5).


- (4) Remove four screws (6) and washers (7).
- (5) Remove cylinder (4).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-36.1. Outrigger LEG Cylinder REMOVAL/INSTALLATION (M984E1) (CONT).

b. Installation.



- (1) Attach suitable lifting device to cylinder(1).
- (2) Install cylinder (1) with four washers (2), and screws (3).
- (3) Install strap (4), two washers (5), and screws (6).

c. Follow-on Maintenance.

- (1) Connect hydraulic hoses (para 17-2.1).
- (2) Install outrigger pads (TM 9-2320-279-10).
- (3) Crane stowed (TM 9-2320-279-10).


END OF TASK

17-36.2. OUTRIGGER LEG CYLINDER REPAIR (M984E1).		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
M984E1	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
None	<i>TM or Para</i>	<i>Condition Description</i>
<i>Special Tools</i>	Para 17-36.1	Outrigger cylinder removed.
None	<i>Special Environmental Conditions</i>	
<i>Supplies</i>	None	
Compound, sealing, thread locking, Item 25, Appendix C	<i>General Safety Instructions</i>	
<i>Personnel Required</i>	None	
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>	
	General Support	

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


a. *Disassembly.*

- (1) Remove holding valve (1).
- (2) Remove two backup rings (2), preformed packing (3), preformed packing (4), backup ring (5), and preformed packing (6) from holding valve (1).




TA476658

- (3) Remove setscrew (7) from cylinder (8).
- (4) Remove head (9) from cylinder (8).




TA476659

- (5) Remove two backup rings (10) and preformed packing (11) from head (9).
- (6) Remove two wear rings (12).
- (7) Remove wiper ring (13), backup ring (14), and seal (15).




TA476660

- (8) Remove spacer (16) from rod (17).
- (9) Remove wear ring (18) from spacer (16).
- (10) Remove rod (17) from cylinder (8).



TA476661

17-36.2. OUTRIGGER LEG CYLINDER REPAIR (M984E1) (CONT).



- (11) Remove four wear rings (18), two backup rings (19), and preformed packing (20) from piston (21).
- (12) Remove setscrew (22) and piston (21) from rod (17).
- (13) Remove two backup rings (23) and preformed packing (24) from piston (21).

b. *Cleaning/Inspection.*


WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Compressed air used for cleaning purposes will not exceed 30 psi. Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc.).

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Replace all wear rings and backup rings.


c. *Assembly.*

- (1) Install two backup rings (1) and preformed packing (2) in piston (3).
- (2) Install piston (3) and setscrew (4) on rod (5).
- (3) Install four wear rings (6), preformed packing (7), and two backup rings (8) on piston (3).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (4) Install rod (9) in cylinder (10).
- (5) Install wear ring (11) in spacer (12).
- (6) Install spacer (12) on rod (9).




TA476664

NOTE


Seal is installed with small lip down.

- (7) Install seal (13), backup ring (14), wiper ring (15), and two wear rings (16) in head (17).
- (8) Install preformed packing (18) and two backup rings (19) on head (17).




TA476665

- (9) Apply compound and install head (17) on cylinder (10).
- (10) Aline and install setscrew (20).



TA476666

- (11) Install preformed packing (21), backup ring (22), preformed packing (23), preformed packing (24), and two backup rings (25) on valve (26).
 - (12) Install valve (26).
- d. *Follow-on Maintenance.*
- (1) Install leg cylinder (para 17-36.1)
 - (2) Check for leaks.




TA476667

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-37. OUTRIGGER EXTENSIONS REMOVAL/INSTALLATION.	
This task covers:	
a. Removal (M985)	d. Installation (M977)
b. Installation (M985)	e. Follow-on Maintenance
c. Removal (M977)	
INITIAL SETUP	
Models	Equipment Condition
M977, M985	<i>TM or Para</i> <i>Condition Description</i>
Test Equipment	TM 9-2320-279-20 Outrigger fully extended.
None	Para 17-36 Outrigger leg cylinder removed.
Special Tools	TM 9-2320-279-20 Fenders removed (M985 only).
None	TM 9-2320-279-20 Outrigger pads removed (M985 only).
Supplies	Special Environmental Conditions
Grease, automotive and artillery, Item 34, Appendix C	None
Personnel Required	General Safety Instructions
MOS 63W, Wheel vehicle repairer	None
References	Level of Maintenance
None	Direct Support

a. Removal (M985).



NOTE

Right and left extensions are removed the same way.

- (1) Remove two nuts (1) from fittings (2).
- (2) Remove two fittings (2) from hoses (3).
- (3) Remove two screws (4), washers (5), and pin (6).
- (4) Mark two stop blocks (7) and remove eight screws (8) and two stop blocks.
- (5) Attach suitable lifting device.
- (6) Remove extension No. 1 (9).
- (7) Mark two stop blocks (10) and remove six screws (11) and two stop blocks.
- (8) Attach suitable lifting device.
- (9) Remove extension No. 2 (12).


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

b. Installation (M985).

NOTE

Right and left extensions are installed the same way.


- (1) Install extension No. 2 (1) in beam (2).
- (2) Install two stop blocks (3) and six screws (4).



NOTE

Be sure hoses go through guide tubes in extension No. 1.

- (3) Install extension No. 1 (5) in extension No. 2 (1).
- (4) Install two stop blocks (6) with eight screws (7).
- (5) Aline rod and install pin (8) with two washers (9) and screws (10).
- (6) Install two fittings (11) on hoses (12).
- (7) Install two nuts (13) on fittings (11).




c. Removal (M977).

NOTE

Right and left extensions are removed the same way.


- (1) Remove two screws (1), washers (2), and pin (3).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-37. OUTRIGGER EXTENSIONS REMOVAL/INSTALLATION (CONT).

- (2) Attach suitable lifting device.
- (3) Remove extension (4) from beam (5).




TA190322

d. Installation (M977).

NOTE

Right and left extensions are installed the same way.

- (1) Install extension (1) in beam (2).




TA190323

- (2) Install pin (3), two washers (4), and screws (5).

e. Follow-on Maintenance.

- (1) Install outrigger leg cylinder (para 17-36).
- (2) Install hoses and tubes (para 17-2).
- (3) Install fenders (TM 9-2320-279-20) (M985 only).
- (4) Install outrigger pads (TM 9-2320-279-20) (M985 only).



TA190324

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-38. OUTRIGGER EXTENSION CYLINDER REMOVAL/INSTALLATION.

This task covers:

- a. Removal
- b. Installation
- c. Follow-on Maintenance

INITIAL SETUP

Models

M977, M985

Test Equipment

None

Special Tools

None

Supplies

Tags, identification, Item 60, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer (3)

References

None

Equipment Condition

TM or Para

Para 17-38

Condition Description

Outrigger extensions removed.

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support

a. Removal.



TA190272

NOTE

Tag and mark hoses before disconnecting.

- (1) Disconnect six hoses (1, 2, and 3) from valve bodies (4, 5, and 6).
- (2) Disconnect one hose (2) from tee (7) and remove from beam (8).
- (3) Remove two quick pins (9) from pins (10).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)


17-38. OUTRIGGER EXTENSION CYLINDER REMOVAL/INSTALLATION (CONT).

- (4) Remove two pins (10).
- (5) Soldier A guides five hoses (1, 2, and 3) through hole in beam (8) while Soldier B removes cylinder (11) and hoses (1, 2, and 3).


NOTE

Some models of beams have plastic edge protection around opening for hoses. Do step (5.1) for this model.

- (5.1) If damaged, remove plastic edge protection (11.1) from hose opening in beam (8).




- (6) Disconnect four hoses (12 and 13).
- (7) Disconnect two hoses (14 and 15) and hose (2) from cylinder (11).
- (8) Remove tee (7) from hoses (14 and 15).
- (9) Disconnect four hoses (1 and 3) from cylinder (11).



b. Installation.

- (1) Connect four hoses (1 and 2) to cylinder (3).
- (2) Connect two hoses (4 and 5) with tee (6).
- (3) Connect hoses (4 and 5) to cylinder (3).
- (4) Connect hose (7) to cylinder (3).
- (5) Connect four hoses (8 and 9) to cylinder (3).





M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (5.1) If removed or not previously installed, install plastic edge protection (2.1) around hose opening in beam (10).

NOTE

Two hoses for leg cylinder must be kept on bottom of cylinder while being fed through to other side.


- (6) Soldier A and Soldier B install cylinder (3) in beam (10) while Soldier C guides and pulls five hoses (1, 2, and 7) through hole in beam (10).
- (7) Aline cylinder (3) and install two pins (11).
- (8) Install two quick pins (12) on pins (11).
- (9) Install hose (13) in beam (10) and connect to tee (6).



- (10) Connect six hoses (1, 2, and 7) to valve bodies (14, 15, and 16).

c. Follow-on Maintenance. Install outrigger extensions (para 17-38).

END OF TASK



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-38.1 OUTRIGGER OUTER BEAM AND EXTENSION CYLINDER REMOVAL/INSTALLATION (M984E1).

This task covers:

- a. Removal
- b. Installation
- c. Follow-on Maintenance

INITIAL SETUP

Models

M984E1

References

None

Test Equipment

None

Equipment Condition

TM or Para	Condition	Description
Para 17-36.1	Outrigger leg cylinder removed.	
TM 9-2320-279-20	Outrigger cover removed.	

Special Tools

None

Special Environmental Conditions

None

Supplies

None

General Safety Instructions

None


Personnel Required

MOS 63W, Wheel vehicle repairer (2)

Level of Maintenance

Direct Support

a. Removal.




NOTE

Some models have guide tubes for the outrigger hoses in place of brackets. For outriggers without guide tubes, do steps (1) and (2). For outriggers with guide tubes, do steps (2) through (2.2).

- (1) Remove two nuts (1), lockwashers (2), washers (3), and bracket (4).
- (2) Remove two screws (5), lockwashers (6), and nuts (7), and slide rods (8) down.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



- (2.1) Remove locknut (8.1), two washers (8.2), and screw (8.3) from right guide tube (8.4) and left guide tube (8.5).
- (2.2) Remove two nuts (8.6), lockwashers (8.7), washers (8.8), and bracket (8.9).

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE


Tag and mark all lines.

- (3) Disconnect four hydraulic lines (9).

WARNING


Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (4) Remove two setscrews (10).
 (5) Soldier A supports beam (11) while
 Soldier B removes pin (12).




TA476671

- (6) Lower beam (11) and attach a suitable
 lifting device.
 (7) Soldier A and Soldier B remove
 beam (11) from outrigger (13).



TA476672


- (8) Remove two screws (14), lockwashers (15),
 and bracket (16) from beam (11).



TA476673


17-38.1. OUTRIGGER OUTER BEAM AND EXTENSION CYLINDER REMOVAL/INSTALLATION (M984E1) (CONT).

- (9) Remove two screws (17), lockwashers (18), washers (19), and pin (20).
- (10) Remove two nuts (21).
- (11) Soldier A slides cylinder (22) back while Soldier B pushes fittings (23) in beam (11).




TA476674

- (12) Remove cylinder (22) and lines (24) from beam (11).



TA476675

- (13) Remove two nuts (25), lockwashers (26), clamps (27), nuts (28), and clamps (29) from studs (30).





TA476676

M977, M995, and M994E1 Crane Maintenance Instructions (Cont)

NOTE

Tag and mark all lines.

- (14) Remove two hydraulic lines (24) from valves (31).



- (15) Remove four lines (24) from hoses (32).
- (16) Remove two fittings (23) from lines (24).
- (17) Remove two rods (8) from sleeves (33).


NOTE

Not all models have guide tubes.

- (17.1) Remove guide tubes (33.1).

17-38.1 OUTRIGGER OUTER BEAM AND EXTENSION CYLINDER REMOVAL/INSTALLATION (M984E1) (CONT).


b. Installation




NOTE

If guide tubes are not present, go to step (1.1).

- (1) Install two guide tubes (1) over hoses (5).
- (1.1) Install two rods (1.1) in sleeves (2).
- (2) Install two fittings (3) on lines (4).
- (3) Install four lines (4) to hoses (5).
- (4) Install two hydraulic lines (4) to valves (6).




- (5) Install two clamps (7), nuts (8), clamps (9), lockwasher (10), and nuts (11) on studs (12).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (6) Soldier A and Soldier B install cylinder (13) and lines (4) in beam (14).




TA476682

- (7) Install two nuts (15) on lines (4).
 (8) Install pin (16), two washers (17), lockwashers (18), and screws (19).



TA476683

- (9) Install bracket (20) with two washers (21) and screws (22).




TA476684


M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-38.1 OUTRIGGER OUTER BEAM AND EXTENSION CYLINDER REMOVAL/INSTALLATION (M984E1) (CONT).


- (10) Soldier A and Soldier B attach suitable lifting device to beam (14) and install beam in outrigger (23).



- (11) Soldier A supports beam (14) while Soldier B aligns and installs pin (24).
- (12) Install two setscrews (25).
- (13) Connect four hydraulic hoses (2).



- (14) Install two rods (1) with screws (26), lockwashers (27), and nuts (28).




M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

NOTE

Some models have guide tubes. For outriggers without guide tubes, do step (15). For outriggers with guide tubes, do steps (16) and (17).

- (15) Install bracket (29) with two washers (30), lockwashers (31), and nuts (32).
- (16) Install bracket (33) with two washers (34), lockwashers (35), and nuts (36).
- (17) Install right guide tube (37) and left guide tube (38) using screw (39), two washers (40), and locknut (41). Tighten nut until there is a 0.03-in. (0.75 mm) gap between washer and guide tube.



c. Follow-on Maintenance.


- (1) Outrigger cover installed (TM 9-2320-279-20).
- (2) Outrigger leg cylinder installed (para 17-35).

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



17-38.2. OUTRIGGER INNER BEAM REMOVAL/INSTALLATION (M984E1).		
This task covers:		
a. Removal	c. Follow-on Maintenance	
b. Installation		
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
M984E1	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 17-38.1	Outrigger beam and extension cylinder removed.
None	Para 17-36.1	Outrigger leg cylinder removed.
<i>Special Tools</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Supplies</i>	<i>General Safety Instructions</i>	
None	None	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheel vehicle repairer (2)	Direct Support	
<i>References</i>		
None		

- a. Removal.
 (1) Attach suitable lifting device to inner beam (1).



TA476689

17-38.2. OUTRIGGER INNER BEAM REMOVAL/INSTALLATION (M984E1) (CONT).





TA476690

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (2) Remove two screws (2), lockwashers (3), end caps (4), and pin (5) from inner beam (1).
- (3) Soldier A and Soldier B remove inner beam (1) outrigger housing (6).

b. Installation.



TA476693

- (1) Soldier A and Soldier B align and install inner beam (1) in outrigger housing (2).
- (2) Install pin (3) in inner beam (1) with two end caps (4), lockwashers (5), and screws (6).

c. Follow-on Maintenance.

- (1) Install extension cylinder and outer beam (para 17-38.1).
- (2) Install outrigger leg cylinder (para 17-36.1).

END OF TASK



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-39. OUTRIGGER EXTENSION CYLINDER REPAIR.	
This task covers:	
a. Disassembly b. Cleaning/Inspection	c. Assembly d. Follow-on Maintenance
INITIAL SETUP	
Models M977, M985	References None
Test Equipment None	Equipment Condition TM or Para Condition Description Outrigger extension cylinder on clean work surface.
Special Tools None	Special Environmental Conditions None
Supplies Compound, sealing and thread locking, Item 25, Appendix C Solvent, dry cleaning, Item 57, Appendix C	General Safety Instructions None
Personnel Required MOS 63W, Wheel vehicle repairer	Level of Maintenance General Support

a. Disassembly.

NOTE

- Left and right cylinder ends are disassembled the same way.
- Seal is a two piece assembly.
 - (1) Remove setscrew (1), retaining ring (2), and seal (3) from rod (4).
 - (2) Remove wiper ring (5) from retaining ring (2).
 - (3) Remove rod assembly (4) from cylinder (6).
- (4) Remove head (7) from rod (4).
- (5) Remove preformed packing (8), backup ring (9), and wear ring (10) from head (7).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-39. OUTRIGGER EXTENSION CYLINDER REPAIR (CONT).


- (6) Remove two guide rings (11) and seal (12).
- (7) Remove piston (13) from rod (4) and preformed packing (14).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.



c. *Assembly.*

NOTE

Left and right cylinder ends are assembled the same way.

- (1) Install preformed packing (1) on rod (2).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (2) Apply sealing and thread locking compound and install piston (3).


NOTE

Groove in guide rings face away from seal.


- (3) Install seal (4) and two guide rings (5).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



- (4) Install wear ring (6) in head (7).
- (5) Install preformed packing (8) and backup ring (9).
- (6) Install head (7) on rod (2).



- (7) Install rod assembly (2) in cylinder (10).
- (8) Install wiper ring (11) in retaining ring (12).
- (9) Install seal (13) in head (7).
- (10) Apply sealing and thread locking compound and install retaining ring (12).
- (11) Install setscrew (14).


d. *Follow-on Maintenance.* None.

END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



<p>17-40. OUTRIGGER INNER BEAM EXTENSION CYLINDER REMOVAL/INSTALLATION (M984E1).</p>									
<p>This task covers:</p> <p>a. Removal b. Installation</p> <p>c. Follow-on Maintenance</p>									
<p>INITIAL SETUP</p> <table border="0"> <tr> <td style="vertical-align: top;"> <p>Models M984E1</p> <p>Test Equipment None</p> <p>Special Tools None</p> <p>Supplies None</p> <p>Personnel Required MOS 63W, Wheel vehicle repairer (2)</p> </td> <td style="vertical-align: top;"> <p>References None</p> <p>Equipment Condition</p> <table border="0"> <tr> <td>TM or Para</td> <td>Condition Description</td> </tr> <tr> <td>Para 17-38.2</td> <td>Outrigger inner beam removed.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane positioned for access.</td> </tr> </table> <p>Special Environmental Conditions None</p> <p>General Safety Instructions None</p> <p>Level of Maintenance Direct Support</p> </td> </tr> </table>		<p>Models M984E1</p> <p>Test Equipment None</p> <p>Special Tools None</p> <p>Supplies None</p> <p>Personnel Required MOS 63W, Wheel vehicle repairer (2)</p>	<p>References None</p> <p>Equipment Condition</p> <table border="0"> <tr> <td>TM or Para</td> <td>Condition Description</td> </tr> <tr> <td>Para 17-38.2</td> <td>Outrigger inner beam removed.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane positioned for access.</td> </tr> </table> <p>Special Environmental Conditions None</p> <p>General Safety Instructions None</p> <p>Level of Maintenance Direct Support</p>	TM or Para	Condition Description	Para 17-38.2	Outrigger inner beam removed.	TM 9-2320-279-10	Crane positioned for access.
<p>Models M984E1</p> <p>Test Equipment None</p> <p>Special Tools None</p> <p>Supplies None</p> <p>Personnel Required MOS 63W, Wheel vehicle repairer (2)</p>	<p>References None</p> <p>Equipment Condition</p> <table border="0"> <tr> <td>TM or Para</td> <td>Condition Description</td> </tr> <tr> <td>Para 17-38.2</td> <td>Outrigger inner beam removed.</td> </tr> <tr> <td>TM 9-2320-279-10</td> <td>Crane positioned for access.</td> </tr> </table> <p>Special Environmental Conditions None</p> <p>General Safety Instructions None</p> <p>Level of Maintenance Direct Support</p>	TM or Para	Condition Description	Para 17-38.2	Outrigger inner beam removed.	TM 9-2320-279-10	Crane positioned for access.		
TM or Para	Condition Description								
Para 17-38.2	Outrigger inner beam removed.								
TM 9-2320-279-10	Crane positioned for access.								

a. Removal.



- (1) Remove two hydraulic hoses (1) from cylinder (2).
- (2) Attach a suitable lifting device to cylinder (2).
- (3) Remove two screws (3), lockwashers (4), end caps (5), and pin (6).



M977, M985, and M984E1 Crane Maintenance Instructions (Cont)



TA476707



- (4) Remove two screws (7), lockwashers (8), and strap (9) from outrigger (10).
- (5) Soldier A and Soldier B remove cylinder (2) through outrigger tower (10).

b. Installation.



TA476709

- (1) Soldier A and Soldier B install cylinder (1) through outrigger tower (2).
- (2) Install strap (3) with two screws (4) and lockwashers (5).



TA476710

- (3) Align and install pin (6).
- (4) Install two end caps (7), lockwashers (8), and screws (9) in pin (6).
- (5) Attach two hydraulic hoses (10).

c. Follow-on Maintenance.

- (1) Install outrigger inner beam (para 17-38.2).
- (2) Crane returned to stowed position (TM 9-2320-279-10).
- (3) Check for leaks.

END OF TASK


17-41. OUTRIGGER INNER AND OUTER BEAM CYLINDER REPAIR (M984E1).	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
Models M984E1	References None
Test Equipment None	Equipment Condition <i>TM or Para</i> <i>Condition Description</i> Para 17-39.1 Outrigger outer and inner beam cylinders removed.
Special Tools None	Special Environmental Conditions None
Supplies Compound, sealing and thread locking, Item 26, Appendix C Oil, lubricating, Item 47.1, Appendix C Solvent, dry cleaning, Item 57, Appendix C	General Safety Instructions None
Personnel Required MOS 63W, Wheel vehicle repairer	Level of Maintenance General Support

a. Disassembly.

NOTE


Both inner and outer cylinders are disassembled the same.

- (1) Remove two fittings (1) and preformed packings (2) from holding valves (3).
- (2) Remove holding valve (3).
- (3) Remove retainer (4), preformed packing (5), retainer (4), retainer (6), and preformed packings (7 and 8).
- (4) Repeat steps (2) and (3) for other holding valve.



TA500325


- (5) Remove setscrew (9) and remove retaining ring (10) from cylinder (11).
- (6) Remove rod assembly (12) from cylinder (11).




TA476713

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

- (7) Remove nut (13) from rod (12).
- (8) Remove wear ring (14), two piston rings (15), preformed packing (16), and wear ring (14).
- (9) Remove piston (17).
- (10) Remove backup ring (18), preformed packing (19), and backup ring (18).



- (11) Remove preformed packing (20) and backup ring (21).
- (12) Remove head (22) from rod (12).
- (13) Remove wear ring (23), and seal (24) from head (22).
- (14) Remove retaining ring (10) and wiper ring (25) from rod (12).



b. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin-and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.


c. *Assembly.*

- (1) Install wiper ring (1) in retaining ring (2).
- (2) Install retaining ring (2) on rod (3).
- (3) Install wear ring (4) and seal (5) in head (6).
- (4) Install backup ring (7) and preformed packing (8) on head (6).
- (5) Install head (6) on rod (3).




17-41. OUTRIGGER INNER AND OUTER BEAM CYLINDER REPAIR (M984E1) (CONT).

- (6) Install backup ring (9), preformed packing (10), and backup ring (9) in piston (11).
- (7) Install piston (11) on rod (3).
- (8) Install wear ring (12), preformed packing (13), two piston rings (14), and wear ring (12).
- (9) Install nut (15) on rod (3) and torque nut (15) to 110 lb-ft (149.1 N • m).



TA476719

- (10) Install rod assembly (3) in cylinder (16).
- (11) Apply thread locking and sealing compound and install retaining ring (2).
- (12) Install setscrew (17).




TA476720

NOTE

Apply lubricant to preformed packings before installing.

- (13) Install preformed packing (18).
- (14) Install preformed packing (19) and retaining ring (20).
- (15) Install preformed packing (21) and two retaining rings (22).
- (16) Repeat steps (13) through (15) for other holding valve.
- (17) Install two holding valves (23).
- (18) Install two fittings (24) and preformed packings (25) in holding valves (23).



TA500326

d. Follow-on Maintenance. None.


END OF TASK

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

17-42. CRANE CYLINDER TEST.		
This task covers:		
a. Test Setup	c. Follow-on Maintenance	
b. Test Procedure		
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
M977, M985, M984E1	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
Tool Outfit NSN 4940-01-036-5784 or equivalent	<i>TM or Para</i>	<i>Condition Description</i>
		Cylinder repaired.
<i>Special Tools</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Supplies</i>	<i>General Safety Instructions</i>	
None	None	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheeled vehicle repairer	General Support	

17-42. CRANE CYLINDER TEST (CONT).

a. Test Setup.



TA500284

WARNING

- Pressures of 2000 psi (13.8 mPa) and 2500 psi (17.2 mPa) are used during test. Hoses, fittings, etc., must be of sufficient safety factor to prevent equipment damage or personal injury.
- Install quick-disconnect in piston side port only. Rod side port must not be blocked. Damage to cylinder and/or personal injury could result.

NOTE

Proper holding valve must be installed prior to test. Removal or replacement of holding valve after test constitutes an untested cylinder assembly.

- (1) Determine piston side and rod side ports of cylinder (1) and plug remaining ports.
- (2) Install hose (2), tee (3), quick-disconnect (4), and hose (5) onto piston side port of cylinder (1).
- (3) Install hose (6), tee (7), and hose (8) onto rod side port of cylinder (1).
- (4) Install bleeder valve (9) and hose (10) onto tee (3).
- (5) Install bleeder valve (11) and hose (12) onto tee (7).
- (6) Route hoses (10) and (12) into suitable container.
- (7) Connect hoses (5) and (8) to test valve of tool outfit.

M977, M985, and M984E1 Crane Maintenance Instructions (Cont)

b. Test Procedure.

- (1) Close bleeder valves (9) and (11).
- (2) Extend and retract cylinder (1) three to five times while checking for leakage at rod seal (13).
- (3) Extend cylinder (1) full stroke and maintain pressure of 2500 psi (17.2 mPa) on hose (5) for minimum of one minute while checking for leaks.
- (4) Relieve pressure and uncouple quick-disconnect (4).

NOTE

With piston port blocked, pressurizing rod side will cause an initial retraction of the cylinder due to the compression of air within the system.

- (5) Apply 2000 psi (13.8 mPa) to hose (8).
- (6) Slowly open bleeder valve (9) to retract cylinder (1) approximately 1 inch (25.4 mm).

NOTE

If cylinder extends while applying pressure to the rod side port, cylinder has an internal leak at the piston seal and/or holding valve.

- (7) Close bleeder valve (9) and maintain 2000 psi (13.8 mPa) to hose (8) while checking for leaks and observing if cylinder (1) extends.
- (8) Slowly open bleeder valve (9) to retract cylinder (1) to midpoint of stroke and repeat Step 7.
- (9) Slowly open bleeder valve (9) to fully retract cylinder (1).
- (10) Relieve pressure and disconnect cylinder (1).
- (11) Plug or cap all ports.

c. Follow-on Maintenance. If cylinder leaked, or extended while pressurizing the rod side port, repair cylinder before using.

END OF TASK

Chapter 18 has been deleted.

CHAPTER 19 POWER TAKEOFF (PTO) AND HYDRAULIC PUMP MAINTENANCE

Contents	Para	Page
General	19-1	19-1
Power Takeoff (PTO) Repair	19-2	19-1
Power Takeoff Repair (M984E1)	19-2.1	19-12
Hydraulic Pump Repair	19-3	19-12.11
Hydraulic Pump Repair (M984E1)	19-4	19-17

Section I. INTRODUCTION

19.1 GENERAL. This chapter contains maintenance instructions for repair of the hydraulic pump and power takeoff components at the direct support maintenance level. The subassemblies and parts which must be removed before the hydraulic pump and power takeoff (PTO) components can be repaired are referenced in TM 9-2320-279-20.

Section II. POWER TAKEOFF (PTO)

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions

19-2. POWER TAKEOFF (PTO) REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
All	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
None	TM or Para	<i>Condition Description</i>
<i>Special Tools</i>	Power takeoff (PTO) on clean work surface).	
None	<i>Special Environmental Conditions</i>	
<i>Supplies</i>	None	
Oil, lubricating, item 46, Appendix C	<i>General Safety Instructions</i>	
Solvent, drycleaning, Item 57, Appendix C	None	
Compound, sealing, pipe thread, Item 29, Appendix C	<i>Level of Maintenance</i>	
Grease, automotive and artillery, Item 34, Appendix C	Direct Support	
Adhesive-sealant, silicon, Item 6, Appendix C		
<i>Personnel Required</i>		
MOS 63W, Wheel vehicle repairer		

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2. POWER TAKEOFF (PTO) REPAIR (CONT).

a. Disassembly

NOTE


There are two models of power takeoff (PTO) units. Model B has two pipe plug adapters, one pipe plug, and no cover plate.

- (1) Remove pipe plug (1), setscrew (2), and fitting (3) from power takeoff (PTO) housing (4).

NOTE

Skip step (2) and do step (2.1) for Model B.

- (2) Remove four screws (5), cover plate (6), and gasket (7).
- (2.1) Remove two pipe plugs (1.1) and pipe plug adapters (1.2).
- (3) Remove screw (8).




NOTE

Mark open-end bearing cover and power takeoff (PTO) housing.


- (4) Remove four screws (9), open-end bearing cover (10), and gasket (11) from power takeoff (PTO) housing (4).

- (5) Remove oil seal (12) and breather (13) from open-end bearing cover (10).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)


- (6) Remove four screws (14), closed-end bearing cover (15), and gasket (16) from power takeoff (PTO) housing (4).
- (7) Remove shaft assembly (17).



- (8) Remove retaining ring (18) and washer (19) from closed-end bearing cover (15).
- (9) Remove seal (20).




- (10) Remove ball bearing (21) and bearing washer (22) from output shaft (23).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2. POWER TAKEOFF (PTO) REPAIR (CONT).

- (11) Remove output gear (24) from output shaft (23).
- (12) Remove two roller bearings (25) and bearing spacer (26).




- (13) Remove ball bearing (27) from output shaft (23).




WARNING

Backup cylinder is under spring pressure and must be clamped to prevent injury caused by sudden release of parts.

- (14) Put backup cylinder (28) and inner clutch gear (29) in vise.
- (15) Remove retaining ring (30) from output shaft (23).



- (16) Remove backup cylinder (28) and inner clutch gear (29) from output shaft (23).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

- (17) Remove clutch spring (31) and piston (32) from backup cylinder (28).
- (18) Remove preformed packing (33) from piston (32).


NOTE

There are two models of power takeoff (PTO) units. Model B does not have a ball. Skip step (19) and do step (19.1) for Model B.


- (19) Remove ball (34) and wiggler wire (35).
- (19.1) Remove wiggler wire (35).



- (20) Remove eight friction plates (36) and seven steel plates (37) from inner clutch gear (29).



- (21) Remove retaining ring (38) and two preformed packings (39) from output shaft (23).



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2. POWER TAKEOFF (PTO) REPAIR (CONT).

- (22) Press idler shaft (40) from power takeoff (PTO) housing (4).
- (23) Remove two thin thrust races (41), two thrust bearings (42), two thick thrust races (43), and input gear (44) from power takeoff (PTO) housing (4).
- (24) Remove two roller assemblies (45) and bearing spacer (46) from input gear (44).

b. Cleaning/Inspection.


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all parts in dry cleaning solvent.
- (2) Inspect parts for damage. Replace damaged parts.
- (3) Coat all parts with lubricating oil.

c. Assembly.

- (1) Install bearing spacer (1) and two roller assemblies (2) into input gear (3).




TA187477




TA187478

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)



- (2) Position thin thrust race (4), thrust bearing (5), and thick thrust race (6) in power takeoff (PTO) housing (7).
- (3) Install input gear (3) thick thrust race (8), thrust bearing (9), and thin thrust race (10) in power takeoff (PTO) housing (7).




- (4) Press idler shaft (11) into power takeoff (PTO) housing (7) and input gear (3).
- (5) Install setscrew (12).


Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2. POWER TAKEOFF (PTO) REPAIR (CONT).

- (6) Install retaining ring (13) and two preformed packings (14) on output shaft (15).




- (7) Starting with friction plate (16) and alternating with steel plates (17), install 15 plates on inner clutch gear (18).




NOTE

There are two models of power takeoff (PTO) units. Model B does not have a ball. Skip steps (8) and (9) and do step (9.1) for Model B.

- (8) Install wiggler wire (19) and ball (20) in piston (21).
- (9) Stake opening so ball (20) will not come out.
- (9.1) Install wiggler wire (19) in piston (21).
- (10) Install preformed packing (22) on piston (21).
- (11) Install piston (21) and clutch spring (23) on backup cylinder (24).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)




(12) Install inner clutch gear (18) and backup cylinder (24) on output shaft (15).

(13) Put inner clutch gear (18) and backup cylinder (24) together in vise.

(14) Install retaining ring (25) on output shaft (15) and remove from vise.




(15) Install ball bearing (26) on output shaft (15).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2. POWER TAKEOFF (PTO) REPAIR (CONT).


- (16) Install bearing spacer (27) and two roller bearings (28) on output shaft (15).
- (17) Align splines on inner clutch gear (18) with splines in output gear (29) and install output gear on output shaft (15).




- (18) Install bearing washer (30) and ball bearing (31) on output shaft (15).



- (19) Install oil seal (32) and breather (33) in open-end bearing cover (34).




- (20) Install seal (35), washer (36), and retaining ring (37) in closed-end bearing cover (38).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

- (21) Apply thin coat of grease to mounting surface of power takeoff (PTO) housing (7).
- (22) Install gasket (39) on power takeoff (PTO) housing (7).
- (23) Install shaft assembly (40) in power takeoff (PTO) housing (7).
- (24) Install closed-end bearing cover (38) with four screws (41). Tighten screws to 17 to 20 lb-ft (23 to 27 N•m).



- (25) Apply thin coat of grease to mounting surface of power takeoff (PTO) housing (7).
- (26) Install gasket (42) and open-end bearing cover (34) to power takeoff (PTO) housing (7) with four screws (43). Tighten screws to 15 to 20 lb-ft (20 to 27 N•m).



WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (27) Apply a thin coat of pipe thread sealing compound to threads of pipe plug (44) and fitting (45) and install in power takeoff (PTO) housing (7).

NOTE

There are two models of power takeoff (PTO) units. Model B has two pipe plug adapters and a pipe plug. Do steps (27.1) and (27.2) for Model B.

- (27.1) Apply a thin coat of pipe thread sealing compound to threads of two pipe plug adapters (45.1) and install in power takeoff (PTO) housing (7). Tighten adapters to 25 to 30 lb-ft (34 to 41 N•m).
- (27.2) Apply a thin coat of pipe thread sealing compound to threads of one pipe plug (45.2) and install in pipe plug adapters (45.1). Tighten plugs to 8 to 12 lb-ft (11 to 16 N•m).

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2. POWER TAKEOFF (PTO) REPAIR (CONT).

(28) Install screw (46).


NOTE

There are two models of power takeoff (PTO) units. Model B has no cover plate. Skip steps (29) and (30) for Model B.

(29) Apply silicone adhesive-sealant to threads of four screws (47) and install gasket (48) and cover plate (49) with four screws to power takeoff (PTO) housing (7).

(30) Tighten screws (47) to 15 to 20 lb-ft (20 to 27 N•m)

d. Follow-on Maintenance. None



END OF TASK

19-2.1 POWER TAKEOFF REPAIR (M984E1).	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M984E1	<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer
<i>Test Equipment</i> None	<i>References</i> None
<i>Special Tools</i> None	<i>Equipment Condition</i> TM or Para
<i>Supplies</i> Oil, lubricating, Item 46, Appendix C Solvent, drycleaning, Item 57, Appendix C Compound, sealing, pipe thread, Item 29, Appendix C Grease, automotive and artillery, Item 34, Appendix C Sealing and thread locking compound, Item 25, Appendix C	<i>Condition Description</i> Power takeoff on a clean work surface.
	<i>Special Environmental Conditions</i> None
	<i>General Safety Instructions</i> None
	<i>Level of Maintenance</i> General Support

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

a. Disassembly.

NOTE


There are two models of power takeoff (PTO) units. Model B has two pipe plug adapters, one pipe plug, and no cover plate.

- (1) Remove pipe plug (1) and setscrew (2) from power takeoff (PTO) (3).


NOTE

Skip step (2) and do step (2.1) for Model B.

- (2) Remove four screws (4), cover plate (5), and gasket (6).
- (2.1) Remove one pipe plug (1.1) and pipe plug and pipe plug adapter (1.2).




MODEL A



MODEL B

- (3) Remove idler shaft (7) from power takeoff (PTO) (3).
- (4) Remove two thin thrust races (8), two thrust bearings (9), two thick thrust races (10), and input gear (11) from PTO (3).
- (5) Remove two roller assemblies (12) and bearing spacer (13) from input gear (11).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2.1. POWER TAKEOFF REPAIR (M984E1) (CONT).

NOTE

Mark pump housing assembly and PTO for installation.


- (6) Remove four screws (14), pump housing assembly (15), and gasket (16) from PTO (3).
- (7) Remove oil seal (17).




NOTE

Mark closed-end bearing cover and PTO housing for installation.

- (8) Remove four screws (18), closed-end bearing cover (19) gasket (20) and output shaft assembly (21) from PTO (3).
- (9) Remove closed-end bearing cover (19) from output shaft assembly (21).




- (10) Remove retaining ring (22) and washer (23) from closed-end bearing cover (19).
- (11) Remove seal (24).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

- (12) Remove ball bearing (25) and bearing washer (26) from output shaft assembly (21).



TA476534

- (13) Remove output gear (27) from output shaft assembly (21).
 (14) Remove two roller bearings (28) and bearing spacer (29).




TA476535

- (15) Remove ball bearing (30) from output shaft assembly (21).

WARNING


Backup cylinder is under spring pressure and must be clamped to prevent injury caused by sudden release of parts.

- (16) Put backup cylinder (31) and inner clutch gear (32) in vise.
 (17) Remove retaining ring (33) from output shaft assembly (21).



TA476536

- (18) Remove backup cylinder (31), spring (34), and inner clutch gear (32) from output shaft assembly (21).




TA476537


Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2.1. POWER TAKEOFF REPAIR (M984E1) (CONT).


- (19) Remove piston (35) from backup cylinder (31).
- (20) Remove preformed packing (36) from piston (35).



- (21) Remove eight friction discs (37) and seven spur gears (38) from inner clutch gear (32).



- (22) Remove retaining ring (39) and two preformed packings (40) from output shaft assembly (21).



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)


b. *Cleaning/Inspection.*WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect friction discs for worn-out condition. If oil grooves are not visible on any portion of any one friction disc, replace all friction discs.
- (3) Inspect clutch spring for breaks or discoloration. Replace spring if broken or discolored.
- (4) Inspect remaining parts for damage. Replace damaged parts.
- (5) Coat all parts with lubricating oil.
- (6) Inspect idler shaft, output shaft, and thrust washers for nicks, burrs, grooves, warps, bends, etc. If nicks, burrs or grooves cannot be removed with emery cloth, replace part.


c. *Assembly.*

- (1) Install retaining ring (1) and two preformed packings (2) on output shaft assembly (3).



TA476541

- (2) Starting with friction disc (4) and alternating with spur gears (5) install eight friction discs and seven spur gears on inner clutch gear (6).




TA476542

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)


19-2.1. POWER TAKEOFF REPAIR (M984E1) (CONT).

- (3) Install preformed packing (7) on clutch piston (8) as shown.
- (4) Install clutch piston (8) in backup cylinder (9).




TA476543

- (5) Install spring (10), inner clutch gear (6), and backup cylinder (9) on output shaft assembly (3).




TA476544

- (6) Put inner clutch gear (6) and backup cylinder (9) together in vise.
- (7) Install retaining ring (11) on output shaft assembly (3) and remove from vise.
- (8) Install ball bearing (12) on output shaft assembly (3).




TA476545

- (9) Install bearing spacer (13) and two roller bearings (14) on output shaft assembly (3).
- (10) Aline splines on steel plates (5) with splines in output gear (15) and install on output shaft assembly (3).




TA476546


Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)



(11) Install bearing washer (16) and ball bearing (17) on output shaft assembly (3).




(12) Install seal (18), washer (19), and retaining ring (20) in closed-end bearing cover (21).



(13) Install closed-end bearing cover (21) on output shaft assembly (3).

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2.1. POWER TAKEOFF REPAIR (M984E1), (CONT).



TA476550

(14) Apply thin coat of grease to mounting surface of PTO (22).

NOTE

Aline matchmarks on closed-end bearing cover and PTO before installing.

(15) Install gasket (23) and closed-end bearing cover (21) and output shaft assembly (3) to PTO (22) with four screws (24). Tighten screws to 15 to 20 lb-ft (20 to 23 N·m).


(16) Install oil seal (25) in pump housing assembly (26).

(17) Apply thin coat of grease to mounting surface of PTO (22).

NOTE

Aline matchmarks on pump housing assembly and PTO before installing.


(18) Install gasket (27) and pump housing assembly (26) with four screws (28). Tighten screws to 17 to 20 lb-ft (23.0 to 27.1 N·m).




TA476551

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

- (19) Install roller assembly (29), bearing spacer (30), and roller assembly (29) into input gear (31).



TA476552



TA476553

NOTE

Line up flat spot on idler shaft with setscrew hole.

- (20) Install idler shaft (32), with slot facing out, in PTO (22) until about 1/4 in. (6 mm) shows in opening in PTO.
- (21) Install thin thrust washer (33), thrust bearing (34), and thick thrust washer (35) on idler shaft (32).
- (22) Install input gear (31) on idler shaft (32) and press idler shaft through input gear, leaving space to install thrust washers (33 and 35) and thrust bearing (34).
- (23) Install thin thrust washer (33), thrust bearing (34), and thick thrust washer (35) under input gear (31).
- (24) Press idler shaft (32) into PTO (22).

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-2.1. POWER TAKEOFF REPAIR (M984E1) (CONT).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (25) Apply thread locking compound to threads of setscrew (36) and install in PTO (22).
- (26) Apply a thin coat of pipe thread sealing compound to threads of pipe plug (37) and install in PTO (22).


NOTE

There are two models of power takeoff (PTO) units. Model B has two pipe plug adapters, two pipe plugs and no cover plate. Do steps (26.1) and (26.2) and skip steps (27) and (28) for Model B.


- (26.1) Apply a thin coat of pipe thread sealing compound to threads of two pipe plug adapters (37.1) and install in PTO (22). Tighten adapters to 25 to 30 lb-ft (34 to 41 N•m).
- (26.2) Apply a thin coat of pipe thread sealing compound to threads of pipe plug (37.2) and install in pipe plug adapters (37.1). Tighten plugs to 8 to 12 lb-ft (11 to 16 N•m).
- (27) Apply thread locking compound to threads of four screws (38) and install gasket (39) and cover plate (40) with four screws to PTO (22).
- (28) Tighten screws (38) to 15 to 20 lb-ft (20 to 27 N•m).

d. Follow-on Maintenance. None.

END OF TASK



MODEL A



MODEL B

Section III. HYDRAULIC PUMP

19-3. HYDRAULIC PUMP REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i> All	<i>References</i> None	
<i>Test Equipment</i> None	<i>Equipment Condition</i> TM or Para	<i>Condition Description</i> Hydraulic pump on clean work surface.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None	
<i>Supplies</i> Oil, lubricating, Item 46, Appendix C Solvent, drycleaning, Item 57, Appendix C	<i>General Safety Instructions</i> None	
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support	

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

a. Disassembly.

NOTE

- There are two models of hydraulic pumps. Model B has two preformed packings and different wear plate configuration. The Model B pump is equal in size and functional performance and fully interchangeable with Model A pump.

- Mark front and rear covers and center section.



- (1) Place hydraulic pump (1) in vise.
- (2) Remove four screws (2), four screws (3), and eight lockwashers (4).
- (3) Remove front cover (5) from center section (6).
- (4) Remove shaft seal (7).

NOTE

Model B pump has preformed packing. Do step (4.1) for Model B.

- (4.1) Remove preformed packing (7.1) from front cover (5).
- (5) Remove seal gland (8), seal retainer (9), and front wear plate (10) from center section (6).

- (6) Remove drive gear (11) and driven gear (12) from center section (6) and rear cover (13).



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-3. HYDRAULIC PUMP REPAIR (CONT).

- (7) Remove center section (6) and rear wear plate (14) from rear cover (13).
- (8) Remove seal retainer (15) and seal gland (16) from rear cover (13).

NOTE

Model B pump has preformed packing. Do step (9) for Model B.


- (9) Remove preformed packing (17) from rear cover (13).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in drycleaning solvent.
- (2) Inspect parts for defects. Replace if necessary.
- (3) Coat all parts with lubricating oil.
- (4) Bushing inside diameter must not exceed 0.003 in. (0.076 mm) larger than shaft diameter.



c. Assembly.

NOTE


There are two models of hydraulic pumps. Model B has two preformed packings and different wear plate configuration.

- (1) Place rear cover (1) in vise with inside facing up.


NOTE

Model B Pump has preformed packing. Do step (1.1) for Model B.

- (1.1) Install preformed packing (1.1) on rear cover (1).
- (2) Install seal gland (2) in rear cover (1).
- (3) Install seal retainer (3) with flat side facing up.
- (4) Install rear wear plate (4) with bronze side up on rear cover (1).
- (5) Aline notches and install center section (5).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)



NOTE

Grooved gear ends go in rear cover.

- (6) Install driven gear (6) and drive gear (7) in center section (5) and rear cover (1).



NOTE

Wear plates of Models A and B have different configurations.

- (7) Install wear plate (8) on center section (5) with bronze side down.

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-3. HYDRAULIC PUMP REPAIR (CONT).

- (8) Install shaft seal (9) in front cover (10).
- (9) Place front cover (10) in vise, inside facing up.

NOTE

Model B pump has preformed packing. Do step (9.1) for Model B.




- (9.1) Install preformed packing (10.1) on front cover (10).
- (10) Install seal gland (11) and seal retainer (12) with flat side facing up.

- (11) Aline notches and install rear assembly (13) on front cover (10).

- (12) Install four long screws (14), four short screws (15), and eight lockwashers (16). Tighten screws to 55 to 65 lb-ft (75 to 88 N•m).
- (13) Use suitable socket and torque wrench to turn drive. If tightness exceeds 35 lb-in. (4 N•m), disassemble and repair hydraulic pump (17).

d. Follow-on Maintenance. None.

END OF TASK



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-4. HYDRAULIC PUMP REPAIR (M984E1)

This task covers:

- | | |
|------------------------|--------------------------|
| a. Disassembly | c. Assembly |
| b. Cleaning/Inspection | d. Follow-on Maintenance |

INITIAL SETUP

Models
None

References
None

Test Equipment
None

Equipment Condition

<i>TM or Para</i>	<i>Condition Description</i>
	Hydraulic pump on clean work surface.

Special Tools
None

Special Environmental Conditions
None

Supplies
 Oil, lubricating, Item 46, Appendix C
 Cloth, drycleaning, Item 16, Appendix C
 Solvent, drycleaning, Item 57, Appendix C
 Jelly, Petroleum, Item 38.1, Appendix C

General Safety Instructions
None

Personnel Required
MOS 63W, Wheel vehicle repairer

Level of Maintenance
Direct Support

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-4. HYDRAULIC PUMP REPAIR (M984E1) (CONT).


a. Disassembly.

CAUTION

If shaft end pump or cover end pump is suspected of failure, both pumps must be disassembled and inspected or early failure of pump may occur because of contamination or unseen damage.

NOTE

- There are two models of hydraulic pumps. Model B has four additional preformed packings, one seal ring, different wear plate configuration and different hardware. The Model B pump is equal in size and functional performance and fully interchangeable with Model A pump.
 - Matchmark pump parts before beginning disassembly
- (1) Position hydraulic pump inlet port section (1) in soft-jaw vise.
 - (2) Remove eight nuts (2), lockwashers (3), and end cover (4).
 - (3) Remove seal retainer (5) and seal gland (6) from end cover (4).



NOTE

Model B pump has a seal ring and preformed packing. Do steps (3.1) and (3.2) for Model B.

- (3.1) Remove preformed packing (6.1) from end cover (4).
- (3.2) Remove seal ring (6.2).
- (4) Remove retaining ring (7), shaft seal (8), and plug (9) from end cover (4).
- (5) Remove front wear plate (10).


Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

- (6) Remove drive gear (11) and driven gear (12).
- (7) Remove center section (13).
- (8) Remove rear wear plate (14), seal retainer (15), and seal gland (16) from inlet port section (1).

NOTE

Model B pump has preformed packing. Do step (8.1) for Model B.

- (8.1) Removed preformed packing (16.1) from inlet port section (1).




- (9) Turn inlet port section (1) over in soft-jaw vise.

NOTE

Model B has preformed packing and different attaching hardware for rear cover. Do steps (10.1), (11), (12), and (12.1) for Model B. Do steps (10), (11), and (12) for Model A.

- (10) Remove two nuts (17), screws (17.1), and four lockwashers (18).
- (10.1) Remove four screws (17.1) and lockwashers (18).
- (11) Remove four screws (19), lockwashers (20), and rear cover (21).
- (12) Remove seal retainer (22) and seal gland (23) from rear cover (21).
- (12.1) Remove preformed packing (23.1) from rear cover (21).




Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-4. HYDRAULIC PUMP REPAIR (M984E1) (CONT).

NOTE

Wear plate of Model B pump has a different configuration.

- (13) Remove front wear plate (24).
- (14) Remove drive gear (25) and driven gear (26).
- (15) Remove center section (27) from inlet port section (1).



- (16) Remove rear wear plate (28), seal retainer (29), and seal gland (30).

NOTE


Model B has an additional preformed packing. Do step (16.1) for Model B.

- (16.1) Remove preformed packing (30.1) from center section (31).
- (17) Remove center section (31).
- (18) Remove preformed packing (32).

NOTE

Model A has two studs installed in inlet port section. Do step (20) for Model A.

- (19) Remove coupling (33).
- (20) Remove two studs (34) from inlet port section (1).
- (21) Remove eight studs (36) from inlet port section (1).



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)**b. Cleaning/Inspection.****WARNING**

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with drycleaning solvent.
- (2) Inspect drive and driven gear bushings for flaking, scoring, discoloration, or wear more than 0.003 in. (0.076 mm) larger than shaft diameter. Replace cover if any listed condition is observed.
- (3) Inspect cover inside flanges for nicks and burrs. Remove with crocus cloth.
- (4) Inspect wear plates for erosion, pitting, scratches, and scoring.
- (5) Inspect center sections for porosity (oil seepage thru metal), cracks, and scratches (0.010 in./0.25 mm or deeper).

CAUTION

Do not deburr figure eight edge of center section. Pump efficiency and power will be affected.

- (6) Inspect drive and driven gear splines for nicks and worn-out condition. Inspect gear journals for scratches and discoloration. Replace drive or driven gear that has any discoloration. It has been overheated.
- (7) Inspect gear teeth for spalling, scratches, and worn-out condition. Removal of scratches with crocus cloth is permitted.
- (8) Inspect port section inlet flanges for nicks and burrs. Remove with crocus cloth.
- (9) Inspect studs, screws, and nuts for cracks, burrs, and cross threading.
- (10) Coat all metal parts with lubricating oil.

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-4. HYDRAULIC PUMP REPAIR (M984E1) (CONT).

c. Assembly

NOTE

- There are two models of hydraulic pumps. Model B has four additional preformed packings and different wear plate configuration.
 - Lubricate all parts with oil before installing.
- (1) Install eight studs (1) in inlet port section (2). Tighten studs to 25 to 35 lb-ft (34 to 48 N•m).

NOTE

Model A has two studs. Do step (2) for Model A. Do step 5.1 for Model B.

- (2) Install two studs (3) in inlet port section (2). Tighten studs to 25 to 35 lb-ft (34 to 48 N•m).
- (3) Install preformed packing (5).
- (4) Install coupling (6).
- (5) Install center section (7).

NOTE


Do step (5.1) for Model B.

- (5.1) Install preformed packing (7.1) on center section (7).

NOTE

Coat seal glands with small amounts of petroleum jelly to hold in place in seal retainers during assembly.

- (6) Install seal gland (8), seal retainer (9), and rear wear plate (10), bronze end up.



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

CAUTION


Make sure gear teeth on drive gear and driven gear are same size or equipment can be damaged when installing rear cover.

- (7) Install drive gear (11) and driven gear (12) in center section (13).


NOTE

Wear plate of Model B pump has a different configuration.

- (8) Install center section (13) on rear wear plate (10).
- (9) Install front wear plate (14), bronze side up.



MODEL A




MODEL B


NOTE

Model B has preformed packing and different hardware for attaching rear cover. Do steps (9.1), (10), (11), and (12.1) for Model B. Do steps (10), (11), and (12) for Model A.

- (9.1) Install preformed packing (14.1) on rear cover (17).
- (10) Install seal gland (15) and seal retainer (16) into rear cover (17).
- (11) Lubricate threads of four screws (18). Install rear end cover (17), screws (18), and four lockwashers (19). Tighten screws to 60 lb-ft (81 N•m).
- (12) Lubricate threads of studs (3). Install four lockwashers (20), two nuts (21), and two screws (21.1). Tighten nuts and screws to 60 lb-ft (81 N•m).
- (12.1) Lubricate threads of four screws (21.1). Install four screws (21.1) and lockwashers (20). Tighten screws to 60 lb-ft (81 N•m).



MODEL A



MODEL B

Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)

19-4. HYDRAULIC PUMP REPAIR (M984E1) (CONT).

(13) Place inlet port section (2) in vise with inside facing up.

NOTE

Model B has preformed packing. Do step (13.1) for Model B.

- (13.1) Install preformed packing (21.2) on inlet port section (2).
- (14) Install seal gland (22) in inlet port section (2).
- (15) Install seal retainer (23) with flat side facing up.
- (16) Install rear wear plate (24) with bronze side up on inlet port section (2).
- (17) Aline notches and install center section (25).


CAUTION

Make sure gear teeth on drive gear and driven gear are same size or equipment can be damaged when installing end cover.


NOTE

Grooved end of gears goes in inlet port section.

- (18) Install driven gear (26) and drive gear (27) in inlet port section (2).



Power Takeoff (PTO) and Hydraulic Pump Maintenance Instructions (Cont)



- (19) Install front wear plate (28) on center section (25) with bronze side down.
 (20) Install shaft seal (29) and retaining ring (30) in end cover (31).

NOTE

Model B pump has a seal ring and preformed packing. Do steps (20.1) and (20.2) for Model B.

- (20.1) Install seal ring (31.1) in end cover (31).
 (20.2) Install preformed packing (31.2) on end cover (31).
 (21) Install seal gland (32), seal retainer (33), and plug (34) in end cover (31).
 (22) Lubricate threads of studs (1). Install end cover (31), eight lockwashers (35), and nuts (36). Tighten nuts to 55 to 65 lb-ft (75 to 88 N•m).

NOTE

Socket may slip when turning shaft. Shop rag may be used to make tighter fit.

- (23) Use 13/16 in. 12 pt. socket and torque wrench to turn drive gear (27). If more than 140 lb-in. (15.6 N•m) is required to turn shaft, disassemble and assemble hydraulic pump.

d. Follow-on Maintenance. None.

END OF TASK

CHAPTER 20 HYDRAULIC SYSTEM MAINTENANCE

Contents	Para	Page
General	20-1	20-1
Hydraulic Hand Pump Repair (M983)	20-2	20-1
Winch/Auxiliary Hydraulic Relief Valve Repair (M983, M984)	20-3	20-5
Self-Recovery Winch Control Valve Assembly Repair	20-4	20-7
Heavy-Duty Selector Valve Repair (M984)	20-5	20-10
Ancillary Equipment Engine Idle Speed Adjustment (M984)	20-6	20-17
Primary Pump Hydraulic Motor Control Valve Repair (M978)	20-7	20-20
Heavy-Duty Winch Manifold Removal/Installation (M984E1)	20-8	20-23
Heavy-Duty Winch Manifold Repair (M984E1)	20-9	20-26
Retriever Control Valve Repair (M984E1)	20-10	20-37

Section I. INTRODUCTION

20-1. GENERAL. This chapter contains maintenance instructions for repair of the hydraulic system at the direct support level.

Section II. HYDRAULIC HAND PUMP


Hydraulic System Maintenance Instructions

20-2. HYDRAULIC HAND PUMP REPAIR (M983).		
This task covers:		
<ul style="list-style-type: none"> a. Disassembly b. Cleaning/Inspection 	<ul style="list-style-type: none"> c. Assembly d. Follow-on Maintenance 	
INITIAL SETUP		
<p><i>Models</i></p> <p>M983</p> <p><i>Test Equipment</i></p> <p>None</p> <p><i>Special Tools</i></p> <p>None</p> <p><i>Fabricated Tools</i></p> <p>Seal retainer tool, Item 7, Appendix B Valve seat tool, Item 6, Appendix B</p> <p><i>Supplies</i></p> <p>Solvent, dry cleaning, Item 57, Appendix C</p> <p><i>Personnel Required</i></p> <p>MOS 63W, Wheel vehicle repairer</p>	<p><i>References</i></p> <p>None</p> <p><i>Equipment Condition</i></p> <p><i>TM or Para</i></p> <p><i>Condition Description</i></p> <p>Hydraulic hand pump on clean work surface.</p> <p><i>Special Environmental Conditions</i></p> <p>None</p> <p><i>General Safety Instructions</i></p> <p>None</p> <p><i>Level of Maintenance</i></p> <p>Direct Support</p>	

20-2. HYDRAULIC HAND PUMP REPAIR (M983) (CONT).


a. Disassembly.

- (1) Remove two cotter pins (1), pins (2), four washers (3), and two pivot links (4).
- (2) Remove screw (5), pivot pin (6), and pivot arm (7).




TA187443

- (3) Remove bushing (8) from pivot arm (7).
- (4) Remove two bushings (9) from pump body (10).



TA187442




TA187441

- (5) Using valve seat tool, remove valve seat (11) and preformed packing (12) from pump body (10).
- (6) Turn pump body (10) over and remove valve poppet (13), preformed packing (14), and spring (15).
- (7) Using seal retainer tool, remove seal retainer (16).
- (8) Remove nylon insert (17).
- (9) Remove piston rod (18).

Hydraulic System Maintenance Instructions (Cont)

- (10) Remove rod scraper (19), seal housing (20), backup ring (21), preformed packing (22), backup ring (23), and preformed packing (24) from piston rod (18).
- (11) Using valve seat tool, remove valve seat (25), preformed packing (26), valve poppet (27), preformed packing (28), and spring (29).
- (12) Remove backup ring (30), preformed packing (31), and backup ring (32).




TA187440

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA187439

- (1) Clean all metal parts with dry cleaning solvent.
- (2) Inspect pump body for cracks and stripped threads.
- (3) Inspect pump body ports for scratched valve seating areas.
- (4) Inspect poppet valve seats for scratches and grooves.
- (5) Inspect seal retainer for stripped threads.
- (6) Inspect valve seats for scratches and grooves.
- (7) Inspect springs for breaks.
- (8) Inspect inside of bushings for out-of-round condition.

c. Assembly.

- (1) Install backup ring (1), preformed packing (2), and backup ring (3) on piston rod (4).
- (2) Install spring (5), preformed packing (6), valve poppet (7), preformed packing (8), and valve seat (9). Using valve seat tool, tighten valve seat to 90 to 100 lb-in. (10 to 11 N·m).
- (3) Install preformed packing (10), backup ring (11), preformed packing (12), backup ring (13), seal housing (14), and rod scraper (15).




TA187438

Hydraulic System Maintenance Instructions (Cont)


20-2. HYDRAULIC HAND PUMP REPAIR (M983) (CONT).

- (4) Install piston rod (4) in pump body (16).
- (5) Install nylon insert (17) in seal retainer (18).
- (6) Using seal retainer tool, install seal retainer (18).
Tighten seal retainer to 79 to 83 lb-ft (107 to 113 N·m).
- (7) Install spring (19), preformed packing (20), and valve poppet (21).
- (8) Install preformed packing (22) and valve seat (23).
Using valve seat tool, tighten valve seat to 90 to 100 lb-in. (10 to 11 N·m).




TA187437

- (9) Install two bushings (24) in pump body (16).
- (10) Install bushing (25) in pivot arm (26).



TA187436

- (11) Install pivot arm (26), pivot pin (27), and screw (28).
- (12) Install two pivot links (29), four washers (30), two pins (31), and cotter pins (32).



TA187435

d. Follow-on Maintenance. None.


END OF TASK

Hydraulic System Maintenance Instructions (Cont)

Section III. HYDRAULIC CONTROL VALVES

20-3. WINCH/AUXILIARY HYDRAULIC RELIEF VALVE REPAIR (M983, M984).		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
M984, M983 without crane	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>		Relief valve on clean work surface.
None		
<i>Special Tools</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Supplies</i>	<i>General Safety Instructions</i>	
Oil, lubricating, Item 46, Appendix C	None	
Solvent, dry cleaning, Item 57, Appendix C	<i>Level of Maintenance</i>	
<i>Personnel Required</i>	Direct Support	
MOS 63W, Wheel vehicle repairer		
<i>References</i>		
None		

a. Disassembly.



TA189235

- (7) Remove spring retaining plug (1), spring end (2), spring (3), and poppet (4) from relief valve body (5).
- (2) Remove preformed packing (6) from spring retaining plug (1).
- (3) Remove preformed packing (7) and packing retainer (8) from poppet (4).
- (4) Remove valve seat (9) from relief valve body (5).
- (5) Remove plug (10), lockscrew (11), and setscrew (12) from spring retaining plug (1).

Hydraulic System Maintenance instructions (Cont)


20-3. WINCH/AUXILIARY HYDRAULIC RELIEF VALVE REPAIR (M983, M984) (CONT).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect all parts for damage.
- (3) Replace damaged parts.
- (4) Relief valve for M983 vehicle is preset for 3000 psi (20 685 kPa). Relief valve for M984 vehicle is preset for 2500 psi (17 238 kPa). Do not mix plugs on valves.



TA357076

c. *Assembly.*

- (1) Install setscrew (1), lock screw (2), and plug (3) in spring retaining plug (4).
- (2) Install valve seat (5) in relief valve body (6).
- (3) Coat preformed packing (7) with oil and install packing retainer (8) and preformed packing on poppet (9).
- (4) Coat preformed packing (10) with oil and install on spring retaining plug (4).
- (5) Install poppet (9), spring (11), spring end (12), and spring retaining plug (4) in relief valve body (6).

d. *Follow-on Maintenance.* None.

END OF TASK

Hydraulic System Maintenance Instructions (Cont)

20-4. SELF-RECOVERY WINCH CONTROL VALVE ASSEMBLY REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

All

Test Equipment

None

Special Tools

None

Supplies

Solvent, dry cleaning, Item 57, Appendix C
Oil, lubricating, Item 47, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

Self-recovery winch control valve assembly on clean work surface.

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support


a. Disassembly.



- (1) Remove two screws (1) and bracket (2).
- (2) Remove relief valve (3). Remove two preformed packings (4 and 5) and retainer (6).
- (3) Remove plug assembly (7), preformed packing (8), spring (9), and load check poppet (10).
- (4) Remove four screws (11) and cover (12).


Hydraulic System Maintenance Instructions (Cont)

20-4. SELF-RECOVERY WINCH CONTROL VALVE ASSEMBLY REPAIR (CONT)



TA357170

- (5) Remove spool (13), spacer (14), packing retainer (15), and preformed packing (16).
- (6) Remove packing retainer (17) and preformed packing (18) from valve body (19).



TA357171

- (7) Remove screw (20), washer (21), spool collar (22), spring (23), spacer (24), and washer (25) from valve spool (13).

b. *Cleaning/Inspection.*


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all parts with dry cleaning solvent.
- (2) Inspect springs for breaks, cracks, and worn spots on coil. Replace springs if broken, cracked, or worn.
- (3) Inspect for damaged threads. Repair damaged threads. If threads on valve body cannot be repaired, replace control valve assembly.
- (4) Inspect valve body for breaks or cracks, or grooves in valve spool bore. Replace control valve assembly if valve body is damaged.
- (5) Inspect valve spool for cracks and scoring. Replace control valve assembly if valve spool is damaged,

Hydraulic System Maintenance Instructions (Cont)

c. Assembly.




TA357172

NOTE

Lubricate all internal parts before installing.


- (1) Install washer (1), spacer (2), spring (3), spool collar (4), washer (5), and screw (6) on valve spool (7).



TA357173

- (2) Install spacer (8), packing retainer (9), and preformed packing (10) on valve spool (7).
 (3) Install valve spool (7) in valve body (11).
 (4) Install preformed packing (12) and packing retainer (13) on valve spool (7).

- (5) Install cover (14) with four screws (15).
 (6) Install preformed packing (16) on plug (17). Install load check poppet (18), spring (19), and plug (17) in valve body (11).
 (7) Install two preformed packings (20 and 21) and retainer (22) on relief valve (23). Install relief valve.
 (8) Install bracket (24) with two screws (25).



TA357174


d. Follow-on Maintenance. None.

END OF TASK

Hydraulic System Maintenance Instructions (Cont)

20-5. HEAVY-DUTY SELECTOR VALVE REPAIR (M984).		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models M984	References None	
Test Equipment None	Equipment Condition TM or Para	Condition Description Heavy-duty selector valve on clean work surface.
Special Tools None		
Supplies Tags, identification, Item 60, Appendix C Compound, sealing, pipe thread, Item 29, Appendix C Solvent, dry cleaning, Item 57, Appendix C	Special Environmental Conditions None	
Personnel Required MOS 63W, Wheel vehicle repairer	General Safety Instructions None	
	Level of Maintenance Direct Support	

a. Disassembly.



TA189208

NOTE

Tag and mark solenoids before disassembly.


(1) Remove two solenoids (1) from valve body (2).

Hydraulic System Maintenance Instructions (Cont)

NOTE


Both solenoids are disassembled the same way.

- (2) Remove nut (3), spacer (4), and valve (5) from coil (6).
- (3) Remove two backup rings (7), preformed packings (8), and preformed packing (9).
- (4) Remove connector (10).




TA189215

- (5) Remove plug (11) from valve body (2).
- (6) Remove preformed packing (12), backup ring (13), and preformed packing (14) from plug (11).
- (7) Remove valve (15) from valve body (2).
- (8) Remove preformed packing (16), backup ring (17), and preformed packing (18) from valve (15).



TA189220

- (9) Remove plug (19) and plug (20) from valve body (2).
- (10) Remove preformed packing (21) from plug (20).
- (11) Remove valve (22) from valve body (2).
- (12) Remove preformed packing (23), backup ring (24), and preformed packing (25) from valve (22).
- (13) Remove plug (26), spring (27), and valve (28) from valve body (2).
- (14) Remove preformed packing (29) from plug (26).




TA189207


Hydraulic System Maintenance Instructions (Cont)

20-5. HEAVY-DUTY SELECTOR VALVE REPAIR (M984) (CONT).

- (15) Remove two nuts (30), screws (31), nuts (32), and screws (33) from two manifolds (34 and 35).
- (16) Remove two manifolds (34 and 35) from valve body (2).



TA189210



TA189221


- (17) Remove two preformed packings (36), preformed packing (37), and preformed packing (38) from manifold (34).
- (18) Remove two preformed packings (39), preformed packing (40), and preformed packing (41) from valve body (2).

Hydraulic System Maintenance Instructions (Cont)

NOTE

- Left and right valve body ends are disassembled the same way.
- Mark valve body ends before removing.

- (19) Remove two screws (42), screws (43), and valve body end (44) from valve body (2).
- (20) Remove spring (45), preformed packing (46), and two preformed packings (47) from valve body end (44).
- (21) Remove spacer (48) and spool (49) from valve body (2).



TA189217


b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect all parts for damage.
- (3) Replace damaged parts.

c. *Assembly.*



TA189216


NOTE

Left and right valve body ends are assembled the same way.


- (1) Install spool (1) in valve body (2).
- (2) Install spacer (3) on valve body (2).
- (3) Install two preformed packings (4), preformed packing (5), and spring (6) on valve body end (7).
- (4) Install valve body end (7) on valve body (2) with two screws (8) and screws (9).

Hydraulic System Maintenance Instructions (Cont)

20-5. HEAVY-DUTY SELECTOR VALVE REPAIR (M984) (CONT).



- (5) Install two preformed packings (10), preformed packing (11), and preformed packing (12) in valve body (2).
- (6) Install two preformed packings (13), preformed packing (14), and preformed packing (15) in manifold (16).




- (7) Install two manifolds (16 and 17) on valve body (2) with two screws (18), nuts (19), screws (20), and nuts (21).

Hydraulic System Maintenance Instructions (Cont)

- (8) Install preformed packing (22) on plug (23).
- (9) Install valve (24), spring (25), and plug (23) in valve body (2).
- (10) Install preformed packing (26), backup ring (27), and preformed packing (28) on valve (29).
- (11) Install valve (29) in valve body (2).
- (12) Install preformed packing (30) on plug (31).
- (13) Install plug (31) in valve body (2).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.



TA189206

- (14) Coat threads of plug (32) with pipe thread sealing compound and install in valve body (2).




TA189212

- (15) Install preformed packing (33), backup ring (34), and preformed packing (35) on valve (36).
- (16) Install valve (36) in valve body (2).
- (17) Install preformed packing (37), backup ring (38), and preformed packing (39) on plug (40).
- (18) Install plug (40) in valve body (2).

Hydraulic System Maintenance Instructions (Cont)

20-5. HEAVY-DUTY SELECTOR VALVE REPAIR (M984) (CONT).



TA189214


NOTE

Both solenoids are assembled the same way.

(19) Install connector (41).

(20) Install preformed packing (42), two preformed packings (43), and backup rings (44) on valve (45).

(21) Install valve (45) and spacer (46) on coil (47) with nut (48).



TA189209

(22) Install two solenoids (49) in valve body (2).

d. Follow-on Maintenance. None.

END OF TASK

Hydraulic System Maintenance Instructions (Cont)

20-6. ANCILLARY EQUIPMENT ENGINE IDLE SPEED ADJUSTMENT (M984).

This task covers:

- a. Maximum Load Speed Adjustment
- b. Engine Idle Speed Adjustment
- c. Follow-on Maintenance

INITIAL SETUP

Model
M984

Test Equipment
None

Special Tools
Turbocharger inlet shield J26554-A

Supplies
None

Personnel Required
MOS 63W, Wheel vehicle repairer (2)

References
None

Equipment Condition


<i>TM or Para</i>	<i>Condition Description</i>
TM 9-2320-279-34&P	Throttle delay adjusted.
TM 9-2320-279-10	Engine side panels removed.
TM 9-2320-279-20	Air intake ducting removed.

Special Environmental Conditions
None

General Safety Instructions
None

Level of Maintenance
Direct Support

a. Maximum Load Speed Adjustment.



TA357066


NOTE

Tag and mark wires before disconnecting.

(1) Disconnect two wires (1) from connectors (2) and solenoids (3) on selector valve (4).

Hydraulic System Maintenance Instructions (Cont)

20-6. ANCILLARY EQUIPMENT ENGINE IDLE SPEED ADJUSTMENT (M984) (CONT).



TA189475

- (2) Disconnect airhose (5) from high speed spring retainer cover (6).
- (3) Remove two screws (7), lockwashers (8), high speed spring retainer cover (6), and gasket (9).
- (4) Loosen idle speed locknut (10).

NOTE

Record number of turns (approximately 7 to 8).

- (5) Turn adjusting screw (11) clockwise until snug.
- (6) Tighten idle speed locknut (10).
- (7) Loosen high speed locknut (12).
- (8) Install turbocharger inlet air shield on air inlet port (13).

WARNING

- Use extreme care when working around air inlet. Hands and tools may be pulled in causing personal injury or death.
- Wear ear protection when running engine. Noise volume of engine can cause hearing loss or injury.
- Do not touch hot engine with bare hands. Manifolds and covers are hot and can cause severe burns if touched.

CAUTION

Run engine in clean area when air intake ducting is removed. Dirt, dust, and particles in unfiltered air can enter engine intake. Dust in engine can damage parts and cause mechanical failure.

NOTE

This task requires two soldiers; one to operate engine, and one to make adjustments.

- (9) Start engine (TM 9-2320-279-10).
- (10) Operate engine for 15 minutes.
- (11) Engage PTO switch (TM 9-2320-279-10).
- (12) Activate ENGINE HIGH IDLE (TM 9-2320-354-10).

Hydraulic System Maintenance Instructions (Cont)

NOTE

Maximum load speed is 1800 rpm.

- (13) Turn air cylinder (14) clockwise to correct engine speed.
- (14) Tighten high speed locknut (12).
- (15) Shut off ENGINE HIGH IDLE (TM 9-2320-279-10).
- (16) Shut off engine (TM 9-2320-279-10).


b. Engine Idle Speed Adjustment.

- (1) Loosen idle speed locknut (1).
- (2) Start engine (TM 9-2320-279-10).

NOTE

Correct engine speed is 600 rpm.


- (3) Turn idle adjusting screw (2) counterclockwise to correct engine speed.
- (4) Tighten idle speed locknut (1).
- (5) Shut off engine (TM 9-2320-279-10).



NOTE

Gasket is not replaced until damaged.

- (6) Install gasket (3) and high speed spring retainer cover (4) with two lockwashers (5) and screws (6).
- (7) Install air hose (7) on high speed spring retainer cover (4).
- (8) Remove turbocharger inlet air shield (8).
- (9) Connect two wires (9) to connectors (10) and solenoids (11) on selector valve (12).



c. Follow-on Maintenance.

- (1) Install air intake ducting (TM 9-2320-279-20).
- (2) Install engine side panels (TM 9-2320-279-10).
- (3) Close engine covers (TM 9-2320-279-20).

END OF TASK

TA357129

Hydraulic System Maintenance Instructions (Cont)

20-7. PRIMARY PUMP HYDRAULIC MOTOR CONTROL VALVE REPAIR (M978).

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

M978

Test Equipment

None

Special Tools

None

Supplies

Solvent, dry cleaning, Item 57, Appendix C
Oil, lubricating, Item 47, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

Primary pump hydraulic motor control valve on clean work surface.

Special Environmental Conditions

None

General Safety Instructions

None

Level of Maintenance


Direct Support

a. Disassembly.

CAUTION


Do not attempt to remove relief valve first. Damage to end cap will occur.

- (1) Remove four screws (1) and end cap (2).
- (2) Remove relief valve assembly (3).
- (3) Remove preformed packing (4), two rings (5), and preformed packing (6) from relief valve assembly (3).
- (4) Remove plug (7) and preformed packing (8) from valve housing (9).



TA357164

Hydraulic System Maintenance Instructions (Cont)




TA357163

- (5) Remove two screws (10) and bracket (11).

CAUTION

Detent balls are spring loaded. Do not pull on detent sleeve when removing spool assembly. Detent balls can be lost if detent sleeve pulled off spool.

- (6) Remove spool assembly (12) from valve housing (9).
- (7) Remove washer (13) and retaining plate (14) from spool assembly (12).
- (8) Remove washer (15) and two seals (16) from valve housing (9).
- (9) Remove detent sleeve (17), two detent balls (18), and spring (19).
- (10) Remove detent adapter (20) and washer (21) from spool assembly (12).



TA357165

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all parts with dry cleaning solvent.
- (2) Thoroughly lubricate relief valve after cleaning.
- (3) Inspect threads for damage. Repair damaged threads.
- (4) Inspect spool and bore of valve housing for cracks and scoring. If valve housing or spool is cracked, or if there are deep scoring marks on spool or in valve housing bore, replace control valve.
- (5) Inspect end cap and retaining plate for bends and breaks. If retaining plate or end cap is bent or broken, replace cap assembly.
- (6) If detent does not work smoothly, if detent balls are lost, or if detent spring is broken, replace cap assembly.

Hydraulic System Maintenance Instructions (Cont)

20-7. PRIMARY PUMP HYDRAULIC MOTOR CONTROL VALVE REPAIR (M978) (CONT).

c. Assembly.

- (1) Install washer (1) and detent adapter (2) on spool assembly (3).
- (2) Install spring (4), two detent balls (5), and detent sleeve (6) on detent adapter (2).




TA357167

NOTE

Lubricate preformed packings, seals, and spool before installing.

- (3) Install seal (7) in valve housing (8).
- (4) Install retaining plate (9) and washer (10) on spool assembly (3). Install spool assembly in valve housing (8).
- (5) Install seal (11) and washer (12).
- (6) Install bracket (13) with two screws (14).

- (7) Install preformed packing (15) on plug (16). Install plug in valve housing (8).
- (8) Install preformed packing (17), two rings (18), and preformed packing (19) on relief valve assembly (20).
- (9) Install relief valve assembly (20).
- (10) Install end cap (21) with four screws (22).



TA357168

d. Follow-on Maintenance. None.

END OF TASK

Hydraulic System Maintenance Instructions (Cont)

20-8. HEAVY DUTY WINCH MANIFOLD REMOVAL/INSTALLATION (M984E1).

This task covers:

- a. Removal
- b. Installation

c. Follow-on Maintenance

INITIAL SETUP

Models

M984E1

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Heavy wheel vehicle repairer

References

None

Equipment Condition

TM or Para *Condition Description*
 TM 9-2320-279-20 Handle removed.

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support


a. Removal.



NOTE

Tag and mark all wires, hoses and lines.


- (1) Loosen three screws (1), remove plugs (2), and seals (3) from solenoids (4).
- (2) Remove hydraulic line (5 and 6).
- (3) Remove four hoses (7).
- (4) Remove hydraulic line (8).
- (5) Remove valve (9).
- (6) Remove three hydraulic lines (10).
- (7) Remove four screws (11) and washers (12).
- (8) Remove manifold valve (13) from tire davit mount (14).



TA476760

Hydraulic System Maintenance Instructions (Cont)

20-8. HEAVY DUTY WINCH MANIFOLD REMOVAL/INSTALLATION (M984E1) (CONT).




TA476761

NOTE

Mark position of all fittings and valves.

- (9) Remove four fittings (15) and preformed packings (16) from manifold valve (13).
- (10) Remove two fittings (17) and preformed packings (18).
- (11) Remove fitting (19) and preformed packing (20).




TA476762

- (12) Remove remaining valve (9) from manifold valve (13).
- (13) Remove preformed packing (21), backup ring (22), and preformed packing (23) from valve (9).
- (14) Repeat step (13) for valve (9) removed in step (5).
- (15) Remove fitting (24) and preformed packing (25).
- (16) Remove elbow (26) and preformed packing (27).
- (17) Remove fitting (28) and preformed packing (29).


Hydraulic System Maintenance Instructions (Cont)

b. Installation.



TA476763

- (1) Install preformed packing (1) and fitting (2) in manifold valve (3).
- (2) Install preformed packing (4) and elbow (5).
- (3) Install preformed packing (6) and fitting (7).
- (4) Install preformed packing (8), backup ring (9), and preformed packing (10) on valve (11).
- (5) Repeat step (4) for other valve (11).
- (6) Install valve (11).




TA476764

- (7) Install preformed packing (12) and fitting (13) in manifold valve (3).
- (8) Install two preformed packings (14) and fittings (15).
- (9) Install four preformed packings (16) and fittings (17).

Hydraulic System Maintenance Instructions (Cont)

20-8. HEAVY DUTY WINCH MANIFOLD REMOVAL/INSTALLATION (M984E1) (CONT).

- (10) Install manifold valve (3) on tire davit mount (18) with four washers (19) and screws (20).
- (11) Install three hydraulic lines (21).
- (12) Install valve (11).
- (13) Install hydraulic line (22).
- (14) Install four hoses (23).
- (15) Install hydraulic lines (24 and 25).
- (16) Install three seals (26) and plugs (27) on solenoids (28).
- (17) Tighten three screws (29).



TA476765


c. *Follow-on Maintenance.* Install handle (TM 9-2320-279-20).

END OF TASK


20-9. HEAVY DUTY WINCH MANIFOLD REPAIR (M984E1).	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
Models M984E1	References None
Test Equipment None	Equipment Condition
Special Tools None	TM or Para Para 20-8
Supplies None	Condition Description Heavy duty winch manifold removed.
Personnel Required MOS 63W, Heavy wheel vehicle repairer	Special Environmental Conditions None
	General Safety Instructions None
	Level of Maintenance General Support

Hydraulic System Maintenance Instructions (Cont)

a. Disassembly.



- (1) Remove four screws (1) and valve assembly (2) from directional valve (3).
- (2) Remove four preformed packings (4) and plate (5).




- (3) Remove eight screws (6), two solenoids (7), and preformed packings (8).
- (4) Remove spool (9) from valve assembly (2).

Hydraulic System Maintenance Instructions (Cont)


20-9. HEAVY DUTY WINCH MANIFOLD REPAIR (M984E1) (CONT)

- (5) Remove four screws (10) and directional valve (3).
- (6) Remove five preformed packings (11) and two preformed packings (12) from manifold valve (13).




TA476768

- (7) Remove screw (14) and seal washer (15).
- (8) Remove four screws (16), end cap (17), and preformed packing (18) from directional valve (3).




TA476769

- (9) Remove four screws (19), end cap (20), and preformed packing (21) from directional valve (3).
- (10) Remove spool (22).
- (11) Remove screw (23), spring cup (24), spring (25), and spring cup (26) from spool (22).




TA476770

Hydraulic System Maintenance Instructions (Cont)




- (12) Remove two plugs (27) and preformed packings (38).
- (13) Remove two valves (29) from manifold valve (13).
- (14) Remove backup ring (30), preformed packing (31), and preformed packing (32) from valve (29).
- (15) Repeat step (14) for other valve (29).




- (16) Remove valve (33) from manifold valve (13).
- (17) Remove preformed packing (34), backup ring (35), backup ring (36), preformed packing (37), and preformed packing (38) from valve (33).
- (18) Remove valve (39) from manifold valve (13).
- (19) Remove backup ring (40), preformed packing (41), backup ring (40), backup ring (42), preformed packing (43), backup ring (42), backup ring (44), preformed packing (45), backup ring (44), and preformed packing (46) from valve (39).

20-9. HEAVY DUTY WINCH MANIFOLD REPAIR (M984E1) (CONT).



TA476773


- (20) Remove nut (47), washer (48), and solenoid (49) from valve (50).
- (21) Remove valve (50) from manifold valve (13).
- (22) Remove backup ring (51), preformed packing (52), and preformed packing (53) from valve (50).
- (23) Remove cap (54) and valve (55) from manifold valve (13).
- (24) Remove backup ring (56), preformed packing (57), backup ring (56), and preformed packing (58) from valve (55).



TA476774


- (25) Remove plug (59) and preformed packing (60) from manifold valve (13).
- (26) Remove plug (61) and preformed packing (62).
- (27) Remove two plugs (63) and preformed packings (64).
- (28) Remove plug (65) and preformed packing (66).

Hydraulic System Maintenance Instructions (Cont)



TA476775

- (29) Remove two plugs (67) and preformed packings (68) from manifold valve (13).
- (30) Remove two plugs (69) and preformed packings (70) from manifold valve (13).



TA476776

- (31) Remove two plugs (71), preformed packings (72), springs (73), and balls (74) from manifold valve (13).
- (32) Remove two plugs (75) and preformed packings (76).
- (33) Remove plug (77) and preformed packing (78).

20-9. HEAVY DUTY WINCH MANIFOLD REPAIR (M984E1) (CONT).


b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.
- (2) Inspect each part for damage.
- (3) Replace damaged parts.
- (4) Replace small springs if free length is less than .375 in. (9.53 mm) or broken.
- (5) Replace large springs if free length is less than 1.250 in (31.75 mm).


c. *Assembly.*



TA476777


- (1) Install preformed packing (1) and plug (2).
- (2) Install two preformed packings (3) and plugs (4).
- (3) Install two balls (5), springs (6), preformed packings (7), and plugs (8) in manifold valve (9).

Hydraulic System Maintenance Instructions (Cont)



TA476778

- (4) Install two preformed packings (10) and plugs (11) in manifold valve (9).
- (5) Install two preformed packings (12) and plugs (13).




TA476779

- (6) Install preformed packing (14) and plug (15).
- (7) Install two preformed packings (16) and plugs (17).
- (8) Install preformed packing (18) and plug (19).
- (9) Install preformed packing (20) and plug (21) in manifold valve (9).


Hydraulic System Maintenance Instructions (Cont)

20-9. HEAVY DUTY WINCH MANIFOLD REPAIR (M984E1) (CONT).



TA476780


- (10) Install preformed packing (22), preformed packing (23), and backup ring (24) on valve (25).
- (11) Install valve (25) in manifold valve (9).
- (12) Install solenoid (26), washer (27), and nut (28) onto valve (25).
- (13) Install preformed packing (29), backup ring (30), preformed packing (31), and backup ring (30) on valve (32).
- (14) Install valve (32) and cap (33).



TA476781

- (15) Install preformed packing (34), backup ring (35), preformed packing (36), backup ring (35), backup ring (37), preformed packing (38), backup ring (37), backup ring (39), preformed packing (40), backup ring (39) on valve (41).
- (16) Install valve (41) in manifold valve (9).
- (17) Install preformed packing (42), preformed packing (43), backup ring (44), backup ring (45), and preformed packing (46) on valve (47).
- (18) Install valve (47) in manifold valve (9).


Hydraulic System Maintenance Instructions (Cont)



TA476782


- (19) Install preformed packing (48), preformed packing (49), and backup ring (50) on valve (51).
- (20) Repeat step (19) for other valve (51).
- (21) Install two valves (51) in manifold valve (9).
- (22) Install two preformed packings (52) and plugs (53).

- (23) Install spring cup (54), spring (55), spring cup (56), and screw (57) in spool (58).
- (24) Install spool (58) in directional valve (59).
- (25) Install preformed packing (60), end cap (61) with four screws (62).



TA476783


- (26) Install preformed packing (63) and end cap (64) with four screws (65) to directional valve (59).
- (27) Install seal washer (66) and screw (67).




TA476784

Hydraulic System Maintenance Instructions (Cont)

20-9. HEAVY DUTY WINCH MANIFOLD REPAIR (M984E1) (CONT.)




- (28) Install two preformed packings (68) and five preformed packings (69) in manifold valve (9).
- (29) Install directional valve (59) with four screws (70).



- (30) Install spool (71) in valve assembly (72).
- (31) Install two preformed packings (73) and solenoids (74) with eight screws (75).

Hydraulic System Maintenance Instructions (Cont)

- (32) Install plate (76) and four preformed packings (77) on directional valve (59).
- (33) Install valve assembly (72) with four screws (78).



TA476787

d. Follow-on Maintenance. None.


END OF TASK

20-10. RETRIEVER CONTROL VALVE REPAIR (M984E1).		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models	References	
M984E1	None	
Test Equipment	Equipment Condition	
None	TM or Para	Condition Description
Special Tools		Retriever control valve on clean work surface
None		
Supplies	Special Environmental Conditions	
Oil, lubricating, Item 46, Appendix C	None	
Solvent, dry cleaning, Item 57, Appendix C	General Safety Instructions	
Personnel Required	None	
MOS 63W, Wheel vehicle repairer	Level of Maintenance	
	Direct Support	

Hydraulic System Maintenance Instructions (Cont)

20-10. RETRIEVER CONTROL VALVE REPAIR (M984E1) (CONT).

a. Disassembly.




NOTE

Tag and mark valve assemblies and end covers.


- (1) Remove three nuts (1), lockwashers (2), and studs (3).
- (2) Remove three nuts (4) and lockwashers (5) from studs (3).
- (3) Separate two end covers (6 and 7) and three valve assemblies (8).
- (4) Remove 12 shims (9), four preformed packings (10), four preformed packings (11), and eight preformed packings (12).

NOTE

- Matchmark all relief valves before removal. All six relief valves are removed the same.
 - All three valve assemblies are disassembled the same.
- (5) Remove two relief valves (13) from valve assembly (11).
 - (6) Remove preformed packing (14), backup ring (15), and preformed packing (16) from relief valve (13).




Hydraulic System Maintenance Instructions (Cont)



TA476793

- (7) Remove two screws (17), lockwashers (18), and end cap (19).
- (8) Remove screw (20), lockwasher (21), retainer (22), two holders (23), and spring (24).
- (9) Remove valve spool (25) and two preformed packings (26).



TA476794

- (10) Remove plug (27) and preformed packing (28).
- (11) Remove spring sleeve (29) and two springs (30 and 31).

Hydraulic System Maintenance Instructions (Cont)

20-10. RETRIEVER CONTROL VALVE REPAIR (M984E1) (CONT).

- (12) Remove poppet (32), ball (33), and two preformed packings (34 and 35).
- (13) Remove valve (36) and three preformed packings (37, 38, and 39).

b. *Cleaning/Inspection.*

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Replace all shims.
- (2) Clean all metal parts with dry cleaning solvent.
- (3) Inspect each part for damage.
- (4) Inspect valve body bores for grooves or other damage.
- (5) Inspect valve spools for grooves, cracks, or other damage.
- (6) Inspect springs for breaks.
- (7) Replace damaged or broken parts.


- (8) Measure springs (1, 2, and 3). Replace spring (1) if it is equal to or less than 2.08 in. (52.83 N·m). Replace spring (2) if it is equal to or less than 2.22 in. (56.39 N·m). Replace spring (3) if it is equal to or less than 2.40 in. (6.00 mm).
- (9) Coat all metal parts with a thin film of lubricating oil.

c. *Installation.*


- (1) Install three preformed packings (1, 2, and 3) and shuttle valve (4).
- (2) Install two preformed packings (5 and 6), ball (7), and poppet (8).



TA476795




TA476866




TA476796

Hydraulic System Maintenance Instructions (Cont)



TA476789

- (3) Install two springs (9 and 10) in spring sleeve (11).
- (4) Install spring sleeve (11) in valve body (12).
- (5) Install preformed packing (13) and plug (14).



TA476797

- (6) Install two preformed packings (15 and 16) in valve body (12).
- (7) Install valve spool (17).
- (8) Install spring (18) with two holders (19), retainer (20), lockwasher (21), and screw (22) on valve spool (17).
- (9) Install end cap (23), two lockwashers (24), and screws (25).

Hydraulic System Maintenance Instructions (Cont)


20-10. RETRIEVER CONTROL VALVE REPAIR (M984E1) (CONT).

CAUTION

Relief valves are preset to specific pressures. Correct relief valve must be installed in each valve body or equipment may be damaged when operating retriever controls.

NOTE


- Lift cylinder relief valves are set to 400 psi (2758 kPa) and 2500 psi (17237 kPa).
- Tow cylinder relief valves are set to 300 psi (2068.5 kPa).
- Relief valves are installed the same way in all three valve bodies.



TA476790

- (10) Install Preformed packing (26), backup ring (27), and preformed packing (28) on relief valve (29).
 (11) Install relief valve (29) in valve body (12).

- (12) Install lockwashers (30) and nuts (31) on three studs (32).
 (13) Install three studs (32) through end cover (33).
 (14) Install three shims (34) on studs (32).
 (15) Install two preformed packings (35), preformed packing (36), and preformed packing (37) on valve body (12).
 (16) Assemble valve body (12) and end cover (33).
 (17) Repeat steps (14) through (16) for other two valve bodies (12) and end cover (38).
 (18) Install lockwashers (30) and nuts (31) on studs (32).



TA476791

d. Follow-on Maintenance. None.

END OF TASK

CHAPTER 21 ARCTIC HEATER KIT MAINTENANCE

Contents	Para	Page
General.....	21-1	21-1
Arctic Kit Coolant Pump Repair.....	21-2	21-1

Section I. INTRODUCTION

21-1. GENERAL This chapter contains maintenance instructions for the repair of the arctic heater kit at the direct support maintenance level.

Section II. ARCTIC HEATER KIT Arctic Heater Kit Repair instructions


21-2. ARCTIC KIT COOLANT PUMP REPAIR.							
This task covers:							
a. Disassembly	c. Assembly						
b. Cleaning/Inspection	d. Follow-on Maintenance						
INITIAL SETUP							
<i>Models</i>	<i>References</i>						
All	None						
<i>Test Equipment</i>	<i>Equipment Condition</i>						
None	<table border="0" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; font-size: small;"><i>TM or Para</i></th> <th style="text-align: left; font-size: small;"><i>Condition</i></th> <th style="text-align: left; font-size: small;"><i>Description</i></th> </tr> </thead> <tbody> <tr> <td style="font-size: small;">TM 9-2320-279-20</td> <td style="font-size: small;">Arctic kit coolant pump removed.</td> <td></td> </tr> </tbody> </table>	<i>TM or Para</i>	<i>Condition</i>	<i>Description</i>	TM 9-2320-279-20	Arctic kit coolant pump removed.	
<i>TM or Para</i>	<i>Condition</i>	<i>Description</i>					
TM 9-2320-279-20	Arctic kit coolant pump removed.						
<i>Special Tools</i>	<i>Special Environmental Conditions</i>						
Puller Tool 24702	None						
<i>Supplies</i>	<i>General Safety Instructions</i>						
Solvent, drycleaning, Item 57, Appendix C	None						
Paper, abrasive, Item 5, Appendix C							
Oil, lubricating, Item 46, Appendix C							
<i>Personnel Required</i>	<i>Level of Maintenance</i>						
MOS 63W, Wheel vehicle repairer	Direct Support						

Arctic Heater Kit Maintenance Instructions (Cont)


21-2. ARCTIC KIT COOLANT PUMP REPAIR (CONT).

a. Disassembly.


- (1) Remove four screws (1), lockwashers (2), two brush shields (3), brush caps (4), and brush and spring assemblies (5) from brush head (6).
- (2) Remove two screws (7), lockwashers (8), and radio noise filter (9) from brush head (6) and stator (10).




- (3) Matchmark pump cover (11), body (12), rear head cover (13), stator (10), and brush head (6).



Arctic Heater Kit Maintenance Instructions (Cont)



- (4) Remove four screws (14), lockwashers (15), two flanges (16), and gaskets (17) from pump cover (11) and body (12).



- (5) Remove eight screws (18), pump cover (11), and gasket (19) from pump body (12).


NOTE

Two nuts removed in step (6) hold motor together. Keep motor as an assembly.

- (6) Remove two nuts (20) and lockwashers (21) from pump body (12).

Arctic Heater Kit Maintenance Instructions (Cont)

21-2. ARCTIC KIT COOLANT PUMP REPAIR (CONT)



- (7) Install puller tool on pump body (12) using four screws (18) removed from pump body (12) in step (5).

CAUTION

Motor will come off pump body when armature shaft is pressed out of impeller.

NOTE


Two nuts removed in step (6) hold motor together. Keep motor as an assembly.

- (8) Tighten puller screws on shaft of armature (22) and press shaft out of impeller (23).
- (9) Remove four screws (18) and puller tool from pump body (12).
- (10) Remove impeller (23) from pump body (12).

NOTE


Note position of components within seal assembly to ensure proper assembly.

- (11) Remove four piece seal assembly (24) from pump body (12).
- (12) Remove two drain plugs (25) from pump body (12).



Arctic Heater Kit Maintenance Instructions (Cont)


- (13) Remove slinger (26) and rear head cover (13) from shaft of armature (22).
- (14) Remove stator (10) from armature (22) and brush head (6).




CAUTION

Do not touch commutator directly with skin. Sweat and body oils will damage commutator.

- (15) Remove armature (22), thrust washer (27), and spring washer (28) from brush head (6).
- (16) Remove two case studs (29) from brush head (6).



- (17) Remove two set screws (30) and brush tubes (31) from brush head (6).



Arctic Heater Kit Maintenance Instructions (Cont)

21-2. ARCTIC KIT COOLANT PUMP REPAIR (CONT).

CAUTION

Do not touch commutator directly with skin.
Sweat and body oils will damage commutator.

- (18) Remove two bearings (32) from shaft of armature (22).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

CAUTION

Do not touch commutator directly with skin. Sweat and body oils will damage commutator.


- (1) Clean all metal parts in drycleaning solvent except armature and stator.
- (2) Inspect commutator contact surface for rough surface, pits, scoring, burns, hard carbon, oil coat, severe wear, and out of round. Commutator may not be more than 0.002 in. (.051 mm) out of round. Commutator diameter difference between nonwear surface and brush wear surface must be less than 0.187 in. (4.75 mm).

Arctic Heater Kit Maintenance Instructions (Cont)

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (a) Cut commutator of armature (1) as required on lathe. When cutting commutator, cut no more than 0.005 in. (0.13 mm) at a time to remove scoring, pits, burrs, or to return commutator to round. Then make final cut of 0.002 in. (0.051 mm). Undercut commutator with a 0.025 in. (0.63 mm) or less slot width. Blow off all loose copper and mica with compressed air.
- (b) Polish commutator of armature (1) with abrasive paper. Blow off all loose debris with compressed air.



- (3) Inspect brush and spring assemblies for brush chips, excessive brush wear, spring distortion, and broken or frayed pigtails. If brush has more than minor chips in it or is less than 0.300 in. (7.620 mm) in length, replace brush spring assembly. If spring is distorted or has lost its resilience, replace brush spring assembly. If pigtail is frayed or broken, replace brush spring assembly.
- (4) Replace unserviceable parts.


21-2. ARCTIC KIT COOLANT PUMP REPAIR (CONT).

c. Assembly


CAUTION

Do not touch armature commutator directly with skin. Sweat and body oils will damage commutator.

- (1) Install two bearings (1) on armature (2).



- (2) Install two brush tubes (3) in brush head (4) with set screws (5).




- (3) Install two case studs (6) in brush head (4).

CAUTION



Do not touch commutator directly with skin. Sweat and body oils will damage commutator.

- (4) Install thrust washer (7) and spring washer (8) on commutator end of armature (2).
- (5) Install armature (2) in brush head (4).



Arctic Heater Kit Maintenance Instructions (Cont)

- (6) Install stator (9) on brush head (4).
- (7) Install rear head cover (10) on armature (2) and stator (9).
- (8) Install slinger (11) on shaft of armature (2).
- (9) Install radio noise filter (12) on brush head (4) and stator (9) with two screws (13) and lockwashers (14).



- (10) Install two drain plugs (15) in pump body (16).
- (11) Install seal assembly seat (17) in recess of pump body (16).
- (12) Install case studs (9) through holes in pump body (16) and install two lockwashers (18) and two nuts (19).

CAUTION

Be sure all components of seal fit together correctly.

- (13) Lubricate shaft of armature (2) with lubricating oil and install remaining components of seal assembly (20) on shaft of armature (2).



Arctic Heater Kit Maintenance Instructions (Cont)

21-2. ARCTIC KIT COOLANT PUMP REPAIR (CONT).

CAUTION

Only use press to install armature shaft into impeller, do not pound on end of motor.

- (14) Place impeller (21) on flat surface with vanes down.
- (15) Press shaft of armature (2) into bore of impeller (21) until surface of pump body (16) is flush with impeller surface (pump body surface is pressed against flat surface without any gaps between pump body and flat surface).




- (16) Install gasket (22) and pump cover (23) on pump body (16) with eight screws (24).
- (17) Install two flanges (25) and gaskets (26) on pump cover (23) and pump body (16) with four screws (27) and lockwashers (28).

Arctic Heater Kit Maintenance Instructions (Cont)**NOTE**

New brushes have a six degree angle on the brush face. Brush should always be installed so that the angle is open away from the pump end of the motor.

- (18) Install two brush and spring assemblies (29), brush caps (30), and brush shields (31) in brush head (4) with four screws (32) and lockwashers (33).



- d. **Follow-on Maintenance.** Install arctic kit coolant pump (TM 9-2320-279-20).

END OF TASK

CHAPTER 22 M978 TANKER MAINTENANCE PROCEDURES

Contents	Para	Page
General	22-1	22-1
General Maintenance Instructions	22-2	22-2
Primary Pump Hydraulic Motor Repair	22-3	22-10
Primary Pump Repair	22-4	22-17
AUXILIARY PUMP Repair	22-5	22-25
Flowmeter Register Removal/Installation	22-6	22-31
Flowmeter Removal/Installation	22-7	22-33
Flowmeter Repair	22-8	22-35
Air Eliminator Repair	22-9	22-44
V1 Emergency Valve Repair	22-10	22-47
V2 Bottom Load Adapter Repair	22-11	22-53
V3 Suction Line Valve and N17 Gravity Valve Repair	22-12	22-55
V4 Bypass/Pressure Relief Valve Repair	22-13	22-58
V5 Air Actuated Flow Valve and Actuator Repair	22-14	22-68
V6 FUEL/DEFUEL Valve Repair	22-15	22-76
V7/V8 Reel Valve Repair	22-16	22-79
V10 Bottom Load Valve Repair	22-17	22-82
V11 Flow Regulating Valve Repair	22-18	22-87
V12 Bottom Load Precheck Valve and Sampling Probe Valve Repair	22-19	22-90
V13 Vent Valve Repair	22-20	22-94
V14 Pilot Valve Repair	22-21	22-97
V18 Bulk Delivery Valve Repair	22-22	22-99
V19 Jet Level Sensor Repair	22-23	22-102
Fuel Service Nozzle Repair	22-24	22-105
Manhole Cover Repair	22-25	22-108

Section I. INTRODUCTION

22-1. GENERAL. This chapter contains maintenance instructions for removing, repairing, and installing the M978 tanker fuel-handling components at the direct support and general support maintenance levels. Major components covered in this chapter include:

- pump, pump motor, and auxiliary pump
- flowmeter
- air eliminator
- valves
- fuel service nozzle

The subassemblies and parts which must be removed before the fuel-handling components can be removed or repaired are referenced to other paragraphs or chapters of this manual or TM 9-2320-279-20.

Section II. SERVICE AND INSPECTION

M978 Tanker Maintenance Procedures Instructions

22.2. GENERAL MAINTENANCE INSTRUCTIONS.

- a. Refer to Figures 22-1 through 22-5 to identify M978 tanker components before beginning work.
- b. Follow these maintenance practices when working on the M978 tanker and tanker components:

WARNING

- To prevent explosion and fire, no smoking, flame, sparks and glowing or hot objects are allowed within 60 ft (16 m) of vehicle.
 - Eye protection is required during all grinding operations.
- (1) Tag and mark shims, connectors, wires, tubes, conduit, hoses, and pipes before disconnecting. Matchmark position of fittings, components and subassemblies before removal. Identify similar parts to ensure correct assembly and installation.
 - (2) Use suitable container to catch fuel when removing hoses, tubes, fittings, pipes, and components.
 - (3) Drain air system before removing air-actuated components and subassemblies.

CAUTION

Do not use tape to close off fuel openings. Sticky surface of tape will mix with and contaminate fuel.

- (4) When a component is removed from vehicle, cover open ends of pipes, valves, and other components. Cover open ends with caps or plugs to prevent contaminants from entering fuel circuit.
- (5) Handle and store removed components carefully.
- (6) To ease assembly, lay out parts in order they are removed during disassembly.
- (7) Plumbing tags are attached with wire, screws, or rivets. Do not remove or replace plumbing tags unless missing or damaged.
- (8) Inspect parts as removed for breaks, dents, cracks, surface defects, or other damage. Turn in defective parts. Set aside good parts for later use.
- (9) When unpacking items, remove all packing material, barrier paper, tape, plastic bags, and protective caps.
- (10) Replace all gaskets, packings, and seals removed during repair work. Replace all lockwire, lockwashers, and cotter pins at time of reassembly.
- (11) Remove burrs from gear teeth with fine-cut file.
- (12) Remove residue and stain from bearing races with crocus cloth.

WARNING

Welding and brazing operations produce heat, toxic fumes, radiation, metal slag, and carbon particles. Welding and brazing goggles, gloves, apron or jacket, and welders boots are required to avoid injury or death.

- (13) Welding and brazing processes may be used to repair cracks in external steel parts, such as brackets, panels, and light framework. Because of time required and chance of subsequent failure, such repairs should be attempted only when replacement parts are unavailable. Welding and brazing of castings and running parts or parts under great stress will be done only in emergencies.
- (24) Replace broken, worn, or burned electrical wiring.
- (25) Replace broken, frayed, crimped, or soft flexible hoses. Replace stripped or damaged fittings. Replace entire connected flexible hose if fittings are damaged. Hose clamps should not crimp hoses.

M978 Tanker Maintenance Procedures Instructions (Cont)

- (16) Replace any screw, nut, or fitting with damaged threads. Inspect tapped holes for thread damage. If cross-threading is evident, retap hole for next oversize screw or stud. If retapping will weaken part, replace part.
 - (17) Reshape elongated mounting holes to round and drill to receive bushing with required inner diameter. Stake bushing in place with center punch.
 - (18) When installing studs, use proper driver. Before driving stud, inspect hole for chips. Blow out foreign matter, coat threads with a film of antiseize compound (Item 17, Appendix C), and start stud by hand.
 - (19) Remove protective grease coatings from new parts before installation.
 - (20) Lubricate all preformed packings with thin coat of oil (Item 47, Appendix C) before installation.
 - (21) To replace a preformed packing, stretch packing and place into position. Rotate component on flat surface and uniformly press packing into position.
 - (22) Remove all traces of old gasket and sealant before installing new gasket. During installation, coat both sides of gasket with adhesive-sealant (Item 6, Appendix C).
 - (23) When replacing coupling gaskets, lubricate with a thin coat of grease (Item 34, Appendix C) before installation.
 - (24) Coat oil seals evenly with oil (Item 47, Appendix C) or grease (Item 36, Appendix C) before installing. Install oil seals applying even force to outer edge of seal. If oil seals are to be installed over keys or splined shafts, use guide to prevent sharp edge of keyway or splines from cutting seal. Construct guides of very thin gage sheet metal and shape to required diameter. Make sure guide edges are not sharp and are bent slightly inward so they do not cut seal.
 - (25) Lubricate bearings before assembly with lubricant used in the related housing or container to provide first run-in protection until lubricant from the system can reach bearings.
 - (26) When mounting bearings on shafts, always apply force to inner races. When mounting bearings in housing, always apply force to outer race.
 - (27) Use suitable lifting device, jack, or other aid when lifting heavy components.
- c. Follow these cleaning instructions when working on tanker components:

WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
 - Compressed air used for cleaning and drying purposes will be reduced to 30 psi (207 kPa) and used only with chip guarding and personal protection equipment to avoid injury.
 - Eye protection is required during all grinding operations to avoid serious injury.
- (1) Soak parts in solvent (Item 57, Appendix C), and wash away deposits by slushing or spraying. When necessary, brush with oval paint brush moistened in solvent. Use a jet of dry compressed air to dry parts, except bearings, after cleaning. Bearings must drip and air dry.
 - (2) Do not use wire brushes, abrasive wheels, or compounds to clean parts, unless specifically approved in the detailed instructions.
 - (3) Do not clean rubber parts in dry cleaning solvent. Wipe clean with a clean, dry, lint-free cloth.
 - (4) Electrical parts, such as coils, junction blocks, and switches, should not be soaked or sprayed with cleaning solutions. Clean these parts with clean lint-free cloth moistened with dry cleaning solvent.

M978 Tanker Maintenance Procedures Instructions (Cont)

22-2. GENERAL MAINTENANCE INSTRUCTIONS (CONT).

- d. Follow these inspection instructions when working on the tanker and tanker components:
- (1) Inspect all surfaces in contact with gaskets, coupling gaskets, packings, or seals for nicks, burrs, scratches or other damage, which might damage the new seal upon reassembly. If any defect is found, remove before assembly.

NOTE

Defects which may cause bearing binding or misalignment are cause for rejection.
Nicks or gouges outside race load area are not cause for rejection.

- (2) Inspect bearings for rusted or pitted bearings, races, or separators. Inspect bearings and races for abrasion and serious discoloration.
- (3) Cuts or grooves parallel to bearing or roller rotation and fatigue pits are causes for bearing rejection.
- (4) Guidelines for rejection of gears by visual inspection are not listed because of varying conditions for gear application. The following descriptions of wear conditions may help determine when parts are defective.
 - (a) Initial pitting may occur when gears are first started in service. When pitting reduces local high spots so there is still enough contact area to carry load without further impairment, initial pitting is not serious.
 - (b) Destructive pitting continues to progress after initial pitting. If there is not enough contact area remaining to carry load, rapid destruction may occur from continued operation.
 - (c) Abrasive wear is surface damage caused by fine particles carried in lubricant or particles embedded in tooth surfaces. Particles can be metal, sand, or scale in the oil.
- (5) Inspect all hose surfaces for damaged or deteriorated material. Check for breaks caused by sharp kinks or contact with other parts of vehicle. Inspect fitting threads for damage. Replace defective parts. After assembly and during initial vehicle operation period, check for leaks.
- (6) Inspect wiring harnesses for chafed or burned insulation. Inspect all terminal connectors for loose connections and broken parts.
- (7) Visually inspect all castings and weldments for cracks.

M978 Tanker Maintenance Procedures Instructions (Cont)




Figure 22-1. Tanker External Components.

22-2. GENERAL MAINTENANCE INSTRUCTIONS (CONT).





Figure 22-2. Tanker Filter and Manual Dispensing Components.


M978 Tanker Maintenance Procedures Instructions (Cont)



TA190842

Figure 22-3. Tanker Dispensing Components-Valves.


22-2. GENERAL MAINTENANCE INSTRUCTIONS (CONT).



TA190843

Figure 22-4. Tanker Loading and Unloading Components.

M978 Tanker Maintenance Procedures Instructions (Cont)




TA190844

Figure 22-5. Tanker Gages, Air, and Electrical Components.

Section III. PUMP, PUMP MOTOR, AND AUXILIARY PUMP MAINTENANCE

22-3. PRIMARY PUMP HYDRAULIC MOTOR REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i>	<i>References</i>	
M978	None	
<i>Test Equipment</i>	<i>Equipment Condition</i>	
None	<i>TM or Para</i>	<i>Condition Description</i>
<i>Special Tools</i>		Primary pump hydraulic motor on clean work surface.
None		
<i>Supplies</i>	<i>Special Environmental Conditions</i>	
Grease, automotive and artillery, Item 34, Appendix C	None	
Oil, lubricating, Item 46, Appendix C	<i>General Safety Instructions</i>	
Solvent, dry cleaning, Item 57, Appendix C	No smoking, flame, sparks, and hot or glowing objects with 50 ft (15 m) of vehicle.	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheel vehicle repairer	General Support	

a. Disassembly.




NOTE

Matchmark cover, gear housing, and adapter.


(1) Remove four screws (1) from cover (2).

M978 Tanker Maintenance Instructions (Cont)

- (2) Remove cover (2), preformed packing (3), and wear plate (4).
- (3) Mark positions and remove long shaft (5) and short shaft (6).
- (4) Remove gear housing (7), wear plate (8), and preformed packing (9) from adapter (10).



TA190667




TA190668

- (5) Remove two packing retainers (11), four fiber strips (12), and two preformed packings (13) from cover (2).
- (6) Remove two roller bearings (14).


M978 Tanker Maintenance Procedures Instructions (Cont)

22-3. PRIMARY PUMP HYDRAULIC MOTOR REPAIR (CONT).


- (7) Remove two retaining rings (15) and press gear (16) from long shaft (5). Remove key (17).
- (8) Remove two retaining rings (18) and press gear (19) from short shaft (6).



- (9) Remove two packing retainers (20) and preformed packings (21) from adapter (10).
- (10) Remove two plugs (22) and balls (23).
- (11) Remove two roller bearings (24).
- (12) Remove fiber washer (25) and bushing (26).



- (13) Remove preformed packing (27) and backup ring (28) from bushing (26).




M978 Tanker Maintenance Procedures Instructions (Cont)

WARNING

Wear safety glasses while removing retaining rings to protect eyes from possible injury or blindness.

(14) Remove retaining ring (29) and seal (30).

b. *Cleaning/Inspection.*




WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.


(1) Clean all parts in dry cleaning solvent. Dry all parts, except bearings, with compressed air. Bearings must be allowed to drip dry. Lubricate bearings with oil when dry.

(2) Inspect wear plate (1). Replace wear plate if wear path (2) is present in area of relief pocket (3) or if plate is scored or excessively worn below 0.112 in. (2.844 mm).




(3) Inspect adapter and cover for visible damage. Remove nicks and burrs.

(4) Inspect shafts (4 and 5) at bearing points for rough surfaces and damage. Replace if damaged.




(5) Inspect edge of gear teeth and gear face (6) for scoring or chipped teeth. Replace if damaged.

(6) Measure thickness of gears across gear faces (6). Record measurement.



22-3. PRIMARY PUMP HYDRAULIC MOTOR REPAIR (CONT).

- (7) Measure thickness of gear housing (7) and record measurement.
- (8) Compare gear housing measurement and gear thickness measurement. If gear housing measurement is 0.0035 in. (0.088 mm) greater than gear thickness measurement, replace both gears.
- (9) Measure distance across gear boxes of housing (7) along dowel pin center line. Replace housing (7) if measurement is greater than 3.259 in. (82.77 mm).




c. Assembly.


WARNING

Wear safety glasses while installing retaining rings to protect eyes from possible injury or blindness.


- (1) Lubricate seal (1) with oil and install seal and retaining ring (2) in adapter (3).




- (2) Lubricate backup ring (4) with grease and install backup ring and preformed packing (5) on bushing (6).




- (3) Lubricate bushing (6) with grease and install fiber washer (7) and two roller bearings (8).
- (4) Install two balls (9) and plugs (10).
- (5) Lubricate two preformed packings (11) with grease and install preformed packings and packing retainers (12).



M978 Tanker Maintenance Procedures Instructions (Cont)




- (6) Install key (13). Lubricate gear (14) with grease and install gear and two retaining rings (15) on long shaft (16).
- (7) Lubricate gear (17) with grease and install gear and two retaining rings (18) on short shaft (19).



- (8) Lubricate two roller bearings (20) with grease and install bearings in cover (21).
- (9) Lubricate two preformed packings (22) with grease and install preformed packings, four fiber strips (23), and two packing retainers (24).

22-3. PRIMARY PUMP HYDRAULIC MOTOR REPAIR (CONT).



(10) Lubricate preformed packing (25) with grease and install on adapter (3).

NOTE


Wear plates must be installed with relief holes toward gears and 180° opposite each other for proper motor operation.

- (11) Install wear plate (26) and gear housing (27) on adapter (3).
- (12) Lubricate long shaft (16) and short shaft (19) with grease and install shafts as marked.
- (13) Install wear plate (28).
- (14) Lubricate preformed packing (29) with grease and install packing in cover (21).
- (15) Position cover (21) on gear housing (27).

(16) Install four screws (30) in cover (21).

d. Follow-on Maintenance. None.

END OF TASK



M978 Tanker Maintenance Procedures Instructions (Cont)

22-4. PRIMARY PUMP REPAIR.	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M978	<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer
<i>Test Equipment</i> None	<i>References</i> None
<i>Special Tools</i> None	<i>Equipment Condition</i> TM or Para <i>Condition Description</i> TM 9-2320-279-20 Primary pump removed and on clean work surface.
<i>Supplies</i> Oil, lubricating, Item 46, Appendix C Solvent, drycleaning, Item 57, Appendix C Adhesive-sealant, silicone, Item 6, Appendix C Tags, identification, Item 60, Appendix C Grease, general purpose, lithium base, Item 36, Appendix C Stock, bar, metal, Item 59, Appendix C (2 required)	<i>Special Environmental Conditions</i> None <i>General Safety Instructions</i> No smoking, flame, sparks, and hot or glowing objects within 50 ft (15 m) of vehicle. <i>Level of Maintenance</i> General Support

a. Disassembly.

NOTE


Mark position of support flange before removal.

- (1) Remove four nuts (1), lockwashers (2), screws (3), and support flange (4) from intermediate housing (5).

NOTE

There are two models of primary pump. Model A does not include discharge elbow and suction flange. Model B is supplied with discharge elbow and suction flange installed. Skip steps (1.1) and (1.2) and continue to step (2) if repairing Model A pump. Do steps (1.1) and (1.2) if repairing Model B pump.


- (1.1) Remove four nuts (5.1), discharge elbow (5.2), and gasket (5.3).
- (1.2) Remove four nuts (5.4), suction flange (5.5), and gasket (5.6).




M978 Tankor Maintenance Procedures Instructions (Cont)

22-4. PRIMARY PUMP REPAIR (CONT).


- (2) Remove four screws (6) lockwashers (7) washers (8), and two coupling covers (9) from intermediate housing (5).
- (3) Remove two pipe plugs (10) from intermediate housing (5).



- (4) Remove eight nuts (11) from studs (12).
- (5) Matchmark and remove intermediate housing (5) from volute casing (13).
- (6) Remove gasket (14).




- (7) Place steel bar through coupling half (15). Place other bar in between impeller vanes (16) as deep as possible.
- (8) Hold coupling half (15) to keep it from turning and strike end of steel bar between impeller vanes (16) to turn impeller (17) counterclockwise.
- (9) When impeller (17) loosens, remove steel bar from between impeller vanes (16).




M978 Tanker Maintenance Procedures Instructions (Cont)


- (10) Hold coupling half (15) to keep from turning and remove impeller (17) and shims (18) from intermediate housing (5). Record number and thickness of shims.
- (11) Remove steel bar from coupling half (15).



- (12) Remove spring centering washer (19) from impeller shaft (20).
- (13) Remove spring (21).
- (14) Remove shaft seal (22) and carbon seal (23).




- (15) Remove seal plate (24) from intermediate housing (5).
- (16) Remove stationary seal (25) from seal plate (24).
- (17) Remove preformed packing (26) from stationary seal (25).



WARNING

Wear safety glasses while removing retaining rings to protect eyes from possible injury or blindness.

- (18) Remove retaining ring (27) from intermediate housing (5).
- (19) Loosen setscrew (28) in coupling half (15).
- (20) Remove coupling half (15) and key (29) from impeller shaft (20).





M978 Tanker Maintenance Procedure Instructions (Cont)

22-4. PRIMARY PUMP REPAIR (CONT).


WARNING

Wear safety glasses while removing retaining rings to protect eyes from injury or blindness.


- (21) Remove retaining ring (30) from intermediate housing (6).
- (22) Remove shims (31). Record number and thickness of shims.
- (23) Remove bearing retainer (32).
- (24) Remove preformed packing (33) from bearing retainer (32).
- (25) Remove oil seal (34) from bearing retainer (32).
- (26) Remove impeller shaft (20) from intermediate housing (5).



- (27) Remove two bearings (35) from impeller shaft (20).




- (28) Remove bearing retainer (36) from impeller side of intermediate housing (6).
- (29) Remove preformed packing (37) from bearing retainer (36).
- (30) Remove oil seal (38) from bearing retainer (36).



M978 Tanker Maintenance Procedures Instructions (Cont)

- (31) Remove eight studs (39) from volute casing (13).
- (32) Remove wear ring (40).
- (33) Remove pipe plug (41).



b. Cleaning/Inspection.


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in drycleaning solvent.
- (2) Inspect seal assembly and shaft sleeve for nicks, cuts, and other visible damage.
- (3) Inspect impeller vanes, seal plate, intermediate housing, coupling halves, and inside of volute casing for pitting, scratches, burrs, nicks, cracks, and other visible damage.
- (4) Inspect bearings for pitting, cracks, scoring, and other visible damage.
- (5) Inspect impeller shaft, bearing retainers, shims, and machined surfaces for pitting, cracks, nicks, burrs, grooves, and other visible damage.
- (5.1) Inspect impeller shaft sleeve for grooves, nicks, pitting and other damage. Replace if necessary.
- (6) Measure inside diameter of wear ring and outside diameter of impeller where they mate. Difference should be 0.010-in. (0.254 mm), or less.
- (7) Inspect coupling halves for nicks, cracks, and other visible damage to metal and rubber parts.
- (8) Inspect seal spring for kinks, cracks, and other visible damage.
- (9) Inspect wear ring and stationary seal for nicks, scratches, burrs, and other visible damage.
- (10) Replace all damaged and worn parts.

c. Assembly.

- (1) Install pipe plug (1) in volute casing (2).
- (2) Install wear ring (3).
- (3) Install eight studs (4).




M978 Tanker Maintenance Procedures Instructions (Cont)

22-4. PRIMARY PUMP REPAIR (CONT).

WARNING

Seals and gaskets must not be reused. Used pump seals and gaskets can leak and cause hazardous operating conditions.

- (4) Install oil seal (6) in bearing retainer (6).
- (5) Install packing (7) on bearing retainer (6).
- (6) Install bearing retainer (6) in impeller side of intermediate housing (8).
- (7) Lubricate surface of oil seal (6) with oil.




TA190814

WARNING


Wear safety glasses while installing retaining rings to protect eyes from injury or blindness.

- (8) Install retaining ring (9).
- (9) Install two bearings (10) on impeller shaft (11).



TA190815


- (10) Install impeller shaft (11) in intermediate housing (8).
- (11) Make sure impeller shaft (11) is fully seated.



TA190816

M978 Tanker Maintenance Procedures Instructions (Cont)

- (12) Install oil seal (12) in bearing retainer (13).
- (13) Install preformed packing (14) on bearing retainer (13).
- (14) Lubricate surface of oil seal (12) with oil.
- (15) Install bearing retainer (13) in coupling end of intermediate housing (8).
- (16) Install same number and thickness of shims (15) as removed.



WARNING



Wear safety glasses while installing retaining rings to protect eyes from injury or blindness.

- (17) Install retaining ring (16).

NOTE

Front coupling half has no rubber damper.

- (18) Install front coupling half (17) on impeller shaft (11).
- (19) Install key (18).
- (20) Tighten setscrew (19).
- (21) Install preformed packing (20) on stationary seal (21).
- (22) Install stationary seal (21) in seal plate (22).
- (23) Aline and install seal plate (22) on intermediate housing (8).




M978 Tanker Maintenance Procedures Instructions (Cont)

22-4. PRIMARY PUMP REPAIR (CONT).

CAUTION

Handle carbon seal by edge only. Fingerprint or contamination on sealing surface will cause pump malfunction.

- (24) Apply a few drops of grease to carbon seal (23) to hold it in place during assembly.
- (25) Install carbon seal (23) in shaft seal (24).



WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (26) Wipe sealing surfaces of stationary seal (21) and carbon seal (23) with dry cleaning solvent.
- (27) Install shaft seal (24), spring (25), and spring centering washer (26) in intermediate housing (8).

NOTE

Pump is shimmed for maximum efficiency. Be sure to install same number and thickness of shims as in removal.


- (28) Install same number and thickness of shims (27) as removed.
- (29) Install impeller (28).
- (30) Hold coupling half (17) so it does not turn, and tighten impeller (28) handtight on impeller shaft (11).



WARNING



Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water,

- (31) Apply silicone adhesive-sealant and install gasket (29) on volute casing (2).
- (32) Install intermediate housing (8) with eight nuts (30). Tighten nuts to 40 lb-ft (54 N•m).
- (33) Turn coupling shaft (17) by hand to check that impeller (28) turns freely. If impeller does not turn freely, remove intermediate housing (8), impeller (28), and one impeller shim (27). Go back to step (29) and continue,



M978 Tanker Maintenance Procedures Instructions (Cont)

- (34) Install two pipe plugs (31) in intermediate housing (8).
- (35) Install two coupling covers (32) on intermediate housing (8) with four screws (331), lockwashers (34), and washers (35).
- (36) Install support flange (36) on intermediate housing (8) with four screws (37), lockwashers (38), and nuts (39). Tighten nuts to 18 lb-ft (24 N•m).

**WARNING**

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE

There are two models of primary pump. Model A does not include discharge elbow and suction flange. If repairing Model B pump, discharge elbow and suction flange must be installed. Do steps (37) through (40) for Model B only.

- (37) Apply silicone adhesive-sealant and install gasket (40) on volute casing (2).
- (38) Install suction flange (41) with four nuts (42). Tighten nuts to 34 lb-ft (46 N•m).
- (39) Apply silicone adhesive-sealant and install gasket (43) on volute casing (2).
- (40) Install discharge elbow (44) with four nuts (45). Tighten nuts to 34 lb-ft (46 N•m).

d. Follow-on Maintenance. None.

END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cont)

22-5. AUXILIARY PUMP REPAIR.

This task covers:

- | | |
|------------------------|--------------------------|
| a. Disassembly | c. Assembly |
| b. Cleaning/Inspection | d. Follow-on Maintenance |

INITIAL SETUP

Models

M978

Test Equipment

None

Special Tools

None

Supplies

- Oil, lubricating, Item 46, Appendix C
- Solvent, drycleaning, Item 57, Appendix C
- Adhesive-sealant, silicone, Item 6, Appendix C
- Compound, sealing, pipe thread, Item 29, Appendix C
- Grease, general purpose, lithium base, Item 36, Appendix C
- Compound, sealing and thread locking, Item 25, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

MOS 63G, Fuel and electrical systems repairer

References

None

Equipment Condition

TM or Para

Condition Description

AUXILIARY PUMP on clear work surface.

Special Environmental Conditions

None

General Safety Instructions

No smoking, flame, sparks, and hot or glowing objects within 50 ft (15 m) of vehicle.


Level of Maintenance

General Support

M978 Tanker Maintenance Procedures Instructions (Cont)

22-5. AUXILIARY PUMP REPAIR (CONT).

a. Disassembly.



TA190328

- (1) Remove access plug (1) from each side of motor (2).
- (2) Remove screw (3) and washer (4) from each side of motor (2).
- (3) Hold spring (6) out of way and remove brush (6).
- (4) Remove four nuts (7) from studs (8).
- (5) Separate pump housing (9) from pedestal (10).
- (6) Remove gasket (11) and preformed packing (12).
- (7) Remove two screws (13) and vane plate (14) from pedestal (10).


NOTE

Seal is provided as a kit. Kit consists of: spring seat, spring, shaft seal, carbon seal, and stationary seal. Seal spring tension is released when impeller is removed.

- (8) Hold impeller shaft (16) and remove jamnut (16) and impeller (17).

NOTE

- Tag and mark shims.
- Number of shims will vary from pump to pump.




TA190330

- (9) Remove washer (18) and shims (19).
- (10) Remove spring seat (20) and spring (21).

M978 Tanker Maintenance Procedures Instructions (Cont)

- (11) Remove four screws (22) and lockwashers (23).
- (12) Remove pedestal (4) from motor (24).
- (13) Remove shaft seal (25), carbon seal (26), and stationary seal (27).




TA190331

- (14) Remove four studs (8) from pump housing (9).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA190332

- (1) Clean all metal parts, except pump motor, in dry cleaning solvent.
- (2) Inspect outside of pump housing for cracks, dents, and breaks.
- (3) Inspect impeller, vane plate, and inside of pump housing for visible wear, pitting, scratches, burrs, nicks, cracks, and other visible damage.
- (4) Inspect impeller shaft for excessive wear, pitting, cracks, nicks, burrs, grooves, damaged threads, and other visible damage.
- (5) Inspect seal spring for kinks, cracks, and other visible damage.
- (6) Inspect all threaded parts for damage.
- (7) Replace all damaged and visibly worn parts.

c. *Assembly.*

- (1) Install four studs (1) in pump housing (2).



TA190333

22-5. AUXILIARY PUMP REPAIR (CONT).


- (2) Install motor (3) on pedestal (4) with four screws (5) and lockwashers (6).

CAUTION

Handle stationary seal and carbon ring by sides only. Fingerprints or contamination on face of seals will cause pump malfunction.

NOTE

Seal is provided as a kit. Kit consists of: spring seat, spring, shaft seal, carbon seal, and stationary seal.



TA190334

- (3) Lubricate edge of stationary seal (7) with oil and install.
- (4) Apply small amount of grease to front of carbon seal (8) and place in shaft seal (9).

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (5) Wipe sealing surfaces of stationary seal (7) and carbon seal (8) with dry cleaning solvent and install shaft seal (9).
- (6) Install spring (10) and spring seat (11) on impeller shaft (12).

NOTE


Number of shims will vary from pump to pump.

- (7) Install shims (13) and washer (14).
- (8) Hold impeller shaft (12) and install impeller (15).
- (9) Apply sealing and thread locking compound to threads of jamnut (16) and install.




TA190335

M978 Tanker Maintenance Procedures Instructions (Cont)



(10) Measure and record distance between height of impeller vanes (17) and plate (18).




(11) Measure and record distance between height of vane plate (19) and housing surface (20).

(12) Subtract the smaller number from the larger number recorded, difference should be between 0.005-in. to 0.008-in. (0.127 to 0.203 mm). If clearance is correct go to step (21). If not continue with step (13).

M978 Tanker Maintenance Procedures Instructions (Cont)

22-5. AUXILIARY PUMP REPAIR (CONT).



TA190338

(13) Hold impeller shaft (12) and remove jamnut (16).

NOTE

Seal spring tension is released as impeller is removed.

(14) Hold impeller shaft (12) to keep from turning and remove impeller (15).

(15) Remove washer (14).

NOTE

- If difference in clearance was under 0.005-in. (0.127 mm) remove shims as required.

- If difference in clearance was over 0.008-in. (0.203 mm) add shims as required.


(16) Add or remove shims (13).

(17) Install washer (14).

(18) Hold impeller shaft (12) and install impeller (15).

(19) Apply sealing and thread locking compound to threads of jamnut (16) and install.

(20) Repeat steps (10) through (12).



TA190339

M978 Tanker Maintenance Procedures Instructions (Cont)

- (21) Apply silicone adhesive-sealant to mating surface of vane plate (19).
- (22) Install vane plate (19) on pedestal (4) with two screws (21).
- (23) Install preformed packing (22) in groove.
- (24) Install gasket (23) and pump housing (2) on pedestal (4) with four nuts (24).
- (25) Install brush (25) in each side of motor (3).
- (26) Position spring (26) over each brush (25).
- (27) Install screw (27) and washer (28) on each side of motor (3).
- (28) Install access plug (29) in each side of motor (3).

d. *Follow-on Maintenance.* None.

END OF TASK


Section IV. FLOWMETER MAINTENANCE

22-6. FLOWMETER REGISTER REMOVAL/INSTALLATION.	
This task covers:	
a. Removal b. Installation	c. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i> M978	<i>Equipment Condition</i> TM or Para
<i>Test Equipment</i> None	TM 9-2320-279-20 Flowmeter register knob removed.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> Lockwire, Item 39, Appendix C	<i>General Safety Instructions</i> No smoking, flame, sparks, and hot or glowing objects within 50 ft (15 m) of vehicle.
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> Direct Support
<i>References</i> None	

M978 Tanker Maintenance Procedures Instructions (Cont)

22-6. FLOWMETER REGISTER REMOVAL/INSTALLATION (CONT).

a. Removal.



TA190290

- (1) Remove safety wire (1) and two front screws (2).
- (2) Remove two rear screws (3).
- (3) Remove flowmeter register (4) from flowmeter (5).

NOTE

Top gear may come off or stay with gear plate.

- (4) Mark position of gear plate (6). Remove two screws (7) and gear plate from flowmeter register (4).
- b. Installation.
- (1) Aline matchmarks and install gear plate (6) on flowmeter register (4) with two screws (7).
 - (2) Position flowmeter register (4) on flowmeter (5).
 - (3) Install four screws (2 and 3).
 - (4) Install safety wire (1) on two screws (2).
- c. Follow-on Maintenance. Install flowmeter register knob (TM 9-2320-279-20).

END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cont)

22-7. FLOWMETER REMOVAL/INSTALLATION.

This task covers:

- a. Removal
- b. Installation
- c. Follow-on Maintenance

INITIAL SETUP

Models

M978

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

TM 9-2320-279-20 V11 flow regulating valve removed.

TM 9-2320-279-20 Flowmeter to venturi assembly piping removed.

Equipment Condition

TM or Para

TM 9-2320-279-20 Flowmeter strainer removed.

TM 9-2320-279-20 Sampling probe valve removed.

TM 9-2320-279-20 Tank level indicator gage removed.

TM 9-2320-279-20 Control junction box removed.

Para 22-6 Flowmeter register removed.

TM 9-2320-279-20 Emergency valve actuator assembly removed.

Special Environmental Conditions

None

General Safety Instructions

No smoking, flame, sparks, and hot or glowing objects within 50 ft (15 m) of vehicle.

Level of Maintenance

Direct Support

a. Removal.


WARNING

Fuel will drain from piping when couplings are removed. Contact with fuel can irritate eyes and skin. Do not let fuel get into eyes. If fuel comes into contact with eyes, immediately rinse eyes with clear water. Wash fuel off skin with soap and water as soon as possible after contact.

NOTE

Right side screw will not separate from mounting bracket until bracket is removed.

- (1) Remove two locknuts (1), washers (2), and screws (3) from flowmeter (4).
- (2) Remove flowmeter (4) from mounting bracket (5).




M978 Tanker Maintenance Procedures Instructions (Cont)

22-7. FLOWMETER REMOVAL/INSTALLATION (CONT).

NOTE


Mark position of mounting bracket before removal.

(3) Remove two locknuts (6), screws (7), brackets (8), and mounting bracket (5) from grating (9).



b. Installation.


(1) Position screw (1) in mounting bracket (2).
 (2) Position mounting bracket (2) on grating (3) and install two brackets (4), screws (5), and locknuts (6).



(3) Position flowmeter (7) on mounting bracket (2).
 (4) Install flowmeter (7) with two screws (1), washers (8), and locknuts (9).

c. Follow-on Maintenance.

- (1) Install tank level indicator gage (TM 9-2320-279-20).
- (2) Install control junction box (TM 9-2320-27920).
- (3) Install sampling probe valve (TM 9-2320-27920).
- (4) Install flowmeter strainer (TM 9-2320-279-20).
- (5) Install flowmeter register (para 22-6).
- (6) Install V11 flow regulating valve (TM 9-2320-279-20).
- (7) Install flowmeter to venturi assembly piping (TM 9-2320-27920).
- (8) Recirculate fuel (TM 9-2320-279-10).
- (9) Inspect flowmeter for leaks and proper operation.
- (10) Close pump module rear access doom (TM 9-2320-279-10).




END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cont)

22-8. FLOWMETER REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection.	d. Follow-on Maintenance	
INITIAL SETUP		
Models	References	
M978	None	
Test Equipment	Equipment Condition	
None	<i>TM or Para</i>	<i>Condition Description</i>
Special Tools		Flowmeter on clean work surface.
None		
Supplies	Special Environmental Conditions	
Adhesive-sealant, silicone, Item 6, Appendix C	None	
Compound, sealing, pipe thread, Item 29, Appendix C	General Safety Instructions	
Solvent, dry cleaning, Item 57, Appendix C	No smoking, flame, sparks, and hot or glowing objects within 50 ft (15 m) of vehicle.	
Personnel Required	Level of Maintenance	
MOS 63W, Wheel vehicle repairer	General Support	


a. Disassembly.




- (1) Remove four screws (1) and cover plate (2) from front cover (3).
- (2) Remove two screws (4) and data plate (5).

M978 Tanker Maintenance Procedures Instructions (Cont)


22-8. FLOWMETER REPAIR (CONT.)



(3) Remove two screws (6) and adjuster plate (7) from front cover (3).




(4) Remove screw (8) and adjuster plate (7) from adjuster (9).



(5) Remove setscrew (10) and adjuster drive gear assembly (11) from front cover (3).


M978 Tanker Maintenance Procedures Instructions (Cont)

- (6) Remove retaining ring (12) and adjuster drive gear (13).
- (7) Separate two-part bushing (14) and remove drive shaft (15).




TA190648

- (8) Remove two screws (16) and retaining plate (17) from front cover (3).
- (9) Remove gland assembly (18).
- (10) Remove preformed packing (19).



TA190649

- (11) Remove nine screws (20), washers (21), rear cover (22), and gasket (23) from housing (24).
- (12) Remove plug (25) from rear cover (22).




TA190650


M978 Tanker Maintenance Procedures Instructions (Cont)

22-8. FLOWMETER REPAIR (CONT).


- (13) Remove six screws (26), washers (27), and bearing plate (28) from housing (24).
- (14) Remove two pins (29).



- (15) Remove nine screws (30), washers (31), front cover (3), and gasket (32) from housing (24).
- (16) Remove two pins (33).




- (17) Remove six screws (34), lockwashers (35), and bearing plate assembly (36) from housing (24).
- (18) Remove two pins (37).



M978 Tanker Maintenance Procedures Instructions (Cont)

- (19) Matchmark two displacement rotor gears (38) and blocking rotor gear (39).
- (20) Remove three locknuts (40), two displacement rotor gears (38), and blocking rotor gear (39) from bearing plate (36).
- (21) Remove two displacement rotors (41), blocking rotor (42), and three machine keys (43).



TA190654

b. *Cleaning/Inspection.*WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts in dry cleaning solvent.



WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with compressed air.
- (3) Inspect threaded parts for stripping or crossthreading. Replace damaged parts.
- (4) Inspect gears for chipped or cracked teeth. Replace damaged gears.
- (5) Inspect packing gland assembly for damage. Replace if damaged.
- (6) Inspect two-piece bushing, bushing plates, and shafts for scoring or damage. Replace if damaged.
- (7) Inspect rotors for damage, chips, or deposits. Remove deposits, nicks, chips, or burrs, then clean and dry.
- (8) Inspect keys and keyways for damage. Replace damaged keys.
- (9) Inspect housings for cracks and deposits. Replace damaged housings. Remove all deposits, then clean and dry.

22-8. FLOWMETER REPAIR (CONT).


c. Assembly.



ROTOR POSITION

TA190655

- (1) Install three machine keys (1) in blocking rotor (2) and two displacement rotors (3).
- (2) Install blocking rotor (2) and two displacement rotors (3) in bearing plate (4).
- (3) Align matchmarks and install blocking rotor gear (5) and two displacement rotor gears (6). Check position of rotors as shown.
- (4) Install three locknuts (7).



TA190656


- (5) Install two pins (8) in rear bearing plate (9).
- (6) Install rear bearing plate (9) on housing (10) with lockwashers (11) and screws (12).

M978 Tanker Maintenance Procedures Instructions (Cont)

NOTE

When installing front bearing plate assembly make sure rotor shafts are seated in holes in rear bearing plate and turn freely.

- (7) Install two pins (13) in housing (10).
- (8) Install front bearing plate assembly (4) on housing (10) with six screws (14) and lockwashers (15).




- (9) Install two pins (16) in housing (10).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (10) Apply silicone adhesive-sealant and install gasket (17) and front cover (18) on housing (10) with nine screws (19) and washers (20).



- (11) Apply pipe thread sealing compound to plug (20) and install in rear cover (22).
- (12) Apply silicone adhesive-sealant and install gasket (23) and rear cover (22) on housing (10) with nine washers (24) and screws (25).



M978 Tanker Maintenance Procedures Instructions (Cont)

22-8. FLOWMETER REPAIR (CONT).


(13) Install preformed packing (26) on gland assembly (27).

NOTE

When assembling packing gland into housing, make sure two blades of packing gland shaft fit into slot in end of blocking rotor shaft.


(14) Install gland assembly (27) in front cover (18).

(15) Install retaining plate (28) with two screws (29).




(16) Install shaft (30) in two piece bushing (31).

(17) Install gear (32) and retaining ring (33) on shaft (30).




(18) Install adjuster gear assembly (34) in front cover (18).


(19) Install setscrew (35).



(20) Position adjuster (36) on adjuster plate (37) and install screw (38).




M978 Tanker Maintenance Procedures Instructions (Cont)



NOTE

Make sure two ears on shaft go inside adjuster.

(21) Install adjuster plate (37) on front cover (18) with two screws (39).



(22) Install cover plate (40) on front cover (18) with four screws (41).

(23) Install data plate (42) with two screws (43).

d. *Follow-on Maintenance.* None.


END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cont)

Section V. AIR ELIMINATOR

22-9. AIR ELIMINATOR REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models	References	
M978	None	
Test Equipment	Equipment Condition	
None	TM or Para	Condition Description
Special Tools		Air eliminator on clean work surface.
None		
Supplies	Special Environmental Conditions	
Solvent, dry cleaning, Item 57, Appendix C	None	
Personnel Required	General Safety Instructions	
MOS 63W, Wheel vehicle repairer	None	
	Level of Maintenance	
	General Support	


a. Disassembly.




- (1) Remove 12 screws (1) and washers (2) from two outlet covers (3).
- (2) Remove two outlet covers (3), two gaskets (4 and 5), and valve plates (6) from housing (7).

M978 Tanker Maintenance Procedures Instructions (Cont)

- (3) Note position and remove two screws (8) from valve reeds (9).



- (4) Remove two screws (10) and baffle (11).
 (5) Remove float (12) from housing (13).



- (6) Remove two nuts (14), lockwashers (15), reed clips (16), and valve reeds (9) from float (17).

b. *Cleaning/Inspection.*

WARNING


Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.


- (2) Dry metal parts with compressed air.
 (3) Inspect each part for damage.
 (4) Replace damaged parts.



M978 Tanker Maintenance Procedures Instructions (Cont)



22-9. AIR ELIMINATOR REPAIR (CONT).

c. Assembly.



(1) Install two valve reeds (1), reed clips (2), lockwashers (3), and nuts (4) on float (5).


(2) Install float (5), baffle (6), and two screws (7) in housing (8).



(3) Bend two valve reeds (1) over and down and install screws (9) in valve reeds and housing (8).

M978 Tanker Maintenance Procedures Instructions (Cont)

- (4) Position two valve plates (10), two gaskets (11 and 12), and outlet covers (13) on housing (8).
- (5) Install 12 washers (14) and screws (15).



TA190774

d. Follow-on Maintenance. None.

END OF TASK


Section VI. VALVES

22-10. V1 EMERGENCY VALVE REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models M978	References None	
Test Equipment None	Equipment Condition	
Special Tools None	TM or Para	Condition Description V1 emergency valve on clean work surface.
Supplies Compound, sealing, lubricating, wicking, thread locking, Item 25, Appendix C Oil, lubricating, Item 47, Appendix C Solvent, dry cleaning, Item 57, Appendix C	Special Environmental Conditions None	
Personnel Required MOS 63W, Wheel vehicle repairer	General Safety Instructions None	
	Level of Maintenance General Support	

22-10. V1 EMERGENCY VALVE REPAIR (CONT).


a. Disassembly.

- (1) Mark position of lever (1) and remove nut (2), lockwasher (3), screw (4), and lever from camshaft assembly (5).
- (2) Remove nut (6) and spring (7).



TA190626

- (3) Remove bonnet assembly (8) from valve body (9) by pressing and turning counterclockwise.




TA190627

WARNING


Make sure bonnet assembly is secure in clamping device compressing spring. If bonnet assembly slips from clamping device while spring is compressed, injury to personnel can result.

- (4) Install bonnet (8) and disk assembly (10) in suitable clamping device and compress spring (11).
- (5) Remove spring pin (12) and bail (13).



TA190628


M978 Tanker Maintenance Procedure Instructions (Cont)




WARNING

Bonnet assembly is spring loaded. Spring tension must be released slowly to prevent injury to personnel.

- (6) Release tension on spring (11) and remove bonnet (8) and disk assembly (10) from clamping device.



- (7) Remove bonnet (8) and spring (11) from valve stem (14).
 (8) Remove disk nut (15), disk (16), and disk holder (17).



- (9) Remove retaining ring (18), camshaft assembly (5), and cam (19) from valve body (9).

22-10. V1 EMERGENCY VALVE REPAIR (CONT).

(10) Remove asbestos packing (20), packing ring (21), asbestos packing (22), gland washer (23), and leather washer (24) from camshaft (25).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Use clean cloth and compressed air to dry metal parts cleaned with dry cleaning solvent.
- (3) Inspect all metal parts for bends, breaks, cracks, and sharp edges.
- (4) Replace damaged parts.


c. *Assembly.*

(1) Install leather washer (1) and gland washer (2) on camshaft (3).


NOTE

Asbestos packings and packing ring are provided as a set.

(2) Install asbestos packing (4), packing ring (5), and asbestos packing (6) on camshaft (3).




TA190632



TA190633

M978 Tanker Maintenance Procedure Instructions (Cont)


- (3) Install cam (7) in valve body (8).
- (4) Install camshaft assembly (9) in valve body (8) and install cam (7) on camshaft assembly.
- (5) Install retaining ring (10).



TA190634

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




TA190635

- (6) Apply thread locking compound on threads of valve stem (11).
- (7) Install disk holder (12), disk (13), and disk nut (14) on valve stem (11).
- (8) Install spring (15) and bonnet (16) on valve stem (11).

WARNING

Make sure bonnet assembly is secure in clamping device before compressing spring. If bonnet assembly slips from clamping device while spring is compressed, injury to personnel can result.

- (9) Install bonnet assembly (17) and disk assembly (18) in suitable clamping device and compress spring (15).



TA190636


M978 Tanker Maintenance Procedure Instructions (Cont)

22-10. V1 EMERGENCY VALVE REPAIR (CONT).


WARNING

Spring pin must be securely installed before removing bonnet assembly from clamping device. Quick release of spring pressure can cause serious injury to personnel.

- (10) Install bail (19) and spring pin (20) on valve stem (11).
- (11) Remove bonnet assembly (17) and disk assembly (12) from clamping device.
- (12) Install bonnet assembly (17) in valve body (8) by pressing and turning clockwise.



TA190637




TA190638

- (13) Apply lubricating oil to spring (21) and install on camshaft (3).
- (14) Install nut (22) in valve body (8).
- (15) Install lever (23) on camshaft (3).
- (16) Install screw (24), lockwasher (25), and nut (26).

d. Follow-on Maintenance. None.

END OF TASK




TA190639

M978 Tanker Maintenance Procedures Instructions (Cont)

22-11. V2 BOTTOM LOAD ADAPTER REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
<i>Models</i> M978	<i>References</i> None	
<i>Test Equipment</i> None	<i>Equipment Condition</i> TM or Para	<i>Condition Description</i> V2 Bottom load adapter on clean work surface.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None	
<i>Supplies</i> Oil, lubricating, Item 47, Appendix C Solvent, drycleaning, Item 57, Appendix C	<i>General Safety Instructions</i> None	
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i> General Support	

a. *Disassembly.*



CAUTION

Bottom load adapter is spring loaded. Compress spring while removing screws to prevent loss of parts.

- (1) Remove nine screws (1) and lockwashers (2) from flange (3).
- (2) Remove flange (3) and preformed packing (4) from valve body (5).
- (3) Remove poppet (6) with shaft (7).
- (4) Remove spring (8).
- (5) Remove cotter pin (9) and shaft (7) from poppet.

M978 Tanker Maintenance Procedures Instructions (Cont)

21-11. V2 BOTTOM LOAD ADAPTER REPAIR (CONT).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with drycleaning solvent.


WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Use clean cloth and compressed air to dry metal parts cleaned with drycleaning solvent.
- (3) Inspect all parts for damage.
- (4) Replace damaged parts.

c. Assembly.

- (1) Install shaft (1) on poppet (2) with cotter pin (3).
- (2) Wrap ends of cotter pin (3) around shaft (1) so they will be clear of spring (4).
- (3) Install spring (4) over shaft (1).




- (4) Position poppet (2) in valve body (5).

NOTE

Compress spring while installing screws to prevent loss of parts.

- (5) Lubricate preformed packing (6) with oil and install in grooves of valve body (5).
- (6) Install flange (7) on valve body (5) with nine lockwashers (8) and screws (9).




d. Follow-on Maintenance. None.

END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cont)

22-12. V3 SUCTION LINE VALVE AND V17 GRAVITY VALVE REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models	Equipment Condition	
M978	TM or Para	Condition Description
Test Equipment		V3 suction line valve or V17 gravity valve on clean work surface.
None		
Special Tools	Special Environmental Conditions	
None	None	
Supplies	General Safety Instructions	
Oil, lubricating, Item 47, Appendix C	None	
Solvent, dry cleaning, Item 57, Appendix C		
Personnel Required	Level of Maintenance	
MOS 63W, Wheel vehicle repairer	General Support	
References		
None		

a. Disassembly.



TA190561

CAUTION


Valve must be in open position to allow removal of valve parts and to prevent equipment damage.

(1) Set handle (1) to OPEN position.

M978 Tanker Maintenance Procedure Instructions (Cont)

22-12. V3 SUCTION LINE VALVE AND V17 GRAVITY VALVE REPAIR (CONT).

- (2) Remove screw (2), washer (3), handle (1), and washer (4) from stem (5).




TA190562

- (3) Remove two nuts (6) and screws (7) from upper housing (8) and lower housing (9).
- (4) Remove lower housing (9) from body and liner (10).

NOTE

Preformed packing and stem may stay in liner.

- (5) Remove preformed packing (11) from stem (12) on lower housing (9). Remove upper housing (8).
- (6) Remove stem (12) from lower housing (9).
- (7) Remove preformed packing (14) from upper stem (5).



TA190564

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield and gloves.

- (2) Dry metal parts with compressed air.
- (3) Inspect all metal parts for bends, breaks, cracks, and sharp edges.
- (4) Replace damaged parts.


M978 Tanker Maintenance Procedure Instructions (Cont)

c. Assembly.

CAUTION

Body and liner disk must be in open position to allow proper installation of valve parts and prevent equipment damage.

(1) Move disk (1) to open position.




TA190565

- (2) Install preformed packing (2) on lower stem (3).
- (3) Lubricate stem (3) and install in lower housing (4).
- (4) Install lower housing (4) on body and liner (5).
- (5) Install preformed packing (6) on upper stem (7).

NOTE


Stem in upper housing is installed in hole stamped T on body and liner.

- (6) Install upper housing (8) on body and liner (5).
- (7) Install two screws (9) and nuts (10) in upper housing (8) and lower housing (4).



TA190566

- (8) Install washer (11), handle (12), washer (13), and screw (14) on stem (6).



TA190568

d. Follow-on Maintenance. None.

END OF TASK

M978 Tanker Maintenance Procedure Instructions (Cont)


22-13. V4 BYPASS/PRESSURE RELIEF VALVE REPAIR.					
This task covers:					
a. Disassembly	c. Assembly				
b. Cleaning/Inspection	d. Follow-on Maintenance				
INITIAL SETUP					
<i>Models</i> M978	<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer				
<i>Test Equipment</i> None	<i>References</i> None				
<i>Special Tools</i> None	<i>Equipment Condition</i>				
<i>Supplies</i> Compound, pipe thread sealing, Item 29, Appendix C Solvent, dry cleaning, Item 57, Appendix C Tags, identification, Item 60, Appendix C	<table border="1"> <thead> <tr> <th>TM or Para</th> <th>Condition Description</th> </tr> </thead> <tbody> <tr> <td></td> <td>V4 pressure relief valve on clean work surface.</td> </tr> </tbody> </table>	TM or Para	Condition Description		V4 pressure relief valve on clean work surface.
TM or Para	Condition Description				
	V4 pressure relief valve on clean work surface.				
	<i>Special Environmental Conditions</i> None				
	<i>General Safety Instructions</i> None				
	<i>Level of Maintenance</i> Direct Support				

a. Disassembly.

NOTE

Tag and mark fittings, tubes, and components before removal.


- (1) Remove two fittings (1) and tube (2) from elbows (3 and 4).
- (2) Remove two fittings (5) and tube (6) from elbows (7 and 8).
- (3) Remove two fittings (9) and tube (10) from elbows (11 and 12).



TA190459


M978 Tanker Maintenance Procedure Instructions (Cont)

- (4) Remove six elbows (3, 4, 7, 8, 11, and 12) from relief valve assembly (13).
- (5) Remove strainer body (14) and nipple (15) from elbow (16).




TA190460

- (6) Remove plug (17), preformed packing (18), and plastic screw (19) from strainer body (14).
- (7) Remove plug (20), fitting (21), preformed packing (22), and strainer screen (23) from strainer body (14).



TA190461


- (8) Remove nipple (24), union (25), union (26), nipple (27), and control assembly (28) from elbow (29).
- (9) Remove elbow (30), nipple (31), and bushing (32) from control assembly (28).
- (10) Remove two plugs (33) from control assembly (28).



TA190482


M978 Tanker Maintenance Procedure Instructions (Cont)

22-13. V4 BYPASS/PRESSURE RELIEF VALVE REPAIR (CONT).



TA190463


- (11) Remove cap (34) from cover (35).
- (12) Record number of threads showing on adjusting screw (36) and remove adjusting screw and nut (37).
- (13) Remove eight screws (38), cover (35), guide (39), spring (40), guide (41), and control body (42) from valve body (43).




TA190464

- (14) Remove preformed packing (44) from control body (42).
- (15) Remove nut (45), washer (46), washer (47), diaphragm (48), and washer (49).
- (16) Remove stem (50), nut (51), and retainer (52).
- (17) Remove two preformed packings (53) from stem (50) and preformed packing (54) from control body (42).
- (18) Remove seat (55) and preformed packing (56) from valve body (43).


M978 Tanker Maintenance Procedures Instructions (Cont)



- (19) Remove elbow (57), bushing (58), and nipple (59) from relief valve (13).
- (20) Remove three plugs (60, 61, and 62) from relief valve (13).
- (21) Remove adapter (63), gasket (64), glass tube (65), gasket (66), housing (67), screw (68), and gasket (69) from relief valve cover (70).




- (22) Remove eight screws (71) and relief valve cover (70) from relief valve (13). Remove spring (72).
- (23) Remove cover (73) from relief valve cover (70).





M978 Tanker Maintenance Procedures Instructions (Cont)

22-13. V4 BYPASS/PRESSURE RELIEF VALVE REPAIR (CONT).



(24) Remove sight rod assembly (74) and seat (75) from relief valve (13).

(25) Remove nut (76), washer (77), diaphragm (78), and seat (79) from stem (80).



(26) Remove guide (81), two washers (82), and disc (83) from seat (79).

M978 Tanker Maintenance Procedure Instructions (Cont)

b. *Cleaning/Inspection.*WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all glass and metal parts in dry cleaning solvent.
- (2) Wipe rubber parts with clean cloth.


WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.


- (3) Dry metal parts with compressed air.
- (4) Inspect threaded parts for stripping or cross threading. Replace damaged or worn parts.
- (5) Inspect rubber parts. Replace damaged parts.
- (6) Inspect stems, seats, and washers for scoring, deposits, chips, nicks, or burrs. Remove deposits, chips, nicks, or burrs.
- (7) Inspect strainer screen for deposits and holes. Replace damaged screen.
- (8) Inspect housings, bodies, and covers for cracks and deposits. Remove deposits, replace damaged housings, bodies, and covers.

c. *Assembly.*

- (1) Install disc (1), two washers (2), and guide (3) in seat (4).




- (2) Install seat (4), diaphragm (5), washer (6), and nut (7) on stem (8).




M978 Tanker Maintenance Procedure Instructions (Cont)

22-13. V4 BYPASS/PRESSURE RELIEF VALVE REPAIR (CONT).

(3) Install seat (9) and sight rod assembly (10) in relief valve (11).




(4) Install seat (12) in relief valve cover (13).
 (5) Position spring (14) on sight rod assembly (10) and install relief valve cover (13) on relief valve (11) with eight screws (15).




WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


(6) Coat threads of adapter (16) with pipe thread sealing compound and install in relief valve cover (13).
 (7) Install gasket (17) and screw (18) in housing (19).
 (8) Install gasket (20), glass tube (21), gasket (20), and housing (19) on adapter (16).



M978 Tanker Maintenance Procedures Instructions (Cont)




- (9) Coat threads of three plugs (22, 23, and 24) with pipe thread sealing compound and install in relief valve (11) and relief valve cover (14).
- (10) Coat threads with pipe thread sealing compound and install nipple (25), bushing (26), and elbow (27) in relief valve (11).



- (11) Install preformed packing (28) and seat (29) in valve body (30).
- (12) Install preformed packing (31) in control body (32) and two preformed packings (33) on stem (34).
- (13) Install stem (34), retainer (35), and nut (36) in control body (32).
- (14) Install washer (37), diaphragm (38), washer (39), washer (40), and nut (41) on control body (32) and stem (34).
- (15) Install preformed packing (42) in control body (32).


M978 Tanker Maintenance Procedures Instructions (Cont)

22-13. V4 BYPASS/PRESSURE RELIEF VALVE REPAIR (CONT).



TA190480

- (16) Position control body (32) on valve body (30).
- (17) Install guide (43), spring (44), guide (45), and cover (46) with eight screws (47).
- (18) Install nut (48) and adjusting screw (49) to recorded number of threads in cover (46). Tighten nut.
- (19) Install cap (50) on cover (46).




TA190481


- (20) Coat threads with pipe thread sealing compound and install two plugs (51) in control assembly (52).
- (21) Coat threads with pipe thread sealing compound and install bushing (53), nipple (54), and elbow (55).
- (22) Coat threads with pipe thread sealing compound and install nipple (56), union (57), union (58), nipple (59), and control assembly (52) on elbow (27). Do not tighten.

M978 Tanker Maintenance Procedure Instructions (Cont)

- (23) Position strainer screen (60) in strainer body (61) and install preformed packing (62) and fitting (63).
- (24) Coat threads of plug (64) with pipe thread sealing compound and install in fitting (63).
- (25) Install plastic screw (65), preformed packing (66), and plug (67) in strainer body (61).




- (26) Coat threads with pipe thread sealing compound and install nipple (68) and strainer body (61) on elbow (65).
- (27) Coat threads with pipe thread sealing compound and install six elbows (69, 70, 71, 72, 73, and 74) in relief valve assembly (75).



- (28) Install two fittings (76) and tube (77) on two elbows (73 and 74).
- (29) Install two fittings (78) and tube (79) on two elbows (71 and 72).
- (30) Install two fittings (80) and tube (81) on two elbows (69 and 70).
- (31) Tighten union (68).

d. Follow-on Maintenance. None.

END OF TASK



M978 Tanker Maintenance Procedures Instructions (Cont)

22-14. V5 AIR ACTUATED FLOW VALVE AND ACTUATOR REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Adjustment
- e. Follow-on Maintenance

INITIAL SETUP

Models
M978

Test Equipment
None

Special Tools
None

Fabricated Tools
Compression Tool, Item 8, Appendix B

Supplies
Oil, lubricating, Item 47, Appendix C
Grease, general purpose, lithium base, Item 36, Appendix C
Solvent, drycleaning, Item 57, Appendix C

Personnel Required
MOS 63W, Wheel vehicle repairer

References
None

Equipment Condition
TM or Para *Condition Description*
V5 air actuated flow valve on clean work surface.

Special Environmental Conditions
None

General Safety Instructions
None

Level of Maintenance
General Support

a. Disassembly.

NOTE


- Mark position of parts before removal.
- There are two models of flow valves. Model A has a two piece bracket. Model B has a single piece bracket. Do step (1) for Model A only.

- (1) Remove four nuts (1), screws (2), and bottom bracket (3) from top bracket (4).
- (2) Remove pin (5) from stem (6).
- (3) Remove four nuts (7) and screws (8).

NOTE

Do step (4) for Model A. Do step (4.1) for Model B.

- (4) Remove bottom bracket (3) from butterfly valve (9).
- (4.1) Remove flow valve body (23) with bracket (9.1) from butterfly valve (9).




M978 Tanker Maintenance Procedures Instructions (Cont)

CAUTION


Pin and hole in stem are tapered. When driving out pin, small end should be driven so big end comes out first, or damage to parts can result.

NOTE

There are two model of butterfly valve. Model A can be repaired. Model B cannot be repaired. Refer to TM 9-2320-279-24P for identification of valves. Do steps (5) through (10) for Model A. Go to step (10.1) for Model B.




- (5) Remove pin (10) from disk (11) and stem (6).
- (6) Remove stem (6) from valve body (12).




NOTE

Seat and preformed packings may come out with stem.

- (7) Matchmark and remove seat (13) and two preformed packings (14) from valve body (12).
- (8) Mark and remove disk (15) from seat (13).
- (9) Remove gasket (16), preformed packing (17), and plug (18).




- (10) Remove pin (19) from collar (20) and remove collar from shaft (21).
- (10.1) Remove pin (19) from collar (20).



M978 Tanker Maintenance Procedures Instructions (Cont)

22-14. V5 AIR ACTUATED FLOW VALVE AND ACTUATOR REPAIR (CONT).



NOTE


Do step (11) for Model A. Do step (11.1) for Model B.

- (11) Remove four screws (22) and top bracket (4) from flow valve body (23).
- (11.1) Remove four screws (22), bracket (9.1), and collar (20) from flow valve body (23).
- (12) Remove retaining ring (24) and washer (25) from shaft (21).



CAUTION

Shaft must be driven out through bottom side of body to prevent damage to parts.

- (13) Remove shaft (21) from flow valve (23).
- (14) Remove bearing (26) from flow valve (23).




- (15) Remove bearing (27), preformed packing (28), and preformed packing (29) from shaft (21).



- (16) Remove two screws (30), end cap (31), and preformed packing (32) from flow valve body (23).
- (17) Record number of threads and remove two stop screws (33) and locknuts (34).


M978 Tanker Maintenance Procedure Instructions (Cont)

- (18) Remove four cylinder locknuts (35), cylinder end cap (36), cylinder assembly (37), and two preformed packings (38) from flow valve body (23).
- (19) Remove four cylinder cap rods (39).
- (20) Remove two guide bars (40), cam lever (41), and two guide pins (42) from cylinder assembly (37).



TA190408

- (21) Remove spring assembly (43) from cylinder (37).
- (22) Remove piston (44) and preformed packing (45).



TA190407


WARNING

Spring is under very extreme tension. Use extreme care when releasing spring to avoid personal injury.

NOTE


Record length of spring before loosening screw. Screw must be loosened before spring assembly is placed in compression tool.

- (23) Hold spring assembly (43) in suitable holding device and loosen screw (46).



TA190406

- (24) Position spring assembly (43) in compression tool.
- (25) Tighten plate (47) against spring assembly (43).
- (26) Remove screw (46).
- (27) Alternately unscrew four nuts (48) and compression tool a few threads at a time to slowly release tension from spring assembly (43).
- (28) Remove spring assembly (43) from compression tool.



TA190409

M978 Tanker Maintenance Procedure Instructions (Cont)

22-14. V5 AIR ACTUATED FLOW VALVE AND ACTUATOR REPAIR (CONT).

(29) Remove spring guides (48 and 49) from spring (43).

b. *Cleaning/Inspection.*

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.


(2) Dry metal parts with compressed air.

(3) Inspect each part for damage.

(4) Replace damaged parts.

c. *Assembly.*

(1) Aline spring (1), spring guides (2 and 3), and screw (4).



TA190411


WARNING

As spring is compressed, keep spring tension under control to prevent injury to personnel.

(2) Using compression tool, alternately tighten four nuts (5) and compress spring (1) and spring guides (2 and 3).

NOTE


Be sure spring is compressed to recorded length.



TA190457

(3) Install screw (4) in spring guide (3) and remove compression tool.


(4) Apply thin layer of grease to inside of cylinder (5) and install spring assembly (6) in cylinder.



TA190412

M978 Tanker Maintenance Procedure Instructions (Cont)

- (5) Install preformed packing (7) on piston (8).




TA190413

CAUTION

If one bearing was faulty, both bearings must be replaced to ensure proper shaft operation and fit.

- (6) Install two preformed packings (9 and 10) and bearing (11) on shaft (12).
- (7) Install cam lever (13) with two pins (14) and guide bars (16) on piston assembly (16).
- (8) Install preformed packing (17) on valve body (18).
- (9) Install piston assembly (16) on valve body (18).




TA190414


NOTE

Make sure shaft is installed through cam lever inside body.

- (10) Aline and install shaft assembly (19) in flow valve body (18). Install bearing (20) in flow valve body.
- (11) Install cylinder assembly (21) in valve body (18).
- (12) Install four cylinder cap rods (22) in valve body (18).
- (13) Install preformed packing (17) in end cap (23).
- (14) Install end cap (23) with four nuts (24).




TA190458



TA190440


- (15) Install two locknuts (22) and stop screws (23) in flow valve body (18) to recorded number of threads.
- (16) Install preformed packing (24) and end cap (25) in flow valve body (18) with two screws (26).



TA190415

M978 Tanker Maintenance Procedures Instructions (Cont)


- (17) Install washer (27) and retaining ring (28) on shaft assembly (19).




NOTE

Do step (18) for Model A. Do step (18.1) for Model B and continue to step (20).

- (18) Position top bracket (29) on flow valve body (18) and install four screws (30).
- (18.1) Position collar (31) and bracket (29.1) on flow valve body (18) and install four screws (30).




- (19) Position collar (31) on shaft (19) and align holes.
- (20) Install pin (32) through collar (31) and shaft (19).



NOTE


There are two models of butterfly valves. Model A can be repaired. Model B cannot be repaired. Refer to TM 9-2320-279-24P for identification of valves. Do steps (21) through (28) for Model A. Go to step (28.1) for Model B.

- (21) Install plug (33) in valve body (34).
- (22) Install preformed packing (35) and gasket (36).
- (23) Install two preformed packings (37 and 38) in seat (39).
- (24) Position disk (40) in seat (39).
- (25) Install seat (39) in valve body (34).



M978 Tanker Maintenance Procedures Instructions (Cont)


- (26) Install stem (41) in valve body (34).




CAUTION

Pin and hole in stem are tapered. When driving in pin, big end should be driven so small end goes in first, or damage to parts can result.

- (27) Install pin (42) through disk (46) and stem (41).




- (28) Install bottom bracket (43) on butterfly valve body (34) with four screws (44) and nuts (45).
- (28.1) Install flow valve body (15) with bracket (29.1) on butterfly valve body (34) with four screws (44) and nuts (45).
- (29) Install pin (46) in stem (41).



M978 Tanker Maintenance Procedures Instructions (Cont)**NOTE**

Do step (30) for Model A only.

- (30) Install bottom bracket (43) on top bracket (29) with four screws (47) and nuts (48).



M978 Tanker Maintenance Procedure Instructions (Cont)

22-14. V5 AIR ACTUATED FLOW VALVE AND ACTUATOR REPAIR (CONT).



d. Adjustment.

- (1) Turn stop screw (1) until disk (2) is in full closed position.
- (2) Hold stop screw (1) and tighten locknut (3).

NOTE

Do not apply over 100 psi (690 kPa) air pressure to actuator.

- (3) Apply air pressure to flow valve body (4).
- (4) Turn stop screw (5) until disk (2) is in full open position.
- (5) Hold stop screw (5) and tighten locknut (6).
- (6) Remove air pressure from valve body (4).



TA180424

e. Follow-on Maintenance. None.

END OF TASK

22-15. V6 FUEL/DEFUEL VALVE REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models
M978

Test Equipment
None

Special Tools
None

Supplies
Adhesive-sealant, silicone, Item 6, Appendix C
Solvent, dry cleaning, Item 57, Appendix C

Personnel Required
MOS 63W, Wheel vehicle repairer

References
None

Equipment Condition
TM or Para

Condition Description
V6 FUEL/DEFUEL valve on clean work surface.

Special Environmental Conditions
None


General Safety Instructions
None

Level of Maintenance
Direct Support


M978 Tanker Maintenance Procedures Instructions (Cent)

a. Disassembly.

(1) Remove eight locknuts (1), screws (2), flange (3), and gasket (4) from valve housing (5).



(2) Remove screw (6), lockwasher (7), washer (8), and handle (9) from valve plug (10).



NOTE


Matchmark valve cap and valve housing before removal.

(3) Remove key (11) from valve plug (10).

(4) Remove eight screws (12), valve cap (13), gasket (14), and valve plug (10) from valve housing (5).

(5) Remove preformed packing (15) from valve cap (13).

MATCHMARKS



b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(1) Clean all metal parts with dry cleaning solvent.

WARNING


Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with compressed air.
- (3) Inspect each part for damage.
- (4) Replace damaged parts.

[22-1 5. V6 FUEL/DEFUEL VALVE REPAIR (CONT).]

c. Assembly.


(1) Position valve plug (1) in valve housing (2) so key slot (3) is down.



(2) Install preformed packing (4) in valve cap (5).

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.




(3) Apply silicone adhesive-sealant to gasket (6) and install on valve cap (5).

(4) Install valve cap (5) on valve housing (2) with eight screws (7).

CAUTION

Woodruff key must be installed securely in valve plug slot to ensure proper valve operation.

(5) Install key (8) in valve plug (1).




(6) Install handle (9), washer (10), lockwasher (1 1), and screw (12) on valve plug (1).

M978 Tanker Maintenance Procedures Instructions (Cent)

(7) Install gasket (13), flange (14), screws (15), and locknuts (16) in valve housing (2).

cf. Follow-on Maintenance. None.

END OF TASK



TA191000

22-16. **V7/V8** REEL VALVE REPAIR.

This task covers:

- a. Disassemble y
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

M978

Test Equipment

None

Special Tools

None

Supplies

Oil, lubricating, Item 47, Appendix C
Solvent, dry cleaning, Item 57, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

V7 or V8 reel valve on clean work surface.

Special Environmental Conditions

None


General Safety Instructions

None


Level of Maintenance

General Support

a. Disassembly.



TA190861



TA190862

CAUTION

Valve must be in open position for removal of valve parts and to prevent equipment damage.

NOTE

V7 and V8 reel valves are disassembled the same way.

(1) Set handle (1) to OPEN position.

(2) Remove screw (2), washer (3), and handle (1) from stem (4).

22-16. V7/V8 REEL VALVE REPAIR (CONT).

- (3) Remove two nuts (5) and screws (6) from upper housing (7) and lower housing (8).
- (4) Remove upper housing (7) and lower housing (8) from body and liner (9).
- (5) Remove preformed packing (10) from stem (4).

NOTE

Stem may stay in lower housing or body.

- (6) Remove stem (11) from lower housing (8).
- (7) Remove preformed packing (12) from stem (11).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.



- (1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with compressed air.
- (3) Inspect all metal parts for bends, breaks, cracks, and sharp edges.
- (4) Replace damaged parts.

c. Assembly.



CAUTION


Disk must be in open position for proper installation of valve parts and to prevent equipment damage.

NOTE


V7 and V8 reel valves are assembled the same way.

- (1) Move disk (1) in body and liner (2) to open position.

M978 Tanker Maintenance Procedures Instructions (Cont)



- (2) Install preformed packing (3) on stem (4).
- (3) Install stem (4) in lower housing (5).
- (4) Install preformed packing (6) on stem (7).
- (5) Lubricate stems (4 and 7) with oil and position upper housing (8) and lower housing (5) on body and liner (2).
- (6) Install two screws (9) and nuts (10) in upper housing (8) and lower housing (6).



- (7) Install handle (11) on stem (7) with washer (22) and screw (13).

d. Follow-on Maintenance. None.

END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cont)

22-17. V10 BOTTOM LOAD VALVE REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models
M978

References
None

Test Equipment
None

Equipment Condition
TM or Pam *Condition Description*
V10 bottom load valve on clean work surface.

Special Tools
None

Supplies
Compound, sealing, pipe thread, Item 29, Appendix C
Compound, antiseize, Item 17, Appendix C
Oil, lubricating, Item 47, Appendix C
Solvent, drycleaning, Item 57, Appendix C


Special Environmental Conditions
None

General Safety Instructions
None

Personnel Required
MOS 63W, Wheel vehicle repairer

Level of Maintenance
Direct Support

a. Disassembly




- (1) Remove four screws (1), lockwashers (2), and retainers (3).
- (2) Remove screen (4) from valve body (5).
- (3) Remove two rivets (6) from screen (4).
- (4) Remove plug (7) and preformed packing (8).
- (5) Remove plug (9).

M978 Tanker Maintenance Procedures Instructions (Cent)


NOTE

Matchmark parts before disassembly.

- (6) Remove two plugs (10).
- (7) Remove spring (11) from lever (12) and elbow (13).
- (8) Remove eight screws (14) and lockwashers (15).
- (9) Remove elbow (13), sump plate (16), preformed packing (17), valve body (5), and preformed packing (18).



TA190711



TA190712

WARNING

Valve is spring loaded. Spring must be compressed during disassembly, then released slowly to prevent personal injury.


- (10) Push down on piston (19) and remove nut assembly (20), bushing (21), and metering rod (22).
- (11) Remove piston (19), spring (23), spring (24), piston seal retainer (25), and seal (26).
- (12) Remove shaft (27) and preformed packing (28) from valve body (5).
- (13) Remove socket (29) and preformed packing (30) from shaft (27).
- (14) Remove retaining ring (31) and bracket (32) from metering rod (22).

22-17. V10 BOTTOM LOAD VALVE REPAIR (CONT.)

NOTE

Matchmark position of lever before removal.

- (15) Remove screw (33) and nut (34) from lever (12).
- (16) Remove lever (12) from shaft (35).
- (17) Remove spring pin (36) and link (37).



TA190713


- (18) Remove gland (38), preformed packing (39), and seal (40).
- (19) Note position and remove shaft (35) and cam (41).
- (20) Remove plug (42) from elbow (14).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with dry cleaning solvent.



TA190714


WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with compressed air.
- (3) Inspect all metal parts for bends, breaks, cracks, and sharp edges.
- (4) Inspect springs for cracks and distortion.
- (5) Replace damaged parts.

M978 Tanker Maintenance Procedures Instructions (Cent)

c. Assembly.




TA190715

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Apply pipe thread sealing compound to plug (1) and install.
- (2) Position cam (2) in elbow (3) and install shaft (4).
- (3) Install seal (5) and preformed packing (6) in gland (7).
- (4) Apply antiseize compound to gland (7) and install in elbow (3).




TA190716

- (5) Install link (8) in lever (9) with spring pin (10).
- (6) Align matchmarks and install lever (9) on shaft (4).
- (7) Apply antiseize compound to screw (11) and install screw and nut (12).

122-17. VI O BOTTOM LOAD VALVE REPAIR (CONT).

- (8) Install socket (13) and preformed packing (14) in shaft (15).
- (9) Install preformed packing (16) and shaft (15) in valve body (17).
- (10) Install piston seal (18) and seal retainer (19) in valve body (17).
- (11) Lubricate spring (20) and piston (21) with oil and install in valve body (17).
- (12) Install bracket (22) and retaining ring (23) on metering rod (24).
- (13) Lubricate spring (25) and nut assembly (26) with oil.
- (14) Install spring (25) and metering rod (24) in piston (21).




TA1 90717

WARNING

Valve is spring loaded. Spring must be compressed during assembly, then released slowly to prevent injury.

- (15) Compress and hold piston (21) and install nut assembly (26) and bushing (27).

- (16) Install preformed packing (28) in valve body (17).
- (17) Install preformed packing (29) in sump plate (30).
- (18) Install sump plate (30) and elbow (3) on valve body (17) with eight lockwashers (31) and screws (32).
- (19) Apply pipe thread sealing compound to two plugs (33) and install.
- (20) Install spring (34) to elbow (3) and lever (9).




TA190718

M978 Tanker Maintenance Procedures Instructions (Cent)

- (21) Apply pipe thread sealing compound to plug (35) and install in valve body (17).
- (22) Install plug (36) and preformed packing (37)
- (23) Install screen (38) with four retainers (40), lockwashers (41), and screws (42).
- (24) Install two rivets (43).

d. Follow-on Maintenance. None.

END OF TASK



TA190719


22-18. V11 FLOW REGULATING VALVE REPAIR.	
This task covers:	
a. Disassembly	c. Assembly
b. Cleaning/Inspection	d. Follow-on Maintenance
INITIAL SETUP	
<i>Models</i>	<i>References</i>
M978	None
<i>Test Equipment</i>	<i>Equipment Condition</i>
None	<i>TM or Para</i> <i>Condition Description</i>
<i>Special Tools</i>	None
None	V11 flow regulating valve on clean work surface.
<i>Supplies</i>	<i>Special Environmental Conditions</i>
Oil, lubricating, Item 47, Appendix C	None
Solvent, dry cleaning, Item 57, Appendix C	<i>General Safety Instructions</i>
<i>Personnel Required</i>	None
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>
	General Support

a. Disassembly.

CAUTION


Valve must be in open position for removal of valve parts and to prevent equipment damage.

(1) Set handle (1) to OPEN position.




TA190755

22-18. **VI 1 FLOW REGULATING VALVE REPAIR (CONT).**



(2) Remove screw (2), washer (3), and handle (1) from stem (4).



(3) Remove two nuts (5) and screws (6) from upper housing (7) and lower housing (8).
 (4) Remove upper housing (7) and lower housing (8) from body and liner (9).

NOTE

Stem and preformed packing may stay in liner during removal,

(5) Remove preformed packing (10) from stem (4).
 (6) Remove stem (11) from lower housing (8).
 (7) Remove preformed packing (12) from stem (11).

M978 Tanker Maintenance Procedures Instructions (Cent)

b. Cleanhg/inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

(Z) Dry metal parts with compressed air.

(3) Inspect all parts for bends, breaks, cracks, and sharp edges.


(4) Replace damaged parts.

c. Assembly.

CAUTION


Body and liner disk must be in open position to allow proper installation of valve parts and prevent equipment damage.

(1) Move disk (1) in body and liner (2) to open position.



TA190759

- (2) Install preformed packing (3) on stem (4).
- (3) Install stem (4) in lower housing (5).
- (4) Install preformed packing (6) on stem (7).
- (5) Lubricate stems (4 and 7) with oil and position upper housing (8) and lower housing (5) on body and liner (2).
- (6) Install two screws (9) and nuts (10) in upper housing (8) and lower housing (5).




TA190760

122-18. **V1** FLOW REGULATING VALVE REPAIR (CONT).

(7) Install handle (11) on stem (7) with washer (12) and screw (13).

d. Follow-on Maintenance. None.

END OF TASK



TA190762

22-19. **V12** BOTTOM LOAD PRECHECK VALVE AND SAMPLING PROBE VALVE REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

M978

Test Equipment

None

Special Tools

None

Supplies

Oil, lubricating, Item 47, Appendix C
 Solvent, dry cleaning, Item 57, Appendix C
 Compound, sealing, pipe thread, Item 29, Appendix C

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para

Condition Description

V 12 bottom load precheck valve or sampling probe valve on clean work surface.

Special Environmental Conditions

None

General Safety Instructions

None

Level of Maintenance


General Support

a. Disassembly.

NOTE


V12 bottom load precheck valve and sampling probe valve are disassembled the same way.

(1) Hold valve body (1) and remove nut (2), handle (3), retaining ring (4), and indicator stop (5) from stem (6).




TA1 90700


M978 Tanker Maintenance Procedures Instructions (Cent)



(2) Remove two nuts (7), screws (8), bonnet plate (9), and data plate (10) from valve body (1).



(3) Remove bearing (11), stem (6), and seal (12) from valve body (1).



(4) Remove end cap (13) and seal (14) from valve body (1).

22-19. **V12** BOTTOM LOAD PRECHECK VALVE AND SAMPLING PROBE VALVE REPAIR
(CONT).

(5) Remove seat (15), ball (16), and seat (17) from valve body (1).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

(2) Dry metal parts with compressed air.

(3) Inspect each part for damage.

(4) Replace damaged parts.

c. Assembly.

NOTE

V12 bottom load precheck valve and sampling probe valve are assembled the same way.

(1) Lubricate seat (1) with oil.

(2) Install seat (1), bevel edge facing out, in valve body (2).

(3) Lubricate ball (3) with oil and install in valve body (2).

(4) Lubricate seal (4) with oil and install in stem (5).

(5) Install stem (5). Turn stem and rotate ball (3) to closed position

(6) Lubricate seat (6) with oil and install in valve body (2) so bevel edge is toward ball (3).

CAUTION


Ball is loose inside valve body and can slide out of position. When handling valve body, avoid misalignment of or damage to valve.

(7) Lubricate seal (7) with oil and install on end cap (8).


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


(8) Apply pipe thread sealing compound on threads of end cap (8) and install in valve body (2).



TA190704



TA1 90705



TA190706


M978 Tanker Maintenance Procedures Instructions (Cent)

(9) Position handle (9) on stem (5).


CAUTION

Do not rotate handle quickly. If parts are not seated correctly and valve is turned too fast, parts can be damaged.

- (10) Look through valve body (2) and slowly rotate handle (9) from closed to open position several times to seat ball in valve.
- (11) Rotate handle (9) to closed position.
- (12) Remove handle (9).




TA190707



TA190708

- (13) Lubricate bearing (10) with oil and install on stem (5).
- (14) Install two screws (11) in bonnet plate (12).
- (15) Install two nuts (13) 3/8 in. (9.5 mm) from end of screw.
- (16) Position data plate (14) on valve body (2).
- (17) Install bonnet plate (12) on stem (5).
- (18) Tighten two screws (11).
- (19) Tighten two nuts (13) against bottom of valve body (2).



TA190709

NOTE

Bottom side of indicator stop is marked "bottom".


- (20) Install indicator stop (15), retaining ring (16), handle (9), and nut (17) on stem (5).
- d. Follow-on Maintenance. None.

END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cent)

22-20. V13VENTVALVE REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models M978	References None	
Test Equipment None	Equipment Condition	
Special 2%01s None	TM or Para	Condition Description V13 vent valve on clean work surf ace.
Supplies Solvent, dry cleaning, Item 57, Appendix C Oil, lubricating, Item 47, Appendix C	Special Environmental Conditions None	
Personnel Required MOS 63W, Wheel vehicle repairer (2)	General Safety Instructions None	
	Level of Maintenance General Support	

a. Disassembly.




WARNING

Valve is spring loaded. Spring must be compressed then released slowly while removing slotted washer or serious injury may result.


- (1) Matchmark socket (1) and shaft (2). Remove socket from shaft.
- (2) Remove nut (3) from shaft (2).
- (3) Soldier A compresses plate (4) and spring (5) while Soldier B removes slotted washer (6) from shaft (2).
- (4) Release tension and remove plate (4) and spring (5) from shaft (2).

M978 Tanker Maintenance Procedures Instructions (Cent)



TA1 90721

- (5) Remove three screws (7) and poppet cover (8).
- (6) Remove screw (9) from slotted washer (10) and slotted washer from shaft (2).
- (7) Remove shaft (2) from poppet (11).
- (8) Remove preformed packing (12) from shaft (2).



TA190722

- (9) Remove poppet (11) from valve body (13).

22-20. VI 3 VENT VALVE REPAIR (CONT).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.


- (2) Dry metal parts with compressed air.
- (3) Inspect all parts for damage.
- (4) Replace damaged parts.

c. Assembly.




TA190723

- (1) Position poppet (1) on valve body (2).
- (2) Lubricate preformed packing (3) with oil and install on shaft (4).
- (3) Install shaft (4) in poppet (1).
- (4) Position slotted washer (5) on shaft (4) and install screw (6).
- (5) Install poppet cover (7) on poppet (1) with three screws (8).



TA190724

M978 Tanker Maintenance Procedures Instructions (Cent)



TA190725

- (6) Position spring (9) and plate (10) on shaft (4).
- (7) Soldier A installs slotted washer(11) and nut (12) while Soldier B compresses plate (10) and spring (9).
- (8) Aline matchmarks and install socket (13) on shaft (4).

cf. Follow-on Maintenance. None.

END OF TASK

22-21. **V14** PILOT VALVE REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models
M978

Test Equipment
None

Special Tools
None

Supplies
Solvent, dry cleaning, Item 57, Appendix C
Oil, lubricating, Item 47, Appendix C

Personnel Required
MOS 63W, Wheel vehicle repairer

References
None

Equipment Condition
TM or Para

Condition Description
V14 pilot valve on clean work surface.

Special Environmental Conditions
None

General Safety Instructions

None

Level of Maintenance
General Support

122-21. V14 PILOT VALVE REPAIR (CONT).

- a. Disassembly.
 (1) Remove six screws (1) and washers (2) from cover (3).
 (2) Remove cover (3) and diaphragm (4) from fitting (5).

CAUTION

Release spring tension slowly to prevent parts from scattering and being lost.

- (3) Remove retaining ring (6) from poppet (7) and remove poppet from fitting (5).
 (4) Remove washer (8) and spring (9) from fitting (5).

- b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with dry cleaning solvent.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with clean cloth or compressed air.
 (3) Inspect all metal parts for bends, breaks, cracks, and sharp edges.
 (4) Replace damaged parts.

- c. Assembly.

- (1) Install poppet (7) in fitting (5).
 (2) Apply thin coat of oil to spring (9) and install on poppet (7).


CAUTION

Keep pressure on spring until retaining ring is installed to prevent parts from scattering and being lost.

- (3) Install washer (8) and retaining ring (6) on poppet (7).
 (4) Install diaphragm (4) and cover (3) with six washers (2) and screws (1).

- d. Follow-on Maintenance. None.

END OF TASK



TA190346

M978 Tanker Maintenance Procedures Instructions (Cent)

22-22. VI 8 BULK DELIVERY VALVE REPAIR.

This task covers:

- | | |
|------------------------|--------------------------|
| a. Disassembly | c. Assembly |
| b. Cleaning/Inspection | d. Follow-on Maintenance |

INITIAL SETUP

MoWs
M978

Test Equipment
None

Special Tools
None

Supplies
Oil, lubricating, Item 47, Appendix C
Solvent, dry cleaning, Item 57, Appendix C

Personnel Required
MOS 63W, Wheel vehicle repairer

References
None

Equipment Condition
TM or Para

Condition Description
V18 bulk delivery valve on clean work surface.

Special Environmental Conditions
None

General Safety Instructions
None

Level of Maintenance
General Support


a. Disassembly.

CAUTION


Valve must be in open position for proper removal of valve parts and to prevent equipment damage.

- (1) Set handle (1) to OPEN position.

- (2) Remove screw (2), washer (3), handle (1), and washer (4) from stem (5).



TA190869



TA1 90870

22-22. VI 8 BULK DELIVERY VALVE REPAIR (CONT).

- (3) Remove two nuts (6) and screws (7) from upper housing (8) and lower housing (9).
- (4) Remove upper housing (8) and lower housing (9) from body and liner (10).

NOTE

Preformed packing and stem may stay in body during removal.

- (5) Remove preformed packing (11) from stem (5).
- (6) Remove stem (12) from lower housing (9).
- (7) Remove preformed packing (13) from stem (12).

b. Cleaning/Inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (1) Clean all metal parts with dry cleaning solvent.

WARNING


Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with compressed air.
- (3) Inspect all metal parts for bends, breaks, cracks, and sharp edges.
- (4) Replace damaged parts.

c. Assembly.



TA190872




TA190873

CAUTION


Body and liner disk must be in open position for proper installation of valve and to prevent equipment damage.

- (1) Move disk (1) in body and liner (2) to open position.

M978 Tanker Maintenance Procedures Instructions (Cent)



- (2) Install preformed packing (3) on stem (4).
- (3) Install stem (4) in lower housing (5).
- (4) Install preformed packing (6) on stem (7).
- (5) Lubricate stems (4 and 7) with oil and position upper housing (8) and lower housing (5) on body and liner (2).
- (6) Install two screws (9) and nuts (10) in upper housing (8) and lower housing (5).



- (7) Install washer (11), handle (12), washer (13), and screw (14) on stem (7).
- d. Follow-on **Maintenance**. None.

END OF TASK

M978 Tanker Maintenance Procedures Instructions (Cent)

22-23. V19JETLEVEL SENSOR REPAIR.

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models
M978

References
None

Test Equipment
None

Equipment Condition

TM or Para	Condition Description
	V 19 jet level sensor on clean work surface.

Special Tools
None

Supplies
Solvent, dry cleaning, Item 57, Appendix C


Special Environmental Conditions
None

Personnel Required
MOS 63W, Wheel vehicle repairer

General Safety Instructions
None


Level of Maintenance
General Support

a. Disassembly.



- (1) Remove cover (1) from sensor body (2).
- (Z) Remove four screws (3), lockwashers (4), and washers (5) from PRECHECK can (6).

M978 Tanker Maintenance Procedures Instructions (Cent)



TA190341

(3) Note OUTLET end and remove sensor body (2) and deflector (7) from collector can (8).

(4) Remove collector can (8) from PRECHECK can (6).

(5) Remove plug (9) from collector can (8).

(6) Remove two plugs (10) from collector can (8).

(7) Remove plug (11) from PRECHECK can (6).

b. Cleaning/inspection.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

(1) Clean all parts with dry cleaning solvent.


WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

(2) Dry parts with compressed air.

(3) Inspect all parts for damage.

(4) Replace damaged parts.





TA1 90342

22-23. V19 JET LEVEL SENSOR REPAIR (CONT).

c. Assembly.

- (1) Install plug (1) in PRECHECK can (2).
- (2) Install plug (3) and two plugs (4) in collector can (5).
- (3) Position collector can (5) in PRECHECK can (2).




NOTE

- Outlet end of sensor body must be positioned on OUTLET end of collector can.
- (4) Position deflector (6) and sensor body (7) in collector can (5).

M978 Tanker Maintenance Procedures Instructions (Cont)

- (5) Aline screw holes and install four washers (8) lockwashers (9) and screws (10) in PRECHECK can (2).
- (6) Install cover (11) on sensor body (7).



TA190345

d. Follow-on Maintenance. None.

END OF TASK

Section VII. FUEL SERVICE NOZZLE

22-24. FUEL SERVICE NOZZLE REPAIR.		
This task covers:		
a. Disassembly	c. Assembly	
b. Cleaning/Inspection	d. Follow-on Maintenance	
INITIAL SETUP		
Models M978	References None	
Test Equipment None	Equipment Condition	
Special Tools None	<i>TM or Para</i>	<i>Condition Description</i> Fuel service nozzle assembly on clean work surface.
Supplies Solvent, dry cleaning, Item 57, Appendix C Compound, sealing, pipe thread, Item 29, Appendix C	Special Environmental Conditions None	
Personnel Required MOS 63W, Wheel vehicle repairer	General Safety Instruction None	
	Level of Maintenance Direct Support	

M978 Tanker Maintenance Procedures Instructions (Cont)


22-24. FUEL SERVICE NOZZLE REPAIR (CONT).

a. *Disassembly.*

NOTE

There are two types of fuel nozzle assemblies.
 For Model A, perform steps (1) through (6).
 For Model B, perform steps (7) through (12).

- (1) Remove cap (1) from nozzle body (2).
- (2) Remove preformed packing (3), helical spring (4), disk and poppet (5), and stem (6).
- (3) Remove spring retainer (7).
- (4) Remove gland (8), packing retainer (9), and preformed packing (10).
- (5) Remove tube (11) and vane (12) from nozzle body (2).
- (6) Drive out spring pin (13) and remove lever (14).



M978 Tanker Maintenance Procedures Instructions (Cont)

- (7) Remove cap (15) from nozzle body (16).
- (8) Remove spring (17), top piece (18), disk (19), and washer (20).
- (9) Remove lower poppet subassembly (21) and disc holder (22).
- (10) Remove dashpot cylinder (23) and plunger (24).
- (11) Remove stem (25), packing spring (26), and packings (27) and (28).
- (12) Remove push nut (29), pin (30), and lever (31).

b. Cleaning/Inspection

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts of fuel nozzle with dry cleaning solvent.
- (2) Inspect all threaded parts for stripped threads or mashed ridges and cracks.
- (3) Inspect valve seat of nozzle body for excessive wear and ridges.
- (4) Inspect valve spring for cracks, breaks, and kinks.
- (5) Inspect disk and poppet for dents and other visible damage.
- (6) Inspect stem for burrs and other visible damage.
- (7) Replace all damaged parts.

c. Assembly.

NOTE

There are two types of fuel nozzle assemblies. For Model A, perform steps (1) through (5). For Model B, perform steps (6) through (11).

- (1) Install lever (31) and spring pin (30) in nozzle body (2).
- (2) Install vane (12) and tube (11) in nozzle body (2).


NOTE

Do not tighten spring retainer on installation.

- (3) Install preformed packing (10), packing retainer (9), gland (8), and spring retainer (7) in nozzle body (2).
- (4) Install stem (6) and tighten spring retainer (7).
- (5) Install disk poppet (5), helical spring (4), preformed packing (3), and cap (1).
- (6) Install lever (31), pin (30), and push nut (29) in nozzle body (16).
- (7) Install packings (28) and (27), packing spring (26), and stem (25).
- (8) Install plunger (24) and dashpot cylinder (23).
- (9) Install disc holder (22) and lower poppet subassembly (21).
- (10) Install washer (20), disk (19), top piece (18), and spring (17).
- (11) Apply thin coat of antiseize lubricant on cap (15) threads and install cap in nozzle body (16).

d. Follow-on Maintenance. None.

END OF TASK



MODEL B

M978 Tanker Maintenance Procedures Instructions (Cont)

22-25. MANHOLE COVER REPAIR (MODEL B).

This task covers:

- a. Disassembly
- b. Cleaning/Inspection
- c. Assembly
- d. Follow-on Maintenance

INITIAL SETUP

Models

M978

References

None

Test Equipment

None

Equipment Condition

TM or Pam Condition Description
 TM 9-2320-279-20 Manhole cover on clean work surface.

Special Tools

None

Special Environmental Conditions

None

Supplies

Solvent, drycleaning, Item 57, Appendix C
 Sealant, pipe, Teflon, Item 55.1, Appendix C

General Safety Instructions

None


Personnel Required

MOS 63W, Wheel vehicle repairer (2)

Level of Maintenance


General Support

a. Disassembly.



- (1) Remove vent assembly (1) and gasket (2) from fill cover (3).
- (2) Remove gasket (4) from fill cover (3).

M978 Tanker Maintenance Procedures Instructions (Cont)



- (3) Remove plug (5) from closure assembly (6).

WARNING

Use extreme care when compressing, releasing, removing, or installing springs. Springs are under tension and can act as projectiles when released. Ensure proper eye protection is worn to prevent injury to personnel.

- (4) While Soldier A holds screw (7), Soldier B removes nut (8), lockwasher (9), and fill cover (10) from closure assembly (6).
 (5) Remove spring (11) and screw (7) from closure assembly (6).

b. Cleaning/Inspection.**WARNING**

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (1) Clean all metal parts with drycleaning solvent.

WARNING


Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment, goggles, shield, and gloves.

- (2) Dry metal parts with compressed air.
 (3) Inspect each part for damage.
 (4) Replace damaged parts.

M978 Tanker Maintenance Procedures Instructions (Cont)

22-25. MANHOLE COVER REPAIR (MODEL B) (CONT).

c. Assembly.



- (1) Position spring (1) on closure assembly (2) with screw (3)


WARNING

Use extreme care when compressing, releasing, removing, or installing springs. Springs are under tension and can act as projectiles when released suddenly. Ensure proper eye protection is worn to prevent injury to personnel.

- (2) While Soldier A holds screw (3), install fill cover (4) on closure assembly (2) with lockwasher (5) and nut (6).
- (3) Install plug (7) on closure assembly (2).
- (4) Install gasket (8) on fill cover (4).
- (5) Install vent assembly (9) with gasket (10) on fill cover (4).

d. Follow-on Maintenance.

- (1) Install manhole cover (TM 9-2320-279-20).
- (2) Adjust manhole cover pressure (TM 9-2320-279-20).



END OF TASK

CHAPTER 23 SPECIAL PURPOSE KIT INSTALLATION

Contents	Para	Page
General	23-1	23-1
Arctic Heater Kit Initial Installation	23-2	23-1
Machine Gun Ring Kit Initial Installation	23-3	23-25
M-16 Rifle Mount Kit Initial Installation	23-4	23-31
Radio Kit Initial Installation	23-5	23-33
Gas Particulate Filter Unit (GPFU) Kit Initial Installation	23-6	23-40
Decontamination Kit Initial Installation	23-7	23-49
M-8 Chemical Alarm Kit Initial Installation	23-8	23-51
Shipping and Storage Containers, Engine, Transmission, and Transfer Case Packing and unpacking	23-9	23-59
Shipping and Storage Containers, Engine, Transmission, and Transfer Case Service and Repair	23-10	23-67
Engine, Preparation for Shipping and Storage Container	23-11	23-74
Transmission, Preparation for Shipping and Storage Container	23-12	23-79

Section I. INTRODUCTION


23-1. GENERAL. This chapter covers initial installation of special purpose kits. Subassemblies and parts which must be removed before the kits can be installed will be referenced to other paragraphs or chapters of this manual or TM 9-2320-279-10 or TM 9-2320-279-20.

Section II. ARCTIC HEATER KIT Special Purpose Kit Installation Instructions


23-2. ARCTIC HEATER KIT INITIAL INSTALLATION.	
This task covers:	
a. Sheet Metal Preparation	c. Follow-on Maintenance
b. Initial Installation	
INITIAL SETUP	<i>References</i>
<i>Models</i>	None
All	<i>Equipment Condition</i>
<i>Test Equipment</i>	<i>TM or Para</i> <i>Condition Description</i>
None	TM 9-2320-279-10 Shut off engine.
<i>Special Tools</i>	TM 9-2320-279-10 Spare tire removed.
None	TM 9-2320-279-10 Engine cover open.
<i>Supplies</i>	TM 9-2320-279-10 Engine side panels removed.
Adhesive, Item 5.3, Appendix C	Para 6-2 Radiator and engine block drained.
Adhesive, Item 5.4, Appendix C	Para 7-92 Battery box removed.
Compound, sealing, pipe thread, Item 28.1, Appendix C	<i>Special Environmental Conditions</i>
Tags, identification, Item 60, Appendix C	None
Ties, cable, plastic, Item 65, Appendix C	<i>General Safety Instructions</i>
<i>Personnel Required</i>	None
MOS 63W, Wheel vehicle repairer (2)	<i>Level of Maintenance</i>
	Direct Support

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).

a. Sheet Metal Preparation




- (1) Remove six screws (1) and heater compartment cover (2).
- (2) Remove PTO indicator light assembly and switch from heater compartment cover (2) (TM 9-2320-279-20).
- (3) If installed, remove chemical alarm switch from heater compartment cover (2) (TM 9-2320-279-20).
- (4) If installed, remove gas particulate switch from heater compartment cover (2) (TM 9-2320-279-20).
- (5) Remove utility outlet from heater compartment cover (2) (TM 9-2320-279-20).
- (6) Drill four 0.094 in. (2.388 mm) holes in heater compartment cover (2).




- (7) Drill 0.50 in. (12.70 mm) hole in heater compartment cover (2).
- (8) Drill two 0.75 in. (19.05 mm) holes.

Special Purpose Kit Installation Instructions (Cont)



(9) Drill two 0.34 in. (8 mm) holes in left front fender (3).



(10) Drill six 0.28 in. (7 mm) holes in left front fender (3).

Special Purpose Kit Installation Instructions (Cont)


23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).

b. initial Installation.


NOTE

Install plastic cable ties as required.


- (1) Remove alternator belts and fan belts (TM 9-2320-279-20).
- (2) Install arctic kit alternator belts and fan belts (TM 9-2320-279-20).
- (3) Remove battery box (TM 9-2320-279-20).
- (4) Install arctic kit battery box (TM 9-2320-279-20).
- (5) Install battery box (1) with six screws (2), washers (3), and locknuts (4).




- (6) Remove locknut (5), screw (6), and rubber hood hook (7) from bracket (8).
- (7) Remove screw (9) and install bracket (8) with screw.



Special Purpose Kit Installation Instructions (Cont)



- (8) Remove two locknuts (10), screws (11), and rubber hood hooks (7).
- (9) Install two brackets (12) with two screws (13), lockwashers (14), and nuts (15).
- (10) Install two rubber hood hooks (7) with two screws (11) and locknuts (10).




- (11) Install two batteries (16).
- (12) Install four screws (17) and washers (18).
- (13) Install two holddowns (19) on four screws (17) with four washers (20) and locknuts (21).
- (14) Install jumper cable (22) and tighten two nuts (23).


Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).


- (15) Remove two nuts (24) and lockwashers (25).
- (16) Install two cables (26) and (27) with two lockwashers (25) and nuts (24).




- (17) Install two terminals (28) on cables (26) and (27) with screws (29) and nuts (30).
- (18) Install two cables (26) and (27) and tighten nuts (31).



Special Purpose Kit Installation Instructions (Cont)




- (19) Install three hood brackets (32) on battery box cover (33) with six screws (34), washers (35), and locknuts (36).
- (20) Install battery box cover (33) with three rubber hood hooks (7).
- (21) Install exhaust pipe (37) within right side frame rail and attach to battery box (38) with clamp (39).




Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).



- (22) Remove hose (40) from elbow (41).
- (23) Remove and discard elbow (41) and bushing (42) from engine block (43).

Special Purpose Kit Installation Instructions (Cont)


**WARNING**

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (24) Apply pipe thread sealing compound to threads of nipple (44) and install nipple and tee (45) in engine block (43).
- (25) Apply pipe thread sealing compound to threads of adapter (46) and install in tee (45).
- (26) Install 112 in. (2845 mm) hose (47) on adapter (46) with clamp (48).
- (27) Apply pipe thread sealing compound to threads of adapter (49), in hose (40), and install adapter in tee (45).
- (28) Remove and discard plug (50) from thermostat housing (51).
- (29) Apply pipe thread sealing compound to threads of adapter (52) and install in thermostat housing (51).
- (30) Install 92 in. (2337 mm) hose (53) on adapter (52) with clamp (54).
- (31) Route hoses (47) and (53) towards front of vehicle using plastic cable ties to secure hoses.

Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).




- (32) While Soldier A holds skid plate grille (55) to skid plate (56), Soldier A removes 16 locknuts (57), washers (58), and screws (59).
- (33) Soldier A and Soldier B remove skid plate grille (55).

NOTE

These two bolt holes will be used to mount bracket that supports coolant pump.

- (34) Remove and discard two nuts (60) and screws (61) from bottom of skid plate (56) nearest right side of frame section (62).
- (35) Modify skid plate grille (55) as follows:
 - (a) Cut a 17.0 in. (431.80 mm) by 18.50 in. (469.90 mm) opening in skid plate grille (55).
 - (b) Drill three 0.281 in. (7.14 mm) holes in skid plate grille (55).
 - (c) Break all sharp edges.



Special Purpose Kit Installation Instructions (Cont)


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


NOTE

Ensure that surface of bracket is clean.

- (37) Apply adhesive (Item 5.3, Appendix C) to rubber (63) and install on bracket (64). Apply hand pressure until adhesive sets.
- (38) Install bracket (64) with screw (65), plate (66), and nut (67).
- (39) Install screw (68) and nut (69).




- (40) Apply pipe thread sealing compound to threads of elbows (70) and (71).
- (41) Install elbow (70), valve (72), and elbow (71) in coolant pump (73).
- (42) Apply pipe thread sealing compound to threads of elbow (74) and install in coolant pump (73).




Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).

- (43) Install coolant pump (73) as follows:
 - (a) Position coolant pump (73) on bracket (64).



- (b) Install wire (75) on coolant pump (73) with lockwasher (76) and nut (77).
 - (c) Install wire (78) on coolant pump (73) with lockwasher (79) and nut (80).



Special Purpose Kit Installation Instructions (Cont)



WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE

Ensure that surface of bracket is clean.

- (d) Apply adhesive (Item 5.3, Appendix C) to rubber (81) and install on bracket (82). Apply hand pressure until adhesive sets.
- (e) Install bracket (82) with two screws (83) and nuts (84). Do not tighten nuts.
- (f) Install hose (53) on elbow (71) with clamp (85).
- (g) Install 8 in. (203 mm) hose (86) on elbow (74) with clamp (87).
- (h) Tighten nuts (84).




Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).


NOTE

Quick release valve is mounted to crossmember only on Model M984E1.

- (44) Remove two nuts (88), screws (89), and quick release valve (90) from crossmember (91).
- (45) Install bracket (92) and quick release valve (90) with two screws (89) and nuts (88).
- (46) Install clamp (93) on bracket (92) with screw (94) and nut (95).
- (47) Install clamp (96) on bracket (82) with screw (97), spacer (98), and nut (99).






- (48) Install water jacket (100) as follows:
 - (a) Position water jacket (100) in two clamps (93) and (96).
 - (b) Install screw (101) in clamp (96). Do not tighten screw.
 - (c) Install safety chain (102) on a screw (101) with washer (103) and nut (104).
 - (d) Install hose (86) on water jacket (100) with clamp (105).
 - (e) Install exhaust pipe (37) on water jacket (100) with clamp (106).



Special Purpose Kit Installation Instructions (Cont)

- (f) Install screw (107) in clamp (93).
Do not tighten screw.
- (g) Install hose (47) on water jacket (100) with clamp (108).
- (h) Tighten screws (101), (107), and
nut (104).
- (i) Install drain plug (109) with
washer (110) in water jacket (100).




- (49) Push wire (78) up through hole (111).


Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).

- (50) Soldier A and Soldier B position skid plate grille (55) on skid plate (56).
- (51) While Soldier A holds skid plate grille (55) in position, Soldier B installs 13 screws (59), washers (58), and locknuts (57).



- (52) Install two pins (112) on chains (113).
- (53) Install two chains (113) on stiffener (114) with two screws (115), washers (116), and locknuts (117).
- (54) Install stiffener (114) with three screws (118), lockwashers (119), and nuts (120).
- (55) Install hinge (121) on skid plate grille (55) with three screws (122), washers (123), and locknuts (124).



Special Purpose Kit Installation Instructions (Cont)


WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE

Ensure that rubber mounting surface of door is clean.


- (56) Apply adhesive (Item 5.4, Appendix C) to rubber (125) and install on door (126). Apply hand pressure until adhesive sets.
- (57) Install door (126) on hinge (121) with four screws (127), lockwashers (128), and nuts (129).
- (58) Ensure that valve (72) is in open position.




Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).

- (59) Install utility outlet on heater compartment cover (130) (TM 9-2320-279-20).
- (60) If removed, install gas particulate switch on heater compartment cover (130) (TM 9-2320-279-20).
- (61) If removed, install chemical alarm switch on heater compartment cover (130) (TM 9-2320-279-20).
- (62) Install PTO indicator light assembly and switch on heater compartment cover (130) (TM 9-2320-279-20).
- (63) Install data plate (131) on heater compartment cover (130) with four screws (132).
- (64) Install receptacle (133) with washer (134) and nut (135).
- (65) Install wire (136) in receptacle (133) and tighten screw (137).




- (66) Remove shield (138).
- (67) Remove lens (139) from housing (140).
- (68) Remove force ring (141) from lens.
- (69) Install housing (140) in heater compartment cover (130) with nut (142).
- (70) Install force ring (141) in lens (139) and install lens in housing (140).
- (71) Install shield (138).
- (72) Attach ground wire (143) to PTO ground wire No. 35 with electrical butt connector (144).




Special Purpose Kit Installation Instructions (Cont)

- (73) Remove one nut (145) from coolant pump switch (146). Adjust remaining nut to provide proper height of switch when installed in heater compartment cover (130).
- (74) Install coolant pump switch (146) in heater compartment cover (130) with nut (145).
- (75) Remove two screws (147) from coolant pump switch (146).
- (76) Install three wires (78), (136), and (148) on output side of coolant pump switch (146) with screw (147).
- (77) Install wire (149) on input side of coolant pump switch (146) with remaining screw (147).




- (78) Remove nut (150) and washer (151) from circuit breaker No. 4 (152).
- (79) Install wire (149) on circuit breaker No. 4 (152) with washer (151) and nut (150).




Special Purpose Kit Installation Instructions (Cont)

23-2. ARCTIC HEATER KIT INITIAL INSTALLATION (CONT).

- (80) Install heater compartment cover (130) with six screws (153).
- (81) Fill cooling system (TM 9-2320-279-20).
- (82) Operate coolant pump (73) (TM 9-2320-279-10) to distribute coolant throughout arctic heater kit.
- (83) Check and till coolant system (TM 9-2320-279-20).



- (84) Place valve (72) in closed position.
- (85) Close door (126) and secure with two pins (112).



c. Follow-on Maintenance.

- (1) Install battery box (para 7-92).
- (2) Install engine side panels (TM 9-2320-279-10).
- (3) Close engine cover (TM 9-2320-279-10).
- (4) Stow spare tire (TM 9-2320-279-10).


END OF TASK

Special Purpose Kit Installation Instructions (Cont)

Section III. ARMAMENT EQUIPMENT

23-3. MACHINE GUN RING KIT INITIAL INSTALLATION.	
This task covers: a. Initial Installation b. Follow-on Maintenance	
INITIAL SETUP	
<i>Models</i> All	<i>Equipment Condition</i> <i>TM or Para</i> <i>Condition Description</i> TM 9-2320-279-10 Shut off engine. TM 9-2320-279-10 Spare tire removed.
<i>Test Equipment</i> None	<i>Special Environmental Conditions</i> None
<i>Special Tools</i> None	<i>General Safety Instructions</i> None
<i>Supplies</i> Adhesive-sealant, silicone, Item 6, Appendix C	<i>Level of Maintenance</i> Direct Support
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer	
<i>References</i> None	

a. Initial Installation.




(1) Remove 34 screws (1) and right roof panel (2).

TA187905

Special Purpose Kit Installation Instructions (Cont)

23-3. MACHINE GUN RING KIT INITIAL INSTALLATION (CONT).




TA187906

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


- (2) Apply silicone adhesive-sealant to roof panel (3).
- (3) Install cab gunner roof panel (4) with 34 screws (1).



TA187907

- (4) Install cover (5) on hatch (6).

Special Purpose Kit Installation Instructions (Cont)




(5) Install gun ring rear support (7) on tire carrier (8) with 12 screws (9), washers (10), and locknuts (11).

(6) Install front support channel (12) to supports (13 and 14) with four screws (15), washers (16), lockwashers (17), and nuts (18).

NOTE

Two nuts, washers, and screws must be removed from the front of the skid plate before positioning support assembly on skid plate. These two nuts, washers, and screws will be used to install the support assembly. Other screws for installation are provided with the kit.




- (7) Remove two nuts (19), washers (20), and screws (21).
- (8) Using suitable lifting device, position support assembly (12) on vehicle.
- (9) Install support assembly (12) with four screws (21), washers (20), and nuts (19).
- (10) Install four screws (22) with washers (23) and nuts (24).

TA357279


Special Purpose Kit Installation Instructions (Cont)

23-3. MACHINE GUN RING KIT INITIAL INSTALLATION (CONT).

- (11) Using suitable lifting device, position machine gun ring (25) on gun ring rear support (7) and support assembly (12).
- (12) Install machine gun ring (25) to support assembly (12) with eight screws (26), washers (27), and locknuts (28). Do not tighten.
- (13) Install machine gun ring (25) to gun ring rear support (7) with four screws (26), washers (27), and locknuts (28).
- (14) Tighten 12 screws (26) and locknuts (28).




- (15) Remove eight screws (29) and heater compartment cover (30).




Special Purpose Kit Installation Instructions (Cont)

- (16) Install support (31) to bulkhead (32) with five screws (33), washers (34), and locknuts (35).




TA187914

- (17) Install heater compartment cover (30) with eight screws (29).



TA187915




TA187916

- (18) Remove screw (36) and lockwasher (37).
 (19) Install platform holddown bracket (38) with screw (36) and lockwasher (37).


Special Purpose Kit Installation Instructions (Cont)

23-3. MACHINE GUN RING KIT INITIAL INSTALLATION (CONT).

(20) Install operator platform (39) in stowed position with S-hook (40) in slot (41), strap (42) over operator platform, and S-hook (43) in platform holddown bracket (38).



TA187918



TA187920

(21) Install operator platform (39) in operating position by inserting tab (44) in slot (41) with leg (45) down.

b. *Follow-on Maintenance.* Stow spare tire (TM 9-2320-279-10).

END OF TASK

Special Purpose Kit Installation Instructions (Cont)

23-4. M-16 RIFLE MOUNT KIT INITIAL INSTALLATION.

This task covers:

- a. Initial Installation
- b. Follow-on Maintenance

INITIAL SETUP

Models

All

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

None

Equipment Condition

TM or Para *Condition Description*
 TM 9-2320-279-10 Shut off engine.

Special Environmental Conditions

None


General Safety Instructions

None

Level of Maintenance

Direct Support

a. Initial Installation.




TA187899


- (1) Remove two screws (1), lockwashers (2), and washers (3).
- (2) Install bracket (4) with two screws (1), lockwashers (2), and washers (3).

Special Purpose Kit Installation Instructions (Cont)

23-4. M-16 RIFLE MOUNT KIT INITIAL INSTALLATION (CONT).




(3) Install support (5) with two screws (6), lockwashers (7), and nuts (8).



(4) Install catch mount (9) on bracket (10) with two screws (11), lockwashers (12), and nuts (13).

Special Purpose Kit Installation Instructions (Cont)

- (5) Remove two screws (14), lockwashers (15), and washers (16).
- (6) Install catch mount assembly (17) with two screws (14), lockwashers (15), and washers (16).



TA187904

b. Follow-on Maintenance. None.

END OF TASK


Section IV. RADIO

23-5. RADIO KIT INITIAL INSTALLATION.	
This task covers:	
<ul style="list-style-type: none"> a. Initial Installation b. Follow-on Maintenance 	
INITIAL SETUP	
<i>Models</i>	<i>Equipment Condition</i>
All	<i>TM or Para</i> <i>Condition Description</i>
<i>Test Equipment</i>	TM 9-2320-279-10 Shut off engine.
None	TM 9-2320-279-10 Spare tire removed.
<i>Special Tools</i>	TM 9-2320-279-20 Batteries disconnected.
None	<i>Special Environmental Conditions</i>
<i>Supplies</i>	None
Ties, cable, plastic, Item 65, Appendix C	<i>General Safety Instructions</i>
<i>Personnel Required</i>	None
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>
<i>References</i>	Direct Support
None	

Special Purpose Kit Installation Instructions (Cont)

23-5. RADIO KIT INITIAL INSTALLATION (CONT).

a. Initial Installation.




TA187922

- (1) Install antenna (1) to mount (2) with four screws (3), lockwashers (4), and nuts (5).

NOTE

Use top four screw holes in mount to attach mount.


- (2) Install mount (2) with four screws (6), eight lockwashers (7), and four nuts (8).
- (3) Remove plug (9).



TA187923


Special Purpose Kit Installation Instructions (Cont)

- (4) Install grommet (10). Pull two cables (11) through grommet.
- (5) Connect two connectors (12) and install cables (11) using plastic cable ties.




TA187924

- (6) Remove 11 screws (13) and heater compartment covers (14 and 15).
- (7) Remove six plugs (16).



TA187925


- (8) Install grommet (17). Push cable (18) down through grommet.




TA187926

Special Purpose Kit Installation Instructions (Cont)

23-5. RADIO KIT INITIAL INSTALLATION (CONT).





- (9) Remove nut (19) and lockwasher (20) from circuit breaker No. 4 (21).
- (10) Install white wire (22) and red wire (23) on circuit breaker No. 4 (21) with lockwasher (20) and nut (19).



- (11) Remove screw (24).
- (12) Install green ground wire (25) and black ground wire (26) with screw (24).

Special Purpose Kit Installation Instructions (Cont)

- (13) Position mount (27) and connect connector (28).





- (14) Lift heater compartment cover (14) and install mount (27) with five screws (29), lockwashers (30), and nuts (31).
 (15) Install heater compartment covers (14 and 15) with 11 screws (13).

Special Purpose Kit Installation Instructions (Cont)


23-5. RADIO KIT INITIAL INSTALLATION (CONT).

- (16) Install radio (32) and tighten two wingnuts (33).
- (17) Connect two antenna leads (34).




- (18) Remove four plugs (35) from heater compartment cover (36).
- (19) Remove eight screws (37) and lift heater compartment cover (36).

Special Purpose Kit Installation Instructions (Cont)



- (20) Install security unit mount (38) with four screws (39), lockwashers (40), and nuts (41).
- (21) Install data plate (42).

- (22) Install heater compartment cover (36) with eight screws (37).
- (23) Install security unit and tighten clamps (43).



b. Follow-on Maintenance.

- (1) To complete installation of kit, refer to TM 11-5820-498-12 and TM 11-5820-498-35.
- (2) Connect batteries (TM 9-2320-279-20).
- (3) Stow spare tire (TM 9-2320-279-10).


END OF TASK

Special Purpose Kit Installation Instructions (Cont)

Section V. CHEMICAL, BIOLOGICAL, AND RADIOLOGICAL (CBR) EQUIPMENT

23-6. GAS PARTICULATE FILTER UNIT (GPFU) KIT INITIAL INSTALLATION.	
This task covers: a. Initial Installation b. Follow-on Maintenance	
INITIAL SETUP	
<i>Models</i> All	<i>References</i> None
<i>Test Equipment</i> None	<i>Equipment Condition</i> TM or Para <i>Condition Description</i> TM 9-2320-279-20 Batteries disconnected.
<i>Special Tools</i> None	<i>Special Environmental Conditions</i> None
<i>Supplies</i> Compound, sealing, pipe thread, Item 29, Appendix C	<i>General Safety Instructions</i> None
<i>Personnel Required</i> MOS 63W, Wheel vehicle repairer (2)	<i>Level of Maintenance</i> Direct Support




- a. *Initial Installation.*
 (1) Remove two plugs (1).
 (2) Remove 11 screws (2) and lift heater compartment covers (3 and 4).




TA168322

Special Purpose Kit Installation Instructions (Cont)

- (3) Remove nut (5) and lockwasher (6) from circuit breaker No. 4 (7).
- (4) Install wire (8) on circuit breaker No. 4 (7) with lockwasher (6) and nut (5).




- (5) Install circuit breaker (9) with two screws (10), lockwashers (11), and nuts (12).
- (6) Remove two screws (13) and lockwashers (14).
- (7) Install two wires (8 and 15) with screws (13) and lockwashers (14).
- (8) Install nut (16) and washer (17) on gas particulate switch (18).



Special Purpose Kit Installation Instructions (Cont)


23-6. GAS PARTICULATE FILTER UNIT (GPFU) KIT INITIAL INSTALLATION (CONT).



TA188327


- (9) Install gas particulate switch (18) and data plate (19) with washer (20) and nut (21) through bottom of heater compartment cover (4).
- (10) Install wire (15) on gas particulate switch (18) with lockwasher (22) and screw (23).

- (11) Install grommet (24) in heater compartment cover (4). Pull wire harness (25) through grommet.




TA188328

- (12) Install wire harness (25) on gas particulate switch (18) with lockwasher (26) and screw (27).




TA188329

Special Purpose Kit Installation Instructions (Cont)



TA188330

(13) Install heater compartment covers (3 and 4) with 11 screws (2).



TA188331

(14) Remove two screws (28) and domelight bracket (29).

(15) Install 8-in. (203 mm) ground wire (30) with lockwasher (31) and nut (32) on screw (33).

(16) Install 8-in. (203 mm) ground wire (34), 4-in. (102 mm) ground wire (35), lockwasher (36), and nut (37) on screw (38).

(17) Install domelight bracket (29) with two screws (28).

Special Purpose Kit Installation Instructions (Cont)

23-6. GAS PARTICULATE FILTER UNIT (GPFU) KIT INITIAL INSTALLATION (CONT).

NOTE

Left and right heaters are installed in the same way.

- (18) Soldier A holds and removes four screws (39) and washers (40) while Soldier B removes four nuts (41) and lockwashers (42).

CAUTION

Tighten screws evenly to avoid breaking heater leg.



- (19) Soldier A installs heater (43) with four washers (40), screws (39), and 4-in. (102 mm) ground wire (35), while Soldier B installs four lockwashers (42) and nuts (41).

- (20) Repeat step (18) for right side.

- (21) Soldier A installs heater (44) with four washers (40), screws (39), and 8-in. (203 mm) ground wire (30) while Soldier B installs four lockwashers (42) and nuts (41).


- (22) Soldier A holds and removes four screws (45) and washers (46) while Soldier B removes four nuts (47) and lockwashers (48) from center of rear cab wall.

- (23) Soldier A installs and holds four screws (45), bracket (49), and four washers (46) while Soldier B installs four lockwashers (48) and nuts (47).




Special Purpose Kit Installation Instructions (Cont)

- (24) Install wire harness (25) in two cushion clips (50). Install two screws (51) with two washers (52), 8-in. (203 mm) ground wire (34), cushion clips, lockwashers (53), and nuts (54).



TA188334

- (25) Install filter (55) and tighten clamps (56).




TA188335

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (26) Apply pipe thread sealing compound and install two plugs (57).
 (27) Apply pipe thread sealing compound and install two fittings (58).
 (28) Repeat steps (26) and (27) for right heater.



TA188336


Special Purpose Kit Installation Instructions (Cont)

23-6. GAS PARTICULATE FILTER UNIT (GPFU) KIT INITIAL INSTALLATION (CONT).


NOTE

Steps (29) and (30) are for right side heater only.

- (29) Loosen two screws (59).
- (30) Twist outlet port (60) towards front of cab to allow clearance for outlet hose. Tighten two screws (59).
- (31) Connect two wires (61 and 62) to wire harness (25).
- (32) Connect connector (63) to filter (55).




- (33) Remove caps (64) from filter (55).
- (34) Install 2-ft (0.6 m) air duct hose (65) and hose clamp (66) on quick release coupling (67).
- (35) Repeat steps (33) and (34) for 4-ft (1.2 m) air duct hose (68).
- (36) Install two air duct hoses (65 and 68) on filter (55).



Special Purpose Kit Installation Instructions (Cont)

- (37) Install air duct hose (68) on heater (43) with clamp (69).
- (38) Install air duct hose (65) on heater (44) with clamp (69).




TA188340

- (39) Install angle bracket (70) with screw (71).
- (40) Install connector (72) with retaining ring (73).
- (41) Install 9-ft (2.75 m) hose (74) on quick release coupling (75) with hose clamp (76).
- (42) Install quick release coupling (75) and orifice (77) on connector (72).

NOTE

Hose clip is installed behind driver's seat.


- (43) Install clip (78) on hose (74).



TA188341

Special Purpose Kit Installation Instructions (Cont)

23-6. GAS PARTICULATE FILTER UNIT (GPFU) KIT INITIAL INSTALLATION (CONT).




TA188342

- (44) Install angle bracket (79) on hose mounting (80) with screw (81), lockwasher (82), and nut (83).
- (45) Install connector (84) with retaining ring (85).
- (46) Install 6-ft (1.8 m) hose (86) on quick release coupling (87) with hose clamp (88).
- (47) Install quick release coupling (87) and orifice (89) on connector (84).

- (48) Install hose (74) on heater (43) with hose clamp (90).
- (49) Install hose (86) on heater (44) with hose clamp (90).

b. *Follow-on Maintenance.*
Connect batteries (TM 9-2320-279-20).

END OF TASK




TA188344

Special Purpose Kit Installation Instructions (Cont)

23-7. DECONTAMINATION KIT INITIAL INSTALLATION.	
<p>This task covers:</p> <ul style="list-style-type: none"> a. Initial Installation b. Follow-on Maintenance 	
INITIAL SETUP	
<i>Models</i>	<i>References</i>
All	None
<i>Test Equipment</i>	<i>Equipment Condition</i>
None	<i>TM or Para</i> <i>Condition Description</i>
<i>Special Tools</i>	TM 9-2320-279-10 Shut off engine.
None	<i>Special Environmental Conditions</i>
<i>Supplies</i>	None
None	<i>General Safety Instructions</i>
<i>Personnel Required</i>	None
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>
	Direct Support

a. Initial Installation.




(1) Install bracket (1) with two screws (2), lockwashers (3), and nuts (4).


Special Purpose Kit Installation Instructions (Cont)

23-7. DECONTAMINATION KIT INITIAL INSTALLATION (CONT).

(2) Install strap (5) through carrier (6).



TA188079




TA188080

(3) Install carrier (6) with four screws (7) and locknuts (8). Do not tighten.

(4) Install two spacers (9), four screws (10), washers (11), lockwashers (12), and nuts (13).

(5) Tighten screws (7 and 10).

Special Purpose Kit Installation Instructions (Cont)



(6) Install decontamination unit (14) and tighten strap (5).

b. Follow-on Maintenance. None.

END OF TASK

23-8. M-8 CHEMICAL ALARM KIT INITIAL INSTALLATION.

This task covers:

- a. Initial Installation
- b. Follow-on Maintenance

INITIAL SETUP

Models

All

Test Equipment

None

Special Tools

None

Supplies

None

Personnel Required

MOS 63W, Wheel vehicle repairer

References

TM 3-6665-225-12

Equipment Condition

<i>TM or Para</i>	<i>Condition Description</i>
TM 9-2320-279-20	Batteries disconnected.

Special Environmental Conditions

None

General Safety Instructions

None

Level of Maintenance


Direct Support

Special Purpose Kit Installation Instructions (Cont)


23-8. M-8 CHEMICAL ALARM KIT INITIAL INSTALLATION (CONT).

a. Initial Installation.


(1) Remove six plugs (1) from heater compartment covers (2 and 3).



(2) Install nut (4) and washer (5) on switch (6).




(3) Remove 11 screws (7) and lift heater compartment covers (3 and 8).




Special Purpose Kit Installation Instructions (Cont)

- (4) Install switch (6) and data plate (9) in heater compartment cover (3) with washer (10) and nut (11).



TA187989





TA187990

- (5) Remove eight screws (12) and lift heater compartment cover (2).

Special Purpose Kit Installation Instructions (Cont)


23-8. M-8 CHEMICAL ALARM KIT INITIAL INSTALLATION (CONT).

(6) Install grommet (13). Install ground wire (14) and wire (15) through grommet.




(7) Remove screw (16).
(8) Install ground wire (14) with screw (16).

Special Purpose Kit Installation Instructions (Cont)



TA187995

- (9) Remove nut (17) and lockwasher (18) from circuit breaker No. 4 (19).
- (10) Install wire (20) on circuit breaker No. 4 (19) with lockwasher (18) and nut (17).




TA187996

- (11) Install wire (20) and wire (15) on switch (6) with two lockwashers (21) and screws (22).


Special Purpose Kit Installation Instructions (Cont)

23-8. M-8 CHEMICAL ALARM KIT INITIAL INSTALLATION (CONT).

- (12) Install two heater compartment covers (3 and 8) with 11 screws (7).
- (13) Install detector mount (23) with four screws (24), lockwashers (25), and nuts (26) on heater compartment cover (2).




- (14) Install heater compartment cover (2) with eight screws (12).
- (15) Install detector (27) in detector mount (23) and tighten two wingnuts (28).




Special Purpose Kit Installation Instructions (Cont)

- (16) Install power input cable (29) on detector mount (23) with two cushion clips (30) and screws (31).
- (17) Connect power input cable connectors (32) to connector (33) and dummy connector (34) on detector mount (23).




TA188001

- (18) Install hanger (35) on bracket (36) with four screws (37), lockwashers (38), and nuts (39).



TA188002

- (19) Remove five screws (40).




TA188003

Special Purpose Kit Installation Instructions (Cont)

23-8. M-8 CHEMICAL ALARM KIT INITIAL INSTALLATION (CONT).

- (20) Install bracket (36) with five screws (40).
- (21) Install alarm (41) and tighten two clamps (42).




TA188005

- (22) Install red wire (43) on binding posts (44 and 45) and brown wire (46) on binding posts (47 and 48).

- b. Follow-on Maintenance.
 - (1) Connect batteries (TM 9-2320-279-20).
 - (2) Do startup and operations procedures (TM 3-6665-225-12).

END OF TASK



TA188006

Special Purpose Kit Installation Instructions (Cont)

23-9. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION AND TRANSFER CASE PACKING AND UNPACKING.

This task covers:

- | | |
|---------------------------------|-------------------------------|
| a. Upper Container Removal | f. Transmission Installation |
| b. Upper Container Installation | g. Transfer Case Removal |
| c. Engine Removal | h. Transfer Case Installation |
| d. Engine Installation | i. Follow-on Maintenance |
| e. Transmission Removal | |

INITIAL SETUP

<i>Models</i>	<i>Equipment Condition</i>	
All	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 23-11	Engine prepared for storage.
None	Para 23-12	Transmission prepared for storage.
<i>Special Tools</i>	<i>Special Environmental Conditions</i>	
None	None	
<i>Supplies</i>	<i>General Safety Instructions</i>	
None	None	
<i>Personnel Required</i>	<i>Level of Maintenance</i>	
MOS 63W, Wheel vehicle repairer	Direct Support	
<i>References</i>		
None		

a. Upper Container Removal.

NOTE


All upper containers are removed the same. Transmission has 22 screws. Transfer case has 20 screws.

- (1) Release air pressure at vent valve (1).
- (2) Remove 30 nuts (2), washers (3), and screws (4).

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (3) Attach suitable lifting device and remove upper container (5) from lower container (6).



TA476798

Special Purpose Kit Installation Instructions (Cont)

23-9. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION AND TRANSFER CASE PACKING AND UNPACKING (CONT).

b. Upper Container Installation.

WARNING


Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (1) Install upper container (1) on lower container (2).


NOTE

When tightening nuts use a crisscross pattern working around container.

- (2) Install 30 screws (3), washers (4), and nuts (5).
- (3) Tighten nuts (5) to 440 lb-in (48 N·m).



c. Engine Removal.



- (1) Remove four nuts (1), lockwashers (2), washers (3), and screws (4) from rear support (5).
- (2) Repeat step (1) for other side.
- (3) Remove two screws (6), washers (7), nuts (8), and lockwashers (9) from inner frame (10).


WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (4) Attach suitable lifting device to engine (11) and remove lower container (12).

Special Purpose Kit Installation Instructions (Cont)

- (5) Remove six screws (13), lockwashers (14), and support (5)
- (6) Repeat step (5) for other side.





d. Engine Installation.

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (1) Install support (1) with six lockwashers (2) and screws (3) to engine (4). Do not tighten.
- (2) Repeat step (1) for other side.




- (3) Align and install engine (4) in lower container (5).
- (4) Install two washers (6), screws (7), lockwashers (8), and nuts (9) in inner frame (10).
- (5) Install four screws (11), washers (12), lockwashers (13), and nuts (14).
- (6) Repeat step (5) for other side.
- (7) Tighten twelve screws (3) to 1000 lb-in. (112 N·m).
- (8) Tighten nuts (9 and 14) to 440 lb-in (48 N·m).

Special Purpose Kit Installation Instructions (Cont)


23-9. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION AND TRANSFER CASE PACKING AND UNPACKING (CONT).

e. Transmission Removal.



TA476804

- (1) Remove dipstick (1) from lower container (2).
- (2) Attach suitable lifting device to transmission (3).



TA476805


- (3) Remove four nuts (4), lockwashers (5), washers (6), and screws (7) from two forward mounts (8).
- (4) Remove two nuts (9), lockwashers (10), washers (11), and screws (12) from aft mount (13).

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (5) Remove transmission (3) from lower container (2) and place in suitable holding fixture.


Special Purpose Kit Installation Instructions (Cont)



TA476806

- (6) Remove four screws (14), lockwashers (15), and forward mount (8) from transmission (3).
- (7) Repeat step (6) for other side.
- (8) Remove two screws (16), lockwashers (17), and aft mount (13).

f. Transmission Installation.



TA476807


WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (1) Install aft mount (1) on transmission (2) with two lockwashers (3) and screws (4). Do not tighten.
- (2) Install forward mount (5) with four lockwashers (6) and screws (7). Do not tighten.
- (3) Repeat step (2) for other side.


Special Purpose Kit Installation Instructions (Cont)

23-9. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION AND TRANSFER CASE PACKING AND UNPACKING (CONT).



TA476808

- (4) Aline and install transmission (2) in lower container (8).
- (5) Install two screws (9), washers (10), lockwashers (11), and nuts (12) in aft mount (1).
- (6) Install four screws (13), washers (14), lockwashers (15), and nuts (16) in two forward mounts (5).
- (7) Tighten screws (4 and 7) to 1000 lb-in (112 Nm).
- (8) Tighten nuts (12 and 16) to 440 lb-in (48 Nm).




TA476809

- (9) Position dipstick (17) in lower container (8) and secure with ties.

Special Purpose Kit Installation Instructions (Cont)

g. Transfer Case Removal.



TA476810

NOTE


All transfer cases in storage containers have 1710 series yoke. 1810 series yoke must be installed on transfer case for M984E1.

- (1) Attach suitable lifting device to transfer case (1).
- (2) Remove eight nuts (2), lockwashers (3), washers (4), and screws (5) from four brackets (6).

WARNING

Keep out from under heavy parts. Falling parts may cause serious injury or death.

- (3) Remove transfer case (1) from lower container (7).
- (4) Remove two screws (8), lockwashers (9), and brackets (6).
- (5) Repeat step (4) for other three brackets



TA476811

Special Purpose Kit Installation Instructions (Cont)


23-9. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION AND TRANSFER CASE PACKING AND UNPACKING (CONT).

h. Transfer Case Installation.

NOTE


M984E1 transfer case has 1810 series yoke. 1710 series yoke must be installed before transfer case is placed in storage container.

- (1) Install bracket (1) with two lockwashers (2) and screws (3) on transfer case (4). Do not tighten.
- (2) Repeat step (1) for other three brackets.



TA476812

- (3) Align and install transfer case (4) in lower container (5) with eight screws (6), washers (7), lockwashers (8), and nuts (9).
- (4) Tighten nuts (9) to 440 lb-in (48 N·m).
- (5) Tighten screws (3) to 1000 lb-in (112 N·m).



TA476813

i. Follow-on Maintenance. None

END OF TASK

Special Purpose Kit Installation Instructions (Cont)


23-10. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION, AND TRANSFER CASE SERVICE AND REPAIR.																																					
<p>This task covers:</p> <table> <tr> <td>a. Service</td> <td>c. Assembly</td> </tr> <tr> <td>b. Disassembly</td> <td>d. Follow-on Maintenance</td> </tr> </table>		a. Service	c. Assembly	b. Disassembly	d. Follow-on Maintenance																																
a. Service	c. Assembly																																				
b. Disassembly	d. Follow-on Maintenance																																				
<p>INITIAL SETUP</p> <table> <tr> <td><i>Models</i></td> <td colspan="2"><i>Equipment Condition</i></td> </tr> <tr> <td>All</td> <td><i>TM or Para</i></td> <td><i>Condition Description</i></td> </tr> <tr> <td><i>Test Equipment</i></td> <td>Para 23-9</td> <td>Remove upper container.</td> </tr> <tr> <td>None</td> <td colspan="2"><i>Special Environmental Conditions</i></td> </tr> <tr> <td><i>Special Tools</i></td> <td colspan="2">None</td> </tr> <tr> <td>None</td> <td colspan="2"><i>General Safety Instructions</i></td> </tr> <tr> <td><i>Supplies</i></td> <td colspan="2">None</td> </tr> <tr> <td>None</td> <td colspan="2"><i>Level of Maintenance</i></td> </tr> <tr> <td><i>Personnel Required</i></td> <td colspan="2">General Support</td> </tr> <tr> <td>MOS 63W, Wheel vehicle repairer</td> <td colspan="2"></td> </tr> <tr> <td><i>References</i></td> <td colspan="2"></td> </tr> <tr> <td>(TB 9-289) Depot reconditioning of engine, transmission and similiar reusable metal containers.</td> <td colspan="2"></td> </tr> </table>		<i>Models</i>	<i>Equipment Condition</i>		All	<i>TM or Para</i>	<i>Condition Description</i>	<i>Test Equipment</i>	Para 23-9	Remove upper container.	None	<i>Special Environmental Conditions</i>		<i>Special Tools</i>	None		None	<i>General Safety Instructions</i>		<i>Supplies</i>	None		None	<i>Level of Maintenance</i>		<i>Personnel Required</i>	General Support		MOS 63W, Wheel vehicle repairer			<i>References</i>			(TB 9-289) Depot reconditioning of engine, transmission and similiar reusable metal containers.		
<i>Models</i>	<i>Equipment Condition</i>																																				
All	<i>TM or Para</i>	<i>Condition Description</i>																																			
<i>Test Equipment</i>	Para 23-9	Remove upper container.																																			
None	<i>Special Environmental Conditions</i>																																				
<i>Special Tools</i>	None																																				
None	<i>General Safety Instructions</i>																																				
<i>Supplies</i>	None																																				
None	<i>Level of Maintenance</i>																																				
<i>Personnel Required</i>	General Support																																				
MOS 63W, Wheel vehicle repairer																																					
<i>References</i>																																					
(TB 9-289) Depot reconditioning of engine, transmission and similiar reusable metal containers.																																					

a. *Service.* Service reusable container (TB 9-289).

Special Purpose Kit Installation Instructions (Cont)

23-10. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION, AND TRANSFER CASE SERVICE AND REPAIR. (CONT).

b. Disassembly.



TA476814

NOTE

All three containers are repaired the same. Engine container shown throughout the task.

(1) Remove seal (1) from lower container (2).

NOTE

All reusable containers are similar except for shapes and quantity of mounting brackets and hardware. Transmission has 3 brackets, 6 screws, washers, lockwashers and nuts. Transfer case has 4 brackets, 8 screws, washers, lockwashers, and nuts.


(2) Remove eight nuts (3), lockwashers (4), washers (5), screws (6), and two mounting brackets (7).

NOTE

- Inner frame for transmission and transfer case only have four screws and lockwashers.
- Mark position of inner frame before removal.

(3) Attach suitable lifting device to inner frame (8) and remove 24 screws (9), lockwashers (10), and inner frame (8) from lower container (2).


Special Purpose Kit Installation Instructions (Cont)



NOTE

Shear mounts are similar except for shape and hardware. Transmission and transfer case have washers and nuts.

(4) Remove four screws (11), lockwashers (12), and shear mount (13) from lower container (2).



(5) Remove plug (14) from lower container (2).

NOTE


All skid legs are removed the same.

(6) Remove two screws (15), four washers (16), two nuts (17), lockwashers (18), and skid leg (19).

Special Purpose Kit Installation Instructions (Cont)

23-10. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION, AND TRANSFER CASE SERVICE AND REPAIR. (CONT).


- (7) Remove cover (20) from upper container (21).
- (8) Remove two end balls (22) and cable (23).
- (9) Remove valve (24), nut (25), washer (26), and gasket (27) from cover (20).




NOTE

Number of dehumidification bags may vary due to amount of units per bag.

- (10) Remove 128 units of desiccant (8 to 16 bags) (28) from upper container (21).
- (11) Remove edge protector (29) from upper container (21).




- (12) Remove sight gage (30), nut (31), washer (32), and gasket (33) from upper container (21).



Special Purpose Kit Installation Instructions (Cont)

c. *Assembly.*

(1) Install gasket (1) and sight gage (2) with washer (3) and nut (4) in upper container (5).



NOTE



Tip container up for access to install edge protectors.

(2) Install edge protector (6) in upper container (5).

NOTE

Desiccant comes in bags of 8 units each or 16 units each. The minimum units for engine is 128 units, transmission is 48 units and transfer case is 40 units.


(3) Install appropriate units of desiccant (8 to 16 bags) (7).



(4) Install gasket (8) and valve (9) in cover (10) with washer (11) and nut (12).
 (5) Install cover (10) on upper container (5) with two balls (13) and cable (14).

Special Purpose Kit Installation Instructions (Cont)



23-10. SHIPPING AND STORAGE CONTAINERS, ENGINE, TRANSMISSION, AND TRANSFER CASE SERVICE AND REPAIR. (CONT).



TA476823

- (6) Install skid leg (15) with four washers (16), two screws (17), lockwashers (18), and nuts (19).
- (7) Install plug (20) in lower container (21).

TRANSMISSION AND TRANSFER CASE



ENGINE


TA476824

NOTE

Shear mounts are similar except for shape and hardware. Transmission and transfer case have washers and nuts.

- (8) Install shear mount (22) in lower container (21) with four lockwashers (23) and screws (24).

Special Purpose Kit Installation Instructions (Cont)



TA476825

NOTE

Inner frame for transmission and transfer case only have four screws and lockwashers.

- (9) Install inner frame (25) in lower container (21) with 24 lockwashers (26) and screws (27).
 (10) Install seal (28) on lower container (21).

NOTE

All reusable containers are similar except for shapes and quantity of mounting brackets and hardware. Transmission has 3 brackets, 6 screws, washers, lockwashers, and nuts. Transfer case has 4 brackets, 8 screws, washers, lockwashers, and nuts.


- (11) Install two mounting brackets (29) with four screws (30), washers (31), lockwashers (32), and nuts (33).
 c. *Follow-on Maintenance.* Install upper container (para 23-9).

END OF TASK

Special Purpose Kit Installation Instructions (Cont)

23-11. ENGINE, PREPARATION FOR SHIPPING AND STORAGE CONTAINER.	
This task covers:	
<ul style="list-style-type: none"> a. Removal b. Follow-on Maintenance 	
INITIAL SETUP	
<i>Models</i>	<i>Equipment Condition</i>
All	<i>TM or Para</i> <i>Condition Description</i>
<i>Test Equipment</i>	TM 9-2320-279-20 Remove starter relay.
None	TM 9-2320-279-20 Remove tachometer sending unit.
<i>Special Tools</i>	TM 9-2320-279-20 Remove ether sensing unit.
None	Para 12-8 Remove throttle control solenoid.
<i>Supplies</i>	TM 9-2320-279-20 Remove air compressor governor.
Sealant, pipe thread, Item 29, Appendix C	Para 12-10 Remove steering pump.
<i>Personnel Required</i>	<i>Special Environmental Conditions</i>
MOS 63W, Wheel vehicle repairer	None
<i>References</i>	<i>General Safety Instructions</i>
None	None
<i>Equipment Condition</i>	<i>Level of Maintenance</i>
<i>TM or Para</i> <i>Condition Description</i>	General Support
Para 3-3 Engine removed from vehicle.	
Para 6-6 Remove engine wiring harness.	

a. Removal.



TA476826

Special Purpose Kit Installation Instructions (Cont)

NOTE

- All components removed in this procedure from old engine must be installed on replacement (new engine).
- The M983 vehicle requires a 100 amp alternator. When replacing engine remove alternator from old engine and install on new engine. Remove alternator from new engine and install on old engine (refer to TM 9-2320-279-20).

Loosen screw (1) and remove reducer (2) and clamp (3) from old engine and install on new engine.

Remove plug (4) from governor (6) on new engine.

Remove fitting (6) from governor (5) of old engine.

Install plug (4) in governor (5) of old engine.

Apply sealant and install fitting (6) in governor (5) of new engine.

Remove plug (7) from air inlet adapter (8) of new engine.

Remove atomizer (9) and

reducer (10) from air inlet

adapter (8) of old engine.



Install plug (7) in air inlet

adapter (8) of old engine.

Apply sealant to atomizer (9)

and reducer (10) and install in

air inlet adapter (8) of new engine.



NOTE


Note position of elbows.

(10) Remove two screws (11), lo&washers (12), flange assembly (13), and discard gasket (14). Install screws, lo&washers, flange assembly, and new gasket on new engine.

(II) Repeat step (10) for other flange assembly (13).

Special Purpose Kit Installation Instructions (Cont)


23-11. ENGINE, PREPARATION FOR SHIPPING AND STORAGE CONTAINER (CONT).



NOTE

Front left screw has star-shaped lockwasher.

- (12) Remove two screws (15), lockwashers (16), and bracket (17) from old engine and install on new engine.
- (13) Repeat step (12) for other side.




NOTE

Screw, washer, lockwasher, and nut must be reinstalled after bracket is removed.


- (14) Remove nut (18), lockwasher (19), screw (20), washer (21), and bracket (22) from old engine and install on new engine.

Special Purpose Kit Installation Instructions (Cont)



TA476831

- (15) Remove screw (23), lockwasher (24), and bracket (25) from old engine and install on new engine.



TA476832

- (16) Disconnect hose (26) from tee (27) and remove screw (28), lockwasher (29), clamp (30), and hose (26) from old engine and install on new engine.
 (17) Remove tee (30) from old engine.
 (18) Apply sealant and install fitting (30) on new engine.


Special Purpose Kit Installation Instructions (Cont)

23-11. ENGINE, PREPARATION FOR SHIPPING AND STORAGE CONTAINER (CONT).


NOTE

Note position of air lines.

- (19) Disconnect hose (31) and remove from old engine and install on new engine.
- (20) Disconnect hose (32) from old engine and install on new engine.



TA476833



TA476834

- (21) Remove screw (33), lockwasher (34), and loosen screw (35).

NOTE

Install screw and lockwasher after removing fitting.

- (22) Remove plug (36) from new engine.
- (23) Remove hose (37), elbow (38), adapter (39), and fitting (40).
- (24) Install plug (36) in old engine.
- (25) Apply compound and install fitting (40), adapter (39), and elbow (38) on new engine.

b. Follow-on Maintenance.


- (1) Install fan (TM 9-2320-279-20).
- (2) Install steering pump on replacement engine (para 12-10).
- (3) Install air compressor governor on replacement engine (TM 9-2320-279-20).
- (4) Install throttle control solenoid on replacement engine (Para 12-8).
- (5) Install ether sensing unit on replacement engine (TM 9-2320-279-20).
- (6) Install tachometer sending unit on replacement engine (TM 9-2320-279-20).
- (7) Install starter relay on replacement engine (TM 9-2320-279-20).
- (8) Install engine wiring harness on replacement engine (para 6-6).
- (9) Install replacement engine in vehicle (para 3-3).
- (10) Install engine in shipping and stowage container (para 23-9).

END OF TASK

Special Purpose Kit Installation Instructions (Cont)

23-12. TRANSMISSION, PREPARATION FOR SHIPPING AND STORAGE CONTAINER.		
This task covers:		
<ul style="list-style-type: none"> a. Removal b. Follow-on Maintenance 		
INITIAL SETUP		
<i>Models</i>	<i>Equipment Condition</i>	
All	<i>TM or Para</i>	<i>Condition Description</i>
<i>Test Equipment</i>	Para 7-3	Transmission removed from vehicle.
None	TM 9-2320-279-20	Neutral interlock switch sender unit removed.
<i>Special Tools</i>	Para 7-4	Modulator valve removed.
None	<i>Special Environmental Conditions</i>	
<i>Supplies</i>	None	
None	<i>General Safety Instructions</i>	
<i>Personnel Required</i>	None	
MOS 63W, Wheel vehicle repairer	<i>Level of Maintenance</i>	
<i>References</i>	General Support	
None		

a. Removal.




NOTE

All components removed in this procedure must be installed on replacement (new) transmission.

- (1) Remove five studs (1) from old transmission (2) and install on new transmission (3).
- (2) Remove six screws (4), washers (5), cover (6), and gasket (7) from new transmission (3) and install on old transmission (2).


Special Purpose Kit Installation Instructions (Cont)

23-12. TRANSMISSION, PREPARATION FOR SHIPPING AND STORAGE CONTAINER (CONT).



TA476836

- (3) Remove fitting (8) from old transmission (2) and install on new transmission (3).
- (4) Remove plug (9) and plug (10) from new transmission (3) and install in old transmission (2).



TA476837

- (5) Remove four screws (11) and nuts (12) from new transmission.
- (6) Remove two screws (13), lockwashers (14), and bracket (15) from new transmission.
- (7) Install bracket (15) on old transmission with two lockwashers (14), screws (13), four screws (11), and nuts (12).

b. Follow-on Maintenance.

- (1) Install modulator valve (para 7-22).
- (2) Install neutral interlock switch sender unit (TM 9-2320-279-20).
- (3) Install transmission (para 7-4).

END OF TASK

APPENDIX A REFERENCES

A-1. SCOPE. This appendix lists all forms, field manuals, technical manuals, and other publications referenced in this manual. Also, those publications that should be consulted for additional information about vehicle operations are listed.

A-2. PUBLICATION INDEXES. The following indexes should be consulted frequently for latest changes or revisions and for new publications relating to material covered in this technical manual.

Consolidated Index of Army Publications and Blank Forms DA Pam 310-1

A-3. FORMS. The following forms pertain to this manual. Refer to DA Pamphlet 310-1 for index of blank forms.

- Equipment Inspection and Maintenance Worksheet (DA Form 2404).
- Maintenance Request (DA Form 2407).
- Recommended Changes to DA Publication and Blank Forms (DA Form 2028).

Refer to DA PAM 738-750, The Army Maintenance Management Systems (TAMMS), for instructions for the use of maintenance forms pertaining to this material.

A-4. OTHER PUBLICATIONS. The following publications contain information pertinent to the M977 series vehicles and associated equipment.

a. Safety.

- First Aid for Soldiers FM 21-11
- Safety Inspection and Testing of Lifting Devices TB 43-0142
- Security of Tactical Wheeled Vehicles. TB 9-2300-422-20

b. Vehicle Operation.

- Operator's Manual, M977 Series Vehicles TM 9-2320-279-10
- Operator's Manual, M984 TM 9-2320-354-10
- Operator's Manual, M985E1 TM 9-2320-355-10

c. Cold Weather Operation and Maintenance.

- Operations and Maintenance of Ordnance Material in Extreme Cold Weather (0 degrees to -65 degrees F) FM 9-207

d. Maintenance and Repair.

- Lubrication Order for M977 Series Vehicles LO 9-2320-279-12
- Organization Repair Parts and Special Tools List for M977 Series Vehicle TM 9-2320-279-24P
- Direct Support and General Support Maintenance Repair Parts and Special Tools List for M977 Series Vehicles TM 9-2320-279-24P
- Organizational, Direct Support and General Support Maintenance, and Repair Parts and Special Tools List, M984 Crane (HIAB 8109) TM 9-2320-354-24&P
- Organizational, Direct Support and General Support Maintenance, and Repair Parts and Special Tools List, M985E1 Crane (HIAB 8108) TM 9-2320-355-24&P
- Cooling Systems: Tactical Vehicles TM 750-254
- Use of Antifreeze Solutions and Cleaning Compounds in Engine Cooling Systems TB 750-651
- Repair of Tents, Canvas, and Webbing. FM 10-16
- Painting Instructions for Field Use TM 43-0139
- Camouflage Pattern Painting TC 5-200
- Color, Marking, and Camouflage Painting of Military Vehicles TB 43 0209
- Description, Use, Bonding Techniques, and Properties of Adhesives TB ORD 1032

References (Cont)

A-4. OTHER PUBLICATIONS (CONT).

Direct Support and General Support Level, Generator Assembly,
 Prestolite Leece-Neville 60 and 100 Amp TM 9-2920-225-34

Direct Support and General Support Maintenance Levels, Load Testing Heavy, Expanded
 Mobility Tactical Truck (HEMTT) Vehicle Cranes TM 9-2320-279-34

Materials Used for Cleaning, Preserving, Abrading, and Cementing Ordnance Materiel and
 Related Materiels Including Chemicals TM 9-247

Metal Body Repair and Related Operations FM 43-2

Welding Theory and Application TM 9-237

Inspection, Care, and Maintenance of Antifriction Bearings TM 9-214

Ordnance Tracked and Wheeled Vehicle Hull and Chassis Wiring, Repair of TB ORD 650

Care and Use of Handtools and Measuring Tools TM 9-243

Charging System Troubleshooting (The Easy Way> DA Pam 750-33

Purging, Cleaning, and Coating Interior Ferrous and Terne Sheet Vehicle Fuel Tanks TB 43-0212

Operator's Unit Direct Support, and General Support Maintenance Manual for Care,
 Maintenance, Repair, and Inspection of Pneumatic Tires and Inner Tube TM 9-2610-200-14

Operator's Organizational, Direct Support, and General Support Maintenance Manual
 for Lead-Acid Storage Batteries TM 9-6140-200-14

Operator's Organizational, Direct Support, and General Support Maintenance Manual
 for Tool Outfit, Hydraulic Systems Test and Repair (HSTRU) TM 9-4940-468-14

e. Decontamination.

Chemical, Biological, and Radiological (CBR) Decontamination TM 3-220

Nuclear, Biological and Chemical (NBC) Decontamination FM 3-5

f. Maintenance of Auxiliary Equipment and Special Purpose Kits.

Operator's and Organizational Maintenance Manual Radio Sets TM 11-5820-498-12

Direct Support, General Support, and Depot Maintenance Manual Radio Sets TM 11-5820-498-35

Operator, Organizational, Direct Support, and General Support Maintenance Manual
 Including Repair Parts and Special Tools List for Machine Gun Mounts TM 9-1005-245-14

Operator and Organizational Maintenance Manual for General Set TM 5-6115-465-12
 LO 5-6115-465-12

Organizational, Direct Support and General Support, and Depot Maintenance
 Repair Parts and Special Tools List Generator Set TM 5-6115-465.24P

Direct and General Support and Depot Maintenance Manual Generator Set TM 5-6115-465-35

g. General.

Procedure for Destruction of Tank-Automotive Equipment to Prevent Enemy Use TM 750-244-6

Principles of Automotive Vehicles TM 9-8000

h. Warranty.

Warranty Technical Bulletin for M977 Series Vehicles TB 9-2300-295-15/19

APPENDIX B ILLUSTRATED LIST OF MANUFACTURED ITEMS

Section I. INTRODUCTION

This appendix includes complete instructions for making items authorized to be manufactured or fabricated at direct support and general support maintenance.

A part number index in alphanumeric order is provided for cross-referencing the part number of the item to be manufactured to the figure which covers fabrication criteria.

All bulk materials needed for manufacture of an item are listed by part number or specification number in a tabular list on the illustration.

Section II. MANUFACTURED ITEMS PART NUMBER INDEX

Part No.	Description	Fig. No.
	Arctic Heater Test Set	B-5
	Crane Hoist Drive Pressure Plate Removal/Installation Tool (M983)	B-4
	Shims	B-2
	Spanner Socket	B-11
A52789-G5	Hose, Nonmetallic	B-12
B107.2	Socket	B-12
FA126GGG0426180	Hose Assembly	B-12
FA3391MMM0750	Hose Assembly	B-12
FA3391MMM0900	Hose Assembly	B-12
FB9535-0043	Hose Assembly	B-12
FG1002GGG0320	Hose Assembly	B-12
FG1002GGG0830	Hose Assembly	B-12
FG1002GGG0880	Hose Assembly	B-12
FG1002KKK0200	Hose Assembly	B-12
FG1002KKK0320	Hose Assembly	B-12
FG1002KKK0400	Hose Assembly	B-12
FG1002KKK0420	Hose Assembly	B-12
FG1002KKK0480	Hose Assembly	B-12
FG1002KKK0640	Hose Assembly	B-12
FG1002KKK0700	Hose Assembly	B-12
FG1002KKK0710	Hose Assembly	B-12
FG1002KKK0730	Hose Assembly	B-12
FG1003KKK1770	Hose Assembly	B-12
FG1003KKK0800	Hose Assembly	B-12
FG10IIGGG0820	Hose Assembly	B-12
FG10IIGGG0870	Hose Assembly	B-12
FG1011KKK0320	Hose Assembly	B-12
FG1011KKK0370	Hose Assembly	B-12
FG1011KKK0380	Hose Assembly	B-12
FG1011KKK0460	Hose Assembly	B-12
FG1011KKK0520	Hose Assembly	B-12
FG1011KKK0610	Hose Assembly	B-12

Illustrated list of Manufactured Items (Cont)

Part No.	Description	Fig. No.
FG1011KKK0870	Hose Assembly	B-12
FG1011KKK1200	Hose Assembly	B-12
FG1011KKK1650	Hose Assembly	B-12
FG1082HHH0910	Hose Assembly	B-12
FG115KJJ0700090	Hose Assembly	B-12
FG1556GGG0290	Hose Assembly	B-12
FG1556GGG0760	Hose Assembly	B-12
FG1556GGG0790	Hose Assembly	B-12
FG1556GGG0820	Hose Assembly	B-12
FG1556GGG0960	Hose Assembly	B-12
FG1556GGG1670	Hose Assembly	B-12
FG1556GGG2300	Hose Assembly	B-12
FG1556HHH0780	Hose Assembly	B-12
FG1556HHH0920	Hose Assembly	B-12
FG1556HHH1330	Hose Assembly	B-12
FG1556HHH2260	Hose Assembly	B-12
FG1556JJJ0260	Hose Assembly	B-12
FG1556JJJ0810	Hose Assembly	B-12
FG1556KKK0080	Hose Assembly	B-12
FG1556KKK0180	Hose Assembly	B-12
FG1556KKK0210	Hose Assembly	B-12
FG1556KKK0270	Hose Assembly	B-12
FG1556KKK0300	Hose Assembly	B-12
FG1556KKK0320	Hose Assembly	B-12
FG1556KKK0380	Hose Assembly	B-12
FG1556KKK0400	Hose Assembly	B-12
FG1556KKK0420	Hose Assembly	B-12
FG1556KKK0440	Hose Assembly	B-12
FG1556KKK0630	Hose Assembly	B-12
FG1556KKK0633	Hose Assembly	B-12
FG1556KKK0660	Hose Assembly	B-12
FG1556KKK0700	Hose Assembly	B-12
FG1556KKK0790	Hose Assembly	B-12
FG1556KKK0860	Hose Assembly	B-12
FG1556KKK0900	Hose Assembly	B-12
FG1556KKK0930	Hose Assembly	B-12
FG1556KKK0960	Hose Assembly	B-12
FG1556KKK1000	Hose Assembly	B-12
FG1556KKK1360	Hose Assembly	B-12
FG1556KKK1380	Hose Assembly	B-12
FG1556KKM0270	Hose Assembly	B-12
FG1556MMM0160	Hose Assembly	B-12
FK540GGG0180	Hose Assembly	B-12
FK540HHH0910180	Hose Assembly	B-12
FK541GGGO770180	Hose Assembly	B-12
FK541GGG0800	Hose Assembly	B-12
FK541HHH0210180	Hose Assembly	B-12
FK541HHH0890180	Hose Assembly	B-12
FK542EEE0230090	Hose Assembly	B-12
FK542EEE0300	Hose Assembly	B-12
FK542EEE0380	Hose Assembly	B-12


Illustrated List of Manufactured Items (Cont)

Part No .	Description	Fig. No.
FK542GGG0310	Hose Assembly	B-12
FK542GGG0450	Hose Assembly	B-12
FK542GGG0720	Hose Assembly	B-12
FK542HHH0350	Hose Assembly	B-12
FK542HHH0900	Hose Assembly	B-12
FL1315EEE0200	Hose Assembly	B-12
FL1315EEE0250	Hose Assembly	B-12
FL1315GEG0130	Hose Assembly	B-12
FL1315GEG0200	Hose Assembly	B-12
FL1315GEG0920	Hose Assembly	B-12
FL1315GEG000	Hose Assembly	B-12
FL1315GEG1060	Hose Assembly	B-12
FL1315GEG1280	Hose Assembly	B-12
FL1315GGG0140	Hose Assembly	B-12
FL1315GGG0240	Hose Assembly	B-12
FL1315GGG0360	Hose Assembly	B-12
FL1315GGG0420	Hose Assembly	B-12
FL1315GGG0460	Hose Assembly	B-12
FL1315GGG0540	Hose Assembly	B-12
FL1315GGG0600	Hose Assembly	B-12
FL1315GGG0650	Hose Assembly	B-12
FL1315HHH0110	Hose Assembly	B-12
FL1315HHH0180	Hose Assembly	B-12
FL1315HHH0200	Hose Assembly	B-12
FL1315HHH0220	Hose Assembly	B-12
FL1315HHH0310	Hose Assembly	B-12
FLI526EEE0110	Hose Assembly	B-12
FLI526EEE0960	Hose Assembly	B-12
FLI526GGG0250	Hose Assembly	B-12
FL1526GGG0270	Hose Assembly	B-12
FLI526GGG0350	Hose Assembly	B-12
FL1526GGG0370	Hose Assembly	B-12
FLI526GGG0450	Hose Assembly	B-12
FL1526GGG0530	Hose Assembly	B-12
FLI526GGG0570	Hose Assembly	B-12
FL1526GGG0600	Hose Assembly	B-12
FLI526GGG0720	Hose Assembly	B-12
FL1526GGG0730	Hose Assembly	B-12
FL1526GGG0800	Hose Assembly	B-12
FLI526HHH0160	Hose Assembly	B-12
FLI526HHH0180	Hose Assembly	B-12
FL1526HHH0280	Hose Assembly	B-12
FL1526HHH0600	Hose Assembly	B-12
FL1526HHH0690	Hose Assembly	B-12
FLI526HHH0840	Hose Assembly	B-12
FLI526HHH0900	Hose Assembly	B-12
FLI526HHH1200	Hose Assembly	B-12
FL1628GGG0260	Hose Assembly	B-12
FL1628GGG0400	HOSE Assembly	B-12
FL1628GGG0560	Hose Assembly	B-12
FL1628GGG0600	Hose Assembly	B-12
FL1628GGGI000	Hose Assembly	B-12

Illustrated List of Manufactured Items (Cont)

Part No.	Description	Fig. No.
FL1628HHH0180	Hose Assembly	B-12
FL1628HHH0200	Hose Assembly	B-12
FL1628HHH0220	Hose Assembly	B-12
FL1628HHH0240	Hose Assembly	B-12
FL1628HHH0690	Hose Assembly	B-12
FL1628HHH1080	Hose Assembly	B-12
IM923	Socket	B-16
IPP161	Detent Ball Compression Tool	B-3
1467160-7	Channel	B-14
1467160-8	Channel	B-14
2AH762	Air Compressor Cylinder Head Removal Tool	B-10
2BF829	Unloader Bore Bushing Tool	B-9
2BH944	Lifting Eyes	B-1
2CS30	Valve Seat Tool (M983)	B-6
2CS31	Seal Retainer Tool (M983)	B-7
2SK886	V5 Air Actuated Valve Spring Compression Tool (M978)	B-8
42925AX2.5	Pad, Rubber	B-18
45A285-P1	Hose Assembly	B-12
45A285-P2	Hose Assembly	B-12
59745AX40	Strip, Locking	B-13
59745AX82	Seal, Rubber	B-13
59747AX40	Channel, Locking	B-14
59747AX82	Channel, Locking	B-14
6-512-00016	Harness Assembly	B-15
7-543-001350	Hose	B-12
8594000019-9	Protection, Plastic Edge	B-19

Section III. MANUFACTURED ITEMS




NOTE

- (1) Fabricate from 1/2 × 6-in. (12.7 × 152 mm) cold rolled steel.
- (2) Thread Size 7-16 × 14 × 1-in. (25.4 mm) long.
- (3) Heat unthreaded end and bend over 1-1/4-in. (32 mm) diameter rod.
- (4) All dimensions are in inches (mm).

TA356194

Figure B-1. Lifting Eyes (PN 2BH944).




NOTE

- (1) Fabricate from flat shim stock 0.02-in. (0.5 mm) thick by 3/32 × 30-in. (2.38 × 762 mm) long.
- (2) Cut shim stock into 10 3-in. (76.2 mm) pieces.
- (3) All dimensions are in inches (mm).

TA356195

Figure B-2. Shims.


Manufactured Items (Cont)



- (1) Weld round bar stock, 0.625 × 0.5 in. (16 × 12.7 mm) to 1.25 × 0.12 × 1.87-in. (3.2 × 47.5 × 46.2 mm) steel tubing.
- (2) Drill and tap bar stock for 5/16-20 × 3/4-in. (19 mm) screw.
- (3) Install 5/16-20 × 3/4-in. (19 mm) screw.
- (4) All dimensions are in inches (mm).

TA356196

Figure B-3. Detent Ball Compression Tool (Heavy-Duty Winch) (PN IPP161).




NOTE

- (1) Drill two 0.375-in. (9.5 mm) diameter holes in 0.25 × 2 × 6.375-in. (6.35 × 50.8 × 162 mm) mild steel flat bar stock.
- (2) Install two 3/4-30 × 1-1/2 in. (38 mm) screws.
- (3) Weld two screws and two 7/8-20 in. nuts to bar stock.
- (4) All dimensions are in inches (mm).

TA356197

Figure B-4. Crane Hoist Drive Unit Pressure Plate Removal/installation (M983).

Manufactured Items (Cont)




NOTE

- (1) Cut two 39-in. (1 m) lengths of 14 gage wire.
- (2) Connect one insulated clip and one power clip to each wire.
- (3) Ground heater, control box, and fuel pump.
- (4) Connect heater wire harness to heater, control box, and fuel pump.
- (5) Connect positive wire to heater control wire and ground negative wire. Wrap positive wire and heater control wire connections with electrical tape.
- (6) Connect two hose assemblies to heater, fuel pump, and fuel container, 1 quart (0.95 l) capacity container graduated in cc.
- (7) Connect positive wire to positive (+) side of power supply.
- (8) Connect negative wire to negative (-) side of power supply.
- (9) Connect two hose assemblies to heater and water reservoir.

TA356198

Figure B-5. Arctic Heater Test Set.

Manufactured Items (Cont)




NOTE (CONT)

- (10) Coat threads of two 3/8-in. elbows with pipe thread sealing compound and install one elbow in IN and one elbow in OUT port of coolant pump.
- (11) Connect two 3/8-in. hoses to elbows with two clamps.
- (12) Place end of hose in 2 gal. (8 l) graduated container.
- (13) Place second hose in 5 gal. (20 l) container of engine coolant.
- (14) Connect positive lead of power supply to coolant pump.

TA356200

Figure B-5. Arctic Heater Test Set (Cont).

Manufactured Items (Cont)




NOTE

- (1) Grind 7/16-in. socket head screw key.
- (2) All dimensions are in inches (mm).

TA356192

Figure B-6. Valve Seat Tool (M983) (PN 2CS30).




NOTE

- (1) Grind 13/16-in. × 3/8-in. square drive socket using 13/16-in. × 3/8 in. standard socket.
- (2) All dimensions are in inches (mm).

TA356193

Figure B-7. Seal Retainer Tool (M983).

Manufactured Items (Cont)



NOTE

Required Stock:

Mild steel plate, 0.25 × 3.5 × 7.0-in. (6.35 × 89 × 178 mm).

Cold rolled steel rod, 0.375 × 80-in. (9.52 × 2100 mm).

Washer, flat, -round, steel, 0.375-in. i.d., (4) (MS 27183-13)

nut, plain, hexagon, 3/8-16 (4).


(1) Cut 0.25 × 3.5 × 3.5-in. (6.35 × 89 × 89 mm) steel plate.

(2) Drill four 0.406 in.-diameter holes in steel plate.

(3) Drill 1.5-in. diameter hole through center of steel plate.

(4) All dimensions are in inches (mm).

TA356187



NOTE (CONT)

(5) Cut 0.25 × 3.5 × 3.5 in. (6.35 × 89 × 89 mm) steel plate.


(6) Drill four 0.375-in. (9.52 mm) diameter holes in steel plate.

(7) All dimensions are in inches (mm).

TA356189


Figure B-8. V5 Air Actuated Valve Spring Compression Tool (M978) (PN 2SK886).

Manufactured Items (Cont)



NOTE (CONT)

- (8) Cut 0.375 × 20 in. (9.52 × 508 mm) steel rod.
- (9) Thread size 3/8-16 × 9-in. (229 mm) long.
- (10) All dimensions are in inches (mm).




TA358188

NOTE (CONT)

- (11) Install four threaded rods in bottom plate.
- (12) Fillet weld completely around bottom of threaded rods to secure to bottom plate.
- (13) Place top plate on threaded rods.
- (14) Install four 3/8-in. (9.52 mm) diameter washers and four 3/8-16 nuts on threaded rods.

Figure B-8. V5 Air Actuated Valve Spring Compression Tool (M978) (PN 2SK886) (Cont).

Manufactured Items (Cont)



NOTE

Stock:

0.12-in. (3.2 mm) pipe nipple, 6.0-in. (152 mm) long.

1.25-in. (32 mm) mild steel, round; 1.75-in. (45 mm) long.

(1) Drill 0.69-in. (17.5 mm) hole 1.25-in. (32 mm) deep, as shown.

(2) Drill 0.31-in. (7.9 mm) hole as shown.


(3) Tap holes as shown.

(4) Screw pipe nipple into round stock.

(5) Use unloader bore bushing removal tool with slide hammer. TA357323

Figure B-9. Air Compressor Unloader Bore Bushing Removal Tool
(PN 2BF829).


Manufactured Items (Cont)



- (1) Drill and tap two 0.25-in (6.35 mm) diameter holes in 0.19 × 1 × 10 in. (4.76 × 25.4 × 254.0 mm) mild steel flat bar stock.
- (2) Install two 0.25 × 0.75 in. (6.35 × 19.05 mm) screws.
- (3) All dimensions are in inches (mm).

TA476197

Figure B-10. Air Compressor Cylinder Head Removal Tool (PN 2AH762).




- (1) Fabricate from any 2½ in. OD socket.
- (2) Weld four 2 in. long strips of 3/16 in. keystock on socket as shown, so that ½ in. extends beyond socket face.

TA477130

Figure B-11. Spanner Socket

Manufactured Items (Cont)



TA477149

Figure B-12. Hoses and Hose Assemblies

1. Fabricate from bulk hose stock listed in table B-1.
2. Using fine tooth hacksaw or suitable cutting tool cut hose to length required in table B-1.
3. For hose assemblies, place fitting A in vise and screw hose counterclockwise until hose bottoms in fitting. Back off 1/4 turn.
4. Place fitting Bin vise and screw hose counterclockwise until hose bottoms. Back off 1/4 turn.
5. Dimensions are in inches (mm).

Table B-1. Hoses and Hose Assemblies

Hose/Assembly Part Number	Bulk Hose Part Number	Cutoff Length Inches (mm)	Fitting A	Fitting B
A52789-G5	2575-4RL	6 (152.4)		
FA126GGG0426180	2781-6-RL	42.75 (1085.9)	Adapter 191112-6-6S	Elbow 191113-6-6S
FA3391MMM0750	FC350-16RL	75 (1905.0)	Adapter 191121-16-16S	Elbow 191112-16-16S
FA3391MMM0900	FC350-16RL	90 (228.6)	Adapter 191121-16-16S	Elbow 191112-16-16S
FB9535-0043	FC914-01	76 (1930.4)	Adapter FC5810-0604S	Adapter FC5810-0604S
FG1002GGG0320	2781-6-RL	32 (812.8)	Adapter 191100H6-6S	Elbow 191113-6-6S
FG1002GGG0830	2781-6-RL	83 (2108.2)	Elbow 191113-6-6S	Adapter 191100H6-6S
FG1002GGG0880	2781-6-RL	88 (2235.2)	Elbow 191113-6-6S	Adapter 191100H6-6S
FG1002KKK0200	2781-12-RL	20 (508.0)	Adapter 191100H12-12S	Elbow 191113-12-12S
FG1002KKK0320	2781-12-RL	32 (812.8)	Elbow 191113-12-12S	Adapter 191100H12-12S
FG1002KKK0400	2781-12-RL	40 (1016.0)	Adapter 191100H12-12S	Elbow 191113-12-12S
FG1002KKK0420	2781-12-RL	42 (1066.8)	Elbow 191113-12-12S	Adapter 191100H12-12S
FG1002KKK0480	2781-12-RL	48 (1219.2)	Adapter 191100412-12S	Elbow 191113-12-12S
FG1002KKK0640	2781-12-RL	64 (1625.6)	Adapter 191100H12-12S	Elbow 191113-12-12S
FG1002KKK0700	2781-12-RL	70 (1778.0)	Elbow 191113-12-12S	Adapter 191100H12-12S
FG1002KKK0710	2781-12-RL	71 (1803.4)	Adapter 191100H12-12S	Elbow 191113-12-12S
FG1002KKK0730	2781-12-RL	73 (1854.2)	Adapter 191100H12-12S	Elbow 191113-12-12S
FG1002KKK1770	2781-12-RL	177 (4495.8)	Elbow 191113-12-12S	Adapter 191100H12-12S
FG1003KKK0800	2781-12-RL	80 (2032.0)	Adapter 191101-12-12S	Elbow 191113-12-12S
FG1011GGG0820	2781-6-RL	82 (2082.8)	Adapter 191100H6-6S	Adapter 191100H6-6S
FG1011GGG0870	2781-6-RL	87 (2209.8)	Adapter 191100H6-6S	Adapter 191100H6-6S
FG1011KKK0320	2781-12-RL	32 (812.8)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK0370	2781-12-RL	37 (939.8)	Adapter 191100H12-12S	Adapter 191100H12-12S

Manufactured items (Cont)
Table B-1. Hoses and Hose Assemblies (Continued)

Hose/Assembly Part Number	Bulk Hose Part Number	Cutoff Length Inches (mm)	Adapter A	Adapter B
FG1011KKK0380	2781-12-RL	38 (965.2)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK0460	2781-12-RL	46 (1168.4)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK0520	2781-12-RL	52 (1320.8)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK0610	2781-12-RL	61 (1549.4)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK0870	2781-12-RL	87 (2209.8)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK1200	2781-12-RL	120 (3048.0)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1011KKK1650	2781-12-RL	165 (4191.0)	Adapter 191100H12-12S	Adapter 191100H12-12S
FG1082HHH0910	2781-8-RL	91 (2311.4)	Adapter 191101-8-8S	Adapter 191100H8-8S
FG115KJJ0700090	2781-10-RL	70 (1778.0)	Adapter 191118-10-10S	Elbow 191112-12-10S
FG1556GGG0290	2781-6-RL	29 (736.6)	Elbow 191112-6-6S	Adapter 191100H6-6S
FG1556GGG0760	2781-6-RL	76 (1930.4)	Elbow 191112-6-6S	Adapter 191100H6-6S
FG1556GGG0790	2781-6-RL	79 (2006.6)	Elbow 191112-6-6S	Adapter 191100H6-6S
FG1556GGG0820	2781-6-RL	82 (2082.8)	Elbow 191112-6-6S	Adapter 191100H6-6S
FG1556GGG0960	2781-6-RL	96 (2438.4)	Elbow 191112-6-6S	Adapter 191100H6-6S
FG1556GGG1670	2781-6-RL	167 (4241.8)	Adapter 191100H6-6S	Elbow 191112-6-6S
FG1556GGG2300	2781-6-RL	230 (5842.0)	Adapter 191100H6-6S	Elbow 191112-6-6S
FG1556HHH0780	2781-8-RL	75 (1905.0)	Adapter 191100H8-8S	Elbow 191118-8-8S
FG1556HHH0920	2781-8-RL	89 (2260.6)	Adapter 191100H8-8S	Elbow 191118-8-8S
FG1556HHH1330	2781-8-RL	130 (3302.0)	Adapter 191100H8-8S	Elbow 191118-8-8S
FG1556HHH2250	2781-8-RL	225 (5715.0)	Adapter 191118-8-8S	Adapter 191100H8-8S
FG1556JJJ0260	2781-10-RL	23 (584.2)	Adapter 191100H10-10S	Elbow 191118-10-10S
FG1556JJJ0810	2781-10-RL	78 (1981.2)	Adapter 191100H10-10S	Elbow 191118-10-10S
FG1556KKK0080	2781-12-RL	8 (203.2)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK0180	2781-12-RL	18 (457.2)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK0210	2781-12-RL	21 (533.4)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK0270	2781-12-RL	27 (685.8)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0300	2781-12-RL	30 (762.0)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK0320	2781-12-RL	32 (812.8)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0380	2781-12-RL	38 (965.2)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0400	2781-12-RL	40 (1016.0)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0420	2781-12-RL	42 (1066.8)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0630	2781-12-RL	63 (1600.2)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0633	2781-12-RL	63.37 (1609.6)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0660	2781-12-RL	66 (1676.4)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0700	2781-12-RL	70 (1778.0)	Elbow 191113-12-12S	Adapter 191100H12-12S
FG1556KKK0790	2781-12-RL	79 (2006.6)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0860	2781-12-RL	86 (2184.4)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0900	2781-12-RL	90 (2286.0)	Elbow 191112-12-12S	Adapter 191100H12012S
FK542GGG0450	FC374-06RL	45 (1143.0)	Elbow FC5814-0606S	Elbow FC5814-0606S
FK542GGG720	FC374-06RL	72 (1828.8)	Elbow FC5814-0606S	Elbow FC5814-0606S
FK542HHH0350	FC374-08RL	35 (889.0)	Elbow FC5937-0808S	Elbow FC5937-0808S
FK542HHH0900	FC374-08RL	90 (2286.0)	Elbow FC5937-0808S	Elbow FC5937-0808S
FL1315EEE0200	FC374-04RL	20 (508.0)	Adapter FC5810-0404S	Adapter FC5810-0404S
FL1315EEE0250	FC374-04RL	25 (635.0)	Adapter FC5810-0404S	Adapter FC5810-0404S
FL1315GEG0130	FC374-04RL	13 (330.2)	Adapter FC5810-0604S	Adapter FC5810-0604S
FL1315GEG0200	FC374-04RL	20 (508.0)	Adapter FC5810-0604S	Adapter FC5810-0604S
FL1315GEG0920	FC374-04RL	92 (2336.8)	Adapter FC5810-0604S	Adapter FC5810-0604S
FL1315GEG1000	FC374-04RL	100 (2540.0)	Adapter FC5810-0604S	Adapter FC5810-0604S

Manufactured Items (Cont)

Table B-1. Hoses and Hose Assemblies (Continued)

Hose/Assembly Part Number	Bulk Hose Part Number	Cutoff Length Inches (mm)	Adaptor A	Adaptor B
FL1315GEG1060	FC374-04RL	106 (2692.4)	Adapter FC5810-0604S	Adapter FC5810-0604S
FL1315GEG1280	FC374-04RL	128 (3261.2)	Adapter FC5810-0604S	Adapter FC5810-0604S
FL1315GGG0140	FC374-06RL	14 (355.6)	Adapter FC5810-0606S	Adapter FC5810-0606S
FL1315GGG0240	FC374-06RL	24 (600.6)	Adapter FC6810-0606S	Adapter FC6810-0606S
FL1315GGG0360	FC374-06RL	36 (914.4)	Adapter FC5810-0606S	Adapter FC5810-0606S
FL1315GGG0420	FC374-06RL	42 (1066.8)	Adapter FC5810-0606S	Adapter FC5810-0606S
FG1556KKK0930	2781-12-RL	93 (2362.2)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKK0960	2781-12-RL	96 (2438.4)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK1000	2781-12-RL	100 (2640.0)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK1360	2781-12-RL	130 (3302.0)	Elbow 191112-12-12S	Adapter 191100H12-12S
FG1556KKK1380	2781-12-RL	138 (3505.2)	Adapter 191100H12-12S	Elbow 191112-12-12S
FG1556KKM0270	2781-12-RL	27 (685.8)	Adapter 191100H12-12S	Elbow 191107-16-12S
FG1556MMM0160	FC350-16RL	16 (406.4)	Elbow 191112-16-16S	Adapter 191100H16-16S
FK540GGG0180	2661-32	90 (2286.0)	Adapter FC5813-0606S	Adapter FC5813-0606S
FK540HHH0910180	FC374-08RL	91 (2311.4)	Elbow FC5936-0808S	Elbow FC5936-0808S
FK541GGG0770180	FC374-06RL	77 (1955.8)	Adapter FC5813-0606S	Elbow FC5814-0606S
FK541GGG0800	FC374-06RL	80 (2032.0)	Adapter FC6813-0606S	Elbow FC5814-0606S
FK541HHH0210180	FC374-08RL	21 (533.4)	Elbow FC5936-0808S	Elbow FC5937-0808S
FK541HHH0890180	FC374-08RL	89 (2260.6)	Elbow FC5936-0808S	Elbow FC6937-0808S
FK642EEE0230090	FC374-04RL	23 (584.2)	Elbow FC5937-0404S	Elbow FC5937-0404S
FK542EEE0300	FC374-04RL	30 (762.0)	Elbow FC5937-0404S	Elbow FC5937-0404S
FK542EEE0380	FC374-04RL	38 (965.2)	Elbow FC5937-0404S	Elbow FC5937-0404S
FK542GGG0310	FC374-06RL	31 (787.4)	Elbow FC5814-0606S	Elbow FC5814-0606S
FL135GGG0460	FC374-06RL	46 (1168.4)	Adapter FC5810-0606S	Adapter FC5810-0606S
FL1315GGG0540	FC374-06RL	54 (1371.6)	Adapter FC5810-0604S	Adapter FC5810-0604S
FL1315GGG0600	FC374-06RL	60 (1624.0)	Adapter FC5810-0606S	Adapter FC5810-0606S
FL1315GGG0650	FC374-06RL	65 (1651.0)	Adapter FC5810-0606S	Adapter FC5810-0606S
FL1315HHH0110	FC374-08RL	11(279.4)	Adapter FC5810-0808S	Adapter FC6810-0808S
FL1315HHH0180	FC374-08RL	18 (457.2)	Adapter FC5810-0808S	Adapter FC5810-0808S
FL1315HHH0200	FC374-08RL	20 (608.0)	Adapter FC5810-0808S	Adapter FC5810-0808S
FL1315HHH0220	FC374-08RL	22 (558.8)	Adapter FC5810-0808S	Adapter FC5810-0808S
FL1315HHH0310	FC374-08RL	31(787.4)	Adapter FC5810-0808S	Adapter FC5810-0808S
FL1526EEE0110	FC374-04RL	11 (279.4)	Elbow FC5937-0404S	Adapter FC5810-0404S
FL1526EEE0960	FC374-04RL	96 (2438.4)	Elbow FC5937-0404S	Adapter FC5810-0404S
FL1526GGG0250	FC374-06RL	25 (635.0)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0270	FC374-06RL	27 (685.8)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0350	FC374-06RL	35 (889.0)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0370	FC374-06RL	37 (939.8)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0450	FC374-06RL	45 (1143.0)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0530	FC374-06RL	53 (1346.2)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0570	FC374-06RL	57 (1447.8)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0600	FC374-06RL	60 (1524)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0720	FC374-06RL	72 (1828.8)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0730	FC374-06RL	73 (1854.2)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526GGG0800	FC374-06RL	80 (2032.0)	Adapter FC5810-0606S	Elbow FC5814-0606S
FL1526HHH0160	FC374-08RL	16 (406.4)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1526HHH0180	FC374-08RL	18 (457.2)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1526HHH0280	FC374-08RL	28 (711.2)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1526HHH0600	FC374-08RL	60 (1524.0)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1526HHH0690	FC374-08RL	69 (1752.6)	Adapter FC5810-0808S	Elbow FC5937-0808S

Manufactured Items (Cont)

Table B-1. Hoses and Hose Assemblies (Continued)

Hose/Assembly Part Number	Bulk Hose Part Number	Cutoff Length Inches (mm)	Adapter A	Adapter B
FL1526HHH0840	FC374-08RL	84 (2133.6)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1526HHH0900	FC374-08RL	90 (2286.0)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1526HHH1200	FC374-08RL	120 (3048.0)	Adapter FC5810-0808S	Elbow FC5937-0808S
FL1628GGG0260	FC374-06RL	26 (660.4)	Adapter FC5810-0606S	Adapter FC5813-0606S
FL1628GGG0400	FC374-06RL	40 (1016.0)	Adapter FC5810-0606S	Adapter FC5813-0606S
FL1628GGG0560	FC374-06RL	56 (1422.4)	Adapter FC5810-0606S	Adapter FC5813-0606S
FL1628GGG0600	FC374-06RL	60 (1524.0)	Adapter FC5810-0606S	Adapter FC5813-0606S
FL1628GGGI000	FC374-06RL	100 (2540.0)	Adapter FC5810-0606S	Adapter FC5813-0606S
FL1628HHH0180	FC374-08RL	18 (457.2)	Adapter FC5810-0808S	Elbow FC5936-0808S
FL1628HHH0200	FC374-08RL	20 (508.0)	Adapter FC5810-0808S	Elbow FC5936-0808S
FL1628HHH0220	FC374-08RL	22 (558.8)	Adapter FC5810-0808S	Elbow FC5936-0808S
FL1628HHH0240	FC374-08RL	24 (609.6)	Adapter FC5810-0808S	Elbow FC5936-0808S
FL1628HHH0690	FC374-08RL	69 (1752.6)	Adapter FC5810-0808S	Elbow FC5936-0808S
FL1628HHH1080	FC374-08RL	108 (2743.2)	Adapter FC5810-0808S	Elbow FC5936-0808S
2252290	2781-12-RL	44 (1117.6)	Elbow 191112-12-128	Adapter 191100H12-12S
45A285-PI	2556-8-RL	96 (2438.4)	Adapter 45A285-P4	Adapter 4797-4
45A285-P2	2556-8-RL	84 (2133.6)	Adapter 45A285-P4	Adapter 4797-4
7-543-001350	FC374-06RL	34 (863.6)	Adapter FC5810-0606S	Adapter FC5813-0606S





Figure B-13. Locking Strip

1. Fabricate from bulk stock listed in table B-2.
2. Using knife or suitable cutting device cut to length required in table B-2.
3. Dimensions are in inches (mm).

Table B-2. Locking Strip

Strip Part Number	Bulk Strip Part Number	Cutoff Length Inches (mm)
59745AX40	AS1597	40 (1016.0)
59745AX82	AS1597	82 (2082.8)

Manufactured Items (Cont)




1. Fabricate from bulk stock listed in table B-3
2. Using knife or suitable cutting device, cut to length required in table B-3.
3. Dimensions are in inches (mm).

Figure B-14. Locking Channel

Table B-3. Locking Channel

Channel Part Number	Bulk Channel Part Number	Cutoff Length Inches (mm)
1467160-7	75000343	7 (177.8)
1467160-8	75000343	8 (203.2)
59747AX40	3509-R	40 (1016.0)
59747AX82	3509-R	82 (2082.8)



1. Fabricate from bulk wire stock listed in table B-4.
2. Using wire cutters, cut to required length.
3. Dimensions are in inches (mm).

Figure B-15. Locking Channel

Table B-4. Harness Assembly

Harness Assembly Part Number	Bulk Channel Part Number	Cutoff Length Inches (mm)
6-512-000156	R-59110	As required

Manufactured Items (Cont)




Figure B-16. Socket - Fabrication

1. Fabricate from 2-7/8 in., 6-point socket with 1 in. square drive, PN IM 923 (55719), NSN 5130-00-684-0923.
2. Machine socket wall to diameter and depth shown.





Figure B-17. Socket - Fabrication


1. Fabricate from 2-1/4 in., 6-point socket with 1 in. square drive, PN B107.2 (802041, NSN 5130-00-293-1374).
2. Machine socket wall to diameter shown.

Manufactured Items (Cont)



1. Fabricate from 42925AX rubber.
2. Using knife or suitable cutting device, cut to length.
3. All dimensions are in inches (mm).

Figure B-18. Rubber Pad



Fabricate from 8594000019 plastic edge. Using knife or suitable cutting device, cut plastic edge to 9.0 in. (228.6 mm). Dimensions are in inches (mm).

Figure B-19. Plastic Edge Protection

Manufactured Items (Cont)

Table B-5. M1977-CBT Components

The maintenance task listed below contains specific information about the M1977-CBT (Common Bridge Transport).

<u>TITLE</u>	<u>PARAGRAPH</u>
Spring Removal/Repair/Installation	14-2

APPENDIX C

EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

C-1. SCOPE. This appendix lists expendable supplies and materials needed to operate and maintain M977 Series Vehicles. These items are authorized by CTA 50-970. This appendix includes expendable items (except Medical, Class V, Repair Parts, and Heraldic Items) and consumable materials.

C-2. EXPLANATION OF COLUMNS.

a. Column (1) - Item Number. This number is assigned to the entry in the listing and is referenced in the Initial Setup under "Supplies" to identify the material ("Compound, cleaning, Item 18, Appendix C").

b. Column (2) - Level. This column identifies the lowest level of maintenance that requires the listed item.

- C - Operator/Crew
- O - Organizational Maintenance
- F - Direct Support Maintenance
- H - General Support Maintenance

c. Column (3) - National Stock Number. This is the national stock number assigned to the item. Use the national stock number to request or requisition the item.

d. Column (4) - Description. Indicates the federal item name and, if required, a description to identify the item. Where applicable, the last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

e. Column (5) - Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy the requirements.

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	F	8040-00-826-3535	Adhesive, Cyanoacrylate, RTV (MIL-A-46050)	
2	F		Adhesive, Epoxy	
2.1	F	8040-00-142-9193	Adhesive, No. 445 (FSCM 05972)	
3	O		Adhesive, No. 4500 (FSCM 08853) (30456 AX) (FSCM 45152)	
4	O		Adhesive, No. 1099-L (FSCM 04963) (EE 39597) (FSCM 45152)	

Expendable Supplies and Materials List (Cont)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
5	O	8040-01-182-8104	Adhesive No. PL 200 (1322080) (FSCM 45152)	
5.1	F		Adhesive, Spray	
5.2	F		Adhesive, Insulation (4289) (FSCM 28112) (OTC P/N 1372150)	gal
5.3	O	8040-01-321-1254	Adhesive, No. 409 (No. 40945) (FSCM 05972) (OTC P/N 1586850)	20 gm tube
5.4	O	8040-01-235-5435	Adhesive, No. 1300-5 (FSCM 28712) (OTC P/N 32167AX)	5 oz tube
6	O	8040-00-995-0590	Adhesive-Sealant, Silicone, RTV, General Purpose (MIL-A-46106A) 108 (FSCM01139)	
7	O		Adhesive-Sealer (No. 517119)	
8	F		Adhesive-Sealant (No. 51517) (Loctite 515)	6 ml tube
			(No. 51531) (Loctite 515)	50 ml tube
			(No. 51574) (Loctite 515)	300 ml tube
8.1	F	8040-01-250-3969	Adhesive (FSCM 05972) (Loctite 242)	ea
9	C		Antifreeze, Arctic Type	
		6850-00-243-1992	1-gal can (MIL-A-11755)	gal
		6850-00-174-1806	55-gal drum	
10	C	6850-00-181-7940	Antifreeze, Permanent, Glycol, Inhibited (FSA-A-870)	gal
11	O		Caps, Shipping and Sealing	
12	O		Cement, General Purpose, Synthetic Base (MIL-C-4003)	
13	O	7510-00-164-8893	Chalk, Marking, White and Colored SS-C-266F	Box
14	C	7930-00-634-3935	Chips, Soap, P-S-579	
15	O		Chemical Agent Resistant Coating (CARC Green 383 (MIL-C-46168B)	
		8010-01-160-6741	1 qt kit	kt
		8010-01-162-5378	1 gal kit	kt
		8010-01-160-6742	5 gal kit	kt
16	O		Cloth, Crocus	
17	O	8030-00-597-5367	Compound, Antiseize, High Temperature (MIL-A-907) 2-1/2 lb can	lb
18	O		Compound, Cleaning, Conditioner and Inhibitor for Engine Cooling System MIL-C-10597)	
		6850-00-598-7328	Package, Consisting of: a. Cleaner, Part 1, Oxalic Acid. b. Cleaner, Part 2, Aluminum Chloride. c. Sodium Silicate Conditioner. d. Alkaline Conditioner. e. Inhibitor. f. Instruction Sheet.	ea
19	O		Compound, Cleaning, Creosol Base (MIL-C-5546)	

Expendable Supplies and Materials List (Cont)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
20	F	5970-00-166-5697	Compound, Insulating, Electrical, Embedding (MIL-C-47233)	
21	F		Compound, International, No. 2	
22	F	5350-01-157-6916	Compound, Lapping and Grinding J3179-5 (FSCM 58805) 1 pk No. 1 dry grain	ea
23	F		Compound, Polishing J23028 (FSCM 58805)	
24	F		Compound, Retaining (MIL-R-46082)	
		8030-00-181-7603	50-cc	cc
		8030-00-181-7529	250-cc	cc
25	O		Compound, Sealing, Lubricating, Wicking, Thread Locking, Anaerobic, Single Component (MIL-S-46163) Type I, Grade K	
26	O		Compound, Sealing, Lubricating, Wicking, Thread Locking, Anaerobic, Single Component (MIL-S-46163) Type II, Grade N	
27	O		Compound, Sealing, Lubricating, Wicking, Thread Locking, Anaerobic, Single Component (MIL-S-46163) Type II, Grade O	
28	O		Compound, Sealing, Lubricating, Wicking, Thread Locking, Anaerobic, Single Component (MIL-S-46163) Type II, Grade R	ml
28.1	F		Compound, Sealing, Pipe Thread (FSCM 05972) (No. 56707) (Loctite 567)	6 ml tube
		8030-01-166-0675	(No. 56747) (Loctite 567)	50 ml tube
			(No. 56765) (Loctite 567)	250 ml tube
29	O		Compound, Sealing, Pipe Thread (Loctite 592) (FSCM 05972) (702350-X)	
29.1	F		Compound, Walking (FSCM 45152) (1330480)	
30	O	5610-00-67-1533	Compound, Walkway, Non-slip (MIL-W-5044)	gal
31	O		Connector, Electrical, Butt 34072 (FSCM 04618)	ea
32	F		Dye, Prussian Blue	
33	O	8010-01-141-2419	Chemical Agent Resistant Coating (CARC) Black (MIL-C-46168B) 1 qt kit	kt
		8010-01-131-6254	1-gal can	kt
		8010-01-131-6261	5-gal can	kt
34	C		Grease, Automotive and Artillery GAA (MIL-G-10924)	
		9150-00-065-0029	2-1/4 oz tube	oz
		9150-00-935-1017	14-oz cartridge	oz
		9150-00-190-0904	1lb can	lb
		9150-00-190-0905	5-lb can	lb
		9150-00-190-0905	35-lb can	lb

Expendable Supplies and Materials List (Cont)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
35	F	9150-01-095-5512	Grease, Ball Bearing, Lithium Base	
36	F	9150-01-091-9336	Grease, General Purpose, Lithium Base	
37	F		Grease, High Performance, Multi-purpose, (MIL-G-24508)	
38	F	9150-00-543-7220	Grease, Molybdenum Disulfide (MIL-G-21164)	
38.1	F		Jelly, Petroleum	
38.2	O		Inhibitor, Corrosion, Liquid Cooling System (89524) (P/N NALCOOL 2000)	
		6850-01-085-4717	1-pt can	Pt
		6850-01-085-4718	64-oz bottle	oz
		6850-01-085-4719	5-gal drum	gal
		6850-01-087-4045	15-gal drum	gal
		6850-01-086-3438	55-gal drum	gal
39	O	9505-00-191-3680	Lockwire	
39.1	O		Lubricant, Tire and Rim	
		2640-00-256-5526	1-qt can	qt
		2640-00-256-5527	1-gal can	gal
		2640-00-256-5529	(5) 1-gal containers in a carton	gal
40	F	6810-00-812-9181	Methyl Ethyl Ketone TT-M-261 (MIL-T-27602)	gal
41	C		Oil, Fuel, Diesel DF-1 Winter (W-F-800)	
		9140-00-286-5286	Bulk	gal
		9140-00-286-5287	5-gal can	gal
		9140-00-286-5288	55-gal drum, 16 gage	gal
		9140-00-286-5289	55-gal drum, 18 gage	gal
42	C		Oil, Fuel, Diesel DF-2 Regular (W-F-800)	
		9140-00-286-5294	Bulk	gal
		9140-00-286-5295	5-gal can	gal
		9140-00-286-5296	55-gal drum, 16 gage	gal
		9140-00-286-5297	55-gal drum, 18 gage	gal
43	C		Oil, Lubricating, Gear, GO 75 (MIL-L-2105C)	
		9150-01-035-5390	1-qt can	qt
		9150-01-035-5391	5-gal drum	gal
		9150-01-035-5393	55-gal drum	gal
44	C		Oil, Lubricating, Gear, GO 80/90 (MIL-L-2105C)	
		9150-01-035-5393	5-gal drum	gal
45	O		Oil, Lubricating, OEA Ice, Subzero (MIL-L-46167)	
		9150-00-402-4478	1-qt can	qt
		9150-00-402-2372	5-gal drum	gal
		9150-00-491-7197	55-gal drum, 16 gage	gal
46	C		Oil, Lubricating, OE/HDO 10 (MIL-L-2104)	
		9150-00-189-6727	1-qt can	qt
		9150-00-186-6668	5-gal drum	gal
			55-gal drum, 16 gage	gal
		9150-00-191-2772	55-gal drum, 18 gage	gal

Expendable Supplies and Materials List (Cont)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
47	C	9150-00-186-6681	Oil, Lubricating, OE/HDO 30 (SAE 30) (MIL-L-2104)	qt
		9150-00-188-9858	1-qt can	gal
		9150-00-265-9436	5-gal drum	gal
		9150-00-189-6729	55-gal drum, 16 gage	gal
47.1	C		55-gal drum, 18 gage	gal
		9150-00-189-6730	Oil, Lubricating, OE/HDO 40 (SAE 40) (MIL-L-2104)	gal
		9150-00-188-9862	1-qt can	gal
48	C		55-gal drum	gal
		9150-00-152-4117	Oil, Lubricating: Internal combustion engine, tactical	qt
		9150-00-152-4119	service (MIL-L-2104) (OE/HDO 15W/40)	
49	O		1-qt can	qt
50	F		55-gal drum, 16 gage	gal
51	O	5350-00-186-8818	Oil, Mineral	
52	O	5350-00-224-7203	Oil, Test, Fuel Injector J26400-5 (FSCM 58805)	
52.1	F		5-gal can	gal
53	F		Paper, Abrasive, Garnet (Emery Cloth) P-P-121	
			Paper, Abrasive, Silicon Carbide, Waterproof P-P-101	
			Plastic, Anti-Friction	
			(FSCM 45152) (1771600)	
			Preventive, Rust (MIL-C-16173) Texaco Type	
			19AS436 (FSCM 45152)	gal
		8030-00-062-5866	1-gal	
		8030-00-244-1293	5-gal	
		8030-00-244-1294	55-gal	
54	O	8010-00-193-0516	Primer, Epoxy, (MIL-P-52192B) qt kit	gal
55	O		Chemical Agent Resistant Coating (CARC) Brown 383	
			(MIL-C46168B) 511X303	kt
		8010-01-160-6744	1-qt kit	kt
			1-gal kit	kt
			5-gal kit	kt
55.1	F	1015-01-255-4144	Sealant, Pipe, Teflon, 50 ml Tube	tu
56	O		Solder, Rosin Flux Core ASTM B 284-79	
57	C		Solvent, Drycleaning SD (P-D-680)	
		6850-00-664-5685	1-qt can	qt
		6850-00-281-1985	1-gal can	gal
58			Deleted	
59	F		Stock, Bar, Steel 0.1975 x 0.25 x 14 in.	
			(4.76 x 6.35 x 355.6 mm)	
60	O	8135-00-178-9200	Tags, Identification (MIL-T-12755) pk/1000	pk
60.1	F		Tape, Acrylic Foam Double Backed	
			(FSCM 45152) (1775280)	
61	F	8030-00-398-4130	Tape, Antiseize, Tetrafluoroethylene (MIL-T-27730)	ea
62	O	5970-00-644-3167	Tape, Insulation, Electrical (MIL-T-50886)	
63	O		Tape, Masking, A-A-883	

Expendable Supplies and Materials List (Cont)


(1) item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
64	0	8010-00-181-8079 8010-00-181-8080	Thinner, Aliphatic, Polyurethane Coat (MIL-T-81772) 5-gal drum	gal
65	0		Ties, Cable, Plastic (MIL-S-29190)	
66			Deleted	
67	F	5970-01-161-8031	Tubing, Heat Shrink (MIL-T-47051)	
68	F		Wood, 120 x 3.5 x 2 in. (3.048 x 88.9 x 50.8 mm)	
69	F		Wood block, 4 x 6 x 40 in. (102 x 152 x 1016 mm)	

APPENDIX D TORQUE LIMITS

D-1. GENERAL. This section provides general torque limits for screws used on the M977 series vehicles. Special torque limits are indicated in the maintenance procedures for applicable components. The general torque limits given in this appendix shall be used when specific torque limits are not indicated in the maintenance procedure. These general torque limits cannot be applied to screws that retain rubber components. The rubber components will be damaged before the torque limit is reached. If a special torque limit is not given in the maintenance instructions, tighten the screw or nut until it touches the metal bracket then tighten it one more turn.


D-2. TORQUE LIMITS. Table D-1 lists dry torque limits. Dry torque limits are used on screws that do not have lubricants applied to the threads. Table D-2 lists wet torque limits. Wet torque limits are used on screws that have high pressure lubricants applied to the threads. Table D-3 lists torque limits for the M983 (HIAB) crane.

D-3. HOW TO USE TORQUE TABLE:



TA357025

(1) Measure the diameter of the screw you are installing.



TA357026

(2) Count the number of threads per inch.

(3) Under the heading **SIZE**, look down the left hand column until you find the diameter of the screw you are installing (there will usually be two lines beginning with the same size).

(4) In the second column under **SIZE**, find the number of threads per inch that matches the number of threads you counted in step (2). (Not required for metric screws.)

CAPSCREW HEAD MARKINGS

Manufacturer's marks may vary. These are all SAE Grade 5 (3-line).	Metric screws are of three grades: 8.8, 10.9, and 12.9. Grades & Manufacturer's marks appear on the screw head.
STANDARD	METRIC

TA357028

(5) To find the grade screw you are installing, match the markings on the head to the correct picture of **CAPSCREW HEAD MARKINGS** on the torque table.

(6) Look down the column under the picture you found in step (5) until you find the torque limit (in lb-ft or N·m) for the diameter and threads per inch of the screw you are installing.

Torque Limits (Cont)





Table D-1. Torque Limits for Dry Fasteners

SIZE			TORQUE							
			SAE GRADE NO. 2		SAE GRADE NO. 5		SAE GRADE NO. 6 or 7		SAE GRADE NO. 8	
DIA. INCHES	THREADS PER INCH	MILLIMETERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS
1/4	20	6.35	5	7	8	11	10	14	12	16
1/4	28	6.35	6	9	10	14	12	16	14	19
5/16	18	7.94	11	15	17	23	21	28	25	34
5/16	24	7.94	12	16	19	26	24	33	25	34
3/8	16	9.53	20	27	30	41	40	54	45	61
3/8	24	9.53	23	31	35	47	45	61	50	68
7/16	14	11.11	30	41	50	68	60	81	70	95
7/16	20		35	47	55	75	70	95	80	108
1/2	13	12.70	50	68	75	102	95	129	110	149
1/2	20		55	75	90	122	100	136	120	163
9/16	12	14.29	65	88	110	149	135	183	150	203
9/16	18		75	102	120	163	150	203	170	231
5/8	11	15.88	90	122	150	203	190	258	220	298
5/8	18		100	136	180	244	210	285	240	325
3/4	10	19.05	160	217	260	353	320	434	380	515
3/4	16		180	244	300	407	360	488	420	597
7/8	9	22.23	140	190	400	542	520	705	600	814
7/8	14		155	210	440	597	580	786	660	895
1	8	25.40	220	298	580	786	800	1085	900	1220
1	12		240	325	640	868	860	1166	1000	1356
1-1/8	7	25.58	300	407	800	1085	1120	1519	1280	1736
1-1/8	12		340	461	880	1193	1260	1709	1440	1953
1-1/4	7	31.75	420	570	1120	1519	1580	2142	1820	2468
1-1/4	12		460	624	1240	1681	1760	2387	2000	2712
1-3/8	6	34.93	560	759	1460	1980	2080	2820	2380	3227
1-3/8	12		640	868	1680	2278	2380	3227	2720	3688
1-1/2	6	38.10	740	1003	1940	2631	2780	3770	3160	4285
1-1/2	12		840	1139	2200	2983	3100	4204	3560	4827

CAPSCREW HEAD MARKINGS



Manufacturer's marks may vary. These are all SAE Grade 5 (3-line).



TA357027

Torque Limits (Cont)





Table D-2. Torque Limits for Wet Fasteners

SIZE			TORQUE							
			SAE GRADE NO. 2		SAE GRADE NO. 5		SAE GRADE NO. 6 or 7		SAE GRADE NO. 8	
DIA INCHES	THREADS PER INCH	MILLIMETERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS
1/4	20	6.35	4	6	6	8	8	11	9	12
1/4	28	6.35	5	7	7	9	9	12	10	14
5/16	18	7.94	8	11	13	18	16	22	18	24
5/16	24	7.94	9	12	14	19	18	24	20	27
3/8	16	9.53	15	20	23	31	30	41	35	47
3/8	24	9.53	17	23	25	34	30	41	35	47
7/16	14	11.11	24	33	15	47	45	61	55	75
7/16	20		25	34	40	54	50	68	60	81
1/2	13	12.70	35	47	55	75	70	95	80	108
1/2	20		40	54	65	88	80	108	90	122
9/16	12	14.29	50	68	80	108	100	136	110	149
9/16	18		55	75	90	122	110	149	130	176
5/8	11	15.88	70	95	110	149	140	190	170	231
5/8	18		80	108	1:30	176	160	217	180	244
3/4	10	19.05	120	163	200	271	240	325	280	x-x)
3/4	16		140	190	220	298	280	380	320	434
7/8	9	22.23	110	149	300	407	400	542	460	624
7/8	14		120	163	320	434	440	597	500	678
1	8	25.40	160	217	440	597	600	814	680	922
1	12		170	231	480	651	660	895	740	1003
1-1/8	7	25.58	220	298	600	814	840	11:39	960	1302
1-1/8	12		260	353	660	895	940	1275	1080	1464
1-1/4	7	31.75	320	434	840	1139	1100	1492	1360	1844
1-1/4	12		360	488	920	1248	1320	1790	1500	2034
1-3/8	6	34.93	420	570	1100	1492	1560	2115	1780	2414
1-3/8	12		460	624	1260	1709	1780	2414	2040	2766
1-1/2	6	38.10	560	760	1460	1980	2080	2820	2360	3200
1-1/2	12		620	841	6 4 0	2224	2320	3146	2660	3607

CAPSCREW HEAD MARKINGS






Manufacturer's marks may vary. These are all SAE Grade 5 (3-line).



TA357027

Torque Limits (Cont)

Table D-3. Dry Torque Limits for M983 Crane (Metric)

CAPSCREW HEAD MARKINGS							
							
		TA357029					
SIZE		TORQUE					
		METRIC GRADE 8.8		METRIC GRADE 10.9		METRIC GRADE 12.9	
DIA INCHES	MILLIMETERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS
.157	4	2	3	3	4	4	5
.197	5	4	5	6	8	7	9
.237	6	7	9	10	14	11	15
.276	7	11	15	16	22	20	27
.315	8	18	24	25	34	29	39
.394	10	32	43	47	64	58	79
.473	12	58	79	83	113	100	136
.552	14	94	127	133	180	159	216
.630	16	144	195	196	266	235	319
.709	18	190	258	269	365	323	438
.788	20	260	353	366	496	440	597
.867	22	368	499	520	705	678	919
.946	24	470	637	664	900	794	1077
1.064	27	707	959	996	1351	1235	1675
1.182	30	967	1311	1357	1840	1630	2210

INDEX

Subject	Paragraph, Figure, Table Number
A	
Accumulator (M977, M985) removal/repair/charging/installation	17-30
Actuated, air, valve spring compression tool, V5, (M978) (PN 2SK886)	F B-8
Actuator and V5 air actuated flow valve (M978) repair/adjustment.	22-14
Adapter, V2 bottom load (M978) repair	22-11
Adhesive and solvent warning.	a
Adjustment, hoist (M977, M985)	17-25
Adjustment, hoist (M984E1)	17-25.1
Adjustment, main hydraulic pressure (M977, M985)	17-31
Adjustment, main hydraulic pressure (M984E1)	17-31.1
Air actuated flow valve, V5, and actuator (M978) repair/adjustment.	22-14
Air actuated valve spring compression tool, V5, (M978) (PN 2SK886)	F B-8
Air and electrical components, tanker gages.	F 22-5
Air eliminator (M978) repair	22-9
Alarm, M-8 chemical, kit initial installation	23-8
Ancillary equipment engine idle speed (M984) adjustment	20-6
Appendixes	
A, References	A-1
B, Illustrated list of manufactured items.	B-1
C, Expendable supplies and material list.	C-1
D, Torque limits	D-1
Arctic engine heater kit initial installation	23-2
Arctic heater kit, engine repair.	21-2
Arctic heater test set	F B-5
Asbestos warning	c
Assembly, hoist, and pivot bushing (M977, M985, M984E1) removal/installation	17-20
Assembly, hoist (M977, M985, M984E1) repair	17-23
Assembly, self-recovery winch control valve repair	20-4
Auxiliary equipment and special purpose kits maintenance references	A-3
AUXILIARY PUMP (M978) repair	22-5
Auxiliary/winch hydraulics relief valve (M983, M984) repair	20-3
B	
Ball compression tool, detent, (heavy-duty winch) (PN IPP161)	F B-3
Bank valve body, eight (M977, M985) repair	17-28
Bank valve body, eight, and mounting bracket (M977, M985) removal/installation	17-26
Bank valve body mounting bracket, eight, (M977, M985) removal/installation	17-27
Batteries, terminals, and cables warning	c
Beam, inner and outer, cylinder, outrigger (M984E1) repair	17-41
Beam, inner, extension cylinder, outrigger (M984E1) removal/installation	17-40
Beam, inner, outrigger (M984E1) removal/installation	17-38.2
Beam, outer and extension cylinder, outrigger (M984E1) removal/installation	17-38.1
Bearing and turntable (M977, M985) removal/installation	17-5
Bearing and turntable (M984E1) removal/installation	17-5.1
Body, eight bank valve (M977, M985) repair	17-28

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Body, eight bank valve, and mounting bracket (M977, M985) removal/installation	17-26
Body, eight bank valve mounting bracket (M977, M985) removal/installation	17-27
Body, left hand control valve (M984E1) removal/repair/installation	17-28.2
Body, right hand front control valve (M984E1) removal/repair/installation	17-28.4
Body, right hand rear control valve (M984E1) removal/repair/installation	17-28.3
Boom (M977, M985) removal/installation	17-10
Boom (M984E1) removal/installation	17-10.1
Boom, cylinder, inner (M983)	
Boom cylinders, hoses, and tubes	F 17-5
	F 17-6
Boom cylinders, hoses and tubes	T 17-5
Boom cylinders, hoses and tubes	T 17-6
Bore bushing tool, unloader	F B-9
Bottom load-adapter, V2 (M978) repair	22-11
Bottom load precheck valve (M978) repair	22-19
Bottom load valve, V10 (M978) repair	22-17
Box, control, crane	
Bracket, mounting, and eight bank valve body (M977, M985) removal/installation	17-26
Bracket, mounting, eight bank valve body (M977, M985) removal/installation	17-27
Bracket, mounting, right hand control valves (M984E1) removal/installation	17-28.1
Brake, hoist (M977, M985)removal/repair/installation	17-24
Brake, hoist (M984E1) removal/repair/installation	17-24.1
Brake, swing drive (M977, M985) removal/repair/installation	17-8
Brake, swing drive (M984E1) removal/repair/installation	17-8.1
Bulk delivery valve, V18 repair	22-22
Bushing tool, bore, unloader.	F B-9
Bushings and mast (M977, M985) removal/installation	17-11
Bushings and mast (M984E1) removal/installation	17-11.1
Bushings, pivot, and hoist assembly (M977, M985, M984E1) removal/installation	17-20
Bypass, V4/pressure relief valve (M978) repair	22-13
Carbon monoxide (exhaust gas) warning	a
Case, engine, transmission ,and transfer, shipping and storage containers	
Packing and Unpacking	23-9
Service and Repair	23-10
Chemical alarm, M-8, kit initial installation	23-8
Cold weather operation and maintenance references	A-4
Compressed air warning	c

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Compression tool, detent ball, (heavy-duty winch) (PN IPP161)	F B-3
Compression tool, V5 air actuated valve spring (M978) (PN 2SK886)	F B-8
Container, shipping and storage, preparation for	
Engine	23-11
Transmission	23-12
Containers, shipping and storage, engine, transmission, and transfer case	
Packing and Unpacking	23-9
Service and Repair	23-10
Control valve assembly, self-recovery winch repair	20-4
Control valve body, left hand (M984E1) removal/repair/installation.	17-28.2
Control valve body, right hand front (M984E1) removal/repair/installation.	17-28.4
Control valve body, right hand rear (M984E1) removal/repair/installation	17-28.3
Control valve, hoist drive motor (M977, M985) removal/repair/installation	17-21
Control valve, hoist drive motor (M984E1) removal/repair/installation	17-21.1
Control valve, primary pump hydraulic motor (M978) repair	20-7
Control valve, retriever (M984E1) repair	20-10
Control valves mounting bracket, right hand (M984E1) removal/installation	17-28.1
Crane cylinder test	17-42
Crane (M977, M985) removal/installation	17-3
Crane (M984E1) removal/installation	17-3.1
Crane electrical schematic.	FO-3
Crane hoist drive unit pressure plate removal/installation tool (M983)	F B-4
Crane hydraulic schematics.	FO-1
Crane wiring diagram	FO-2
Cylinder and wear pads, extension No. 1 and No. 2 (M977, M985) removal/installation	17-18
Cylinder and wear pads, extension No. 1 and No. 2 (M984E1) removal/installation	17-18.1
Cylinder, crane test	17-42
Cylinder, erection	
Removal/Installation (M977, M985).	17-14
Removal/Installation (M984E1)	17-14.1
Repair (M977, M985, M984E1)	17-15
Cylinder, extension (M977, M985) repair	17-19
Cylinder, extension (M984E1) repair	17-19.1

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Cylinder, extension, and outer beam, outrigger (M984E1) removal/installation	17-38.1
Cylinder, extension, outrigger inner beam (M984E1) removal/installation.	17-40
Cylinder, inner and outer beam, outrigger (M984E1) repair.	17-41
Cylinder, inner boom (M983)	
Cylinder, lift	
Removal/Installation (M977, M985)	17-16
Removal/Installation (M984E1)	17-16.1
Repair (M977, M985, M984E1)	17-17
Cylinder, outrigger extension (M977, M985)	
Removal/Installation.	17-38
Repair	17-39
Cylinder, outrigger leg	
Removal/Installation (M977, M985)	17-35
Removal/Installation (M984E1)..	17-36.1
Repair (M977, M985)	17-36
Repair (M984E1)	17-36.2
Cylinder, tension (M984E1) removal/repair/installation	17-19.2
Cylinders, extension No. 1 and No. 2 and wear pads (M977, M985) removal/installation.	17-18
D	
Decontamination kit initial installation	23-7
Decontamination references.	A-2
DEFUEL valve repair, V-6 FUEL.	22-15
Delivery valve, V18 bulk (M978) repair	22-22
Detent ball compression tool (heavy-duty winch) (PN IPP161)	F B-3
Dispensing components-valves, tanker	F 22-3
Dispensing components, manual, and tanker filter	F 22-2
Drive brake, swing (M977, M985) removal/repair/installation	17-8
Drive brake, swing (M984E1) removal/repair/installation	17-8.1
Drive motor, hoist, control valve (M977, M985) removal/repair/installation	17-21
Drive motor, hoist, control valve (M984E1) removal/repair/installation	17-21.1
Drive motor, hoist (M977, M985) removal/repair/installation	17-22
Drive motor, hoist (M984E1) removal/repair/installation	17-22.1
Drive motor, swing (M977, M985) removal/repair/installation	17-7
Drive motor, swing (M984E1) removal/repair/installation	17-7.1
Drive, swing (M977, M985) removal/repair/installation	17-9
Drive, swing (M984E1) removal/repair/installation.	17-9.1
Drive unit, hoist (M983)	
Drive unit pressure plate, crane hoist removal/installation tool.	F B-4

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Drive valve, swing (M977, M985) removal/repair/installation	17-6
Drive valve, swing (M984E1) removal/repair/installation	17-6.1
Dry torque limits for M983 crane (metric)	T D-3
E	
Eight bank valve body and mounting bracket (M977, M985) removal/installation	17-26
Eight bank valve body mounting bracket (M977, M985) removal/installation	17-27
Eight bank valve body (M977, M985) repair	17-28
Electrical components, tanker gages, air	F 22-5 FO-3
Eliminator, air (M978) repair	22-9
Emergency valve, V1 (M978) repair.	22-10
Engine arctic heater kit initial installation	23-2
Engine arctic heater kit repair.	21-2
Engine idle speed, ancillary equipment (M984) adjustment.	20-6
Engine, preparation for shipping and storage container	23-11
Engine, transmission, and transfer case, shipping and storage containers Packing and Unpacking	23-9
Service and Repair	23-10
Equipment, ancillary, engine idle speed (M984) adjustment	20-6
Erection cylinder Removal/Installation (M977, M985)	17-14
Removal/Installation (M984E1).	17-14.1
Repair (M977, M985, M984E1).	17-15
Expendable supplies and materials list, Appendix C	C-1
Extension cylinder (M977, M985) repair	17-19
Extension cylinder (M984E1) repair	17-19.1
Extension cylinder and outer beam, outrigger (M984E1) removal/installation	17-38.1
Extension cylinder, outrigger (M977, M985) Removal/Installation	17-38
Repair	17-39
Extension cylinder, outrigger inner beam (M984E1) removal/installation	17-40
Extension No. 1 and No. 2 cylinder and wear pads (M977, M985) removal/installation	17-18
Extension No. 1 and No. 2 cylinder and wear pads (M984E1) removal/installation	17-18.1
Extension No. 1 and wear pads (M977, M985) removal/installation	17-12
Extension No. 1 and wear pads (M984E1) removal/installation.	17-12.1
Extension No. 2 and wear pads (M977, M985) removal/installation	17-13
Extension No. 2 and wear pads (M984E1) removal/installation.	17-13.1

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Extensions, outrigger (M977, M985) removal/installation	17-37
External components, tanker.	F 22-1
Eyes, lifting (PN 2BH944)	F B-1
F	
Filter and manual dispensing components, tanker	F 22-2
Filter unit, gas particulate (GPFU) kit initial installation	23-6
Fittings, hoses, and tubes, hydraulic (M977, M985) removal/installation	17-2
Fittings, hoses, tubes, hydraulic (M984E1) removal/installation	17-2.1
Flowmeter (M978)	
Removal/Installation	22-7
Repair	22-8
Flowmeter register (M978) removal/installation	22-6
Flow regulating valve, V11 (M978) repair	22-18
Flow valve, V5 air actuated, and actuator (M978) repair/adjustment	22-14
Forms, reference	A-1
Front control valve body, right hand (M984E1) removal/repair/installation.	17-28.4
FUEL/DEFUEL valve, V6 (M978) repair	22-15
Fuel service nozzle (M978) repair	22-24
Fuel tank truck maintenance	22-1
Fuel warning	a
G	
Gages, air and electrical components, tanker	F 22-5
Gas particulate filter unit (GPFU) kit initial installation	23-6
General references	A-3
(GPFU), gas particulate filter unit, initial installation	23-6
Gravity valve, V17 (M978) repair	22-12
Gun, machine, ring kit initial installation	23-3
Gun ring kit, machine initial installation	23-3
H	
Hand pump, hydraulic (M983) repair	20-2
Heater kit, engine arctic, initial installation	23-2
Heater kit, engine arctic repair.	21-2
Heater test set, arctic	F B-5
Heavy-duty selector valve (M984) repair	20-5
Heavy-duty winch, detent ball compression tool (PN IPP161)	F B-3
Heavy-duty winch manifold (M984E1)	
Removal/Installation	20-8
Repair	20-9

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
High voltage warning	b
Hoist adjustment (M977, M985)	17-25
Hoist adjustment (M984E1)	17-25.1
Hoist assembly (M977, M985, M984E1) repair	17-23
Hoist assembly and pivot bushings (M977, M985, M984E1) removal/installation.	17-20
Hoist brake (M977, M985) removal/repair/installation	17-24
Hoist brake (M984E1) removal repair/installation.	17-24.1
Hoist check valve (M983)	
Hoist drive motor (M977, M985) removal/repair/installation	17-22
Hoist drive motor (M984E1) removal/repair/installation	17-22.1
Hoist drive motor control valve (M977, M985) removal/repair/installation	17-21
Hoist drive motor control valve (M984E1) removal/repair/installation.	17-21.1
Hoist drive unit (M983)	
Hoist drive unit pressure plate, crane, removal/installation tool (M983)	F B-4
Hoist hoses and tubes (left side).	F 17-1
Hoist hoses and tubes (left side).	T 17-1
Hoist hoses and tubes (right side).	F 17-2
Hoist hoses and tubes (right side)..	T 17-2
Hoses, tubes, and fittings, hydraulic (M977, M985) removal/installation	17-2
Hoses, tubes, and fittings, hydraulic (M984E1) removal/installation	17-2.1
Hot exhaust pipe/muffler warning	b
Hot radiator	b
Hydraulic hand pump (M983) repair.	20-2
Hydraulic hoses, tubes, and fittings (M977, M985) removal/installation.	17-2
Hydraulic hoses, tubes, and fittings (M984E1) removal/installation	17-2.1
Hydraulic motor control valve, primary pump (M978) repair	20-7
Hydraulic motor, primary pump (M978) repair	22-3
Hydraulic pressure, main (M977, M985) adjustment	17-31
Hydraulic pressure, main (M984E1) adjustment	17-31.1
Hydraulic pump repair	19-3
Hydraulic pump (M984E1) repair	19-4
Hydraulic pump and power takeoff (PTO) maintenance	19-1
Hydraulic relief valve, winch/auxiliary (M983, M984) repair.	20-3

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Hydraulic schematics	FO-1
I	
Idle speed, ancillary equipment engine (M984) adjustment	20-6
Illustrated list of manufactured items, Appendix B	B-1
Illustrations, list of	iv
Initial installation, decontamination kit	23-7
Initial installation, engine arctic heater kit	23-2
Initial installation, gas particulate filter unit (GPFU) kit.	23-6
Initial installation, M-8 chemical alarm kit	23-8
Initial installation, M-16 rifle mount kit	23-4
Initial installation, machine gun ring kit	23-3
Initial installation, radio kit	23-5
Inner and outer beam cylinder, outrigger (M984E1) repair	17-41
Inner beam extension cylinder, outrigger (M984E1) removal/installation.. . . .	17-40
Inner beam, outrigger (M984E1) removal/installation	17-38.2
Inner boom cylinder (M983)	
Inspection, tanker service.	22-2
J	
Jet level sensor, V19 (M978) repair	22-23
Jewelry, wearing, warning	a
K	
Kit, decontamination, initial installation	23-7
Kit, engine arctic, initial installation	23-2
Kit, engine arctic heater repair.	21-2
Kit, gas particulate filter unit (GPFU), initial installation	23-6
Kit, M-8 chemical alarm, initial installation	23-8
Kit, M-16 rifle mount, initial installation	23-4
Kit, machine gun ring, initial installation	23-3
Kit, radio, initial installation.	23-5
Kits, special purpose	23-1
L	
Left hand control valve body (M984E1) removal/repair/installation	17-28.2
Removal/Installation (M977, M985)	17-35
Removal/Installation (M984E1).	17-36.1
Repair (M977, M985)	17-36
Repair (M984E1)	17-36.2
Level sensor, V19 jet (M978) repair	22-23
Removal/Installation (M977, M985)	17-16
Removal/Installation (M984E1).	17-16.1
Repair (M977, M985, M984E1).	17-17
Lift down and shutdown solenoids (M977, M985) removal/repair/installation	17-32
Lift down and shut down solenoids (M984E1) removal/repair/installation	17-2.1
Lifting eyes (PN SBH944)F B-1

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Line valve, V3 suction/V17 gravity valve (M978) repair	22-12
List of	
Illustrations	iv
Tables	vii
Load adapter, V2 bottom (M978) repair	22-11
Load precheck valve, bottom, V12/sampling probe valve (M978) repair	22-19
Load valve, bottom, V10 (M978) repair	22-17
Low voltage	b
M	
M-8 chemical alarm kit initial installation	23-8
M-16 rifle mount kit initial installation	23-4
Machine gun ring kit initial installation	23-3
Main control valve	F 17-10
Main control valve	T 17-10
Main hydraulic pressure (M977, M985) adjustment	17-31
Main hydraulic pressure (M984E1) adjustment	17-31.1
Main hydraulic hoses and tubes	F 17-9
Main hydraulic hoses and tubes	T 17-9
Maintenance and repair references	A-2
Maintenance, tanker	22-1
Manifold, heavy-duty winch (M984E1)	
Removal/Installation	20-8
Repair	20-9
Manufactured items list	B-1
Mast and bushings (M977, M985) removal/installation	17-11
Mast and bushings (M984E1) removal/installation	17-11.1
Mast erection cylinder, tubes, and hoses	F 17-7
Mast erection cylinder, tubes, and hoses	T 17-7
Materials list, expendable supplies and	C-1
Meter, flow (M978)	
Removal/Installation	22-7
Repair	22-8
Meter, flow, register (M978) removal/installation	22-6
Motor, control valve, primary pump hydraulic (M978) repair	20-7
Motor, hoist drive (M977, M985) removal/repair/installation	17-22
Motor, hoist drive (M984E1) removal/repair/installation	17-22.1
Motor, hoist drive, control valve (M977, M985) removal/repair/installation	17-21
Motor, hoist drive, control valve (M984E1) removal/repair/installation	17-21.1
Motor, primary pump hydraulic (M978) repair	22-3
Motor, swing drive (M977, M985) removal/repair/installation	17-7
Motor, swing drive (M984E1) removal/repair/installation	17-7.1
Mount kit, M-16 rifle initial installation	23-4

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Mounting bracket and eight bank valve body (M977, M985) removal/installation.	17-26
Mounting bracket, eight bank valve body (M977, M985) removal/installation.	17-27
Mounting bracket, right hand control valves (M984E1) removal/installation.	17-28.1
N	
No. 1 extension and wear pads (M977, M985) removal/installation	17-12
No. 1 extension and wear pads (M984E1) removal/installation.	17-12.1
No. 2 extension and wear pads (M977, M985) removal/installation	17-13
No. 2 extension and wear pads (M984E1) removal/installation.	17-13.1
No. 1 and No. 2 extension cylinder and wear pads (M977, M985) removal/installation	17-18
No. 1 and No. 2 extension cylinder and wear pads (M984E1) removal/installation.	17-18.1
No. 1 and No. 2 extensions hydraulic cylinder pipes, tubes, and fittings (M983) removal/	
Nozzle, fuel service (M978)	22-24
Nuclear, biological, or chemical warning	c
O	
Outer and inner beam cylinder, outrigger (M984E1) repair	17-41
Outer beam and extension cylinder, outrigger (M984E1) removal/installation.	17-38.1
outrigger (M977, M985) removal/installation	17-34
Removal/installation	17-38
Repair	17-39
Outrigger extensions (M977, M985) removal/installation	17-37
Outrigger inner and outer beam cylinder (M984E1) repair.	17-41
Outrigger inner beam (M984E1) removal/installation.	17-38.2
Outrigger inner beam extension cylinder (M984E1) removal/installation.	17-40
Removal/Installation (M977, M985)	17-35
Removal/Installation (M984E1).	17-36.1
Repair (M977, M985)	17-36
Repair (M984E1)	17-36.2
Outrigger outer beam and extension cylinder (M984E1) removal/installation	17-38.1

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Overload sensor switch (M977, M985) adjustment	17-33
Overload sensor switch (M984E1) adjustment	17-33.1
Overload solenoid (M977 only)	F 17-11
Overload solenoid (M977 only)	T 17-11
P	
Packing and unpacking, shipping and storage containers, engine, transmission, and transfer case	23-9
Pads, extension No. 1 and No. 2 cylinder and wear (M977, M985) removal/installation	17-18
Pads, extension No. 1 and No. 2 cylinder and wear (M984E1) removal/installation	17-18.1
Pads, extension No. 1 and wear (M977, M985) removal/installation	17-12
Pads, extension No. 1 and wear (M984E1) removal/installation	17-12.1
Pads, extension No. 2 and wear (M977, M985) removal/installation	17-13
Pads, extension No. 2 and wear (M984E1) removal/installation	17-13.1
Parking brake, incorrect use of, warning	a
Particulate filter unit, gas (GPFU) kit initial installation	23-6
Pilot valve, V14 (M978) repair	22-21
Pivot bushings and hoist assembly (M977, M985, M984E1) removal/installation	17-20
Power takeoff (PTO) repair	19-2
Power takeoff (PTO) (M984E1) repair	19-2.1
Power takeoff (PTO) and hydraulic pump maintenance.	19-1
Precheck valve, V12 bottom load (M978) repair	22-19
Preparation for shipping and storage container	
Engine	23-11
Transmission	23-12
Pressure, main hydraulic (M977, M985) adjustment	17-31
Pressure, main hydraulic (M984E1) adjustment	17-31.1
Pressure relief valve, V-4 bypass (M978) repair	22-13
Primary pump (M978) repair	22-4
Primary pump hydraulic motor (M978) repair	22-3
Primary pump hydraulic motor control valve (M978) repair	20-7
Probe valve, sampling repair	22-19
(PTO), power takeoff repair	19-2
(PTO), power takeoff (M984E1) repair	19-2.1
Publication references	
Cold weather operation and maintenance.	A-1

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Publication references (Cont)	
Decontamination	A-2
General	A-3
Maintenance and repair	A-2
Maintenance of auxiliary equipment and special purpose kits	A-3
Safety	A-1
Vehicle operation	A-1
Warranty	A-3
PUMP, AUXILIARY (M978) repair	22-5
Pump, hand hydraulic (M983) repair	20-2
Pump, hydraulic motor, primary (M978) repair	22-3
Pump, hydraulic repair	19-3
Pump, hydraulic (M984E1) repair	19-4
Pump, hydraulic motor control valve, primary (M978) repair	20-7
Pump, primary (M978) repair	22-4
R	
Radio kit initial installation..	23-5
Rear control valve body, right hand (M984E1) removal/repair/installation	17-28.3
Reel valve,V7/V8 (M978) repair.	22-16
References, Appendix A.	A-1
Register, flow meter (M978) removal/installation	22-6
Regulating valve, V11 flow (M978) repair	22-18
Relief valve, pressure, V4 bypass (M978) repair	22-13
Relief valve, winch/auxiliary hydraulic (M983, M984) repair	20-3
Repair and service, shipping and storage containers, engine, transmission, and transfer case	23-10
Retriever control valve (M984E1) repair	20-10
Rifle mount kit, M16, initial installation	23-4
Right hand control valves mounting bracket (M984E1) removal/installation	17-28.1
Right hand front control valve body (M984E1) removal/repair/installation	17-28.4
Right hand rear control valve body (M984E1) removal/repair/installation	17-28.3
Ring kit, machine gun, initial installation	23-3
S	
Safety references	A-1
Sampling probe valve (M978) repair	22-19
Seal retainer tool (M983) (PN 2CS31)	F B-7
Seat belts	b
Selector valve, heavy-duty (M984) repair	20-5
Self-recovery winch control valve assembly repair	20-4
Sensor switch, overload (M977, M985) adjustment	17-33
Sensor switch, overload (M984E1) adjustment	17-33.1
Sensor, V19 jet level (M978) repair	22-23
Service and repair, shipping and storage containers, engine, transmission, and transfer case.	23-10
Service nozzle, fuel repair.	22-24
Service, tanker, inspection..	22-2

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Shims	F B-2
Shipping and storage container, preparation for	
Engine	23-11
Transmission	23-12
Shipping and storage containers, engine, transmission, and transfer case	
Packing and Unpacking	23-9
Service and Repair	23-10
Shut down and lift down solenoids (M977, M985) removal/repair/installation	17-32
Shut down and lift down solenoids (M984E1) removal/repair/installation	17-32.1
Solenoid (M977, M985) removal/installation	17-29
Solenoid (M984E1) removal/installation	17-29.1
Solenoids, lift down and shut down (M977, M985) removal/repair/installation	17-32
Solenoids, lift down and shutdown (M984E1) removal/repair/installation	17-32.1
Special purpose kits installation	23-1
Speed, ancillary equipment engine idle (M984) adjustment	20-6
Starting fluid warning	c
Stop, turntable (M984E1) removal/installation	17-5.2
Storage and shipping container, preparation for	
Engine	23-11
Transmission	23-12
Storage and shipping containers, engine, transmission, and transfer case	
Packing and Unpacking	23-9
Service and Repair	23-10
Stowage box, remote control (M983) removal/installation	18-47
Subframe (M977, M985, M984E1) removal/installation	17-4
Suction line valve, V3 (M978) repair	22-12
Supplies, expendable	C-1
Swing drive (M977, M985) removal/repair/installation	17-9
Swing drive (M984E1) removal/repair/installation	17-9.1
Swing drive brake (M977, M985) removal/repair/installation	17-8
Swing drive brake (M984E1) removal/repair/installation	17-8.1
Swing drive hoses and tubes	F 17-8
Swing drive hoses and tubes	T 17-8
Swing drive motor (M977, M985) removal/repair/installation	17-7
Swing drive motor (M984E1) removal/repair/installation	17-7.1
Swing drive valve (M977, M985) removal/repair/installation	17-6
Swing drive valve (M984E1) removal/repair/installation	17-6.1
Switch, overload sensor (M977, M985) adjustment	17-33
Switch, overload sensor (M984E1) adjustment	17-33.1

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
T	
Table of contents	i
Tables, list of	vii
Takeoff, power (PTO) repair	19-2
Takeoff, power (PTO) (M948E1) repair	19-2.1
Tank truck, fuel, maintenance (M978)	22-1
Tanker dispensing components-valves	F 22-3
Tanker external components.	F 22-1
Tanker filter and manual dispensing components	F 22-2
Tanker gages, air, and electrical components	F 22-5
Tanker loading and unloading components	F 22-4
Tanker maintenance	22-1
Tanker service and inspection.	22-2
Telescoping cylinders, hoses, and tubes	F 17-3
	T 17-4
Telescoping cylinders, hoses, and tubes	F 17-3
	T 17-4
Tension cylinder (M984E1) removal/repair/installation	17-19.2
Test, crane cylinder	17-42
Torque limits for dry fasteners	T D-1
Torque limits for wet fasteners	T D-2
Torque limits, Appendix D	D-1
How to use torque tables	D-1
Table D-1 (dry fasteners)	D-2
Table D-2 (wet fasteners)	D-3
Table D-3 (metric, M983 crane)..	D-4
Trailer brake warning	b
Transfer case, engine , and transmission, shipping and storage containers	
Packing and Unpacking	23-9
Service and Repair	23-10
Transmission, preparation for shipping and storage container	23-12
Transmission, transfer case, and engine shipping and storage containers	
Packing and Unpacking	23-9
Service and Repair	23-10
Tubes, fittings, and hoses, hydraulic (M977, M985) removal/installation	17-2
Tubes, hoses, and fittings, hydraulic (M984E1) removal/installation	17-2.1
Turntable and bearing (M977, M985) removal/installation	17-5
Turntable and bearing (M984E1) removal/installation	17-5.1
Turntable stop (M984E1) removal/installation.	17-5.2

INDEX (CONT)


Subject	Paragraph, Figure, Table Number
u	
Unit, gas particulate filter (GPFU) kit initial installation	23-6
Unloader bore bushing tool	F B-9
Unpacking and packing, shipping and storage containers, engine, transmission, and transfer case	23-9
v	
V1 emergency valve (M978) repair	22-10
V2 bottom load adapter (M978) repair	22-11
V3 suction line valve (M978) repair	22-12
V4 bypass/pressure relief valve (M978) repair	22-13
V5 air actuated flow valve and actuator (M978) repair/adjustment	22-14
V5 air actuated valve spring compression tool (M978) (PN 2SK886)	F B-8
V6 FUEL/DEFUEL valve (M978) repair	22-15
V7/V8 reel valve (M978) repair	22-16
V10 bottom load valve (M978) repair	22-17
V11 flow regulating valve (M978) repair	22-18
V12 bottom load precheck valve (M978) repair	22-19
V13 vent valve (M978) repair	22-20
V14 pilot valve (M978) repair	22-21
V17 gravity valve (M978) repair	22-12
V18 bulk delivery valve (M978) repair	22-22
V19 jet level sensor (M978) repair	22-23
Valve body, eight bank (M977, M985) repair	17-28
Valve body, eight bank, and mounting bracket (M977, M985) removal/installation	17-26
Valve body, left hand control (M984E1) removal/repair/installation	17-28.2
Valve body mounting bracket, eight bank (M977, M985) removal/installation.	17-27
Valve body, right hand front control (M984E1) removal/repair/installation	17-28.4
Valve body, right hand rear control (M984E1) removal/repair/installation.	17-28.3
Valve, control, hoist drive motor (M977, M985) removal/repair/installation	17-21
Valve, control, hoist drive motor (M984E1) removal/repair/installation.	17-21.1
Valve, control, primary pump hydraulic motor (M978) repair	20-7
Valve, control, self-recovery winch, assembly repair	20-4
Valve, pilot, V14 (M978) repair.	22-21
Valve, pressure relief, V4 bypass (M978) repair	22-13
Valve, relief, winch/auxiliary hydraulic (M983, M984) repair	20-3
Valve, retriever control (M984E1) repair	20-10
Valve, sampling probe (M978) repair	22-19

INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Valve seat tool (M983) (PN 2CS30)	F B-6
Valve, swing drive (M977, M978) removal/repair/installation	17-6
Valve, swing drive (M984E1) removal/repair/installation.	17-6.1
Valve, V1 emergency (M978) repair	22-10
Valve, V3 suction line (M978) repair.	22-12
Valve, V5 air actuated flow, and actuator (M978) repair/adjustment	22-14
Valve, V6 FUEL, DEFUEL (M978) repair.	22-15
Valve, V7/V8 reel (M978) repair	22-16
Valve, V10 bottom load (M978) repair	22-17
Valve, V11 flow regulating (M978) repair.	22-18
Valve, V12, bottom load precheck (M978) repair	22-19
Valve, V13 vent (M978) repair.	22-20
Valve, V14 pilot (M978) repair.	22-21
Valve, V17 gravity (M978) repair	22-12
Valve, V18 bulk delivery (M978)	22-22
Valves, right hand control, mounting bracket (M984E1) removal/installation	17-28.1
Vehicle operation references.	A-1
Vent valve, V13 (M978) repair	22-20
w	
Warnings	
Adhesives and solvents	a
Asbestos in brake linings	c
Batteries, terminals, and cables	c
Carbon monoxide (exhaust gas)	a
Compressed air	c
Crane operation under powerlines.	b
Fuel	a
High voltage	b
Hot exhaust pipe/muffler	b
Hot radiator	b
Jewelry, wearing of	a
“Low” voltage	b
Nuclear, biological, or chemical (NBC) exposure	c
Parking brake, incorrect use of	a
Seatbelts, use of	b
Starting fluid	c
Trailer brakes	b
Winch cable, handling of	b
Winch operation	b
Warranty references	A-3
Wear pads and cylinder extension No. 1 and No. 2 (M977, M985) removal/installation	17-18
Wear pads and cylinder, extension No. 1 and No. 2 (M984E1) removal/installation	17-18.1
Wear pads and extension No. 1 (M977, M985) removal/installation	17-12
Wear pads and extension No. 1 (M984E1) removal/installation	17-12.1
Wear pads and extension No. 2 (M977, M985) removal/installation	17-13
Wear pads and extension No. 2 (M984E1) removal/installation	17-13.1
Winch/auxiliary hydraulic relief valve (M983, M984) repair	20-3
Winch, heavy-duty, manifold (M984E1)	
Removal/Installation	20-8


INDEX (CONT)

Subject	Paragraph, Figure, Table Number
Winch, heavy-duty, manifold (M984E1) (Cont)	
Repair	20-9
Winch, self-recovery, control valve assembly repair	20-4
Wiring diagrams, cranes	FO-2




TA356936

FO-1. Hydraulic Schematic (M977, M985) (Sheet 1 of 11).




FO-1. Hydraulic Schematic (M985 Crane) (Sheet 3 of 11).
Change 3 FP-5/(FP-6 blank)




TA366939

FO-1. Hydraulic Schematic (M984E1) (Sheet 4 of 11).




FO-1. Hydraulic Schematic (M984E1 Crane) (Sheet 5 of 11).




TA356934


FO-1. Hydraulic Schematic (M978) (Sheet 6 of 11).



TA356932




TA356933




TA356931

FO-1. Hydraulic Schematic (M983 w/Crane) (Sheet 9 of 11).



TA356938

FO-1. Hydraulic Schematic (M983 Crane) (Sheet 10 of 11).



TA356935

FO-1. Hydraulic Schematic (M985E1) (Sheet 11 of 11).


LEGEND	
LETTER	COLOR
R	RED
W	WHITE
B	BLACK
U	BLUE
O	ORANGE
G	GREEN
N	BROWN
Y	YELLOW

LEGEND	
SYM	TERMINAL
→	MALE PIN
⊖	FEMALE RECEPT

ALL NUMBERED WIRES ARE WHITE.

COE#	POS#
843	1
310	2
012	3
435	4

(REF: 1M9 2320 279 20)



NOTE
RELAY MODULE AND
CABLE MODULE ARE
NOT REPAIRABLE

ALTERNATE LOCATION
FOR REMOTE CONTROL
CABLE

FO-2. Wiring Diagram (M977 Crane) (Sheet 1 of 3).


TA356953

FP-23/(FP-24 blank)

LEGEND	
LETTER	COLOR
R	RED
W	WHITE
B	BLACK
U	BLUE
O	ORANGE
G	GREEN
N	BROWN
Y	YELLOW

ALL NUMBERED WIRES ARE WHITE.


LEGEND	
SYM	TERMINAL
→	MALE PIN
⊥	FEMALE RECEPT



NOTE
RELAY MODULE AND
CABLE MODULE ARE
NOT REPAIRABLE


FO-2. Wiring Diagram (M985 Crane) (Sheet 2 of 3).

TA356954




FO-2. Wiring Diagram (M984E1 Crane) (Sheet 3 of 3).

TA356950




TA356948




FO-3. Electrical Schematic (M977 Crane) (Sheet 2 of 4).

TA356951



TA356947

FO-3. Electrical Schematic (M984E1 Crane) (Sheet 3 of 4).



TA356937

FO-3. Electrical Schematic (M983 Crane) (Sheet 4 of 4).

By Order of the Secretary of the Army

JOHN A. WICKHAM, JR.
General, United States Army
Chief of Staff

Official:

R.L. DILWORTH
Brigadier General United States Army
The Adjutant General

Distribution

To be distributed in accordance with DA Form 12-38, Direct and General Support Maintenance requirements for Truck, Cargo, 10-Ton, 8x8, Heavy Expanded Mobility, Tactical Truck, HEMTT, M977, M978, M983, M984, and M985.

RECOMMENDED CHANGES TO EQUIPMENT PUBLICATIONS



THEN - JOT DOWN THE INFO ON THIS FORM---TEAR OUT THIS PAGE---FOLD IT---AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (IMPRINT YOUR UNIT'S COMPLETE ADDRESS)

HQ & HQ CO.
46TH TRANS. BN.
FT. CARSON, CO

DATE SENT: 5 JAN., 1997

PUBLICATION NUMBER
TM 9-2320-279-34

PUBLICATION DATE
3 JUNE 1987

PUBLICATION TITLE DIRECT SUPPORT
AND GENERAL SUPPORT MAINTENANCE
MANUAL M977 Series Vehicles

BE EXACT...PINPOINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
21-8	21-2	NA	NA

IN THIS SPACE, TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

In para 21-2.c, Assembly, step (1) user is not cautioned about touching commutator.

Add caution to not touch commutator of armature during assembly so oils from skin will not damage it.

SAMPLE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER
ALBERT RAND, SSG, 226-5644

SIGN HERE:
Albert Rand

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT PUBLICATIONS



THEN - JOT DOWN THE INFO ON THIS FORM---TEAR OUT THIS PAGE---FOLD IT---AND DROP IT IN THE MAIL

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (IMPRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT:

PUBLICATION NUMBER
TM 9-2320-279-34-3

PUBLICATION DATE
3 JUNE 1987

PUBLICATION TITLE
DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL
M977 Series Vehicles

BE EXACT...PINPOINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
----------	------------	------------	-----------

IN THIS SPACE, TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 1 JUL 79 **2028-2**

PREVIOUS EDITIONS ARE OBSOLETE.

P.S. IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION, MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

TEAR ALONG PERFORATED LINE

DEPARTMENT OF THE ARMY



OFFICIAL BUSINESS

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS

BRM PERMIT NO. 82

ROCK ISLAND, IL

POSTAGE WILL BE PAID BY ROCK ISLAND ARSENAL



Director
Armament and Chemical Acquisition
and Logistics Activity
ATTN: AMSTA-AC-NML
ROCK ISLAND, IL 61201-9948



THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

SQUARE MEASURE

1 Sq Centimeter = 100 Sq Millimeters = 0.155 Sq Inches
 1 Sq Meter = 10,000 Sq Centimeters = 10.76 Sq Feet
 1 Sq Kilometer = 1,000,000 Sq Meters = 0.386 Sq Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

CUBIC MEASURE

1 Cu Centimeter = 1000 Cu Millimeters = 0.06 Cu Inches
 1 Cu Meter = 1,000,000 Cu Centimeters = 35.31 Cu Feet

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

TEMPERATURE

$5/9 (°F - 32) = °C$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5C + 32 = F°$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	To	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.289
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.195
Square Kilometers	Square Miles	0.385
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.303
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pound-Feet	0.733
Kilopascals	Pounds per Square Inch	0.145
Kilometers per Liter	Miles per Gallon	2.354
Kilometers per Hour	Miles per Hour	0.621

