


# \*TM 5-2350-378-23&P

## TECHNICAL MANUAL FIELD MAINTENANCE MANUAL INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST FOR

## HYDRAULIC DIAGNOSTIC CENTER (HDC) SUPPORTING ARMORED COMBAT EARTHMOVER (ACE), M9 NSN 2350-00-808-7100



\* **SUPERSEDURE NOTICE** - TM 5-2350-378-23&P dated 30 June 2012 supersedes TM 5-2350-378-24&P dated 26 December 2008, including all changes.

**DISTRIBUTION STATEMENT A** - Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY  
30 JUNE 2012





## WARNING SUMMARY

This warning summary contains general safety warnings and hazardous materials warnings that must be understood and applied during operation and maintenance of this equipment. Failure to observe these precautions could result in serious injury or death to personnel. Also included are explanations of safety and hazardous materials icons used within the technical manual.

### FIRST AID DATA

For information on first aid, refer to FM 4-25.11.

### EXPLANATION OF SAFETY WARNING ICONS



**EAR PROTECTION** - headphones over ears show that noise level will harm ears.



**ELECTRICAL** - electrical wire to arm with electricity symbol running through human body shows that shock hazard is present.




**ELECTRICAL** - electrical wire to hand with electricity symbol running through hand shows that shock hazard is present.



**FALLING PARTS** - arrow bouncing off human shoulder and head shows that falling parts present a danger to life or limb.



**FLYING PARTICLES** - arrows bouncing off face shows that particles flying through the air will harm face.



**FLYING PARTICLES** - arrows bouncing off face with face shield show that particles flying through the air will harm face.



**HEAVY OBJECT** - human figure stooping over heavy object shows physical injury potential from improper lifting technique.

## WARNING SUMMARY - Continued

### EXPLANATION OF SAFETY WARNING ICONS - Continued



**HEAVY PARTS** - hand with heavy object on top shows that heavy parts can crush and harm.



**HEAVY PARTS** - foot with heavy object on top shows that heavy parts can crush and harm.



**HEAVY PARTS** - heavy object on human figure shows that heavy parts present a danger to life or limb.



**HEAVY PARTS** - heavy object pinning human figure against wall shows that heavy, moving parts present a danger to life or limb.



**HELMET PROTECTION** - arrow bouncing off head with helmet shows that falling parts present a danger.



**HOT AREA** - hand over object radiating heat shows that part is hot and can burn.



**LASER LIGHT** - laser light hazard symbol indicates extreme danger for eyes from laser beams and reflections.



**MOVING PARTS** - human figure with arm caught between gears shows that the moving parts of the equipment present a danger to life or limb.



**MOVING PARTS** - hand with fingers caught between gears shows that the moving parts of the equipment present a danger to life or limb.

## WARNING SUMMARY - Continued

### EXPLANATION OF SAFETY WARNING ICONS - Continued



**MOVING PARTS** - hand with fingers caught between rollers shows that the moving parts of the equipment present a danger to life or limb.



**SHARP OBJECT** - pointed object in hand shows that a sharp object presents a danger to limb.



**SHARP OBJECT** - pointed object in hand shows that a sharp object presents a danger to limb.




**SHARP OBJECT** - pointed object in foot shows that a sharp object presents a danger to limb.



**SLICK FLOOR** - wavy line on floor with legs prone shows that slick floor presents a danger for falling.

### GENERAL SAFETY WARNINGS DESCRIPTION

#### WARNING



High oil pressure is present in the M9 hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.

## WARNING SUMMARY - Continued

### GENERAL SAFETY WARNINGS DESCRIPTION - Continued

#### WARNING



Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.

Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.


When folding blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

#### WARNING




Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

#### WARNING



Before performing any hydraulic troubleshooting in the bowl, move the ejector forward and disable it by disconnecting the ejector cylinder or by engaging the ejector lock. Failure to comply may result in severe injury to personnel.

#### WARNING




High-pressure nitrogen gas is used in this equipment. Keep hands and face away from valves and hose ends. Failure to comply may result in severe injury or death to personnel.

## WARNING SUMMARY - Continued


### GENERAL SAFETY WARNINGS DESCRIPTION - Continued

#### WARNING



Ensure right main hydraulic pressure inhibit valve V22 is fully opened prior to starting vehicle. A fully or partially closed valve will cause immediate high pressure. Failure to comply may result in damage to equipment and injury to personnel.

#### WARNING



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.


### EXPLANATION OF HAZARDOUS MATERIALS ICONS AND DESCRIPTIONS



**BIOLOGICAL** - abstract symbol bug shows that a material may contain bacteria or viruses that present a danger to life or health.



**CHEMICAL** - drops of liquid on hand shows that the material will cause burns or irritation to human skin or tissue.



**CRYOGENIC** - hand in block of ice shows that the material is extremely cold and can injure human skin or tissue.



**EXPLOSION** - rapidly expanding symbol shows that the material may explode if subjected to high temperatures, sources of ignition, or high pressure.



**EYE PROTECTION** - person with goggles shows that the material will injure the eyes.

## WARNING SUMMARY - Continued

### EXPLANATION OF HAZARDOUS MATERIALS ICONS AND DESCRIPTIONS - Continued



**FIRE** - flame shows that a material may ignite and cause burns.



**POISON** - skull and crossbones shows that a material is poisonous or is a danger to life.



**RADIATION** - three circular wedges shows that the material emits radioactive energy and can injure human tissue.



**VAPOR** - human figure in a cloud shows that material vapors present a danger to life or health.

## WARNING SUMMARY - Continued

### HAZARDOUS MATERIALS DESCRIPTIONS

#### WARNING



#### CARBON MONOXIDE

- Carbon monoxide is a colorless, odorless, deadly poison which, when breathed, deprives the body of oxygen and causes suffocation. Exposure to air containing carbon monoxide produces symptoms of headache, dizziness, loss of muscular control, apparent drowsiness, and coma. Permanent brain damage or death to personnel can result from severe exposure.
- Carbon monoxide occurs in exhaust fumes of fuel-burning heaters and internal combustion engines. Carbon monoxide can become dangerously concentrated under conditions of inadequate ventilation. The following precautions must be observed to ensure the safety of personnel whenever the personnel heater, main, or auxiliary engine of any vehicle is operated for maintenance purposes or tactical use.
  - a. DO NOT operate heater or engine in enclosed area without adequate ventilation.
  - b. DO NOT idle engine without adequate ventilation.
  - c. DO NOT drive machine with inspection plates or cover plates removed.
  - d. BE ALERT for exhaust poisoning symptoms. They are:
    - Headache
    - Dizziness
    - Sleepiness
    - Loss of muscular control
  - e. If you see another person with exhaust poisoning symptoms:
    - Remove person from area
    - Expose to fresh air
    - Keep person warm
    - DO NOT permit physical exercise
    - Administer Cardiopulmonary Resuscitation (CPR) if necessary
    - Notify a Medic
  - f. BE AWARE. The field protective mask for Chemical, Biological, Radiological, and Nuclear (CBRN) protection will not protect you from carbon monoxide poisoning.

## WARNING SUMMARY - Continued

### HAZARDOUS MATERIALS DESCRIPTIONS - Continued

#### WARNING



#### FUEL

Fuel is a combustible material. Do not smoke or allow sparks or open flames into areas where fuel is present. Failure to comply may result in severe injury or death to personnel. If injured, seek medical attention immediately.

#### WARNING



#### NITROGEN GAS

Do not breathe nitrogen gas. Failure to comply may result in severe injury or death to personnel.



## LIST OF EFFECTIVE PAGES/WORK PACKAGES

NOTE: TM 5-2350-378-23&P dated 30 June 2012 supersedes TM 5-2350-378-24&P dated 26 December 2008, including all changes. Zero in the "Change No." column indicates an original page or work package.

Date of issue for the original manual is:

Original 30 June 2012

**TOTAL NUMBER OF PAGES FOR FRONT AND REAR MATTER IS 74 AND TOTAL NUMBER OF WORK PACKAGES IS 56 CONSISTING OF THE FOLLOWING:**

Page/WP No.	Change No.	Page/WP No.	Change No.
Front Cover	0	WP 0028 (4 pages)	0
Warning Summary (8 pages)	0	WP 0029 (4 pages)	0
Technical Manual Title Block Page	0	WP 0030 (4 pages)	0
Table of Contents (18 pages)	0	WP 0031 (8 pages)	0
How to Use This Manual (2 pages)	0	WP 0032 (10 pages)	0
Chapter 1 Title Page	0	WP 0033 (4 pages)	0
WP 0001 (4 pages)	0	WP 0034 (10 pages)	0
WP 0002 (8 pages)	0	WP 0035 (10 pages)	0
WP 0003 (8 pages)	0	WP 0036 (8 pages)	0
Chapter 2 Title Page	0	WP 0037 (8 pages)	0
WP 0004 (10 pages)	0	WP 0038 (8 pages)	0
WP 0005 (2 pages)	0	WP 0039 (10 pages)	0
WP 0006 (18 pages)	0	WP 0040 (4 pages)	0
WP 0007 (8 pages)	0	WP 0041 (4 pages)	0
WP 0008 (14 pages)	0	WP 0042 (2 pages)	0
WP 0009 (10 pages)	0	WP 0043 (6 pages)	0
WP 0010 (12 pages)	0	Chapter 5 Title Page	0
WP 0011 (24 pages)	0	WP 0044 (8 pages)	0
WP 0012 (28 pages)	0	WP 0045 (4 pages)	0
WP 0013 (12 pages)	0	WP 0046 (4 pages)	0
WP 0014 (6 pages)	0	WP 0047 (54 pages)	0
WP 0015 (58 pages)	0	WP 0048 (4 pages)	0
WP 0016 (6 pages)	0	WP 0049 (4 pages)	0
WP 0017 (12 pages)	0	Chapter 6 Title Page	0
WP 0018 (14 pages)	0	WP 0050 (2 pages)	0
WP 0019 (8 pages)	0	WP 0051 (4 pages)	0
WP 0020 (12 pages)	0	WP 0052 (4 pages)	0
WP 0021 (34 pages)	0	WP 0053 (2 pages)	0
Chapter 3 Title Page	0	WP 0054 (2 pages)	0
WP 0022 (2 pages)	0	WP 0055 (2 pages)	0
WP 0023 (4 pages)	0	WP 0056 (2 pages)	0
Chapter 4 Title Page	0	Index (4 pages)	0
WP 0024 (2 pages)	0	Foldout Pages (28 pages)	0
WP 0025 (32 pages)	0	Inside Back Cover	0
WP 0026 (2 pages)	0	Back Cover	0
WP 0027 (4 pages)	0		



HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 30 JUNE 2012

TECHNICAL MANUAL  
FIELD MAINTENANCE MANUAL  
INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST  
FOR

HYDRAULIC DIAGNOSTIC CENTER (HDC)  
SUPPORTING  
ARMORED COMBAT EARTHMOVER (ACE), M9  
NSN 2350-00-808-7100

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this publication. If you find any errors, or if you would like to recommend any improvements to the procedures in this publication, please let us know. The preferred method is to submit your DA Form 2028 (Recommended Changes to Publications and Blank Forms) through the Internet on the TACOM Unique Logistics Support Applications (TULSA) Web site. The Internet address is <https://tulsa.tacom.army.mil>. Access to all applications requires CAC authentication, and you must complete the Access Request form the first time you use it. The DA Form 2028 is located under the TULSA Applications on the left-hand navigation bar. Fill out the form and click on SUBMIT. Using this form on the TULSA Web site will enable us to respond more quickly to your comments and to better manage the DA Form 2028 program. You may also mail, e-mail, or fax your comments or DA Form 2028 directly to the U.S. Army TACOM Life Cycle Management Command. The postal mail address is U.S. Army TACOM Life Cycle Management Command, ATTN: AMSTA-LCL-MPP/ TECH PUBS, MS 727, 6501 E. 11 Mile Road, Warren, MI 48397-5000. The e-mail address is [tacomlcmc.daform2028@us.army.mil](mailto:tacomlcmc.daform2028@us.army.mil). The fax number is DSN 786-1856 or Commercial (586) 282-1856. A reply will be furnished to you.

\* **SUPERSEDURE NOTICE** - TM 5-2350-378-23&P dated 30 June 2012 supersedes TM 5-2350-378-24&P dated 26 December 2008, including all changes.

**DISTRIBUTION STATEMENT A** - Approved for public release; distribution is unlimited.



# TABLE OF CONTENTS

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
HOW TO USE THIS MANUAL .....	xxi
<b>Chapter 1 - GENERAL INFORMATION, EQUIPMENT DESCRIPTION, AND THEORY OF OPERATION</b>	
GENERAL INFORMATION.....	WP 0001
EQUIPMENT DESCRIPTION AND DATA.....	WP 0002
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.....	0002-2
Figure 2. Hydraulic Diagnostic Center (HDC) Control Box Locator.....	0002-4
Figure 3. M9 ACE Hydraulic System Major Components.....	0002-5
Figure 4. M9 ACE Hydraulic System Major Components.....	0002-6
THEORY OF OPERATION.....	WP 0003
Figure 1. Main Hydraulic Accumulator.....	0003-2
Figure 2. Bowl Area Major Components.....	0003-3
Figure 3. Hydraulic Suspension Components.....	0003-4
Figure 4. DCV Bank.....	0003-7
<b>Chapter 2 - TROUBLESHOOTING PROCEDURES</b>	
INTRODUCTION TO USING THE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM TO TROUBLESHOOT THE M9 ACE HYDRAULIC SYSTEM.....	WP 0004
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box Installation.....	0004-4
Figure 2. Wiring Harness W4 (Umbilical Cable W4) Installation.....	0004-5
Figure 3. Wiring Harness W4 (Umbilical Cable W4) Installation.....	0004-6
Figure 4. Wiring Harness W4 (Umbilical Cable W4) Removal.....	0004-7
Figure 5. Wiring Harness W4 (Umbilical Cable W4) Removal.....	0004-8
Figure 6. Stowage of Hydraulic Diagnostic Center (HDC) Control Box.....	0004-9
TROUBLESHOOTING INDEX.....	WP 0005
TROUBLESHOOTING PROCEDURES - ALL HYDRAULIC FUNCTIONS INOPERATIVE.....	WP 0006
Figure 1. Hydraulic Return Line Filter.....	0006-2
Figure 2. Main Pump.....	0006-3
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.....	0006-4

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 4. Directional Control Valve (DCV) Bank.....	0006-5
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0006-6
Figure 6. Directional Control Valve (DCV) Bank.....	0006-7
Figure 7. Main Pump Relief Valve 13R.....	0006-8
Figure 8. Hydraulic Diagnostic Center (HDC) Control Box.....	0006-8
Figure 9. Directional Control Valve (DCV) Bank.....	0006-9
Figure 10. Hydraulic Diagnostic Center (HDC) Control Box.....	0006-10
Figure 11. Hydraulic Diagnostic Center (HDC) Control Box.....	0006-12
Figure 12. Directional Control Valve (DCV) Bank.....	0006-13
Figure 13. Main Pump Relief Valve 13L.....	0006-13
Figure 14. Directional Control Valve (DCV) Bank.....	0006-14
Figure 15. Hydraulic Diagnostic Center (HDC) Control Box.....	0006-15
<b>TROUBLESHOOTING PROCEDURES - APRON AND LEFT-HAND WHEEL CONTROL</b>	
<b>INOOPERATIVE.....</b>	<b>WP 0007</b>
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.....	0007-2
Figure 2. Directional Control Valve (DCV) Bank.....	0007-3
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.....	0007-4
Figure 4. Directional Control Valve (DCV) Bank.....	0007-5
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0007-6
Figure 6. Directional Control Valve (DCV) Bank.....	0007-7
<b>TROUBLESHOOTING PROCEDURES - APRON WILL NOT RAISE.....</b>	<b>WP 0008</b>
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.....	0008-3
Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.....	0008-4
Figure 3. Directional Control Valve (DCV) Bank.....	0008-5
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0008-6
Figure 5. Apron Control Pressure Relief Valve.....	0008-7
Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.....	0008-7
Figure 7. Directional Control Valve (DCV) Bank.....	0008-8

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 8. Apron Cylinders Operation Check.....	0008-9
Figure 9. Apron Cylinders Oil Flow Test.....	0008-11
Figure 10. Apron Cylinders Leakage Test.....	0008-12
TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE.....	WP 0009
Figure 1. Left Front Bump Stop.....	0009-2
Figure 2. Left Front Bump Stop.....	0009-3
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.....	0009-5
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0009-7
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0009-8
TROUBLESHOOTING PROCEDURES - EJECTOR CREEPS.....	WP 0010
Figure 1. Ejector Control Valve Linkage.....	0010-2
Figure 2. Directional Control Valve (DCV) Bank.....	0010-3
Figure 3. Directional Control Valve (DCV) Bank.....	0010-4
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0010-5
Figure 5. Hydraulic Diagnostic Center (HDC) Control Bank.....	0010-6
Figure 6. Directional Control Valve (DCV) Bank.....	0010-7
Figure 7. Directional Control Valve (DCV) Bank.....	0010-8
Figure 8. Hydraulic Diagnostic Center (HDC) Control Box.....	0010-9
Figure 9. Ejector Relief Valve Adjustment.....	0010-9
Figure 10. Hydraulic Diagnostic Center (HDC) Control Box.....	0010-10
TROUBLESHOOTING PROCEDURES - EJECTOR DOES NOT EXTEND OR RETRACT.....	WP 0011
Figure 1. Ejector.....	0011-3
Figure 2. Directional Control Valve (DCV) Bank.....	0011-3
Figure 3. Suction Strainer.....	0011-4
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-5
Figure 5. Directional Control Valve (DCV) Bank.....	0011-6
Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-7

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 7. Directional Control Valve (DCV) Bank.....	0011-8
Figure 8. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-9
Figure 9. Main Relief Valve 13L and 13R.....	0011-9
Figure 10. Hydraulic Diagnostic Center (HDC) Control Bank.....	0011-10
Figure 11. Directional Control Valve (DCV) Bank.....	0011-11
Figure 12. Suction Tubes and Hoses.....	0011-12
Figure 13. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-13
Figure 14. Ejector Control.....	0011-14
Figure 15. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-15
Figure 16. Directional Control Valve (DCV) Bank.....	0011-16
Figure 17. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-17
Figure 18. Directional Control Valve (DCV) Bank.....	0011-18
Figure 19. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-19
Figure 20. Ejector Control Valve.....	0011-19
Figure 21. Directional Control Valve (DCV) Bank.....	0011-20
Figure 22. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-21
Figure 23. Ejector Control Lever.....	0011-22
Figure 24. Hydraulic Diagnostic Center (HDC) Control Box.....	0011-23
<b>TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE.....</b>	<b>WP 0012</b>
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-3
Figure 2. Control Valve Linkage.....	0012-4
Figure 3. SPRUNG/UNSPRUNG Control Valve Linkage.....	0012-5
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-7
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-9
Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-11
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-12
Figure 8. Suspension Control Relief Valve Adjustment.....	0012-13



**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 9. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-15
Figure 10. Circuit 3 Components, Hoses and Lines.....	0012-16
Figure 11. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-17
Figure 12. Circuit 11 Components, Hoses and Lines.....	0012-18
Figure 13. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-19
Figure 14. Main Pump Suction Hose Blockage Test.....	0012-21
Figure 15. Directional Control Valve (DCV) Bank.....	0012-22
Figure 16. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-23
Figure 17. Main Relief Valve.....	0012-24
Figure 18. Directional Control Valve (DCV) Bank.....	0012-24
Figure 19. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-25
Figure 20. Directional Control Valve (DCV) Bank.....	0012-26
Figure 21. Hydraulic Diagnostic Center (HDC) Control Box.....	0012-27
<b>TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE.....</b>	<b>WP 0013</b>
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.....	0013-3
Figure 2. No. 1 Right Actuator.....	0013-5
Figure 3. No. 1 Right Actuator.....	0013-6
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0013-7
Figure 5. SPRUNG/UNSPRUNG Control Valve Linkage.....	0013-8
Figure 6. SPRUNG/UNSPRUNG Valve Linkage.....	0013-9
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.....	0013-11
Figure 8. Manifold Inlet/Outlet Port 9.....	0013-12
<b>TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE.....</b>	<b>WP 0014</b>
Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.....	0014-2
Figure 2. No. 1 Right Actuator Depicted.....	0014-3
Figure 3. No. 1 Right Actuator Depicted.....	0014-5

## TABLE OF CONTENTS - Continued

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
TROUBLESHOOTING PROCEDURES - HYDRAULIC OIL OVERHEATS.....	WP 0015
Figure 1. Directional Control Valve (DCV) Bank.....	0015-2
Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-3
Figure 3. Manifold Hoses.....	0015-4
Figure 4. Compensating Pump.....	0015-7
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-8
Figure 6. Directional Control Valve (DCV) Bank.....	0015-9
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-10
Figure 8. Directional Control Valve (DCV) Bank.....	0015-11
Figure 9. Suspension Relief Valve.....	0015-11
Figure 10. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-12
Figure 11. Directional Control Valve (DCV) Bank.....	0015-13
Figure 12. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-15
Figure 13. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-16
Figure 14. Directional Control Valve (DCV) Bank.....	0015-17
Figure 15. Main Pump Relief Valves.....	0015-18
Figure 16. HDC Control Valve.....	0015-18
Figure 17. Directional Control Valve (DCV) Bank.....	0015-19
Figure 18. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-21
Figure 19. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-22
Figure 20. Suspension Relief Valve Port 3L and Port 3R.....	0015-22
Figure 21. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-24
Figure 22. Directional Control Valve (DCV) Bank.....	0015-25
Figure 23. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-26
Figure 24. Directional Control Valve (DCV) Bank.....	0015-27
Figure 25. Ejector Relief Valve.....	0015-27
Figure 26. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-28

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 27. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-30
Figure 28. Directional Control Valve (DCV) Bank.....	0015-31
Figure 29. Apron Relief Valve.....	0015-31
Figure 30. Apron Relief Valve.....	0015-32
Figure 31. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-33
Figure 32. Apron Control Valve.....	0015-34
Figure 33. Apron Cylinder Leakage Test.....	0015-37
Figure 34. Main Hydraulic Accumulator.....	0015-39
Figure 35. Main Hydraulic Accumulator.....	0015-40
Figure 36. Main Accumulator Charging.....	0015-41
Figure 37. Compensating Pump.....	0015-43
Figure 38. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-45
Figure 39. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-46
Figure 40. Directional Control Valve (DCV) Bank.....	0015-47
Figure 41. Suspension Relief Valve.....	0015-47
Figure 42. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-49
Figure 43. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-50
Figure 44. Suspension Raise/Lower Relief Valve 3L and Relief Valve 3R.....	0015-51
Figure 45. Hydraulic Diagnostic Center (HDC) Control Box.....	0015-53
Figure 46. Right-Hand Corner Actuators.....	0015-53
Figure 47. Actuator Accumulator Pressure Test.....	0015-55
Figure 48. Actuator Accumulator Pressure Test.....	0015-56
Figure 49. Actuator Accumulator Charging.....	0015-57
Figure 50. Actuator Accumulator Charging.....	0015-58
<b>TROUBLESHOOTING PROCEDURES - LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE.....</b>	<b>WP 0016</b>
Figure 1. No. 4 Left Actuator.....	0016-3
Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.....	0016-3

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.....	0016-4
Figure 4. No. 3 Left Actuator.....	0016-5
<b>TROUBLESHOOTING PROCEDURES - REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE.....</b>	<b>WP 0017</b>
Figure 1. No. 4 Left Actuator Port 8 Check Valve.....	0017-3
Figure 2. No. 4 Left Actuator.....	0017-4
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.....	0017-6
Figure 4. SPRUNG/UNSPRUNG Control Valve Linkage.....	0017-7
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0017-8
Figure 6. SPRUNG/UNSPRUNG Control Valve Control Rod Travel.....	0017-9
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.....	0017-11
<b>TROUBLESHOOTING PROCEDURES - VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS.....</b>	<b>WP 0018</b>
Figure 1. High-Pressure Filter Inlet Port 13R.....	0018-2
Figure 2. STE/ICE-R Interface Box.....	0018-3
Figure 3. Main Hydraulic Pump Suction Hose.....	0018-3
Figure 4. No. 4 Left Actuator.....	0018-4
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0018-5
Figure 6. Hydraulic System Sample Control Valve.....	0018-6
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.....	0018-7
Figure 8. Directional Control Valve (DCV) Bank.....	0018-8
Figure 9. Hydraulic Diagnostic Center (HDC) Control Box.....	0018-9
Figure 10. Directional Control Valve (DCV) Bank.....	0018-10
Figure 11. Hydraulic Diagnostic Center (HDC) Control Box.....	0018-11
Figure 12. Main Relief Valve 13R.....	0018-11
Figure 13. Directional Control Valve (DCV) Bank.....	0018-12
Figure 14. Hydraulic Diagnostic Center (HDC) Control Box.....	0018-12

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
<b>TROUBLESHOOTING PROCEDURES - WINCH AND RIGHT-HAND WHEEL</b>	
CONTROL INOPERATIVE.....	WP 0019
Figure 1. Directional Control Valve (DCV) Bank.....	0019-2
Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.....	0019-3
Figure 3. Main Relief Valve 13L.....	0019-4
Figure 4. Directional Control Valve (DCV) Bank.....	0019-5
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.....	0019-5
Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.....	0019-7
Figure 7. Directional Control Valve (DCV) Bank.....	0019-7
<b>TROUBLESHOOTING PROCEDURES - WINCH WILL NOT PULL RATED LOAD.....</b>	
	<b>WP 0020</b>
Figure 1. Winch Control and Ejector Lock.....	0020-2
Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.....	0020-3
Figure 3. Directional Control Valve (DCV) Bank.....	0020-4
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.....	0020-5
Figure 5. Winch Relief Valve.....	0020-6
Figure 6. Directional Control Valve (DCV) Bank.....	0020-6
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.....	0020-7
Figure 8. Winch Motor.....	0020-9
Figure 9. Winch Shift Linkage.....	0020-10
Figure 10. Winch Linkage.....	0020-11
<b>TROUBLESHOOTING PROCEDURES - APPARENT HYDRAULIC DIAGNOSTIC CENTER</b>	
(HDC) SYSTEM PROBLEM.....	WP 0021
Figure 1. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.....	0021-2
Figure 2. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.....	0021-3
Figure 3. Hydraulic Diagnostic Center (HDC) System Ground Connection in Vehicle.....	0021-3
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box Front Panel.....	0021-4
Figure 5. Vehicle Transmission in Neutral with Parking Brake Fully Engaged.....	0021-6

## TABLE OF CONTENTS - Continued

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 6. Parking Brake Light Location.....	0021-6
Figure 7. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.....	0021-7
Figure 8. Pin Layout for Connector W4P1.....	0021-7
Figure 9. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.....	0021-8
Figure 10. Pin Layout for Connector W1J1.....	0021-8
Figure 11. Pin Layout for Connectors W4P1 and W4P4.....	0021-9
Figure 12. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.....	0021-10
Figure 13. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.....	0021-10
Figure 14. Hydraulic Diagnostic Center (HDC) Power Cable Assembly W1 Connection to Parking Brake Relay.....	0021-11
Figure 15. Location of Power Cable Assembly Connector W1J1.....	0021-12
Figure 16. Parking Brake Relay Terminals.....	0021-13
Figure 17. Hydraulic Diagnostic Center (HDC) Simplified Power Input Circuit.....	0021-14
Figure 18. Hydraulic Diagnostic Center (HDC) System Power Input Circuit Components.....	0021-15
Figure 19. Hydraulic Diagnostic Center (HDC) Simplified Power Input Circuit Components.....	0021-16
Figure 20. Hydraulic Diagnostic Center (HDC) Simplified Power Input Circuit Components.....	0021-17
Figure 21. Hydraulic Diagnostic Center (HDC) Control Box Front Panel.....	0021-18
Figure 22. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.....	0021-22
Figure 23. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.....	0021-22
Figure 24. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.....	0021-24
Figure 25. Upper Cable Assembly W2J1 and Lower Cable Assembly W3J1 Electrical Connections.....	0021-25

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 26. Umbilical Cable Assembly W4P2 and W4P3 Connections to Hydraulic Diagnostic Center (HDC) Control Box.....	0021-26
Figure 27. Umbilical Cable Assembly W4P2 and W4P3 Electrical Connections.....	0021-27
Figure 28. Umbilical Cable Assembly W4P5 and W4P6 Electrical Connections.....	0021-27
Figure 29. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.....	0021-29
Figure 30. Pin Locations for W2J1 and W3J1 Connectors.....	0021-30
Figure 31. Upper Cable Assembly W2 and Lower Cable Assembly W3 Electrical Connections.....	0021-30
Figure 32. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.....	0021-31
Figure 33. Umbilical Cable Assembly W4P2 and W4P3 Electrical Connectors.....	0021-32
Figure 34. Umbilical Cable Assembly W4P5 and W4P6 Electrical Connectors.....	0021-32
 <b>Chapter 3 - PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) MAINTENANCE INSTRUCTIONS</b>	
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION.....	WP 0022
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS).....	WP 0023
Table 1. Preventive Maintenance Checks and Services (PMCS).....	0023-1
Figure 1. Bolt.....	0023-1
Figure 2. Hydraulic Diagnostic Center (HDC) Bracket.....	0023-2
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.....	0023-3
Figure 4. Hydraulic Hoses, Tubes, and Fittings.....	0023-3
Figure 5. Hydraulic Metal Tubes.....	0023-4
 <b>Chapter 4 - MAINTENANCE INSTRUCTIONS</b>	
SERVICE UPON RECEIPT.....	WP 0024
M9 ACE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM FUNCTIONAL CHECK-OUT.....	WP 0025
Figure 1. Directional Control Valve (DCV) Bank.....	0025-2
Figure 2. Typical Hydraulic Diagnostic Center (HDC) Control Box Test Display (Not The Start-up Display).....	0025-4
Table 1. Default Solenoid Valve LCD Display.....	0025-5

## TABLE OF CONTENTS - Continued

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Table 2. HDC System Solenoid Valve Definition.....	0025-9
Table 3. HDC System Pressure Transducers.....	0025-11
Figure 3. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-13
Figure 4. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-14
Figure 5. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-15
Figure 6. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-16
Figure 7. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-17
Figure 8. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-18
Figure 9. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-19
Figure 10. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-20
Figure 11. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-21
Figure 12. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-22
Figure 13. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-23
Figure 14. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.....	0025-24
Table 4. Possible Symptoms Of Failed HDC System Components.....	0025-25
HYDRAULIC DIAGNOSTIC CENTER (HDC) STOWAGE BRACKET REPLACEMENT.....	WP 0026
Figure 1. Hydraulic Diagnostic Center (HDC) Stowage Bracket Removal.....	0026-1
Figure 2. Hydraulic Diagnostic Center (HDC) Stowage Bracket Installation.....	0026-2
HYDRAULIC DIAGNOSTIC CENTER (HDC) DISCONNECT BRACKET REPLACEMENT.....	WP 0027
Figure 1. Hydraulic Diagnostic Center (HDC) Disconnect Bracket Removal.....	0027-2



**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 2. Hydraulic Diagnostic Center (HDC) Disconnect Bracket Installation.....	0027-3
HYDRAULIC DIAGNOSTIC CENTER (HDC) CIRCUIT BREAKER REPLACEMENT.....	WP 0028
Figure 1. Hydraulic Diagnostic Center (HDC) Circuit Breaker Removal.....	0028-2
Figure 2. Hydraulic Diagnostic Center (HDC) Circuit Breaker Installation.....	0028-3
HYDRAULIC DIAGNOSTIC CENTER (HDC) POWER COMPONENTS REPLACEMENT.....	WP 0029
Figure 1. Hydraulic Diagnostic Center (HDC) Power Distribution Components Removal.....	0029-2
Figure 2. Hydraulic Diagnostic Center (HDC) Power Distribution Components Installation.....	0029-3
WIRING HARNESS W1 REPLACEMENT.....	WP 0030
Figure 1. Wiring Harness W1 Removal.....	0030-2
Figure 2. Wiring Harness W1 Installation.....	0030-3
WIRING HARNESS W2 REPLACEMENT.....	WP 0031
Figure 1. Wiring Harness W2 from Filter Area Removal.....	0031-2
Figure 2. Wiring Harness W2 from Main Manifold Removal.....	0031-3
Figure 3. Wiring Harness W2 Connector J1 at Disconnect Bracket Removal.....	0031-4
Figure 4. Wiring Harness W2 Connector J1 at Disconnect Bracket Installation.....	0031-5
Figure 5. Wiring Harness W2 to Main Manifold Installation.....	0031-6
Figure 6. Wiring Harness W2 to Filter Area Installation.....	0031-7
WIRING HARNESS W3 REPLACEMENT.....	WP 0032
Figure 1. Wiring Harness W3 from Disconnect Bracket and Actuator Area Removal.....	0032-3
Figure 2. Wiring Harness W3 from Under Vehicle Removal.....	0032-5
Figure 3. Wiring Harness W3 at Actuator Area Removal.....	0032-6
Figure 4. Wiring Harness W3 at Actuator Area Installation.....	0032-7
Figure 5. Wiring Harness W3 Connections Under Vehicle Installation.....	0032-9
Figure 6. Wiring Harness W3 to Disconnect Bracket and Actuator Area Installation.....	0032-10
PRESSURE TRANSDUCERS REPLACEMENT.....	WP 0033
Table 1. Hydraulic Diagnostic Center (HDC) Pressure Transducer Locations.....	0033-2
Figure 1. Transducer Removal/Installation.....	0033-3

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD ASSEMBLY AND MOUNTING BRACKET REPLACEMENT.....	WP 0034
Figure 1. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Removal.....	0034-3
Figure 2. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Removal.....	0034-5
Figure 3. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Installation.....	0034-7
Figure 4. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Installation.....	0034-8
HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD REPAIR.....	WP 0035
Figure 1. Adapters and Plugs from Primary Manifold Disassembly.....	0035-3
Figure 2. Transducers and Valves from Primary Manifold Disassembly.....	0035-5
Figure 3. Valves and Transducers on Primary Manifold Assembly.....	0035-7
Figure 4. Plugs and Adapters on Primary Manifold Assembly.....	0035-9
HYDRAULIC DIAGNOSTIC CENTER (HDC) FORWARD LEFT MANIFOLD ASSEMBLY REPAIR	WP 0036
Figure 1. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Assembly Removal.....	0036-3
Figure 2. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Disassembly.....	0036-4
Figure 3. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Assembly.....	0036-5
Figure 4. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Assembly Installation.....	0036-7
HYDRAULIC DIAGNOSTIC CENTER (HDC) FORWARD RIGHT MANIFOLD ASSEMBLY REPAIR.....	WP 0037
Figure 1. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Removal.....	0037-3
Figure 2. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Disassembly.....	0037-4
Figure 3. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Assembly.....	0037-5
Figure 4. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Installation.....	0037-7
HYDRAULIC DIAGNOSTIC CENTER (HDC) AFT MANIFOLD ASSEMBLY REPAIR.....	WP 0038
Figure 1. Hydraulic Diagnostic Center (HDC) Manifold Assembly Removal.....	0038-3
Figure 2. Hydraulic Diagnostic Center (HDC) Manifold Disassembly.....	0038-4

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 3. Hydraulic Diagnostic Center (HDC) Aft Manifold Assembly.....	0038-5
Figure 4. Hydraulic Diagnostic Center (HDC) Aft Manifold Assembly Installation.....	0038-7
<b>MAIN PUMP HYDRAULIC FILTER AREA REPLACEMENT.....</b>	<b>WP 0039</b>
Figure 1. Valve V21 (V22), Relief Valve, and Bypass Hose Removal.....	0039-3
Figure 2. Valve V21 (V22), Relief Valve, and Bypass Hose Removal.....	0039-5
Figure 3. Valve V21 (V22), Relief Valve, and Bypass Hose Installation.....	0039-7
Figure 4. Valve V21 (V22), Relief Valve, and Bypass Hose Installation.....	0039-8
<b>HYDRAULIC DIAGNOSTIC CENTER (HDC) INTERCONNECTING HYDRAULIC HOSES AND TUBES REPLACEMENT.....</b>	<b>WP 0040</b>
Figure 1. Hydraulic Diagnostic Center (HDC) Interconnecting Hydraulic Hoses and Tubes Removal/Installation.....	0040-3
<b>DIRECTIONAL CONTROL VALVE (DCV) BANK REPLACEMENT.....</b>	<b>WP 0041</b>
Figure 1. Manual Shutoff Valve V23 Removal.....	0041-2
Figure 2. Manual Shutoff Valve V23 Installation.....	0041-3
<b>HULL/EJECTOR INTERFERENCE REPLACEMENT.....</b>	<b>WP 0042</b>
Figure 1. Hull/Ejector Interference Modification Removal/Installation.....	0042-2
<b>GENERAL MAINTENANCE.....</b>	<b>WP 0043</b>
Figure 1. National Pipe Thread (NPT) Fittings.....	0043-3
Figure 2. 37 Degree Flare Termination Fitting.....	0043-3
Figure 3. O-Ring (Packing) Boss.....	0043-4
Figure 4. Flareless Fitting.....	0043-4
Figure 5. Four-Bolt Split Flange.....	0043-5
Figure 6. Adjustable Fittings.....	0043-6
<b>Chapter 5 - PARTS INFORMATION</b>	
<b>REPAIR PARTS AND SPECIAL TOOLS LISTS (RPSTL) INTRODUCTION.....</b>	<b>WP 0044</b>
Table 1. SMR Code Explanation.....	0044-2
Table 2. Source Code First and Second Position.....	0044-2
Table 3. Maintenance Code Third Position.....	0044-3

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Table 4. Maintenance Code Fourth Position.....	0044-4
Table 5. Recoverability Code Fifth Position.....	0044-5
GROUP AQ01 HYDRAULIC CONTROL INSTALLATION.....	WP 0045
Figure 1 Hydraulic Control Levers and Linkage.....	0045-2
GROUP A501 WINCH INSTALLATION.....	WP 0046
Figure 2 Winch Assembly -7D3-05815.....	0046-2
GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.....	WP 0047
Figure 3 Hydraulic Diagnostic Center (HDC) Control Box.....	0047-2
Figure 4 Hydraulic Diagnostic Center (HDC) Stowage Bracket.....	0047-4
Figure 5 Hydraulic Diagnostic Center (HDC) Disconnect Bracket.....	0047-6
Figure 6 Hydraulic Diagnostic Center (HDC) Circuit Breaker.....	0047-8
Figure 7 Hydraulic Diagnostic Center (HDC) Power Components.....	0047-10
Figure 8 Wiring Harness W1.....	0047-12
Figure 9 Wiring Harness W2.....	0047-14
Figure 10 Wiring Harness W3.....	0047-16
Figure 11 Wiring Harness W4.....	0047-18
Figure 12 Pressure Transducers.....	0047-20
Figure 13 Mounting Brackets, Primary Manifold.....	0047-22
Figure 14 Left Main Manifold.....	0047-24
Figure 15 Primary Manifold Assembly. (Sheet 1 of 2) .....	0047-27
Figure 15 Primary Manifold Assembly. (Sheet 2 of 2) .....	0047-28
Figure 16 Forward Left Manifold Mounting and Hose Interconnections.....	0047-32
Figure 17 Forward Left Manifold Assembly.....	0047-34
Figure 18 Forward Right Manifold Mounting and Hose Interconnections.....	0047-36
Figure 19 Forward Right Manifold Assembly.....	0047-38
Figure 20 Aft Manifold Mounting and Hose Interconnections.....	0047-40
Figure 21 Aft Manifold Assembly.....	0047-42

**TABLE OF CONTENTS - Continued**

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
Figure 22 Main Pump Hydraulic Filter Area, Right Side and Left Side (Left Side Shown).....	0047-44
Figure 23 Hydraulic Filter Mounting.....	0047-46
Figure 24 Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly Hydraulic Tubes and Hoses.....	0047-48
Figure 25 Directional Control Valve (DCV) Bank.....	0047-50
Figure 26 Hull/Ejector Interference.....	0047-52
NATIONAL STOCK NUMBER INDEX.....	WP 0048
PART NUMBER INDEX.....	WP 0049
<b>Chapter 6 - SUPPORTING INFORMATION</b>	
REFERENCES.....	WP 0050
MAINTENANCE ALLOCATION CHART (MAC) INTRODUCTION.....	WP 0051
STANDARD TWO-LEVEL MAC.....	WP 0052
Table 1. Maintenance Allocation Chart (MAC).....	0052-1
Table 2. Tools and Test Equipment.....	0052-3
Table 3. Remarks.....	0052-3
EXPENDABLE AND DURABLE ITEMS LIST.....	WP 0053
Table 1. Expendable and Durable Items List.....	0053-1
TOOL IDENTIFICATION LIST.....	WP 0054
Table 1. Tool Identification List.....	0054-1
MANDATORY REPLACEMENT PARTS LIST.....	WP 0055
Table 1. Mandatory Replacement Parts List.....	0055-1
DIAGRAMS.....	WP 0056
<b>Foldout Figures</b>	
FO-1.M9 ACE HDC Hydraulic Schematic (Sheet 1 of 3).....	FP-1
FO-2.M9 ACE HDC Hydraulic Schematic (Sheet 2 of 3).....	FP-3
FO-3.M9 ACE HDC Hydraulic Schematic (Sheet 3 of 3).....	FP-5
FO-4.Power Cable Assembly W1.....	FP-7

## TABLE OF CONTENTS - Continued

	<b>Page No.</b>
	<b><u>WP Sequence No.</u></b>
FO-5.Upper Cable Assembly W2.....	FP-9
FO-6.Lower Cable Assembly W3.....	FP-11
FO-7.Umbilical Cable Assembly W4.....	FP-13
FO-8.Simplified Electrical Schematic Diagram of HDC System Power Distribution.....	FP-15
FO-9.HDC System Electrical Interconnection Diagram.....	FP-17
FO-10.Hydraulic Pressure Transducer Electrical Diagram.....	FP-19
FO-11.Solenoid Valve Electrical Diagram.....	FP-21
FO-12.W2 Wiring Diagram.....	FP-23
FO-13.W3 Wiring Diagram.....	FP-25
FO-14.W4 Wiring Diagram.....	FP-27

Index

## HOW TO USE THIS MANUAL

This manual is designed to help you operate and maintain the Hydraulic Diagnostic Center (HDC) supporting the Armored Combat Earthmover (ACE), M9. Listed below are special features which have been included to make it easier to locate and use the information you need.

### WARNINGS, CAUTIONS, AND NOTES

Read all WARNINGS, CAUTIONS, and NOTES before performing any procedure.

Warnings, cautions, notes, subject headings, and other essential information are printed in **BOLD** type, making them easier to see.

### GENERAL INFORMATION

This manual is divided into CHAPTERS and WORK PACKAGES. For a specific Chapter or Work Package, refer to the TABLE OF CONTENTS.

- The TABLE OF CONTENTS lists the titles of each Chapter and Work Package.
- CHAPTER 1 provides General Information, Equipment Description, and Theory of Operation.
- CHAPTER 2 provides Troubleshooting Procedures.
- CHAPTER 3 provides PMCS Introduction and PMCS Maintenance Instructions.
- CHAPTER 4 provides Maintenance Instructions.
- CHAPTER 5 provides Parts Information.
- CHAPTER 6 provides Supporting Information. The Supporting Information includes tables listing **References** used in this manual, a Maintenance Allocation Chart (**MAC**), a listing of **Expendable and Durable Items**, and a listing of **Tools** and **Mandatory Replacement Parts** used in this manual.

This manual also provides text that works in conjunction with illustrations showing:

- Components, controls, and indicators.
- How to operate the vehicle and its components.
- How to remove, install, and maintain components.
- How to clean and inspect vehicle components.

The illustrations throughout this manual contain numerical callouts pointing to various components mentioned in the procedural steps. Replacement parts must be discarded after removal and replaced with a new part, which is listed in the Materials/Parts section located at the beginning of the task in the Initial Setup.

Prior to performing any maintenance functions on the HDC supporting the M9 ACE, ALWAYS do the following:

- Read and follow all WARNINGS in all work packages.
- Read the Safety Summary.
- Read the Equipment Description and Data located in Chapter 1.
- Read completely through the maintenance procedure to familiarize yourself with the procedure and the affected parts before beginning work.

## HOW TO USE THIS MANUAL - Continued

### GENERAL INFORMATION - Continued

The troubleshooting section is set up either by how a physical problem is occurring or how an active or stored trouble code is read from a diagnostic tool. Following a prescribed flow path through making decisions will lead you to a solution to remedy the problem. RPSTL (found in the Parts Information chapter) is to be used to help find needed parts for procurement. The RPSTL lists and authorizes spares and repair parts; special tools; special Test, Measurement, and Diagnostic Equipment (TMDE); and other special support equipment required for performance of maintenance on the HDC supporting the M9 ACE. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the Source, Maintenance, and Recoverability (SMR) codes.

### METRIC SYSTEM

The equipment described herein contains metric components and requires metric, common, and special tools. Therefore, metric units and English units will be used throughout this publication. An English-to-Metric conversion table is included as the last page of this manual inside the back cover.



**CHAPTER 1**

**GENERAL INFORMATION, EQUIPMENT DESCRIPTION, AND  
THEORY OF OPERATION**



---

## FIELD MAINTENANCE GENERAL INFORMATION

---

### SCOPE

**Type of Manual:** Field Maintenance

**Model Number and Equipment Name:**

M9 ACE HDC - Armored Combat Earthmover, Hydraulic Diagnostic Center.

**Purpose of Equipment:** Reduce maintenance time when vehicle's hydraulic system fails.

### MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 750-8, The Army Maintenance Management System (TAMMS).

### REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If your Hydraulic Diagnostic Center (HDC) needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you do not like about your equipment. Let us know why you do not like the design or performance. If you have Internet access, the easiest and fastest way to report problems or suggestions is to follow the instructions and links below:

For ALL non-Aviation/Missile Warranty, EIR and PQDRs must be submitted through the Web Product Quality Deficiency Reporting (PQDR) site. The Web PQDR site is: <http://www.nslcptsmh.csd.disa.mil/webpqdr/webpqdr.htm>. New accounts can be established at the following address: <http://www.nslcptsmh.csd.disa.mil/accessforms/uarform.htm>.

You may also submit your information using an SF 368 (Product Quality Deficiency Report). You can send your SF 368 using e-mail, regular mail, or fax using the addresses/fax numbers specified in DA PAM 750-8, The Army Maintenance Management System (TAMMS) Users Manual. We will send you a reply.

### CORROSION PREVENTION AND CONTROL (CPC)

Corrosion prevention and control (CPC) of Army materiel is a continuing concern. It is important that any corrosion problems with this item be reported so that the problem can be corrected and improvements can be made to prevent the problem in future items. Corrosion specifically occurs with metals. It is an electrochemical process that causes the degradation of metals. It is commonly caused by exposure to moisture, acids, bases, or salts. An example is the rusting of iron. Corrosion damage in metals can be seen, depending on the metal, as tarnishing, pitting, fogging, surface residue, and/or cracking. Plastics, composites, and rubber can also degrade. Degradation is caused by thermal (heat), oxidation (oxygen), solvation (solvents), or photolytic (light, typically UV) processes. The most common exposures are excessive heat or light. Damage from these processes will appear as cracking, softening, swelling, and/or breaking.

SF Form 368, Product Quality Deficiency Report, should be submitted to the address specified in DA PAM 750-8, The Army Maintenance Management System (TAMMS) Users Manual.

### DESTRUCTION OF MILITARY EQUIPMENT TO PREVENT ENEMY USE

When the tactical situation requires that Army materiel be abandoned, refer to TM 750-244-6, Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use.

## PREPARATION FOR STORAGE OR SHIPMENT

When not in use, stow HDC control box in stowage fixture with front of control box facing towards the rear wall and electrical connectors at top. To secure HDC control box in stowed position, hand-tighten wing nuts against retainer bar on threaded rods.

## LIST OF ABBREVIATIONS/ACRONYMS

The following abbreviations/acronyms are used in this manual.

<b><u>Term</u></b>	<b><u>Definition</u></b>
ACE	Armored Combat Earthmover
ADPTR	Adapter
AEPS	Army Electronic Product Support
AWG	American Wire Gauge
BIT	Binary Digit
BIT	Built-In Test
°C	Centigrade, Celsius
CAGEC	Commercial and Government Entity Code
cm	Centimeter(s)
DA PAM	Department of the Army Pamphlet
DC	Direct Current
DCV	Directional Control Valve
EMP	Electromagnetic Pulse
°F	Fahrenheit
FLTR	Filter
FO	Foldout
FP	Foldout Page
FWD	Forward
gal.	Gallon(s)
gpm	Gallons per Minute
HCI	Hardness Critical Item
HDC	Hydraulic Diagnostic Center
HYDR	Hydraulic
in.	Inch(es)
INTMD	Intermediate
kg	Kilogram(s)
km/h	Kilometers per Hour
kPa	Kilopascal(s)
L	Liter(s)
lb	Pound(s)
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LH	Left-Hand
Lpm	Liters per Minute
MAC	Maintenance Allocation Chart
MANF	Manifold
max	Maximum
mm	Millimeter(s)
mph	Miles per Hour
N·m	Newton Meter
NC	Normally Closed
NIIN	National Item Identification Number
NO	Normally Open
NPT	National Pipe Thread

**LIST OF ABBREVIATIONS/ACRONYMS - Continued**

<b><u>Term</u></b>	<b><u>Definition</u></b>
NSN	National Stock Number
P/N	Part Number
PMCS	Preventive Maintenance Checks and Services
psi	Pounds per Square Inch
psig	Pounds per Square Inch Gauge
PWR	Power
qts	Quarts
RH	Right-Hand
rpm	Revolutions per Minute
RPSTL	Repair Parts and Special Tools List
SF	Standard Form
SMR	Source, Maintenance, and Recoverability
SPNSN	Suspension
SRA	Specialized Repair Activity
STE/ICE-R	Simplified Test Equipment for Internal Combustion Engines - Reprogrammable
SUCT	Suction
TB	Technical Bulletin
TM	Technical Manual
TMDE	Test, Measurement, and Diagnostic Equipment
TULSA	TACOM Unique Logistics Support Applications
UOC	Usable On Code
VDC	Volts Direct Current
VLV	Valve
WP	Work Package

**QUALITY OF MATERIAL**

Material used for replacement, repair, or modification must meet the requirements of this technical manual. If quality of material requirements are not stated in this technical manual, the material must meet the requirements of the drawings, standards, specifications, or approved engineering change proposals applicable to the subject equipment.

**SAFETY, CARE, AND HANDLING**

Warnings are listed in the warning summary and before specific steps where they apply in the work package procedures. In addition to these warnings, always keep in mind the following when working on the M9 ACE:

- The hydraulic system operates at pressures up to 4,500 psi (31,028 kPa).
- Ensure the upper apron lockpins are installed any time personnel are working on the apron or dozer blade and any time the apron is raised.
- Never operate the ejector when personnel are in the bowl.
- Always place support stands under the hull before crawling under the vehicle. The vehicle suspension will settle down after engine has been shut off.

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
EQUIPMENT DESCRIPTION AND DATA**

---

**SCOPE**

This section contains information that is useful when performing Hydraulic Diagnostic Center (HDC) troubleshooting tasks on the M9 ACE.

**PURPOSE**

The HDC is used for troubleshooting the hydraulic system and components.

**CAPABILITIES AND FEATURES**

- Highly mobile
- Efficient and accurate
- User Friendly
- Time saving

**EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES**

The HDC (Figure 1) is used to aid in troubleshooting the M9 ACE's hydraulic system and components. The HDC consists of a control box with a display screen, 20 electrically controlled solenoid valves, three manually controlled valves, and 13 transducers. Four wiring harnesses connect the HDC to the vehicle's hydraulic system's test points (installed prior to use of the HDC, and left in place on the vehicle) and the LED screen. Each of the 20 electronically-controlled valves (V1 through V20) return to their normal operating positions when the HDC control box is shut off or power is disconnected for any other reason. Valves V1 through V20 can be opened and closed by using the LINE UP and LINE DOWN buttons on the display screen to select a valve, then pressing the CHANGE POSITION button to open or close the valve. The control box software allows up to four of the solenoid valves to be powered ON at one time. Pressing the RESET VALVES button returns all valves to their normal vehicle operating position (power OFF).




Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.



**EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES - Continued**

VALVE NO.	PWR	/	POSITION
V1	OFF	/	OPEN
V2	OFF	/	OPEN
V3	OFF	/	OPEN
V4	OFF	/	OPEN
V5	OFF	/	OPEN
V6	OFF	/	OPEN
V7	OFF	/	OPEN
V8	OFF	/	OPEN
V9	OFF	/	OPEN
V10	OFF	/	OPEN
V11	OFF	/	OPEN
V12	OFF	/	OPEN
V13	OFF	/	OPEN
V14	OFF	/	OPEN
V15	OFF	/	OPEN
V16	OFF	/	OPEN
V17	OFF	/	OPEN
V18	OFF	/	CLOSED
V19	OFF	/	CLOSED
V20	OFF	/	CLOSED

Valves V21 and V22, located in the bowl area near the high pressure filters, are manually operated and can be operated from outside the bowl, while standing on top of the vehicle.

Valve V23, also manually operated, is located on the front of the Directional Control Valve (DCV) bank in the bowl area, and must be operated while standing in the bowl. This valve is used to interrupt the flow to the ejector. It is recommended for safety purposes that the engine be shut down when operating valve V23.

The diagnostic unit is stowed in the operator's compartment. It is removed and becomes mobile for use, and, upon completion of troubleshooting, is stored in the operator's compartment. Harness W4 is also stowed in the operator's compartment.

## LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

The major component of the HDC is a centrally located, permanently installed Control Box (Figure 2), connected to distributed sensors and hydraulic controls mounted throughout the vehicle that is used to diagnose the hydraulic system for malfunctions, routine, and breakdown maintenance.





Figure 2. Hydraulic Diagnostic Center (HDC) Control Box Locator.

## LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued




T0001HDC

Figure 3. M9 ACE Hydraulic System Major Components.

1. APRON CYLINDER (Figure 3, Item 1). Raises and lowers apron and dozer assembly (one each side).
2. RETURN LINE FILTER (Figure 3, Item 2). Filters out contaminants from hydraulic oil that is returning to reservoir.
3. HIGH PRESSURE FILTERS (Figure 3, Item 3). Two high-pressure filters located directly in front of operator's compartment filter hydraulic fluid from the main hydraulic pump while it is enroute to the DCV bank.
4. DIRECTIONAL CONTROL VALVE (DCV) BANK (Figure 3, Item 4). Activated by mechanical linkages from the operator's controls to activate hydraulic functions in the vehicle. Controls direction of fluid flow and pressure.
5. WINCH MOTOR (Figure 3, Item 5). Operates the winch which is used in recovery operations.
6. FORWARD MANIFOLD (Figure 3, Item 6). Routes the flow of hydraulic fluid to components.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued



T0002HDC

Figure 4. M9 ACE Hydraulic System Major Components.

1. MAIN HYDRAULIC PUMP (Figure 4, Item 1). Fixed displacement pump that pulls hydraulic oil from the reservoir to perform whatever function is necessary.
2. MAIN ACCUMULATOR (Figure 4, Item 2). Helps keep pressure constant in hydropneumatic suspension system.
3. SPRUNG/UNSPRUNG VALVE (Figure 4, Item 3). Regulates pressurized fluid flow for whichever mode is selected.
4. HYDRAULIC RESERVOIR (Figure 4, Item 4). Supplies hydraulic oil through main pump, high-pressure filters, and DCV to activate hydraulic functions of vehicle.
5. NO. 1 AND NO. 4 ACTUATORS (Figure 4, Item 5). Front: provides vehicle suspension in SPRUNG mode and allows vehicle to raise and lower in UNSPRUNG mode. Rear: No. 4 is same as front, except they cannot be raised or lowered.
6. NO. 2 AND NO. 3 ACTUATORS (Figure 4, Item 6). Operate off No. 1 and No. 4 actuators. Interwheel control valves allow them to follow, rather than lead No. 1 and No. 4 actuators when vehicle is lowered.

**LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued**

7. SUSPENSION RELIEF VALVE (Figure 4, Item 7). Relieves pressure surges or gradual increases in pressure to suspension.
8. BUMP STOP CYLINDERS (Figure 4, Item 8). Limit upward travel of roadwheel arms when in SPRUNG position  
(one on each side).
9. INTERMEDIATE WHEEL VALVE (Figure 4, Item 9). Prevents No. 2 and 3 actuators from raising when lowering front of vehicle.
10. EJECTOR CYLINDER (Figure 4, Item 10). Moves ejector forward and back with hydraulic pressure.
11. CHECK VALVE (Figure 4, Item 11). A device to control the direction of fluid flow.
12. COMPENSATING PUMP (Figure 4, Item 12). Provides pressure to vehicle for SPRUNG/UNSPRUNG hydraulic operation.

**EQUIPMENT DATA****Hydraulic Diagnostic Center**

Size

Length - 11 in. (28 cm)

Width - 10 in. (25.4 cm)

Depth - 2.75 in. (7 cm)

Weight

15 lb (6.8 kg)

**END OF WORK PACKAGE**



---

## FIELD MAINTENANCE THEORY OF OPERATION

---

### SCOPE

This section contains information relative to the principles of operation for the hydraulic system and the Hydraulic Diagnostic Center (HDC). The general functional description of the hydraulic system and HDC is contained in this section. Field maintenance personnel should be familiar with the principles of operation of these systems before working on or troubleshooting the hydraulic system. A more thorough understanding of the hydraulic system and electrical system/HDC integration may be obtained by referring to the interconnecting wiring diagram (FP-17) and the HDC hydraulic schematic (FP-6).

Components:

### HYDRAULIC DIAGNOSTIC CENTER

This component analyzes and diagnoses problems within the M9 ACE vehicle's hydraulic system. Connected to valves and transducers on manifolds and at components by wiring harness W4, it sends messages to the LED screen concerning problems it encounters within the hydraulic system. The HDC is stowed in the operator's compartment.

### LCD SCREEN

This screen is used to input commands to the unit itself and displays alerts and diagnoses as they become available.

### SOLENOID VALVES

The HDC uses twenty electronically-controlled solenoids, as well as three manual valves.

### TRANSDUCERS

Thirteen transducers are installed into the hydraulic lines at critical points and remain there. Connected to the HDC system, they aid in diagnosing any problems the M9 ACE may be having with the hydraulic system.

### WIRING HARNESES

Four wiring harnesses connect the components of the HDS system to the vehicle's hydraulic system. When not in use, harness W4 is stowed in the operator's compartment.

## HYDRAULIC SYSTEM


The hydraulic system provides hydraulic pressure to energize the suspension system, operate the winch, ejector, and apron cylinders. Some hydraulic components are briefly described below.

### Hydraulic Return Line Filter

This filter (Figure 1), located behind the bowl area, on top of the engine, filters out contaminants from the hydraulic oil returning to the hydraulic reservoir.

### Main Hydraulic Accumulator

The main hydraulic accumulator (Figure 1) is located on the left side of the filter support. It is charged with nitrogen to 1,750-1,850 psi (12,066-12,756 kPa) at 70°F (21°C) and provides immediate response to temporary needs of the SPRUNG mode that the compensating pump cannot meet. A charge and gauge assembly is mounted on the accumulator (Figure 1) and is used to check accumulator charge status and to charge the accumulator (Figure 1).



T0003HDC

Figure 1. Main Hydraulic Accumulator.

### Hydraulic High-Pressure Filters

Two high-pressure filters (Figure 2) located directly in front of the operator's compartment, filter hydraulic fluid from the main hydraulic pump while it is enroute to the Directional Control Valve (DCV) bank.

### Hydraulic Reservoir

The hydraulic reservoir (Figure 2) is located beneath the operator's compartment and its check and fill point is located in the operator's compartment. It has a capacity of 32 gal. (121 L) of OE/HDO-10.



**Direction Control Valve (DCV) Bank**

The control valve bank (Figure 2) is located beneath the hydraulic high-pressure filters (Figure 2). The control valves in the valve bank are activated by mechanical linkages from the operator's compartment and they, in turn, activate the hydraulic functions of the vehicle.

**Hydraulic Manifolds**


Located in the hull, the manifolds (Figure 2) route the flow of hydraulic fluid to the vehicle components.

**Compensating Hydraulic Pump**

Located on the front of the transfer case, the pump (Figure 2) provides pressure at a constant 2,800-2,900 psi (19,306-19,996 kPa) to the SPRUNG/UNSPRUNG hydraulic operation. Capacity of this variable displacement pump is 10 gpm (38 Lpm).

**Main Hydraulic Pump**

A fixed displacement pump is mounted on the rear of the transfer case. The pump pulls fluid from the hydraulic reservoir and circulates it through the hydraulic filters at 13 gpm (49 Lpm), then splits the pressure at the DCVs to provide pressure to both left and right suspension controls. (Figure 2)



T0004HDC

Figure 2. Bowl Area Major Components.

## Hydraulic Suspension Operation


**SPRUNG/UNSPRUNG Circuit** The key to the operation of the M9 ACE is its hydropneumatic suspension system that allows the vehicle to operate in both SPRUNG and UNSPRUNG modes.

**SPRUNG Mode** Pressure is delivered through line 9 to bump stops and front actuator fill valves, causing the bump stops to extend and limit movement of the front roadwheel arms. The actuators (Figure 3) become a fixed suspension with the accumulators acting like shock absorbers for the system, providing a smooth ride up to 30 MPH (48 Km/H). SPRUNG mode is used for road marches and parking.

**UNSPRUNG Mode** Pressure is routed through the SPRUNG/UNSPRUNG valve (Figure 3) to line 11 and to the actuator wheel valves, causing bump stops to retract and the suspension system to become variable. The front of the vehicle can be raised or lowered, and the operator has independent control of the left and right suspension components. UNSPRUNG mode is used for earthmoving operations.

## Sprung/Unsprung Control Valve

Located to the right of the main DCV bank, facing rearward, this valve (Figure 3) regulates fluid flow for whichever mode is selected.



T0005HDC

Figure 3. Hydraulic Suspension Components.

### **Hydraulic Control Valve Operation**

The hydraulic control valves on the DCV bank are activated by mechanical linkages from the operator's compartment and they, in turn, activate the hydraulic functions of the vehicle.

The following pages describe the functions of valves and circuits they activate. Refer to these pages when following the apron raise/lower, winch, and ejector valve circuits.

**Right Pump Control Valve (13R)**

Receives oil flow from the main hydraulic pump and maintains pressure at 3,950-4,050 psi (27,235-27,925 kPa) for the right-side hydraulic functions (Figure 4).

**Left Pump Control Valve (13L)**

Receives oil flow from the main hydraulic pump and maintains pressure at 3,950-4,050 psi (27,235-27,925 kPa) (Figure 4).

**Right Suspension Control Valve (3R/17R)**

Port 3R (Figure 4), front bottom of valve, raises the right front-side of vehicle. Port 17R (Figure 4), above port 3R (Figure 4), lowers right front-side of vehicle. Relief valve is set at 3,450-3,550 psi (23,788-24,477 kPa).

**Left Suspension Control Valve (3L/17L)**

Port 3L (Figure 4), front bottom of valve, raises the left front-side of vehicle. Port 17L (Figure 4), above port 3L (Figure 4), lowers left front-side of vehicle. Relief valve is set at 3,450-3,550 psi (23,788-24,477 kPa).

**Apron Raise/Lower Control Valve (19/20)**

Port 19 (Figure 4), front top of valve, actuates circuit and raises apron. Port 20 (Figure 4), below port 19 (Figure 4), actuates circuit and lowers apron. Relief valve No. 19 (Figure 4) is set at 4,450-4,550 psi (30,688-31,372 kPa) and relief valve No. 20 (Figure 4) is set at 1,950-2,050 psi (13,445-14,135 kPa).


**Winch Control Valve (C1/C2)**

Port C1 (Figure 4), front bottom of valve, actuates circuit, moves cable out of winch C2 (Figure 4), above port C1 (Figure 4), and brings cable into winch. Relief valve is set at 1,950-2,050 psi (13,445-14,135 kPa) on the winch.

**Ejector Control Valve (21/22)**

Port 21 (Figure 4), front top of valve, actuates circuit and moves ejector forward. Port 22 (Figure 4), below port 21 (Figure 4), actuates and moves the ejector back. Relief valve is set at 1,950-2,050 psi (13,445-14,135 kPa).

Ejector Control Valve (21/22) - Continued



T0006HDC

Figure 4. DCV Bank.

END OF WORK PACKAGE



**CHAPTER 2**  
**TROUBLESHOOTING PROCEDURES**





---

## FIELD MAINTENANCE

### INTRODUCTION TO USING THE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM TO TROUBLESHOOT THE M9 ACE HYDRAULIC SYSTEM

---

#### INTRODUCTION

This work package contains information needed when troubleshooting the M9 ACE hydraulic system using the Hydraulic Diagnostic Center (HDC) System. It includes information for preparing the HDC System for use and procedures for performing a Functional Check-Out of the HDC System, both as a weekly PMCS check of the HDC System integrity, and as the initial step in using the HDC System to aid in troubleshooting the M9 ACE hydraulic system.

This work package describes the differences between troubleshooting the M9 ACE hydraulic system with, and without, the HDC System, and explains the additional items that need to be considered when using the HDC System to aid in troubleshooting the vehicle hydraulic system. Information as to how to use the HDC System to aid in troubleshooting the M9 ACE hydraulic system is included as well as information to aid in troubleshooting the specific HDC System hydraulic and electrical circuits, when used with the HDC System troubleshooting work package (WP 0021).

The HDC System is an aid, used to assist in the troubleshooting of the M9 ACE hydraulic system. The HDC is not an independent diagnostic tool; it does not provide an automated or semi-automated means of localizing hydraulic faults. The use of the HDC System allows the amount of time required to isolate faults and malfunctions in the vehicle hydraulic system to be dramatically reduced, when compared to the time required to troubleshoot the vehicle hydraulic system without the HDC System.

#### TROUBLESHOOTING THE HDC SYSTEM

Using the HDC System does introduce some additional factors that should be considered when troubleshooting the vehicle hydraulic system. Components of the HDC System are located throughout the M9 ACE vehicle and, although they simplify the actual troubleshooting process, they also introduce additional components that interface with the previously existing vehicle hydraulic system, that also can fail or malfunction like any other component.

To aid in the troubleshooting of the M9 ACE hydraulic system, the HDC System must be operating properly, and there must be some way to assess the operational status of the HDC System. The M9 ACE HDC System Functional Check-Out (WP 0025) provides the means for the maintainer to easily check portions of the HDC System to determine if the HDC System is functionally operational.

When the HDC System is to be used (for troubleshooting the vehicle hydraulic system or when just being functionally checked as part of a PMCS requirement), the M9 ACE HDC System Functional Check-Out (WP 0025) should first be performed. If the HDC System does not pass all portions of the Functional Check-Out, refer to (WP 0021) and proceed to troubleshoot the HDC System as indicated.

Aside from the HDC Control Box and three electrical cables integrated into the vehicle, two main types of components comprise the HDC System; solenoid valves and hydraulic pressure transducers. Although both of these types of components are very reliable (as are the electrical cables), they can possibly fail like other electrical and hydraulic components. The solenoid valves are spring-loaded and can possibly fail in two ways. They can fail to energize, and they can fail to return to the original de-energized state (valve spool does not return to the de-energized state), when energizing (supply) voltage is removed. The probability of a solenoid valve being stuck (the valve spool does not return to the de-energized position) is very low and would only occur after a hydraulic maintenance test was performed in which the valve had been energized. The actual movement (or non-movement) of the valve spool cannot be detected by the HDC Control Box as part of the System BIT. The solenoid valves are normally not energized. They are only energized upon command, and are supplied 24 VDC only when energized. Normally all solenoid valves are de-energized (reset) and are not supplied any voltage.

## TROUBLESHOOTING THE HDC SYSTEM - Continued

When the HDC System is operating, a reference voltage is always supplied to the hydraulic pressure transducers from the HDC Control Box and the respective hydraulic pressure measured by the individual pressure transducers is displayed on the HDC Control Box upper LCD. The pressure transducer is supplied a 15 VDC reference voltage and returns a DC analog voltage between 0.5 VDC and 9.5 VDC to the HDC Control Box representing the hydraulic pressure measured by the transducer in the circuit.

The hydraulic pressure transducers can also fail in two ways; failure to measure any hydraulic pressure (complete failure) or failure to accurately measure the hydraulic pressure (producing erroneous measurement indications) and provide an analog voltage back to the HDC Control Box that is outside of the range of acceptable voltages (outside the 0.5 - 9.5 VDC range). If the "measured" DC voltage returned to the HDC Control Box from the pressure transducer is within the acceptable range of 0.5 to 9.5 VDC, regardless of how inaccurate the measurement may be, the inaccuracy/malfunction cannot be detected by the HDC Control Box as part of the System BIT.

The HDC System Functional Check-Out (WP 0025) addresses many of the HDC System components and fault isolates most problems/malfunctions associated with those components. For those HDC System solenoid valves and pressure transducers specified, and those not specifically addressed in the Functional Check-Out, refer to the applicable maintenance WP to aid in determining if an HDC System solenoid valve or hydraulic pressure transducer may have failed or malfunctioned, based on possible consequences and symptoms of a malfunctioning or failed HDC system component.

## USE OF THE HDC SYSTEM

The HDC is only used when a problem has been detected (or suspected) in the M9 ACE hydraulic system and formal troubleshooting of the system is necessary. Before the HDC System is actually used to aid in troubleshooting the vehicle hydraulic system, the M9 ACE HDC System Functional Check-Out (WP 0025) should be performed to establish the operational readiness of the HDC System. The HDC system is only used when the vehicle is not moving, the vehicle is in "neutral" and the parking brake is fully engaged.

## GENERAL HYDRAULIC SYSTEM TROUBLESHOOTING PROCEDURES

Refer to TM 5-2350-262-20.

### GENERAL

Refer to TM 5-2350-262-20.

### GENERAL NOTES

Refer to TM 5-2350-262-20.

Hydraulic troubleshooting can often be reduced by taking the following step:

- Instead of replacing an HDC System solenoid valve or pressure transducer, temporarily switch it with a spare item, or with another identical solenoid valve or pressure transducer.

## NOTE

Before attempting to repair or replace any hydraulic component you must:

1. Determine the maintenance responsibility for repair or replacement of the component.
2. If the task is at your echelon of maintenance responsibility, you must identify the tools needed and the replacement parts required.

Refer to the Maintenance Allocation Chart (MAC) to determine not only the maintenance responsibility of the item, but also to obtain an estimate of the time required to perform the task, tools needed, and any special notes/requirements necessary.

**GENERAL NOTES - Continued**

Refer to Repair Parts and Special Tools List in TM 5-2350-262-20 for requisition data concerning replacement parts for this task.

**PRELIMINARY TROUBLESHOOTING PROCEDURES**

Ensure all equipment and tools are available before performing hydraulic system troubleshooting. The following items are required for hydraulic system troubleshooting:

Pressure Measuring Devices:

Pressure Measuring Device-4940-00-595-5720-GS5

Refer to TM 5-2350-262-20 for procedures, additional equipment, and tools.

**SUSPENDING THE M9 ACE FOR SUSPENSION SYSTEM CHECKS**

Refer to TM 5-2350-262-20.

**RELIEVING HYDRAULIC SYSTEM PRESSURE**

Refer to TM 5-2350-262-20.

**ACCUMULATOR DUMP VALVE INSTALLATION**

Refer to TM 5-2350-262-20.

**GENERAL SUSPENSION TROUBLESHOOTING INFORMATION**

Refer to TM 5-2350-262-20.

**ACTUATOR PORT IDENTIFICATION AND DESCRIPTION**

Refer to TM 5-2350-262-20.

**LOCKING AND DISABLING EJECTOR**

Refer to TM 5-2350-262-20.

**HDC CONTROL BOX INSTALLATION**

1. Loosen two thumb screws (Figure 1, Item 3) on two threaded rods (Figure 1, Item 2) until control box (Figure 1, Item 1) can be removed from stowage bracket (Figure 1, Item 4).




Figure 1. Hydraulic Diagnostic Center (HDC) Control Box Installation.

**HDC CONTROL BOX INSTALLATION - Continued**

2. Connect umbilical cable connector W4P4 (Figure 2, Item 5) to disconnect bracket harness W1 connector J1 (Figure 2, Item 6).
3. Connect umbilical cable connector W4P5 (Figure 2, Item 4) to disconnect bracket harness W2 connector J1 (Figure 2, Item 1).
4. Connect umbilical cable connector W4P6 (Figure 2, Item 3) to disconnect bracket harness W3 connector J1 (Figure 2, Item 2).




Figure 2. Wiring Harness W4 (Umbilical Cable W4) Installation.

**HDC CONTROL BOX INSTALLATION - Continued**

5. Connect umbilical cable connector W4P1 (Figure 3, Item 5) to control box connector J1 (Figure 3, Item 4).
6. Connect umbilical cable connector W4P2 (Figure 3, Item 6) to control box connector J2 (Figure 3, Item 3).
7. Connect umbilical cable connector W4P3 (Figure 3, Item 1) to control box connector J3 (Figure 3, Item 2).





Figure 3. Wiring Harness W4 (Umbilical Cable W4) Installation.

**HDC CONTROL BOX REMOVAL**

1. Remove umbilical cable connector W4P3 (Figure 4, Item 1) from control box connector J3 (Figure 4, Item 2).
2. Remove umbilical cable connector W4P2 (Figure 4, Item 6) from control box connector J2 (Figure 4, Item 3).
3. Remove umbilical cable connector W4P1 (Figure 4, Item 5) from control box connector J1 (Figure 4, Item 4).




T0026HDC

Figure 4. Wiring Harness W4 (Umbilical Cable W4) Removal.

**HDC CONTROL BOX REMOVAL - Continued**

4. Remove umbilical cable connector W4P6 (Figure 5, Item 3) from disconnect bracket harness W3 connector J1 (Figure 5, Item 2).
5. Remove umbilical cable connector W4P5 (Figure 5, Item 4) from disconnect bracket harness W2 connector J1 (Figure 5, Item 1).
6. Remove umbilical cable connector W4P4 (Figure 5, Item 5) from disconnect bracket harness W1 connector J1 (Figure 5, Item 6).



T0027HDC

Figure 5. Wiring Harness W4 (Umbilical Cable W4) Removal.



**HDC CONTROL BOX REMOVAL - Continued**

7. Place control box (Figure 6, Item 1) in storage bracket (Figure 6, Item 4) and secure by tightening two wingnuts (Figure 6, Item 3) on two threaded rods (Figure 6, Item 2).




Figure 6. Stowage of Hydraulic Diagnostic Center (HDC) Control Box.

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
TROUBLESHOOTING INDEX**

**TROUBLESHOOTING SYMPTOM INDEX**

<u>Malfunction/Symptom</u>	<u>Troubleshooting Procedure</u>
1. ALL HYDRAULIC FUNCTIONS INOPERATIVE.....	WP 0006
2. APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE.....	WP 0007
3. APRON WILL NOT RAISE.....	WP 0008
4. BUMP STOPS INOPERATIVE.....	WP 0009
5. EJECTOR CREEPS.....	WP 0010
6. EJECTOR DOES NOT EXTEND OR RETRACT.....	WP 0011
7. FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE.....	WP 0012
8. FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE.....	WP 0013
9. FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE.....	WP 0014
10. HYDRAULIC OIL OVERHEATS.....	WP 0015
11. LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE.....	WP 0016
12. REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE.....	WP 0017
13. VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS.....	WP 0018
14. WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE.....	WP 0019
15. WINCH WILL NOT PULL RATED LOAD.....	WP 0020
16. APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM.....	WP 0021

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - ALL HYDRAULIC FUNCTIONS INOPERATIVE**

**INITIAL SETUP:**

**Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

**References (cont.)**

FO-2  
FO-3

**Personnel Required**

Construction Equipment Repairer 91L (Two)

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)


**References**

FO-1

**TROUBLESHOOTING PROCEDURE**

**ALL HYDRAULIC FUNCTIONS INOPERATIVE**

**WARNING**



High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- The hydraulic control valves on the Directional Control Valve (DCV) bank are activated by mechanical linkages from the operator's compartment which then activate hydraulic functions of the vehicle.
- Perform this procedure only when all hydraulic functions are inoperative. Refer to Hydraulic Diagnostic Center (HDC) hydraulic system schematic (FO-1, FO-2, and FO-3).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

**STEP**

1. Check if vehicle moves under its own power.  
Operate vehicle (TM 5-2350-262-10).

**CONDITION/INDICATION**

Will vehicle move under its own power?

**DECISION**

- YES - Go to Step (2).
- NO - Go to Step (9).

**STEP**

2. Check for flow of hydraulic oil from hydraulic return line at hydraulic return line filter.

**NOTE**

Have suitable container ready to catch oil.

- a. Stop engine; relieve hydraulic pressure.
- b. Disconnect HYDR-FLTR-IN-7 hose (Figure 1, Item 3) from tee (Figure 1 Item 4) at port 7 (Figure 1, Item 2) on hydraulic return line filter (Figure 1, Item 1).
- c. Cap tee (Figure 1, Item 4).
- d. While holding open end of hose (Figure 1, Item 3) in container, have assistant start engine.
- e. Check for free flow of hydraulic oil from hose (Figure 1, Item 3).
- f. Stop engine; relieve hydraulic pressure.
- g. Connect hose (Figure 1, Item 3) to tee (Figure 1, Item 4).




Figure 1. Hydraulic Return Line Filter.

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

**CONDITION/INDICATION**

Is there a free flow of oil?

**DECISION**

- YES - Go to Step (4).
- NO - Go to Step (3).

**STEP**

- 3. Check for blockage in main pump suction hose.

**WARNING**



Do not work under vehicle unless hull is properly blocked or allowed to settle on bump stops. Failure to comply may result in severe injury or death to personnel.

**NOTE**

Have suitable container ready to catch oil.

- a. Loosen, but do not disconnect, PUMP SUCT TUBE-#7 (Figure 2, Item 1) from elbow (Figure 2, Item 3) on main hydraulic pump (Figure 2, Item 2).




Figure 2. Main Pump.

- b. Hydraulic oil should flow freely from the loosened fitting.
- c. Tighten PUMP SUCT TUBE-#7 hose.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

- YES - Clear blockage or replace hose.
- NO - If there is no blockage, go to Step (4).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

**STEP**

4. Perform main hydraulic pump test. Check transducer T-3 hydraulic pressure on HDC display.
  - a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 3, Item 5) on the HDC control box.
  - c. Ensure right main hydraulic pressure inhibit valve V21 (Figure 3, Item 1) is fully opened.





Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- d. Disable ejector by manually closing the ejector inhibit ball valve V23 (Figure 4, Item 2) on the DCV bank.



**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

*Figure 4. Directional Control Valve (DCV) Bank.*

- e. Using LINE UP or LINE DOWN button (Figure 3, Item 3), select V1 on the HDC display (Figure 3, Item 2).
- f. Close V1 on the HDC display (Figure 3, Item 2) by selecting CHANGE POSITION button (Figure 3, Item 4) on HDC control box.
- g. Have assistant start engine and allow engine to idle (750-800 rpm).
- h. Slowly close right main hydraulic pressure inhibit valve V21 (Figure 4, Item 1), until transducer T-3 pressure on the HDC display (Figure 3, Item 1) indicates 3,950-4,050 psi (27,235-27,925 kPa).
- i. Fully open right main hydraulic pressure inhibit valve V21 (Figure 4, Item 1).
- j. Stop engine; relieve hydraulic pressure.
- k. Open ejector inhibit ball valve V23 (Figure 4, Item 2) on the DCV bank.
- l. Using LINE UP or LINE DOWN button (Figure 3, Item 3), select V1 on the HDC display (Figure 3, Item 2).
- m. Open V1 on the HDC display (Figure 3, Item 2) by selecting the CHANGE POSITION button (Figure 3, Item 4) on the HDC control box.

**CONDITION/INDICATION**

Does main hydraulic pump develop 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Go to Step (5).

NO - Replace main hydraulic pump (TM 5-2350-262-20).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

**STEP**

5. Check transducer T-3 hydraulic pressure at port 13R.
  - a. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 5, Item 5) on the HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on the HDC display (Figure 5, Item 2). Close V1 on the HDC display (Figure 5, Item 2) by selecting the CHANGE POSITION button (Figure 5, Item 4) on the HDC control box.
  - c. Have assistant start engine, move SPRUNG/UNSPRUNG lever to SPRUNG, and hold EJECTOR CONTROL lever in BACK. Read transducer T-3 pressure on the HDC display (Figure 5, Item 1). If hydraulic pressure is not within limits, continue with the following step.
  - d. While assistant is still holding EJECTOR CONTROL lever in BACK, have assistant move right-hand SUSPENSION CONTROL lever to RAISE. Read transducer T-3 pressure on HDC display (Figure 5, Item 1). If hydraulic pressure is not within limits, main relief valve 13R requires adjustment.
  - e. Release EJECTOR CONTROL and right-hand SUSPENSION CONTROL levers.
  - f. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 5, Item 5) on the HDC control box.




Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is pressure 3,950-4,050 psi (27,235-27,925 kPa)?

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued****DECISION**


- YES - Go to Step (7).  
 NO - Go to Step (6).

**STEP**

6. Perform 13R main pump relief valve adjustment using the HDC.
- a. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 5, Item 5) on the HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Manually close the ejector inhibit ball valve V23 (Figure 6, Item 1) on the DCV bank.
  - c. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on the HDC display (Figure 5, Item 2). Close V1 on the HDC display (Figure 5, Item 2) by selecting the CHANGE POSITION button (Figure 5, Item 4) on the HDC control box.



T00411HDC

Figure 6. Directional Control Valve (DCV) Bank.

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

- d. Loosen jam nut (Figure 7, Item 1).
- e. Read transducer T-3 hydraulic pressure on the HDC display (Figure 8, Item 1), as assistant moves right-hand SUSPENSION CONTROL lever to RAISE and EJECTOR CONTROL lever to BACK.
- f. Rotate relief valve adjustment (Figure 7, Item 2) clockwise to increase pressure; counterclockwise to decrease pressure.




Figure 7. Main Pump Relief Valve 13R.

- g. When transducer T-3 pressure indicates 3,950-4,050 psi (27,235-27,925 kPa) on the HDC display (Figure 8, Item 1), tighten jam nut (Figure 7, Item 1).




Figure 8. Hydraulic Diagnostic Center (HDC) Control Box.

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

- h. Verify pressure is now within limits by having assistant move right-hand SUSPENSION CONTROL lever to RAISE and EJECTOR CONTROL lever to BACK. Read transducer T-3 hydraulic pressure on the HDC display (Figure 8, Item 1).
- i. Stop engine; relieve hydraulic pressure.
- j. Manually open ejector inhibit ball valve V23 (Figure 9, Item 1) on the DCV bank. Using LINE UP or LINE DOWN button (Figure 8, Item 3), select V1 on the HDC display (Figure 8, Item 2). Open V1 on the HDC display (Figure 8, Item 2) by selecting the CHANGE POSITION button (Figure 8, Item 4) on the HDC control box.




Figure 9. Directional Control Valve (DCV) Bank.

**CONDITION/INDICATION**

Can hydraulic pressure be adjusted to 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Go to Step (7).

NO - Replace DCV bank (TM 5-2350-262-20).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

**STEP**

7. Check transducer T-4 hydraulic pressure at port 13L.
  - a. Stop engine and relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 10, Item 5) on the HDC control box.
  - c. Using LINE UP or LINE DOWN button (Figure 10, Item 3), select V1 on the HDC display (Figure 10, Item 2). Close V1 on the HDC display (Figure 10, Item 2) by selecting the CHANGE POSITION button (Figure 10, Item 4) on the HDC control box.
  - d. Have assistant start engine, move the SPRUNG/UNSPRUNG lever to SPRUNG, and hold EJECTOR CONTROL lever to BACK.
  - e. Read transducer T-4 hydraulic pressure on the HDC display (Figure 10, Item 1).
  - f. If hydraulic pressure is not within limits, continue with following steps.
  - g. While still holding EJECTOR CONTROL lever in BACK, have assistant move left-hand SUSPENSION CONTROL lever to RAISE.
  - h. Read transducer T-4 hydraulic pressure on the HDC display (Figure 10, Item 1).




Figure 10. Hydraulic Diagnostic Center (HDC) Control Box.

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

- i. If pressure is not within limits, main relief valve 13L requires adjustment.
- j. Release EJECTOR and SUSPENSION CONTROL levers.
- k. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is pressure 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Stop engine; relieve hydraulic pressure. Verify problem with operator.

NO - Go to Step (8).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

**STEP**

8. Perform 13L main pump relief valve adjustment using the HDC.
  - a. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 11, Item 5) on the HDC control box.




Figure 11. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.

- b. Manually close the ejector inhibit ball valve V23 (Figure 12, Item 1) on the DCV bank.



## ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued




Figure 12. Directional Control Valve (DCV) Bank.

- c. Using LINEUP or LINE DOWN button (Figure 11, Item 3), select V1 on the HDC display (Figure 11, Item 2).
- d. Close V1 on the HDC display (Figure 11, Item 2) by selecting the CHANGE POSITION button (Figure 11, Item 4) on the HDC control box.
- e. Loosen jam nut (Figure 13, Item 2).





Figure 13. Main Pump Relief Valve 13L.

- f. Read transducer T-4 hydraulic pressure on the HDC display (Figure 11, Item 1).
- g. As assistant moves left-hand SUSPENSION CONTROL lever to RAISE and EJECTOR CONTROL lever to BACK, rotate valve (Figure 13, Item 1) clockwise to increase pressure; counterclockwise to decrease pressure.
- h. When transducer T-4 pressure indicates 3,950–4,050 psi (27,235–27,925 kPa), tighten jam nut (Figure 13, Item 2).
- i. Verify pressure is now within limits by having assistant move left-hand SUSPENSION CONTROL lever to RAISE and EJECTOR CONTROL lever to BACK.

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued**

- j. Read transducer T-4 hydraulic pressure on the HDC display (Figure 15, Item 1).
- k. Stop engine; relieve hydraulic pressure.
- l. Manually open ejector inhibit ball valve V23 (Figure 14, Item 1) on the DCV bank.



*Figure 14. Directional Control Valve (DCV) Bank.*

- m. Using LINE UP or LINE DOWN button (Figure 15, Item 3), select V1 on the HDC display (Figure 15, Item 2).
- n. Open V1 on the HDC display (Figure 15, Item 2) by selecting the CHANGE POSITION button (Figure 15, Item 4) on the HDC control box.

## ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued




Figure 15. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Can hydraulic pressure be adjusted to 3,950-4,050 psi (27,235-27,95 kPa)?

**DECISION**

YES - Verify problem is solved.

NO - Replace DCV bank (TM 5-2350-262-20).

**STEP**

9. Check if vehicle rises within two minutes.
  - a. Start engine.
  - b. Check if vehicle rises.

**CONDITION/INDICATION**

Does vehicle "rise" (within two minutes) when engine is started with SPRUNG/UNSPRUNG lever in SPRUNG?

**DECISION**

YES - Go to Step (10).

NO - Go to Step (11).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued****STEP**

10. Check operation of vehicle engine.

**CONDITION/INDICATION**

Does engine appear to be operating normally?

**DECISION**

YES - Go to Step (13).

NO - Go to Step (19).

**STEP**

11. Check main accumulator charge with engine off.

**CONDITION/INDICATION**

Does hydraulic pressure gauge indicate a pressure between 1,500-2,000 psi (10,343-13,790 kPa)?

**DECISION**

YES - Go to Step (12).

NO - Charge main accumulator (TM 5-2350-262-20).

**STEP**

12. Check accumulator pressure with engine running.

Start engine and check main accumulator charge with engine speed at 1,500 rpm.

**CONDITION/INDICATION**

Is hydraulic pressure at least 2,800 psi (19,306 kPa) with engine speed at 1,500 rpm?

**DECISION**

YES - Repair/replace compensating pump (TM 5-2350-262-20).

NO - Go to Step (13).

**STEP**

13. Check hydraulic oil level.

**CONDITION/INDICATION**

Are hydraulic oil levels at proper fill levels?

**DECISION**

YES - Charge main accumulator. If charge can not be maintained, repair or replace main accumulator (TM 5-2350-262-20).

NO - Add hydraulic oil, but do not overfill.

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued****STEP**

14. Check transmission, steer unit, transfer case, and final drive oil levels.

**CONDITION/INDICATION**

Are all oil levels at proper fill levels (TM 5-2350-262-10)?

**DECISION**

YES - Go to Step (15).

NO - Add oil where necessary, but do not overfill.

**STEP**

15. Check operation of transmission gear shift.

**CONDITION/INDICATION**

Does transmission gear shift appear to be operating properly?

**DECISION**

YES - Go to Step (16).

NO - Troubleshoot and repair/replace transmission gear shift linkage/mechanism (TM 5-2350-262-20).

**STEP**

16. Check transmission assembly for cracks, leaks, and warps in hoses, lines, and fittings.

**CONDITION/INDICATION**

Are there any cracks, leaks, or warps in transmission assembly?

**DECISION**

YES - Repair/replace transmission assembly (TM 5-2350-262-20).

NO - Go to Step (17).

**STEP**

17. Check transfer case for cracks, leaks, and warps in hoses, lines and fittings.

**CONDITION/INDICATION**

Are there any cracks, leaks, or warps in transfer case?

**DECISION**

YES - Repair/replace transfer case (TM 5-2350-262-20).

NO - Go to Step (18).

**ALL HYDRAULIC FUNCTIONS INOPERATIVE - Continued****STEP**

18. Inspect/test final drive assemblies.

**CONDITION/INDICATION**

Do final drives appear to be operating normally?

**DECISION**

YES - Go to Step (19).

NO - Replace final drive assemblies (TM 5-2350-262-20).

**STEP**

19. Check if vehicle is operational.

- a. Turn off engine.
- b. Allow engine to cool down.
- c. Perform "Before Operation PMCS" procedures (TM 5-2350-262-10).
- d. Attempt to start and operate vehicle in a normal manner.

**CONDITION/INDICATION**

Can vehicle be operated in a normal manner?

**DECISION**

YES - Verify problem no longer exists.

NO - Notify Supervisor.

**END OF WORK PACKAGE**

---

**FIELD MAINTENANCE**  
**TROUBLESHOOTING PROCEDURES - APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- The inboard valve bank hydraulic system 13R circuit is supplied by hydraulic pump port 13R and pressure is controlled by the relief valve at inlet port 13R.
- Perform this procedure only when the apron, left-hand suspension controls, and ejector are all inoperative.

**APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE - Continued**

**STEP**

1. Perform main relief valve pressure test using the HDC.

**WARNING**



Before performing any hydraulic troubleshooting in the bowl, move ejector forward and disable it by disconnecting ejector cylinder from hydraulic system. Failure to comply may result in severe injury or death to personnel.

- a. Move ejector forward, stop engine, and relieve hydraulic pressure.
- b. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 1, Item 5) on the HDC control box.





Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.



## APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE - Continued

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- c. Disable ejector by manually closing the ejector inhibit ball valve V23 (Figure 2, Item 1) on the Directional Control Valve (DCV) bank. Using LINE UP or LINE DOWN button (Figure 1, Item 3), select V1 on the HDC display (Figure 1, Item 2).



*Figure 2. Directional Control Valve (DCV) Bank.*

- d. Close V1 on the HDC display (Figure 1, Item 2) by selecting the CHANGE POSITION button (Figure 1, Item 4) on the HDC control box.
- e. Have assistant start engine, move the SPRUNG/UNSPRUNG lever to SPRUNG and move the EJECTOR CONTROL lever to BACK.
- f. Read transducer T-3 hydraulic pressure on the HDC display (Figure 1, Item 1).
- g. While simultaneously holding the EJECTOR CONTROL lever in BACK, have assistant move the right-hand SUSPENSION CONTROL lever to RAISE.
- h. Read transducer T-3 hydraulic pressure on the HDC display (Figure 1, Item 1).

**APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE - Continued**

**CONDITION/INDICATION**

Is hydraulic pressure at transducer T-3 between 3,950-4,050 psi (27,235-27,925 kPa) on the HDC display?

**DECISION**

- YES - Stop engine; relieve hydraulic pressure. Verify the problem with operator.
- NO - Go to Step (2).

**STEP**

2. Perform 13R main relief valve adjustment.
  - a. Loosen jam nut (Figure 4, Item 1) on main relief valve 13R (Figure 4, Item 2).
  - b. Have assistant simultaneously hold EJECTOR CONTROL lever in BACK while holding the right-hand SUSPENSION CONTROL lever in RAISE.
  - c. Read transducer T-3 hydraulic pressure on the HDC display (Figure 3, Item 1).




Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.

**APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE - Continued**

- d. While reading transducer T-3 hydraulic pressure on the HDC display (Figure 3, Item 1), rotate adjusting screw (Figure 4, Item 3) clockwise to increase pressure; counterclockwise to decrease pressure, until correct pressure is indicated.




Figure 4. Directional Control Valve (DCV) Bank.

- e. Tighten jam nut (Figure 4, Item 1).
- f. Stop engine; relieve hydraulic pressure.
- g. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 3, Item 2) on the HDC control box.

**CONDITION/INDICATION**

Can the 13R main relief valve be set to develop hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - If transducer T-3 hydraulic pressure is between 3,950-4,050 psi (27,235-27,925 kPa), verify problem is solved.

NO - Go to Step (3).

**APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE - Continued**

**STEP**

- 3. Perform main hydraulic pump pressure test using the HDC.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.

- a. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 5, Item 5) on the HDC control box.





Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

- b. Disable ejector by manually closing the ejector inhibit ball valve V23 (Figure 6, Item 2) on the DCV bank.
  - (1) Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on the HDC display (Figure 5, Item 2).
  - (2) Close V1 on the HDC display (Figure 5, Item 2) by selecting the CHANGE POSITION button

**APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE - Continued**

(Figure 5, Item 4) on the HDC control box.

- c. Ensure right main hydraulic pressure inhibit valve V21 (Figure 6, Item 1) is fully open.



*Figure 6. Directional Control Valve (DCV) Bank.*

- d. Have assistant start engine and allow engine to idle (750–800 rpm).
- e. Slowly close right main hydraulic pressure inhibit valve V21 (Figure 6, Item 1) until transducer T-3 on the HDC display (Figure 5, Item 1) indicates 3,950-4,050 psi (27,235-27,925 kPa).
- f. Open right main hydraulic pressure inhibit valve V21 (Figure 6, Item 1).
- g. Stop engine; relieve hydraulic pressure.
- h. Open ejector inhibit ball valve V23 (Figure 6, Item 2) on the DCV bank.
- i. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 5, Item 5) on the HDC control box.

**CONDITION/INDICATION**

Does pressure transducer T-3 indicate main hydraulic pump develops 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).  
NO - Notify Direct Support maintenance to replace main hydraulic pump.

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - APRON WILL NOT RAISE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Wood Blocks

**References**

WP 0035


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****APRON WILL NOT RAISE****WARNING**

High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.

**NOTE**

The apron cylinders receive oil flow from main control valve circuits 19 and 20. Relief valves at port 19 and 20 of main control valve limit pressure to apron cylinders to 3,500 psi (24,131 kPa).

**APRON WILL NOT RAISE - Continued****STEP**

1. Check apron for interference.

**CONDITION/INDICATION**

Is the apron binding or jammed as a result of damage to apron or hull?

**DECISION**

YES - Clear obstructions and repair mechanical damage.

NO - Go to Step (2).

**STEP**

2. Perform apron control valve pressure test, using the Hydraulic Diagnostic Center (HDC).

**WARNING**

Before performing any hydraulic troubleshooting in the bowl, move ejector forward and disable it by disconnecting ejector cylinder from hydraulic system. Failure to comply may result in severe injury or death to personnel.

- a. Start engine.
- b. Move ejector forward, stop engine, and relieve hydraulic pressure.
- c. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 1, Item 5) on the HDC control box.
- d. Using LINE UP or LINE DOWN button (Figure 1, Item 3), select V17 on the HDC display (Figure 1, Item 2).
- e. Close V17 on the HDC display (Figure 1, Item 2) by selecting the CHANGE POSITION button (Figure 1, Item 4) on the HDC control box.
- f. Have assistant start engine and hold APRON CONTROL lever in UP position (RAISE).
- g. Read transducer T-1 hydraulic pressure on the HDC display (Figure 1, Item 1).



APRON WILL NOT RAISE - Continued




Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is hydraulic pressure at transducer T-1 less than 2,000 psi (13,790 kPa)?

**DECISION**

- YES - Go to Step (4).
- NO - Go to Step (3).

**APRON WILL NOT RAISE - Continued**

**STEP**

3. Perform V17 test.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 2, Item 5) on the HDC control box.
  - b. Wait for transducer T-1 hydraulic pressure on the HDC display (Figure 2, Item 1) to drop below 500 psi (3,447 kPa).
  - c. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V17 on the HDC display (Figure 2, Item 2).
  - d. Close V17 on the HDC display (Figure 2, Item 2) by selecting the CHANGE POSITION button (Figure 2, Item 4) on the HDC control box.
  - e. Have assistant start engine (if engine is already running) and move APRON CONTROL lever to UP position (RAISE).
  - f. Read transducer T-1 hydraulic pressure on the HDC display (Figure 2, Item 1).
  - g. Stop engine; relieve hydraulic pressure.
  - h. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 2, Item 5) on the HDC control box.




Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.

**APRON WILL NOT RAISE - Continued****CONDITION/INDICATION**

Is hydraulic pressure at transducer T-1 less than 500 psi (3,447 kPa)?

**DECISION**

YES - Go to Step (5).


NO - Replace solenoid valve V17 on HDC system primary manifold (WP 0035).

**STEP**

4. Perform relief valve adjustment.
  - a. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 2, Item 5).

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Stop engine and relieve hydraulic pressure.
  - c. Manually close ejector inhibit ball valve V23 (Figure 3, Item 1) on the DCV bank.



T00608HDC

Figure 3. Directional Control Valve (DCV) Bank.

## APRON WILL NOT RAISE - Continued

- d. Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V1 on the HDC display (Figure 4, Item 2).




Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

- e. Close V1 on the HDC display (Figure 4, Item 2) by selecting the CHANGE POSITION button (Figure 4, Item 4) on the HDC control box. Select V17 on the HDC display (Figure 4, Item 2).
- f. Close V17 on the HDC display (Figure 4, Item 2) by selecting the CHANGE POSITION button (Figure 4, Item 4) on the HDC control box.
- g. Have assistant start engine and hold APRON CONTROL lever to UP position.
- h. Loosen jam nut (Figure 5, Item 1) on apron control pressure relief valve (Figure 5, Item 3).

APRON WILL NOT RAISE - Continued




Figure 5. Apron Control Pressure Relief Valve.

- i. Read transducer T-1 hydraulic pressure on the HDC display (Figure 4, Item 1).
- j. Have assistant hold APRON CONTROL lever in UP position.
- k. Rotate valve adjustment (Figure 5, Item 2) clockwise to increase pressure, counterclockwise to decrease pressure, until hydraulic pressure is a minimum of 3,500 psi (24,131 kPa).
- l. When transducer T-1 hydraulic pressure on the HDC display (Figure 4, Item 1) indicates 3,500 psi (24,131 kPa); tighten jam nut (Figure 5, Item 1).
- m. Stop engine; relieve hydraulic pressure.
- n. Manually open ejector inhibit ball valve V23 (Figure 6, Item 1) on the DCV bank.




Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.

**APRON WILL NOT RAISE - Continued**

- o. Using LINE UP or LINE DOWN button (Figure 7, Item 2), select V1 on the HDC display (Figure 7, Item 1).
- p. Open V1 on the HDC display (Figure 7, Item 1) by selecting the CHANGE POSITION button (Figure 7, Item 3) on the HDC control box.
- q. Select V17 on the HDC display (Figure 7, Item 1).
- r. Open V17 on the HDC display (Figure 7, Item 1) by selecting the CHANGE POSITION button (Figure 7, Item 3) on the HDC control box.




Figure 7. Directional Control Valve (DCV) Bank.

**CONDITION/INDICATION**

Can circuit 19 relief valve be set to develop 3,500 psi (24,131 kPa)?

**DECISION**

YES - Verify problem is solved.

NO - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).

**APRON WILL NOT RAISE - Continued****STEP**

5. Perform apron cylinders operation check.

**CAUTION**

Ensure apron cylinders are blocked prior to retracting disconnected cylinder rod ends.  
Cylinders will drop and damage hydraulic hoses.

- a. Stop engine; relieve hydraulic pressure.
- b. With apron (Figure 8, Item 1) lowered, remove exterior armor plates 1L (Figure 8, Item 2) and 1R (Figure 8, Item 3).
- c. Remove bolt (Figure 8, Item 5), nut (Figure 8, Item 9), two washers (Figure 8, Items 4 and 10), and clevis pin (Figure 8, Item 8) from rod end (Figure 8, Item 11) of both apron cylinders (Figure 8, Item 6).
- d. Insert wood blocks (Figure 8, Item 7) under apron cylinders (Figure 8, Item 6).
- e. Start engine and hold APRON CONTROL lever in UP position.
- f. Observe movement of apron cylinders (Figure 8, Item 6).




Figure 8. Apron Cylinders Operation Check.

**CONDITION/INDICATION**

Does one cylinder retract completely before the other cylinder will retract?

**DECISION**

- YES - Go to Step (8).  
NO - Go to Step (6).

**APRON WILL NOT RAISE - Continued****STEP**

6. Check which apron cylinder fails to retract.

**CONDITION/INDICATION**

Does either one or both apron cylinders fail to retract?

**DECISION**

YES - Go to Step (7).

NO - Verify problem with operator.

**STEP**

7. Perform apron cylinders oil flow test.

**NOTE**

Have suitable container ready to catch oil.

- a. Extend apron cylinders (Figure 9, Item 1) fully.
- b. Stop engine.
- c. Relieve hydraulic pressure by moving APRON CONTROL lever UP and DOWN several times, and disconnect left and right APRON CYL-#19 hoses (Figure 9, Item 2) from apron cylinders (Figure 9, Item 1).
- d. Hold open end of each hose (Figure 9, Item 2) in a bucket.

**NOTE**

If there is no flow from one of the APRON CYL-#19 hoses, the blockage is between cylinder end of that hose and circuit 19 tee on the hull floor. If no flow from either hose is observed, the blockage is in CONT VLV-#19 hose between circuit 19 control valve and tee on hull floor.

- e. Have assistant start engine and slowly move APRON CONTROL lever to UP position.
- f. Observe oil flow from both APRON CYL-#19 hoses.
- g. Stop engine; relieve hydraulic pressure.
- h. Reconnect left and right APRON CYL-#19 hoses (Figure 9, Item 2) to cylinders (Figure 9, Item 1).




**APRON WILL NOT RAISE - Continued**

Figure 9. Apron Cylinders Oil Flow Test.

**CONDITION/INDICATION**

Is there oil flow from both apron cylinder circuit 19 hoses?

**DECISION**

YES - Go to Step (8).

NO - Clear blockage or replace obstructed line(s).


**APRON WILL NOT RAISE - Continued****STEP**

8. Perform apron cylinder leakage test.

**NOTE**

Have suitable container ready to catch oil.

- a. Have assistant start engine, and retract cylinders (Figure 10, Item 4) approximately halfway.
- b. Stop engine; relieve hydraulic pressure.
- c. Disconnect CLT-20 (REAR) TEE hose (Figure 10, Item 2) and CKT-20 (REAR) TEE tube (Figure 10, Item 1) from tee (Figure 10, Item 3) on hull floor.
- d. Plug hose (Figure 10, Item 2) and tube (Figure 10, Item 1), and cap tee (Figure 10, Item 3).
- e. Start engine and have assistant hold APRON CONTROL lever in UP position.
- f. Measure cylinder rod extension of both apron cylinders (Figure 10, Item 4).
- g. Continue to hold APRON CONTROL lever UP for one minute.
- h. Have assistant return APRON CONTROL lever to NEUTRAL position.
- i. Measure cylinder rod extension of both apron cylinders (Figure 10, Item 4) again.



T00614HDC

Figure 10. Apron Cylinders Leakage Test.

- j. If extension rate is greater than 0.5 in. (13 mm) per minute, cylinder is leaking excessively.

**APRON WILL NOT RAISE - Continued**

- k. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is either apron cylinder leaking excessively?

**DECISION**

YES - Replace or repair leaking apron cylinder (TM 5-2350-262-20).

NO - Connect hoses and tubes. Verify problem with operator.

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)


**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**References**

WP 0036  
WP 0037

---

**TROUBLESHOOTING PROCEDURE****TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- The bump stops limit travel of vehicle's No. 1 left and right suspension unit in the SPRUNG mode. Hydraulic pressure is supplied to bump stops by the compensating pump through SPRUNG/UNSPRUNG valve.
- Perform these procedures for left and right bump stop.

## TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued

## STEP

1. Perform visual inspection. Check hydraulic hoses, tubes, and fittings.
  - a. Remove bump stop access panels (Figure 1, Item 1) from hull on inoperative side of vehicle.
  - b. Check hydraulic lines at circuits 9 (Figure 1, Item 4) and 11 (Figure 1, Item 3) between bump stop cylinder (Figure 1, Item 2) and forward manifold (Figure 1, Item 5).




Figure 1. Left Front Bump Stop.

## CONDITION/INDICATION

Is there a leaking, pinched, or damaged hose in the bump stop circuit?

## DECISION

- YES - Repair or replace damaged hoses or fittings (TM 5-2320-262-20).  
 NO - Go to Step (2).

**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued****STEP**

2. Perform mechanical binding check.
  - a. Clear debris from area of bump stop (Figure 2, Item 1).
  - b. Start engine and allow to run for at least two minutes to build up hydraulic pressure.
  - c. Have assistant shift SPRUNG/UNSPRUNG lever to SPRUNG, then to UNSPRUNG. Repeat several times.
  - d. Check for free movement of bump stop cylinder (Figure 2, Item 3), cylinder rod connecting pin (Figure 2, Item 2), and bump stop (Figure 2, Item 1).
  - e. Check for missing or damaged components including cylinder rod (Figure 2, Item 3), cylinder rod connecting pin (Figure 2, Item 2), and bump stop (Figure 2, Item 1).




Figure 2. Left Front Bump Stop.

- f. Leave SPRUNG/UNSPRUNG lever in SPRUNG to support later test.

**CONDITION/INDICATION**

Is bump stop cylinder jammed or binding?

**DECISION**

YES - Free bump stop or replace damaged components (TM 5-2350-262-20).  
 NO - Go to Step (3).

**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued****STEP**

3. Perform bump stop circuit test using the Hydraulic Diagnostic Center (HDC).
  - a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 3, Item 5) on the HDC control box.
  - c. Have assistant start engine and place vehicle in SPRUNG mode.
  - d. For left side bump stop circuit, close left forward manifold valve, by using LINE UP or LINE DOWN button (Figure 3, Item 3), select V9 on HDC display (Figure 3, Item 2).
  - e. Close V9 on the HDC display (Figure 3, Item 2), by selecting the CHANGE POSITION button (Figure 3, Item 4) on HDC control box.
  - f. Read transducer T-9 hydraulic pressure on HDC display (Figure 3, Item 1).
  - g. For right side bump stop circuit, close right forward manifold valve, by using LINE UP or LINE DOWN button (Figure 3, Item 3), select V10 on HDC display (Figure 3, Item 2).
  - h. Close V10 on HDC display (Figure 3, Item 2), by selecting CHANGE POSITION button (Figure 3, Item 4) on HDC control box.
  - i. Read transducer T-8 hydraulic pressure on HDC display (Figure 3, Item 1).

**CONDITION/INDICATION**

Is transducer T-8 (right side) or T-9 (left side) hydraulic pressure at line 9 less than 2,500 psi (17,238 kPa)?

**DECISION**

- YES - Go to Step (4).  
NO - Go to Step (5).

**STEP**

4. Perform forward manifold pressure test using the HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 3, Item 5) on the HDC control box.
  - b. Start engine.
  - c. For left forward manifold pressure, close left forward manifold valve.
  - d. Using LINE UP or LINE DOWN button (Figure 3, Item 3), select V9 on the HDC display (Figure 3, Item 2).
  - e. Close V9 on the HDC display (Figure 3, Item 2), by selecting the CHANGE POSITION button (Figure 3, Item 4) on HDC control box.
  - f. Read transducer T-7 hydraulic pressure on the HDC display (Figure 3, Item 1).
  - g. For right forward manifold pressure, close right forward manifold valve.
  - h. Using LINE UP or LINE DOWN button (Figure 3, Item 3), select V10 on the HDC display (Figure 3, Item 2).
  - i. Close V10 on HDC display (Figure 3, Item 2), by selecting CHANGE POSITION button (Figure 3, Item 4) on the HDC control box.
  - j. Read transducer T-7 hydraulic pressure on the HDC display (Figure 3, Item 1).



**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued**

- k. Stop engine and relieve hydraulic pressure.
- l. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 3, Item 5) on the HDC control box.




Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is transducer T-7 hydraulic pressure less than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Verify with operator that problem is only confined to bump stops.

NO - Clear or replace circuit 9 hoses between bump stop cylinder and left main manifold port (TM 5-2350-262-20).

**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued****STEP**

5. Perform bump stop cylinder leakage check using the HDC.
  - a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 4, Item 5) on HDC control box.
  - c. Move SPRUNG/UNSPRUNG lever to UNSPRUNG.
  - d. For left bump stop circuit; using LINE UP or LINE DOWN button (Figure 4, Item 3), select V10 on HDC display (Figure 4, Item 2).
  - e. Close V10 on the HDC display (Figure 4, Item 2), by selecting the CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - f. For right bump stop circuit; using LINE UP or LINE DOWN button (Figure 4, Item 3), select V9 on HDC display (Figure 4, Item 2).
  - g. Close V9 on HDC display (Figure 4, Item 2), by selecting the CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - h. Start engine and move SPRUNG/UNSPRUNG lever to SPRUNG. Note the time it takes for the bump stops to extend fully.
  - i. Stop engine; relieve hydraulic pressure.
  - j. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 4, Item 5) on HDC control box.

**CONDITION/INDICATION**

Does cylinder fully extend in less than two seconds?

**DECISION**

YES - Replace or repair affected bump stop cylinder (TM 5-2350-262-20).  
NO - Go to Step (6).

**STEP**

6. Perform bump stop circuit 11 test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.
  - b. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG.
  - c. For left bump stop circuit; Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V10 on HDC display (Figure 4, Item 2).
  - d. Close V10 on HDC display (Figure 4, Item 2), by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - e. Read transducer T10 hydraulic pressure on HDC display (Figure 4, Item 1).
  - f. For right bump stop circuit; Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V9 on HDC display (Figure 4, Item 2).
  - g. Close V9 on HDC display (Figure 4, Item 2), by selecting the CHANGE POSITION button (Figure 4, Item 4) on HDC control box.

**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued**

- h. Read transducer T-11 hydraulic pressure on HDC display (Figure 4, Item 1).
- i. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.




Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

- j. Stop engine and relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-10 or T-11 hydraulic pressure less than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Verify problem with operator.  
 NO - Go to Step (7).

**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued**

**STEP**

7. Perform forward manifold pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting the RESET VALVES button (Figure 5, Item 5) on HDC control box.
  - b. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG.
  - c. For left forward manifold pressure: Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V9 on HDC display (Figure 5, Item 2).
  - d. Close V9 on HDC display (Figure 5, Item 2), by selecting the CHANGE POSITION button (Figure 5, Item 4) on HDC control box.
  - e. Read transducer T-10 hydraulic pressure on HDC display (Figure 5, Item 1).
  - f. For right forward manifold pressure; Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V10 on HDC display (Figure 5, Item 2).
  - g. Close V10 on HDC display (Figure 5, Item 2), by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.
  - h. Read transducer T-11 hydraulic pressure on HDC display (Figure 5, Item 1).
  - i. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 5) on HDC control box.




Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

- j. Stop engine and relieve hydraulic pressure.

**TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE - Continued****CONDITION/INDICATION**

Is transducer T-10 (left side) or T-11 (right side) hydraulic pressure less than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Verify with operator that problem is only confined to bump stop. If so, repair or replace compensating pump (TM 5-2350-262-20).

NO - Go to Step (8).

**STEP**

8. Inspect appropriate circuit II hose between forward manifold and bump stop.

**CONDITION/INDICATION**

Is circuit II blocked or damaged?

**DECISION**

YES - Clear blockage or replace circuit 11 hose between bump stop cylinder and forward manifold (TM 5-2350-262-20).

NO - Replace solenoid valve V9 (left side) on left forward manifold (WP 0036) or solenoid valve V10 (right side) on right forward manifold (WP 0037).

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - EJECTOR CREEPS**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**References**

WP 0035


**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

---

**TROUBLESHOOTING PROCEDURE****EJECTOR CREEPS****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

Hydraulic oil is supplied to the ejector cylinder through circuits 21 and 22. When actuated, the ejector control valve distributes hydraulic pressure to extend the ejector cylinder through port 21 and retract the ejector cylinder through port 22. Hydraulic pressure is controlled by the ejector relief valve 21 on DCV control bank.

**EJECTOR CREEPS - Continued****STEP**

1. Check if ejector creeps on its own.

Observer movement of the ejector with bowl emptied, engine running, and ejector moved halfway forward.

**CONDITION/INDICATION**

Does ejector creep on its own?

**DECISION**

YES - Go to Step (2).

NO - Go to Step (5).

**STEP**

2. Check ejector valve linkage.
  - a. Stop engine; relieve hydraulic pressure.
  - b. Hold a measuring device (Figure 1, Item 1) on the face of ejector control valve (Figure 1, Item 3) on DCV bank.
  - c. Have assistant move EJECTOR CONTROL lever between FORWARD and BACK.
  - d. Measure distance plunger (Figure 1, Item 2) travels as lever is moved.




Figure 1. Ejector Control Valve Linkage.

- e. The distance of travel should be 9/32 in. (7 mm).



**EJECTOR CREEPS - Continued**

**CONDITION/INDICATION**

Is control valve linkage adjusted correctly?

**DECISION**

YES - Go to Step (3).

NO - Adjust control valve linkage.

**STEP**

3. Perform ejector control valve leakage test using Hydraulic Diagnostic Center (HDC).
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 2, Item 1) on HDC control box.




Figure 2. Directional Control Valve (DCV) Bank.

**EJECTOR CREEPS - Continued**

- b. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 3, Item 1) on HDC bank.




Figure 3. Directional Control Valve (DCV) Bank.

- (1) Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V1 on HDC display (Figure 4, Item 2).
  - (2) Close V1 on HDC display (Figure 4, Item 2), by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - (3) Select V12 on HDC display (Figure 4, Item 2).
  - (4) Close V12 on HDC display (Figure 4, Item 2), by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - (5) Select V20 on HDC display (Figure 4, Item 2).
  - (6) Open V20 on HDC display (Figure 4, Item 2), by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - (7) Select V13 on HDC display (Figure 4, Item 2).
  - (8) Close V13 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
- c. Start engine and hold EJECTOR CONTROL lever in FORWARD or BACK position until transducer T-2 hydraulic pressure on HDC display (Figure 4, Item 1) indicates 1,950-2,050 psi (13,445-14,135 kPa).
- d. Release EJECTOR CONTROL lever to NEUTRAL position, allow hydraulic pressure to stabilize for thirty seconds, then time the pressure loss for one minute.
- e. If pressure loss is greater than 100 psi (690 kPa) per minute, oil is leaking excessively past the ejector control valve spool.
- f. Stop engine and relieve hydraulic pressure.
- g. Enable ejector by manually opening ejector inhibit ball valve V23 (Figure 3, Item 1) on DCV bank.
- h. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.

**EJECTOR CREEPS - Continued**

**CONDITION/INDICATION**

Is oil leaking excessively past the control valve spool?

**DECISION**

YES - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).

NO - Go to Step (4).

**STEP**

4. Perform HDC system solenoid valve V20 test.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.
  - b. Start engine and leave it running.
  - c. Wait until transducer T-13 hydraulic pressure on HDC display (Figure 4, Item 1) is greater than 2,000 psi (13,789.51 kPa).
  - d. Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V12 on HDC display (Figure 4, Item 2).
  - e. Close V12 on HDC display (Figure 6, Item 2), by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.
  - f. Allow hydraulic pressure to stabilize for thirty seconds, then time the pressure loss for one minute at pressure transducer T-13 as indicated on HDC display (Figure 4, Item 1).




Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

- g. If pressure loss is greater than 100 psi (690 kPa) per minute, solenoid valve V20 is leaking.
- h. Stop engine and relieve hydraulic pressure.

**EJECTOR CREEPS - Continued**

**CONDITION/INDICATION**

Is solenoid valve V20 leaking?

**DECISION**

YES - Replace HDC system solenoid valve V20 on primary manifold (WP 0035).  
 NO - Verify problem with operator.

**STEP**

5. Check if ejector creeps when loading bowl with earth.  
 Operate vehicle to fill bowl with earth.

**CONDITION/INDICATION**

Does ejector creep when loading bowl with earth?

**DECISION**

YES - Go to Step (6).  
 NO - Stop engine. Verify problem with operator.

**STEP**

6. Perform ejector relief valve test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 5) on HDC control box.





Figure 5. Hydraulic Diagnostic Center (HDC) Control Bank.

**EJECTOR CREEPS - Continued****WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Disable ejector by manually closing the ejector inhibit ball valve V23 (Figure 6, Item 1) on DCV bank.



T00808HDC

*Figure 6. Directional Control Valve (DCV) Bank.*

- c. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on HDC display (Figure 5, Item 2).
- d. Close V1 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.
- e. Have assistant start engine and hold EJECTOR CONTROL lever in FORWARD position.
- f. Read transducer T-2 hydraulic pressure on HDC display (Figure 5, Item 1).
- g. Stop engine; relieve hydraulic pressure.
- h. Enable ejector by manually operating ejector inhibit ball valve V23 (Figure 6, Item 1) on DCV bank.
- i. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on HDC display (Figure 5, Item 2).
- j. Open V1 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.

**EJECTOR CREEPS - Continued****CONDITION/INDICATION**

Is transducer T-2 hydraulic pressure between 1,950-2,050 psi (13,445-14,135 kPa)?


**DECISION**

YES - Go to Step (8).

NO - Go to Step (7).

**STEP**

7. Perform ejector relief valve adjustment.
  - a. Disable ejector by manually closing the ejector inhibit ball valve V23 (Figure 7, Item 1) on DCV bank.



*Figure 7. Directional Control Valve (DCV) Bank.*

- b. Using LINE UP or LINE DOWN button (Figure 8, Item 3), select V1 on HDC display (Figure 8, Item 2).
- c. Close V1 on HDC display (Figure 8, Item 2) by selecting CHANGE POSITION button (Figure 8, Item 4) on HDC control box.
- d. Have assistant start engine and hold EJECTOR CONTROL lever in FORWARD position.
- e. Read transducer T-2 hydraulic pressure on HDC display (Figure 8, Item 1).

EJECTOR CREEPS - Continued




Figure 8. Hydraulic Diagnostic Center (HDC) Control Box.

- f. Loosen jam nut (Figure 9, Item 1) on ejector relief valve and turn adjusting screw (Figure 9, Item 2) clockwise (to increase pressure) or counterclockwise (to decrease pressure) until pressure is within limits.
- g. Tighten jam nut (Figure 9, Item 1).




Figure 9. Ejector Relief Valve Adjustment.

- h. Stop engine; relieve hydraulic pressure.
- i. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 8, Item 5) on HDC control box.

**EJECTOR CREEPS - Continued****CONDITION/INDICATION**

Can circuit 21 ejector relief valve be set to develop hydraulic pressure between 1,950-2,050 psi (13,445-14,135 kPa)?

**DECISION**

YES - Go to Step (8).

NO - Remove all test equipment and connect hoses. Replace DCV bank (TM 5-2350-262-20).

**STEP**

8. Perform ejector cylinder internal leakage test.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 10, Item 4) on HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 10, Item 2), select V1 on HDC display (Figure 10, Item 1).
  - c. Close V1 on HDC display (Figure 10, Item 1), by selecting CHANGE POSITION button (Figure 10, Item 3) on HDC control box.




Figure 10. Hydraulic Diagnostic Center (HDC) Control Box.

- d. Start engine and have assistant hold EJECTOR CONTROL lever in BACK position for one minute.
- e. Mark position of ejector at side of hull and continue to hold lever in BACK position for one more minute.
- f. Check position of ejector while still holding lever in BACK position.
- g. If ejector has moved forward (extends) more than 0.5 in. (13 mm), ejector cylinder is leaking excessively.
- h. If ejector has moved backwards (retracts) more than 0.5 in. (13 mm), solenoid valve V1 on primary manifold is leaking.



**EJECTOR CREEPS - Continued**

- i. Stop engine and relieve hydraulic pressure.

**CONDITION/INDICATION**

Is ejector cylinder leaking excessively?

**DECISION**

YES - Repair or replace ejector cylinder (TM 5-2350-262-20) or replace solenoid valve V1 on primary manifold as determined by results of ejector cylinder internal leakage test (WP 0035).

NO - Go to Step (9).

**STEP**

9. Perform ejector control valve internal leakage test.

Follow ejector control valve leakage test from Step (3).

**CONDITION/INDICATION**

Is oil leaking excessively past control valve spool?

**DECISION**

YES - Replace DCV bank (TM 5-2350-262-20).

NO - Verify problem with operator.

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - EJECTOR DOES NOT EXTEND OR RETRACT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)


**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**References**

WP 0035  
TM 5-2350-262-20

---

**TROUBLESHOOTING PROCEDURE****EJECTOR DOES NOT EXTEND OR RETRACT****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

Ejector circuit oil is supplied by main pump outputs 13L and 13R. Oil enters main control valve through inlet ports 13L and 13R and combines at the ejector control valve section. When ejector control valve is shifted to BACK position, oil is supplied from port 22 and fed to rod end of ejector cylinder, which causes cylinder rod to retract, pulling ejector back in bow. When ejector control valve is shifted to FORWARD position, oil is supplied from port 21 and fed to ejector head end, causing cylinder rod to extend, pushing ejector forward in bowl. Pressure in ejector circuit is limited by main relief valves 13L and 13R to 3,950-4,050 psi (27,235-27,925 kPa) and circuit relieve valve 21, which limits pressure to extend ejector cylinder.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued****STEP**

1. Check for obstructions in bowl area.

Check bowl area for rock or other debris.

**CONDITION/INDICATION**

Is ejector/bowl area free of obstructions?

**DECISION**

YES - Go to Step (2).

NO - Remove rocks or other obstructions from bowl area. Verify problem is solved.


**STEP**

2. Perform mechanical binding check.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- a. Start engine, operate ejector (Figure 1, Item 1) and check for mechanical binding.
  - b. Check ejector (Figure 1, Item 1), rollers (Figure 1, Item 3), and ejector hydraulic cylinder (Figure 1, Item 4) for damage or jamming.
  - c. Check that ejector lock (Figure 1, Item 2) is not restricting movement of control lever.


**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**



T00903HDC

Figure 1. Ejector.

- d. Check that ejector inhibit ball valve V23 (Figure 2, Item 1) is in the open position.



T00904HDC

Figure 2. Directional Control Valve (DCV) Bank.

- e. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is ejector binding?

**DECISION**

YES - Adjust, repair, or replace damaged components (TM 5-2350-262-20). Verify problem is solved.  
 NO - Go to Step (3).

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued****STEP**

3. Perform suction strainer check.
  - a. Slowly loosen hydraulic tank dipstick (Figure 3, Item 1) to release pressure and remove dipstick.
  - b. Remove suction strainer (Figure 3, Item 2) and inspect for clogged ports or obstructions.
  - c. If dirt, obstructions, or debris is found, clear and clean suction strainer (Figure 3, Item 2).
  - d. Replace suction strainer (Figure 3, Item 2) and dipstick (Figure 3, Item 1).




Figure 3. Suction Strainer.

**CONDITION/INDICATION**

Is suction strainer clean?

**DECISION**

YES - Go to Step (4).

NO - Clean suction strainer. Verify problem is solved.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

**STEP**

4. Perform main relief valve pressure check using Hydraulic Diagnostic Center (HDC).
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 1) on HDC control box.





Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

## EJECTOR DOES NOT EXTEND OR RETRACT - Continued

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- b. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 5, Item 1) on DCV bank.



T00908HDC

*Figure 5. Directional Control Valve (DCV) Bank.*

- c. Using LINE UP or LINE DOWN button (Figure 6, Item 3), select V1 on HDC display (Figure 6, Item 2).
- d. Close V1 on HDC display (Figure 6, Item 2) by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.
- e. Start vehicle engine.
- f. To test 13R circuit:
- (1) With SPRUNG/UNSPRUNG control valve in SPRUNG mode, actuate left SUSPENSION CONTROL valve to RAISE position.
  - (2) Read transducer T-3 hydraulic pressure on HDC display (Figure 6, Item 1).



**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

- g. To test 13L circuit:
- (1) With SPRUNG/UNSPRUNG control valve in SPRUNG mode, actuate right SUSPENSION CONTROL valve to RAISE position.
  - (2) Read transducer T-4 hydraulic pressure on HDC display (Figure 6, Item 1).




Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.

- h. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**


Is hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

- YES - Go to Step (8).  
 NO - Go to Step (5).

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued****STEP**

5. Perform main relief valve adjustment, using HDC.
  - a. Main relief valve adjustment.
    - (1) Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 8, Item 5) on HDC control box.
    - (2) Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 7, Item 1) on DCV bank.



*Figure 7. Directional Control Valve (DCV) Bank.*

- (3) Using LINE UP or LINE DOWN button (Figure 8, Item 3), select V1 on HDC display (Figure 8, Item 2).
      - (4) Close V1 on HDC display (Figure 8, Item 2) by selecting CHANGE POSITION button (Figure 8, Item 4) on HDC control box.
    - b. Main relief valve 13L.
      - (1) With the SPRUNG/UNSPRUNG lever still in SPRUNG, have assistant start engine and move left-hand SUSPENSION CONTROL lever to RAISE, while at the same time, holding EJECTOR CONTROL lever in BACK.
      - (2) Read transducer T-4 hydraulic pressure on HDC display (Figure 8, Item 1).

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**




Figure 8. Hydraulic Diagnostic Center (HDC) Control Box.

- (3) Adjust main relief valve 13L (Figure 9, Item 4) by loosening jam nut (Figure 9, Item 3) and rotating adjustment screw (Figure 9, Item 2) clockwise to increase pressure; counterclockwise to decrease pressure.
- (4) When hydraulic pressure is within limits, tighten jam nut (Figure 9, Item 3).
- (5) Stop engine; relieve hydraulic pressure.
- c. Main relief valve 13R (Figure 9, Item 1).
  - (1) Repeat previous steps using the right-hand SUSPENSION CONTROL lever, main relief valve 13R (Figure 9, Item 1), and read T-3 pressure.
  - (2) Adjustment for main relief valve 13R (Figure 9, Item 1) is on underside of main relief valve 13R (Figure 9, Item 1).




Figure 9. Main Relief Valve 13L and 13R.

- (3) Stop engine; relieve hydraulic pressure.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

**CONDITION/INDICATION**

Is transducer T-3 and T-4 hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

- YES - Verify problem is solved.
- NO - Go to Step (6).

**STEP**

6. Perform main hydraulic pump pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 10, Item 5) on HDC control box.




Figure 10. Hydraulic Diagnostic Center (HDC) Control Bank.

**WARNING**



- Before performing any troubleshooting in bowl, move ejector forward and disable it from hydraulic system. Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

- b. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 11, Item 2) on DCV bank.




Figure 11. Directional Control Valve (DCV) Bank.

- c. Using LINE UP or LINE DOWN button (Figure 10, Item 3), select V1 on HDC display (Figure 10, Item 2).
- d. Close V1 on HDC display (Figure 10, Item 2) by selecting CHANGE POSITION button (Figure 10, Item 4) on HDC control box.
- e. Have assistant start engine and allow engine to idle (750-800 rpm).
- f. Slowly close right main hydraulic pressure inhibit valve V21 (Figure 11, Item 1) until transducer T-3 hydraulic pressure on HDC display (Figure 10, Item 1) indicates 3,950-4,050 psi (27,235-27,925 kPa).
- g. Fully open right main hydraulic pressure inhibit valve V21 (Figure 11, Item 1) on DCV bank.
- h. Stop engine; relieve hydraulic pressure.
- i. Enable ejector by manually opening ejector inhibit ball valve V23 (Figure 11, Item 2) on DCV bank.
- j. Using LINE UP or LINE DOWN button (Figure 10, Item 3), select V1 on HDC display (Figure 10, Item 2).
- k. Open V1 on HDC display (Figure 10, Item 2) by selecting CHANGE POSITION button (Figure 10, Item 4) on HDC control box.

**CONDITION/INDICATION**

Is transducer T-3 hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).  
NO - Go to Step (7).

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued****STEP**

7. Check suction tubes and hoses (inlet) for damage.

Inspect suction tubes and hoses (inlet) (Figure 12).




Figure 12. Suction Tubes and Hoses.

**CONDITION/INDICATION**

Are suction tubes and hoses (inlet) damaged?

**DECISION**

YES - Replace damaged suction tubes or hoses (inlet) (TM 5-2350-262-20).  
 NO - Replace main hydraulic pump (TM 5-2350-262-20).

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

**STEP**

8. Perform ejector circuit pressure check using HDC.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 13, Item 1) on HDC control box.





Figure 13. Hydraulic Diagnostic Center (HDC) Control Box.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

- b. Have assistant start engine and actuate EJECTOR CONTROL lever (Figure 14, Item 1) to BACK position.



*Figure 14. Ejector Control.*

- c. Read transducer T-2 hydraulic pressure on HDC display (Figure 15, Item 1).  
 d. Pressure should be 3,950-4,050 psi (27,235-27,925 kPa).  
 e. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-2 hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Go to Step (9).  
 NO - Replace DCV bank (TM 5-2350-262-20).

**STEP**

9. For ejector extension problems, check ejector circuit No. 21 for pressure.
- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 15, Item 2) on HDC control box.



**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**




Figure 15. Hydraulic Diagnostic Center (HDC) Control Box.


**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- b. Start engine, move ejector halfway forward; stop engine and relieve hydraulic pressure.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

- c. Disable ejector by manually closing ejector inhibit valve V23 (Figure 16, Item 1) on DCV bank.



*Figure 16. Directional Control Valve (DCV) Bank.*

- d. Using LINE UP or LINE DOWN button (Figure 17, Item 3), select V1 on HDC display (Figure 17, Item 2).
- e. Close V1 on HDC display (Figure 17, Item 2) by selecting CHANGE POSITION button (Figure 17, Item 4) on HDC control box.
- f. Have assistant start engine and hold EJECTOR CONTROL lever in FORWARD position.
- g. Read transducer T-2 hydraulic pressure on HDC display (Figure 17, Item 1).
- h. Stop engine; relieve hydraulic pressure.
- i. Enable ejector by manually operating ejector inhibit ball valve V23 (Figure 16, Item 1) on DCV bank.
- j. Using LINE UP or LINE DOWN button (Figure 18, Item 3), select V1 on HDC display (Figure 17, Item 2).
- k. Open V1 on HDC display (Figure 17, Item 2), by selecting CHANGE POSITION button (Figure 17, Item 4) on HDC control box.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**




Figure 17. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is transducer T-2 hydraulic pressure between 1,950-2,050 psi (13,445-14,135 kPa)?

**DECISION**

- YES - Go to Step (11).
- NO - Go to Step (10).


**EJECTOR DOES NOT EXTEND OR RETRACT - Continued****STEP**

10. Perform ejector control valve adjustment using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 19, Item 5) on HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- b. Disable ejector by manually closing ejector inhibit valve V23 (Figure 18, Item 1) on DCV bank.



T00924HDC

*Figure 18. Directional Control Valve (DCV) Bank.*

- c. Using LINE UP or LINE DOWN button (Figure 19, Item 3), select V1 on HDC display (Figure 19, Item 2).
- d. Close V1 on HDC display (Figure 19, Item 2) by selecting CHANGE POSITION button (Figure 19, Item 4) on HDC control box.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**




Figure 19. Hydraulic Diagnostic Center (HDC) Control Box.

- e. Start engine.
- f. With engine at idle speed and EJECTOR CONTROL lever in FORWARD position, loosen jam nut (Figure 20, Item 1) on ejector control valve and turn adjusting screw (Figure 20, Item 2) clockwise to increase pressure; counterclockwise to decrease pressure.





Figure 20. Ejector Control Valve.

- g. Transducer T-2 hydraulic pressure on HDC display (Figure 19, Item 1) should indicate 1,950-2,050 psi (13,445-15,135 kPa).

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

- h. Stop engine; relieve hydraulic pressure.
- i. Manually open ejector inhibit ball valve V23 (Figure 21, Item 1) on DCV bank.



T00924HDC

*Figure 21. Directional Control Valve (DCV) Bank.*

- j. Using LINE UP or LINE DOWN button (Figure 22, Item 2), select V1 on HDC display (Figure 22, Item 1).
- k. Close V1 on HDC display (Figure 22, Item 1), by selecting CHANGE POSITION button (Figure 22, Item 4) on HDC control box.

**CONDITION/INDICATION**

Can pressure be adjusted?

**DECISION**

YES - Verify problem is solved.  
NO - Replace DCV bank (TM 5-2350-262-20).

**STEP**

- 11. Perform ejector cylinder leakage test using HDC.

EJECTOR DOES NOT EXTEND OR RETRACT - Continued

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 22, Item 4) on HDC control box.




Figure 22. Hydraulic Diagnostic Center (HDC) Control Box.

**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

- b. Have assistant actuate EJECTOR CONTROL lever (Figure 23, Item 1) to move ejector forward 3/4 of full travel.




Figure 23. Ejector Control Lever.

- c. Stop engine and relieve hydraulic pressure.
- d. Close main ejector valve (V1) on HDC primary manifold.
- e. Using LINE UP or LINE DOWN button (Figure 24, Item 2), select V1 on HDC display (Figure 24, Item 1).
- f. Close V1 on HDC display (Figure 24, Item 1) by selecting CHANGE POSITION button (Figure 24, Item 3) on HDC control box.
- g. Have assistant start engine and hold EJECTOR CONTROL lever in BACK position for one minute.
- h. Mark position of ejector at side of hull and continue to hold valve lever in BACK position for one more minute.
- i. Check position of ejector while still holding valve lever in BACK position.
- j. If ejector has moved forward more than 0.5 in. (13 mm), the ejector cylinder is leaking excessively.
- k. If cylinder moves aft more than 0.5 in. (13 mm), solenoid valve V1 on HDC primary manifold valve is leaking.
- l. Open main ejector valve; by using LINE UP or LINE DOWN button (Figure 24, Item 2), select V1 on HDC display (Figure 24, Item 1).
- m. Open V1 on HDC display (Figure 24, Item 1), by selecting CHANGE POSITION button (Figure 24, Item 3) on HDC control box.




**EJECTOR DOES NOT EXTEND OR RETRACT - Continued**

Figure 24. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is ejector cylinder leaking internally?

**DECISION**

YES - Replace or repair ejector cylinder (TM 5-2350-262-20) if ejector moved forward, or replace solenoid valve V1 on HDC primary manifold if ejector moved AFT (WP 0035).

NO - Replace solenoid valve V1 on HDC primary manifold (WP 0035).

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT  
UNSPRUNG MODE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**References (cont.)**

WP 0036  
WP 0037

**Materials/Parts**

Sealing Compound (WP 0053, Table 1, Item 3)  
Pin, Cotter (WP 0055, Table 1, Item 1) Qty: 1

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)


**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**References**

WP 0035

---

**TROUBLESHOOTING PROCEDURE****FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- SPRUNG mode provides for a smooth ride up to 30 mph (48 km/h) and is used for over the road marches and parking of vehicle. Hydraulic pressure is supplied to front actuators through line 9.
- Use these procedures to troubleshoot either left or right front of vehicle.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

1. Check if either corner of vehicle will raise in UNSPRUNG mode.
  - a. Start vehicle.
  - b. Move SPRUNG/UNSPRUNG lever to UNSPRUNG.
  - c. Check if one corner raises.

**CONDITION/INDICATION**

Will one corner raise?

**DECISION**

- YES - Go to Step (10).  
 NO - Go to Step (2).

**STEP**

2. Perform system pressure test using Hydraulic Diagnostic Center (HDC).
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 1, Item 2) on HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- If right corner will not raise in UNSPRUNG mode, check 13L circuit using right wheel control.
  - If left corner will not raise in UNSPRUNG mode, check 13R circuit using left wheel control.
- b. Start engine, move ejector forward, engage ejector lock.
  - c. Stop engine, and relieve hydraulic pressure.
  - d. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG and SUSPENSION CONTROL lever to RAISE.
  - e. To read 13R circuit pressure, read transducer T-3 hydraulic pressure on HDC display (Figure 1, Item 1).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- f. To read 13L circuit pressure, read transducer T-4 hydraulic pressure on HDC display (Figure 1, Item 1).




Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.

- g. Move SUSPENSION CONTROL lever to NEUTRAL.
- h. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-3 or T-4 hydraulic pressure between 3,450-3,550 psi (23,788-24,477 kPa)?

**DECISION**

- YES - Go to Step (3).
- NO - Go to Step (6).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**STEP**


3. Perform SPRUNG/UNSPRUNG valve linkage check.

**WARNING**



Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.

- a. Hold measuring device (Figure 2, Item 1) on face of SPRUNG/UNSPRUNG control valve (Figure 2, Item 3).
- b. Have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG mode.
- c. Measure distance plunger (Figure 2, Item 2) travels as lever is moved.



T00105HDC

Figure 2. Control Valve Linkage.

- d. Distance of travel should be 9/32 in. (7 mm).

**CONDITION/INDICATION**

Is linkage correctly adjusted?

**DECISION**

- YES - Go to Step (5).
- NO - Go to Step (4).

**STEP**

4. Perform SPRUNG/UNSPRUNG control valve linkage adjustment.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**WARNING**



Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.

**NOTE**

All control rods are adjusted same way. This procedure covers SPRUNG/UNSPRUNG control rod.

- a. Note position of control valve plunger (Figure 3, Item 1) when SPRUNG/UNSPRUNG control lever is in NEUTRAL (off) position.

**NOTE**

Normal control valve plunger travel is 9/32 in. (7 mm).

- b. Remove cotter pin (Figure 3, Item 2), straight pin (Figure 3, Item 5), and clevis (Figure 3, Item 6) from control valve plunger (Figure 3, Item 1). Discard cotter pin (Figure 3, Item 2).
- c. Loosen jam nut (Figure 3, Item 7). Turn clevis (Figure 3, Item 6) clockwise to shorten rod (Figure 3, Item 3); counterclockwise to lengthen rod (Figure 3, Item 3).
- d. Hold measuring device (Figure 3, Item 4) on face of SPRUNG/UNSPRUNG control valve.
- e. Have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG mode.
- f. Measure distance of plunger travel.
- g. Adjust length of rod (Figure 3, Item 3) travel to desired distance by turning clevis (Figure 3, Item 6) as necessary.
- h. Coat threads of rod (Figure 3, Item 3) with sealing compound.
- i. Tighten jam nut (Figure 3, Item 7) against clevis (Figure 3, Item 6).
- j. Connect clevis (Figure 3, Item 6) to control valve plunger (Figure 3, Item 1) with straight pin (Figure 3, Item 5) and new cotter pin (Figure 3, Item 2).




Figure 3. SPRUNG/UNSPRUNG Control Valve Linkage.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****CONDITION/INDICATION**

Is linkage correctly adjusted?

**DECISION**

YES - Go to Step (5).

NO - Repair or replace SPRUNG/UNSPRUNG control valve linkage (TM 5-2350-262-20).

**STEP**

5. Perform SPRUNG/UNSPRUNG control valve pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.
  - b. Start engine and have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG mode several times.
  - c. Read transducer T-12 hydraulic pressure on HDC display (Figure 4, Item 1).
  - d. Hydraulic pressure should be less than 145 psi (1,000 kPa) in SPRUNG mode and greater than 2,500 psi (17,238 kPa) in UNSPRUNG mode.
  - e. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-12 pressure between 145 psi (1,000 kPa) AND 2,500 psi (17,238 kPa)?

**DECISION**

YES - Go to Step (15).

NO - Replace SPRUNG/UNSPRUNG control valve assembly (TM 5-2350-262-20).

**STEP**

6. Perform main relief valve pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V1 on HDC display (Figure 4, Item 2).
  - c. Close V1 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - d. Have assistant start engine and move ejector forward.
  - e. Move SPRUNG/UNSPRUNG lever to SPRUNG and move EJECTOR CONTROL lever to BACK.
  - f. Read transducer T-3 hydraulic pressure on HDC display (Figure 4, Item 1).
  - g. While simultaneously holding EJECTOR CONTROL lever in BACK, have assistant move right-hand SUSPENSION CONTROL lever to RAISE.
  - h. Read transducer T-3 hydraulic pressure on HDC display (Figure 4, Item 1).
  - i. Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V1 on HDC display (Figure 4, Item 2).
  - j. Open V1 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.



**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**




Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

- k. Stop engine and relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-3 hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

- YES - Go to Step (7).
- NO - Go to Step (20).

**STEP**

- 7. Perform main pump flow test.

**NOTE**

As insufficient flow of hydraulic oil is indicated if ejector requires more than 32 seconds to fully extend or if apron requires more than 15 seconds to fully raise.

- a. Start engine and allow engine to idle (750-850 rpm).
- b. With ejector fully retracted, hold EJECTOR CONTROL lever in FORWARD, and note length of time required for ejector to fully extend.
- c. With apron in full down position, move APRON CONTROL lever to UP, and note length of time required for apron to fully raise. Lower apron.
- d. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Does ejector fully extend in less than 32 seconds and apron raise fully in less than 15 seconds?

**DECISION**

- YES - Go to Step (8).
- NO - Go to Step (19).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

8. Perform suspension pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 5) on HDC control box.

**NOTE**

Perform this test for ports 17R and 17L on Directional Control Valve (DCV) bank. Use the right-hand SUSPENSION CONTROL lever for port 17R and left-hand SUSPENSION CONTROL lever for port 17L.

- b. Port 17L: Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V11 on HDC display (Figure 5, Item 2).
- c. Close V11 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.
- d. Port 17R: Repeat previous step for port 17R, but close V5 instead of V11.
- e. Start engine and have assistant move SPRUNG/UNSPRUNG lever to UNSPRUNG and SUSPENSION CONTROL lever to LOWER.
- f. Read 17L or 17R circuit pressure from transducer T-1 hydraulic pressure on HDC display (Figure 5, Item 1).
- g. Port 17L: Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V11 on HDC display (Figure 5, Item 2).
- h. Open V11 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.

## FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued




Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

- i. Port 17R: Repeat previous step for port 17R, but open V5 instead of V11.
- j. Stop engine; relieve hydraulic pressure.
- k. Remove all test equipment and connect hose.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure at least 3,900 psi (26,891 kPa)?

**DECISION**

YES - Go to Step (9).

NO - Replace DCV bank (TM 5-2350-262-20). Verify problem is solved.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

9. Perform solenoid valve V11 or V5 (as applicable) pressure check.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 6, Item 5) on HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 6, Item 3), select V1 on HDC display (Figure 6, Item 2).
  - c. Close V1 on HDC display (Figure 6, Item 2) by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.
  - d. Verify that transducer T-1 hydraulic pressure on HDC display (Figure 6, Item 1), reads less than 500 psi (3,447.379 kPa).
  - e. Have assistant start engine and place vehicle in UNSPRUNG mode.
  - f. For solenoid valve V11 (circuit 17L): Have assistant move left SUSPENSION CONTROL lever to LOWER.
  - g. Verify that transducer T-1 hydraulic pressure on HDC display (Figure 6, Item 1), reads greater than 3,000 psi (20,684.27 kPa).

**NOTE**

This indicates that V11 has directed flow from suspension to transducer T1, which now reads system relief valve pressure setting.

- h. If pressure is 3,000 psi (20,684.27 kPa) or more, solenoid valve V11 on primary manifold is bad.
- i. For solenoid valve V5 (circuit 17R): Have assistant move the right SUSPENSION CONTROL lever to LOWER.
- j. Verify that transducer T-1 hydraulic pressure on HDC display (Figure 6, Item 1), reads greater than 3,000 psi (20,684.27 kPa).

**NOTE**

This indicates that V5 has directed flow from the suspension to transducer T-1, which now reads system relief valve pressure setting.

- k. If pressure is 3,000 psi (20,684.27 kPa) or more, solenoid valve V11 on primary manifold is bad.
- l. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure greater than 3,000 psi (20,684 kPa)?

**DECISION**

YES - Replace solenoid valve V11 or V5, on primary manifold, as applicable (WP 0035).

NO - Go to Step (10).

**STEP**

10. Perform suspension control valve pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 6, Item 5) on HDC control box.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**NOTE**

If left corner of vehicle will not raise, perform test at port 3L and actuate left-hand SUSPENSION CONTROL lever. If right corner of vehicle will not raise, perform test at port 3R and actuate right-hand SUSPENSION CONTROL lever.

- b. Port 3R: Using LINE UP or LINE DOWN button (Figure 6, Item 3), select V15 on HDC display (Figure 6, Item 2).
- c. Close V15 on HDC display (Figure 6, Item 2) by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.
- d. Port 3L: Repeat previous step for port 3L and close V16 instead of V15.
- e. Start engine and have assistant move SPRUNG/UNSPRUNG lever to UNSPRUNG and SUSPENSION CONTROL lever to RAISE.
- f. Read transducer T-1 hydraulic pressure on HDC display (Figure 6, Item 1).
- g. Port 3R: Using LINE UP or LINE DOWN button (Figure 6, Item 3), select V15 on HDC display (Figure 6, Item 2).
- h. Open V15 on HDC display (Figure 6, Item 2) by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.




Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.

- i. Port 3L: Repeat previous step for port 3L and open V16 instead of V15.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure between 3,400-3,550 psi (23,788-24,477 kPa)?

**DECISION**

- YES - Go to Step (12).
- NO - Go to Step (11).

**STEP**

11. Perform suspension control relief valve adjustment using HDC.
  - a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 5) on HDC control box.




Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.


**NOTE**

If left corner of vehicle will not raise, perform this adjustment at relief valve 3L and actuate left-hand SUSPENSION CONTROL lever. If right corner of vehicle will not raise, perform this adjustment at relief valve 3R and actuate right-hand SUSPENSION CONTROL lever.

- c. Port 3R RELIEF VALVE: Using LINE UP or LINE DOWN button (Figure 7, Item 3), select V15 on HDC display (Figure 7, Item 2).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- d. Close V15 on HDC display (Figure 7, Item 2) by selecting CHANGE POSITION button (Figure 7, Item 4) on HDC control box.
- e. Port 3L relief valve: Repeat previous step for port 3L and close V16 instead of V15.
- f. Start engine and have assistant move SPRUNG/UNSPRUNG lever to UNSPRUNG and SUSPENSION CONTROL lever to RAISE.
- g. Read transducer T-1 hydraulic pressure on HDC display (Figure 7, Item 1).
- h. Loosen jam nut (Figure 8, Item 2) and turn adjusting screw (Figure 8, Item 3) clockwise to increase pressure; counterclockwise to decrease pressure, as necessary.



*Figure 8. Suspension Control Relief Valve Adjustment.*

- i. Adjust pressure to within limits, and tighten jam nut (Figure 8, Item 2).
- j. Stop engine; relieve hydraulic pressure.
- k. Port 3R relief valve (Figure 8, Item 4): Using LINE UP or LINE DOWN button (Figure 7, Item 3), select V15 on HDC display (Figure 7, Item 2).
- l. Open V15 on HDC display (Figure 7, Item 2) by selecting CHANGE POSITION button (Figure 7, Item 4) on HDC control box.
- m. Port 3L relief valve (Figure 8, Item 1): Repeat previous step for port 3L and open V16 instead of V15.

**CONDITION/INDICATION**

Can relief valve be adjusted to 3,450-3,550 psi (23,788-24,477 kPa)?

**DECISION**

- YES - Go to Step (12).
- NO - Replace DCV bank (TM 5-2350-262-20).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

12. Perform No. 1 actuator pressure test (port 3) using HDC.
  - a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 9, Item 2) on HDC control box.

**NOTE**

This test is performed at No. 1 actuator of front corner which will not raise.

- c. Start engine. Place SPRUNG/UNSPRUNG lever in SPRUNG. Move (right or left, as applicable) SUSPENSION CONTROL lever to RAISE.
- d. Read transducer T-5 (front right actuator) or T-6 (front left actuator) hydraulic pressure on HDC display (Figure 9, Item 1).
- e. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-5 (front right actuator) and T-6 (front left actuator) hydraulic pressure greater than 3,000 psi (20,685 kPa)?

**DECISION**

- YES - Go to Step (15).  
NO - Go to Step (13).

**STEP**

13. Perform solenoid valve V15/V16 test.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 9, Item 2) on HDC control box.
  - b. Start engine.
  - c. Wait until transducer T-1 hydraulic pressure on HDC display (Figure 9, Item 1) is less than 500 psi (3,447.379 kPa).
  - d. Move SUSPENSION CONTROL lever (left-hand or right-hand lever, as applicable) to RAISE.
  - e. Read transducer T-1 hydraulic pressure on HDC display (Figure 9, Item 1).



## FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued




Figure 9. Hydraulic Diagnostic Center (HDC) Control Box.

- f. Stop engine; relieve hydraulic pressure.

### CONDITION/INDICATION

Is transducer T-1 hydraulic pressure less than 1,000 psi (6,894.757 kPa)?

### DECISION

YES - Go to Step (14).

NO - Replace solenoid valve V15 on primary manifold if right side of vehicle will not raise (WP 0035). Replace solenoid valve V16 on primary manifold if left side of vehicle will not raise (WP 0035).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**STEP**

14. Perform circuit 3 hoses and lines blockage check.

**WARNING**



Do not work under vehicle unless hull is properly blocked or allowed to settle on bump stops. Failure to comply may result in severe injury or death to personnel.

a. Check for blockage in all hoses and lines applicable to corner of vehicle which will not raise (Figure 10).




Figure 10. Circuit 3 Components, Hoses and Lines.

b. Connect hoses. Verify problem with operator.

**CONDITION/INDICATION**

Is there any blockage?

**DECISION**

YES - Clear blockage or replace lines (TM 5-2350-262-20). Verify problem is solved.

NO - A previous task was incorrectly performed or results misinterpreted. Verify results of all previous tests, beginning at Step (1).

**STEP**

15. Perform No. 1 actuator pressure test (port 11) using HDC.

a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 11, Item 5) on HDC control box.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**NOTE**

This test is performed at No. 1 front actuator which will not raise.

- b. To test RIGHT No. 1 front actuator that will not rise: Using LINE UP or LINE DOWN button (Figure 11, Item 3) on HDC control box, select V2 on HDC display (Figure 11, Item 2).
- c. Using CHANGE POSITION button (Figure 11, Item 4), close V2 on HDC display (Figure 11, Item 2).
- d. Start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG.
- e. Read transducer T-11 hydraulic pressure on HDC display (Figure 11, Item 1).
- f. Using LINE UP or LINE DOWN button (Figure 11, Item 3) on HDC control box, select V2 on HDC display (Figure 11, Item 2).
- g. Using CHANGE POSITION button (Figure 11, Item 4), open V2 on HDC display (Figure 11, Item 2).
- h. To test LEFT No. 1 front actuator that will not rise: Using LINE UP or LINE DOWN button (Figure 11, Item 3) on HDC control box, select V3 on HDC display (Figure 11, Item 2)
- i. Using CHANGE POSITION button (Figure 11, Item 4), close V3 on HDC display (Figure 11, Item 2).
- j. Move SPRUNG/UNSPRUNG lever to UNSPRUNG.
- k. Read transducer T-10 hydraulic pressure on HDC display (Figure 11, Item 1).
- l. Using LINE UP or LINE DOWN button (Figure 11, Item 3) on HDC control box, select V3 on HDC display (Figure 11, Item 2).
- m. Using CHANGE POSITION button (Figure 11, Item 4), open V3 on HDC display (Figure 11, Item 2).




Figure 11. Hydraulic Diagnostic Center (HDC) Control Box.

- n. Stop engine; relieve hydraulic pressure.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**CONDITION/INDICATION**

Is transducer T-10 (front left actuator) and T-11 (front right actuator) hydraulic pressure between 2,800-2,900 psi (19,306-19,996 kPa)?

**DECISION**

YES - Go to Step (17).  
 NO - Go to Step (16).

**STEP**

16. Perform circuit 11 hoses and lines blockage check.

Check for blockage in all hoses and lines applicable to corner of vehicle which will not raise (Figure 12).




Figure 12. Circuit 11 Components, Hoses and Lines.

**CONDITION/INDICATION**

Is there any blockage?

**DECISION**

YES - Clear blockage or replace lines. Verify problem is solved.  
 NO - Verify problem with operator.

**STEP**

17. Check lines between actuator and forward manifold.

**CONDITION/INDICATION**

Is there any blockage?

**DECISION**

YES - Clear blockage or replace lines. Verify problem is solved.  
 NO - Go to Step (18).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**STEP**

18. Perform solenoid valve V2/V3 flow test using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 13, Item 1) on HDC control box.




Figure 13. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**



Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**

Have suitable container ready to catch oil.

- b. Disconnect right forward manifold line 11 for solenoid valve V2.
- c. Disconnect left forward manifold line 11 for solenoid valve V3.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- d. Start engine and have assistant move SPRUNG/UNSPRUNG lever to UNSPRUNG.
- e. Observe flow.
- f. Stop engine; relieve hydraulic pressure.
- g. Reconnect right forward manifold line 11 for solenoid valve V2.
- h. Reconnect left forward manifold line 11 for solenoid valve V3.

**CONDITION/INDICATION**

Is there any flow?

**DECISION**

YES - Notify Direct Support maintenance to replace No. 1 actuator.

NO - Replace solenoid valve V2 on right forward manifold (WP 0037) or replace solenoid valve V3 on left forward manifold, as applicable (WP 0036).

**STEP**

19. Perform main pump suction hose blockage check.


**WARNING**

Do not work under vehicle unless hull is properly blocked or allowed to settle on bump stops. Failure to comply may result in severe injury or death to personnel.

**NOTE**

Have suitable container ready to catch oil.

- a. Stop engine; relieve hydraulic pressure.
- b. Loosen, but do not disconnect, PUMP SUCT TUB-7 (Figure 14, Item 1) from elbow (Figure 14, Item 3) on main hydraulic pump (Figure 14, Item 2).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

*Figure 14. Main Pump Suction Hose Blockage Test.*

- c. Hydraulic oil should flow freely from loosened fitting.
- d. Reconnect line.

**CONDITION/INDICATION**

Is suction hose blocked?

**DECISION**

YES - Clear blockage or replace hose. Verify problem is solved.  
NO - Go to Step (21).


**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

20. Perform main relief valve adjustment using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 16, Item 5) on HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 15, Item 1) on DCV bank.



T00122HDC

Figure 15. Directional Control Valve (DCV) Bank.



**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- c. Using LINE UP or LINE DOWN button (Figure 16, Item 3), select V1 on HDC display (Figure 16, Item 2).
- d. Close V1 on HDC display (Figure 16, Item 2) by selecting CHANGE POSITION button (Figure 16, Item 4) on HDC control box.
- e. With SPRUNG/UNSPRUNG lever in SPRUNG, have assistant move left hand SUSPENSION CONTROL lever to RAISE, while at same time, holding EJECTOR CONTROL lever in BACK.
- f. Observe transducer T-4 hydraulic pressure on HDC display (Figure 16, Item 1).




Figure 16. Hydraulic Diagnostic Center (HDC) Control Box.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- g. If pressure is not within limits adjust main relief valve 13L (Figure 17, Item 4) by loosening jam nut (Figure 17, Item 3) and rotating adjustment screw (Figure 17, Item 2) clockwise to increase pressure; counterclockwise to decrease pressure.
- h. When hydraulic pressure is within limits, tighten jam nut (Figure 17, Item 2).
- i. Stop engine; relieve hydraulic pressure.
- j. Repeat previous steps for main relief valve 13R (Figure 17, Item 1) using right-hand SUSPENSION CONTROL lever and observe transducer T-3 hydraulic pressure on HDC display (Figure 19, Item 1).




Figure 17. Main Relief Valve.

- k. Stop engine; relieve hydraulic pressure.
- l. Enable ejector by manually opening ejector inhibit ball valve V23 (Figure 18, Item 1) on DCV bank.




Figure 18. Directional Control Valve (DCV) Bank.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- m. Using LINE UP or LINE DOWN button (Figure 19, Item 3), select V1 on HDC display (Figure 19, Item 2).
- n. Open V1 on HDC display (Figure 19, Item 2) by selecting CHANGE POSITION button (Figure 19, Item 4) on HDC control box.

**CONDITION/INDICATION**

Can hydraulic pressure be adjusted to 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Verify problem is solved.

NO - Go to Step (21).

**STEP**

- 21. Perform main hydraulic pump testing using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 19, Item 5) on HDC control box.





Figure 19. Hydraulic Diagnostic Center (HDC) Control Box.

## FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- b. Stop engine; relieve hydraulic pressure.
- c. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 20, Item 2) on DCV bank.



T00128HDC

*Figure 20. Directional Control Valve (DCV) Bank.*

- d. Using LINE UP or LINE DOWN button (Figure 21, Item 3), select V1 on HDC display (Figure 21, Item 2).
- e. Close V1 on HDC display (Figure 21, Item 2) by selecting CHANGE POSITION button (Figure 21, Item 4) on HDC control box.
- f. Ensure right main hydraulic pressure inhibit valve V21 (Figure 20, Item 1) is fully opened.
- g. Have assistant start engine and allow engine to idle (750-800 rpm).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

- h. Slowly close right main hydraulic pressure inhibit valve V21 (Figure 20, Item 1), until transducer T-3 hydraulic pressure on HDC display (Figure 21, Item 1) reaches 3,950-4,050 psi (27,235-27,925 kPa).
- i. Fully open right main hydraulic pressure inhibit valve V21 (Figure 20, Item 1).
- j. Stop engine; relieve hydraulic pressure.
- k. Open ejector inhibit ball valve V23 (Figure 20, Item 2) on DCV bank.
- l. Using LINE UP or LINE DOWN button (Figure 21, Item 3), select V1 on HDC display (Figure 21, Item 2).
- m. Open V1 on HDC display (Figure 21, Item 2) by selecting CHANGE POSITION button (Figure 21, Item 4) on HDC control box.




Figure 21. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Does transducer T-3 hydraulic pressure indicate that main pump develops 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

- YES - Replace DCV bank (TM 5-2350-262-20).
- NO - Notify Direct Support maintenance to replace main hydraulic pump.

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT  
SPRUNG MODE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Tester, Hydraulic Hose Assembly  
(WP 0054, Table 1, Item 6)

**References**

WP 0035

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)


**Materials/Parts**

Pin, Cotter (WP 0055, Table 1, Item 1) Qty: 1

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- SPRUNG mode provides for a smooth ride up to 30 mph (48 km/h) and is used for over the road marches and parking of vehicle. Hydraulic pressure is supplied to front actuators through line 9.
- Use these procedures to troubleshoot either left or right front of vehicle.

**STEP**

1. Perform V19 test.
  - a. Start engine.
  - b. Reset all Hydraulic Diagnostic Center (HDC) solenoid valves by selecting RESET VALVES button (Figure 1, Item 5) on HDC control box.
  - c. Using LINE UP or LINE DOWN button (Figure 1, Item 3) on HDC control box.
  - d. Select V5 on HDC display (Figure 1, Item 2), and using CHANGE POSITION button (Figure 1, Item 4), close V5 on HDC display (Figure 1, Item 2).
  - e. Move SPRUNG/UNSPRUNG lever to UNSPRUNG.
  - f. Read transducer T-1 hydraulic pressure on HDC display (Figure 1, Item 1).
  - g. Using LINE UP or LINE DOWN button (Figure 1, Item 3) on HDC control box, select V5 on HDC display (Figure 1, Item 2).
  - h. Using CHANGE POSITION button (Figure 1, Item 4), open V5 on HDC display (Figure 1, Item 3).



**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**




Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.

- i. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure greater than 500 psi (3,447.79 kPa)?

**DECISION**

- YES - Replace solenoid V19 on primary manifold (WP 0035).
- NO - Go to Step (2).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued****STEP**

2. Perform No. 1 actuator oil flow and hydraulic pressure test.

**NOTE**

Have suitable container ready to catch oil.

- a. Stop engine; relieve hydraulic pressure.
- b. Disconnect No. 1 SPNSN UNIT- #9 hose (Figure 2, Item 2) at elbow (Figure 2, Item 6) on port 9 (Figure 2, Item 7) of No. 1 actuator (Figure 2, Item 4).
- c. Cap elbow (Figure 2, Item 6).
- d. Connect tee (Figure 2, Item 1), globe valve (Figure 2, Item 8), and pressure measuring device (Figure 2, Item 3) to end of No. 1 SPNSN UNIT-#9 hose (Figure 2, Item 2).
- e. Connect a drain hose (Figure 2, Item 5) to open end of globe valve (Figure 2, Item 8).
- f. Place end of hose (Figure 2, Item 5) in container. Start engine. Open globe valve (Figure 2, Item 8).
- g. Observe for flow of oil.

**CONDITION/INDICATION**

Does oil flow freely?

**DECISION**

YES - Go to Step (3).  
NO - Go to Step (10).

**STEP**

3. Close globe valve and check hydraulic pressure.

Close globe valve (Figure 2, Item 8) and measure pressure on pressure measuring device (Figure 2, Item 3).

**CONDITION/INDICATION**

Is hydraulic pressure greater than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Go to Step (4).  
NO - Go to Step (10).

**STEP**

4. Check for blockage at port 9.

**CONDITION/INDICATION**

Is port 9 blocked?


**DECISION**

YES - Clear blockage. Remove all test equipment and connect hoses. Verify problem is solved.  
NO - Go to Step (10).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued****STEP**

5. Check if front corner will raise when front suspension control valve is actuated.

Close globe valve (Figure 2, Item 8) and measure pressure on pressure measuring device (Figure 2, Item 3).



T01104HDC

Figure 2. No. 1 Right Actuator.

**CONDITION/INDICATION**

Will front corner raise?

**DECISION**

YES - Go to Step (8).  
NO - Go to Step (6).

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**


**STEP**

- 6. Perform raise front corner test.

**NOTE**

Have suitable container ready to catch oil.

- a. Disconnect SPNSN UNIT-2 hose (Figure 3, Item 1) from port 2 (Figure 3, Item 2) on No. 1 actuator (Figure 3, Item 3).
- b. Cap and plug port 2 (Figure 3, Item 2) and SPNSN UNIT-2 hose (Figure 3, Item 1).



T01105HDC

*Figure 3. No. 1 Right Actuator.*

- c. Start engine. Move SPRUNG/UNSPRUNG lever to SPRUNG mode.
- d. Stop engine; relieve hydraulic pressure and connect hoses.

**CONDITION/INDICATION**

Does corner raise?

**DECISION**

- YES - Replace No. 2 actuator (TM 5-2350-262-20).
- NO - Replace No. 1 actuator (TM 5-2350-262-20).

**STEP**

- 7. Perform front actuator pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 5) on HDC control box.
  - b. For front left:
    - (1) Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V3 on HDC display (Figure 4, Item 2).
    - (2) Close V3 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
  - c. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG mode.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**

- d. Read transducer T-10 hydraulic pressure on HDC display (Figure 4, Item 1).
- e. Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V3 on HDC display (Figure 4, Item 2).
- f. Open V3 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
- g. For front right:
  - (1) Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V2 on HDC display (Figure 4, Item 2).
  - (2) Close V2 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.
- h. Have assistant keep SPRUNG/UNSPRUNG lever in UNSPRUNG mode.
- i. Read transducer T-11 hydraulic pressure on HDC display (Figure 4, Item 1).
- j. Using LINE UP or LINE DOWN button (Figure 4, Item 3), select V2 on HDC display (Figure 4, Item 2).
- k. Open V2 on HDC display (Figure 4, Item 2) by selecting CHANGE POSITION button (Figure 4, Item 4) on HDC control box.




Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

- l. Stop engine; relieve hydraulic pressure.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**

**CONDITION/INDICATION**

Is transducer T-10 (front left) and T-11 (front right) pressure greater than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Go to Step (9).

NO - Replace front actuator (TM 5-2350-262-20).

**STEP**

8. Perform SPRUNG/UNSPRUNG control valve linkage check.
  - a. Hold measuring device (Figure 5, Item 1) on face of SPRUNG/UNSPRUNG control valve (Figure 5, Item 2).
  - b. Have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG mode.
  - c. Measure distance plunger (Figure 5, Item 3) travels as lever is moved.




Figure 5. SPRUNG/UNSPRUNG Control Valve Linkage.

- d. Distance of travel should be 9/32 in. (7 mm).

**CONDITION/INDICATION**

Is linkage correctly adjusted?

**DECISION**

YES - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).

NO - Go to Step (9).

**STEP**

9. Perform SPRUNG/UNSPRUNG valve linkage adjustment.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**

**WARNING**



Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.

**NOTE**

All valve control rods are adjusted basically the same way. This procedure covers SPRUNG/UNSPRUNG valve control rod.

- a. Note position of control valve plunger (Figure 6, Item 1) when SPRUNG/UNSPRUNG control lever is in neutral (off) position.

**NOTE**

Normal control valve plunger travel is 9/32 in. (7 mm).

- b. Remove cotter pin (Figure 6, Item 2), straight pin (Figure 6, Item 5), and clevis (Figure 6, Item 6) from control valve plunger (Figure 6, Item 1).
- c. Discard cotter pin (Figure 6, Item 2).
- d. Loosen jam nut (Figure 6, Item 7).
- e. Turn clevis (Figure 6, Item 6) clockwise to shorten rod (Figure 6, Item 3), counterclockwise to lengthen rod (Figure 6, Item 3).
- f. Hold measuring device (Figure 6, Item 4) on face of SPRUNG/UNSPRUNG control valve.
- g. Have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG mode.
- h. Measure distance of plunger travel.
- i. Adjust clevis (Figure 6, Item 6) so plunger (Figure 6, Item 1) travel distance is correct (9/32 in. (7 mm)).
- j. When proper adjustment has been made, coat threads of rod (Figure 6, Item 3) with sealing compound primer and sealing compound.
- k. Tighten jam nut (Figure 6, Item 7) against clevis (Figure 6, Item 6).
- l. Connect clevis (Figure 6, Item 6) to control valve plunger (Figure 6, Item 1) with straight pin (Figure , Item 5) and new cotter pin (Figure 6, Item 2).




Figure 6. SPRUNG/UNSPRUNG Valve Linkage.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued****CONDITION/INDICATION**

Is linkage correctly adjusted? Can it be adjusted?

**DECISION**

YES - Replace DCV bank (TM 5-2350-262-20).

NO - Repair or replace DCV linkage (TM 5-2350-262-20).

**STEP**

10. Perform forward manifold pressure test using HDC.
  - a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 5) on HDC control box.
  - c. For front left (left forward manifold): Using LINE UP or LINE DOWN button (Figure 7, Item 3), select V9 on HDC display (Figure 7, Item 2).
  - d. Close V9 on HDC display (Figure 7, Item 2) by selecting CHANGE POSITION button (Figure 7, Item 4) on HDC control box.
  - e. Have assistant start engine and move SPRUNG/UNSPRUNG control valve lever to SPRUNG mode.
  - f. Read transducer T-7 hydraulic pressure on HDC display (Figure 7, Item 1).
  - g. For front right (right forward manifold): Using LINE UP or LINE DOWN button (Figure 7, Item 3), select V10 on HDC display (Figure 7, Item 2).
  - h. Close V10 on HDC display (Figure 7, Item 2), by selecting CHANGE POSITION button (Figure 7, Item 4) on HDC control box.
  - i. With SPRUNG/UNSPRUNG control valve lever still in SPRUNG mode, read transducer T-8 hydraulic pressure on HDC display (Figure 7, Item 1).
  - j. Stop engine; relieve hydraulic pressure.
  - k. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 5) on HDC control box.



**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**




Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is transducer T-7 (left) and T-8 (right) hydraulic pressure greater than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Go to Step (11).  
 NO - Go to Step (12).

**STEP**

11. Check for blockage between inlet port 9 of forward manifold and port 9 of No. 1 actuator, and between left main manifold and No. 1 actuator.

**CONDITION/INDICATION**

Is there blockage?


**DECISION**

YES - Clear blockage. Verify problem is solved.  
 NO - Verify problem with operator.

**FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE - Continued**

**STEP**

12. Check for blockage in line between forward manifold inlet port 9 and main manifold outlet port 9 (Figure 8).



T0111HDC

Figure 8. Manifold Inlet/Outlet Port 9.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

- YES - Clear blockage or replace FWD MNF-9 tube between main forward manifold and LH or RH forward manifold. Verify problem is solved.
- NO - Verify problem with operator.

**END OF WORK PACKAGE**

---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG  
OR UNSPRUNG MODE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- In SPRUNG mode, hydraulic pressure is delivered to front actuator through line 9. In UNSPRUNG mode, hydraulic pressure to raise front corner of vehicle is delivered through line 3.
- Use these procedures to troubleshoot either left or right front of vehicle.

**FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued**

**STEP**

1. Perform front actuator port 9 pressure test using the Hydraulic Diagnostic Center (HDC).
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 1, Item 2) on HDC control box.
  - b. Have assistant start engine and move SPRUNG/UNSPRUNG lever to SPRUNG mode.
  - c. Read transducer T-8 (right) and T-9 (left) hydraulic pressure on HDC display (Figure 1, Item 1).

**CONDITION/INDICATION**

Is transducer T-8 (right) and T-9 (left) hydraulic pressure greater than 2,500 psi (17,238 kPa)?

**DECISION**

- YES - Go to Step (3).
- NO - Go to Step (2).

**STEP**

2. Perform front actuator port 3 pressure test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 1, Item 2) on HDC control box.
  - b. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG mode and SUSPENSION CONTROL lever to RAISE.
  - c. Read transducer T-5 (right) and T-6 (left) hydraulic pressure on HDC display (Figure 1, Item 1).




Figure 1. Hydraulic Diagnostic Center (HDC) Control Box.

- d. Stop engine; relieve hydraulic pressure.

**FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued****CONDITION/INDICATION**

Is transducer T-5 (right) and T-6 (left) hydraulic pressure greater than 2,500 psi (17,238 kPa)?

**DECISION**

YES - Go to Step (3)

NO - Replace No. 1 actuator (TM 5-2350-262-20).


**STEP**

3. Determine if there is excessive internal leakage from No. 1 actuator by checking if front corner will raise in both SPRUNG and UNSPRUNG mode.

**NOTE**

Have suitable container ready to catch oil.

- a. Disconnect NO 1 SPNSN UNIT-2 hose (Figure 2, Item 4) from elbow (Figure 2, Item 3) at port 2 (Figure 2, Item 2) on No. 1 actuator (Figure 2, Item 1).
- b. Cap elbow (Figure 2, Item 3) and plug hose (Figure 2, Item 4).



*Figure 2. No. 1 Right Actuator Depicted.*

- c. Have assistant start engine and move SPRUNG/UNSPRUNG lever to SPRUNG. Observe that corner of vehicle does raise.
- d. Have assistant move SPRUNG/UNSPRUNG lever to UNSPRUNG and SUSPENSION CONTROL lever to RAISE. Observe that corner of vehicle does raise.
- e. Stop engine; relieve hydraulic pressure and connect lines.

**FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued****CONDITION/INDICATION**

Does front corner raise in SPRUNG mode?

**DECISION**

YES - Go to Step (4).

NO - Go to Step (5).

**STEP**

4. Check if front corner raises in UNSPRUNG mode.

**CONDITION/INDICATION**

Will front corner raise in UNSPRUNG mode?

**DECISION**

YES - Go to Step (6).

NO - Verify with operator that problem is only confined to front corner.

**STEP**

5. Check if front corner raises in UNSPRUNG mode.

**CONDITION/INDICATION**

Does front corner raise in UNSPRUNG mode?

**DECISION**

YES - Verify with operator that problem is only confined to front corner.

NO - Replace No. 1 actuator (TM 5-2350-262-20).

**STEP**


6. Perform No. 2 actuator leakage check.

**NOTE**

Have suitable container ready to catch oil.

- a. Connect NO 1 SPNSN UNIT-2 hose (Figure 3, Item 3) to NO 1 SPNSN UNIT-3 hose (Figure 3, Item 2).
- b. Start engine and move SUSPENSION CONTROL lever to RAISE. Excessive leakage is indicated if corner of vehicle fails to raise.
- c. If front corner does raise, problem is most likely No. 1 actuator (Figure 3, Item 1).

**FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued**



T01205HDC

*Figure 3. No. 1 Right Actuator Depicted.*

- d. Stop engine; relieve hydraulic pressure and connect lines.

**CONDITION/INDICATION**

Does front corner raise?

**DECISION**

- YES - Verify problem with operator.
- NO - Go to Step (7).

**STEP**

- 7. Check for blockage in line between No. 1 and No. 2 actuators.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

- YES - Clear blockage or replace line. Verify problem is solved.
- NO - Replace No. 2 actuator (TM 5-2350-262-20).

**END OF WORK PACKAGE**





---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - HYDRAULIC OIL OVERHEATS**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

**References**

WP 0035  
WP 0038

**Materials/Parts**

Suitable Container,  
Minimum Capacity 2 gal. (7.6 L)  
Suitable Support Block(s)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****HYDRAULIC OIL OVERHEATS****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

1. Perform Hydraulic Diagnostic Center (HDC) manual valve status check. Ensure that manually-operated HDC valves V21, V22, and V23 are open.
  - a. Check status of manually-operated valves V21 (Figure 1, Item 1), V22 (Figure 1, Item 2), and V23 (Figure 1, Item 3).




Figure 1. Directional Control Valve (DCV) Bank.

- b. Ensure these manually-operated valves are completely open.

**CONDITION/INDICATION**

Are all manual valves open?

**DECISION**

- YES - Go to Step (2).  
 NO - Open valves.

**STEP**

2. Perform HDC solenoid valve V19 test.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 2, Item 5) on HDC control box.
  - b. Start engine and have assistant move SPRUNG/UNSPRUNG lever to SPRUNG mode.
  - c. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V5 on HDC display (Figure 2, Item 2).
  - d. Close V5 on HDC display (Figure 2, Item 2) by selecting CHANGE POSITION button (Figure 2, Item 4) on HDC control box.
  - e. Have assistant move SPRUNG/UNSPRUNG lever to UNSPRUNG mode.
  - f. Read transducer T-1 hydraulic pressure on HDC display (Figure 2, Item 1).

**HYDRAULIC OIL OVERHEATS - Continued**

- g. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V5 on HDC display (Figure 2, Item 2).
- h. Open V5 on HDC display (Figure 2, Item 2) by selecting CHANGE POSITION button (Figure 2, Item 4) on HDC control box.




Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.

- i. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure greater than 1,000 psi (6,894.757 kPa)?

**DECISION**

YES - Replace solenoid valve V19 on HDC primary manifold (WP 0035).  
 NO - Go to Step (3).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

3. Perform overheated hoses check.

**WARNING**



- Before performing any hydraulic troubleshooting in the bowl, move the ejector forward and engage the ejector lock. Failure to comply may result in severe injury to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury to personnel.

**NOTE**

Begin this procedure with engine cold.

- a. Start engine and allow engine to run for about five minutes before testing for overheating.
- b. As engine warms, carefully feel CONT VLV-19 (Figure 3, Item 2), CONT VLV-20 (Figure 3, Item 5), SPNSN PUMP DRAIN-7V hose (Figure 3, Item 1), relief VLV-7 tube (Figure 3, Item 6), CONT VLV-21 hose (Figure 3, Item 4), and CON VLV-22 hose (Figure 3, Item 3) with an ungloved hand.




Figure 3. Manifold Hoses.

- c. Hoses should feel warm but not hot.

**HYDRAULIC OIL OVERHEATS - Continued**

- d. Cycle apron and ejector control levers for total oil flow through systems.
- e. Operate vehicle for 1/2 hour.
- f. Stop and repeat previous two steps every 10 minutes to check if an overheated hose or tube can be detected.
- g. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Are hoses overheated?

**DECISION**

YES - Go to Step (4).  
NO - Troubleshoot temperature indicator and transmitter.

**STEP**

- 4. Check if SPNSN PUMP DRAIN 7V hose is over heated.

**CONDITION/INDICATION**

Is SPNSN PUMP DRAIN 7V hose overheated?

**DECISION**

YES - Go to Step (10).  
NO - Go to Step (5).

**STEP**

- 5. Check if RELIEF VLV-7 tube is overheated.

**CONDITION/INDICATION**

Is RELIEF VLV-7 tube overheated?

**DECISION**

YES - Go to Step (11).  
NO - Go to Step (6).

**STEP**

- 6. Check if CONT VLV-21 or CONT VLV-22 hose is overheated.

**CONDITION/INDICATION**

Is CONT VLV-21 or CONT VLV-22 hose overheated?

**DECISION**

YES - Go to Step (13).  
NO - Go to Step (7).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

7. Check if control valve hose 19 or 20 is overheated.

**CONDITION/INDICATION**

Is control valve hose 19 OR 20 overheated?

**DECISION**

YES - Go to Step (13).

NO - Go to Step (8).

**STEP**

8. Check if circuits 9 or 2 hoses at right or left No. 1 or No. 4 actuators are overheated.
- Start engine and allow to run for 5 minutes before testing for overheating.
  - Feel circuit No. 2 line between HDC system aft manifold and No. 4 left actuator, and circuit No. 2 line between aft manifold and No. 3 left actuator.
  - Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Are circuits 9 OR 2 hoses at right or left No. 1 or No. 4 actuators overheated?

**DECISION**

YES - Go to Step (26).

NO - Go to Step (9).

**STEP**

9. Perform solenoid valve V18 check.
- Start engine and allow to run 5 minutes before testing for overheating.
  - Feel circuit No. 2 line between HDC system aft manifold and No. 4 left actuator, and circuit No. 2 line between aft manifold and No. 3 left actuator.
  - Stop engine, relieve hydraulic pressure.

**CONDITION/INDICATION**

Is line to NO. 4 actuator noticeably hotter than line to NO. 3 actuator?

**DECISION**

YES - Replace solenoid valve V18 on HDC aft manifold (WP 0038).

NO - Verify problem with operator.

**STEP**

10. Perform case drain leakage test to check for excessive internal leakage from compensating pump.

HYDRAULIC OIL OVERHEATS - Continued

**WARNING**



Before performing any troubleshooting in bowl, move ejector forward and engage ejector lock. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- Have a graduated container of at least two quart (1.9 liter) capacity available to catch hydraulic oil while test is being performed.
  - Have suitable container ready to catch oil.
- a. Start engine, move ejector forward.
  - b. Stop engine, engage ejector lock, and relieve hydraulic pressure.
  - c. Disconnect SPNSN PUMP-9 hose (Figure 4, Item 3) and elbow (Figure 4, Item 4) on compensating pump (Figure 4, Item 2).
  - d. Cap elbow (Figure 4, Item 4) and plug hose (Figure 4, Item 3).
  - e. Disconnect SPNSN PUMP DRAIN-7V hose (Figure 4, Item 5) from elbow (Figure 4, Item 1). Plug hose (Figure 4, Item 5).
  - f. Connect drain hose (Figure 4, Item 6) to elbow (Figure 4, Item 1).
  - g. Hold end of drain hose (Figure 4, Item 6) in graduated container.




Figure 4. Compensating Pump.

- h. Have assistant start engine and run at 1,800 rpm for 15 seconds.
- i. Observe quantity of hydraulic oil in container.
- j. More than 1.25 qts (1.2 L) indicates excessive leakage.
- k. Stop engine; relieve hydraulic pressure, remove all test equipment, and connect hoses.

**HYDRAULIC OIL OVERHEATS - Continued**

**CONDITION/INDICATION**

Is internal leakage more than 1.25 QTS (1.2 L) for 15 seconds?

**DECISION**

YES - Replace compensating pump (TM 5-2350-262-20).

NO - Go to Step (11).

**STEP**

11. Perform pressure test on suspension relief valve using HDC.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.

- a. Start engine, move ejector forward, engage ejector lock.
- b. Stop engine and relieve hydraulic pressure.
- c. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 4) on HDC control box.





Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.



**HYDRAULIC OIL OVERHEATS - Continued**

- d. Manually close ejector inhibit ball valve V23 (Figure 6, Item 1) on DCV bank.



T01310HDC

*Figure 6. Directional Control Valve (DCV) Bank.*

- e. Using LINE UP or LINE DOWN button (Figure 5, Item 2) on HDC control box, select V5 on HDC display (Figure 5, Item 1).
- f. Using CHANGE POSITION button (Figure 5, Item 3), close V5 on HDC display (Figure 5, Item 1).
- g. Repeat step for V12, V13, and V19; closing V12 and V13, and opening V19.
- h. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG and right SUSPENSION CONTROL lever to LOWER.
- i. Read transducer T-13 pressure on HDC display (Figure 5, Item 1).
- j. Stop engine; relieve hydraulic pressure.
- k. Using LINE UP or LINE DOWN button (Figure 5, Item 2) on HDC control box, select V5 on HDC display (Figure 5, Item 1).
- l. Using CHANGE POSITION button (Figure 5, Item 3), open V5 on HDC display (Figure 7, Item 1).
- m. Repeat step for V12, V13 and V19, opening V12 and V13, and closing V19.
- n. Manually open ejector inhibit ball valve V23 (Figure 6, Item 1) on DCV bank.

**CONDITION/INDICATION**

Is transducer T-13 hydraulic pressure 3,700-3,800 psi (25,512-26,201 kPa)?

**DECISION**

YES - Go to Step (13).  
NO - Go to Step (12).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

12. Perform suspension relief valve adjustment using HDC.

**WARNING**



- Before performing any hydraulic troubleshooting in the bowl, move the ejector forward and engage the ejector lock. Failure to comply may result in severe injury to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury to personnel.

a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 5) on HDC control box.





Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.


b. Manually close ejector inhibit ball valve V23 (Figure 8, Item 1) on DCV bank.

**HYDRAULIC OIL OVERHEATS - Continued**



*Figure 8. Directional Control Valve (DCV) Bank.*

- c. Using LINE UP or LINE DOWN button (Figure 7, Item 3) on HDC control box, select V5 on HDC display (Figure 7, Item 2).
- d. Using CHANGE POSITION button (Figure 7, Item 4), close V5 on HDC display (Figure 7, Item 2).
- e. Repeat steps for V12, V13 and V19, closing V12 and V13, and opening V19.
- f. Start engine.
- g. Adjust pressure as follows: remove cap (Figure 9, Item 3) from suspension relief valve adjustment shaft (Figure 9, Item 2) and loosen jam nut (Figure 9, Item 1).
- h. Turn adjusting shaft (Figure 9, Item 2) clockwise to increase pressure; counterclockwise to decrease pressure.



*Figure 9. Suspension Relief Valve.*

- i. Read transducer T-13 hydraulic pressure on HDC display (Figure 7, Item 1).
- j. Turn adjusting shaft (Figure 9, Item 2) to obtain proper pressure indication on transducer T-13 (Figure 7, Item 1) on HDC control box.
- k. Tighten jam nut (Figure 9, Item 1) and replace cap (Figure 9, Item 3).
- l. Stop engine; relieve hydraulic pressure.
- m. Using LINE UP or LINE DOWN button (Figure 7, Item 3) on HDC control box, select V5 on HDC display (Figure 7, Item 2).
- n. Manually open ejector inhibit ball valve V23 (Figure 8, Item 1) on DCV bank.

**HYDRAULIC OIL OVERHEATS - Continued**

- o. Using CHANGE POSITION button (Figure 10, Item 4), open V5 on HDC display (Figure 10, Item 2).
- p. Repeat step for V12, V13 and V19; opening V12 and V13, and closing V19.
- q. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-13 hydraulic pressure 3,700-3,800 psi (25,512-26,201 kPa)?


**DECISION**

- YES - Verify problem is solved.
- NO - Replace suspension relief valve (TM 5-2350-262-20).

**STEP**

13. Perform main hydraulic pump pressure test using HDC.

**WARNING**



- Before performing any troubleshooting in bowl, move ejector forward and engage ejector lock. Failure to comply may result in severe injury or death to personnel.
- Ensure right main hydraulic pressure inhibit valve V21 is fully opened prior to starting vehicle. A fully or partially closed valve will cause immediate high pressure. Failure to comply may result in damage to equipment and injury to personnel.

a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 10, Item 5) on HDC control box.




Figure 10. Hydraulic Diagnostic Center (HDC) Control Box.

## HYDRAULIC OIL OVERHEATS - Continued

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Stop engine; relieve hydraulic pressure.
- c. Ensure right main hydraulic pressure inhibit valve V21 (Figure 11, Item 1) is fully opened.




Figure 11. Directional Control Valve (DCV) Bank.

- d. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 11, Item 2) on DCV bank.
- e. Using LINE UP or LINE DOWN button (Figure 10, Item 3), select V1 on HDC display (Figure 10, Item 2).
- f. Close V1 on HDC display (Figure 10, Item 2) by selecting CHANGE POSITION button (Figure 10, Item 4) on HDC control box.
- g. Have assistant start engine and allow engine to idle (750-800 rpm).
- h. Slowly close right main hydraulic pressure inhibit valve V21 (Figure 11, Item 1), until transducer T-3 hydraulic pressure on HDC display (Figure 10, Item 1) indicates 3,950-4,050 psi (27,235-27,925 kPa).
- i. Open right main hydraulic pressure inhibit valve V21 (Figure 11, Item 1) fully.
- j. Stop engine; relieve hydraulic pressure.
- k. Open ejector inhibit ball valve V23 (Figure 11, Item 2) on DCV bank.
- l. Using LINE UP or LINE DOWN button (Figure 10, Item 3), select V1 on HDC display (Figure 10, Item 2).
- m. Open V1 (Figure 10, Item 2) on HDC display by selecting CHANGE POSITION button (Figure 10, Item 4) on HDC control box.

**HYDRAULIC OIL OVERHEATS - Continued****CONDITION/INDICATION**

Does main hydraulic pump develop 3,950-4,050 psi (27,235-27,925 kPa)?


**DECISION**

YES - Go to Step (14).

NO - Stop engine; relieve hydraulic pressure. Replace main hydraulic pump (TM 5-2350-262-20).

**STEP**

14. Perform main relief valve test using HDC.

**WARNING**

Before performing any hydraulic troubleshooting in the bowl, move ejector forward and disable it by disconnecting ejector cylinder from hydraulic system. Failure to comply may result in severe injury or death to personnel.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 12, Item 5) on HDC control box.
- b. Start engine, move ejector forward.
- c. Using LINE UP or LINE DOWN button (Figure 12, Item 3), select V1 on HDC display (Figure 12, Item 2). Close V1 on HDC display (Figure 12, Item 2) by selecting CHANGE POSITION button (Figure 12, Item 4) on HDC control box.
- d. Have assistant hold EJECTOR CONTROL lever in BACK. Read transducer T-3 (13R) and T-4 (13L) pressure valves individually on HDC display (Figure 12, Item 1). Check main relief valves 13R and 13L as follows:
  - e. For 13R; With SPRUNG/UNSPRUNG lever in SPRUNG position, have assistant move right-hand SUSPENSION CONTROL lever to RAISE, while at the same time holding the EJECTOR CONTROL lever in BACK. Read transducer T-3 hydraulic pressure on HDC display (Figure 12, Item 1). If pressure is not within limits, adjust main relief valve 13R.
  - f. For 13L; Repeat steps for main relief valve 13L (pressure transducer T-4) moving left-hand SUSPENSION CONTROL lever to RAISE while at same time holding EJECTOR CONTROL lever in BACK.
- g. Read transducer T-4 hydraulic pressure on HDC display (Figure 12, Item 1).
- h. Using LINE UP or LINE DOWN button (Figure 12, Item 3), select V1 on HDC display (Figure 12, Item 2). Close V1 on HDC display (Figure 12, Item 2) by selecting CHANGE POSITION button (Figure 12, Item 4) on HDC control box.

**HYDRAULIC OIL OVERHEATS - Continued**




Figure 12. Hydraulic Diagnostic Center (HDC) Control Box.

- i. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-3 AND T-4 hydraulic pressure 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

- YES - Go to Step (16).
- NO - Go to Step (15).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

15. Perform main relief valve adjustment using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 13, Item 4) on HDC control box.




Figure 13. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**




- Before performing any hydraulic troubleshooting in the bowl, move the ejector forward and engage the ejector lock. Failure to comply may result in severe injury to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury to personnel.



**HYDRAULIC OIL OVERHEATS - Continued**

- b. Disable ejector; manually close V23 (Figure 14, Item 1) on DCV bank.



*Figure 14. Directional Control Valve (DCV) Bank.*

- c. Using LINE UP or LINE DOWN button (Figure 13, Item 2), select V1 on HDC display (Figure 13, Item 1).
- d. Close V1 on HDC display (Figure 13, Item 1) by selecting CHANGE POSITION button (Figure 13, Item 3) on HDC control box.

**HYDRAULIC OIL OVERHEATS - Continued**

- e. Loosen jam nut (Figure 15, Item 6) on main relief valve 13R (Figure 15, Item 1).
- f. For 13R (Figure 15, Item 1); have assistant simultaneously hold EJECTOR CONTROL lever in BACK while holding right-hand SUSPENSION CONTROL lever in RAISE.
- g. Rotate adjusting screw (Figure 15, Item 5) on main relief valve 13R (Figure 15, Item 1) clockwise to increase pressure or counterclockwise to decrease pressure.




Figure 15. Main Pump Relief Valves.

- h. Once indication from transducer T-3 on HDC display (Figure 16, Item 1) hydraulic pressure is within desired limits, tighten jam nut (Figure 15, Item 6).




Figure 16. HDC Control Valve.

- i. For 13L (Figure 15, Item 4); repeat previous steps for main relief valve 13L (Figure 15, Item 4) using left-hand SUSPENSION CONTROL lever.

**HYDRAULIC OIL OVERHEATS - Continued**

- j. Reference main relief valve 13L (Figure 15, Item 4) jam nut (Figure 15, item 3), adjusting screw (Figure 15, Item 2), and pressure transducer T-4 (Figure 16, Item 1) on HDC display, when adjusting 13L main relief valve (Figure 15, Item 4).
- k. Stop engine; relieve hydraulic pressure.
- l. Enable ejector; manually open V23 (Figure 17, Item 1) on DCV bank.




Figure 17. Directional Control Valve (DCV) Bank.

- m. Using LINE UP or LINE DOWN button (Figure 16, Item 3) select V1 on HDC display (Figure 16, Item 2).
- n. Open V1 on HDC display (Figure 16, Item 2) by selecting CHANGE POSITION button (Figure 16, Item 4) on HDC control box.

**CONDITION/INDICATION**

Is transducer T-3 hydraulic pressure 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Stop engine, relieve hydraulic pressure. Verify problem is solved.

NO - Stop engine, relieve hydraulic pressure. Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

16. Perform suspension raise/lower relief valve test using HDC.
- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 18, Item 5) on HDC control box.

**NOTE**

This test is done at both right-hand and left-hand suspension raise/lower relief valves.  
For the right-hand valve (port 3R), actuate right-hand SUSPENSION CONTROL lever.  
For left-hand valve (port 3L), actuate left-hand SUSPENSION CONTROL lever.

- b. For 3R; using LINE UP or LINE DOWN button (Figure 18, Item 3) select V15 on HDC display (Figure 18, Item 2).
- c. Close V15 on HDC display (Figure 18, Item 2) by selecting CHANGE POSITION button (Figure 18, Item 4) on HDC control box.
- d. Have assistant start engine, move right-hand SUSPENSION CONTROL lever to RAISE.
- e. Read transducer T-1 hydraulic pressure on HDC display (Figure 18, Item 1).
- f. Using LINE UP or LINE DOWN button (Figure 18, Item 3) select V15 on HDC display (Figure 18, Item 2).
- g. Open V15 on HDC display (Figure 18, Item 2) by selecting CHANGE POSITION button (Figure 18, Item 4) on HDC control box.
- h. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 18, Item 5) on HDC control box.
- i. For 3L; using LINE UP or LINE DOWN button (Figure 18, Item 3) select V16 on HDC display (Figure 18, Item 2).
- j. Close V16 on HDC display (Figure 18, Item 2) by selecting CHANGE POSITION button (Figure 18, Item 4) on HDC control box.
- k. Have assistant start engine (if not already running).
- l. Move left-hand SUSPENSION CONTROL lever to RAISE.
- m. Read transducer T-1 hydraulic pressure on HDC display (Figure 18, Item 1).
- n. Using LINE UP or LINE DOWN button (Figure 18, Item 3) select V16 on HDC display (Figure 18, Item 2).
- o. Open V16 on HDC display (Figure 18, Item 2) by selecting CHANGE POSITION button (Figure 18, Item 4) on HDC control box.

HYDRAULIC OIL OVERHEATS - Continued




Figure 18. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure 3,450-3,550 psi (23,788-24,477 kPa)?

**DECISION**

YES - Stop engine; relieve hydraulic pressure. Go to Step (18).  
 NO - Go to Step (17).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

17. Perform suspension raise/lower relief valve adjustment using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 19, Item 5) on HDC control box.




Figure 19. Hydraulic Diagnostic Center (HDC) Control Box.

- b. For port 3R relief valve (Figure 20, Item 2); loosen jam nut (Figure 20, Item 3) on port 3R suspension raise/lower relief valve (Figure 20, Item 2).




Figure 20. Suspension Relief Valve Port 3L and Port 3R.

- c. Using LINE UP or LINE DOWN button (Figure 19, Item 3) select V15 on HDC display (Figure 19, Item 2).

**HYDRAULIC OIL OVERHEATS - Continued**

- d. Close V15 on HDC display (Figure 19, Item 2) by selecting CHANGE POSITION button (Figure 19, Item 4) on HDC control box.
- e. With right-hand SUSPENSION CONTROL lever still in RAISE position, and observing transducer T-1 hydraulic pressure on HDC display (Figure 19, Item 1), turn adjusting screw (Figure 20, Item 4) clockwise to increase pressure or counterclockwise to decrease pressure, until desired pressure is indicated.
- f. Tighten jam nut (Figure 20, Item 3).
- g. Using LINE UP or LINE DOWN button (Figure 19, Item 3) select V15 on HDC display (Figure 19, Item 2).
- h. Open V15 on HDC display (Figure 19, Item 2) by selecting CHANGE POSITION button (Figure 19, Item 4) on HDC control box.
- i. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 19, Item 5) on HDC control box.
- j. For port 3L relief valve (Figure 20, Item 1); loosen jam nut (Figure 20, Item 3) on port 3L suspension raise/lower relief valve (Figure 20, Item 1).
- k. Using LINE UP or LINE DOWN button (Figure 19, Item 3) select V16 on HDC display (Figure 19, Item 2).
- l. Close V16 on HDC display (Figure 19, Item 2) by selecting CHANGE POSITION button (Figure 19, Item 4) on HDC control box.
- m. With left-hand SUSPENSION CONTROL lever still in RAISE position, and observing transducer T-1 hydraulic pressure on HDC display (Figure 19, Item 1), turn adjusting screw (Figure 20, Item 4) clockwise to increase pressure or counterclockwise to decrease pressure until desired pressure is indicated.
- n. Tighten jam nut (Figure 20, Item 3).
- o. Using LINE UP or LINE DOWN button (Figure 19, Item 3) select V16 on HDC display (Figure 19, Item 2).
- p. Open V16 on HDC display (Figure 19, Item 2) by selecting CHANGE POSITION button (Figure 19, Item 4) on HDC control box.
- q. Stop engine; relieve hydraulic pressure.
- r. Observe transducer T-1 hydraulic pressure.

**CONDITION/INDICATION**

Can pressure at suspension raise/lower relief valve be adjusted to 3,450-3,550 psi (23,788-24,477 kPa)?

**DECISION**

YES - Verify problem is solved.

NO - Replace DCV bank (TM 5-2350-262-20).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

18. Perform ejector relief valve test using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 21, Item 5) on HDC control box.





Figure 21. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Move ejector halfway forward.
  - c. Stop engine and relieve hydraulic pressure.
  - d. Disable ejector; manually close V23 (Figure 22, Item 1) on DCV bank.



**HYDRAULIC OIL OVERHEATS - Continued**

*Figure 22. Directional Control Valve (DCV) Bank.*

- e. Using LINE UP or LINE DOWN button (Figure 21, Item 3) select V1 on HDC display (Figure 21, Item 2).
- f. Close V1 on HDC display (Figure 21, Item 2) by selecting CHANGE POSITION button (Figure 21, Item 4) on HDC control box.
- g. Have assistant start engine and hold EJECTOR CONTROL lever in FORWARD position.
- h. Read transducer T-2 hydraulic pressure on HDC display (Figure 21, Item 1).

**CONDITION/INDICATION**

Is transducer T-2 hydraulic pressure 2,950-3,050 psi (20,340-21,030 kPa)?

**DECISION**

YES - Stop engine; relieve hydraulic pressure. Go to Step (20).  
NO - Go to Step (19).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

19. Perform ejector relief valve adjustment using HDC.

- a. Stop engine and relieve hydraulic pressure.
- b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 23, Item 5) on HDC control box.




Figure 23. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

c. Disable ejector; manually close V23 (Figure 24, Item 1) on DCV bank.

HYDRAULIC OIL OVERHEATS - Continued




Figure 24. Directional Control Valve (DCV) Bank.

- d. Using LINE UP or LINE DOWN button (Figure 23, Item 3) select V1 on HDC display (Figure 23, Item 2).
- e. Close V1 on HDC display (Figure 23, Item 2) by selecting CHANGE POSITION button (Figure 23, Item 4) on HDC control box.
- f. Start engine.
- g. Loosen jam nut (Figure 25, Item 1) on ejector relief valve.




Figure 25. Ejector Relief Valve.

- h. While observing transducer T-2 hydraulic pressure on HDC display (Figure 23, Item 1); turn relief valve adjustment (Figure 25, Item 2) clockwise (to increase pressure) or counterclockwise (to decrease pressure) until hydraulic pressure is within limits.
- i. Tighten jam nut (Figure 25, Item 1) on ejector relief valve.
- j. Stop engine; relieve hydraulic pressure.
- k. Enable ejector; manually open V23 (Figure 24, Item 1) on DCV bank.
- l. Using LINE UP or LINE DOWN button (Figure 23, Item 3) select V1 on HDC display (Figure 23, Item 2). Close V1 on HDC display (Figure 23, Item 2).
- m. Open V1 on HDC display (Figure 23, Item 2) by selecting CHANGE POSITION button (Figure 23, Item 4) on HDC control box.
- n. Stop engine; relieve hydraulic pressure.

**HYDRAULIC OIL OVERHEATS - Continued**

**CONDITION/INDICATION**

Can ejector relief valve observed transducer T-2 hydraulic pressure be adjusted to 2,950-3,050 psi (20,340-21,030 kPa)?

**DECISION**

- YES - Verify problem is solved.
- NO - Replace DCV bank (TM 5-2350-262-20).

**STEP**

20. Perform ejector cylinder internal leakage test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 26, Item 5) on HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 26, Item 3), select V1 on HDC display (Figure 26, Item 2).
  - c. Close V1 on HDC display (Figure 26, Item 2) by selecting CHANGE POSITION button (Figure 26, Item 4) on HDC control box.
  - d. Start engine and have assistant hold EJECTOR CONTROL lever in BACK position for one minute.
  - e. Mark position of ejector at side of hull and continue to hold valve lever in BACK position for one more minute.
  - f. Check position of ejector while still holding valve lever in BACK position.
  - g. If ejector has moved forward more than 1/2 in. (12 mm), the ejector cylinder is leaking excessively.
  - h. If ejector has moved aft more than 1/2 in. (12 mm), solenoid valve V1 on HDC primary manifold is leaking.
  - i. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 26, Item 5) on HDC control box.




Figure 26. Hydraulic Diagnostic Center (HDC) Control Box.

**HYDRAULIC OIL OVERHEATS - Continued****CONDITION/INDICATION**

Is solenoid valve V1 on HDC system primary manifold or ejector leaking excessively?

**DECISION**

YES - Replace or repair leaking components, as applicable; solenoid valve V1 on HDC primary manifold (WP 0035) or ejector cylinder (TM 5-2350-262-20).

NO - Go to Step (21).

**STEP**

21. Perform apron relief valve pressure test (port 19) using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 26, Item 1) on HDC control box.
  - b. Move ejector forward, engage ejector lock.
  - c. Using LINE UP or LINE DOWN button (Figure 26, Item 3), select V17 on HDC display (Figure 26, Item 2).
  - d. Close V17 on HDC display (Figure 26, Item 2) by selecting CHANGE POSITION button (Figure 26, Item 4) on HDC control box.
  - e. Have assistant start engine and hold APRON CONTROL lever in UP position.
  - f. Read transducer T-1 hydraulic pressure on HDC display (Figure 26, Item 1).
  - g. If pressure is low, adjust apron RAISE relief valve.

**CONDITION/INDICATION**

Is observed transducer T-1 hydraulic pressure 3,450-3,550 psi (23,780-24,475 kPa)?

**DECISION**

YES - Stop engine; relieve hydraulic pressure. Go to Step (23).

NO - Go to Step (22).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

22. Perform apron relief valve adjustment using HDC.

- a. Stop engine; relieve hydraulic pressure.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

- b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 27, Item 5) on HDC control box.





Figure 27. Hydraulic Diagnostic Center (HDC) Control Box.


**HYDRAULIC OIL OVERHEATS - Continued**

- c. Disable ejector; manually close V23 (Figure 28, Item 1) on DCV bank.



*Figure 28. Directional Control Valve (DCV) Bank.*

- d. Using LINE UP or LINE DOWN button (Figure 27, Item 3), select V1 on HDC display (Figure 27, Item 2).
- e. Close V17 on HDC display (Figure 27, Item 2) by selecting CHANGE POSITION button (Figure 27, Item 4) on HDC control box.
- f. Using LINE UP or LINE DOWN button (Figure 27, Item 3), select V17 on HDC display (Figure 27, Item 2).
- g. Close V17 on HDC display (Figure 27, Item 2) by selecting CHANGE POSITION button (Figure 27, Item 4) on HDC control box.
- h. Start engine.
- i. As assistant holds APRON CONTROL lever in UP position, loosen jam nut (Figure 29, Item 1) while observing transducer T-1 hydraulic pressure on HDC display (Figure 27, Item 1).
- j. Rotate adjusting screw (Figure 29, Item 2) clockwise to increase pressure; counterclockwise to decrease pressure, as necessary to obtain desired pressure. Tighten jam nut (Figure 29, Item 1).




*Figure 29. Apron Relief Valve.*

- k. Stop engine; relieve hydraulic pressure.

**HYDRAULIC OIL OVERHEATS - Continued**

- I. Manually open V23 (Figure 30, Item 1) on DCV bank.



*Figure 30. Apron Relief Valve.*

- (1) Using LINE UP or LINE DOWN button (Figure 31, Item 2), select V1 on HDC display (Figure 31, Item 1).
- (2) Open V1 on HDC display (Figure 31, Item 1) by selecting CHANGE POSITION button (Figure 31, Item 3) on HDC control box.
- (3) Using LINE UP or LINE DOWN button (Figure 31, Item 2), select V17 on HDC display (Figure 31, Item 1).
- (4) Open V17 on HDC display (Figure 31, Item 1) by selecting CHANGE POSITION button (Figure 31, Item 3) on HDC control box.



**HYDRAULIC OIL OVERHEATS - Continued**




Figure 31. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Can transducer T-1 hydraulic pressure be adjusted to 3,450-3,550 psi (23,780-24,475 kPa)?

**DECISION**


- YES - Verify problem is solved.
- NO - Replace DCV bank (TM 5-2350-262-20).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

23. Perform apron relief valve (port 20) pressure test.

**WARNING**



Before performing any hydraulic troubleshooting in the bowl, move ejector forward and engage the ejector lock. Failure to comply may result in severe injury to personnel.

**NOTE**

Have suitable container ready to catch oil.

- a. Start engine, move ejector forward, engage ejector lock.
- b. Stop engine; relieve hydraulic pressure.
- c. Disconnect CONT VLV-20 hose (Figure 32, Item 5) from elbow (Figure 32, Item 1) at port 20 (Figure 32, Item 4) of apron control valve (Figure 32, Item 3).
- d. Connect pressure measuring device (Figure 32, Item 2) to elbow (Figure 32, Item 1).
- e. Plug hose (Figure 32, Item 5).
- f. Have assistant start engine and hold APRON CONTROL lever in DOWN position. Read pressure measuring device (Figure 32, Item 2).




Figure 32. Apron Control Valve.

**HYDRAULIC OIL OVERHEATS - Continued****CONDITION/INDICATION**

Is pressure 3,450-3,550 psi (23,780-24,475 kPa)?

**DECISION**

YES - Stop engine; relieve hydraulic pressure. Go to Step (25).

NO - Go to Step (24).

**STEP**

24. Perform apron relief valve adjustment.

- a. As assistant holds APRON CONTROL lever DOWN, loosen jam nut (Figure 32, Item 6) and rotate adjusting screw (Figure 32, Item 7) clockwise to increase pressure; counterclockwise to decrease pressure.
- b. When adjustment is completed, tighten jam nut (Figure 32, Item 6).
- c. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Can pressure be adjusted to 3,450-3,550 psi (23,780-24,475 kPa)?

**DECISION**

YES - Remove all test equipment and connect lines. Verify problem is solved.

NO - Replace DCV (TM 5-2350-262-20).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

25. Perform apron cylinder leakage test.


**CAUTION**

Ensure apron cylinders are blocked (Figure 33, Item 4) prior to retracting disconnected cylinder rod ends. Cylinders will drop and damage hoses.

**NOTE**

- Armor plates 1L and 1R must be removed to expose apron cylinder.
  - Have suitable container ready to catch oil.
- a. Start engine, lower apron completely, and disconnect right-hand and left-hand end of cylinder rods (Figure 33, Item 5) from apron (Figure 33, Item 6).
  - b. Retract cylinder rods (Figure 33, Item 5) approximately halfway.
  - c. Stop engine; relieve hydraulic pressure.
  - d. Disconnect CKT-20 (REAR) TEE hose (Figure 33, Item 2) and CKT-20 (REAR) TEE tube (Figure 33, Item 1) from tee (Figure 33, Item 3) on hull floor.
  - e. Cap and plug hose, tube, and fittings.
  - f. Start engine, have assistant hold APRON CONTROL lever in UP position.
  - g. Measure extension of both cylinder rods (Figure 33, Item 5).
  - h. Continue to hold APRON CONTROL lever in UP position for one minute.
  - i. Measure extension of both cylinder rods (Figure 33, Item 5) again.

## HYDRAULIC OIL OVERHEATS - Continued



T01348HDC

Figure 33. Apron Cylinder Leakage Test.

- j. Have assistant return APRON CONTROL lever to NEUTRAL position.
- k. If extension rate is greater than 1/2 in. (13 mm) per minute, the cylinder is leaking excessively.
- l. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is extension rate greater than 1/2 IN. (13 MM) per minute?

**DECISION**

YES - Remove all test equipment and connect lines. Replace or repair apron cylinder (TM 5-2350-262-20).  
 NO - Go to Step (26).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

26. Perform main accumulator pressure test.

**WARNING**

- High-pressure nitrogen gas is used in this equipment. Keep hands and face away from valves and hose ends. Failure to comply may result in severe injury or death to personnel.
  - Do not breathe nitrogen gas. Failure to comply may result in severe injury or death to personnel.
- a. Connect pressure measuring device (Figure 34, Item 4) to bleed valve (Figure 34, Item 10) on charging harness (Figure 34, Item 12). Close shutoff valve (Figure 34, Item 3).
  - b. Open nitrogen tank valve (Figure 34, Item 1) and adjust regulator valve (Figure 34, Item 2) to 50 psi (353 kPa).
  - c. Open shutoff valve (Figure 34, Item 3) for about 10 seconds to clear charging hoses. Close valve (Figure 34, Item 3).
  - d. Remove valve guard (Figure 34, Item 11).
  - e. Remove charge valve cap (Figure 34, Item 8) from charge valve assembly (Figure 34, Item 6) on accumulator (Figure 34, Item 9).
  - f. Loosely connect adapter valve (Figure 34, Item 5) to charge valve (Figure 34, Item 6) and again open shutoff valve (Figure 34, Item 3) for about 10 seconds.
  - g. Close shutoff valve (Figure 34, Item 3).
  - h. Fully tighten adapter valve (Figure 34, Item 5).

**NOTE**

Accumulator gas valve is fully open after about 2-1/2 turns.

- i. Open charge valve (Figure 34, Item 6) by loosening nut (Figure 34, Item 7).
- j. Read pressure measuring device (Figure 34, Item 4).

## HYDRAULIC OIL OVERHEATS - Continued




Figure 34. Main Hydraulic Accumulator.

**CONDITION/INDICATION**

Is gas valve pressure 1,750-1,850 psi (12,066-12,756 kPa)?

**DECISION**

YES - Go to Step (27).

NO - Go to Step (28).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

27. Remove all test equipment.
  - a. Tighten nut (Figure 35, Item 6) on charge valve (Figure 35, Item 5).
  - b. Close nitrogen tank valve (Figure 35, Item 1).
  - c. Back off regulator valve (Figure 35, Item 2), open bleed valve (Figure 35, Item 8), and bleed hose pressure to 0 psi.
  - d. Remove adapter valve (Figure 35, Item 4) from charge valve (Figure 35, Item 5).
  - e. Remove pressure measuring device (Figure 35, Item 3) from bleed valve (Figure 35, Item 8) on charging harness (Figure 35, Item 10).
  - f. Install charge valve cap (Figure 35, Item 7) on charge valve (Figure 35, Item 5).
  - g. Install valve guard (Figure 35, Item 9).




Figure 35. Main Hydraulic Accumulator.

**CONDITION/INDICATION**

Is all test equipment removed?

**DECISION**

YES - Go to Step (29).  
 NO - Repeat Step (27).



**HYDRAULIC OIL OVERHEATS - Continued****STEP**

28. Charge main accumulator.

**CAUTION**

Ensure regulator valve is fully backed off to relieve tension on diaphragm. Failure to comply may result in damage to equipment.

**NOTE**

Rapid pressurization will cause an inaccurate pressure reading due to heating of nitrogen gas. Always pressurize slowly.

- a. Adjust regulator valve (Figure 36, Item 3) on nitrogen tank (Figure 36, Item 1) to 1,750-1,850 psi (12,066-12,756 kPa).
- b. Open shutoff valve (Figure 36, Item 4).
- c. Read pressure measuring device (Figure 36, Item 5).
- d. When pressure reaches 1,750-1,850 psi (12,066-12,756 kPa), close shutoff valve (Figure 36, Item 4), nitrogen tank valve (Figure 36, Item 2), and accumulator charge valve (Figure 36, Item 6).
- e. Wait 15 minutes and open charge valve (Figure 36, Item 6).
- f. Read pressure measuring device (Figure 36, Item 5) to determine if accumulator can retain charge.




Figure 36. Main Accumulator Charging.

**HYDRAULIC OIL OVERHEATS - Continued****CONDITION/INDICATION**

Can main accumulator be charged to 1,750-1,850 psi (12,066-12,756 kPa)?


**DECISION**

YES - Remove all test equipment and connect hoses. Verify problem is solved.

NO - Remove all test equipment and connect hoses. Replace main accumulator (TM 5-2350-262-20).

**STEP**


29. Perform case drain leakage test.

**WARNING**

Before performing any hydraulic troubleshooting in the bowl, move ejector forward and engage the ejector lock. Failure to comply may result in severe injury to personnel.

**NOTE**

- Have a graduated container of at least 2 qts (1.9 L) capacity available to catch hydraulic oil while test is being performed.
  - Have suitable container ready to catch oil.
- a. Start engine, move ejector forward.
  - b. Stop engine, engage ejector lock, and relieve hydraulic pressure.
  - c. Disconnect SPNSN PUMP DRAIN-9 hose (Figure 37, Item 3) from elbow (Figure 37, Item 4) on compensating pump (Figure 37, Item 2). Cap elbow (Figure 37, Item 4) and plug hose (Figure 37, Item 1).
  - d. Disconnect SPNSN PUMP DRAIN-7V hose (Figure 37, Item 5) from elbow (Figure 37, Item 1). Plug hose (Figure 37, Item 5).
  - e. Connect drain hose (Figure 37, Item 6) to elbow (Figure 37, Item 1).
  - f. Hold end of drain hose (Figure 37, Item 6) in graduated container.

**HYDRAULIC OIL OVERHEATS - Continued**

*Figure 37. Compensating Pump.*

- g. Have assistant start engine and run at 1,800 rpm for 15 seconds.
- h. Observe quantity of hydraulic oil in container.
- i. Stop engine; relieve hydraulic pressure and connect hoses.

**CONDITION/INDICATION**

Is internal leakage more than 1.25 qts (1.2 L) for 15 seconds?

**DECISION**

YES - Replace compensating pump (TM 5-2350-262-20).  
NO - Go to Step (30).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

30. Perform suspension relief valve pressure test using HDC.

**WARNING**

Before performing any hydraulic troubleshooting in the bowl, move ejector forward and engage the ejector lock. Failure to comply may result in severe injury to personnel.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 38, Item 5) on HDC control box.
- b. Start engine; move ejector forward, engage ejector lock.
- c. Stop engine and relieve hydraulic pressure.
- d. Using LINE UP or LINE DOWN button (Figure 38, Item 3) on HDC control box, select V5 on HDC display (Figure 38, Item 2).
- e. Using CHANGE POSITION button (Figure 38, Item 4), close V5 on HDC display (Figure 38, Item 2).
- f. Repeat steps and close V12 and V13, and open V19.
- g. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG and right-hand SUSPENSION CONTROL lever to LOWER.
- h. Read transducer T-13 hydraulic pressure on HDC display (Figure 38, Item 1).
- i. Using LINE UP or LINE DOWN button (Figure 38, Item 3) on HDC control box, select V5 on HDC display (Figure 38, Item 2).
- j. Using CHANGE POSITION button (Figure 38, Item 4), close V5 on HDC display (Figure 38, Item 2).

**HYDRAULIC OIL OVERHEATS - Continued**




Figure 38. Hydraulic Diagnostic Center (HDC) Control Box.

- k. Repeat steps and open V12 and V13, and close V19.
- l. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-13 hydraulic pressure 3,700-3,800 psi (25,512-26,201 kPa)?

**DECISION**

- YES - Go to Step (32).
- NO - Go to Step (31).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

31. Perform suspension relief valve adjustment using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 39, Item 5) on HDC control box.




Figure 39. Hydraulic Diagnostic Center (HDC) Control Box.

**WARNING**



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

- b. Stop engine and relieve hydraulic pressure.
- c. Manually close ejector inhibit ball valve V23 (Figure 40, Item 1) on DCV bank.

## HYDRAULIC OIL OVERHEATS - Continued




Figure 40. Directional Control Valve (DCV) Bank.

- d. Using LINE UP or LINE DOWN button (Figure 39, Item 3) on HDC control box, select V5 on HDC display (Figure 39, Item 2).
- e. Using CHANGE POSITION button (Figure 39, Item 4), close V5 on HDC display (Figure 39, Item 2).
- f. Repeat last two steps for V12, V13, and V19; closing V12 and V13, and opening V19.
- g. Start engine.
- h. Remove cap (Figure 41, Item 3) from suspension relief valve adjusting shaft (Figure 41, Item 2) and loosen jam nut (Figure 41, Item 1).




Figure 41. Suspension Relief Valve.

- (1) Observe transducer T-13 hydraulic pressure on HDC display (Figure 39, Item 1).
  - (2) Turn adjusting shaft (Figure 41, Item 2) clockwise to increase pressure or counterclockwise to decrease pressure, as necessary, to obtain desired pressure.
  - (3) Tighten jam nut (Figure 41, Item 1) and replace cap (Figure 41, Item 3).
- i. Stop engine and relieve hydraulic pressure
  - j. Manually open ejector ball valve V23 (Figure 40, Item 1) on DCV bank.

**HYDRAULIC OIL OVERHEATS - Continued**

- k. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 42, Item 5) on HDC control box.

**CONDITION/INDICATION**

Is transducer T-13 hydraulic pressure 3,700-3,800 psi (25,512-26,201 kPa)?

**DECISION**

YES - Verify problem is solved.

NO - Replace suspension relief valve (TM 5-2350-262-20).

**STEP**

32. Perform suspension raise/lower relief valve test at port 3R or 3L using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 42, Item 5) on HDC control box.

**NOTE**

This test is done at both the right-hand and left-hand suspension raise/lower relief valves. For right-hand valve (port 3R), actuate right-hand SUSPENSION CONTROL lever. For left-hand valve (port 3L), actuate left-hand SUSPENSION CONTROL lever.

- b. For 3R; using LINE UP or LINE DOWN button (Figure 42, Item 3), select V15 on HDC display (Figure 42, Item 2).
- c. Close V15 on HDC display (Figure 42, Item 2) by selecting CHANGE POSITION button (Figure 42, Item 4) on HDC control box.
- d. Have assistant start engine and move right-hand SUSPENSION CONTROL lever to RAISE.
- e. Read transducer T-1 hydraulic pressure on HDC display (Figure 42, Item 1).
- f. Using LINE UP or LINE DOWN button (Figure 42, Item 3), select V15 on HDC display (Figure 42, Item 2).
- g. Open V15 on HDC display (Figure 42, Item 2) by selecting CHANGE POSITION button (Figure 42, Item 4) on HDC control box.



**HYDRAULIC OIL OVERHEATS - Continued**




Figure 42. Hydraulic Diagnostic Center (HDC) Control Box.

- h. For 3L; repeat above steps, closing and opening solenoid valve V16 as instructed, using left-hand SUSPENSION CONTROL lever, and monitoring hydraulic pressure at transducer T-1.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure 3,450-3,550 psi (23,788-24,477 kPa)?

**DECISION**

- YES - Go to Step (35).
- NO - Go to Step (33).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

33. Perform suspension raise/lower relief valve adjustment at 3R or 3L using HDC.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 43, Item 5) on HDC control box.




Figure 43. Hydraulic Diagnostic Center (HDC) Control Box.

- b. For 3R (Figure 44, Item 2); Using LINE UP or LINE DOWN button (Figure 43, Item 3), select V15 on HDC display (Figure 43, Item 2).
- c. Close V15 on HDC display (Figure 43, Item 2) by selecting CHANGE POSITION button (Figure 43, Item 4) on HDC control box.
- d. Loosen jam nut (Figure 44, Item 3) on port 3R (Figure 44, Item 2) of suspension raise/lower relief valve.
- e. With right-hand SUSPENSION CONTROL lever in RAISE position, while observing transducer T-1 hydraulic pressure on HDC display (Figure 43, Item 1), turn suspension raise/lower relief valve 3R adjusting screw (Figure 44, Item 4), clockwise to increase pressure or counterclockwise to decrease pressure, until desired pressure is indicated.

## HYDRAULIC OIL OVERHEATS - Continued




Figure 44. Suspension Raise/Lower Relief Valve 3L and Relief Valve 3R.

- f. Tighten jam nut (Figure 44, Item 3).
- g. Using LINE UP or LINE DOWN button (Figure 43, Item 3), select V15 on HDC display (Figure 43, Item 2). Open V15 on HDC display (Figure 43, Item 2) by selecting CHANGE POSITION button (Figure 43, Item 4) on HDC control box.
- h. For 3L (Figure 44, Item 1); repeat above steps, closing and opening solenoid valve V16 as instructed, using left-hand SUSPENSION CONTROL lever, adjusting suspension raise/lower relief valve 3L adjusting screw (Figure 44, Item 4) for port 3L and monitoring hydraulic pressure at transducer T-1.
- i. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Can pressure at suspension relief valves be adjusted to 3,450-3,550 psi (23,788-24,477 kPa)?

**DECISION**

YES - Verify problem is solved.  
 NO - Replace DCV bank (TM 5-2350-262-20).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

34. Perform actuator internal leakage test on No. 1 or No. 4 actuators where excessive heat in circuit 9 or 2 hoses was detected using HDC.

**WARNING**

Do not work under vehicle unless hull is properly blocked or allowed to settle on bump stops. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- First procedure below, using HDC system, is for No. 4 left actuator internal leakage test. Manual procedures for No. 4 right, No. 1 left, and No. 1 right actuators are same, but HDC system is not used during test. Ports are in same location on opposite face. Circuits 2 and 9 are same.
  - Have suitable container ready to catch oil.
- a. Stop engine; relieve hydraulic pressure.
- b. No. 4 Left Actuator (using HDC system).
- (1) Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 45, Item 4) on HDC control box.
  - (2) Using LINE UP or LINE DOWN button (Figure 45, Item 2) on HDC control box, select V4 on HDC display (Figure 45, Item 1).
  - (3) Using CHANGE POSITION button (Figure 45, Item 3), close V4 on HDC display (Figure 45, Item 1). Repeat steps for V7 and V8; closing V7 and opening V18.
  - (4) Catch oil in a 2 gal. (7.6 L) container.
  - (5) With suspension in SPRUNG mode start engine and check leakage from ports 7 (Figure 46, Item 10), 7B (Figure 46, Item 9), and 17 (Figure 46, Item 2).
  - (6) Stop engine; relieve hydraulic pressure.
  - (7) Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 45, Item 4) on HDC control box.

HYDRAULIC OIL OVERHEATS - Continued




Figure 45. Hydraulic Diagnostic Center (HDC) Control Box.

- c. No. 4 Left Actuator, No. 1 Left Actuator, and No. 1 Right Actuator manual procedure.
  - (1) Stop engine; relieve hydraulic pressure.
  - (2) Disconnect SPNSN UNIT-9 hose (Figure 46, Item 4) from elbow (Figure 46, Item 3) on port 9 (Figure 46, Item 1) of No. 1 right actuator (Figure 46, Item 7).
  - (3) Cap elbow (Figure 46, Item 3).
  - (4) Disconnect CORNER SPNSN UNIT-2 hose (Figure 46, Item 5) from elbow (Figure 46, Item 6) on port 2 (Figure 46, Item 8) of No. 1 right actuator (Figure 46, Item 7).
  - (5) Plug hose (Figure 46, Item 5).
  - (6) Connect hose (Figure 46, Item 4) to elbow (Figure 46, Item 6) on port 2 (Figure 46, Item 8).
  - (7) Catch oil in a graduated 2 gal. (7.6 L) container.
  - (8) With suspension in SPRUNG mode, start engine and check for leakage from ports 7 (Figure 46, Item 10), 7B (Figure 46, Item 9) and 17 (Figure 46, Item 2).




Figure 46. Right-Hand Corner Actuators.

**HYDRAULIC OIL OVERHEATS - Continued**

- (9) Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is leakage greater than 1/2 GPM (1.89 LPM)?

**DECISION**

YES - Reconnect hoses and Replace leaking actuator (TM 5-2320-262-20).  
NO - Go to Step (35).


**STEP**

35. Perform a pressure test on all No. 1 or No. 4 actuator accumulators.

**WARNING**

- High-pressure nitrogen gas is used in this equipment. Keep hands and face away from valves and hose ends. Failure to comply may result in severe injury or death to personnel.
  - Do not breathe nitrogen gas. Failure to comply may result in severe injury or death to personnel.
- a. Connect pressure measuring device (Figure 47, Item 5) to bleed valve (Figure 47, Item 11) on charging harness (Figure 47, Item 4). Close shutoff valve (Figure 47, Item 3).
  - b. Open nitrogen tank valve (Figure 47, Item 1) and adjust regulator valve (Figure 47, Item 2) to 50 psi (353 kPa).
  - c. Open shutoff valve (Figure 47, Item 3) for about 10 seconds to clear charging hoses. Close shutoff valve (Figure 47, Item 3).
  - d. Remove charge valve cap (Figure 47, Item 8).
  - e. Loosely connect adapter valve (Figure 47, Item 9) to charge valve (Figure 47, Item 7) on actuator accumulator (Figure 47, Item 10).
  - f. Open shutoff valve (Figure 47, Item 3) for about 10 seconds.
  - g. Close shutoff valve (Figure 47, Item 3). Tighten adapter valve (Figure 47, Item 9).
  - h. Open charge valve (Figure 47, Item 7) by loosening nut (Figure 47, Item 6).
  - i. Read pressure measuring device (Figure 47, Item 5).

HYDRAULIC OIL OVERHEATS - Continued



T01366HDC

Figure 47. Actuator Accumulator Pressure Test.

**CONDITION/INDICATION**


Is pressure 800-900 psi (5,516-6,206 kPa)?

**DECISION**

- YES - Go to Step (36).
- NO - Go to Step (37).

**HYDRAULIC OIL OVERHEATS - Continued****STEP**

36. Remove all test equipment and connect hoses.
- Tighten nut (Figure 48, Item 4) on actuator accumulator (Figure 48, Item 7).
  - Close nitrogen tank valve (Figure 48, Item 1) to ease pressure.
  - Open bleed valve (Figure 48, Item 8), bleed line pressure to 0 psi.
  - Remove adapter valve (Figure 48, Item 6) from actuator accumulator (Figure 48, Item 7).
  - Remove pressure measuring device (Figure 48, Item 3) from bleed valve (Figure 48, Item 8) on charging harness (Figure 48, Item 2).
  - Install valve cap (Figure 48, Item 5) on actuator accumulator (Figure 48, Item 7).



T01367HDC

Figure 48. Actuator Accumulator Pressure Test.

**CONDITION/INDICATION**

Is all test equipment removed?

**DECISION**

YES - Verify with operator.

NO - Repeat Step (36).



**HYDRAULIC OIL OVERHEATS - Continued****STEP**

37. Charge actuator accumulator.

**CAUTION**

Ensure regulator valve is fully backed off to relieve tension in diaphragm. Failure to comply may result in damage to equipment.

**NOTE**

Have suitable container ready to catch oil.

- a. Adjust regulator valve (Figure 49, Item 2) on nitrogen tank (Figure 49, Item 3) to 800-900 psi (5,516-6,206 kPa).
- b. Open shutoff valve (Figure 49, Item 4). Read pressure measuring device (Figure 49, Item 5).
- c. When pressure reaches 800-900 psi (5,516-6,206 kPa), close shutoff valve (Figure 49, Item 4), nitrogen tank valve (Figure 49, Item 1), and accumulator charge valve (Figure 49, Item 6).
- d. Wait 15 minutes and open accumulator charge valve (Figure 49, Item 6).
- e. Read pressure measuring device (Figure 49, Item 5) to determine if accumulator can retain charge.




Figure 49. Actuator Accumulator Charging.

**CONDITION/INDICATION**

Can accumulator be charged to 800-900 psi (5,516-6,206 kPa)?

**DECISION**

YES - Go to Step (38).

NO - Remove all test equipment. Replace or repair actuator accumulator (TM 5-2320-262-20).

**HYDRAULIC OIL OVERHEATS - Continued**

**STEP**

38. Remove all test equipment.
  - a. Tighten nut (Figure 50, Item 4) on charge valve (Figure 50, Item 5).
  - b. Close nitrogen tank valve (Figure 50, Item 1).
  - c. Back off regulator valve (Figure 50, Item 2), open bleed valve (Figure 50, Item 9), and bleed hose pressure to 0 psi.
  - d. Remove adapter valve (Figure 50, Item 7) from charge valve (Figure 50, Item 5).
  - e. Remove pressure measuring device (Figure 50, Item 3) from bleed valve (Figure 50, Item 9) on charging harness.
  - f. Install charge valve cap (Figure 50, Item 6) on actuator accumulator (Figure 50, Item 8).




Figure 50. Actuator Accumulator Charging.

**CONDITION/INDICATION**

Verify problem is solved.

**DECISION**

- YES - Problem is solved.
- NO - Notify Supervisor.

**END OF WORK PACKAGE**

---

**FIELD MAINTENANCE**  
**TROUBLESHOOTING PROCEDURES - LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG**  
**MODE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

**References**

WP 0038


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

No. 4 left and right actuators provide vehicle suspension in SPRUNG mode and allow vehicle to raise and lower in UNSPRUNG mode. The compensating pump provides fluid through line 9 for SPRUNG mode and line 11 for UNSPRUNG mode.

**LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued****STEP**

1. Perform actuator hose 9 flow test.

**NOTE**

Have suitable container ready to catch oil.

- a. Stop engine; relieve hydraulic pressure. Disconnect REAR SPNSN UNIT-9 hose (Figure 1, Item 2) from port 9 (Figure 1, Item 1) on No. 4 left actuator (Figure 1, Item 3).
- b. Cap port 9 (Figure 1, Item 1).
- c. Connect drain hose to open end of REAR SPNSN UNIT-9 hose (Figure 1, Item 1).
- d. Place end of drain hose in container and have assistant start engine.
- e. Observe a free flow of oil from drain hose.
- f. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is there steady flow of hydraulic oil to actuator?

**DECISION**

- YES - Go to Step (4).  
NO - Go to Step (2).

**STEP**

2. Check for blockage in REAR SPNSN UNIT-9 hose.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

- YES - Clear blockage or replace REAR SPNSN UNIT-9 hose. Reconnect hose to proper port.  
NO - Go to Step (3).

**STEP**

3. Perform left manifold blockage test using Hydraulic Diagnostic Center (HDC).
  - a. Connect REAR SPNSN UNIT-9 hose (Figure 1, Item 2) to port 9 (Figure 1, Item 1) on No. 4 left actuator (Figure 1, Item 2)

**LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued**




Figure 1. No. 4 Left Actuator.

- b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 2, Item 2) on HDC control box.
- c. Start engine; read transducer T-7 hydraulic pressure on HDC display (Figure 2, Item 1).




Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.

- d. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-7 hydraulic pressure at port 9 less than 2,500 PSI (17,238 KPA)?

**LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued**

**DECISION**

- YES - Clear blockage or replace manifold.
- NO - Replace AFT manifold solenoid valve V4 (WP 0038).

**STEP**

4. Perform No. 3 left actuator internal leakage test using HDC (pressure transducer T-7).
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 3, Item 4) on HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 3, Item 2) on HDC control box, select V4 on HDC display (Figure 3, Item 1).
  - c. Using the CHANGE POSITION button (Figure 3, Item 3), close V4 on HDC display (Figure 3, Item 1).
  - d. Repeat steps and close V6 and open V18.
  - e. Start engine and observe that transducer T-7 hydraulic pressure is greater than 2,500 psi (17,238 kPa).
  - f. Less than 2,500 psi (17,238 kPa) indicates leakage from No. 3 left actuator.
  - g. Stop engine; relieve hydraulic pressure.
  - h. Using LINE UP or LINE DOWN button (Figure 3, Item 2) on HDC control box, select V4 on HDC display (Figure 3, Item 1).
  - i. Using the CHANGE POSITION button (Figure 3, Item 3), open V4 on HDC display (Figure 3, Item 1).




Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.

- j. Repeat steps and open V7 and close V18.

**LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued**

**CONDITION/INDICATION**

Is #3 left actuator leaking internally?

**DECISION**

YES - If transducer T-7 pressure is less than 2,500 psi (17,238 kPa), replace No. 3 left actuator (TM 5-2350-262-20).

NO - If transducer T-7 pressure is equal or greater than 2,500 psi (17,238 kPa), then go to Step (5).

**STEP**

5. Check for binding in No. 3 left actuator.

**NOTE**

Have suitable container ready to catch oil.

- a. Disconnect INTMD SPNSN UNIT-2 hose (Figure 4, Item 10) from adapter (Figure 4, Item 9) at port 2 (Figure 4, Item 8), and disconnect LH 3 SPNSN UNIT-7 TEE tube (Figure 4, Item 1) and NO 3 SPNSN UNIT-7 TEE hose (Figure 4, Item 2) from elbow (Figure 4, Item 3) and tee (Figure 4, Item 4) at port 7 (Figure 4, Item 7) on No. 3 left actuator (Figure 4, Item 5).
- b. Plug all lines.
- c. Check for binding in No. 3 left actuator (Figure 4, Item 5) by using a prybar (Figure 4, Item 6) to determine if No. 3 lift road-wheel can be moved up or down.




Figure 4. No. 3 Left Actuator.

- d. Reconnect lines.

---

**LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE - Continued****CONDITION/INDICATION**

Is #3 left actuator binding?

**DECISION**

YES - Replace No. 3 left actuator (TM 5-2350-262-20).

NO - Replace No. 4 left actuator (TM 5-2350-262-20).

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG  
MODE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

**References**

TM 5-2350-262-20  
WP 0038

**Materials/Parts**

Sealing Compound (WP 0053, Table 1, Item 3)  
Pin, Cotter (WP 0055, Table 1, Item 1) Qty: 1


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

The rear of the vehicle is raised by left and right actuators, interconnected by hydraulic circuit 8. The SPRUNG and UNSPRUNG circuits operate left and right rear actuators through valves and mechanical controls. Circuit 9 operates SPRUNG mode; circuit 11 operates UNSPRUNG mode.

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

1. Perform port 8 check valve flow test.

**NOTE**

Have suitable container ready to catch oil.

- a. Stop engine; relieve hydraulic pressure.
- b. Disconnect LH 4 SPNSN UNIT-8 hose (Figure 1, Item 5) from check valve (Figure 1, Item 3) at port 8 (Figure 1, Item 1) on No. 4 left actuator (Figure 1, Item 2).
- c. Plug end of LH 4 SPNSN UNIT-8 hose (Figure 1, Item 5).
- d. Connect drain hose to check valve (Figure 1, Item 3).
- e. While holding end of drain hose in container, have assistant start engine and move SPRUNG/UNSPRUNG lever to SPRUNG mode.
- f. Observe for steady flow of oil from drain hose.
- g. Vehicle should raise.
- h. Stop engine; relieve hydraulic pressure and connect line.

**CONDITION/INDICATION**

Does hydraulic oil flow freely through check valve?

**DECISION**

- YES - Go to Step (6).  
NO - Go to Step (2).

**STEP**

2. Perform check valve inspection.
  - a. Inspect check valve (Figure 1, Item 3).
  - b. Ensure arrow (Figure 1, Item 4) points away from actuator (Figure 1, Item 2).
  - c. Connect LH 4 SPNSN UNIT-8 hose (Figure 1, Item 5) to check valve (Figure 1, Item 3) at port 8 (Figure 1, Item 1).

REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued




Figure 1. No. 4 Left Actuator Port 8 Check Valve.

**CONDITION/INDICATION**

Is valve installed correctly?

**DECISION**

YES - Go to Step (3).

NO - Install valve correctly. Verify problem is solved.

**STEP**

3. Check for blockage in check valve.

**CONDITION/INDICATION**

Is check valve plugged?

**DECISION**

YES - Clear blockage or replace check valve (TM 5-2350-262-20). Verify problem is solved.

NO - Go to Step (4).

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

4. Perform actuator hose 9 flow test.

**NOTE**

Have suitable container ready to catch oil.

- a. Disconnect REAR SPNSN UNIT-#9 hose (Figure 2, Item 2) at port 9 (Figure 2, Item 1) on No. 4 left actuator (Figure 2, Item 3).
- b. Cap port 9.
- c. Connect a drain hose to open end of REAR SPNSN UNIT-#9 hose (Figure 2, Item 2).




Figure 2. No. 4 Left Actuator.

- d. Hold free end of drain hose in clean container.
- e. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG.
- f. Look for a steady flow of oil from drain hose.
- g. Stop engine; relieve hydraulic pressure and connect hose.

**CONDITION/INDICATION**

Is there a steady flow of oil?

**DECISION**

YES - Go to Step (7).  
NO - Go to Step (5).

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

5. Check for blockage in REAR SPNSN UNIT-#9 hose.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

YES - Clear blockage or replace hose (TM 5-2350-262-20).

NO - Go to Step (13).

**STEP**

6. Check for blockage in LH 4 SPNSN UNIT-#8 hose.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

YES - Clear blockage or replace hose (TM 5-2350-262-20).

NO - Go to Step (7).

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**STEP**

7. Perform actuator port 11 pressure test using Hydraulic Diagnostic Center (HDC).
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 3, Item 5) on HDC control box.
  - b. Using LINE UP or LINE DOWN button (Figure 3, Item 3) on HDC control box, select V8 on HDC display (Figure 3, Item 2).
  - c. Using CHANGE POSITION button (Figure 3, Item 4), close V8 on HDC display (Figure 3, Item 2).
  - d. Have assistant start engine and move SPRUNG/UNSPRUNG lever to UNSPRUNG.
  - e. Observe transducer T-12 hydraulic pressure on HDC display (Figure 3, Item 1).
  - f. Using LINE UP or LINE DOWN button (Figure 3, Item 3) on HDC control box, select V8 on HDC display (Figure 3, Item 2).
  - g. Using CHANGE POSITION button (Figure 3, Item 4), open V8 on HDC display (Figure 3, Item 2).




Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.

- h. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-12 hydraulic pressure greater than 2,500 psi (17,238 kPa)?

**DECISION**

- YES - Go to Step (11).
- NO - Go to Step (8).

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****STEP**

8. Check SPRUNG/UNSPRUNG control valve linkage.
  - a. Hold measuring device (Figure 4, Item 1) on face of SPRUNG/UNSPRUNG control valve (Figure 4, Item 3).
  - b. Have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG modes.
  - c. Measure distance that plunger (Figure 4, Item 2) travels as lever is moved.




Figure 4. SPRUNG/UNSPRUNG Control Valve Linkage.

- d. Distance of travel should be  $9/32$  in. (7 mm).

**CONDITION/INDICATION**

Is linkage adjusted correctly?

**DECISION**

YES - Go to Step (9).  
NO - Go to Step (10).

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued**

**STEP**

9. Perform SPRUNG/UNSPRUNG control valve operation test using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 2) on HDC control box.
  - b. Start engine and have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG several times.
  - c. Observe transducer T-12 hydraulic pressure on HDC display (Figure 5, Item 1).




Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

- d. Hydraulic pressure should be less than 145 psi (1,000 kPa) in SPRUNG mode and greater than 2,500 psi (17,238 kPa) in UNSPRUNG mode.
- e. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is valve operating correctly?

**DECISION**

- YES - Verify problem with operator.  
 NO - Replace SPRUNG/UNSPRUNG control valve (TM 5-2350-262-20).

**STEP**

10. Adjust SPRUNG/UNSPRUNG control valve linkage.



## REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued

**WARNING**

Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.

**NOTE**

All control rods are adjusted same way. This procedure covers the SPRUNG/UNSPRUNG control rod.

- a. Note position of control valve plunger (Figure 6, Item 1) when SPRUNG/UNSPRUNG control lever is in neutral (off) position.

**NOTE**

Normal control valve plunger travel is 9/32 in. (7mm).

- b. Remove cotter pin (Figure 6, Item 2), straight pin (Figure 6, Item 6), and clevis (Figure 6, Item 5) from control valve plunger (Figure 6, Item 1).
- c. Discard cotter pin (Figure 6, Item 2).
- d. Loosen jam nut (Figure 6, Item 4), turn clevis (Figure 6, Item 5) clockwise to shorten rod (Figure 6, Item 3) and counterclockwise to lengthen rod (Figure 6, Item 3) as necessary to obtain correct valve plunger (Figure 6, Item 1) travel.
- e. Hold measuring device (Figure 6, Item 7) on face of SPRUNG/UNSPRUNG control valve.
- f. Have assistant move SPRUNG/UNSPRUNG lever between SPRUNG and UNSPRUNG mode.
- g. Measure distance of plunger travel.
- h. When rod (Figure 6, Item 3) is adjusted for desired length of travel, coat thread of rod (Figure 6, Item 3) with sealing compound primer and sealing compound.
- i. Tighten jam nut (Figure 6, Item 4) against clevis (Figure 6, Item 5).
- j. Connect clevis (Figure 6, Item 5) to control valve plunger (Figure 6, Item 1) with straight pin (Figure 6, Item 6) and new cotter pin (Figure 6, Item 2).




Figure 6. SPRUNG/UNSPRUNG Control Valve Control Rod Travel.

**REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued****CONDITION/INDICATION**

Can linkage be adjusted?

**DECISION**

YES - Verify problem is solved.

NO - Repair or replace control valve linkage (TM 5-2350-262-20).

**STEP**

11. Check REAR SPNSN UNIT-#11 hose for blockage.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

YES - Clear blockage or replace hose (TM 5-2350-262-20). Verify problem is solved.

NO - Go to Step (12).

**STEP**

12. Check left main manifold II hose to aft manifold for blockage.

**CONDITION/INDICATION**

Is there blockage?

**DECISION**

YES - Clear blockage or replace hose (TM 5-2350-262-20). Verify problem is solved.

NO - Replace solenoid valve V8 on HDC aft manifold (WP 0038).

**STEP**

13. Perform left manifold blockage test using HDC.

- a. Stop engine; relieve hydraulic pressure.
- b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 2) on HDC control box.
- c. Start engine; read transducer T-7 hydraulic pressure on HDC display (Figure 7, Item 1).

REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE - Continued




Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.

- d. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is port 9 transducer T-7 hydraulic pressure less than 2,500 psi (17, 238 kPa)?

**DECISION**

YES - Clear blockage or replace left manifold (TM 5-2350-262-20). Verify problem is solved.  
 NO - Verify problem with operator.

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS**

**INITIAL SETUP:**

**Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**References**

WP 0006

**Personnel Required**

Construction Equipment Repairer, 91L (Three)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**TROUBLESHOOTING PROCEDURE**

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS**

**WARNING**



- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- Valve bank hydraulic system is supplied by hydraulic ports 13L and 13R. Pressure is controlled by relief valves 13L and 13R.
- Perform this procedure when all operator controls are inoperative. Refer to vehicle hydraulic system schematic diagram (FP-1 through FP-6).

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued****STEP**

1. Check if vehicle can move under its own power.

**CONDITION/INDICATION**

Does vehicle move under its own power?

**DECISION**

YES - Go to Step (2).


NO - Refer to Step (1) of All Hydraulic Functions Inoperative troubleshooting symptom (WP 0006).

**STEP**

2. Perform oil flow test.

**NOTE**

- Three personnel are required to perform this test.
  - Have suitable container ready to catch oil.
- a. Stop engine; relieve hydraulic pressure.
  - b. Disconnect HYDR FLTR-IN-13R hose (Figure 1, Item 2) from high-pressure filter inlet port 13R (Figure 1, Item 1).



T01603HDC

Figure 1. High-Pressure Filter Inlet Port 13R.

- c. While assistant one is holding disconnected end of hose (Figure 1, Item 2) over container, assistant two will hold fuel solenoid shutoff toggle switch (Figure 2, Item 2) on STE/ICE-R interface box (Figure 2, Item 1) in shutoff position.

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued**




Figure 2. STE/ICE-R Interface Box.

- d. Crank engine for approximately 15 seconds.
- e. Hydraulic oil should flow freely.

**CONDITION/INDICATION**

Is there hydraulic oil flow from main hydraulic pump?

**DECISION**

- YES - Go to Step (4).
- NO - Go to Step (3).

**STEP**

- 3. Perform suction hose check.

**NOTE**

Have suitable container ready to catch oil.

- a. Loosen PUMP SUCT TUBE-7 hose (Figure 3, Item 1) approximately three-quarters of the way at main hydraulic pump (Figure 3 Item 2).




Figure 3. Main Hydraulic Pump Suction Hose.

- b. Hydraulic oil should flow freely.

**CONDITION/INDICATION**

Is suction hose blocked?

**DECISION**


- YES - Clear blockage or replace hose (TM 5-2350-262-20).
- NO - Go to Step (4).

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued**


**STEP**

4. Perform main hydraulic pump pressure test using Hydraulic Diagnostic Center (HDC).

**WARNING**



- Before performing any troubleshooting in bowl, move ejector forward and engage ejector lock. Failure to comply may result in severe injury or death to personnel.
  - Ensure right main hydraulic pressure inhibit valve V21 is fully opened prior to starting vehicle. A fully or partially closed valve will cause immediate high pressure. Failure to comply may result in damage to equipment and injury to personnel.
- a. Stop engine; relieve hydraulic pressure (if not previously done).
  - b. Ensure right main hydraulic pressure inhibit valve V21 (Figure 4, Item 1) is fully opened.
  - c. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 5) on HDC control box.
  - d. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 4, Item 2) on DCV bank.



T01607HDC

*Figure 4. No. 4 Left Actuator.*

- e. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on HDC display (Figure 5, Item 2).
- f. Close V1 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.
- g. Have assistant start engine and allow engine to idle (750-800 rpm).
- h. Slowly close right main hydraulic pressure inhibit valve V21 (Figure 4, Item 1) until transducer T-3 on HDC display (Figure 5, Item 1) indicates 3,950-4,050 psi (27,235-27,925 kPa).



**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued**

- i. Fully open right main hydraulic pressure inhibit valve V21 (Figure 4, Item 1).
- j. Stop engine; relieve hydraulic pressure.
- k. Manually open ejector inhibit ball valve V23 (Figure 4, Item 2) on DCV bank.
- l. Ensure both valves are fully open.
- m. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on HDC display (Figure 5, Item 2).
- n. Open V1 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.




Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Does transducer T-3 main hydraulic pump pressure read 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

- YES - Go to Step (5).  
 NO - Replace main hydraulic pump (TM 5-2350-262-20).

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued****STEP**

5. Perform control valve flow test.

**NOTE**

Have suitable container ready to catch oil.

- a. Start engine.
- b. Remove cap (Figure 6, Item 1) from hydraulic system sample valve (Figure 6, Item 2).
- c. Open valve (Figure 6, Item 2) by turning it clockwise.
- d. Hold valve (Figure 6, Item 2) open for several seconds.
- e. Oil should flow freely from sample valve (Figure 6, Item 2).
- f. Close valve (Figure 6, Item 2), and replace cap (Figure 6, Item 1).




Figure 6. Hydraulic System Sample Control Valve.

- g. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is there a flow of oil?

**DECISION**

YES - Go to Step (6).

NO - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued****STEP**

6. Perform main relief valve test using HDC.
  - a. Stop engine; relieve hydraulic pressure (if not already done).
  - b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 1) on HDC control box.





Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued**

- c. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 8, Item 1) on DCV bank.
- d. Using LINE UP or LINE DOWN button (Figure 9, Item 3), select V1 on HDC display (Figure 9, Item 2).
- e. Close V1 on HDC display (Figure 9, Item 2) by selecting CHANGE POSITION button (Figure 9, Item 4) on HDC control box.
- f. Have assistant start engine, move SPRUNG/UNSPRUNG lever to SPRUNG and move EJECTOR CONTROL lever to BACK.
- g. Read transducer T-3 hydraulic pressure on HDC display (Figure 9, Item 1).
- h. While holding EJECTOR CONTROL lever to BACK, have assistant move right-hand SUSPENSION CONTROL lever to RAISE.
- i. Read transducer T-3 hydraulic pressure on HDC display (Figure 8, Item 1).
- j. Stop engine; relieve hydraulic pressure.
- k. Enable ejector by manually opening ejector inhibit ball valve V23 (Figure 8, Item 1) on DCV bank.



T01610HDC

*Figure 8. Directional Control Valve (DCV) Bank.*

- l. Using LINE UP or LINE DOWN button (Figure 9, Item 3), select V1 on HDC display (Figure 9, Item 2).
- m. Open V1 on HDC display (Figure 9, Item 2) by selecting CHANGE POSITION button (Figure 9, Item 4) on HDC control box.

VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued




Figure 9. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Is transducer T-3 pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Verify problem with operator.


NO - Go to Step (7).

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued****STEP**

7. Perform main relief valve adjustment using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 11, Item 4) on HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- b. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 10, Item 1) on DCV bank.



T01612HDC

*Figure 10. Directional Control Valve (DCV) Bank.*

- c. Using LINE UP or LINE DOWN button (Figure 11, Item 2), select V1 on HDC display (Figure 11, Item 1).
- d. Close V1 on HDC display (Figure 11, Item 1) by selecting CHANGE POSITION button (Figure 11, Item 3) on HDC control box.

VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued




Figure 11. Hydraulic Diagnostic Center (HDC) Control Box.

- e. Loosen jam nut (Figure 12, Item 3) on main relief valve 13R (Figure 12, Item 1).
- f. Have assistant start engine and simultaneously hold EJECTOR CONTROL lever in BACK while holding right-hand SUSPENSION CONTROL lever to RAISE.
- g. Rotate adjusting screw (Figure 12, Item 2) clockwise to increase pressure and counterclockwise to decrease pressure as necessary to obtain desired pressure.
- h. Tighten jam nut (Figure 12, Item 3).




Figure 12. Main Relief Valve 13R.

**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued**

- i. Stop engine; relieve hydraulic pressure.
- j. Enable ejector by manually opening ejector inhibit ball valve V23 (Figure 13, Item 1).




Figure 13. Directional Control Valve (DCV) Bank.

- k. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 14, Item 1) on HDC control box.




Figure 14. Hydraulic Diagnostic Center (HDC) Control Box.



**VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS - Continued**

**CONDITION/INDICATION**

Can main relief valve be adjusted to 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**

YES - Verify problem with operator.

NO - Replace DCV bank (TM 5-2350-262-20).

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE**  
**TROUBLESHOOTING PROCEDURES - WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**TROUBLESHOOTING PROCEDURE****WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**NOTE**

- The outboard valve bank hydraulic system 13L circuit is supplied by hydraulic pump port 13L; pressure is controlled by relief valve at inlet port 13L.
- Perform this procedure only when the winch and right-hand suspension controls are inoperative.


**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued****STEP**

1. Perform main relief valve test to verify hydraulic pressure at 13L main relief valve using Hydraulic Diagnostic Center (HDC).

**WARNING**

Before performing any hydraulic troubleshooting in the bowl, move ejector forward and disable it by disconnecting ejector cylinder from hydraulic system. Failure to comply may result in severe injury or death to personnel.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 2, Item 5) on HDC control box.
- b. Move ejector forward, stop engine, and relieve hydraulic pressure.
- c. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 1, Item 1) on DCV bank.



T01703HDC

*Figure 1. Directional Control Valve (DCV) Bank.*

- d. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V1 on HDC display (Figure 2, Item 2).
- e. Close V1 on HDC display (Figure 2, Item 2) by selecting CHANGE POSITION button (Figure 2, Item 4) on HDC control box.
- f. Have assistant start engine, move SPRUNG/UNSPRUNG lever to SPRUNG, and move EJECTOR CONTROL lever to BACK.
- g. Read transducer T-4 hydraulic pressure on HDC display (Figure 2, Item 1).
- h. While simultaneously holding EJECTOR CONTROL lever in BACK, have assistant move left-hand SUSPENSION CONTROL lever to RAISE.
- i. Read transducer T-4 hydraulic pressure on HDC display (Figure 2, Item 1).

**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued**

- j. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V1 on HDC display (Figure 2, Item 2).
- k. Open V1 on HDC display (Figure 2, Item 2) by selecting CHANGE POSITION button (Figure 2, Item 4) on HDC control box.




Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.

- l. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-4 hydraulic pressure between 3,950-4,050 psi (27,235-27,925 kPa)?

**DECISION**


- YES - Verify problem with operator.  
 NO - Go to Step (2).

**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued****STEP**

2. Perform main relief valve adjustment using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 5, Item 5) on HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- b. Disable ejector by manually closing ejector inhibit ball valve V23 (Figure 4, Item 1) on DCV bank.
  - c. Using LINE UP or LINE DOWN button (Figure 5, Item 3), select V1 on HDC display (Figure 5, Item 2).
  - d. Close V1 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.
  - e. Loosen jam nut (Figure 3, Item 2) on main relief valve 13L (Figure 3, Item 3).
  - f. Have assistant start engine and simultaneously hold EJECTOR CONTROL lever in BACK while holding left-hand SUSPENSION CONTROL lever is RAISE.
  - g. While observing transducer T-4 hydraulic pressure on HDC display (Figure 5, Item 1); rotate adjusting screw (Figure 3, Item 1) clockwise to increase hydraulic pressure, counterclockwise to decrease hydraulic pressure until desired pressure is obtained; tighten jam nut.




T01706HDC

*Figure 3. Main Relief Valve 13L.*

- h. Stop engine; relieve hydraulic pressure.

**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued**


- i. Manually open ejector inhibit ball valve V23 (Figure 4, Item 1) on DCV bank. Using LINE UP or LINE DOWN button (Figure 5, Item 3) select V1 on HDC display (Figure 5, Item 2).



T01707HDC

Figure 4. Directional Control Valve (DCV) Bank.

- j. Open V1 on HDC display (Figure 5, Item 2) by selecting CHANGE POSITION button (Figure 5, Item 4) on HDC control box.



T01708HDC

Figure 5. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Can the 13L main relief valve be set to develop hydraulic pressure 3,950-4,050 psi (27,235-28,925 kPa)?


**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued****DECISION**

YES - Verify problem is solved.

NO - Go to Step (3).

**STEP**

3. Perform main hydraulic pump pressure test using HDC.

**WARNING**

- Before performing any troubleshooting in bowl, move ejector forward and engage ejector lock. Failure to comply may result in severe injury or death to personnel.
  - Ensure left main hydraulic pressure inhibit valve V22 is fully opened prior to starting vehicle. A fully or partially closed valve will cause immediate high pressure. Failure to comply may result in damage to equipment and injury to personnel.
- a. Stop engine; relieve hydraulic pressure.
  - b. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 6, Item 5) on HDC control box.
  - c. Disable ejector by manually closing the ejector inhibit ball valve V23 (Figure 7, Item 2) on DCV bank.
  - d. Using LINE UP or LINE DOWN button (Figure 6, Item 3), select V1 on HDC display (Figure 6, Item 2).
  - e. Close V1 on HDC display (Figure 6, Item 2) by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.
  - f. Ensure left main hydraulic pressure inhibit valve V22 (Figure 7, Item 1) is fully opened.
  - g. Have assistant start engine and allow engine to idle (750-800 rpm).
  - h. Slowly close left main hydraulic pressure inhibit valve V22 (Figure 7, Item 1), until transducer T-4 on HDC display (Figure 6, Item 1) reaches 3,950-4,050 psi (27,235-27,925 kPa).
  - i. Open left main hydraulic pressure inhibit valve V22 (Figure 7, Item 1) fully.
  - j. Using LINE UP or LINE DOWN button (Figure 6, Item 3), select V1 on HDC display (Figure 6, Item 2).
  - k. Open V1 (Figure 6, Item 2) on HDC display by selecting CHANGE POSITION button (Figure 6, Item 4) on HDC control box.



**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued**




Figure 6. Hydraulic Diagnostic Center (HDC) Control Box.

- l. Stop engine; relieve hydraulic pressure.
- m. Open ejector inhibit ball valve V23 (Figure 7, Item 2).




Figure 7. Directional Control Valve (DCV) Bank.

**CONDITION/INDICATION**

Does main hydraulic pump develop 3,950-4,050 psi (27,235-27,925 kPa)?

**WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE - Continued****DECISION**

- YES - Replace Directional Control Valve (DCV) bank (TM 5-2350-262-20).
- NO - Replace main hydraulic pump (TM 5-2350-262-20).

**END OF WORK PACKAGE**

**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - WINCH WILL NOT PULL RATED LOAD**

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

**Personnel Required**


Construction Equipment Repairer, 91L (Two)

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**Materials/Parts**

Pin, Cotter (WP 0055, Table 1, Item 10) Qty: 1

**TROUBLESHOOTING PROCEDURE****WINCH WILL NOT PULL RATED LOAD****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**CAUTION**

Do not reuse drained captured hydraulic oil unless it has been filtered and is clean. Failure to comply may result in damage to equipment.

**NOTE**

The winch hydraulic motor receives oil flow from control valve through circuit VA to PAY OUT cable and through circuit VB to PAY IN cable. Hydraulic pressure is controlled by winch relief valve C2. The winch motor case drain line is 7W.

**WINCH WILL NOT PULL RATED LOAD - Continued**

**STEP**

1. Perform winch control valve hydraulic pressure check using Hydraulic Diagnostic Center (HDC).

**WARNING**



Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.

- a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 2, Item 5) on HDC control box.
- b. Start vehicle engine and move ejector forward. Stop engine and relieve hydraulic pressure.
- c. Engage ejector lock (Figure 1, Item 2).
- d. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V14 on HDC display (Figure 2, Item 2).
- e. Close V14 on HDC display (Figure 2, Item 2) by selecting CHANGE POSITION button (Figure 2, Item 4) on HDC control box.
- f. Have assistant start vehicle engine and hold WINCH CONTROL lever (Figure 1, Item 1) in PAY IN position.
- g. Read transducer T-1 hydraulic pressure on HDC display (Figure 2, Item 1).
- h. Return WINCH CONTROL lever (Figure 1, Item 1) to NEUTRAL position.




Figure 1. Winch Control and Ejector Lock.

**WINCH WILL NOT PULL RATED LOAD - Continued**

- i. Using LINE UP or LINE DOWN button (Figure 2, Item 3), select V14 on HDC display (Figure 2, Item 2).
- j. Open V14 on HDC display (Figure 2, Item 2) by selecting CHANGE POSITION button (Figure 2, Item 4) on HDC control box.




Figure 2. Hydraulic Diagnostic Center (HDC) Control Box.

- k. Stop engine; relieve hydraulic pressure.

**CONDITION/INDICATION**

Is transducer T-1 hydraulic pressure at port VB 1,950-2,050 psi (13,445-14,135 kPa)?

**DECISION**


- YES - Go to Step (3).  
 NO - Go to Step (2).

**WINCH WILL NOT PULL RATED LOAD - Continued****STEP**

2. Perform winch relief valve VB adjustment using HDC.
  - a. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 4, Item 4) on HDC control box.

**WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
- b. With engine off, disable ejector; manually close ejector inhibit ball valve V23 (Figure 3, Item 1) on DCV bank.



T01808HDC

Figure 3. Directional Control Valve (DCV) Bank.

**WINCH WILL NOT PULL RATED LOAD - Continued**

- c. Using LINE UP or LINE DOWN button (Figure 4, Item 2), select V1 on HDC display (Figure 4, Item 1).
- d. Close V1 on HDC display (Figure 4, Item 1) by selecting CHANGE POSITION button (Figure 4, Item 3) on HDC control box.
- e. Select V14 on HDC display (Figure 4, Item 1).
- f. Close V14 on HDC display (Figure 4, Item 1) by selecting CHANGE POSITION button (Figure 4, Item 3) on HDC control box.
- g. Have assistant start engine and hold WINCH CONTROL in PAY IN position.





Figure 4. Hydraulic Diagnostic Center (HDC) Control Box.

**WINCH WILL NOT PULL RATED LOAD - Continued**


- h. Read transducer T-1 hydraulic pressure on HDC display (Figure 7, Item 1).
- i. While observing transducer T-1 hydraulic pressure on HDC display (Figure 7, Item 1), loosen jam nut (Figure 5, Item 2) and turn relief valve adjustment screw (Figure 5, Item 1), clockwise to increase pressure; counterclockwise to decrease pressure until desired pressure is obtained.
- j. Tighten jam nut (Figure 5, Item 2).



T01810HDC

Figure 5. Winch Relief Valve.

- k. Stop engine and relieve hydraulic pressure.
- l. Open ejector inhibit ball valve V23 (Figure 6, Item 1) on DCV bank. Using LINE UP or LINE DOWN button (Figure 7, Item 3), select V1 on HDC display (Figure 7, Item 2).



T01808HDC

Figure 6. Directional Control Valve (DCV) Bank.



**WINCH WILL NOT PULL RATED LOAD - Continued**

- m. Open V1 on HDC display (Figure 7, Item 2) by selecting CHANGE POSITION button (Figure 7, Item 4) on HDC control box.
- n. Repeat for V14; Open V14.
- o. Reset all HDC solenoid valves by selecting RESET VALVES button (Figure 7, Item 5) on HDC control box.




Figure 7. Hydraulic Diagnostic Center (HDC) Control Box.

**CONDITION/INDICATION**

Can relief valve be set to develop correct hydraulic pressure: 1,950-2,050 psi (13,445-14,135 kPa)?

**DECISION**

YES - Verify problem is solved.

NO - Replace Directional Control Valve (DCV) bank assembly (TM 5-2350-262-20).

**WINCH WILL NOT PULL RATED LOAD - Continued****STEP**

3. Perform winch motor internal leakage test.

**NOTE**

Have suitable container ready to catch oil.


- a. Disconnect WINCH DRAIN-7W hose (Figure 8, Item 3) from winch motor port 7W and plug hose (Figure 8, Item 3).
- b. Connect drain hose (Figure 8, Item 2) to elbow (Figure 8, Item 4) on port 7W (Figure 8, Item 5) and place end of hose (Figure 8, Item 2) in container.
- c. Disconnect CONT-VLV-VA (FWD) hose (Figure 8, Item 7) from winch.
- d. Plug hose (Figure 8, Item 7) and cap elbow (Figure 8, Item 6).

**NOTE**

Two containers are necessary for a true metered 15-second reading during winch motor internal leakage test.

- e. Have assistant start vehicle engine and hold WINCH CONTROL lever (Figure 8, Item 1) in PAY IN position.
- f. With lever held in PAY IN position and oil flowing, move drain hose 7W (Figure 8, Item 2) to a graduated container for exactly 15 seconds.
- g. Return WINCH CONTROL lever (Figure 8, Item 1) to NEUTRAL position.
- h. Measure oil in graduated container.
- i. Allowable internal leakage flow from drain hose (Figure 8, Item 2) is 1.25 qts (1.18 L) in 15 seconds or 1.25 gpm (4.73 Lpm).

**WINCH WILL NOT PULL RATED LOAD - Continued**



T01813HDC

Figure 8. Winch Motor.

- j. Stop engine; relieve hydraulic pressure and connect all hoses.

**CONDITION/INDICATION**

Is winch leakage rate greater than 1.25 gpm (4.73 Lpm)?


**DECISION**

- YES - Replace winch motor (TM 5-2350-262-20).
- NO - Go to Step (4).

**WINCH WILL NOT PULL RATED LOAD - Continued**

**STEP**

4. Perform winch shift linkage adjustment check.
  - a. Set control lever (Figure 9, Item 2) in NEUTRAL detent (Figure 9, Item 1).
  - b. Move lever (Figure 9, Item 4) from side to side and measure for proper shift rod (Figure 9, Item 3) NEUTRAL position.
  - c. Shift rod (Figure 9, Item 3) must move at least 0.10 in. (2.54 mm) in either direction without engaging LOW or HIGH gear.
  - d. Total NEUTRAL zone travel is 0.34 in. (8.64 mm).
  - e. Go to Step (5) if shift rod (Figure 9, Item 3) NEUTRAL travel is not within limits.



T01814HDC

Figure 9. Winch Shift Linkage.

**CONDITION/INDICATION**

Does linkage fully engage high and low positions?

**DECISION**

- YES - Replace winch motor (TM 5-2350-262-20).
- NO - Go to Step (5).

**STEP**

5. Adjust winch HIGH/LOW linkage.

**NOTE**

- Ensure control lever is in NEUTRAL detent.
  - Control lever must move 0.10 in. (2.54 mm) in either direction without engaging winch. Total NEUTRAL travel zone is 0.34 in. (8.64 mm).
- a. Remove cotter pin (Figure 10, Item 4) and clevis pin (Figure 10, Item 1) from clevis (Figure 10, Item 2) and control lever (Figure 10, Item 5).
  - b. Discard cotter pin (Figure 10, Item 4).

**WINCH WILL NOT PULL RATED LOAD - Continued**

- c. Pull shift rod (Figure 10, Item 3) out as far as possible.
- d. This is the end of travel in high-gear position.
- e. Push shift rod (Figure 10, Item 3) back in 1.220 in. (30.99 mm) to locate center of NEUTRAL position.
- f. Adjustment can be made by turning clevis (Figure 10, Item 2) clockwise for NEUTRAL position out; counterclockwise for NEUTRAL position in.
- g. Install clevis (Figure 10, Item 2) on control lever (Figure 10, Item 5) with clevis pin (Figure 10, Item 1) and new cotter pin (Figure 10, Item 4).
- h. Verify shift rod (Figure 10, Item 3) is within NEUTRAL travel limits.




Figure 10. Winch Linkage.

- i. Operate winch and check for proper operation.
- j. If winch does not function properly, notify supervisor.

**CONDITION/INDICATION**

Can linkage be adjusted?

**DECISION**

YES - Verify problem is solved.  
 NO - Replace winch (TM 5-2350-262-20).

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
TROUBLESHOOTING PROCEDURES - APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM  
PROBLEM**

**INITIAL SETUP:**

**Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**References (cont.)**

WP 0028  
WP 0029  
WP 0030  
WP 0036  
WP 0037  
WP 0038  
WP 0034

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**References**

WP 0004  
WP 0005  
WP 0023  
WP 0025


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle on jack stands (TM 5-2350-262-20)

**TROUBLESHOOTING PROCEDURE**

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM**

**WARNING**



- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Transmission shifting lines are pressurized. Do not disconnect lines, fittings, or accumulator unless transmission shift control valve pressure has been relieved. Discharge transmission shift accumulator by moving shift control lever through all forward and reverse ranges several times, with engine off. Failure to comply may result in severe injury to personnel.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

1. Perform HDC system functional check-out (WP 0025).

**CONDITION/INDICATION**

Can HDC system functional check-out be performed successfully?

**DECISION**

YES - HDC system appears to be functioning properly and ready to aid in troubleshooting the M9 ACE hydraulic system. If this functional checkout was performed as part of weekly HDC system PMCS (WP 0023), power off HDC system, disconnect it from vehicle, and stow HDC control box and umbilical cable W4. If this functional checkout was performed prior to troubleshooting a problem in vehicle hydraulic system using HDC system, refer to applicable problem symptom work package as applicable and proceed as indicated (WP 0005).

NO - Go to Step (2).

**STEP**

2. Check installation of HDC control box and umbilical cable W4. Check for clean and secure HDC system ground connection in vehicle (Figures 1, 2, and 3).




Figure 1. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.



APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued




Figure 2. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.




Figure 3. Hydraulic Diagnostic Center (HDC) System Ground Connection in Vehicle.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****CONDITION/INDICATION**

Is HDC control box and umbilical cable W4 installed properly with all cable connectors tight? Is HDC system ground connection in vehicle clean and secure?

**DECISION**

YES - Go to Step (3).

NO - Install HDC control box and umbilical cable W4 properly, and tighten all cable W4 connectors and HDC system ground connection in vehicle. Go to Step (3).

**STEP**

3. Check for indication that power is applied to HDC control box (Figure 4, Item 1).

**CONDITION/INDICATION**

Does red POWER ON led on HDC control box illuminate indicating power is applied to control box, when POWER ON button is pressed?




Figure 4. Hydraulic Diagnostic Center (HDC) Control Box Front Panel.

**DECISION**

YES - Go to Step (4).

NO - Go to Step (7).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

4. Check if HDC system powers up after normal startup delay and performs start up BIT (Built-In-Test).

**CONDITION/INDICATION**

Does HDC system appear to power up after normal start-up delay and perform start-up BIT (Built-In-Test)?

**DECISION**

YES - Go to Step (5).

NO - Go to Step (6).

**STEP**

5. Check if HDC displays pass message after BIT.

**CONDITION/INDICATION**

Does HDC system perform a start-up BIT (Built-In-Test) and display a PASS message on HDC control box LCD screen?

**DECISION**

YES - Go to Step (20).

NO - Go to Step (23).

**STEP**

6. Power off HDC system. Wait a few moments, then power up HDC system again.

**CONDITION/INDICATION**

Does same problem still exist?


**DECISION**

YES - Replace HDC control box.


NO - Continue with HDC system functional check out (WP 0025).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

7. Check if vehicle is in neutral and check if parking brake is engaged (Figures 5 and 6).

**PARKING BRAKE LEVER**

*Figure 5. Vehicle Transmission in Neutral with Parking Brake Fully Engaged.*

**PARKING BRAKE LIGHT**

*Figure 6. Parking Brake Light Location.*

**CONDITION/INDICATION**

Is vehicle transmission in neutral with parking brake fully engaged (parking brake light in vehicle is illuminated)?

**DECISION**

YES - Go to Step (8).

NO - Place vehicle transmission in neutral and fully engage parking brake (parking brake light in vehicle should illuminate). Continue with HDC system functional check-out. (WP 0025)

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

8. Disconnect umbilical cable connector W4P1 from HDC control box connector J1 (Figures 7 and 8).




Figure 7. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.




Figure 8. Pin Layout for Connector W4P1.

**CONDITION/INDICATION**

Is 28 VDC present between umbilical cable connector W4P1 pins A and B?

**DECISION**

YES - Replace HDC control box.

NO - Go to Step (9).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

9. Check for 28 VDC at connector W1J1 pins A and B.

Disconnect umbilical cable connector W4P4 from power cable connector W1J1, on umbilical disconnect bracket (Figures 9 and 10).




Figure 9. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.




Figure 10. Pin Layout for Connector W1J1.

**CONDITION/INDICATION**

Is 28 VDC present between power cable connector W1J1, pins A and B, on umbilical cable disconnect bracket?

**DECISION**

- YES - Go to Step (10).
- NO - Go to Step (12).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

10. Check for continuity across umbilical cables.
  - a. Power off HDC system.
  - b. Perform continuity check between umbilical cable connector W4P1-A, and connector W4P4-A, and between W4P1-B and W4P4-B (Figure 11).




Figure 11. Pin Layout for Connectors W4P1 and W4P4.

**CONDITION/INDICATION**

Does continuity exist between umbilical cable connector W4P1-A and connector W4P4-A, and between W4P1-B and W4P4-B?

**DECISION**

YES - Go to Step (11).  
NO - Replace umbilical cable W4.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

11. Check cable W4P1-A and W4P4-A pins for short circuit to cable W4 connector pin B or to W4 connector shell (Figures 12 and 13).




Figure 12. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.




Figure 13. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.

**CONDITION/INDICATION**

Does a short circuit exist in umbilical cable W4 at W4P1-A or W4P4-A?

**DECISION**

YES - Replace umbilical cable W4.


NO - Reconnect umbilical cable W4, tighten all HDC system connectors securely, and check vehicle 28 VDC power circuits.



**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

12. Check for 28 VDC on parking brake relay terminal B1 (Figure 14).



T01914HDC

Figure 14. Hydraulic Diagnostic Center (HDC) Power Cable Assembly W1 Connection to Parking Brake Relay.

**CONDITION/INDICATION**

Is 28 VDC present on parking brake relay terminal B1?

**DECISION**

YES - Go to Step (14).  
 NO - Go to Step (13).

**STEP**

13. Check for 28 VDC on parking brake relay terminal B2.

**CONDITION/INDICATION**

Is 28 VDC present on parking brake relay terminal B2?

**DECISION**

YES - Replace parking brake relay (TM 5-2350-262-20).  
 NO - Go to Step (16).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

14. Perform continuity check between parking brake relay terminal B1 and power cable connector pin W1J1-A (Figure 15).



T01915HDC

Figure 15. Location of Power Cable Assembly Connector W1J1.

**CONDITION/INDICATION**

Does continuity exist between parking brake terminal B1 and power cable connector pin W1J1-A?

**DECISION**

YES - Go to Step (15).

NO - Replace power cable W1 (WP 0030).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

15. Check power cable W1 for short circuit from W1J1-A to connector W1J1 shell or other pins.




Figure 16. Parking Brake Relay Terminals.

**CONDITION/INDICATION**

Does a short circuit exist in power cable W1?

**DECISION**


YES - Replace power cable W1 (WP 0030).

NO - Check for loose or damaged terminals B1 and B2 on parking brake relay (Figure 16). Check terminals, tighten wiring and replace parking brake relay if defective.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

16. Check for 28 VDC at master relay (input) side of HDC circuit breaker (Figure 17).



T01917HDC

Figure 17. Hydraulic Diagnostic Center (HDC) Simplified Power Input Circuit.

**CONDITION/INDICATION**

Is 28 VDC present at master relay (input) side of HDC circuit breaker?


**DECISION**

YES - Go to Step (18).  
 NO - Go to Step (17).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

17. Check for 28 VDC at Y-connector terminal going to master relay.

Remove "Y" -connector (Figure 18, Item 1) from in-line connector (Figure 18, Item 2). Power up vehicle. Check for 28 VDC on "Y"-connector terminal coming from master relay (wiring harness 12357211).



T01918HDC

Figure 18. Hydraulic Diagnostic Center (HDC) System Power Input Circuit Components.

**CONDITION/INDICATION**

Is 28 VDC present at input to "Y"-connector from wiring harness 12357211 coming from master relay?

**DECISION**

YES - Go to Step (19).

NO - Troubleshoot portion of vehicle electrical system associated with wiring harness 12357211 coming from master relay and repair/replace wiring or components as necessary.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

18. Check for 28 VDC at parking brake relay side of HDC circuit breaker (Figure 19).




Figure 19. Hydraulic Diagnostic Center (HDC) Simplified Power Input Circuit Components.

**CONDITION/INDICATION**

Is 28 VDC present at parking brake relay (output) side of HDC circuit breaker?


**DECISION**

YES - Replace lead assembly 12496958 (WP 0029).

NO - Replace HDC circuit breaker (WP 0028).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

19. Check for 28 VDC at Y connector input terminal of HDC circuit breaker.
  - a. Remove end of lead assembly 12496957 (Figure 20, Item 2) from other terminal of "Y" connector.
  - b. Check for 28 VDC on "Y" connector terminal going to input terminal of HDC circuit breaker.



T01920HDC

Figure 20. Hydraulic Diagnostic Center (HDC) Simplified Power Input Circuit Components.

**CONDITION/INDICATION**

Is 28 VDC present at "Y"-connector terminal going to input terminal of HDC circuit breaker?

**DECISION**

YES - Replace lead assembly 12496957 (WP 0029).

NO - Replace "Y" connector 7982404 (Figure 20, Item 1) (WP 0029).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

20. Check HDC control box LCD screen display for proper startup de-energized state information for HDC system solenoid valves (Figure 21, Items 1 and 2).

**CONDITION/INDICATION**

Do HDC control box LCD screens (PRESSURE TRANSDUCER, UPPER LCD SCREEN, and SOLENOID VALVES STATUS, LOWER LCD SCREEN) display proper start up (initial conditions) de-energized state information for HDC system solenoid valves?

**DECISION**

- YES - Go to Step (22).
- NO - Go to Step (21).

**STEP**

21. Check LCD screens display for proper start up information (Figure 21, Items 1 and 2).
  - a. Power off HDC system.
  - b. Wait a few moments, then power up HDC system again.




Figure 21. Hydraulic Diagnostic Center (HDC) Control Box Front Panel.

**CONDITION/INDICATION**

Do LCD screens display proper start up (initial conditions) information?



**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****DECISION**

YES - HDC control box now appears to have passed start-up BIT. Continue with HDC system functional check-out (WP 0025).  
NO - Go to Step (27).

**STEP**

22. Proceed to functionally check out HDC system and individual HDC system components in accordance with procedure and sequence listed in HDC system functional check-out (WP 0025).

Refer to "Introduction to Using the Hydraulic Diagnostic Center (HDC) System to Troubleshoot the M9 Hydraulic System" (WP 0004).

**CONDITION/INDICATION**

Do all of HDC control box push button switches operate properly?

**DECISION**

YES - Go to Step (25).  
NO - Replace HDC control box.

**STEP**

23. Check HDC for fault message.

**CONDITION/INDICATION**

Is a BIT fault, DO NOT USE FOR TESTING message, or any abnormal group of characters displayed?

**DECISION**

YES - Go to Step (24).  
NO - Replace HDC control box.

**STEP**

24. Check if control box performs BIT startup and displays a PASS message.
- Power off HDC system.
  - Wait a few moments, then power up HDC system again.

**CONDITION/INDICATION**

Does control box perform a start-up BIT and display a PASS message?

**DECISION**

YES - HDC control box now appears to have passed start-up BIT. Continue with HDC system functional check-out (WP 0025).  
NO - Replace HDC control box.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

25. Check if HDC system is fully operational.

**CONDITION/INDICATION**

Is HDC system fully operational as indicated by all of individual HDC system components specified in check-out procedure passing their functional check-out?

**DECISION**

YES - The HDC system has passed functional check-out and can be used to aid in troubleshooting vehicle hydraulic system.

NO - Go to Step (26).

**STEP**

26. If here, at least one HDC system component failed to pass the functional check-out.

**CONDITION/INDICATION**

Did all components of the HDC system pass the functional check-out?

**DECISION**

YES - Replace HDC control box.

NO - Go to Step (29).

**STEP**

27. Check if CIRCUIT FAULT message is displayed.

**CONDITION/INDICATION**

Is CIRCUIT FAULT message displayed on either LCD screen indicating that a problem exists in one (or more) of HDC system solenoid valves or pressure transducer circuits?

**DECISION**

YES - Go to Step (31).

NO - Go to Step (28).

**STEP**

28. Check if same condition exists.

a. Power off HDC system.

b. Wait a few moments, then power up HDC system again.

**CONDITION/INDICATION**

Do same CONDITIONS/INDICATIONS still exist?

**DECISION**

YES - Replace HDC control box.

NO - Continue with HDC system functional check-out (WP 0025) .

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

29. Check if check fails.
- a. Power off HDC system.
  - b. Change out HDC system component that did not pass functional check-out with an identical, known good spare, component (solenoid valve or pressure transducer, as applicable) or temporarily switch identical type component from another nearby location in HDC system.
  - c. Repeat functional test of HDC system components th (WP 0025) .

**CONDITION/INDICATION**

Did functional check-out test fail again for same component designator as it did for original component in previous test?

**DECISION**

YES - Go to Step (30).

NO - Replace HDC system component (the original solenoid valve or pressure transducer) that did not pass functional test first time.

**STEP**

30. Check if CIRCUIT FAULT is a solenoid valve.

**CONDITION/INDICATION**

Is the CIRCUIT FAULT component that did not pass functional test a solenoid valve?

**DECISION**

YES - Go to Step (33).

NO - Go to Step (38).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

31. Check if CIRCUIT FAULT message is displayed on either screen.
  - a. Check all umbilical cable W4 electrical connectors on HDC control box and umbilical cable disconnect bracket for proper connections and tightness (Figures 22 and 23).




Figure 22. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.




Figure 23. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.

- b. Tighten as necessary.
- c. Power off HDC system, wait a few moments, then power up HDC system again.

**CONDITION/INDICATION**

Is a CIRCUIT FAULT message displayed on either HDC control box LCD screen (upper or lower)?

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****DECISION**

YES - Go to Step (32).

NO - HDC system appears to have passed start-up BIT. Continue to perform HDC system functional check-out (WP 0025) .

**STEP**

32. Check what CIRCUIT FAULT message is associated with.

**CONDITION/INDICATION**

Is CIRCUIT FAULT message associated with a solenoid valve? (CIRCUIT FAULT message is displayed on hydraulic valve status LCD screen (lower LCD display))?

**DECISION**

YES - Go to Step (33).

NO - Go to Step (38).

**STEP**

33. If "CIRCUIT FAULT" message is associated with a solenoid valve (lower LCD screen display).

- a. Power off HDC system.
- b. Tag W2 or W3 cable assembly electrical lead to HDC system solenoid valve (on HDC system primary manifold, right forward manifold, left forward manifold, or aft manifold, as applicable) identified in "CIRCUIT FAULT" message and switch electrical leads with another (identical type) solenoid valve on same manifold assembly.
- c. Power up HDC system again.
- d. Power off HDC system.
- e. If a "good" solenoid valve was switched with another valve to check out first valve, make sure good valve is returned to original location.
- f. Reconnect proper electrical leads and ensure all W2 or W3 electrical leads are mated with proper solenoid valves.

**CONDITION/INDICATION**

Does lower LCD screen display same CIRCUIT FAULT message (identifying same solenoid valve as previous CIRCUIT FAULT message)?

**DECISION**

YES - Go to Step (34).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward left manifold (WP 0036).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward right manifold (WP 0037).


NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC aft manifold (WP 0038).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC primary manifold (WP 0034).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**STEP**

34. Check for open or short circuit in cable assemblies W2 and W3.
  - a. Disconnect W2 or W3 cable assembly electrical lead going into electrical connector of solenoid valve on primary manifold, forward manifolds, or aft manifold identified in "CIRCUIT FAULT" message (Figures 24 and 25).
  - b. Reference individual cable assembly wiring schematic diagrams (for cable assemblies W2 through W4) in FP-23 through FP-28, and HDC control box connections pin number signal name (WP 0004) , and trace signal path for the "CIRCUIT FAULT" solenoid valve energizing voltage (28 VDC) from a connector on HDC control box (J2 or J3) to a connector on umbilical disconnect bracket (W2J1 or W3J1), through umbilical cable connectors W4P5 or W4P6, respectively.




*Figure 24. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.*

- c. Disconnect umbilical cable connector W4P5 or W4P6 (as applicable) associated with "CIRCUIT FAULT" solenoid valve from cable assembly W2J1 or cable assembly W3J1 (as applicable) connector on umbilical disconnect bracket.
- d. Perform continuity test and check for short circuit to cable ground (connector case/shell) for two pins/wires in applicable embedded cable assembly (W2J1 or W3J1) that route 28 VDC energizing voltage from HDC control box to solenoid valve associated with "CIRCUIT FAULT" message (28 VDC energizing voltage is applied between pins 1 and 2 on three-pin solenoid valve electrical connector on all solenoid valves).

Refer to FP-21 Solenoid Valve Electrical Wiring Diagram.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**



*Figure 25. Upper Cable Assembly W2J1 and Lower Cable Assembly W3J1 Electrical Connections.*

**CONDITION/INDICATION**

Does an open circuit or short circuit exist in applicable cable assembly W2 or W3 wiring circuit (CIRCUIT FAULT solenoid valve 28 VDC energizing circuit) being checked? (Refer to FP-23 through FP-26) for wiring schematic diagrams of electrical cable assemblies (W2 and W3).

**DECISION**

- YES - Replace embedded cable assembly (W2 or W3 as applicable) associated with designated "CIRCUIT FAULT" solenoid valve 28 VDC energizing circuit wiring.
- NO - Go to Step (35).

## APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued

## STEP

35. Check for an open or short circuit in cable assembly W4.
- Disconnect umbilical cable W4 connector W4P2 or W4P3 (Figures 26, 27, and 28) (from HDC control box connector J2 or J3, as applicable) associated with designated "CIRCUIT FAULT" solenoid valve.




Figure 26. Umbilical Cable Assembly W4P2 and W4P3 Connections to Hydraulic Diagnostic Center (HDC) Control Box.

- Perform continuity test and check for short circuit to cable (connector case/shell) for two pins/wires in W4 cable that go from connector W4P2 or W4P3 (as applicable) normally connected to HDC control box, to W4P5 or W4P6 connector (as applicable) normally connected to umbilical disconnect bracket.



**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**




Figure 27. Umbilical Cable Assembly W4P2 and W4P3 Electrical Connections.




Figure 28. Umbilical Cable Assembly W4P5 and W4P6 Electrical Connections.

**CONDITION/INDICATION**

Does an open circuit or short circuit exist in umbilical cable assembly W4 wiring circuit (CIRCUIT FAULT solenoid valve 28 VDC energizing circuit) being checked?

**DECISION**

YES - Replace umbilical cable assembly W4. Resume HDC system functional check-out (WP 0025).  
NO - Go to Step (36).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

36. Substitute a spare (good) solenoid valve with "CIRCUIT FAULT" solenoid valve and repeat test.

**CONDITION/INDICATION**

ARE RESULTS SAME?

**DECISION**

YES - Replace HDC control box. Resume HDC system functional check-out (WP 0025) .

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward left manifold (WP 0036).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward right manifold (WP 0037).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC aft manifold (WP 0038).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC primary manifold (WP 0034).

**STEP**

37. Check if CIRCUIT FAULT appears after faulty transducer is replaced with known good transducer.

- a. If here, "CIRCUIT FAULT" message is associated with a pressure transducer (upper LCD screen display).
- b. Power off HDC system.
- c. Tag W2 or W3 cable assembly electrical lead to hydraulic pressure transducer identified in "CIRCUIT FAULT" message and switch electrical leads with another (or spare) hydraulic pressure transducer. If a spare of another pressure transducer is not nearby, temporarily exchange identified pressure transducer with another pressure transducer from elsewhere in vehicle.
- d. Power up HDC system again.
- e. Power off HDC system.
- f. If a "good" pressure transducer was switched with another pressure transducer to check out first transducer, make sure good transducer is returned to original location.
- g. Reconnect proper electrical leads and ensure all W2 or W3 electrical leads are mated with proper pressure transducer.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**CONDITION/INDICATION**

Does upper LCD screen display same CIRCUIT FAULT message (identifying same hydraulic pressure transducer as previous CIRCUIT FAULT message)?

**DECISION**

YES - Go to Step (38)

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward left manifold (WP 0036).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward right manifold (WP 0037).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC aft manifold (WP 0038).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC primary manifold (WP 0034).

**STEP**

38. Check if cable assemblies W2 or W3 have an open or short circuit.
  - a. Disconnect applicable W2 or W3 cable assembly electrical lead going to electrical connector of pressure transducer identified in "CIRCUIT FAULT" message.
  - b. Reference individual cable assembly wiring schematic diagrams (for cable assemblies W2 through W4) in FP-23 through FP-28, and HDC control box connectors pin number signal names information in "Introduction to Using the Hydraulic Diagnostic Center (HDC) System to Troubleshoot the M9 Hydraulic System" (WP 0004), and trace signal path for "CIRCUIT FAULT: pressure transducer reference voltage (15 VDC) from a connector on HDC control box (J2 or J3) to a connector on umbilical disconnect bracket (W2J1 or W3J1), through applicable umbilical cable connector W4P5 or W4P6, respectively (Figure 29).




Figure 29. Umbilical Cable Assembly W4 Connection to Umbilical Cable Disconnect Bracket.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

- c. Disconnect umbilical cable connector W4P5 or W4P6 (as applicable) associated with "CIRCUIT FAULT" pressure transducer from cable assembly W2J1 or cable assembly W3J1 (as applicable) connector on umbilical disconnect bracket (Figures 30 and 31).




Figure 30. Pin Locations for W2J1 and W3J1 Connectors.




Figure 31. Upper Cable Assembly W2 and Lower Cable Assembly W3 Electrical Connections.

- d. Perform continuity test and check for short circuit to cable ground (connector case/shell) for two pins/ wires in embedded cables assembly (W2J1 or W3J1, as applicable) that route 15 VDC reference voltage from HDC control box to pressure transducer associated with "CIRCUIT FAULT" message. (15 VDC reference voltage is applied between pins 1 and 2 on 5-pin hydraulic pressure transducer electrical connector J1 on all pressure transducers. The DC voltage representing hydraulic pressure measured by pressure transducer is returned to HDC control box between pins 4 and 5 on transducer electrical connector J1).

Refer to FP-19 Hydraulic Pressure Transducer Electrical Wiring Diagram.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

**CONDITION/INDICATION**


Does an open circuit or short circuit exist in cable assembly W2 or W3 wiring circuit (CIRCUIT FAULT pressure transducer 15 VDC reference circuit) being checked? (Refer to FP-23 through FP26, for wiring schematic diagrams of electrical cable assemblies W2 and W3).

**DECISION**

YES - Replace embedded cable assembly (W2 or W3, as applicable) associated with designated "CIRCUIT FAULT" pressure transducer 15 VDC reference voltage circuit wiring.  
 NO - Go to Step (39).

**STEP**

- 39. Check if cable assembly W4 has an open or shorted circuit.
  - a. Disconnect umbilical cable W4 connector W4P2 on W4P3 (Figure 32) (from HDC control box connector J2 or J3, as applicable) associated with designated "CIRCUIT FAULT" pressure transducer.



T01932HDC

Figure 32. Umbilical Cable Assembly W4 Connections to Hydraulic Diagnostic Center (HDC) Control Box.

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued**

- b. Perform continuity test and check for short circuit to cable (connector case/shell) for two pins/wires in W4 cable that go from either connector W4P2 or W4P3 (as applicable), normally connected to HDC control box, to W4P5 or W4P6 connector (as applicable) normally connected to umbilical disconnect bracket (Figures 33 and 34).




Figure 33. Umbilical Cable Assembly W4P2 and W4P3 Electrical Connectors.




Figure 34. Umbilical Cable Assembly W4P5 and W4P6 Electrical Connectors.

**CONDITION/INDICATION**

Does an open circuit or short circuit exist for umbilical cable assembly W4 wiring circuit (CIRCUIT FAULT pressure transducer 15 VDC referenced voltage circuit) being checked?

**DECISION**

YES - Replace umbilical cable assembly W4. Resume HDC system functional check-out (WP 0025) .  
NO - Go to Step (40).

**APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM - Continued****STEP**

40. Substitute a spare (good) pressure transducer for "CIRCUIT FAULT" pressure transducer identified during BIT and repeat test.

**CONDITION/INDICATION**

Are results same?

**DECISION**

YES - Replace HDC control box. Resume HDC system functional check-out (WP 0025) .

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward left manifold (WP 0036).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on forward right manifold (WP 0037).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC aft manifold (WP 0038).

NO - Replace applicable HDC system solenoid valve identified in first "CIRCUIT FAULT" message on HDC primary manifold (WP 0034).

**END OF WORK PACKAGE**





**CHAPTER 3**

**PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)**  
**MAINTENANCE INSTRUCTIONS**



---

**OPERATOR MAINTENANCE  
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION**

---

This work package contains the Preventive Maintenance Checks and Services (PMCS) required for the M9 ACE Hydraulic Diagnostic Center (HDC) System. PMCS is a scheduled, step-by-step inspection and service of the vehicle and vehicle components. Its purpose is to keep the vehicle in good condition and to identify and correct problems before costly and time-consuming repairs are needed.

**MAINTENANCE FORMS AND RECORDS**

Use DA Form 2404, Equipment Inspection and Maintenance Worksheet, to record periodic maintenance service performed and faults corrected. The item number on the DA Form 2404 must be the same as the item number of the PMCS. For information on maintenance forms and records, see DA Pam 750-8.

**MECHANIC PARTICIPATION**

The operator may perform operator PMCS (TM 5-2350-262-10) and may also help Field Maintenance perform field PMCS and lubrication in accordance with TM 5-2350-262-10.

**INTERVALS**

HDC PMCS should be performed every week.

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)**

**INITIAL SETUP:**

**Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**References**

WP 0021  
WP 0025

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)

**Equipment Condition**


Vehicle MASTER power OFF (TM 5-2350-262-10)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**Table 1. Preventive Maintenance Checks and Services (PMCS).**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
1	Weekly	Nuts, Bolts, and Screws (Figure 1)	Check for loose parts by looking for cracked or chipped paints around screws and bolt heads. Check for missing or broken cotter pins or lock wire.	Nuts, bolts, or screws missing, loose, stripped, or improperly installed.





*Figure 1. Bolt.*


**Table 1. Preventive Maintenance Checks and Services (PMCS) - Continued.**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
2	Weekly	Hydraulic Diagnostic Center (HDC) System Components (Figure 2)	<p>a. Clean HDC system components. They should be free of dirt, oil, and hydraulic fluids.</p> <p>b. Check condition of Umbilical Disconnect Bracket and attached cables in Operator's Compartment.</p>	<p>Any condition would prevent safe operation of vehicle.</p> <p>Bracket is not secured and/or cables are missing or broken.</p>
<p>Figure 2. Hydraulic Diagnostic Center (HDC) Bracket.</p>				
3	Weekly	HDC System Electrical Components (Figure 3)	<p>a. Check that all HDC electrical connections and connectors are clean and tight.</p> <p>b. Check condition of HDC Control Box and Umbilical Cable Assembly W4.</p>	<p>Any condition would prevent safe operation of vehicle.</p>

Table 1. Preventive Maintenance Checks and Services (PMCS) - Continued.

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				
<p>Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.</p>				
			<p>c. Check condition of HDC Power Cable W1, Upper Cable Assembly W2, and Lower Cable Assembly W3.</p> <p>d. Check HDC system solenoid valves and pressure transducer electrical connectors for proper connections and tight fit. Tighten as required.</p>	Any condition would prevent safe operation of vehicle.
4	Weekly	HDC System Hydraulic Components (Figure 4)	<p>a. Check all HDC hydraulic hoses, tubes, and fittings for damage, loose clamps, improper routing, leaks, and chafing.</p> <p>b. Check fittings for evidence of leaks and looseness. Do not overtighten hoses, tubes, or fittings.</p>	Any condition would prevent safe operation of vehicle.
				
<p>Figure 4. Hydraulic Hoses, Tubes, and Fittings.</p>				

**Table 1. Preventive Maintenance Checks and Services (PMCS) - Continued.**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
5	Weekly	Primary Manifold/ Directional Control Valve (DCV) Bank (Figure 5)	Ensure that the seven hydraulic metal tubes connected between primary manifold and DCV bank are tight and that there are no leaking fittings.	Any condition would prevent safe operation of vehicle.
 <p data-bbox="581 1115 943 1142">Figure 5. Hydraulic Metal Tubes.</p>				
6	Weekly	HDC System Pressure Transducers	Check that all HDC system pressure transducers are tightly seated in adapters.	Any condition would prevent safe operation of vehicle.
7	Weekly		Perform M9 ACE HDC system Functional Check-Out pro (WP 0025) . If the HDC system does not pass all portions of the Functional Check-out procedure, refer to (WP 0021) and proceed to troubleshoot as applicable.	Any condition would prevent safe operation of vehicle.

**PMCS MANDATORY REPLACEMENT PARTS**

There are no mandatory replacement parts for these PMCS procedures.

**END OF TASK**

**END OF WORK PACKAGE**



**CHAPTER 4**  
**MAINTENANCE INSTRUCTIONS**



---

**FIELD MAINTENANCE  
SERVICE UPON RECEIPT**

---

**INITIAL SETUP:****Personnel Required**

Construction Equipment Repairer, 91L

**References (cont.)**

DA PAM 750-8

SF 361, Transportation Discrepancy Report

**References**

WP 0004

---

**SERVICE UPON RECEIPT OF MATERIEL**

Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on the SF 361, Transportation Discrepancy Report.

Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with applicable service instructions (e.g., for Army instructions, see DA PAM 750-8).

Check to see whether the equipment has been modified.

Refer to INTRODUCTION TO USING THE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM TO TROUBLESHOOT THE M9 ACE HYDRAULIC SYSTEM (WP 0004) for the required equipment and tools.

**INSTALLATION INSTRUCTIONS**

Refer to INTRODUCTION TO USING THE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM TO TROUBLESHOOT THE M9 ACE HYDRAULIC SYSTEM (WP 0004) for installation instructions.

**END OF TASK****END OF WORK PACKAGE**



**FIELD MAINTENANCE**  
**M9 ACE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM FUNCTIONAL CHECK-OUT**

**INITIAL SETUP:****Personnel Required**

Combat Engineer, 21B  
 Construction Equipment Repairer, 91L

**References**

TM 5-2350-262-10

**M9 ACE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM FUNCTIONAL CHECK-OUT****Purpose:**

The purpose of the Functional Check-Out is to ensure that the vehicle and the HDC System are functioning properly.

**Assumptions:**

1. Vehicle relief valve settings have previously been adjusted using a GS-5 pressure gauge, with a tolerance of +/- 100 psi (689.4757 kPa).
2. The accuracy of the HDC system is +/- 100 psi (689.4757 kPa).
3. Pressure values within +/- 200 psi (1378.951 kPa) are considered within specification.
4. Other vehicle operational characteristics meet the specifications.

**Procedure:**

The individual tests should be conducted in accordance with this procedure. Figures and tables provide additional information. The HDC System is considered fully operational when it has passed all of the tests.

**WARNING**

Before performing any troubleshooting in bowl, move the ejector forward and disconnect the ejector cylinder from the hydraulic system by pulling the handle down on ball valve V23, located in the rear of the bowl area, just below the main Directional Control Valve (DCV) bank. Failure to comply may result in severe injury or death to personnel.

**NOTE**

Problems existing in the vehicle hydraulic system when the HDC System Functional Check-Out is performed could result in the HDC System not passing all portions of the Functional Check-Out. Because of this, it is important that all applicable vehicle PMCS checks have been performed and that vehicle hydraulic functions be exercised prior to performing the HDC System Functional Check-Out to determine exactly which vehicle hydraulic functions are impaired and to use this information with the results of the Functional Check-Out to help isolate the problem area.

1. Exercise vehicle functions:

- a. Confirm that the three HDC System manual valves V21 (Figure 1, Item 1), V22 (Figure 1, Item 2), and V23 (Figure 1, Item 3) are in fully OPEN position. Handles must be vertical.




Figure 1. Directional Control Valve (DCV) Bank.

- b. Start engine.
  - c. Confirm that vehicle rises up and levels out normally when the engine is started within two minutes.
  - d. Confirm that ejector extends and retracts.
  - e. Confirm that apron moves up and down.
  - f. Confirm that left suspension moves up and down.
  - g. Confirm that right suspension moves up and down.
  - h. Confirm that the left and right bump stops extend when the vehicle is placed in SPRUNG mode, and retract when the vehicle is placed in UNSPRUNG mode.
  - i. Confirm that winch pays out and pays in.
2. Valve V23 check:
- a. Stop engine.
  - b. Manually place valve V23 in the closed position. Handle horizontal (down).
  - c. Start engine.
  - d. Confirm that the ejector does not extend or retract. (This indicates that valve V23 is working properly.)
  - e. Stop engine and ensure that engine is off before connecting HDC control box.

## 3. HDC Control Box power-up and operation.

**WARNING**

Do not activate the vehicle's hydraulic control levers or depress any buttons on the HDC control box unless directed by this procedure. Failure to comply could result in serious injury or death to personnel.

- a. Ensure vehicle power is off.
- b. Remove HDC Control Box and umbilical cable W4 from stowage location behind operator's seat.
- c. Place HDC Control Box in operating location.
- d. Connect HDC Control Box and umbilical cable W4 to vehicle as per (WP 0004).
- e. Place vehicle power on.
- f. Ensure parking brake is on and transmission is in neutral, then start vehicle engine. HDC System will not receive operating power from vehicle unless parking brake is on and transmission is in neutral.
- g. With the vehicle engine running and the transmission in neutral, turn the HDC Control Box on by pressing the POWER button. (Depressing the POWER button again will turn the HDC Control box off.) Note that:
  - (1) Power to the HDC System is disconnected if the vehicle is taken out of neutral.
  - (2) The solenoid valves will return to their normal vehicle operating positions (de-energized/not powered) when the HDC Control Box is turned off (or power is disconnected).

**NOTE**

The HDC System automatically initiates a start-up Built-In-Test (BIT) when power is applied to the system.

- h. After power is applied to the HDC System, and a start-up BIT is performed, if a BIT fault message is displayed on the Liquid Crystal Display (LCD), do not use the HDC Control Box for testing.
- i. When system powers up, displays will be dark for 3 seconds. If significant sections of the displays are missing, displays will be unreadable; do not use if displays are unreadable.
- j. If the temperature is below -4°F (-20°C), the displays will not come on until warmed up. The power light will blink until the displays have warmed up.
- k. If the start-up BIT passed, and the HDC System is operating properly, the initial default display for the status of the HDC System solenoid valves will appear as shown in Table 1. This is the normal de-energized (unpowered) state of the HDC System solenoid valves.
- l. Confirm that the HDC Control Box displays the pressure transducer number, hydraulic line pressure, solenoid valve number, valve power status (on/off) (PWR), and valve position (open/closed) status similar to Table 1 (for the solenoid valves). (Note: a CIRCUIT FAULT message indicates a disconnected or malfunctioning wire harness, electrical cable, or defective component. Check all connections in the event of a CIRCUIT FAULT message as shown in the test display example on Figure 2).




Figure 2. Typical Hydraulic Diagnostic Center (HDC) Control Box Test Display (Not The Start-up Display).

- m. If the solenoid valves portion of the HDC Control Box start-up LCD display does not appear as shown in Table 1, refer to Troubleshooting (WP 0021), for troubleshooting procedures to aid in isolating a fault or problem in the HDC System.
- n. The HDC Control Box default solenoid valve display (all solenoid valves in the OFF position) should be as shown in Table 1.



**Table 1. Default Solenoid Valve LCD Display.**

<b>VALVE NO.</b>	<b>PWR</b>	<b>/</b>	<b>POSITION</b>
V1	OFF	/	OPEN
V2	OFF	/	OPEN
V3	OFF	/	OPEN
V4	OFF	/	OPEN
V5	OFF	/	OPEN
V6	OFF	/	OPEN
V7	OFF	/	OPEN
V8	OFF	/	OPEN
V9	OFF	/	OPEN
V10	OFF	/	OPEN
V11	OFF	/	OPEN
V12	OFF	/	OPEN
V13	OFF	/	OPEN
V14	OFF	/	OPEN
V15	OFF	/	OPEN
V16	OFF	/	OPEN
V17	OFF	/	OPEN
V18	OFF	/	CLOSED
V19	OFF	/	CLOSED
V20	OFF	/	CLOSED

**NOTE**

- Electrical solenoid valves V1 through V20 can be opened and closed by using the LINE UP and LINE DOWN buttons on the HDC Control Box to select a valve, and then pressing the CHANGE POSITION button to open or close the valve. The HDC Control Box software allows up to four of the solenoid valves (V1-V20) to be powered ON at one time. Pressing the RESET VALVES button returns all solenoid valves to their normal (default) operating position (power to the valves is OFF).
  - Valves V21 and V22 are manually operated, and are located in the bowl area, near the high pressure filters.
  - Valve V23 is also manually operated, and is located in the bowl area, on the front of the Directional Control Valve (DCV) bank. It is operated while standing in the bowl. This valve is used to interrupt hydraulic fluid flow to the ejector. It is recommended that the engine be shut down when operating valve V23, for safety purposes.
- o. Use LINE UP or LINE DOWN buttons to scroll to desired solenoid valve number and select CHANGE POSITION to energize (open or close) valve. Note: A maximum of four valves can be powered on at one time. If a solenoid valve circuit has failed, CIRCUIT FAULT will be displayed next to the solenoid valve number on the HDC Control Box LCD display and that valve cannot be selected/powerd.
  - p. After solenoid valves are selected, read applicable hydraulic line pressures on the other LCD. If a hydraulic pressure transducer circuit has failed, a CIRCUIT FAULT message will be displayed next to the transducer number and the pressure will not be displayed.
  - q. Use "RESET VALVES" to place all solenoid valves in their normal de-energized (un-powered) position.
  - r. Select "CHANGE" to adjust display lighting.
4. Transducer T7, T8, T9, T10, T11, T12, and T13 check:
    - a. Have the vehicle operator move the SPRUNG/UNSPRUNG lever to the UNSPRUNG position.
    - b. With the vehicle running, confirm that T7, T8, T9, T10, T11, T12, and T13 read greater than 2500 psi (17236.89 kPa). (This is the pressure provided by the compensating pump, and it indicates that transducers T7 through T13 are working properly).
  5. Transducer T5 check:
    - a. Push the RESET VALVES button on the HDC Control Box, and verify that all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - b. Verify that the SPRUNG/UNSPRUNG lever is in the UNSPRUNG position.
    - c. Have the vehicle operator move the right SUSPENSION CONTROL lever to the RAISE position, and hold it there until the vehicle reaches the maximum height.
    - d. Verify that the pressure reading for T5 is at least 2,800 psi (19305.32 kPa). (T5 is now indicating the pressure setting of the right suspension relief valve, and indicates that transducer T5 is working properly.)
    - e. Have the vehicle operator release the right SUSPENSION CONTROL lever.
  6. Transducer T6 check:
    - a. Push the RESET VALVES button and verify all the valves are set to the power OFF setting and are in the default position, as shown in Table 1.
    - b. Verify that the SPRUNG/UNSPRUNG lever is in the UNSPRUNG position.
    - c. Have the vehicle operator move the left SUSPENSION CONTROL lever to the RAISE position, and hold it there until the vehicle reaches the maximum height.
    - d. Verify that the pressure reading for T6 is at least 2,800 psi (19305.32 kPa). (T6 is now indicating the pressure setting of the left suspension relief valve, and indicates that transducer T6 is working properly.)

- e. Have the vehicle operator release the left SUSPENSION CONTROL lever.
7. Valve V21 and transducer T3 check:
    - a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - b. Slowly close ball valve V21 until the pressure reading on T3 display exceeds 3,000 psi (20684.27 kPa). (This indicates that V21 and T3 are both working properly.)
    - c. Open ball valve V21 completely.
  8. Valve V22 and transducer T4 check:
    - a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - b. Slowly close ball valve V22 until the pressure reading on T4 display exceeds 3,000 psi (20684.27 kPa). (This indicates that V22 and T4 are both working properly.)
    - c. Open ball valve V22 completely.
  9. Valve V5 and transducer T1 check:
    - a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - b. Have the vehicle operator place the vehicle in UNSPRUNG mode.
    - c. Use the LINE UP and LINE DOWN buttons to select valve V5. Press CHANGE POSITION to close valve V5.
    - d. Have the vehicle operator move the right SUSPENSION CONTROL lever to LOWER. Verify that the right suspension does NOT lower, and that transducer T1 reads greater than 3500 psi (24131.65 kPa). (This indicates that valve V5 has redirected flow from the suspension to transducer T1, which will now read the value of the system relief valves.)
  10. Valve V9 and V10 check:
    - a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - b. Have the vehicle operator place the vehicle in SPRUNG mode.
    - c. Verify that the bump stops are extended.
    - d. Use the LINE UP and LINE DOWN buttons to select valve V9. Press CHANGE POSITION to close valve V9.
    - e. Use the LINE UP and LINE DOWN buttons to select valve V10. Press CHANGE POSITION to close valve V10.
    - f. Have the vehicle operator place the vehicle in UNSPRUNG mode.
    - g. Verify that the bump stops are still extended. (This indicates that V9 and V10 are closed, preventing operation of the bump stops.)
    - h. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - i. Verify that the bump stops are now retracted. (This verifies that V9 and V10 have opened.)
  11. Valve V11 check:
    - a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
    - b. Have the vehicle operator place the vehicle in SPRUNG mode.

- c. Use the LINE UP and LINE DOWN buttons to select valve V11. Press CHANGE POSITION to close valve V11.
  - d. Verify that transducer T1 reads less than 500 psi (3447.379 kPa).
  - e. Have the vehicle operator place the vehicle in UNSPRUNG mode.
  - f. Have the vehicle operator move the left SUSPENSION CONTROL lever to LOWER.
  - g. Verify that transducer T1 reads greater than 3000 psi (20684.27 kPa). (This indicates that V11 has directed flow from the suspension to transducer T1, which now reads the system relief valve pressure setting.)
12. Valve V14 check:
- a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
  - b. Use the LINE UP and LINE DOWN buttons to select valve V14. Press CHANGE POSITION to close valve V14.
  - c. Have the vehicle operator move the winch control lever to PAY OUT until transducer T1 reads less than 500 psi (3447.379 kPa).
  - d. Have the vehicle operator move the winch control lever to PAY IN until transducer T1 reads greater than 1500 psi (10342.14 kPa). (This indicates that V14 has directed flow from the winch circuit to transducer T1.)
13. Valve V15 check:
- a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
  - b. Use the LINE UP and LINE DOWN buttons to select valve V15. Press CHANGE POSITION to close valve V15.
  - c. Have the vehicle operator move the right SUSPENSION CONTROL lever to LOWER until transducer T1 reads less than 500 psi (3447.379 kPa).
  - d. Have the vehicle operator move the right SUSPENSION CONTROL lever to RAISE until transducer T1 reads greater than 3000 psi (20684.27 kPa). (This indicates that V15 has directed flow from the suspension circuit to transducer T1.)
14. Valve V16 check:
- a. Push the RESET VALVES button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
  - b. Use the LINE UP and LINE DOWN buttons to select valve V16. Press CHANGE POSITION to close valve V16.
  - c. Have the vehicle operator move the left SUSPENSION CONTROL lever to LOWER until transducer T1 reads less than 500 psi (3447.379 kPa).
  - d. Have the vehicle operator move the left SUSPENSION CONTROL lever to RAISE until transducer T1 reads greater than 3000 psi (20684.227 kPa). (This indicates that V16 has directed flow from the suspension circuit to transducer T1.)
15. Valve V17 check:
- a. Push the RESET VALVE button on the HDC Control Box, and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
  - b. Use the LINE UP and LINE DOWN buttons to select valve V17. Press CHANGE POSITION to close valve V17.

- c. Have the vehicle operator move the APRON control lever to LOWER until transducer T1 reads less than 500 psi (3447.379 kPa).
  - d. Have the vehicle operator move the APRON control lever to RAISE until transducer T1 reads greater than 3000 psi (20684.27 kPa). (This indicates that V17 has directed flow from the apron circuit to transducer T1.)
16. Valve V1 check:
- a. Turn off the HDC Control Box by depressing the POWER button.
  - b. Have the vehicle operator stop the engine.
  - c. Manually open valve V23 by moving the handle to a fully vertical position.
  - d. Have the vehicle operator start the engine.
  - e. Power up the HDC Control Box by pressing the POWER button.
  - f. Use the LINE UP and LINE DOWN buttons to select valve V1. Press CHANGE POSITION button to close valve V1.
  - g. Have vehicle operator move the EJECTOR CONTROL lever forward and backward. Ensure that the ejector does not move. (This indicates that valve V1 has closed.)
  - h. Push the RESET VALVE button on the HDC Control Box and verify all the valves are set to the power OFF setting and are in the default position as shown in Table 1.
17. When the Functional Check-Out is complete, proceed to use the HDC system as an aid to troubleshoot a problem with the vehicle hydraulic system or shut down the vehicle per TM 5-2350-262-10 and stow the HDC Control Box and umbilical cable W4.

**Table 2. HDC System Solenoid Valve Definition.**

VALVE NO.	ELECTRICAL MATING CONNECTOR	PHYSICAL LOCATION	DEFINITION	CIRCUIT/PORT	NOTES
V1	W2P1	Primary Manifold	Ejector Control Extend	21	Shutoff Valve (Normally Open)
V2	W3P2	Forward Right Manifold	No. 1 Actuator, Right Suspension Port 11	11/11A	Shutoff Valve (Normally Open)
V3	W3P3	Forward Left Manifold	No 1. Actuator, Left Suspension Port 11	11/11A	Shutoff Valve (Normally Open)
V4	W3P4	Aft Manifold	No. 4 Actuator, Left Suspension Port 9	9	Shutoff Valve (Normally Open)
V5	W2P5	Primary Manifold	Right Hand Suspension Lower	17R	Three-Way Valve

**Table 2. HDC System Solenoid Valve Definition - Continued.**

VALVE NO.	ELECTRICAL MATING CONNECTOR	PHYSICAL LOCATION	DEFINITION	CIRCUIT/PORT	NOTES
V6	W3P6	Aft Manifold	No. 4 Actuator, Left Suspension Port 2	2	Shutoff Valve (Normally Open)
V7	W3P7	Aft Manifold	No. 3 Actuator, Left Suspension Port 2	2A/2	Shutoff Valve (Normally Open)
V8	W3P8	Aft Manifold	No. 4 Actuator, Left Suspension Port 11	11	Shutoff Valve (Normally Open)
V9	W3P9	Forward Left Manifold	Left Bump Stop Cylinder Extend	11/11B	Shutoff Valve (Normally Open)
V10	W3P10	Forward Right Manifold	Right Bump Stop Cylinder Extend	11/11B	Shutoff Valve (Normally Open)
V11	W2P11	Primary Manifold	Left Hand Suspension Lower	17L/7	Three-Way Valve
V12	W2P12	Primary Manifold	Suspension Relief Valve Port 9	9	Shutoff Valve (Normally Open)
V13	W2P13	Primary Manifold	Suspension Relief Valve, Main Accumulator	9A	Shutoff Valve (Normally Open)
V14	W2P14	Primary Manifold	Winch Control Shutoff	C2	Three-Way Valve
V15	W2P15	Primary Manifold	Right Hand Suspension Raise	3R	Three-Way Valve
V16	W2P16	Primary Manifold	Left Hand Suspension Raise	3L	Three-Way Valve
V17	W2P17	Primary Manifold	Apron Cylinder Retract (Raise)	19	Three-Way Valve
V18	W3P18	Aft Manifold	No. 4 Actuator, Left Suspension Port 9 to Port 2		Shutoff Valve (Normally Open)

**Table 2. HDC System Solenoid Valve Definition - Continued.**

VALVE NO.	ELECTRICAL MATING CONNECTOR	PHYSICAL LOCATION	DEFINITION	CIRCUIT/PORT	NOTES
V19	W2P19	Primary Manifold	Suspension Relief Valve Port 17R	17R	Shutoff Valve (Normally Closed)
V20	W2P20	Primary Manifold	Ejector Cylinder Extend to Main Accumulator	9A	Shutoff Valve (Normally Closed)

**Table 3. HDC System Pressure Transducers.**

TRANSDUCER NO.	ELECTRICAL MATING CONNECTOR	PHYSICAL LOCATION	DEFINITION
T1	W2P31	Primary Manifold	Shared
T2	W2P2	Primary Manifold	Ejector Control Valve Extend Pressure
T3	W2P3	Near Left Main Pump Filter	Right Main Hydraulic Pressure
T4	W2P4	Near Right Main Pump Filter	Left Main Hydraulic Pressure
T5	W3P5	Forward Right Actuator #1	#1 Actuator, Right Suspension Port 3 Pressure
T6	W3P31	Forward Left Actuator #1	#1 Actuator, Left Suspension Port 3 Pressure
T7	W2P7	Left Main Manifold	Left Manifold Port 9 Pressure
T8	W3P33	Right Side Underneath Sprung Stop Cylinder	Right Bump Stop Cylinder Retract Pressure
T9	W3P32	Left Side Underneath Sprung Stop Cylinder	Left Bump Stop Cylinder Retract Pressure
T10	W3P30	Forward Left Manifold	Left Bump Stop Cylinder Extend Pressure
T11	W3P11	Forward Right Manifold	Right Bump Stop Cylinder Extend Pressure

**Table 3. HDC System Pressure Transducers - Continued.**

<b>TRANSDUCER NO.</b>	<b>ELECTRICAL MATING CONNECTOR</b>	<b>PHYSICAL LOCATION</b>	<b>DEFINITION</b>
T12	W2P30	Near Suspension (Sprung/ Unsprung) Valve	Sprung/Unsprung Control Valve Port 11 Pressure
T13	W2P32	Primary Manifold	Suspension Relief Valve Pressure



Figure 3. Hydraulic Diagnostic Center (HDC) Control Box Connectors - Pin Designation Signal Names/Identification.

Connector J1: Mates with Umbilical Cable Connector W4P1								
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description	Comments
A	16	HDC Control Box Power		Vehicle 15A Circuit Breaker	HDC Control Box	1070	18 - 32VDC per MIL-STD-1275, 10A Maximum	The maximum current rating includes the 4 spare transducers and 4 valves turned 'ON' simultaneously.
B	16	HDC Control Box Power Return		Vehicle Ground Connection	HDC Control Box	1069	24VDC Ground	
C	16	Spare						

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
A	20	Spare Shutoff Valve Power 1		HDC Control Box			18 - 32VDC per MIL-STD-1275
B	20	Spare Shutoff Valve Power Return 1		HDC Control Box			18 - 32VDC per MIL-STD-1275 Power Return
C	20	Spare Shutoff Valve Power 2		HDC Control Box			18 - 32VDC per MIL-STD-1275
D	20	Spare Shutoff Valve Power Return 2		HDC Control Box			18 - 32VDC per MIL-STD-1275 Power Return
E	20	Spare Shutoff Valve Power 3		HDC Control Box			18 - 32VDC per MIL-STD-1275
F	20	Spare Shutoff Valve Power Return 3		HDC Control Box			18 - 32VDC per MIL-STD-1275 Power Return

M0055HDC

Figure 4. Hydraulic Diagnostic Center (HDC) Control Box Connectors - Pin Designation Signal Names/Identification.

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
G	20	Spare Shutoff Valve Power 4		HDC Control Box			18 - 32VDC per MIL-STD-1275
H	20	Spare Shutoff Valve Power Return 4		HDC Control Box			18 - 32VDC per MIL-STD-1275 Power Return
J	20	Spare					
K	20	Spare					
L	20	Spare					
M	20	Spare					
N	20	Spare					
P	20	Ejector Control Extend Shutoff Valve Power	V1	HDC Control Box	Ejector Control Extend Shutoff Valve	1029	18 - 32VDC per MIL-STD-1275
R	20	Ejector Control Extend Shutoff Valve Power Return	V1	HDC Control Box	Ejector Control Extend Shutoff Valve	1030	18 - 32VDC per MIL-STD-1275 Power Return
S	20	Right Suspension Port 11 Shutoff Valve No. 1 Actuator Power	V2	HDC Control Box	Right Suspension Port 11 Shutoff Valve No. 1 Actuator	1031	18 - 32VDC per MIL-STD-1275
T	20	Right Suspension Port 11 Shutoff Valve No. 1 Actuator Power Return	V2	HDC Control Box	Right Suspension Port 11 Shutoff Valve No. 1 Actuator	1032	18 - 32VDC per MIL-STD-1275 Power Return
U	20	Left Suspension Port 11 Shutoff Valve No. 1 Actuator Power	V3	HDC Control Box	Left Suspension Port 11 Shutoff Valve No. 1 Actuator	1033	18 - 32VDC per MIL-STD-1275

M0056HDC

Figure 5. Hydraulic Diagnostic Center (HDC) Control Box Connectors - Pin Designation Signal Names/Identification.

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
V	20	Left Suspension Port 11 Shutoff Valve No. 1 Actuator Power Return	V3	HDC Control Box	Left Suspension Port 11 Shutoff Valve No. 1 Actuator	1034	18 - 32VDC per MIL-STD-1275 Power Return
W	20	Left Suspension Port 9 Shutoff Valve No. 4 Actuator Power	V4	HDC Control Box	Left Suspension Port 9 Shutoff Valve No. 4 Actuator	1035	18 - 32VDC per MIL-STD-1275
X	20	Left Suspension Port 9 Shutoff Valve No. 4 Actuator Power Return	V4	HDC Control Box	Left Suspension Port 9 Shutoff Valve No. 4 Actuator	1036	18 - 32VDC per MIL-STD-1275 Power Return
Y	20	Right Hand Suspension Lower Shutoff Valve Power	V5	HDC Control Box	Right Hand Suspension Lower Shutoff	1037	18 - 32VDC per MIL-STD-1275
Z	20	Right Hand Suspension Lower Shutoff Valve Power Return	V5	HDC Control Box	Right Hand Suspension Lower Shutoff	1038	18 - 32VDC per MIL-STD-1275 Power Return
a	20	Left Suspension Port 2 Shutoff Valve No. 4 Actuator Power	V6	HDC Control Box	Left Suspension Port 2 Shutoff Valve No. 4 Actuator	1039	18 - 32VDC per MIL-STD-1275
b	20	Left Suspension Port 2 Shutoff Valve No. 4 Actuator Power Return	V6	HDC Control Box	Left Suspension Port 2 Shutoff Valve No. 4 Actuator	1040	18 - 32VDC per MIL-STD-1275 Power Return
c	20	Left Suspension Port 2 Shutoff Valve No. 3 Actuator Power	V7	HDC Control Box	Left Suspension Port 2 Shutoff Valve No. 3 Actuator	1041	18 - 32VDC per MIL-STD-1275

M0057HDC

Figure 6. Hydraulic Diagnostic Center (HDC) Control Box Connectors - Pin Designation Signal Names/Identification.

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
d	20	Left Suspension Port 2 Shutoff Valve No. 3 Actuator Power Return	V7	HDC Control Box	Left Suspension Port 2 Shutoff Valve No. 3 Actuator	1042	18 - 32VDC per MIL-STD-1275 Power Return
e	20	Left Suspension Port 11 Shutoff Valve No. 4 Actuator Power	V8	HDC Control Box	Left Suspension Port 11 Shutoff Valve No. 4 Actuator	1043	18 - 32VDC per MIL-STD-1275
f	20	Left Suspension Port 11 Shutoff Valve No. 4 Actuator Power Return	V8	HDC Control Box	Left Suspension Port 11 Shutoff Valve No. 4 Actuator	1044	18 - 32VDC per MIL-STD-1275 Power Return
g	20	Left Bump Stop Cylinder Extend Shutoff Valve Power	V9	HDC Control Box	Left Bump Stop Cylinder Extend Shutoff Valve	1045	18 - 32VDC per MIL-STD-1275
h	20	Left Bump Stop Cylinder Extend Shutoff Valve Power Return	V9	HDC Control Box	Left Bump Stop Cylinder Extend Shutoff Valve	1046	18 - 32VDC per MIL-STD-1275 Power Return
k	20	Right Bump Stop Cylinder Extend Shutoff Valve Power	V10	HDC Control Box	Right Bump Stop Cylinder Extend Shutoff Valve	1047	18 - 32VDC per MIL-STD-1275
m	20	Right Bump Stop Cylinder Extend Shutoff Valve Power Return	V10	HDC Control Box	Right Bump Stop Cylinder Extend Shutoff Valve	1048	18 - 32VDC per MIL-STD-1275 Power Return
n	20	Left Hand Suspension Lower Shutoff Valve Power	V11	HDC Control Box	Left Hand Suspension Lower Shutoff Valve	1049	18 - 32VDC per MIL-STD-1275

M0058HDC

Figure 7. Hydraulic Diagnostic Center (HDC) Control Box Connectors - Pin Designation Signal Names/Identification.

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
p	20	Left Hand Suspension Lower Shutoff Valve Power Return	V11	HDC Control Box	Left Hand Suspension Lower Shutoff Valve	1050	18 - 32VDC per MIL-STD-1275 Power Return
q	20	Suspension Relief Valve Port 9 Shutoff Valve Power	V12	HDC Control Box	Suspension Relief Valve Port 9 Shutoff Valve	1051	18 - 32VDC per MIL-STD-1275
r	20	Suspension Relief Valve Port 9 Shutoff Valve Power Return	V12	HDC Control Box	Suspension Relief Valve Port 9 Shutoff Valve	1052	18 - 32VDC per MIL-STD-1275 Power Return
s	20	Suspension Relief Valve - Main Accumulator Shutoff Valve Power	V13	HDC Control Box	Suspension Relief Valve - Main Accumulator Shutoff Valve	1053	18 - 32VDC per MIL-STD-1275
t	20	Suspension Relief Valve - Main Accumulator Shutoff Valve Power Return	V13	HDC Control Box	Suspension Relief Valve - Main Accumulator Shutoff Valve	1054	18 - 32VDC per MIL-STD-1275 Power Return
u	20	Winch Control Shutoff Valve Power	V14	HDC Control Box	Winch Control Shutoff Valve	1055	18 - 32VDC per MIL-STD-1275
v	20	Winch Control Shutoff Valve Power Return	V14	HDC Control Box	Winch Control Shutoff Valve	1056	18 - 32VDC per MIL-STD-1275 Power Return

M0059HDC

Figure 8. Hydraulic Diagnostic Center (HDC) Control Box Connectors - Pin Designation Signal Names/Identification.

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
w	20	Right Hand Suspension Raise Shutoff Valve Power	V15	HDC Control Box	Right Hand Suspension Raise Shutoff Valve	1057	18 - 32VDC per MIL-STD-1275
x	20	Right Hand Suspension Raise Shutoff Valve Power Return	V15	HDC Control Box	Right Hand Suspension Raise Shutoff Valve	1058	18 - 32VDC per MIL-STD-1275 Power Return
y	20	Left Hand Suspension Raise Shutoff Valve Power	V16	HDC Control Box	Left Hand Suspension Raise Shutoff Valve	1059	18 - 32VDC per MIL-STD-1275
z	20	Left Hand Suspension Raise Shutoff Valve Power Return	V16	HDC Control Box	Left Hand Suspension Raise Shutoff Valve	1060	18 - 32VDC per MIL-STD-1275 Power Return
AA	20	Apron Cylinder Retract Shutoff Valve Power	V17	HDC Control Box	Apron Cylinder Retract Shutoff Valve	1061	18 - 32VDC per MIL-STD-1275
BB	20	Apron Cylinder Retract Shutoff Valve Power Return	V17	HDC Control Box	Apron Cylinder Retract Shutoff Valve	1062	18 - 32VDC per MIL-STD-1275 Power Return
CC	20	Left Suspension Port 9 to Port 2 Shutoff Valve No. 4 Actuator Power	V18	HDC Control Box	Valve Left Suspension Port 9 to Port 2 Shutoff Valve No. 4 Actuator	1063	18 - 32VDC per MIL-STD-1275
DD	20	Left Suspension Port 9 to Port 2 Shutoff Valve No. 4 Actuator Power Return	V18	HDC Control Box	Valve Left Suspension Port 9 to Port 2 Shutoff Valve No. 4 Actuator	1064	18 - 32VDC per MIL-STD-1275 Power Return

M0060HDC

Figure 9. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.

Connector J2: Mates with Umbilical Cable Connector W4P2							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
EE	20	Suspension Relief Valve Port 17R Shutoff Valve Power	V19	HDC Control Box	Suspension Relief Valve Port 17R Shutoff Valve	1065	18 - 32VDC per MIL-STD-1275
FF	20	Suspension Relief Valve Port 17R Shutoff Valve Power Return	V19	HDC Control Box	Suspension Relief Valve Port 17R Shutoff Valve	1066	18 - 32VDC per MIL-STD-1275 Power Return
GG	20	Ejector Cylinder Extend to Main Accumulator Shutoff Valve Power	V20	HDC Control Box	Ejector Cylinder Extend to Main Accumulator Shutoff Valve	1067	18 - 32VDC per MIL-STD-1275
HH	20	Ejector Cylinder Extend to Main Accumulator Shutoff Valve Power Return	V20	HDC Control Box	Ejector Cylinder Extend to Main Accumulator Shutoff Valve	1068	18 - 32VDC per MIL-STD-1275 Power Return

Connector J3: Mates with Umbilical Cable Connector W4P3							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
A	20	Spare Transducer Signal Output 1		Pressure Transducer	HDC Control Box		0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
B	20	Spare Transducer Signal Output Return 1		HDC Control Box	Pressure Transducer		HDC Control Box Signal Output Return
C	20	Spare Transducer Signal Output 2		Pressure Transducer	HDC Control Box		0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
D	20	Spare Transducer Signal Output Return 2		HDC Control Box	Pressure Transducer		HDC Control Box Signal Output Return
E	20	Spare Transducer Signal Output 3		Pressure Transducer	HDC Control Box		0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG

M0061HDC

Figure 10. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/ Identification.

Connector J3: Mates with Umbilical Cable Connector W4P3							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
F	20	Spare Transducer Signal Output Return 3		HDC Control Box	Pressure Transducer		HDC Control Box Signal Output Return
G	20	Spare Transducer Signal Output 4		Pressure Transducer	HDC Control Box		0.5VDC - 0 PSIG 9.5VDC - 4000 PSIG
H	20	Spare Transducer Signal Output Return 4		HDC Control Box	Pressure Transducer		HDC Control Box Signal Output Return
J	20	CANH		HDC Control Box			
K	20	CANL		HDC Control Box			
L	20	CAN BUS SHIELD		HDC Control Box			
M	20	Spare					
N	20	Spare					
P	20	Spare					
R	20	Spare					
S	20	Shared Transducer Signal Output Function Utilizing Shared Transducer: Right Hand Suspension Raise Pressure Apron Cylinder Retract Pressure Right Hand Suspension Lower Pressure Left Hand Suspension Lower Pressure	T1	Pressure Transducer	HDC Control Box	1000	0.5VDC - 0 PSIG 9.5VDC - 4000 PSIG

M0062HDC



Connector J3: Mates with Umbilical Cable Connector W4P3							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
S (cont)	20	Winch Control Pressure Left Hand Suspension Raise Pressure	T1	Pressure Transducer	HDC Control Box	1000	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
T	20	Shared Transducer Signal Output Return	T1	HDC Control Box	Pressure Transducer	1001	HDC Control Box Signal Output Return
U	20	Ejector Control Valve Extend Pressure Signal Output	T2	Pressure Transducer	HDC Control Box	1002	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
V	20	Ejector Control Valve Extend Pressure Signal Output Return	T2	HDC Control Box	Pressure Transducer	1003	HDC Control Box Signal Output Return
W	20	Right Main Hydraulic Pressure Signal Output	T3	Pressure Transducer	HDC Control Box	1004	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
X	20	Right Main Hydraulic Pressure Signal Output Return	T3	HDC Control Box	Pressure Transducer	1005	HDC Control Box Signal Output Return
Y	20	Left Main Hydraulic Pressure Signal Output	T4	Pressure Transducer	HDC Control Box	1006	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
Z	20	Left Main Hydraulic Pressure Signal Output Return	T4	HDC Control Box	Pressure Transducer	1007	HDC Control Box Signal Output Return
a	20	Right Suspension Port 3 Pressure No. 1 Actuator Signal Output	T5	Pressure Transducer	HDC Control Box	1008	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
b	20	Right Suspension Port 3 Pressure No. 1 Actuator Signal Output Return	T5	HDC Control Box	Pressure Transducer	1009	HDC Control Box Signal Output Return
c	20	Left Suspension Port 3 Pressure No. 1 Actuator Signal Output	T6	Pressure Transducer	HDC Control Box	1010	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG

M0063HDC

Figure 11. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/Identification.

Figure 12. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/ Identification.

Connector J3: Mates with Umbilical Cable Connector W4P3							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
d	20	Left Suspension Port 3 Pressure No. 1 Actuator Signal Output Return	T6	HDC Control Box	Pressure Transducer	1011	HDC Control Box Signal Output Return
e	20	Left Manifold Port 9 Pressure Signal Output	T7	Pressure Transducer	HDC Control Box	1012	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
f	20	Left Manifold Port 9 Pressure Signal Output Return	T7	HDC Control Box	Pressure Transducer	1013	HDC Control Box Signal Output Return
g	20	Right Bump Stop Cylinder Retract Pressure Signal Out	T8	Pressure Transducer	HDC Control Box	1014	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
h	20	Right Bump Stop Cylinder Retract Pressure Signal Output Return	T8	HDC Control Box	Pressure Transducer	1015	HDC Control Box Signal Output Return
k	20	Left Bump Stop Cylinder Retract Pressure Signal Output	T9	Pressure Transducer	HDC Control Box	1016	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
m	20	Left Bump Stop Cylinder Retract Pressure Signal Output Return	T9	HDC Control Box	Pressure Transducer	1017	HDC Control Box Signal Output Return
n	20	Left Bump Stop Cylinder Extend Pressure Signal Output	T10	Pressure Transducer	HDC Control Box	1018	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
p	20	Left Bump Stop Cylinder Extend Pressure Signal Output Return	T10	HDC Control Box	Pressure Transducer	1019	HDC Control Box Signal Output Return
q	20	Right Bump Stop Cylinder Extend Pressure Signal Output	T11	Pressure Transducer	HDC Control Box	1020	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
r	20	Right Bump Stop Cylinder Extend Pressure Signal Output Return	T11	HDC Control Box	Pressure Transducer	1021	HDC Control Box Signal Output Return

M0064HDC

Figure 13. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/ Identification.

Connector J3: Mates with Umbilical Cable Connector W4P3							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
s	20	Sprung/Unsprung Control Valve Port 11 Pressure Signal Output	T12	Pressure Transducer	HDC Control Box	1022	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
t	20	Sprung/Unsprung Control Valve Port 11 Pressure Signal Output Return	T12	HDC Control Box	Pressure Transducer	1023	HDC Control Box Signal Output Return
u	20	Suspension Relief Valve Pressure Signal Output	T13	Pressure Transducer	HDC Control Box	1024	0.5 VDC - 0 PSIG 9.5 VDC - 4000 PSIG
v	20	Suspension Relief Valve Pressure Signal Output Return	T13	HDC Control Box	Pressure Transducer	1025	HDC Control Box Signal Output Return
w	20	Pressure Transducer Excitation (+)		HDC Control Box	Pressure Transducer	1026A	15VDC +/- 0.5VDC, Ripple and Noise: 200 mVpk - pk
x	20	Pressure Transducer Excitation (-)		HDC Control Box	Pressure Transducer	1027A	HDC Control Box Pressure Transducer Power Return
y	20	Pressure Transducer Excitation (+)		HDC Control Box	Pressure Transducer	1026B	15VDC +/- 0.5VDC, Ripple and Noise: 200 mVpk - pk
z	20	Pressure Transducer Excitation (-)		HDC Control Box	Pressure Transducer	1027B	HDC Control Box Pressure Transducer Power Return
AA	20	Pressure Transducer Excitation (+)		HDC Control Box	Pressure Transducer	1026C	15VDC +/- 0.5VDC, Ripple and Noise: 200 mVpk - pk
BB	20	Pressure Transducer Excitation (-)		HDC Control Box	Pressure Transducer	1027C	HDC Control Box Pressure Transducer Power Return
CC	20	Pressure Transducer Excitation (+)		HDC Control Box	Pressure Transducer	1026D	15VDC +/- 0.5VDC, Ripple and Noise: 200 mVpk - pk

M0065HDC

Connector J3: Mates with Umbilical Cable Connector W4P3							
Pin Number	AWG	Signal Name Description	Reference Designator	Signal Source	Signal Designation	Signal Circuit No.	Signal Description
DD	20	Pressure Transducer Excitation (-)		HDC Control Box	Pressure Transducer	1027D	HDC Control Box Pressure Transducer Power Return
EE	20	Signal Output Shield		HDC Control Box	Pressure Transducer	1028A	HDC Control Box Signal Output Shield (Chassis Ground)
FF	20	Signal Output Shield		HDC Control Box	Pressure Transducer	1028B	HDC Control Box Signal Output Shield (Chassis Ground)
GG	20	Signal Output Shield		HDC Control Box	Pressure Transducer	1028C	HDC Control Box Signal Output Shield (Chassis Ground)
HH	20	Signal Output Shield		HDC Control Box	Pressure Transducer	1028D	HDC Control Box Signal Output Shield (Chassis Ground)

M0066HDC

Figure 14. Hydraulic Diagnostic Center (HDC) Control Box Connectors-Pin Designation Signal Names/ Identification.

**Table 4. Possible Symptoms Of Failed HDC System Components.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
<p style="text-align: center;"><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• The probability of a stuck solenoid valve is low and would occur after a hydraulic maintenance test is performed where a solenoid valve was energized (to change status) as part of a specific test.</li> <li>• Numbers in parentheses (possible consequences) correspond to vehicle hydraulic line numbers as shown on M9 ACE HDC hydraulic system schematic (FO-1 through FO-3).</li> </ul>	
<p>Solenoid Valve V-1 - Shutoff valve - ejector control valve extend</p>	<ul style="list-style-type: none"> <li>• Cannot extend ejector cylinder or cannot retract ejector cylinder.</li> <li>• Cannot dump load or cannot retract ejector to fill load.</li> <li>• Cannot fold or unfold apron.</li> </ul>
<p>Solenoid Valve V2 - Shutoff valve - No. 1 actuator right front</p>	<p><b>SPRUNG MODE:</b></p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (11) from right front wheel valve.</li> <li>• Wheel valve stays in unsprung position.</li> <li>• No hydraulic fluid supply (9) to right front actuators 1 &amp; 2.</li> <li>• Front right of vehicle will not be raised.</li> <li>• Right front of vehicle will drag or bottom out.</li> <li>• No suspension shock absorbing capability on right front side.</li> </ul> <p><b>UNSPRUNG MODE:</b></p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (11) to right front wheel valve.</li> <li>• Wheel valve stays in sprung position.</li> <li>• No hydraulic fluid return (3) connection from actuators 1 &amp; 2 to DCV.</li> <li>• Undesired hydraulic fluid supply (9) to front right actuators 1 &amp; 2.</li> <li>• Right front of vehicle is raised to sprung position.</li> <li>• Undesired suspension dampening on right front side.</li> </ul> <p><b>UNSPRUNG-LOWER:</b></p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (17) to front right actuator 1.</li> <li>• No hydraulic fluid return (3) from right front actuators 1 &amp; 2.</li> <li>• Front right of vehicle will not be lowered.</li> </ul>

**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
	<p>UNSPRUNG-RAISE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (3) to right front actuators 1 &amp; 2.</li> <li>• No hydraulic fluid return (17) from right front actuators 1 &amp; 2.</li> <li>• Front right of vehicle cannot be raised but is already in sprung/raised position.</li> </ul>
<p>Solenoid Valve V3 - Shutoff valve - No. 1 actuator left front</p>	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (11) from left front wheel valve.</li> <li>• Wheel valve stays in unsprung position.</li> <li>• No hydraulic fluid supply (9) to left front actuators 1 &amp; 2.</li> <li>• Front left of vehicle will not be raised.</li> <li>• No suspension shock absorbing capability on left front side.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (11) to left front wheel valve.</li> <li>• Wheel valve stays in sprung position.</li> <li>• No hydraulic fluid return (3) connection from actuators 1 &amp; 2 to DCV.</li> <li>• Undesired hydraulic fluid supply (9) to front left actuators 1 &amp; 2.</li> <li>• Left front of vehicle is raised to sprung position.</li> <li>• Undesired suspension dampening on left front side.</li> </ul> <p>UNSPRUNG-LOWER:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (17) to front left actuator 1.</li> <li>• No hydraulic fluid return (3) from left front actuators 1 &amp; 2.</li> <li>• Front left of vehicle will not be lowered.</li> </ul> <p>UNSPRUNG-RAISE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (3) to left front actuators 1 &amp; 2.</li> <li>• No hydraulic fluid return (17) from left front actuators 1 &amp; 2.</li> <li>• Front left of vehicle cannot be raised but is already in sprung/raised position.</li> </ul>

**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
<p>Solenoid Valve V4 - Shutoff valve - No. 4 left actuator port 9</p>	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (9) to left rear wheel valve.</li> <li>• Wheel valve in unsprung position.</li> <li>• No hydraulic fluid supply (9) to left rear actuators 3 &amp; 4.</li> <li>• Rear left of vehicle will not be raised.</li> <li>• Left rear of vehicle will drag or bottom out.</li> <li>• No suspension shock absorbing capability on rear left side.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (9) to left and right rear wheel valves.</li> <li>• No hydraulic fluid supply to left actuators 3 &amp; 4 and right actuators 3 &amp; 4.</li> <li>• Rear of vehicle will not be raised.</li> </ul>
<p>Solenoid Valve V5 - Shutoff valve - right hand suspension</p>	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (17).</li> <li>• Delay in intermediate valve operation.</li> <li>• Delay in raising right front side.</li> </ul> <p>UNSPRUNG MODE-LOWER:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (17 lower) to intermediate wheel control valve.</li> <li>• No hydraulic fluid supply (17) to right front actuator 1.</li> <li>• Inability to completely lower right front side of vehicle.</li> </ul> <p>UNSPRUNG MODE-RAISE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (17) from right front actuator 1 &amp; 2.</li> <li>• Hydraulic fluid will return through (7).</li> </ul>

**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
Solenoid Valve V6 - Shutoff valve - No. 3 left actuator	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (9) to left rear intermediate actuator 3.</li> <li>• Rear left of vehicle partially raised.</li> <li>• Left rear of vehicle will bottom out.</li> <li>• Possible vehicle damage.</li> <li>• Partial suspension shock absorbing capability on rear left side.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (9) to left rear intermediate actuator 3.</li> <li>• Rear left of vehicle will only be partially raised.</li> </ul>
Solenoid Valve V7 - Shutoff valve - No. 3 actuator, left suspension port 2	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (9) to left rear intermediate actuator 3.</li> <li>• Rear left of vehicle partially raised.</li> <li>• Left rear of vehicle will bottom out.</li> <li>• Partial suspension shock absorbing capability on rear left side.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (9) to left rear intermediate actuator 3.</li> <li>• Rear left of vehicle will only be partially raised.</li> </ul>
Solenoid Valve V8 - Shutoff valve - No. 4 left actuator	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (11) from left rear wheel valve.</li> <li>• Wheel valve in unsprung position.</li> <li>• No suspension shock absorbing capability on rear left side.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (11) to left rear wheel valve.</li> <li>• Wheel valve in sprung position.</li> <li>• Undesired suspension shock absorbing capability on rear left side.</li> <li>• Right rear actuators maintain position or lower.</li> <li>• Rear actuators maintain sprung position.</li> </ul>
Solenoid Valve V9 - Shutoff valve - Front left bump stop extend	<p>SPRUNG MODE:</p>



**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
	<ul style="list-style-type: none"> <li>• No hydraulic fluid return (11) from left side spring stop cylinder (extend).</li> <li>• Left front wheel road arm upper travel not limited.</li> <li>• Suspension can bottom out.</li> <li>• Track may be thrown if vehicle is backed.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (11) to left side stop cylinder (retract).</li> <li>• Left front wheel road arm upper travel limited.</li> <li>• Left front of vehicle cannot be lowered to doze or scrape.</li> </ul>
<p>Solenoid Valve V10 - Shutoff valve - Front right bump stop extend</p>	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (11) from right side spring stop cylinder (extend).</li> <li>• Right front wheel road arm upper travel not limited.</li> <li>• Suspension can bottom out.</li> <li>• Track may be thrown if vehicle is backed.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (11) to right side stop cylinder (retract).</li> <li>• Right front wheel road upper arm travel limited.</li> <li>• Right front of vehicle cannot be lowered to doze or scrape.</li> </ul>
<p>Solenoid Valve V11 - Shutoff valve - Left hand suspension lower</p>	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• No impact.</li> </ul> <p>UNSPRUNG MODE-LOWER:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (17 lower) to intermediate wheel control valve.</li> <li>• No hydraulic fluid supply (17) to left front actuator 1.</li> <li>• Inability to completely lower left front side of vehicle.</li> <li>• Degraded dozing and scraping.</li> </ul> <p>UNSPRUNG MODE-RAISE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (17) from left front actuators 1 &amp; 2.</li> <li>• Hydraulic fluid will return through (7).</li> </ul>

**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
Solenoid Valve V12 - Shutoff valve - Suspension relief valve port 9	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Inability to charge main accumulator.</li> <li>• Delayed response in suspension adjustment if compensating pump cannot keep up with system demand.</li> <li>• Relief valve inactive.</li> <li>• Possible hydraulic system damage if compensating pump fails to regulate pressure.</li> </ul>
Solenoid Valve V13 - Shutoff valve - Suspension relief valve, main accumulator	<p>SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Inability to charge main accumulator.</li> <li>• Delayed response in suspension adjustment if compensating pump cannot keep up with system demand.</li> </ul>
Solenoid Valve V14 - Shutoff valve - Winch control valve	<ul style="list-style-type: none"> <li>• Cannot supply hydraulic fluid to, or return fluid from, winch motor.</li> <li>• Cannot pay out or pay in winch.</li> </ul>
Solenoid Valve V15 - Shutoff valve - Right hand suspension raise/lower relief	<p>UNSPRUNG MODE-RAISE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (3) to right front actuators 1 &amp; 2 through right front wheel valve.</li> <li>• Right front of vehicle cannot be raised (was raised in sprung mode and now supply is cut off and cannot get 3500 psi [24131.65 kPa] pressure.)</li> </ul> <p>UNSPRUNG MODE-LOWER:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid return (3) from front actuators 1 &amp; 2 through right front wheel valve.</li> <li>• Cannot lower right front of vehicle.</li> <li>• Cannot doze or fill load evenly.</li> </ul>
Solenoid Valve V16 - Shutoff valve - Left hand suspension raise/lower relief	<p>UNSPRUNG MODE-RAISE:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (3) to left front actuators 1 &amp; 2 through left front wheel valve.</li> <li>• Cannot raise left front of vehicle (was raised in sprung mode and now supply is cut off and cannot get 3500 psi [24131.65 kPa] pressure.)</li> </ul> <p>UNSPRUNG MODE-LOWER:</p> <ul style="list-style-type: none"> <li>• No hydraulic fluid supply (3) from front actuators 1 &amp; 2 through left front wheel valve.</li> <li>• Cannot lower left front of vehicle.</li> <li>• Degraded dozing or scraping capability.</li> </ul>

**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
Solenoid Valve V17 - Shutoff valve - Apron retract	<ul style="list-style-type: none"> <li>• No hydraulic fluid supply going to (raise) or from (lower) apron cylinders.</li> <li>• Apron cannot be raised or lowered.</li> <li>• Cannot unload or cannot retain load in bowl.</li> </ul>
Solenoid Valve V18 - Shutoff valve - No. 4 actuator, left suspension port 9 to port 2 (normally closed)	<p>STUCK OPEN SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Compensating pressure continuously supplied to left rear actuators 3 &amp; 4.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Compensating pressure at 2850 psi (19650.06 kPa) continuously supplied to left rear actuators 3 &amp; 4 and right rear actuators 3 &amp; 4. If this is normal pressure in unsprung mode, there is no impact.</li> </ul>
Solenoid Valve V19 - Shutoff valve - Suspension relief valve port 17R (normally closed)	<p>STUCK OPEN SPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Compensating pump pressure is directed to reservoir return.</li> <li>• No hydraulic fluid supply (9) to wheel valves.</li> <li>• No hydraulic fluid supply (9) to actuators.</li> <li>• Vehicle will not be raised.</li> <li>• Track may be thrown if vehicle is backed.</li> <li>• No suspension shock absorbing capability.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Main accumulator/compensating pump pressure is directed to right front intermediate control valve.</li> <li>• Main accumulator pressure is directed to right front actuator lower side.</li> <li>• No vehicle change in height since raise side pressure is trapped.</li> </ul> <p>UNSPRUNG MODE-LOWER:</p> <ul style="list-style-type: none"> <li>• No impact.</li> </ul> <p>UNSPRUNG MODE-RAISE:</p> <ul style="list-style-type: none"> <li>• Hydraulic fluid supply is directed to return.</li> </ul>

**Table 4. Possible Symptoms Of Failed HDC System Components - Continued.**

HDC SYSTEM	POSSIBLE CONSEQUENCES
Solenoid Valve V20 - Shutoff valve - Ejector cylinder extend to main accumulator (normally closed)	<p>STUCK OPEN:</p> <ul style="list-style-type: none"> <li>• Undesired compensating pressure on ejector cylinder extend.</li> <li>• Ejector will slowly extend due to leakage.</li> </ul> <p>UNSPRUNG MODE:</p> <ul style="list-style-type: none"> <li>• Maximum suspension pressure 2000 psi (13789.51 kPa).</li> <li>• Vehicle cannot be fully raised.</li> </ul>
Solenoid Valve V21 - Shutoff valve - (manual)	<ul style="list-style-type: none"> <li>• No hydraulic fluid supply to 5/15 micron filters, suspension, apron, winch, main ejector from one side of main pump.</li> <li>• Main pump output is cut off on one side, no flow.</li> </ul>
Solenoid Valve V22 - Shutoff valve - (manual)	<ul style="list-style-type: none"> <li>• No hydraulic fluid supply to main pump filters, suspension, winch, main ejector, apron from one side of main pump.</li> <li>• Main pump output is cut off on one side, no flow.</li> </ul>
Solenoid Valve V23 - Shutoff valve - (manual)	<ul style="list-style-type: none"> <li>• Cannot extend ejector cylinder or cannot retract ejector cylinder.</li> <li>• Cannot dump load or cannot retract ejector to fill load.</li> <li>• Cannot fold dozer blade.</li> </ul>

**END OF TASK**

**END OF WORK PACKAGE**

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) STOWAGE BRACKET REPLACEMENT**

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
 (WP 0054, Table 1, Item 7)

**Equipment Condition (cont.)**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
 Operator's seat forward (TM 5-2350-262-10)

**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

HDC distribution box removed (WP 0004)

**REMOVAL**

1. Loosen two jam nuts (Figure 1, Item 2) on two threaded rods (Figure 1, Item 1) at compartment bulkhead.
2. Remove two threaded rods (Figure 1, Item 1), two washers (Figure 1, Item 3), and stowage bracket (Figure 1, Item 4) from compartment bulkhead.




Figure 1. Hydraulic Diagnostic Center (HDC) Stowage Bracket Removal.

**END OF TASK**

**INSTALLATION**

1. Install stowage bracket (Figure 2, Item 4) with two washers (Figure 2, Item 3) and two threaded rods (Figure 2, Item 1) onto compartment bulkhead.
2. Tighten two jam nuts (Figure 2, Item 2) against bulkhead to secure two threaded rods (Figure 2, Item 1).




Figure 2. Hydraulic Diagnostic Center (HDC) Stowage Bracket Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Install Hydraulic Diagnostic Center (HDC) distribution box (WP 0004).
2. Return operator's seat to ready position (TM 5-2350-262-10).

**END OF TASK****END OF WORK PACKAGE**

---

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) DISCONNECT BRACKET REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Personnel Required**

Construction Equipment Repairer, 91L

**Materials/Parts**

Bolt, Machine (WP 0055, Table 1, Item 3) Qty: 2  
Washer, Lock (WP 0055, Table 1, Item 22)  
Qty: 2


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

---

## REMOVAL

## WARNING



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Remove dust caps (Figure 1, Item 14) from wiring harness connectors W1J1 (Figure 1, Item 18), W2J1 (Figure 1, Item 19), and W3J1 (Figure 1, Item 4).
2. Remove four screws (Figure 1, Item 16), nutplate (Figure 1, Item 1), and wiring harness connector W1J1 (Figure 1, Item 18) from disconnect bracket (Figure 1, Item 17).
3. Remove four screws (Figure 1, Item 15), nutplate (Figure 1, Item 2), and wiring harness connector W2J1 (Figure 1, Item 19) from disconnect bracket (Figure 1, Item 17).
4. Remove four screws (Figure 1, Item 13), nutplate (Figure 1, Item 3), and wiring harness connector W3J1 (Figure 1, Item 4) from disconnect bracket (Figure 1, Item 17).
5. Disconnect circuit 10 (Figure 1, Item 8) and circuit 1070 (Figure 1, Item 5) connectors from Hydraulic Diagnostic Center (HDC) circuit breaker (Figure 1, Item 11).
6. Remove two nuts (Figure 1, Item 9), two lockwashers (Figure 1, Item 10), two screws (Figure 1, Item 12), and HDC circuit breaker (Figure 1, Item 11) from HDC disconnect bracket (Figure 1, Item 17). Discard lockwashers.
7. Remove two machine bolts (Figure 1, Item 6), two flat washers (Figure 1, Item 7), and disconnect bracket (Figure 1, Item 17) from bulkhead. Discard machine bolts.





Figure 1. Hydraulic Diagnostic Center (HDC) Disconnect Bracket Removal.

END OF TASK



**INSTALLATION**

**WARNING**



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Install disconnect bracket (Figure 2, Item 17) on bulkhead with two flat washers (Figure 2, Item 7) and two new machine bolts (Figure 2, Item 6).
2. Install HDC circuit breaker (Figure 2, Item 11) with two screws (Figure 2, Item 12), two new lockwashers (Figure 2, Item 10), and two nuts (Figure 2, Item 9) to HDC disconnect bracket (Figure 2, Item 17).
3. Connect circuit 1070 (Figure 2, Item 5) and circuit 10 (Figure 2, Item 8) connectors to HDC circuit breaker (Figure 2, Item 11).
4. Connect wiring harness connector W3J1 (Figure 2, Item 4) to disconnect bracket (Figure 2, Item 17) with nutplate (Figure 2, Item 3) and four screws (Figure 2, Item 13).
5. Connect wiring harness connector W2J1 (Figure 2, Item 19) to disconnect bracket (Figure 2, Item 17) with nutplate (Figure 2, Item 2) and four screws (Figure 2, Item 15).
6. Connect wiring harness connector W1J1 (Figure 2, Item 18) to disconnect bracket (Figure 2, Item 17) with nutplate (Figure 2, Item 1) and four screws (Figure 2, Item 16).
7. Install dust caps (Figure 2, Item 14) on wiring harness connectors W3J1 (Figure 2, Item 4), W2J1 (Figure 2, Item 19), and W1J1 (Figure 2, Item 18).




Figure 2. Hydraulic Diagnostic Center (HDC) Disconnect Bracket Installation.

**END OF TASK**

**FOLLOW-ON MAINTENANCE**

Connect negative battery cables (TM 5-2350-262-20).

**END OF TASK**

**END OF WORK PACKAGE**

---

**FIELD MAINTENANCE  
HYDRAULIC DIAGNOSTIC CENTER (HDC) CIRCUIT BREAKER REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Personnel Required**

Construction Equipment Repairer, 91L

**Materials/Parts**

Bolt, Machine (WP 0055, Table 1, Item 3)  
Washer, Lock (WP 0055, Table 1, Item 22)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

---


## REMOVAL

## WARNING



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Remove two machine bolts (Figure 1, Item 2), washers (Figure 1, Item 1), and disconnect bracket (Figure 1, Item 9) from bulkhead. Discard machine bolts.
2. Disconnect circuit 1070 and circuit 10 (Figure 1, Items 3 and 4) from Hydraulic Diagnostic Center (HDC) circuit breaker (Figure 1, Item 7).
3. Remove two nuts (Figure 1, Item 5), lockwashers (Figure 1, Item 6), screws (Figure 1, Item 8), and HDC circuit breaker (Figure 1, Item 7) from HDC disconnect bracket (Figure 1, Item 9). Discard lockwashers.




M0006HDC

Figure 1. Hydraulic Diagnostic Center (HDC) Circuit Breaker Removal.

## END OF TASK

**INSTALLATION**

1. Install HDC circuit breaker (Figure 2, Item 7) on HDC disconnect bracket (Figure 2, Item 9) with two screws (Figure 2, Item 8), new lockwashers (Figure 2, Item 6), and nuts (Figure 2, Item 5).
2. Connect circuit 10 and circuit 1070 connectors (Figure 2, Items 3 and 4) to HDC circuit breaker (Figure 2, Item 7).
3. Install disconnect bracket (Figure 2, Item 9) on bulkhead with two washers (Figure 2, Item 1) and new machine bolts (Figure 2, Item 2).



M0009HDC

Figure 2. Hydraulic Diagnostic Center (HDC) Circuit Breaker Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

Connect negative battery cables (TM 5-2350-262-20).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) POWER COMPONENTS REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Equipment Condition**

Vehicle MASTER power off (TM 5-2350-262-10)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

**Materials/Parts**

Washer, Lock (WP 0055, Table 1, Item 22)


**Personnel Required**

Construction Equipment Repairer, 91L (Two)

---

**REMOVAL**

**WARNING**



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Remove screw (Figure 1, Item 5), lockwasher (Figure 1, Item 4), and lead assembly 1070 (Figure 1, Item 3) from terminal B2 on parking brake relay (Figure 1, Item 2). Discard lockwasher.
2. Remove lead assemblies (Figure 1, Item 6), "Y"-connector (Figure 1, Item 7), and in-line connector (Figure 1, Item 8) from trailer receptacle and trouble light circuit breaker (Figure 1, Item 1) located behind operator's compartment switch and gauge panel.




Figure 1. Hydraulic Diagnostic Center (HDC) Power Distribution Components Removal.

**END OF TASK**



**INSTALLATION**

1. Install in-line connector (Figure 2, Item 8), "Y"-connector (Figure 2, Item 7), and lead assemblies (Figure 2, Item 6) on trailer receptacle and trouble light circuit breaker (Figure 2, Item 1) located behind operator's compartment switch and gauge panel.
2. Install lead assembly 1070 (Figure 2, Item 3) on terminal B2 on parking brake relay (Figure 2, Item 2) with new lockwasher (Figure 2, Item 4) and screw (Figure 2, Item 5).




Figure 2. Hydraulic Diagnostic Center (HDC) Power Distribution Components Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

Connect negative battery cables (TM 5-2350-262-20).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
WIRING HARNESS W1 REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Materials/Parts**

Washer, Lock (WP 0055, Table 1, Item 2) Qty: 1

**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)

---

**Equipment Condition (cont.)**


Apron locked in full-up position  
(TM 5-2350-262-10)

Ejector to front of vehicle (TM 5-2350-262-10)

Negative battery cables disconnected  
(TM 5-2350-262-20)


REMOVAL

WARNING



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Remove screw (Figure 1, Item 1), lockwasher (Figure 1, Item 2), and wiring harness W1 lead 1070 (Figure 1, Item 3) from parking brake relay (Figure 1, Item 4) terminal B1. Discard lockwasher.
2. Remove bolt (Figure 1, Item 10), from the compartment wall above the CBRN filter and remove wiring harness lead 1069 (Figure 1, Item 11).
3. Remove dust cap (Figure 1, Item 8), four screws (Figure 1, Item 6), nutplate (Figure 1, Item 5), and wiring harness W1 connector J1 (Figure 1, Item 9) from Hydraulic Diagnostic Center (HDC) disconnect bracket (Figure 1, Item 7).
4. Pull wiring harness W1 leads 1070 (Figure 1, Item 3) and 1069 (Figure 1, Item 11) through wire clamps and remove wiring harness W1 from vehicle.




M0010HDC

Figure 1. Wiring Harness W1 Removal.

END OF TASK


**INSTALLATION**

**WARNING**



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Thread wiring harness W1 leads 1070 (Figure 2, Item 3) and 1069 (Figure 2, Item 11) through wire clamps to parking brake relay (Figure 2, Item 4) and battery box.
2. Connect wiring harness W1 connector J1 (Figure 2, Item 9) to HDC disconnect bracket (Figure 2, Item 7) with nutplate (Figure 2, Item 5), and four screws (Figure 2, Item 6). Attach dust cap (Figure 2, Item 8) to connector J1.
3. Install wiring harness W1 lead 1069 (Figure 2, Item 11) on compartment wall above the CBRN filter with bolt (Figure 2, Item 10).
4. Install wiring harness W1 lead 1070 (Figure 2, Item 3) on parking brake relay (Figure 2, Item 4) with new lockwasher (Figure 2, Item 2) and screw (Figure 2, Item 1).



M0011HDC

Figure 2. Wiring Harness W1 Installation.

**END OF TASK**

**FOLLOW-ON MAINTENANCE**

1. Return ejector to stowed position (TM 5-2350-262-10).
2. Return apron to stowed position (TM 5-2350-262-10).
3. Connect negative battery cables (TM 5-2350-262-20).

**END OF TASK****END OF WORK PACKAGE**

---

**FIELD MAINTENANCE  
WIRING HARNESS W2 REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)

**Materials/Parts**

Strap, Tiedown, Electrical  
(WP 0053, Table 1, Item 4)

**Equipment Condition (cont.)**

Apron locked in full-up position  
(TM 5-2350-262-10)  
Ejector to front of vehicle (TM 5-2350-262-10)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)

---


REMOVAL

WARNING



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

1. At the main hydraulic pump left and right high-pressure filter area, remove wiring harness W2 connector P3 (Figure 1, Item 6) from transducer T3 (Figure 1, Item 5), wiring harness W2 connector P4 (Figure 1, Item 4) from transducer T4 (Figure 1, Item 3), and wiring harness W2 connector P30 (Figure 1, Item 1) from transducer T12 (Figure 1, Item 2).




M0012HDC

Figure 1. Wiring Harness W2 from Filter Area Removal.



**REMOVAL - Continued**

2. In the vehicle bowl bottom area, remove wiring harness W2 connector P7 (Figure 2, Item 7) from transducer T7 (Figure 2, Item 6) at left main manifold (Figure 2, Item 5).
3. In the vehicle bowl at the Hydraulic Diagnostic Center (HDC) main manifold remove wiring harness W2 connectors as follows: P1, P5, P11, P12, P13, P14, P15, P16, P17, P19, and P20 (Figure 2, Item 4) from valves V1, V5, V11, V12, V13, V14, V15, V16, V17, V18, V19, and V20 (Figure 2, Item 3).
4. In the vehicle bowl at the HDC main manifold remove wiring harness W2 connectors as follows: P2, P31, and P32 (Figure 2, Item 1) from transducers T2, T1, and T13 (Figure 2, Item 2).




M0013HDC

Figure 2. Wiring Harness W2 from Main Manifold Removal.

**REMOVAL - Continued**

5. Remove dust cap (Figure 3, Item 4), four screws (Figure 3, Item 3), nutplate (Figure 3, Item 1), and wiring harness W2 connector J1 (Figure 3, Item 2) from HDC disconnect bracket (Figure 3, Item 5).
6. Cut and remove tie down straps, pull leads through wire clamps, and remove wiring harness from vehicle. Discard tie down straps.



M0014HDC

*Figure 3. Wiring Harness W2 Connector J1 at Disconnect Bracket Removal.*


**END OF TASK**

## INSTALLATION

## WARNING



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
1. Thread wiring harness leads through wire clamps and secure harness with new tie down straps.
  2. Install wiring harness W2 connector J1 (Figure 4, Item 2) to HDC disconnect bracket (Figure 4, Item 5) with nutplate (Figure 4, Item 1), and four screws (Figure 4, Item 3). Attach dust cap (Figure 4, Item 4) to connector J1.




M0015HDC

Figure 4. Wiring Harness W2 Connector J1 at Disconnect Bracket Installation.

**INSTALLATION - Continued**

3. In the vehicle bowl at the HDC main manifold connect wiring harness W2 connectors as follows: P2, P31, and P32 (Figure 5, Item 1) to transducers T2, T1, and T13 (Figure 5, Item 2).
4. In the vehicle bowl at the HDC main manifold connect wiring harness W2 connectors as follows: P1, P5, P11, P12, P13, P14, P15, P16, P17, P19, and P20 (Figure 5, Item 4) to valves V1, V5, V11, V12, V13, V14, V15, V16, V17, V19, and V20 (Figure 5, Item 3).
5. In the vehicle bowl bottom area connect wiring harness W2 connector P7 (Figure 5, Item 7) to transducer T7 (Figure 5, Item 6) at the left main manifold (Figure 5, Item 5).




M0016HDC

Figure 5. Wiring Harness W2 to Main Manifold Installation.

**INSTALLATION - Continued**

6. At the main hydraulic pump left and right high-pressure filter area, connect wiring harness W2 connector P3 (Figure 6, Item 6) to transducer T3 (Figure 6, Item 5), wiring harness W2 connector P4 (Figure 6, Item 4) to transducer T4 (Figure 6, Item 3), and wiring harness W2 connector P30 (Figure 6, Item 1) to transducer T12 (Figure 6, Item 2).



M0017HDC

Figure 6. Wiring Harness W2 to Filter Area Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Connect negative battery cables (TM 5-2350-262-20).
2. Return vehicle ejector to stowed position (TM 5-2350-262-10).
3. Return vehicle apron to stowed position (TM 5-2350-262-10).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
WIRING HARNESS W3 REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Stand, Vehicle Support  
(WP 0054, Table 1, Item 5)

**Materials/Parts**

Strap, Tiedown, Electrical  
(WP 0053, Table 1, Item 4)

**Personnel Required**

Construction Equipment Repairer, 91L


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)

---

**Equipment Condition (cont.)**

Apron locked in full-up position  
(TM 5-2350-262-10)  
Ejector to front of vehicle (TM 5-2350-262-10)  
Hull raised on jack stands (TM 5-2350-262-20)  
Hull access plates removed (TM 5-2350-262-20)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

**REMOVAL****WARNING**

Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Remove dust cap (Figure 1, Item 5), four screws (Figure 1, Item 4), nutplate (Figure 1, Item 1), and wiring harness W3 connector J1 (Figure 1, Item 2) from Hydraulic Diagnostic Center (HDC) disconnect bracket (Figure 1, Item 3).
2. Remove wiring harness W3 connector P5 (Figure 1, Item 7) from transducer T5 (Figure 1, Item 6) at forward right actuator #1 (Figure 1, Item 8).
3. Remove wiring harness W3 connector P31 (Figure 1, Item 10) from transducer T6 (Figure 1, Item 11) at forward left actuator #1 (Figure 1, Item 9).



REMOVAL - Continued





Figure 1. Wiring Harness W3 from Disconnect Bracket and Actuator Area Removal.

**REMOVAL - Continued****WARNING**

Do not work under vehicle unless hull is on jack stands and apron lockpins are installed.  
Failure to comply may result in severe injury or death to personnel.

4. From access under vehicle, remove the following W3 wiring harness connectors from the forward right manifold (Figure 2, Item 21): connector P2 (Figure 2, Item 24) from valve V2 (Figure 2, Item 25), connector P10 (Figure 2, Item 23) from valve V10 (Figure 2, Item 22), and connector P11 (Figure 2, Item 1) from transducer T11 (Figure 2, Item 2).
5. From access under vehicle, remove the following W3 wiring harness connectors from the forward left manifold (Figure 2, Item 9): connector P3 (Figure 2, Item 7) from valve V3 (Figure 2, Item 8), connector P9 (Figure 2, Item 6) from valve V9 (Figure 2, Item 5), and connector P30 (Figure 2, Item 4) from transducer T10 (Figure 2, Item 3).
6. From access under vehicle, remove the following W3 wiring harness connectors from the aft manifold (Figure 2, Item 12): connector P4 (Figure 2, Item 20) from valve V4 (Figure 2, Item 11), connector P6 (Figure 2, Item 14) from valve V6 (Figure 2, Item 13), connector P7 (Figure 2, Item 16) from valve P7 (Figure 2, Item 15), connector P8 (Figure 2, Item 18) from valve V8 (Figure 2, Item 17), and connector P18 (Figure 2, Item 19) from valve V18 (Figure 2, Item 10).

REMOVAL - Continued



M0019HDC

Figure 2. Wiring Harness W3 from Under Vehicle Removal.

**REMOVAL - Continued**

7. Remove wiring harness W3 connector P32 (Figure 3, Item 3) from transducer T9 (Figure 3, Item 2) at left sprung stop cylinder (Figure 3, Item 1).
8. Remove wiring harness W3 connector P33 (Figure 3, Item 6) from transducer T8 (Figure 3, Item 5) at right sprung stop cylinder (Figure 3, Item 4).
9. Remove tie down straps, open cable clamps, and remove wiring harness W3 from vehicle. Discard tie down straps.





Figure 3. Wiring Harness W3 at Actuator Area Removal.

**END OF TASK**


**INSTALLATION**

**WARNING**



Ensure that vehicle power is off and battery disconnected. Remove all jewelry, such as rings, dog tags, bracelets, etc. If jewelry or disconnected battery ground cable contacts battery positive terminal, a direct short will result, causing instant heating of tools, tool damage, battery damage, or battery explosion. Failure to comply may result in severe injury or death.

1. Position wiring harness W3 in vehicle, secure in cable clamps, and secure with new tie down straps.
2. Connect wiring harness W3 connector P33 (Figure 4, Item 6) to transducer T8 (Figure 4, Item 5) at right sprung stop cylinder (Figure 4, Item 4).
3. Connect wiring harness W3 connector P32 (Figure 4, Item 3) to transducer T9 (Figure 4, Item 2) at left sprung stop cylinder (Figure 4, Item 1).



M0021HDC


Figure 4. Wiring Harness W3 at Actuator Area Installation.

**INSTALLATION - Continued****WARNING**

Do not work under vehicle unless hull is on jack stands and apron lockpins are installed.  
Failure to comply may result in severe injury or death to personnel.

4. From access under vehicle, connect the following W3 wiring harness connectors to the aft manifold (Figure 5, Item 12): connector P4 (Figure 5, Item 20) to valve V4 (Figure 5, Item 11), connector P6 (Figure 5, Item 14) to valve V6 (Figure 5, Item 13), connector P7 (Figure 5, Item 16) to valve P7 (Figure 5, Item 15), connector P8 (Figure 5, Item 18) to valve V8 (Figure 5, Item 17), and connector P18 (Figure 5, Item 19) to valve V18 (Figure 5, Item 10).
5. From access under vehicle, connect the following W3 wiring harness connectors to the forward left manifold (Figure 5, Item 9): connector P3 (Figure 5, Item 7) to valve V3 (Figure 5, Item 8), connector P9 (Figure 5, Item 6) to valve V9 (Figure 5, Item 5), and connector P30 (Figure 5, Item 4) to transducer T10 (Figure 5, Item 3).
6. From access under vehicle, connect the following W3 wiring harness connectors to the forward right manifold (Figure 5, Item 21): connector P2 (Figure 5, Item 24) to valve V2 (Figure 5, Item 25), connector P10 (Figure 5, Item 23) to valve V10 (Figure 5, Item 22), and connector P11 (Figure 5, Item 1) to transducer T11 (Figure 5, Item 2).

INSTALLATION - Continued



M0022HDC

Figure 5. Wiring Harness W3 Connections Under Vehicle Installation.

**INSTALLATION - Continued**

7. Connect wiring harness W3 connector P31 (Figure 6, Item 10) to transducer T6 (Figure 6, Item 11) at forward left actuator #1 (Figure 6, Item 9).
8. Connect wiring harness W3 connector P5 (Figure 6, Item 7) to transducer T5 (Figure 6, Item 6) at forward right actuator #1 (Figure 6, Item 8).
9. Install wiring harness W3 connector J1 (Figure 6, Item 2) to HDC disconnect bracket (Figure 6, Item 3) with nutplate (Figure 6, Item 1) and four screws (Figure 6, Item 4). Attach dust cap (Figure 6, Item 5) to connector J1.




Figure 6. Wiring Harness W3 to Disconnect Bracket and Actuator Area Installation.

**END OF TASK**

**FOLLOW-ON MAINTENANCE**

1. Connect negative battery cables (TM 5-2350-262-20).
2. Install hull access plates (TM 5-2350-262-20).
3. Remove vehicle from jack stands and lower hull (TM 5-2350-262-20).
4. Return ejector to stowed position (TM 5-2350-262-10).
5. Return apron to stowed position (TM 5-2350-262-10).

**END OF TASK**

**END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
PRESSURE TRANSDUCERS REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Adapter, Socket Wrench  
(WP 0054, Table 1, Item 1)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Stand, Vehicle Support  
(WP 0054, Table 1, Item 5)  
Wrench Set, Crowfoot (WP 0054, Table 1, Item 8)

**Materials/Parts**

O-ring (WP 0055, Table 1, Item 19) Qty: 13

**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)

---

**Equipment Condition (cont.)**

Hydraulic pressure relieved (WP 0004)  
Filter guard protective bracket removed for  
transducers T3, T4, and T12  
(TM 5-2350-262-20)  
Vehicle hull raised and on jack stands for  
transducers T5 and T6 (TM 5-2350-262-20)  
Hull access plates removed for transducers T5 and  
T6 (TM 5-2350-262-20)  
Apron locked in full-up position for transducer T7  
(TM 5-2350-262-10)  
Ejector to front of vehicle for transducer T7  
(TM 5-2350-262-10)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

**REMOVAL**

**NOTE**

- All transducers are removed and replaced in the same manner. This task covers the removal and replacement of only one transducer.
- Refer to Table 1. Hydraulic Diagnostic Center (HDC) Pressure Transducer Locations for the location of each pressure transducer.
- Tag electrical connector and hydraulic hose/tube to assist in installation. Plug fitting that transducer is removed from to prevent leakage.

**Table 1. Hydraulic Diagnostic Center (HDC) Pressure Transducer Locations.**


Transducer	Location	WP #
T3, T4, T12	Main hydraulic filter area	WP 0031
T5, T8	Right actuator access area	WP 0032
T6, T9	Left actuator access area	WP 0032
T7	Left main manifold	WP 0047
T1, T2, T13	Primary manifold	WP 0035
T10	Left forward manifold	WP 0036
T11	Main hydraulic filter area	WP 0037

1. If wiring harness and connector are connected, disconnect transducer connector (Figure 1, Item 2) from wiring harness connector (Figure 1, Item 1).
2. Remove transducer (Figure 1, Item 4) and O-ring (Figure 1, Item 3) from component. Discard O-ring.

**END OF TASK**

**INSTALLATION**

1. Install new O-ring (Figure 1, Item 3) and transducer (Figure 1, Items 2 and 4) on component.
2. Connect transducer connector (Figure 1, Item 2) to wiring harness connector (Figure 1, Item 1).

**INSTALLATION - Continued**

M0048HDC

*Figure 1. Transducer Removal/Installation.*

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Return ejector to properly stowed position (TM 5-2350-262-10).
2. Restore hydraulic pressure to system (TM 2350-262-10).
3. Connect negative battery cables (TM 5-2350-262-20).
4. Install filter guard protective bracket for transducers T3, T4, and T12 (TM 5-2350-262-20).
5. Remove vehicle hull from jack stands for transducers T5 and T6 (TM 5-2350-262-20).
6. Install hull access plates for transducers T5 and T6 (TM 5-2350-262-20).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD ASSEMBLY AND MOUNTING BRACKET  
REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Plug, Hydraulic Tank (WP 0054, Table 1, Item 4)  
Wrench Set, Crowfoot (WP 0054, Table 1, Item 8)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)  
Bolt, Machine (WP 0055, Table 1, Item 4)  
Qty: 11  
Bolt, Machine (WP 0055, Table 1, Item 6) Qty: 2  
Bolt, Machine (WP 0055, Table 1, Item 5) Qty: 3  
Nut, Self-Locking (WP 0055, Table 1, Item 9)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)


**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)

---

**Equipment Condition (cont.)**

Apron locked in full-up position  
(TM 5-2350-262-10)  
Ejector to front of vehicle (TM 5-2350-262-10)  
Hydraulic pressure relieved (WP 0004)  
Directional Control Valve (DCV) bank removed  
(TM 5-2350-262-20)  
Sprung/Unsprung valve removed  
(TM 5-2350-262-20)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

**REMOVAL****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

**CAUTION**


Cap or plug all oil ports and ends of hoses and tubes when oil hoses or tubes are disconnected or removed to prevent contamination. Failure to comply may result in damage to equipment.

**NOTE**

Tag all hydraulic lines and wiring harness leads being disconnected to assist in installation.

1. Remove 17 hydraulic hoses and tubes (Figure 1, Items 6 through 19) from primary manifold (Figure 1, Item 5). Plug ends of hoses and tubes and cap ends of adapters to prevent leakage.
2. Remove wiring harness W2 connectors P1, P5, P11, P12, P13, P14, P15, P16, P17, P19, and P20 (Figure 1, Item 3) from valves V1, V5, V11, V12, V13, V14, V15, V16, V17, V19, and V20 (Figure 1, Item 4) at primary manifold (Figure 1, Item 5).
3. Remove wiring harness W2 connectors P2, P31, and P32 (Figure 1, Item 1) from transducers T2, T1, and T13 (Figure 1, Item 2) at primary manifold (Figure 1, Item 5).

REMOVAL - Continued



M0036HDC

Figure 1. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Removal.

**REMOVAL - Continued**

4. Remove two machine bolts (Figure 2, Item 7), two flat washers (Figure 2, Item 6), screw (Figure 2, Item 9), three flat washers (Figure 2, Item 10), self-locking nut (Figure 2, Item 13), and lateral support bracket (Figure 2, Item 14) from primary manifold (Figure 2, Item 5) and hull floor support bracket (Figure 2, Item 8). Discard machine bolts and self-locking nut.
5. Remove three machine bolts (Figure 2, Item 12), three flat washers (Figure 2, Item 11), and hull floor support bracket (Figure 2, Item 8). Discard machine bolts.
6. Fully supporting weight of primary manifold (Figure 2, Item 5), remove seven machine bolts (Figure 2, Item 3), seven flat washers (Figure 2, Item 4), and primary manifold (Figure 2, Item 5) with mounting plate (Figure 2, Item 1) from bracket (Figure 2, Item 2). Discard machine bolts.
7. Remove four machine bolts (Figure 2, Item 3), four flat washers (Figure 2, Item 4), and mounting plate (Figure 2, Item 1) from primary manifold (Figure 2, Item 5). Discard machine bolts.



REMOVAL - Continued





Figure 2. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Removal.

END OF TASK

**INSTALLATION****WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
1. Install mounting plate (Figure 3, Item 1) on primary manifold (Figure 3, Item 5) with four flat washers (Figure 3, Item 4) and four new machine bolts (Figure 3, Item 3).
  2. Supporting weight of primary manifold (Figure 3, Item 5), install primary manifold (Figure 3, Item 5) with seven flat washers (Figure 3, Item 4) and seven new machine bolts (Figure 3, Item 3).
  3. Install hull floor support bracket (Figure 3, Item 8) with three flat washers (Figure 3, Item 11) and three new machine bolts (Figure 3, Item 12).
  4. Install lateral support bracket (Figure 3, Item 14) with screw (Figure 3, Item 9), three flat washers (Figure 3, Item 10), two flat washers (Figure 3, Item 6), and two new machine bolts (Figure 3, Item 7).

INSTALLATION - Continued




M0038HDC

Figure 3. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Installation.

**INSTALLATION - Continued**

5. At primary manifold (Figure 4, Item 5) connect wiring harness W2 connectors P2, P31, and P32 (Figure 4, Item 1) to transducers T2, T1, and T13 (Figure 4, Item 2).
6. At primary manifold (Figure 4, Item 5) connect wiring harness W2 connectors P1, P5, P11, P12, P13, P14, P15, P16, P17, P19, and P20 (Figure 4, Item 3) to valves V1, V5, V11, V12, V13, V14, V15, V16, V17, V19, and V20 (Figure 4, Item 4).
7. Remove caps from adapters and plugs from 17 hydraulic hoses and tubes and connect 17 hydraulic hoses and tubes (Figure 4, Items 6 through 19) to primary manifold (Figure 4, Item 5).



M0039HDC

Figure 4. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly and Mounting Bracket Installation.

**END OF TASK**

**FOLLOW-ON MAINTENANCE**

1. Connect negative battery cables (TM 5-2350-262-20).
2. Install Sprung/Unsprung valve (TM 5-2350-262-20).
3. Install DCV bank (TM 5-2350-262-20).
4. Restore hydraulic pressure to system (TM 5-2350-262-10).
5. Return ejector to properly stowed position (TM 5-2350-262-10).
6. Return apron to properly stowed position (TM 5-2350-262-10).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD REPAIR**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Plug, Hydraulic Tank (WP 0054, Table 1, Item 4)  
Wrench Set, Crowfoot (WP 0054, Table 1, Item 8)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)  
O-ring (WP 0055, Table 1, Item 16) Qty: 6  
O-ring (WP 0055, Table 1, Item 14) Qty: 6  
O-ring (WP 0055, Table 1, Item 15) Qty: 11  
O-ring (WP 0055, Table 1, Item 17) Qty: 5  
O-ring (WP 0055, Table 1, Item 19) Qty: 11  
O-ring (WP 0055, Table 1, Item 20) Qty: 2  
O-ring (WP 0055, Table 1, Item 21) Qty: 21  
O-ring (WP 0055, Table 1, Item 18) Qty: 1

**Materials/Parts (cont.)**

Retainer, Packing (WP 0055, Table 1, Item 13)  
Qty: 12  
Retainer, Packing (WP 0055, Table 1, Item 12)  
Qty: 12  
Retainer, Packing (WP 0055, Table 1, Item 11)  
Qty: 10

**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Primary manifold removed from vehicle  
(WP 0034)


---

**DISASSEMBLY****CAUTION**

- Disassembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
  - When securing primary manifold in vise, exercise extreme care not to mar any surfaces or damage components.
1. Remove 11 adapters (Figure 1, Item 7), 11 O-rings (Figure 1, Item 2), three adapters (Figure 1, Item 1), and three O-rings (Figure 1, Item 2), from primary manifold (Figure 1, Item 3). Discard O-rings.
  2. Remove adapter (Figure 1, Item 12), O-ring (Figure 1, Item 13), adapter (Figure 1, Item 8), O-ring (Figure 1, Item 2), adapter (Figure 1, Item 11), and O-ring (Figure 1, Item 2) from primary manifold (Figure 1, Item 3). Discard O-rings.
  3. Remove five plugs (Figure 1, Item 5), five O-rings (Figure 1, Item 4), plug (Figure 1, Item 9), O-ring (Figure 1, Item 10), six plugs (Figure 1, Item 6), and six O-rings (Figure 1, Item 2) from primary manifold (Figure 1, Item 3). Discard O-rings.



DISASSEMBLY - Continued



FRONT/TOP VIEW

BOTTOM/REAR VIEW


M0040HDC

Figure 1. Adapters and Plugs from Primary Manifold Disassembly.

**DISASSEMBLY - Continued**

4. Remove three transducers (Figure 2, Item 12), three O-rings (Figure 2, Item 13), and relief valve (Figure 2, Item 15), from primary manifold (Figure 2, Item 14). Discard O-rings.
5. Remove six three-way valves (Figure 2, Item 6), six packing retainers (Figure 2, Item 10), six O-rings (Figure 2, Item 11), six packing retainers (Figure 2, Item 10), six packing retainers (Figure 2, Item 8), six O-rings (Figure 2, Item 9), six packing retainers (Figure 3, Item 8), and six O-rings (Figure 2, Item 7) from primary manifold (Figure 2, Item 14). Discard O-rings and packing retainers.
6. Remove two (NC) valves (Figure 2, Item 5), two packing retainers (Figure 2, Item 3), two O-rings (Figure 2, Item 4), two packing retainers (Figure 2, Item 3), and two O-rings (Figure 2, Item 2), from primary manifold (Figure 2, Item 14). Discard O-rings and packing retainers.
7. Remove three (NO) valves (Figure 2, Item 1), three O-rings (Figure 2, Item 2), three packing retainers (Figure 2, Item 3), three O-rings (Figure 2, Item 4), and three packing retainers (Figure 2, Item 3), from primary manifold (Figure 2, Item 14). Discard O-rings and packing retainers.

DISASSEMBLY - Continued



M0041HDC


Figure 2. Transducers and Valves from Primary Manifold Disassembly.

END OF TASK

**ASSEMBLY****CAUTION**

- Assembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
  - When securing primary manifold in vise, exercise extreme care not to mar any surfaces or damage components.
  - Do not over torque.
1. Install three new O-rings (Figure 3, Item 2), three new packing retainers (Figure 3, Item 3), three new O-rings (Figure 3, Item 4), three new packing retainers (Figure 3, Item 3), and three (NO) valves (Figure 3, Item 1) on primary manifold (Figure 3, Item 14).
  2. Install two new O-rings (Figure 3, Item 2), two new packing retainers (Figure 3, Item 3), two new O-rings (Figure 3, Item 4), two new packing retainers (Figure 3, Item 3), and two (NC) valves (Figure 3, Item 5).
  3. Install six new O-rings (Figure 3, Item 7), six new packing retainers (Figure 3, Item 8), six new O-rings (Figure 3, Item 9), six new packing retainers (Figure 3, Item 8), six new packing retainers (Figure 3, Item 10), six new O-rings (Figure 3, Item 11), six new packing retainers (Figure 3, Item 10), and six three-way valves (Figure 3, Item 6) on primary manifold (Figure 3, Item 14).
  4. Install relief valve (Figure 3, Item 15), three O-rings (Figure 3, Item 13), and three transducers (Figure 3, Item 12) on primary manifold (Figure 3, Item 14).

ASSEMBLY - Continued




M0042HDC

Figure 3. Valves and Transducers on Primary Manifold Assembly.

**ASSEMBLY - Continued**

5. Install six new O-rings (Figure 4, Item 2), six plugs (Figure 4, Item 6), new O-ring (Figure 4, Item 10), plug (Figure 4, Item 9), five new O-rings (Figure 4, Item 4), and five plugs (Figure 4, Item 5) on primary manifold (Figure 4, Item 3).
6. Install O-ring (Figure 4, Item 2), adapter (Figure 4, Item 11), O-ring (Figure 4, Item 2), adapter (Figure 4, Item 8), O-ring (Figure 4, Item 13), and adapter (Figure 4, Item 12) on primary manifold (Figure 4, Item 3).
7. Install three new O-rings (Figure 4, Item 2), three adapters (Figure 4, Item 1), 11 new O-rings (Figure 4, Item 2), and 11 adapters (Figure 4, Item 7) on primary manifold (Figure 4, Item 3).

ASSEMBLY - Continued



M0043HDC

Figure 4. Plugs and Adapters on Primary Manifold Assembly.

END OF TASK

FOLLOW-ON MAINTENANCE

Install primary manifold (WP 0034).

END OF TASK

END OF WORK PACKAGE





---

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) FORWARD LEFT MANIFOLD ASSEMBLY REPAIR**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Adapter, Socket Wrench  
(WP 0054, Table 1, Item 1)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Plug, Hydraulic Tank  
(WP 0054, Table 1, Item 4)  
Stand, Vehicle Support  
(WP 0054, Table 1, Item 5)  
Wrench Set, Crowfoot  
(WP 0054, Table 1, Item 8)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)  
Bolt, Machine (WP 0055, Table 1, Item 6) Qty: 2  
O-ring (WP 0055, Table 1, Item 19) Qty: 3  
O-ring (WP 0055, Table 1, Item 20) Qty: 4  
O-ring (WP 0055, Table 1, Item 21) Qty: 2

**Materials/Parts (cont.)**

O-ring (WP 0055, Table 1, Item 15) Qty: 2  
O-ring (WP 0055, Table 1, Item 17) Qty: 2  
Retainer, Packing (WP 0055, Table 1, Item 11)  
Qty: 4


**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Hydraulic pressure relieved (WP 0004)  
Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle hull raised and on jack stands  
(TM 5-2350-262-20)  
Hull access plates removed (TM 5-2350-262-20)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

---

**WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- All removal steps are accomplished through access under vehicle.
- Tag all hydraulic lines and wiring harness leads being disconnected to assist in installation.

**REMOVAL**


1. Remove wiring harness W3 connectors P3 and P9 (Figure 1, Item 6) from two two-way (NO) valves V3 and V9 (Figure 1, Item 5) on left forward manifold (Figure 1, Item 9).
2. Remove wiring harness W3 connector P30 (Figure 1, Item 3) from transducer T10 (Figure 1, Item 4) on left forward manifold (Figure 1, Item 9).

**CAUTION**

Cap or plug all oil ports and ends of hoses and tubes when oil hoses or tubes are disconnected or removed to prevent contamination. Failure to comply may result in damage to equipment.

3. Remove five hydraulic hoses (Figure 1, Item 2) and three hydraulic tubes (Figure 1, Item 1) from left forward manifold (Figure 1, Item 9).
4. Remove two machine bolts (Figure 1, Item 7), two flat washers (Figure 1, Item 8), and left forward manifold (Figure 1, Item 9) from vehicle. Discard machine bolts.

REMOVAL - Continued



M0024HDC

Figure 1. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Assembly Removal.

END OF TASK

## DISASSEMBLY

## CAUTION

- Disassembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
- When securing forward left manifold in vise, exercise extreme care not to mar any surfaces or damage components.

1. Remove two adapters (Figure 2, Item 3), two O-rings (Figure 2, Item 4), two adapters (Figure 2, Item 12), two O-rings (Figure 2, Item 13), adapter (Figure 2, Item 11), O-ring (Figure 2, Item 2), adapter (Figure 2, Item 15), O-ring (Figure 2, Item 13), two adapters (Figure 2, Item 1), and two O-rings (Figure 2, Item 2) from left forward manifold (Figure 2, Item 14). Discard O-rings.
2. Remove two two-way (NO) valves V3 and V9 (Figure 2, Item 10), two packing retainers (Figure 2, Item 7), two O-rings (Figure 2, Item 8), two packing retainers (Figure 2, Item 7), two O-rings (Figure 2, Item 9), transducer T10 (Figure 2, Item 6), and O-ring (Figure 2, Item 5) from left forward manifold (Figure 2, Item 14). Discard O-rings and packing retainers.




Figure 2. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Disassembly.

## END OF TASK

**ASSEMBLY**

**CAUTION**

- Assembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
  - When securing forward left manifold in vise, exercise extreme care not to mar any surfaces or damage components.
  - Do not over torque.
1. Install new O-ring (Figure 3, Item 5), transducer T10 (Figure 3, Item 6), two new O-rings (Figure 3, Item 9), two new packing retainers (Figure 3, Item 7), two new O-rings (Figure 3, Item 8), two new packing retainers (Figure 3, Item 7), and two two-way (NO) valves V3 and V9 (Figure 3, Item 10) into left forward manifold (Figure 3, Item 14).
  2. Install new O-ring (Figure 3, Item 2), adapter (Figure 3, Item 1), new O-ring (Figure 3, Item 13), adapter (Figure 3, Item 16), new O-ring (Figure 3, Item 13), adapter (Figure 3, Item 15), new O-ring (Figure 3, Item 2), adapter (Figure 3, Item 11), two new O-rings (Figure 3, Item 13), two adapters (Figure 3, Item 12), two new O-rings (Figure 3, Item 4), and two adapters (Figure 3, Item 3) into left forward manifold (Figure 3, Item 14).




Figure 3. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Assembly.

**END OF TASK**

**INSTALLATION****WARNING**

Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- Installation steps are accomplished through access under vehicle.
  - After installation is complete, remove tags from all hydraulic lines and wiring harness leads.
1. Install left forward manifold (Figure 4, Item 9) using two flat washers (Figure 4, Item 8) and two new machine bolts (Figure 4, Item 7).
  2. Connect wiring harness W3 connector P30 (Figure 4, Item 3) to transducer T10 (Figure 4, Item 4) on left forward manifold (Figure 4, Item 9).
  3. Connect wiring harness W3 connectors P3 and P9 (Figure 4, Item 6) to two two-way (NO) valves V3 and V9 (Figure 4, Item 5) on left forward manifold (Figure 4, Item 9).
  4. Remove all caps and plugs from hydraulic fittings.
  5. Connect five hydraulic hoses (Figure 4, Item 2) and three hydraulic tubes (Figure 4, Item 1) to left forward manifold (Figure 4, Item 9).


**INSTALLATION - Continued**

Figure 4. Hydraulic Diagnostic Center (HDC) Forward Left Manifold Assembly Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Connect negative battery cables (TM 5-2350-262-20).
2. Install hull access plates (TM 5-2350-262-20).
3. Remove vehicle from jack stands and lower hull (TM 5-2350-262-20).
4. Bring hydraulic system to operating pressure (TM 5-2350-262-10).

**END OF TASK****END OF WORK PACKAGE**





---

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) FORWARD RIGHT MANIFOLD ASSEMBLY REPAIR**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Adapter, Socket Wrench  
(WP 0054, Table 1, Item 1)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Plug, Hydraulic Tank (WP 0054, Table 1, Item 4)  
Stand, Vehicle Support  
(WP 0054, Table 1, Item 5)  
Wrench Set, Crowfoot (WP 0054, Table 1, Item 8)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)  
Bolt, Machine (WP 0055, Table 1, Item 6) Qty: 2  
O-ring (WP 0055, Table 1, Item 19) Qty: 3  
O-ring (WP 0055, Table 1, Item 20) Qty: 4  
O-ring (WP 0055, Table 1, Item 21) Qty: 2  
O-ring (WP 0055, Table 1, Item 15) Qty: 2

**Materials/Parts (cont.)**

O-ring (WP 0055, Table 1, Item 17) Qty: 2  
Retainer, Packing (WP 0055, Table 1, Item 11)  
Qty: 4


**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Hydraulic pressure relieved (WP 0004)  
Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle hull raised and on jack stands  
(TM 5-2350-262-20)  
Hull access plates removed (TM 5-2350-262-10)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

---

**REMOVAL****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**


- All removal steps are accomplished through access under vehicle.
- Tag all hydraulic lines and wiring harness leads being disconnected to assist in installation.

**CAUTION**

Cap or plug all oil ports and ends of hoses and tubes when oil hoses or tubes are disconnected or removed to prevent contamination. Failure to comply may result in damage to equipment.

1. Remove five hydraulic hoses (Figure 1, Item 1) and three hydraulic tubes (Figure 1, Item 2) from forward right manifold (Figure 1, Item 3).
2. Remove wiring harness W3 connectors P2 and P10 (Figure 1, Item 7) from two two-way (NO) valves V2 and V10 (Figure 1, Item 6), and wiring harness W3 connector P11 (Figure 1, Item 9) from transducer T11 (Figure 1, Item 8).
3. Remove two machine bolts (Figure 1, Item 5), two flat washers (Figure 1, Item 4), and forward right manifold (Figure 1, Item 3) from vehicle. Discard machine bolts.

REMOVAL - Continued



M0028HDC

Figure 1. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Removal.

END OF TASK

**DISASSEMBLY**

**CAUTION**

- Disassembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
- When securing forward right manifold in vise, exercise extreme care not to mar any surfaces or damage components.

1. Remove two adapters (Figure 2, Item 3), two O-rings (Figure 2, Item 2), two adapters (Figure 2, Item 10), two O-rings (Figure 2, Item 7), adapter (Figure 2, Item 11), O-ring (Figure 2, Item 4), adapter (Figure 2, Item 8), O-ring (Figure 2, Item 7), adapter (Figure 2, Item 5), O-ring (Figure 2, Item 4), adapter (Figure 2, Item 6), and O-ring (Figure 2, Item 7) from right manifold (Figure 2, Item 9). Discard O-rings.
2. Remove two two-way (NO) valves V2 and V10 (Figure 2, Item 12), two packing retainers (Figure 2, Item 14), two O-rings (Figure 2, Item 15), two packing retainers (Figure 2, Item 14), two O-rings (Figure 2, Item 13), transducer T11 (Figure 2, Item 1), and O-ring (Figure 2, Item 2) from right manifold (Figure 2, Item 9). Discard O-rings and packing retainers.




Figure 2. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Disassembly.

**END OF TASK**

**ASSEMBLY**

**CAUTION**

- Assembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
  - When securing forward right manifold in vise, exercise extreme care not to mar any surfaces or damage components.
  - Do not over torque.
1. Install new O-ring (Figure 3, Item 2), transducer T11 (Figure 3, Item 1), two new O-rings (Figure 3, Item 13), two new packing retainers (Figure 3, Item 14), two new O-rings (Figure 3, Item 15), two new packing retainers (Figure 3, Item 14), and two two-way (NO) valves V2 and V10 (Figure 3, Item 12) into right forward manifold (Figure 3, Item 9).
  2. Install new O-ring (Figure 3, Item 4), adapter (Figure 3, Item 5), new O-ring (Figure 3, Item 7), adapter (Figure 3, Item 6), new O-ring (Figure 3, Item 7), adapter (Figure 3, Item 8), new O-ring (Figure 3, Item 4), adapter (Figure 3, Item 11), two new O-rings (Figure 3, Item 7), two adapters (Figure 3, Item 10), two new O-rings (Figure 3, Item 2), and two adapters (Figure 3, Item 3) into right forward manifold (Figure 3, Item 9).




Figure 3. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Assembly.


**END OF TASK**

**INSTALLATION****WARNING**

Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- Installation steps are accomplished through access under vehicle.
  - After installation is complete, remove tags from all hydraulic lines and wiring harness leads.
1. Install right forward manifold (Figure 4, Item 3) using two flat washers (Figure 4, Item 4) and two new machine bolts (Figure 4, Item 5).
  2. Connect wiring harness W3 connector P11 (Figure 4, Item 9) to transducer T11 (Figure 4, Item 8) on right forward manifold (Figure 4, Item 3).
  3. Connect wiring harness W3 connectors P2 and P10 (Figure 4, Item 7) to two two-way (NO) valves V2 and V10 (Figure 4, Item 6) on right forward manifold (Figure 4, Item 3).
  4. Remove all caps and plugs from hydraulic fittings.
  5. Connect five hydraulic hoses (Figure 4, Item 1) and three hydraulic tubes (Figure 4, Item 2) to right forward manifold (Figure 4, Item 3).

**INSTALLATION - Continued**

M0031HDC

Figure 4. Hydraulic Diagnostic Center (HDC) Forward Right Manifold Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Connect negative battery cables (TM 5-2350-262-20).
2. Install hull access plates (TM 5-2350-262-10).
3. Remove vehicle from jack stands and lower hulls (TM 5-2350-262-20).
4. Bring hydraulic system to operating pressure (TM 5-2350-262-10).

**END OF TASK****END OF WORK PACKAGE**





---

**FIELD MAINTENANCE**  
**HYDRAULIC DIAGNOSTIC CENTER (HDC) AFT MANIFOLD ASSEMBLY REPAIR**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Adapter, Socket Wrench  
(WP 0054, Table 1, Item 1)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Plug, Hydraulic Tank (WP 0054, Table 1, Item 4)  
Stand, Vehicle Support  
(WP 0054, Table 1, Item 5)  
Wrench Set, Crowfoot (WP 0054, Table 1, Item 8)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)  
O-ring (WP 0055, Table 1, Item 20) Qty: 2  
O-ring (WP 0055, Table 1, Item 16) Qty: 2  
O-ring (WP 0055, Table 1, Item 21) Qty: 1  
O-ring (WP 0055, Table 1, Item 19) Qty: 2  
O-ring (WP 0055, Table 1, Item 15) Qty: 5  
O-ring (WP 0055, Table 1, Item 17) Qty: 5

**Materials/Parts (cont.)**

Retainer, Packing  
(WP 0055, Table 1, Item 11) Qty: 10  
Screw, Cap, Hexagon Head  
(WP 0055, Table 1, Item 7) Qty: 3


**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Hydraulic pressure relieved (WP 0004)  
Vehicle MASTER power OFF (TM 5-2350-262-10)  
Vehicle hull raised and on jack stands  
(TM 5-2350-262-20)  
Hull access plates removed (TM 5-2350-262-20)  
Negative battery cables disconnected  
(TM 5-2350-262-20)

---

**REMOVAL****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- All removal steps are accomplished through access under vehicle.
  - Tag all hydraulic lines and wiring harness leads being disconnected to assist in installation.
1. Remove wiring harness W3 connectors P4, P6, P7, P8, and P18 (Figure 1, Item 1) from five two-way valves V4, V6, V7, V8, and V18 (Figure 1, Item 2) on aft manifold (Figure 1, Item 6).

**CAUTION**

Cap or plug all oil ports and ends of hoses and tubes when oil hoses or tubes are disconnected or removed to prevent contamination. Failure to comply may result in damage to equipment.

2. Remove six hydraulic hoses (Figure 1, Item 3) from aft manifold (Figure 1, Item 6).
3. Remove three hexagon head cap screws (Figure 1, Item 4), three flat washers (Figure 1, Item 5), and aft manifold (Figure 1, Item 6) from vehicle. Discard cap screws.

REMOVAL - Continued




Figure 1. Hydraulic Diagnostic Center (HDC) Manifold Assembly Removal.

END OF TASK

**DISASSEMBLY**

**CAUTION**

- Disassembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
- When securing aft manifold in vise, exercise extreme care not to mar any surfaces or damage components.

1. Remove adapter (Figure 2, Item 10), adapter (Figure 2, Item 9), adapter (Figure 2, Item 14), O-ring (Figure 2, Item 6), O-ring (Figure 2, Item 15), two adapters (Figure 2, Item 12), two O-rings (Figure 2, Item 11), plug (Figure 2, Item 8), O-ring (Figure 2, Item 7), adapter (Figure 2, Item 5), O-ring (Figure 2, Item 6), adapter (Figure 2, Item 16), and O-ring (Figure 2, Item 15) from aft manifold (Figure 2, Item 13).
2. Remove four two-way (NO) valves V4, V6, V7, and V8 (Figure 2, Item 1), one two-way (NC) valve (Figure 2, Item 17), five packing retainers (Figure 2, Item 3), five O-rings (Figure 2, Item 4), five packing retainers (Figure 2, Item 3), and five O-rings (Figure 2, Item 2) from aft manifold (Figure 2, Item 13). Discard O-rings and packing retainers.





Figure 2. Hydraulic Diagnostic Center (HDC) Manifold Disassembly.

**END OF TASK**

**ASSEMBLY**

**CAUTION**

- Assembly should be performed in a clean environment and protective dust covers or caps should be installed on all openings to prevent contamination. Dirt can damage parts and cause malfunctions.
  - When securing aft manifold in vise, exercise extreme care not to mar any surfaces or damage components.
  - Do not over torque.
1. Install five new O-rings (Figure 3, Item 2), five new packing retainers (Figure 3, Item 3), five new O-rings (Figure 3, Item 4), five new packing retainers (Figure 3, Item 3), one two-way (NC) valve V18 (Figure 3, Item 17), and four two-way (NO) valves V4, V6, V7, and V8 (Figure 3, Item 1) into aft manifold (Figure 3, Item 13).
  2. Install new O-ring (Figure 3, Item 6), adapter (Figure 3, Item 5), new O-ring (Figure 3, Item 15), adapter (Figure 3, Item 16), new O-ring (Figure 3, Item 7), plug (Figure 3, Item 8), two new O-rings (Figure 3, Item 11), two adapters (Figure 3, Item 12), new O-ring (Figure 3, Item 15), adapter (Figure 3, Item 14), new O-ring (Figure 3, Item 6), adapter (Figure 3, Item 9), and adapter (Figure 3, Item 10) into aft manifold (Figure 3, Item 13).



M0034HDC

Figure 3. Hydraulic Diagnostic Center (HDC) Aft Manifold Assembly.

**ASSEMBLY - Continued****WARNING**

Do not work under vehicle unless hull is on jack stands and apron lockpins are installed. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- Installation steps are accomplished through access under vehicle.
  - After installation is complete, remove tags from all hydraulic lines and wiring harness leads.
3. Install aft manifold (Figure 4, Item 6) in vehicle with three new hexagon head cap screws (Figure 4, Item 4) and three flat washers (Figure 4, Item 5).
  4. Remove caps from adapters and plugs from hydraulic hose connector ends and connect six hydraulic hoses (Figure 4, Item 3) to aft manifold (Figure 4, Item 6).
  5. Connect wiring harness W3 connectors P4, P6, P7, P8, and P18 (Figure 4, Item 1) to five two-way valves V4, V6, V7, V8, and V18 (Figure 4, Item 2) on aft manifold (Figure 4, Item 6).
  6. Remove tags from all hydraulic hoses and wiring harness W3 connectors.


**ASSEMBLY - Continued**

Figure 4. Hydraulic Diagnostic Center (HDC) Aft Manifold Assembly Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Connect negative battery cables (TM 5-2350-262-20).
2. Install hull access plates (TM 5-2350-262-20).
3. Remove vehicle from jack stands and lower hull (TM 5-2350-262-20).
4. Bring hydraulic system to operating pressure (TM 5-2350-262-10).

**END OF TASK****END OF WORK PACKAGE**





---

**FIELD MAINTENANCE  
MAIN PUMP HYDRAULIC FILTER AREA REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Plug, Hydraulic Tank (WP 0054, Table 1, Item 4)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)  
O-ring (WP 0055, Table 1, Item 21) Qty: 14


**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Filter guard protective bracket removed  
(TM 5-2350-262-20)  
Hydraulic pressure relieved (WP 0004)

---

**REMOVAL****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

**CAUTION**


Cap or plug all oil ports and ends of hoses and tubes when oil hoses or tubes are disconnected or removed to prevent contamination. Failure to comply may result in damage to equipment.

**NOTE**

The procedure for replacing valve V21, relief valve, and bypass hose is identical for valve 22, relief valve, and bypass hose. This task covers the V21 valve, relief valve, and bypass hose.

1. Remove bypass hose (Figure 1, Item 4), adapter (Figure 1, Item 5), and O-ring (Figure 1, Item 2) from relief valve (Figure 1, Item 3). Discard O-ring.
2. Remove adapter (Figure 1, Item 1) and O-ring (Figure 1, Item 2) from bottom of relief valve (Figure 1, Item 3) and tee (Figure 1, Item 6). Discard O-ring.
3. Remove adapter (Figure 1, Item 1), O-ring (Figure 1, Item 2), and relief valve (Figure 1, Item 3) from bulkhead bracket (Figure 1, Item 7). Discard O-ring.

REMOVAL - Continued




M0044HDC

Figure 1. Valve V21 (V22), Relief Valve, and Bypass Hose Removal.

**REMOVAL - Continued**

4. Remove nut (Figure 2, Item 6), adapter (Figure 2, Item 9), two flat washers (Figure 2, Item 7), O-ring (Figure 2, Item 4), and valve V21 (Figure 2, Item 10) from bulkhead bracket (Figure 2, Item 8). Discard O-ring.
5. Remove adapter (Figure 2, Item 3) and O-ring (Figure 2, Item 4) from top of valve V21 (Figure 2, Item 10) and from tee (Figure 2, Item 11). Discard O-ring.
6. Remove bypass hose (Figure 2, Item 2) from adapter (Figure 2, Item 1).
7. Remove adapter (Figure 2, Item 1) from tee (Figure 2, Item 11) and tee (Figure 2, Item 11) from adapter (Figure 2, Item 3).
8. Remove adapter (Figure 2, Item 3) and O-ring (Figure 2, Item 4) from filter (Figure 2, Item 5). Discard O-ring.

REMOVAL - Continued



M0045HDC

Figure 2. Valve V21 (V22), Relief Valve, and Bypass Hose Removal.

END OF TASK

**INSTALLATION****WARNING**

- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
1. Install new O-ring (Figure 3, Item 4) and adapter (Figure 3, Item 3) into filter (Figure 3, Item 5).
  2. Install tee (Figure 3, Item 11) on adapter (Figure 3, Item 3) and adapter (Figure 3, Item 1) onto top of tee (Figure 3, Item 11).
  3. Install bypass hose (Figure 3, Item 2) onto adapter (Figure 3, Item 1).
  4. Install new O-ring (Figure 3, Item 4) with adapter (Figure 3, Item 3) on top of valve V21 (Figure 3, Item 10).
  5. Install valve V21 (Figure 3, Item 10), new O-ring (Figure 3, Item 4), two flat washers (Figure 3, Item 7), adapter (Figure 3, Item 9), and nut (Figure 3, Item 6) on bulkhead bracket (Figure 3, Item 8) and tee (Figure 3, Item 11).

INSTALLATION - Continued





Figure 3. Valve V21 (V22), Relief Valve, and Bypass Hose Installation.

**INSTALLATION - Continued**

6. Install new O-ring (Figure 4, Item 2) and adapter (Figure 4, Item 1) on relief valve (Figure 4, Item 3) and attach to bulkhead bracket (Figure 4, Item 7).
7. Install new O-ring (Figure 4, Item 2) and adapter (Figure 4, Item 1) on relief valve (Figure 4, Item 3) and attach tee (Figure 4, Item 6) to adapter (Figure 4, Item 1).
8. Install new O-ring (Figure 4, Item 2) and adapter (Figure 4, Item 5) on relief valve (Figure 4, Item 3) and attach bypass hose (Figure 4, Item 4) to adapter (Figure 4, Item 5).




M0047HDC

Figure 4. Valve V21 (V22), Relief Valve, and Bypass Hose Installation.

**END OF TASK**



**FOLLOW-ON MAINTENANCE****WARNING**

Ensure right main hydraulic pressure inhibit valve V22 is fully opened prior to starting vehicle. A fully or partially closed valve will cause immediate high pressure. Failure to comply may result in damage to equipment and injury to personnel.

1. Restore hydraulic pressure (TM 5-2350-262-10).
2. Install filter guard protective bracket (TM 5-2350-262-20).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE  
HYDRAULIC DIAGNOSTIC CENTER (HDC) INTERCONNECTING HYDRAULIC HOSES AND TUBES  
REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Adapter, Socket Wrench  
(WP 0054, Table 1, Item 1)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)  
Plug, Hydraulic Tank (WP 0054, Table 1, Item 4)  
Wrench Set, Crowfoot (WP 0054, Table 1, Item 8)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2)

**Personnel Required**

Construction Equipment Repairer, 91L (Two)

**References**

TM 5-2350-262-20


**Equipment Condition**

Hydraulic pressure relieved (WP 0004)

---

**Equipment Condition (cont.)**

Vehicle MASTER power OFF (TM 5-2350-262-10)  
Apron locked in full-up position for hoses in the filter  
area (TM 5-2350-262-10)  
Ejector to front of vehicle for hoses in the filter area  
(TM 5-2350-262-10)  
Vehicle hull raised and blocked for hoses and tubes  
at the primary manifold and aft manifolds  
(TM 5-2350-262-20)  
Hull access plates removed for hoses and tubes at  
the primary and aft manifolds  
(TM 5-2350-262-20)

**REMOVAL****WARNING**


- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

**NOTE**

- The initial setup in this task indicates the materials/parts, references, and equipment conditions required to replace all associated Hydraulic Diagnostic Center (HDC) hydraulic tubes and hoses. You need only to requisition the items and perform the steps necessary for the hose or tube that you are replacing.
  - Though in different locations, all hydraulic tubes and hoses are disconnected and removed in the same manner. This task covers the replacement of only one hose. For location and configuration of hoses and tubes, refer to TM 5-2350-262-20.
1. Remove hose (Figure 1, Item 3) from adapter (Figure 1, Item 4) on primary manifold assembly (Figure 1, Item 5). Plug hose (Figure 1, Item 3) and cap adapter (Figure 1, Item 4) on manifold to prevent leakage.
  2. Remove other end of hose (Figure 1, Item 3) from adapter (Figure 1, Item 2) on main accumulator (Figure 1, Item 1). Plug hose (Figure 1, Item 2) and cap adapter (Figure 1, Item 2) to prevent leakage.

**END OF TASK****INSTALLATION**

1. Install hose (Figure 1, Item 3) at main accumulator (Figure 1, Item 1) adapter (Figure 1, Item 2).
2. Install other end of hose (Figure 1, Item 3) at primary manifold (Figure 1, Item 5) on adapter (Figure 1, Item 4).

**INSTALLATION - Continued**

M0052HDC

Figure 1. Hydraulic Diagnostic Center (HDC) Interconnecting Hydraulic Hoses and Tubes Removal/Installation.

**END OF TASK****FOLLOW-ON MAINTENANCE**

1. Return ejector to stowed position (TM 5-2350-262-10).
2. Return apron to stowed position (TM 5-2350-262-10).
3. Recharge hydraulic system (TM 5-2350-262-10).
4. Unblock and lower vehicle (TM 5-2350-262-20).
5. Install hull access plates (TM 5-2350-262-20).

**END OF TASK****END OF WORK PACKAGE**



---

**FIELD MAINTENANCE**  
**DIRECTIONAL CONTROL VALVE (DCV) BANK REPLACEMENT**

---

**INITIAL SETUP:****Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

**Personnel Required**

Construction Equipment Repairer, 91L


**Equipment Condition**

Ejector moved to front of vehicle  
(TM 5-2350-262-10)

**Materials/Parts**

Rag, Wiping (WP 0053, Table 1, Item 2) Qty: 2  
O-ring (WP 0055, Table 1, Item 21) Qty: 2

---

**REMOVAL****WARNING**

- High oil pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. After hydraulic system has been relieved, wait at least four minutes before disconnecting any hose or fitting. Ensure each of the hydraulic control levers is moved several times through all positions and the hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
- Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
- When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.

**CAUTION**

Cap or plug all oil ports and ends of hoses and tubes when oil hoses or tubes are disconnected or removed to prevent contamination. Failure to comply may result in damage to equipment.

**REMOVAL - Continued**

1. Remove hose (Figure 1, Item 5) from bottom adapter (Figure 1, Item 4) of manual shutoff valve V23 (Figure 1, Item 2).
2. Remove adapter (Figure 1, Item 4) and O-ring (Figure 1, Item 3) from bottom of manual shutoff valve V23 (Figure 1, Item 2). Discard O-ring.
3. Remove adapter (Figure 1, Item 6) and manual shutoff valve V23 (Figure 1, Item 2) from port 22 of Directional Control Valve (DCV) bank (Figure 1, Item 1).
4. Remove adapter (Figure 1, Item 6) and O-ring (Figure 1, Item 3) from top of manual shutoff valve V23 (Figure 1, Item 2). Discard O-ring.




Figure 1. Manual Shutoff Valve V23 Removal.

**END OF TASK**



## INSTALLATION

## WARNING



- Do not operate ejector when personnel are in bowl. Do not work in bowl unless ejector lock is engaged. Failure to comply may result in severe injury or death to personnel.
  - Do not stand or work in bowl area unless ejector lock is engaged. Do not stand in bowl to observe roller guide travels. Failure to comply may result in severe injury or death to personnel.
  - When folding dozer blade, work on blade latches from side of vehicle only. Do not stand in front of dozer blade while retracting ejector. Failure to comply may result in severe injury or death to personnel.
1. Install new O-ring (Figure 2, Item 3) and adapter (Figure 2, Item 6) in top of manual shutoff valve V23 (Figure 2, Item 2).
  2. Install adapter (Figure 2, Item 6) and manual shutoff valve V23 (Figure 2, Item 2) to port 22 of DCV bank (Figure 2, Item 1).
  3. Install new O-ring (Figure 2, Item 3) and adapter (Figure 2, Item 4) in bottom port of manual shutoff valve V23 (Figure 2, Item 2).
  4. Connect hose (Figure 2, Item 5) to bottom adapter (Figure 2, Item 4) of manual shutoff valve V23 (Figure 2, Item 2).




Figure 2. Manual Shutoff Valve V23 Installation.

END OF TASK

**FOLLOW-ON MAINTENANCE**

Return ejector to stowed position (TM 5-2350-262-10).

**END OF TASK**

**END OF WORK PACKAGE**

**FIELD MAINTENANCE  
HULL/EJECTOR INTERFERENCE REPLACEMENT**

**INITIAL SETUP:**

**Tools and Special Tools**

Tool Kit, General Mechanic's: Automotive  
(WP 0054, Table 1, Item 7)  
Lifting Device, Minimum Capacity 325 lb (148 kg)

**Materials/Parts (cont.)**

Bolt, Machine (WP 0055, Table 1, Item 23)  
Qty: 4  
Nut, Self-Locking (WP 0055, Table 1, Item 8)  
Qty: 1

**Materials/Parts**

Lubricating Oil, Engine  
(WP 0053, Table 1, Item 1)

**Personnel Required**

Construction Equipment Repairer, 91L

**Equipment Condition**

Hydraulic pressure relieved (WP 0004)  
Rear floor plates removed (TM 5-2350-262-20)

**WARNING**



Ejector cylinder weighs 325 lb (148 kg). Support ejector cylinder before disconnecting. Failure to comply may result in severe injury to personnel.

**CAUTION**

Ensure ejector cylinder end is securely supported when replacing bracket to avoid damaging engine and transmission hoses and fittings.

**REMOVAL**

1. Support rear ejector cylinder end (Figure 1, Item 5) and remove screw (Figure 1, Item 3), locknut (Figure 1, Item 6), and pin (Figure 1, Item 4) from ejector cylinder (Figure 1, Item 5) and bracket (Figure 1, Item 7). Discard locknut.
2. Remove four machine bolts (Figure 1, Item 2), washers (Figure 1, Item 1), and bracket (Figure 1, Item 7) from hull (Figure 1, Item 8). Discard machine bolts.


**END OF TASK**

**INSTALLATION**

**NOTE**

Apply lubricating oil to threads of screws prior to installation.

1. Install bracket (Figure 1, Item 7) on hull (Figure 1, Item 8) with four washers (Figure 1, Item 1) and new machine bolts (Figure 1, Item 2). Tighten four machine bolts (Figure 1, Item 2) to 123-135 lb-ft (167-183 N·m).
2. Install rear ejector cylinder end (Figure 1, Item 5) on bracket (Figure 1, Item 7) with pin (Figure 1, Item 4), screw (Figure 1, Item 3), and locknut (Figure 1, Item 6). Tighten screw (Figure 1, Item 3) to 20-22 lb-ft (27-30 N·m).



M0067HDC

Figure 1. Hull/Ejector Interference Modification Removal/Installation.

**END OF TASK**

**FOLLOW-ON MAINTENANCE**

Install rear floor plates (TM 5-2350-262-20).

**END OF TASK**

**END OF WORK PACKAGE**

---

## FIELD MAINTENANCE GENERAL MAINTENANCE

---

### INITIAL SETUP:

#### Tools and Special Tools

Parts Kit, Hydraulic (WP 0054, Table 1, Item 3)

#### Materials/Parts

Lubricating Oil, Engine  
(WP 0053, Table 1, Item 1)


---

### GENERAL HYDRAULIC SYSTEM REPAIR METHODS

This section contains repair methods for the hydraulic system. If special repair methods or procedures are required for the hydraulic system components or parts, specific repair instructions are included in the individual maintenance tasks in TM 5-2350-262-20.

### GENERAL HYDRAULIC SYSTEM REPAIR

#### WARNING



- High pressure is present in the M9 ACE hydraulic system. Do not disconnect any hydraulic system component unless hydraulic system pressure has been relieved. Ensure each hydraulic control lever is moved several times through all positions, and hydraulic tank dipstick is slowly loosened to relieve pressure. Failure to comply may result in severe injury or death to personnel.
- Main hydraulic pump weighs approximately 130 lb (59 kg). Severe injury to personnel could result if pump is not handled with caution.
- Before performing any hydraulic troubleshooting in the bowl, move the ejector forward and disable it by disconnecting the ejector cylinder or by engaging the ejector lock. Failure to comply may result in severe injury or death to personnel.
- Spilled hydraulic oil is very slippery. Be careful when entering or working in bowl area. Wipe up any spilled oil immediately. Failure to comply may result in severe injury to personnel.

**GENERAL HYDRAULIC SYSTEM REPAIR - Continued****CAUTION**

- Always clean around fittings before disconnecting or connecting hoses or fittings. Ensure area is clean before installing hydraulic components. Failure to comply may result in damage to equipment.
- Cover, cap, or plug all openings, ports, and tube or hose ends when they are disconnected. Failure to comply may result in damage to equipment.
- Ensure you mate only fittings designed to be mated with each other. Never depend on trial and error. Just because two fittings will screw together is no guarantee that the connection will not leak. See illustrations of fitting types in this work package. Failure to comply may result in damage to equipment.
- Fittings must be installed and hand-tightened. If a fitting cannot be hand-tightened, it may be cross-threaded or have damaged threads. Use wrench only for final tightening. Failure to comply may result in damage to equipment.
- Do not use Teflon tape as a sealer on any fittings. It can separate from the fittings and cause control valves, relief valves, and actuators to become contaminated and fail.
- It is possible to screw a male National Pipe Thread (NPT) into a female straight thread, but the fitting will leak. Learn to recognize the very slight taper which an NPT has. Do not attempt to connect NPT and female straight threads.
- Do not apply sealant to the first threads of NPT fittings. If sealant enters the hydraulic system, it may cause components to fail.
- When connecting NPTs, care must be exercised. If overtightened, the female pipe thread will split. Replace it. If a connection leaks, disconnect and apply thread sealant. Reconnect the threads and snug up with an open-end wrench. Failure to comply may result in damage to equipment.
- Be careful when installing preformed packings. Sharp threads can nick the packing, causing it to leak. If fitting leaks, check packing for nicks or cuts and replace if necessary.
- Do not overtighten a flareless connection. Observe torque values in appendix for hydraulic fittings. Overtightening can cause leakage, requiring replacement of entire tube assembly.
- When connecting a hose to a fitting, always use two wrenches. Use one wrench to turn the swivel nut onto the fitting, and use another wrench to keep the hose from rotating. If the hose rotates, it can loosen the other end of the hose, or loosen the fitting at the other end.


The following information is provided to familiarize personnel with the various types of hydraulic fittings. Refer to this work package and the WARNINGS and CAUTIONS on the previous pages when working on hydraulic systems.

**GENERAL HYDRAULIC SYSTEM REPAIR - Continued**

**CAUTION**

Do not apply sealant to the leading edge or the first thread of hydraulic fitting, or sealant may get into the hydraulic system and contaminate it. Failure to comply may result in damage to equipment.


1. National Pipe Thread (NPT) is commonly found in hydraulic systems. It differs from other fittings because it is tapered. In order to obtain a proper seal with this thread, you must use a sealant. The sealant should be applied to the male fitting (Figure 1). Torque value guide is NOT to be used.



T0007HDC

*Figure 1. National Pipe Thread (NPT) Fittings.*

2. The 37 degree flare termination has a male straight thread that mates with a female straight thread. The sealing surface for this termination is the angled nose at the end of the male fitting. This nose mates with a similar surface in the female 37 degree flare fitting (Figure 2). These sealing surfaces must be free of nicks and scratches in order to seal properly. If nicked or scratched, item must be replaced. For torque requirements, see guide in appendix.



T0008HDC

*Figure 2. 37 Degree Flare Termination Fitting.*

**GENERAL HYDRAULIC SYSTEM REPAIR - Continued**

3. An O-ring (preformed packing) boss has a straight thread. The seal for this termination is a preformed packing that fits at the top of the threads on the male fitting. This packing is squeezed into the extra space at the top of the threads of the female fitting and seals the connection (Figure 3). The installed packing must be free of nicks and cuts to seal properly. If packing is nicked or cut, it must be replaced.




Figure 3. O-Ring (Packing) Boss.

**CAUTION**

Packing must be located fully into groove and not on threads. Failure to comply may result in damage to equipment.

4. A flareless fitting uses a straight thread. The female fitting contains a ferrule that mates with a cavity in the male fitting (Figure 4). Use recommended torque values to tighten nut (TM 5-2350-262-20). If this fitting is overtightened, the ferrule will be deformed and the fitting will leak.





Figure 4. Flareless Fitting.



**GENERAL HYDRAULIC SYSTEM REPAIR - Continued****CAUTION**

Replace or repair parts with nicks, cuts, or scratches. Failure to comply may result in damage to equipment.

5. A four-bolt split flange has a flange head that is clamped to a smooth face. The flange head uses a preformed packing that is squeezed between the head and the face (Figure 5). The face and the end of flange head must be free of nicks and scratches to seal properly. The packing must also be free of nicks and cuts, or the connection will leak.



T0011HDC

Figure 5. Four-Bolt Split Flange.

**END OF TASK**


**INSTALLATION OF ADJUSTABLE FITTINGS**

1. Apply engine lubricating oil to O-ring (preformed packing) (Figure 6).

**CAUTION**

Packing must be positioned fully into groove and not on threads. Failure to comply may result in damage to equipment.

2. Gently push backup washer and O-ring all the way into groove (Figure 6).
3. Turn locknut down until locknut contacts backup washer (Figure 6).
4. Install fitting on boss until backup washer contacts face of boss (Figure 6).
5. Position fitting to desired position by backing out fitting up to one full turn. Hold fitting in desired position, and tighten locknut (Figure 6).
6. Connect tube to fitting after fitting is properly positioned and tightened (Figure 6).



T0012HDC

Figure 6. Adjustable Fittings.

**END OF TASK**

**END OF WORK PACKAGE**

**CHAPTER 5**  
**PARTS INFORMATION**



---

## FIELD MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS (RPSTL) INTRODUCTION

---

### SCOPE

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of Field maintenance of the Hydraulic Diagnostic Center (HDC) supporting the M9 ACE. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the source, maintenance, and recoverability (SMR) codes.

### GENERAL

In addition to the Introduction work package, this RPSTL is divided into the following work packages.

1. **Repair Parts List Work Packages.** Work packages containing lists of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. These work packages also include parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Sending units, brackets, filters, and bolts are listed with the component they mount on. Bulk materials are listed by item name in FIG. BULK at the end of the work packages. Repair parts kits are listed separately in their own functional group and work package. Repair parts for reparable special tools are also listed in a separate work package. Items listed are shown on the associated illustrations.
2. **Special Tools List Work Packages.** Work packages containing lists of special tools, special TMDE, and special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in the DESCRIPTION AND USABLE ON CODE (UOC) column). Tools that are components of common tool sets and/or Class VII are not listed.
3. **Cross-Reference Indexes Work Packages.** There are two cross-reference indexes work packages in this RPSTL: the National Stock Number (NSN) Index work package, and the Part Number (P/N) Index work package. The National Stock Number Index work package refers you to the figure and item number. The Part Number Index work package refers you to the figure and item number.

### EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES

**ITEM NO. (Column (1)).** Indicates the number used to identify items called out in the illustration.

**SMR CODE (Column (2)).** The SMR code containing supply/requisitioning information, maintenance level authorization criteria, and disposition instruction, as shown in the following breakout. This entry may be subdivided into 4 subentries, one for each service.

**EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued**

**Table 1. SMR Code Explanation.**

<u>SOURCE CODE</u>	<u>MAINTENANCE CODE</u>	<u>RECOVERABILITY CODE</u>
XX	XX	X
1st two positions: How to get an item.	3rd position: Who can install, replace, or use the item.	4th position: Who can do complete repair* on the item.
		5th position: Who determines disposition action on unserviceable items.

\*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

Source Code. The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

**Table 2. Source Code First and Second Position.**

<u>SOURCE CODE</u>	<u>APPLICATION/EXPLANATION</u>
PA	
PB	<p style="text-align: center;"><b>NOTE</b></p> <p>Items coded PC are subject to deterioration.</p> <p>Stock items; use the applicable NSN to requisition/request items with these source codes. They are authorized to the level indicated by the code entered in the third position of the SMR code.</p>
PC	
PD	
PE	
PF	
PG	
PH	
PR	
PZ	
KD	
KF	
KB	
MF-Made at field	<p>Items with these codes are not to be requisitioned/requested individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the bulk material group work package of the RPSTL. If the item is authorized to you by the third position code of the SMR code, but the source code indicates it is</p>
MH-Made at below sustainment level	
ML-Made at SRA	
MD-Made at depot	

**EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued**

*Table 2. Source Code First and Second Position - Continued.*

<u>SOURCE CODE</u>	<u>APPLICATION/EXPLANATION</u>
	made at higher level, order the item from the higher level of maintenance.
AF-Assembled by field AH-Assembled by below depot sustainment level AL-Assembled by SRA AD-Assembled by depot	Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the third position of the SMR code authorizes you to replace the item, but the source code indicates the item is assembled at a higher level, order the item from the higher level of maintenance.
XA	Do not requisition an "XA" coded item. Order the next higher assembly. (Refer to NOTE below.)
XB	If an item is not available from salvage, order it using the CAGEC and part number.
XC	Installation drawings, diagrams, instruction sheets, field service drawings; identified by manufacturer's part number.
XD	Item is not stocked. Order an XD-coded item through local purchase or normal supply channels using the CAGEC and part number given, if no NSN is available.

**NOTE**

Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes except for those items source coded "XA" or those aircraft support items restricted by requirements of AR 750-1.

**Maintenance Code.** Maintenance codes tell you the level(s) of maintenance authorized to use and repair support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

**Third Position.** The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following levels of maintenance:

*Table 3. Maintenance Code Third Position.*

<u>MAINTENANCE CODE</u>	<u>APPLICATION/EXPLANATION</u>
F-	Field maintenance can remove, replace, and use the item.

**EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued**

**Table 3. Maintenance Code Third Position - Continued.**

<u>MAINTENANCE CODE</u>	<u>APPLICATION/EXPLANATION</u>
H-	Below Depot Sustainment maintenance can remove, replace, and use the item.
L-	Specialized repair activity can remove, replace, and use the item.
Z-	Item is not authorized to be removed, replaced, or used at any maintenance level.
D-	Depot can remove, replace, and use the item.

**NOTE**

Army may use C in the third position. However, for joint service publications, Army will use O.

**Fourth Position.** The maintenance code entered in the fourth position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (perform all authorized repair functions).

**NOTE**

Some limited repair may be done on the item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.

**Table 4. Maintenance Code Fourth Position.**

<u>MAINTENANCE CODE</u>	<u>APPLICATION/EXPLANATION</u>
F-	Field is the lowest level that can do complete repair of the item.
H-	Below Depot Sustainment is the lowest level that can do complete repair of the item.
L-	Specialized repair activity (SRA) is the lowest level that can do complete repair of the item.
D-	Depot is the lowest level that can do complete repair of the item.
Z-	Nonreparable. No repair is authorized.
B-	No repair is authorized. No parts or special tools are authorized for maintenance of "B" coded item. However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

**Recoverability Code.** Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is shown in the fifth position of the SMR code as follows:



**EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued**

*Table 5. Recoverability Code Fifth Position.*

<u>RECOVERABILITY CODE</u>	<u>APPLICATION/EXPLANATION</u>
Z-	Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of SMR Code.
F-	Reparable item. When uneconomically repairable, condemn and dispose of the item at the field level.
H-	Reparable item. When uneconomically repairable, condemn and dispose of the item at the below depot sustainment level.
D-	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item are not authorized below depot level.
L-	Reparable item. Condemnation and disposal not authorized below Specialized Repair Activity (SRA).
A-	Item requires special handling or condemnation procedures because of specific reasons (such as precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

**NSN (Column (3)).** The NSN for the item is listed in this column.

**CAGEC (Column (4)).** The Commercial and Government Entity Code (CAGEC) is a five-digit code which is used to identify the manufacturer, distributor, or Government agency/activity that supplies the item.

**PART NUMBER (Column (5)).** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

**NOTE**

When you use an NSN to requisition an item, the item you receive may have a different part number from the number listed.

**DESCRIPTION AND USABLE ON CODE (UOC) (Column (6)).** This column includes the following information:

1. The federal item name, and when required, a minimum description to identify the item.
2. Part numbers of bulk materials are referenced in this column in the line entry to be manufactured or fabricated.
3. Hardness Critical Item (HCI). A support item that provides the equipment with special protection from electromagnetic pulse (EMP) damage during a nuclear attack.
4. The statement END OF FIGURE appears just below the last item description in column (6) for a given figure in both the repair parts list and special tools list work packages.

**QTY (Column (7)).** The QTY (quantity per figure) column indicates the quantity of the item used in the breakout shown on the illustration/figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column instead of a quantity indicates that the quantity is variable and quantity may change from application to application.

## EXPLANATION OF CROSS-REFERENCE INDEXES WORK PACKAGES FORMAT AND COLUMNS

1. **National Stock Number (NSN) Index Work Package.** NSN's in this index are listed in National Item Identification Number (NIIN) sequence.

**STOCK NUMBER Column.** This column lists the NSN in NIIN sequence. The NIIN consists of the last nine digits of the NSN. When using this column to locate an item, ignore the first four digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

For example, if the NSN is 5385-01-574-1476, the NIIN is 01-574-1476.

**FIG. Column.** This column lists the number of the figure where the item is identified/located. The figures are in numerical order in the repair parts list and special tools list work packages.

**ITEM Column.** The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

2. **Part Number (P/N) Index Work Package.** Part numbers in this index are listed in ascending alphanumeric sequence (vertical arrangement of letter and number combinations which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

**PART NUMBER Column.** Indicates the part number assigned to the item.

**FIG. Column.** This column lists the number of the figure where the item is identified/located in the repair parts list and special tools list work packages.

**ITEM Column.** The item number is the number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

## SPECIAL INFORMATION

**Fabrication Instructions.** Bulk materials required to manufacture items are listed in the bulk material functional group of this RPSTL. Part numbers for bulk material are also referenced in the Description Column of the line item entry for the item to be manufactured/fabricated. Detailed fabrication instructions for items source coded to be manufactured or fabricated are found in Illustrated List of Manufactured Items.

**Index Numbers.** Items which have the word BULK in the figure column will have an index number shown in the item number column. This index number is a cross-reference between the NSN/Part Number (P/N) Index work packages and the bulk material list in the repair parts list work package.

## HOW TO LOCATE REPAIR PARTS

### 1. When NSNs or Part Numbers Are Not Known.

First. Using the table of contents, determine the assembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and lists are divided into the same groups.

Second. Find the figure covering the functional group or the subfunctional group to which the item belongs.

Third. Identify the item on the figure and note the number(s).

Fourth. Look in the repair parts list work packages for the figure and item numbers. The NSNs and part numbers are on the same line as the associated item numbers.

### 2. When NSN Is Known.

First. If you have the NSN, look in the STOCK NUMBER column of the NSN index work package. The NSN is arranged in NIIN sequence. Note the figure and item number next to the NSN.

Second. Turn to the figure and locate the item number. Verify that the item is the one you are looking for.

**HOW TO LOCATE REPAIR PARTS - Continued****3. When Part Number is Known.**

First. If you have the part number and not the NSN, look in the PART NUMBER column of the part number index work package. Identify the figure and item number.


Second. Look up the item on the figure in the applicable repair parts list work package.

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
GROUP AQ01 HYDRAULIC CONTROL INSTALLATION**

---



R0026T78

Figure 1. Hydraulic Control Levers and Linkage.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP AQ01 HYDRAULIC CONTROL INSTALLATION.</b>						
<b>FIG. 1. HYDRAULIC CONTROL LEVERS AND LINKAGE.</b>						
1	PAFZZ	5355-01-179-9116	97403	13211E9392-2	KNOB RED.....	2
2	PFFZZ	3040-01-179-9210	19207	12325792	SHAFT,STRAIGHT.....	1
3	PFFFF	3040-01-179-9222	19207	12332232	BELL CRANK.....	1
4	PAFZZ	3120-01-179-9151	19207	12331895-1	. BEARING,SLEEVE.....	2
5	XAFZZ		19207	12331885	. BELLCRANK.....	1
6	PAFZZ	5315-00-468-1635	80205	MS35674-48	PIN,GROOVED,HEADLES.....	1
7	PFFFF	3040-01-186-8004	19207	12332097-3	BELL CRANK.....	1
8	PAFZZ	3120-01-179-9151	19207	12331895-1	. BEARING,SLEEVE.....	2
9	XAFZZ		19207	12325799-3	. BELLCRANK.....	1
10	PFFFF	3040-01-179-9221	19207	12332097-2	BELL CRANK.....	1
11	PAFZZ	3120-01-179-9151	19207	12331895-1	. BEARING,SLEEVE.....	2
12	XAFZZ		19207	12325799-2	. BELLCRANK.....	1
13	PAFZZ	5315-00-815-8840	96906	MS35810-4	PIN,STRAIGHT,HEADED.....	7
14	PAFZZ	5340-00-985-0823	08277	2708-4A	CLEVIS,ROD END.....	7
15	PAFZZ	5315-00-842-3044	80205	MS24665-283	PIN,COTTER.....	7
16	PAFZZ	5310-00-975-2075	96906	MS35691-21	NUT,PLAIN,HEXAGON.....	7
17	PAFZZ	5355-01-181-6415	97403	13211E9392-1	KNOB BLACK.....	2
18	PFFFF	3040-01-179-9220	19207	12332097-1	BELL CRANK.....	1
19	PAFZZ	3120-01-179-9151	19207	12331895-1	. BEARING,SLEEVE.....	2
20	XAFZZ		19207	12325799-1	. BELLCRANK.....	1
21	PFFZZ	5306-01-194-0004	19207	12335109-2	ROD,THREADED END.....	2
22	PAFZZ	5310-00-853-9335	96906	MS35691-13	NUT,PLAIN,HEXAGON.....	7
23	PAFZZ	5340-01-212-0433	97403	13214E2272	CLEVIS,ROD END.....	7
24	PAFZZ	5315-00-839-2325	15434	109155	PIN,COTTER.....	7
25	PAFZZ	5315-00-081-7875	00462	1141-51	PIN,STRAIGHT,HEADED.....	7
26	PFFZZ	5306-01-194-0003	19207	12335109-1	ROD,THREADED END.....	4
27	PFFZZ	5306-01-194-7033	19207	12335109-3	ROD,THREADED END.....	1

END OF FIGURE





**FIELD MAINTENANCE  
GROUP A501 WINCH INSTALLATION**

---




Figure 2. Winch Assembly -7D3-05815.

R002778


(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A501 WINCH INSTALLATION.</b>						
<b>FIG. 2. WINCH ASSEMBLY -7D3-05815.</b>						
1	PAFHH	2590-01-440-8736	34712	7D3-05815	WINCH,DRUM,VEHICLEM 35,000 LB FULL CAPACITY.....	1
2	PAFZA	5330-01-440-7575	34712	7B1-06951	. PACKING,PREFORMED.....	2
3	PFFZZ	2590-01-440-8752	34712	7D1-06124	. COVER,WINCH.....	1
4	PAFZZ	5310-00-809-5998	96906	MS27183-18	. WASHER,FLAT.....	20
5	PAFZZ	5305-00-543-4372	80204	B1821BH038C075N	. SCREW,CAP,HEXAGON H.....	20
6	PAFZA	5330-01-440-7577	34712	7B1-06965	. GASKET.....	2
7	PFFZZ	3120-01-175-9336	70417	TT-2304-02	. BEARING,WASHER,THRU.....	2
8	PAFZZ	5305-00-071-2081	80204	B1821BH050C450N	. SCREW,CAP,HEXAGON H.....	2
9	PAFFF	2540-01-461-5899	34712	7D3-06212	. MOTOR,HYDRAULIC.....	1
10	PAFZZ	4720-01-441-1294	34712	7B8-06961	. . HOSE ASSEMBLY,NONME.....	1
11	PAFZZ	5305-00-071-2067	80204	B1821BH050C125N	. . SCREW,CAP,HEXAGON H.....	4
12	PAFZZ	5305-00-846-5703	80204	B1821BH038C300N	. . SCREW,CAP,HEXAGON H.....	3
13	PAFZZ	4730-01-440-5269	54035	9510-179-A06	. . MANIFOLD ASSEMBLY,H.....	1
14	PAFZZ	4730-00-822-5609	96906	MS51527A8	. . ELBOW,TUBE TO BOSS 90 DEGREES WITH O-RING.....	2
15	PAFZZ	4730-00-811-1848	96906	MS51527A4P	. . ELBOW,TUBE TO BOSS 90 DEGREES WITH O-RING.....	3
16	XAFZZ	2530-01-415-9449	92865	3B-131240-L2	. . BRAKE,MULTIPLE DISK.....	1
17	PAFZZ	4010-01-440-9273	34712	7B1-6946	. WIRE ROPE ASSEMBLY,.....	1
18	PAFZZ	5305-00-071-2067	80204	B1821BH050C125N	. SCREW,CAP,HEXAGON H.....	2
19	PAFZZ	5365-01-116-3731	30780	5HP50NSS	. PLUG,MACHINE THREAD.....	3
20	PAFZA	5330-00-180-9037	80201	4984	. SEAL,PLAIN ENCASED.....	1
21	PAFDD	3040-01-495-5955	34712	7D3-06213	ACTUATOR,MECHANICAL.....	1
22	PFFZZ	5340-01-440-1445	34712	7C1-05925	. COVER,ACCESS.....	1
23	PAFZZ	5305-00-068-0510	05047	B1821BH038C100N	. SCREW,CAP,HEXAGON H.....	8
24	PAFZZ	5310-01-442-6932	39428	93783A031	. WASHER,SEAL.....	2
25	PAFZZ	5310-01-335-7092	96906	MS27183-11	. WASHER,FLAT.....	2
26	PAFZZ	5310-00-851-2682	96906	MS35691-17	. NUT,PLAIN,HEXAGON.....	2
27	PAFZZ	5310-00-809-5997	96906	MS27183-17	. WASHER,FLAT.....	2
28	PFFZZ	3040-01-440-7132	34712	7B1-06949	. LEVER,REMOTE CONTRO.....	1
29	PAFZZ	5315-00-842-3044	80205	MS24665-283	. PIN,COTTER.....	1
30	PAFZZ	5315-01-317-2696	06970	CP103	. PIN,STRAIGHT,HEADED.....	1
31	PAFZZ	5340-00-400-3606	06970	AC218	. CLEVIS.....	1

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
32	PAFZZ	5306-00-226-4824	80204	B1821BH031C063N	. BOLT,MACHINE.....	1
33	PAFZZ	5305-01-373-6291	96906	MS51576-37	. SCREW,SHOULDER.....	1
34	PFFZZ	5305-00-253-5625	80205	MS21318-46	. SCREW,DRIVE.....	2
35	PFFZZ	9905-01-440-7208	34712	7B1-07039	. PLATE,IDENTIFICATIO.....	1
36	PAFZZ	5306-01-456-9447	06970	161-010-004	. BOLT,U.....	1
37	PFFZZ	5340-01-440-1443	34712	7B1-06950	. BRACKET,ANGLE.....	1
38	PAFZZ	5305-00-071-2066	80204	B1821BH050C100N	. SCREW,CAP,HEXAGON H.....	2
39	PFFZZ	5340-01-440-8652	34712	7B1-06991	. BRACKET,MOUNTING.....	2
40	PAFZZ	4030-01-472-9767	19207	12466295-1	SHACKLE.....	1
41	PAFZZ	5315-00-234-1673	80205	MS24665-688	. PIN,COTTER PART OF P/N 12466295.....	1
42	PAFZZ	5310-01-454-5759	2T469	C0122-N	. NUT,PLAIN,HEXAGON PART OF P/N 12466295.....	1
43	XAFZZ		19207	12466295-A	. BOLT,MACHINE PART OF P/N 12466295.....	1
44	XAFZZ		19207	12466295-B	. SHACKLE PART OF P/N 12466295.....	1
45	PAFZZ	2540-01-454-0663	2T469	C0120	HOOK,TOW.....	1
46	PAFFF	4010-01-460-7224	19207	12412159	WIRE ROPE ASSEMBLY,.....	1
47	PAFZZ	4030-01-454-2066	75535	1037390	THIMBLE,ROPE USE FOR WIRE ROPE REPAIR ONLY.....	1
48	PAFZZ	4030-00-243-4442	96906	MS16842-9	CLAMP,WIRE ROPE,SAD USE FOR WIRE ROPE REPAIR ONLY.....	4

END OF FIGURE

**FIELD MAINTENANCE  
GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS**

---



R0001T78

Figure 3. Hydraulic Diagnostic Center (HDC) Control Box.


(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
--------------------	-----------------	------------	--------------	--------------------	--	------------

GROUP A801 HYDRAULIC  
DIAGNOSTIC CENTER COMPONENTS.

FIG. 3. HYDRAULIC DIAGNOSTIC  
CENTER (HDC) CONTROL BOX.

1	PAFHL	6110-01-537-8428	19207	12496937	DISTRIBUTION BOX.....	1
---	-------	------------------	-------	----------	-----------------------	---

END OF FIGURE




R0002778

Figure 4. Hydraulic Diagnostic Center (HDC) Stowage Bracket.



(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 4. HYDRAULIC DIAGNOSTIC CENTER (HDC) STOWAGE BRACKET.</b>						
1	PAFZZ	5310-00-815-1073	26233	S-7926	NUT,SELF-LOCKING,WI.....	2
2	PAFZZ	5340-01-536-9863	19207	12496933	BRACKET,MOUNTING.....	1
3	PAFZZ	5307-01-536-0580	80205	NAS1454C4A-0504	STUD,CONTINUOUS THR.....	2
4	PAFZZ	5310-00-761-6882	96906	MS51967-2	NUT,PLAIN,HEXAGON.....	2
5	PAFZZ	5310-00-285-8124	96906	MS27183-50	WASHER,FLAT.....	2
6	PAFZZ	2590-01-536-1519	19207	12496932	PAD,CUSHIONING.....	2

**END OF FIGURE**




R0003T78

Figure 5. Hydraulic Diagnostic Center (HDC) Disconnect Bracket.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<p><b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b></p> <p><b>FIG. 5. HYDRAULIC DIAGNOSTIC CENTER (HDC) DISCONNECT BRACKET.</b></p>						
1	PAFZZ	5306-01-175-7558	80204	B1821BH025C075L	BOLT,MACHINE.....	2
2	PAFZZ	5310-00-285-8124	96906	MS27183-50	WASHER,FLAT.....	2
3	PAFZZ	2590-01-536-3813	19207	12496964	BRACKET,VEHICULAR C.....	1

**END OF FIGURE**




R0004T78

Figure 6. Hydraulic Diagnostic Center (HDC) Circuit Breaker.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<p><b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b></p> <p><b>FIG. 6. HYDRAULIC DIAGNOSTIC CENTER (HDC) CIRCUIT BREAKER.</b></p>						
1	PAFZZ	5310-00-934-9757	80205	MS35649-282	NUT,PLAIN,HEXAGON.....	2
2	PAFZZ	5310-00-559-0070	72582	115544	WASHER,LOCK.....	2
3	PAFZZ	5925-01-430-2318	58536	AA55571/01-001	CIRCUIT BREAKER.....	1
4	PAFZZ	5305-00-984-6197	05869	4177205-028	SCREW,MACHINE.....	2

**END OF FIGURE**




R0005T78

Figure 7. Hydraulic Diagnostic Center (HDC) Power Components.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<p><b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b></p> <p><b>FIG. 7. HYDRAULIC DIAGNOSTIC CENTER (HDC) POWER COMPONENTS.</b></p>						
1	PAFZZ	6150-01-536-3072	19207	12496957	LEAD,ELECTRICAL.....	1
2	PAFZZ	5935-00-900-6281	96906	MS27147-1	ADAPTER,CONNECTOR.....	1
3	PAFZZ	5935-00-807-4109	19207	8741492	ADAPTER,CONNECTOR.....	1
4	PAFZZ	6150-01-536-2015	19207	12496958	LEAD,ELECTRICAL.....	1

**END OF FIGURE**



R0006T78


Figure 8. Wiring Harness W1.



(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
--------------------	-----------------	------------	--------------	--------------------	--	------------

					GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.	
					FIG. 8. WIRING HARNESS W1.	
1	PAFZZ	6150-01-536-1117	19207	12496953	CABLE ASSEMBLY,SPEC.....	1

END OF FIGURE




R0007778

Figure 9. Wiring Harness W2.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
--------------------	-----------------	------------	--------------	--------------------	--	------------

					GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.	
					FIG. 9. WIRING HARNESS W2.	
1	PAFZA	6150-01-536-2129	19207	12496954	CABLE ASSEMBLY,SPEC.....	1

END OF FIGURE




R0008T78

Figure 10. Wiring Harness W3.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
--------------------	-----------------	------------	--------------	--------------------	--	------------

1	PAFZA	6150-01-536-3311	19207	12496955	<p>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</p> <p>FIG. 10. WIRING HARNESS W3. CABLE ASSEMBLY,SPEC.....</p>	1
---	-------	------------------	-------	----------	---	---

END OF FIGURE



R0009T78

Figure 11. Wiring Harness W4.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
--------------------	-----------------	------------	--------------	--------------------	--	------------

					GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.	
					FIG. 11. WIRING HARNESS W4.	
1	PAFZZ	6150-01-536-5854	19207	12496956	CABLE ASSEMBLY,SPEC.....	1

END OF FIGURE




Figure 12. Pressure Transducers.




(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
--------------------	-----------------	------------	--------------	--------------------	--	------------

**GROUP A801 HYDRAULIC  
DIAGNOSTIC CENTER COMPONENTS.**

**FIG. 12. PRESSURE TRANSDUCERS.**

1	PCFZZ	5331-00-805-2966	81343	MS28778-4	O-RING.....	3
2	PAFZZ	6695-01-536-2040	19207	12496923	TRANSDUCER,PRESSURE.....	3
3	PAFZZ	4730-01-537-0516	30780	8-4XHX6G5TP	TEE,BOSS.....	8

**END OF FIGURE**




R001178

Figure 13. Mounting Brackets, Primary Manifold.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 13. MOUNTING BRACKETS, PRIMARY MANIFOLD.</b>						
1	PAFZZ	5340-01-536-1486	19207	12496959	PLATE,MOUNTING.....	1
2	PAFZZ	5310-00-483-8790	80205	MS17829-6C	NUT,SELF-LOCKING,HE.....	2
3	PAFZZ	5310-00-877-5972	19200	10910174-3	WASHER,FLAT (USED IN DISTRIBUTION BOX)PRIMARY MANIF/GPA.....	17
4	PAFZZ	2590-01-537-2318	19207	12496944	BRACKET,VEHICULAR C.....	1
5	PAFZZ	5306-01-114-0963	80204	B1821BH038C100L	BOLT,MACHINE (USED IN PRIMARY MANIFOLD)BKTS/GPA.....	11
6	PAFZZ	5306-01-196-0442	80204	B1821BH050C113L	BOLT,MACHINE.....	8
7	PAFZZ	5310-00-809-5998	96906	MS27183-18	WASHER,FLAT.....	8
8	PAFZZ	5305-00-068-0511	80204	B1821BH038C125N	SCREW,CAP,HEXAGON H.....	2
9	PAFZZ	5340-01-536-2060	19207	12496952	BRACKET,ANGLE.....	1
10	PAFZZ	5306-01-194-0591	80204	B1821BH038C200L	BOLT,MACHINE (USED IN DIST BOX)MANIF BKT/PRIMARY MANIF/ GPA.....	2
11	PAFZZ	5340-01-536-4160	19207	12496927	BRACKET,ANGLE.....	1
12	PAFZZ	5305-00-071-2073	80204	B1821BH050C250N	SCREW,CAP,HEXAGON H.....	1
13	PAFZZ	5310-00-866-4417	19207	10910174-5	WASHER,FLAT.....	3
14	PAFZZ	5310-00-595-7421	80205	MS17829-8C	NUT,SELF-LOCKING,HE.....	1
15	PAFZZ	5340-01-536-7170	19207	12496924	BRACKET,MOUNTING.....	1

**END OF FIGURE**



R0020T78

Figure 14. Left Main Manifold.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<p><b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b></p> <p><b>FIG. 14. LEFT MAIN MANIFOLD.</b></p>						
1	PAFZZ	4730-00-812-2434	96906	MS51521A8	ELBOW,TUBE (USED IN DISTRIBUTION BOX)LT.MAIN MANIF/GP:A.....	4
2	PAFZZ	4730-01-139-1585	81343	SAE J514 10-10 070221S	ELBOW,TUBE (USED IN DISTRIBUTION BOX)LT.MAIN MANIF/GP:A.....	1

**END OF FIGURE**







Figure 15. Primary Manifold Assembly. (Sheet 1 of 2)

R0012T78



R0013T78

Figure 15. Primary Manifold Assembly. (Sheet 2 of 2)




(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 15. PRIMARY MANIFOLD ASSEMBLY.</b>						
1	PAFFZ	4810-01-536-2997	14775	SB70-DO-24AD	VALVE,SOLENOID.....	3
2	PAFZZ	5331-01-514-0923	81343	MS28775-118	. O-RING.....	1
3	PAFZZ	5330-01-118-5705	96906	MS27595-019	. RETAINER,PACKING.....	2
4	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	1
5	PAFFZ	4810-01-536-6609	14775	SB70-DC-24AD	VALVE,SOLENOID.....	2
6	PAFZZ	5331-01-514-0923	81343	MS28775-118	. O-RING.....	1
7	PAFZZ	5330-01-118-5705	96906	MS27595-019	. RETAINER,PACKING.....	2
8	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	1
9	PAFFZ	4810-01-536-5871	19207	12496936	VALVE,SOLENOID.....	6
10	PCFZZ	5331-01-219-7930	81343	MS28778-12	. O-RING.....	1
11	PAFZZ	5330-00-720-3652	96906	MS28774-019	. RETAINER,PACKING.....	2
12	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	1
13	PAFZZ	5330-00-839-1846	96906	MS28774-018	. RETAINER,PACKING.....	2
14	PCFZZ	5331-00-618-0799	62983	196425	. O-RING.....	1
15	PAFZZ	6695-01-536-2040	19207	12496923	TRANSDUCER,PRESSURE.....	1
16	PCFZZ	5331-00-805-2966	81343	MS28778-4	O-RING.....	1
17	PAFZZ	4730-01-536-3025	19207	12496935	MANIFOLD,HYDRAULIC.....	1
18	PCFZZ	5331-00-805-2966	81343	MS28778-4	O-RING.....	5
19	PAFZZ	5365-01-200-1519	19207	12335054-2	PLUG,MACHINE THREAD.....	5
20	PCFZZ	5365-01-228-0730	19207	12335054-5	PLUG,MACHINE THREAD.....	6
21	PCFZZ	5331-00-808-0794	81343	MS28778-8	O-RING.....	16
22	PAFZZ	4730-01-156-4835	96906	MS51525A8	ADAPTER,STRAIGHT,TU.....	6
23	PCFZZ	5331-00-108-5691	81343	MS28778-10	O-RING.....	2
24	PAFZZ	4730-01-192-9590	96906	MS51526A10	ADAPTER,STRAIGHT,TU.....	1
25	PAFZZ	4730-00-822-5609	96906	MS51527A8	ELBOW,TUBE TO BOSS.....	3
26	PAFZA	4820-00-550-6786	8Z296	1A30-01-V-0-E-D-304	VALVE,SAFETY RELIEF.....	1
27	PAFZZ	4730-00-936-2172	96906	MS51528A10Z	ELBOW,TUBE TO BOSS.....	1
28	PAFZZ	4730-01-236-2682	96906	MS51528A8Z	ELBOW,TUBE TO BOSS.....	1
29	PAFZZ	5365-01-242-4564	19207	12335054-4	PLUG,MACHINE THREAD.....	1

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
30	PCFZZ	5331-00-804-5695	62983	151548	O-RING.....	1

END OF FIGURE






R0021T78

Figure 16. Forward Left Manifold Mounting and Hose Interconnections.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<p><b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b></p> <p><b>FIG. 16. FORWARD LEFT MANIFOLD MOUNTING AND HOSE INTERCONNECTIONS.</b></p>						
1	PCFZZ	4720-01-195-3838	97403	13214E2495-2	HOSE ASSEMBLY, NONME HOSE, ASSY, NONME (USED DIST BOX) FWR LT. MANIF/HOSE/GP:A.....	1
2	PAFZZ	4720-01-541-1308	97403	13214E2495-8	HOSE ASSEMBLY, NONME (USED DIST BOX) FWR LT. MANIF/HOSE/GP:A....	1
3	PAFZZ	4720-01-541-0697	97403	13214E2495-9	HOSE ASSEMBLY, NONME.....	1
4	PAFZZ	4710-01-179-7619	97403	13214E2751	TUBE ASSEMBLY, METAL.....	1
5	PAFZZ	4710-01-179-7623	97403	13214E2755	TUBE ASSEMBLY, METAL.....	1
6	PAFZZ	4710-01-179-7621	97403	13214E2753	TUBE ASSEMBLY, METAL.....	1
7	PAFZZ	4720-01-181-6166	19207	13214E2500-1	HOSE ASSEMBLY, NONME HOSE, ASSY, NONME (USED DIST BOX) FWR LT. MANIF/HOSE/GP:A.....	1
8	PAFZZ	5306-01-194-0591	80204	B1821BH038C200L	BOLT, MACHINE (USED IN DIST BOX) FWR LT. MANIF/HOSE/GP:A.....	2
9	PAFZZ	5310-00-877-5972	19200	10910174-3	WASHER, FLAT (USED DISTRIBUTION BOX) FORWARD LT. MANIF/GPA.....	2
10	PCFZZ	4720-01-195-3841	98441	A2660-1	HOSE ASSEMBLY, NONME (USED DIST BOX) FWR LT. MANIF/HOSE/GP:A....	1

**END OF FIGURE**




R0014T78

Figure 17. Forward Left Manifold Assembly.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 17. FORWARD LEFT MANIFOLD ASSEMBLY.</b>						
1	PAFFZ	4730-01-536-2677	19207	12496934	MANIFOLD, HYDRAULIC.....	1
2	PCFZZ	5331-00-804-5695	62983	151548	O-RING.....	4
3	PAFZZ	4730-00-143-3941	96906	MS51527A6	ELBOW, TUBE TO BOSS.....	1
4	PAFZZ	4730-00-585-2309	96906	MS51527A4	ELBOW, TUBE TO BOSS.....	2
5	PCFZZ	5331-00-805-2966	81343	MS28778-4	O-RING.....	2
6	PAFZZ	4730-00-679-9766	96906	MS51528A6	. ELBOW, TUBE TO BOSS.....	1
7	PAFZZ	4730-00-062-5470	96906	MS51528B8	ELBOW, TUBE TO BOSS.....	1
8	PCFZZ	5331-00-808-0794	81343	MS28778-8	O-RING.....	2
9	PAFFZ	6695-01-536-2040	19207	12496923	TRANSDUCER, PRESSURE.....	1
10	PCFZZ	5331-00-805-2966	81343	MS28778-4	. O-RING.....	1
11	PAFFZ	4810-01-536-2997	14775	SB70-DO-24AD	VALVE, SOLENOID.....	2
12	PAFZZ	5330-01-118-5705	96906	MS27595-019	. RETAINER, PACKING.....	2
13	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	1
14	PAFZZ	5331-01-514-0923	81343	MS28775-118	. O-RING.....	1
15	PAFZZ	4730-00-491-9576	96906	MS51525A6	ADAPTER, STRAIGHT, TU.....	2
16	PAFZZ	4730-01-156-4835	96906	MS51525A8	ADAPTER, STRAIGHT, TU.....	1

END OF FIGURE




R0022T78

Figure 18. Forward Right Manifold Mounting and Hose Interconnections.



(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 18. FORWARD RIGHT MANIFOLD MOUNTING AND HOSE INTERCONNECTIONS.</b>						
1	PAFZZ	4720-01-541-1308	97403	13214E2495-8	HOSE ASSEMBLY, NONME.....	1
2	PCFZZ	4720-01-195-3838	97403	13214E2495-2	HOSE ASSEMBLY, NONME.....	1
3	PCFZZ	4720-01-195-3841	98441	A2660-1	HOSE ASSEMBLY, NONME (USED DIST BOX) FWR RT. MANIF/HOSE/ GP:A.....	1
4	PAFZZ	5310-00-877-5972	19200	10910174-3	WASHER, FLAT (USED DISTRIBUTION BOX) FORWARD RT. MANIF/GPA.....	2
5	PAFZZ	5306-01-194-0591	80204	B1821BH038C200L	BOLT, MACHINE (USED IN DIST BOX) FWR RT. MANIF/HOSE/GP:A.....	2
6	PAFZZ	4720-01-181-6166	19207	13214E2500-1	HOSE ASSEMBLY, NONME.....	1
7	PAFZZ	4710-01-179-7620	19207	13214E2752	TUBE ASSEMBLY, METAL.....	1
8	PAFZZ	4710-01-179-7622	97403	13214E2754	TUBE ASSEMBLY, METAL.....	1
9	PAFZZ	4710-01-179-7618	97403	13214E2750	TUBE ASSEMBLY, METAL.....	1
10	PAFZZ	4720-01-541-0697	97403	13214E2495-9	HOSE ASSEMBLY, NONME.....	1

**END OF FIGURE**




R0015T78

Figure 19. Forward Right Manifold Assembly.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 19. FORWARD RIGHT MANIFOLD ASSEMBLY.</b>						
1	PAFZZ	6695-01-536-2040	19207	12496923	TRANSDUCER,PRESSURE.....	1
2	PCFZZ	5331-00-805-2966	81343	MS28778-4	. O-RING.....	1
3	PCFZZ	5331-00-805-2966	81343	MS28778-4	O-RING.....	2
4	PAFZZ	4730-00-585-2309	96906	MS51527A4	ELBOW,TUBE TO BOSS.....	2
5	PAFZZ	4730-00-062-5470	96906	MS51528B8	ELBOW,TUBE TO BOSS.....	1
6	PCFZZ	5331-00-808-0794	81343	MS28778-8	O-RING.....	2
7	PAFZZ	4730-00-679-9766	96906	MS51528A6	. ELBOW,TUBE TO BOSS.....	1
8	PCFZZ	5331-00-804-5695	62983	151548	O-RING.....	4
9	PAFZZ	4730-00-143-3941	96906	MS51527A6	ELBOW,TUBE TO BOSS.....	1
10	PAFZZ	4730-01-536-5726	19207	12496948	MANIFOLD,HYDRAULIC.....	1
11	PAFZZ	4730-00-491-9576	96906	MS51525A6	ADAPTER,STRAIGHT,TU.....	2
12	PAFZZ	4730-01-156-4835	96906	MS51525A8	ADAPTER,STRAIGHT,TU.....	1
13	PAFFZ	4810-01-536-2997	14775	SB70-DO-24AD	VALVE,SOLENOID.....	2
14	PAFZZ	5331-01-514-0923	81343	MS28775-118	. O-RING.....	2
15	PAFZZ	5330-01-118-5705	96906	MS27595-019	. RETAINER,PACKING.....	4
16	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	2

END OF FIGURE




R0023T78

Figure 20. Aft Manifold Mounting and Hose Interconnections.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 20. AFT MANIFOLD MOUNTING AND HOSE INTERCONNECTIONS.</b>						
1	PAFZZ	4720-01-540-6760	97403	13214E2495-7	HOSE ASSEMBLY,NONME.....	1
2	PAFZZ	4720-01-446-7545	01276	FG1011GGG0360	HOSE ASSEMBLY,NONME.....	1
3	PAFZZ	5305-01-449-7391	80204	B1821BH038C325L	SCREW,CAP,HEXAGON H.....	3
4	PAFZZ	5310-00-877-5972	19200	10910174-3	WASHER,FLAT (USED DISTRIBUTION BOX)AFT MANIFOLD/GPA.....	3
5	PAFZZ	4720-01-537-0586	97403	13214E2501-11	HOSE ASSEMBLY,NONME.....	1
6	PAFZZ	4730-00-618-5372	96906	MS51521A6	ELBOW,TUBE.....	1
7	PAFZZ	4720-01-536-8728	97403	13214E2486-2	HOSE ASSEMBLY,NONME.....	1
8	PAFZZ	4720-01-538-3157	97403	13214E2486-3	HOSE ASSEMBLY,NONME.....	1
9	PCFZZ	4720-01-536-8024	97403	13214E2495-6	HOSE ASSEMBLY,NONME.....	1

**END OF FIGURE**




R0016T78

Figure 21. Aft Manifold Assembly.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 21. AFT MANIFOLD ASSEMBLY.</b>						
1	PAFFZ	4810-01-536-2997	14775	SB70-DO-24AD	VALVE,SOLENOID.....	3
2	PAFZZ	5331-01-514-0923	81343	MS28775-118	. O-RING.....	1
3	PAFZZ	5330-01-118-5705	96906	MS27595-019	. RETAINER,PACKING.....	2
4	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	1
5	PAFZZ	4730-00-143-3941	96906	MS51527A6	ELBOW,TUBE TO BOSS.....	1
6	PCFZZ	5331-00-804-5695	62983	151548	O-RING.....	2
7	PCFZZ	5331-00-808-0794	81343	MS28778-8	O-RING.....	1
8	PCFZZ	5365-01-228-0730	19207	12335054-5	PLUG,MACHINE THREAD.....	1
9	PAFZZ	4730-00-491-9576	96906	MS51525A6	ADAPTER,STRAIGHT,TU.....	1
10	PCFZZ	5331-01-219-7930	81343	MS28778-12	O-RING.....	2
11	PAFZZ	4730-00-710-5571	96906	MS51525A12	ADAPTER,STRAIGHT,TU.....	2
12	PAFZZ	4730-01-543-4250	19207	12496938	MANIFOLD ASSEMBLY,H.....	1
13	PCFZZ	5331-00-805-2966	81343	MS28778-4	O-RING.....	2
14	PAFZZ	4730-01-007-5232	81343	SAE J514 4-4 070120S	ADAPTER,STRAIGHT,TU.....	1
15	PAFZZ	4730-00-585-2309	96906	MS51527A4	ELBOW,TUBE TO BOSS.....	1
16	PAFZZ	4810-01-536-6609	14775	SB70-DC-24AD	VALVE,SOLENOID.....	1
17	PAFZZ	5331-01-514-0923	81343	MS28775-118	. O-RING.....	1
18	PAFZZ	5330-01-118-5705	96906	MS27595-019	. RETAINER,PACKING.....	2
19	PAFZZ	5331-00-551-8441	62983	175962	. O-RING.....	1

**END OF FIGURE**




R001778

Figure 22. Main Pump Hydraulic Filter Area, Right Side and Left Side (Left Side Shown).



(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 22. MAIN PUMP HYDRAULIC FILTER AREA, RIGHT SIDE AND LEFT SIDE (LEFT SIDE SHOWN).</b>						
1	PAFZZ	4730-01-284-2195	81343	SAE J514 8-6 070201C	ELBOW,TUBE.....	2
2	PCFZZ	4720-01-536-7713	19207	13214E2501-12	HOSE ASSEMBLY,NONME.....	2
3	PAFZZ	4730-01-441-9417	30780	8F650X-SS	ADAPTER,STRAIGHT,TU.....	4
4	PCFZZ	5331-00-808-0794	81343	MS28778-8	O-RING (USED IN HDC)MAIN PUMP HYD FILTER RT/LT SIDE/GPA.....	14
5	PAFZZ	4730-00-225-0699	46717	AC-1-390	ELBOW,TUBE TO BOSS.....	2
6	PAFZZ	4820-01-158-4066	8Z296	1A30-01-V-8S-E-D	VALVE,RELIEF,PRESSU (V22 RIGHT).....	2
6	PAFZZ	4820-01-550-0151	8Z296	1A30-01-V-8ST1-E- D-430	VALVE,RELIEF,PRESSU (V21 LEFT).....	1
7	PAFZZ	4730-01-143-9017	96906	MS51860-56Z	LOCKNUT,TUBE FITTIN.....	4
8	PAFZZ	5310-00-877-7527	19200	10910174-8	WASHER,FLAT.....	2
9	PAFZZ	4730-01-536-8399	30780	8WF50X	UNION,TUBE.....	2
10	PAFZZ	4820-01-536-6135	09990	BVHP-08-SSS-1NG	VALVE,REGULATING,FL (V21USED IN DIST BOX MAIN PUMP ) GP:A.....	2
11	PAFZZ	4730-01-054-3881	96906	MS51523-B8	TEE,TUBE.....	2

**END OF FIGURE**




R0018T78

Figure 23. Hydraulic Filter Mounting.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 23. HYDRAULIC FILTER MOUNTING.</b>						
1	PAFZZ	5340-01-536-3775	19207	12496966	PLATE,MOUNTING.....	2
2	PAFZZ	5310-00-877-5972	19200	10910174-3	WASHER,FLAT (USED IN DISTRIBUTION BOX)FILTER/MOD/ GPA.....	6
3	PAFZZ	5306-01-119-6763	80204	B1821BH038C150L	BOLT,MACHINE.....	6
4	PAFZZ	5340-01-541-5407	19207	12496967	BRACKET,ANGLE.....	2
5	PAFZZ	5310-00-080-6004	96906	MS27183-14	WASHER,FLAT.....	4
6	PAFZZ	5306-01-114-0963	80204	B1821BH038C100L	BOLT,MACHINE (USED IN HYD FILTER MOD)/GPA.....	4

**END OF FIGURE**




R0019T78

Figure 24. Hydraulic Diagnostic Center (HDC) Primary Manifold Assembly Hydraulic Tubes and Hoses.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 24. HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD ASSEMBLY HYDRAULIC TUBES AND HOSES.</b>						
1	PAFZZ	4710-01-543-3418	19207	12496941	TUBE ASSEMBLY,METAL.....	1
2	PAFZZ	4710-01-179-9200	97403	13211E9566	TUBE ASSEMBLY,METAL.....	1
3	PAFZZ	4710-01-179-7634	97403	13211E9564	TUBE ASSEMBLY,METAL.....	1
4	PAFZZ	4710-01-179-9199	97403	13211E9565	TUBE ASSEMBLY,METAL.....	1
5	PAFZZ	4710-01-543-0840	19207	12496940	TUBE ASSEMBLY,METAL.....	4
6	PAFZZ	4710-01-543-3416	19207	12496939	TUBE ASSEMBLY,METAL.....	1
7	PAFZZ	4710-01-543-5071	19207	12496963	TUBE ASSEMBLY,METAL.....	1
8	PCFZZ	4720-01-563-6545	97403	13214E2478-3	HOSE ASSEMBLY,NONME.....	1
9	PAFZZ	4720-01-536-6678	19207	13214E2457-21	HOSE ASSEMBLY,NONME.....	1
10	PAFZZ	4720-01-543-4246	19207	13214E2457-25	HOSE ASSEMBLY,NONME.....	1
11	PAFZZ	4720-01-543-1165	19207	13214E2457-24	HOSE ASSEMBLY,NONME.....	1
12	PAFZZ	4720-01-536-7657	19207	13214E2457-22	HOSE ASSEMBLY,NONME.....	1
13	PAFZZ	4720-01-543-4241	19207	13214E2457-23	HOSE ASSEMBLY,NONME.....	1
14	PAFZZ	4720-01-181-6462	97403	13214E2457-3	HOSE ASSEMBLY,NONME.....	1
15	PCFZZ	4720-01-536-9957	19207	13214E2457-18	HOSE ASSEMBLY,METAL.....	1
16	PCFZZ	4720-01-536-6252	19207	13214E2457-19	HOSE ASSEMBLY,NONME.....	1
17	PAFZZ	4720-01-536-8277	19207	13214E2457-20	HOSE ASSEMBLY,METAL.....	1
18	PCFZZ	4720-01-249-2026	97403	13214E2457-9	HOSE ASSEMBLY,NONME.....	1

**END OF FIGURE**




R0024T78

Figure 25. Directional Control Valve (DCV) Bank.

(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 25. DIRECTIONAL CONTROL VALVE (DCV) BANK.</b>						
1	PCFZZ	5331-00-808-0794	81343	MS28778-8	O-RING (USED IN HDC MOD)DCV BANK MOD/ GP: A.....	14
2	PAFZZ	4730-01-156-4835	96906	MS51525A8	ADAPTER,STRAIGHT,TU.....	9
3	PAFZZ	4730-01-042-0228	96906	MS51524A8	TEE,TUBE.....	2
4	PAFZZ	4730-00-812-2434	96906	MS51521A8	ELBOW,TUBE.....	6
5	PAFZZ	4730-00-224-7757	22031	6400-12-8	ADAPTER,STRAIGHT,TU.....	2
6	PAFZZ	4730-01-139-1585	81343	SAE J514 10-10 070221S	ELBOW,TUBE.....	1
7	PAFZZ	4730-00-062-5470	96906	MS51528B8	ELBOW,TUBE TO BOSS.....	1
8	PAFZZ	4730-00-623-3889	01276	J514 10-10 070120SA	ADAPTER,STRAIGHT,TU.....	1
9	PCFZZ	5331-00-108-5691	81343	MS28778-10	O-RING.....	1
10	PAFZZ	4730-01-536-9912	30780	8A0EX6	ELBOW,PIPE.....	1
11	PAFZZ	4820-01-536-6135	09990	BVHP-08-SSS-1NG	VALVE,REGULATING,FL.....	1
12	PAFZZ	4730-00-822-5609	96906	MS51527A8	ELBOW,TUBE TO BOSS.....	1

**END OF FIGURE**



R0025T78

Figure 26. Hull/Ejector Interference.



(1) ITEM NO.	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
<b>GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.</b>						
<b>FIG. 26. HULL/EJECTOR INTERFERENCE.</b>						
1	XDFZZ		19207	12488667	SPACER,EJECT CYL.....	1
2	PAFZZ	5310-00-585-3243	81343	MS9320-16	WASHER,FLAT.....	4
3	PAFZZ	5306-01-206-8396	80205	NASM51095-446	BOLT,MACHINE.....	4
4	PAFZZ	5305-00-846-5703	80204	B1821BH038C300N	SCREW,CAP,HEXAGON H.....	1
5	PAFZZ	5315-01-180-8641	19207	13211E8634	PIN,STRAIGHT,HEADLE.....	1
6	PAFZZ	5310-00-483-8790	80205	MS17829-6C	NUT,SELF-LOCKING,HE.....	1

END OF FIGURE



**FIELD MAINTENANCE  
NATIONAL STOCK NUMBER INDEX**

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4730-00-062-5470	17	7	5331-00-618-0799	15	14
	19	5	4730-00-618-5372	20	6
	25	7	4730-00-623-3889	25	8
5305-00-068-0510	2	23	4730-00-679-9766	17	6
5305-00-068-0511	13	8		19	7
5305-00-071-2066	2	38	4730-00-710-5571	21	11
5305-00-071-2067	2	11	5330-00-720-3652	15	11
	2	18	5310-00-761-6882	4	4
5305-00-071-2073	13	12	5331-00-804-5695	15	30
5305-00-071-2081	2	8		17	2
5310-00-080-6004	23	5		19	8
5315-00-081-7875	1	25		21	6
5331-00-108-5691	15	23	5331-00-805-2966	12	1
	25	9		15	16
4730-00-143-3941	17	3		15	18
	19	9		17	5
	21	5		17	10
5330-00-180-9037	2	20		19	2
4730-00-224-7757	25	5		19	3
4730-00-225-0699	22	5		21	13
5306-00-226-4824	2	32	5935-00-807-4109	7	3
5315-00-234-1673	2	41	5331-00-808-0794	15	21
4030-00-243-4442	2	48		17	8
5305-00-253-5625	2	34		19	6
5310-00-285-8124	4	5		21	7
	5	2		22	4
5340-00-400-3606	2	31		25	1
5315-00-468-1635	1	6	5310-00-809-5997	2	27
5310-00-483-8790	13	2	5310-00-809-5998	2	4
	26	6		13	7
4730-00-491-9576	17	15	4730-00-811-1848	2	15
	19	11	4730-00-812-2434	14	1
	21	9		25	4
5305-00-543-4372	2	5	5310-00-815-1073	4	1
4820-00-550-6786	15	26	5315-00-815-8840	1	13
5331-00-551-8441	15	4	4730-00-822-5609	2	14
	15	8		15	25
	15	12		25	12
	17	13	5330-00-839-1846	15	13
	19	16	5315-00-839-2325	1	24
	21	4	5315-00-842-3044	1	15
	21	19		2	29
5310-00-559-0070	6	2	5305-00-846-5703	2	12
4730-00-585-2309	17	4		26	4
	19	4	5310-00-851-2682	2	26
	21	15	5310-00-853-9335	1	22
5310-00-585-3243	26	2	5310-00-866-4417	13	13
5310-00-595-7421	13	14	5310-00-877-5972	13	3

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
	16	9	4720-01-181-6166	16	7
	18	4		18	6
	20	4	5355-01-181-6415	1	17
	23	2	4720-01-181-6462	24	14
5310-00-877-7527	22	8	3040-01-186-8004	1	7
5935-00-900-6281	7	2	4730-01-192-9590	15	24
5310-00-934-9757	6	1	5306-01-194-0003	1	26
4730-00-936-2172	15	27	5306-01-194-0004	1	21
5310-00-975-2075	1	16	5306-01-194-0591	13	10
5305-00-984-6197	6	4		16	8
5340-00-985-0823	1	14		18	5
4730-01-007-5232	21	14	5306-01-194-7033	1	27
4730-01-042-0228	25	3	4720-01-195-3838	16	1
4730-01-054-3881	22	11		18	2
5306-01-114-0963	13	5	4720-01-195-3841	16	10
	23	6		18	3
5365-01-116-3731	2	19	5306-01-196-0442	13	6
5330-01-118-5705	15	3	5365-01-200-1519	15	19
	15	7	5306-01-206-8396	26	3
	17	12	5340-01-212-0433	1	23
	19	15	5331-01-219-7930	15	10
	21	3		21	10
	21	18	5365-01-228-0730	15	20
5306-01-119-6763	23	3		21	8
4730-01-139-1585	14	2	4730-01-236-2682	15	28
	25	6	5365-01-242-4564	15	29
4730-01-143-9017	22	7	4720-01-249-2026	24	18
4730-01-156-4835	15	22	4730-01-284-2195	22	1
	17	16	5315-01-317-2696	2	30
	19	12	5310-01-335-7092	2	25
	25	2	5305-01-373-6291	2	33
4820-01-158-4066	22	6	2530-01-415-9449	2	16
5306-01-175-7558	5	1	5925-01-430-2318	6	3
3120-01-175-9336	2	7	5340-01-440-1443	2	37
4710-01-179-7618	18	9	5340-01-440-1445	2	22
4710-01-179-7619	16	4	4730-01-440-5269	2	13
4710-01-179-7620	18	7	3040-01-440-7132	2	28
4710-01-179-7621	16	6	9905-01-440-7208	2	35
4710-01-179-7622	18	8	5330-01-440-7575	2	2
4710-01-179-7623	16	5	5330-01-440-7577	2	6
4710-01-179-7634	24	3	5340-01-440-8652	2	39
5355-01-179-9116	1	1	2590-01-440-8736	2	1
3120-01-179-9151	1	4	2590-01-440-8752	2	3
	1	8	4010-01-440-9273	2	17
	1	11	4720-01-441-1294	2	10
	1	19	4730-01-441-9417	22	3
4710-01-179-9199	24	4	5310-01-442-6932	2	24
4710-01-179-9200	24	2	4720-01-446-7545	20	2
3040-01-179-9210	1	2	5305-01-449-7391	20	3
3040-01-179-9220	1	18	2540-01-454-0663	2	45
3040-01-179-9221	1	10	4030-01-454-2066	2	47
3040-01-179-9222	1	3	5310-01-454-5759	2	42
5315-01-180-8641	26	5	5306-01-456-9447	2	36

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4010-01-460-7224	2	46		25	11
2540-01-461-5899	2	9	4720-01-536-6252	24	16
4030-01-472-9767	2	40	4810-01-536-6609	15	5
3040-01-495-5955	2	21		21	16
5331-01-514-0923	15	2	4720-01-536-6678	24	9
	15	6	5340-01-536-7170	13	15
	17	14	4720-01-536-7657	24	12
	19	14	4720-01-536-7713	22	2
	21	2	4720-01-536-8024	20	9
	21	17	4720-01-536-8277	24	17
5307-01-536-0580	4	3	4730-01-536-8399	22	9
6150-01-536-1117	8	1	4720-01-536-8728	20	7
5340-01-536-1486	13	1	5340-01-536-9863	4	2
2590-01-536-1519	4	6	4730-01-536-9912	25	10
6150-01-536-2015	7	4	4720-01-536-9957	24	15
6695-01-536-2040	12	2	4730-01-537-0516	12	3
	15	15	4720-01-537-0586	20	5
	17	9	2590-01-537-2318	13	4
	19	1	6110-01-537-8428	3	1
5340-01-536-2060	13	9	4720-01-538-3157	20	8
6150-01-536-2129	9	1	4720-01-540-6760	20	1
4730-01-536-2677	17	1	4720-01-541-0697	16	3
4810-01-536-2997	15	1		18	10
	17	11	4720-01-541-1308	16	2
	19	13		18	1
	21	1	5340-01-541-5407	23	4
4730-01-536-3025	15	17	4710-01-543-0840	24	5
6150-01-536-3072	7	1	4720-01-543-1165	24	11
6150-01-536-3311	10	1	4710-01-543-3416	24	6
5340-01-536-3775	23	1	4710-01-543-3418	24	1
2590-01-536-3813	5	3	4720-01-543-4241	24	13
5340-01-536-4160	13	11	4720-01-543-4246	24	10
4730-01-536-5726	19	10	4730-01-543-4250	21	12
6150-01-536-5854	11	1	4710-01-543-5071	24	7
4810-01-536-5871	15	9	4820-01-550-0151	22	6
4820-01-536-6135	22	10	4720-01-563-6545	24	8

END OF WORK PACKAGE



**FIELD MAINTENANCE  
PART NUMBER INDEX**

<b>PART NUMBER</b>	<b>FIG.</b>	<b>ITEM</b>	<b>PART NUMBER</b>	<b>FIG.</b>	<b>ITEM</b>
A2660-1	16	10	MS27595-019	15	3
	18	3		15	7
AA55571/01-001	6	3		17	12
AC-1-390	22	5		19	15
AC218	2	31		21	3
B1821BH025C075L	5	1		21	18
B1821BH031C063N	2	32	MS28774-018	15	13
B1821BH038C075N	2	5	MS28774-019	15	11
B1821BH038C100L	13	5	MS28775-118	15	2
	23	6		15	6
B1821BH038C100N	2	23		17	14
B1821BH038C125N	13	8		19	14
B1821BH038C150L	23	3		21	2
B1821BH038C200L	13	10		21	17
	16	8	MS28778-10	15	23
	18	5		25	9
B1821BH038C300N	2	12	MS28778-12	15	10
	26	4		21	10
B1821BH038C325L	20	3	MS28778-4	12	1
B1821BH050C100N	2	38		15	16
B1821BH050C113L	13	6		15	18
B1821BH050C125N	2	11		17	5
	2	18		17	10
B1821BH050C250N	13	12		19	2
B1821BH050C450N	2	8		19	3
BVHP-08-SSS-1NG	22	10		21	13
	25	11	MS28778-8	15	21
C0120	2	45		17	8
C0122-N	2	42		19	6
CP103	2	30		21	7
FG1011GGG0360	20	2		22	4
J514 10-10 070120SA	25	8		25	1
MS16842-9	2	48	MS35649-282	6	1
MS17829-6C	13	2	MS35674-48	1	6
	26	6	MS35691-13	1	22
MS17829-8C	13	14	MS35691-17	2	26
MS21318-46	2	34	MS35691-21	1	16
MS24665-283	1	15	MS35810-4	1	13
	2	29	MS51521A6	20	6
MS24665-688	2	41	MS51521A8	14	1
MS27147-1	7	2		25	4
MS27183-11	2	25	MS51523-B8	22	11
MS27183-14	23	5	MS51524A8	25	3
MS27183-17	2	27	MS51525A12	21	11
MS27183-18	2	4	MS51525A6	17	15
	13	7		19	11
MS27183-50	4	5		21	9
	5	2	MS51525A8	15	22

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
	17	16	12325799-3	1	9
	19	12	12331885	1	5
	25	2	12331895-1	1	4
MS51526A10	15	24		1	8
MS51527A4	17	4		1	11
	19	4		1	19
	21	15	12332097-1	1	18
MS51527A4P	2	15	12332097-2	1	10
MS51527A6	17	3	12332097-3	1	7
	19	9	12332232	1	3
	21	5	12335054-2	15	19
MS51527A8	2	14	12335054-4	15	29
	15	25	12335054-5	15	20
	25	12		21	8
MS51528A10Z	15	27	12335109-1	1	26
MS51528A6	17	6	12335109-2	1	21
	19	7	12335109-3	1	27
MS51528A8Z	15	28	12412159	2	46
MS51528B8	17	7	12466295-1	2	40
	19	5	12466295-A	2	43
	25	7	12466295-B	2	44
MS51576-37	2	33	12488667	26	1
MS51860-56Z	22	7	12496923	12	2
MS51967-2	4	4		15	15
MS9320-16	26	2		17	9
NAS1454C4A-0504	4	3		19	1
NASM51095-446	26	3	12496924	13	15
S-7926	4	1	12496927	13	11
SAE J514 10-10 070221S	14	2	12496932	4	6
	25	6	12496933	4	2
SAE J514 4-4 070120S	21	14	12496934	17	1
SAE J514 8-6 070201C	22	1	12496935	15	17
SB70-DC-24AD	15	5	12496936	15	9
	21	16	12496937	3	1
SB70-DO-24AD	15	1	12496938	21	12
	17	11	12496939	24	6
	19	13	12496940	24	5
	21	1	12496941	24	1
TT-2304-02	2	7	12496944	13	4
1037390	2	47	12496948	19	10
10910174-3	13	3	12496952	13	9
	16	9	12496953	8	1
	18	4	12496954	9	1
	20	4	12496955	10	1
	23	2	12496956	11	1
10910174-5	13	13	12496957	7	1
10910174-8	22	8	12496958	7	4
109155	1	24	12496959	13	1
1141-51	1	25	12496963	24	7
115544	6	2	12496964	5	3
12325792	1	2	12496966	23	1
12325799-1	1	20	12496967	23	4
12325799-2	1	12	13211E8634	26	5



PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
13211E9392-1	1	17		21	6
13211E9392-2	1	1	161-010-004	2	36
13211E9564	24	3	175962	15	4
13211E9565	24	4		15	8
13211E9566	24	2		15	12
13214E2272	1	23		17	13
13214E2457-18	24	15		19	16
13214E2457-19	24	16		21	4
13214E2457-20	24	17		21	19
13214E2457-21	24	9	196425	15	14
13214E2457-22	24	12	1A30-01-V-0-E-D-304	15	26
13214E2457-23	24	13	1A30-01-V-8S-E-D	22	6
13214E2457-24	24	11	1A30-01-V-8ST1-E-D-430	22	6
13214E2457-25	24	10	2708-4A	1	14
13214E2457-3	24	14	3B-131240-L2	2	16
13214E2457-9	24	18	4177205-028	6	4
13214E2478-3	24	8	4984	2	20
13214E2486-2	20	7	5HP50NSS	2	19
13214E2486-3	20	8	6400-12-8	25	5
13214E2495-2	16	1	7B1-06949	2	28
	18	2	7B1-06950	2	37
13214E2495-6	20	9	7B1-06951	2	2
13214E2495-7	20	1	7B1-06965	2	6
13214E2495-8	16	2	7B1-06991	2	39
	18	1	7B1-07039	2	35
13214E2495-9	16	3	7B1-6946	2	17
	18	10	7B8-06961	2	10
13214E2500-1	16	7	7C1-05925	2	22
	18	6	7D1-06124	2	3
13214E2501-11	20	5	7D3-05815	2	1
13214E2501-12	22	2	7D3-06212	2	9
13214E2750	18	9	7D3-06213	2	21
13214E2751	16	4	8-4XHX6G5TP	12	3
13214E2752	18	7	8741492	7	3
13214E2753	16	6	8A0EX6	25	10
13214E2754	18	8	8F650X-SS	22	3
13214E2755	16	5	8WF50X	22	9
151548	15	30	93783A031	2	24
	17	2	9510-179-A06	2	13
	19	8			

END OF WORK PACKAGE



**CHAPTER 6**  
**SUPPORTING INFORMATION**



---

**FIELD MAINTENANCE  
REFERENCES**

---

**SCOPE**

This work package lists all field manuals, forms, technical manuals, and miscellaneous publications referenced in this manual.

**PUBLICATION INDEXES**

The following indexes should be consulted frequently for latest changes or revisions and for new publications relating to material covered in this technical manual.

**FIELD MANUALS**

FM 4-25.11 First Aid

**FORMS**

DA Form 2028	Recommended Changes to Publications and Blank Forms
DA Form 2404	Equipment Inspection and Maintenance Worksheet
SF 361	Transportation Discrepancy Report
SF 368	Product Quality Deficiency Report

**PAMPHLETS**

DA PAM 750-8 The Army Maintenance Management System (TAMMS) Users Manual

**TECHNICAL MANUALS**

TM 5-2350-262-10	Operator's Manual for Armored Combat Earthmover (ACE), M9 (2350-00-808-7100)
TM 5-2350-262-20	Unit Maintenance Manual for Armored Combat Earthmover (ACE)
TM 5-2350-262-24P	Field Maintenance Repair Parts and Special Tools List for Armored Combat Earthmover (ACE), M9
TM 750-244-6	Procedures for Destruction of Equipment to Prevent Enemy Use (Mobility Equipment Command)

**END OF WORK PACKAGE**



---

## FIELD MAINTENANCE MAINTENANCE ALLOCATION CHART (MAC) INTRODUCTION

---

### The Army Maintenance System MAC

This introduction provides a general explanation of all maintenance and repair functions authorized at the two maintenance levels under the Two-Level Maintenance System concept.

This MAC (immediately following the introduction) designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component shall be consistent with the capacities and capabilities of the designated maintenance levels, which are shown on the MAC in column (4) as:

Field - includes two subcolumns, Crew (C) and Maintainer (F)

Sustainment - includes two subcolumns, Below Depot (H) and Depot (D)

The maintenance to be performed at field and sustainment levels is described as follows:

1. **Crew maintenance.** The responsibility of using organization to perform maintenance on its assigned equipment. It normally consists of inspecting, servicing, lubricating, adjusting, and replacing parts, minor assemblies, and subassemblies. The replace function for this level of maintenance is indicated by the letter "C" in the third position of the SMR code. A "C" appearing in the fourth position of the SMR code indicates complete repair is possible at the crew maintenance level.
2. **Maintainer maintenance.** Maintenance accomplished on a component, accessory, assembly, subassembly, plug-in unit, or other portion either on the system or after it is removed. The replace function for this level of maintenance is indicated by the letter "F" appearing in the third position of the SMR code. An "F" appearing in the fourth position of the SMR code indicates complete repair is possible at the field maintenance level. Items are returned to the user after maintenance is performed at this level.
3. **Below depot sustainment.** Maintenance accomplished on a component, accessory, assembly, subassembly, plug-in unit, or other portion either on the system or after it is removed. The replace function for this level of maintenance is indicated by the letter "H" appearing in the third position of the SMR code. An "H" appearing in the fourth position of the SMR code indicates complete repair is possible at the below depot sustainment maintenance level. Items are returned to the supply system after maintenance is performed at this level.
4. **Depot sustainment.** Maintenance accomplished on a component, accessory, assembly, subassembly, plug-in unit, or other portion either on the system or after it is removed. The replace function for this level of maintenance is indicated by the letter "D" or "K" appearing in the third position of the SMR code. Depot sustainment maintenance can be performed by either depot personnel or contractor personnel. A "D" or "K" appearing in the fourth position of the SMR code indicates complete repair is possible at the depot sustainment maintenance level. Items are returned to the supply systems after maintenance is performed at this level.

The tools and test equipment requirements table (immediately following the MAC) lists the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from the MAC.

The remarks table (immediately following the tools and test equipment requirements) contains supplemental instructions and explanatory notes for a particular maintenance function.

## The Army Maintenance System MAC - Continued

Maintenance functions are limited to and defined as follows:

1. **Inspect.** To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g., by sight, sound, or feel) this includes scheduled inspection and gauging and evaluation of cannon tubes.
2. **Test.** To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards on a scheduled basis, i.e., load testing of lift devices and hydrostatic testing of pressure hoses.
3. **Service.** Operations required periodically to keep an item in proper operation condition; e.g., to clean (includes decontamination, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases. This includes scheduled exercising and purging of recoil mechanisms. The following are examples of service functions:
  - a. **Unpack.** To remove from packing box for service or when required for the performance of maintenance operations.
  - b. **Repack.** To return item to packing box after service and other maintenance operations.
  - c. **Clean.** To rid the item of contamination.
  - d. **Touch up.** To spot paint scratched or blistered surfaces.
  - e. **Mark.** To restore obliterated identification.
4. **Adjust.** To maintain or regulate, within prescribed limits, by bringing into proper position, or by setting the operating characteristics to specified parameters.
5. **Align.** To adjust specified variable elements of an item to bring about optimum or desired performance.
6. **Calibrate.** To determine and cause corrections to be made or to be adjusted on instruments of test, measuring, and diagnostic equipment used in precision measurements. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.
7. **Remove/Install.** To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.
8. **Paint (ammunition only).** To prepare and spray color coats of paint so that the ammunition can be identified and protected. The color indicating primary use is applied, preferably, to the entire exterior surface as the background color of the item. Other markings are to be repainted as original so as to retain proper ammunition identification.
9. **Replace.** To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and assigned maintenance level is shown as the third position code of the Source, Maintenance and Recoverability (SMR) code.
10. **Repair.** The application of maintenance services, including fault location/troubleshooting, removal/installation, disassembly/assembly procedures and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.



**The Army Maintenance System MAC - Continued****NOTE**

The following definitions are applicable to the "repair" maintenance function:

Services: Inspect, test, service, adjust, align, calibrate, and/or replace.

Fault location/troubleshooting. The process of investigating and detecting the cause of equipment malfunctioning; the act of isolating a fault within a system or Unit Under Test (UUT).

Disassembly/assembly. The step-by-step breakdown (taking apart) of a spare/functional group coded item to the level of its least component, that is assigned an SMR code for the level of maintenance under consideration (i.e., identified as maintenance significant).

Actions. Welding, grinding, riveting, straightening, facing, machining, and/or resurfacing.

11. **Overhaul.** That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.
12. **Rebuild.** Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (e.g., hours/miles) considered in classifying Army equipment/components.

**EXPLANATION OF COLUMNS IN THE MAC**

Maintenance functions are limited to and defined as follows:

**Column (1) Group Number.** Column (1) lists Functional Group Code (FGC) numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the Next Higher Assembly (NHA).

**Column (2) Component/Assembly.** Column (2) contains the item names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

**Column (3) Maintenance Function.** Column (3) lists the functions to be performed on the item listed in column (2). (For a detailed explanation of these functions refer to "Maintenance Functions" outlined above).

**Column (4) Maintenance Level.** Column (4) specifies each level of maintenance authorized to perform each function listed in column (3), by indicating work time required (expressed as manhours in whole hours or decimals) in the appropriate subcolumn. This work time figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function carries at different maintenance levels, appropriate work time figures are to be shown for each level. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the MAC. The symbol designations for the various maintenance levels are as follows:

**The Army Maintenance System MAC - Continued**Field:

- C Crew maintenance
- F Maintainer maintenance

Sustainment:

- L Specialized Repair Activity (SRA)
- H Below depot maintenance
- D Depot maintenance

**NOTE**

The "L" maintenance level is not included in column (4) of the MAC. Functions to this level of maintenance are identified by work time figure in the "H" column of column (4), and an associated reference code is used in the REMARKS column (6). This code is keyed to the remarks and the SRA complete repair application is explained there.

**Column (5) Tools and Equipment Reference Code.** Column (5) specifies, by code, those common tool sets (not individual tools), common Test, Measurement and Diagnostic Equipment (TMDE), and special tools, special TMDE and special support equipment required to perform the designated function. Codes are keyed to the entries in the tools and test equipment table.

**Column (6) Remarks Code.** When applicable, this column contains a letter code, in alphabetical order, which is keyed to the remarks table entries.

**Explanation of Columns in the Tools and Test Equipment Requirements**

**Column (1) - Tool or Test Equipment Reference Code.** The tool or test equipment reference code correlates with a code used in column (5) of the MAC.

**Column (2) - Maintenance Level.** The lowest level of maintenance authorized to use the tool or test equipment.

**Column (3) - Nomenclature.** Name or identification of the tool or test equipment.

**Column (4) - National Stock Number (NSN).** The NSN of the tool or test equipment.

**Column (5) - Tool Number.** The manufacturer's part number.

**Explanation of Columns in the Remarks**

**Column (1) - Remarks Code.** The code recorded in column (6) of the MAC.

**Column (2) - Remarks.** This column lists information pertinent to the maintenance functions being performed as indicated in the MAC.

**END OF WORK PACKAGE**

**FIELD MAINTENANCE  
STANDARD TWO-LEVEL MAC**

**Table 1. Maintenance Allocation Chart (MAC).**

(1) GROUP NUMBER	(2) COMPONENT/ ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL				(5) TOOLS AND EQUIPMENT REFERENCE CODE	(6) REMARKS CODE
			FIELD		SUSTAINMENT			
			CREW	MAINTAINER	BELOW DEPOT	DEPOT		
			C	F	H	D		
A801-00	HDC Control Box							
A801-01	HDC Stowage Bracket	Replace	0.5			5	A	
A801-02	HDC Disconnect Bracket	Replace	1.0			5	A	
A801-03	HDC Circuit Breaker	Replace	0.5			5	A	
A801-04	HDC Power Components	Replace	0.5			5	A	
A801-05	Wiring Harness W1	Replace	0.5			5	A	
A801-06	Wiring Harness W2	Replace	2.5			5	A	
A801-07	Wiring Harness W3	Replace	4.4			4, 5	A	
A801-08	Wiring Harness W4	Replace	0.1				A	
A801-09	Pressure Transducers	Replace	0.4			5, 6	A, B	
A801-10	HDC Primary Manifold Assembly and Mounting Bracket	Replace	9.0			1, 3, 5, 6	A, B	
A801-11	HDC Primary Manifold Assembly	Repair	10.0			1, 3, 5, 6	A, B	

**Table 1. Maintenance Allocation Chart (MAC) - Continued.**

(1) GROUP NUMBER	(2) COMPONENT/ ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL				(5) TOOLS AND EQUIPMENT REFERENCE CODE	(6) REMARKS CODE
			FIELD		SUSTAINMENT			
			CREW	MAINTAINER	BELOW DEPOT	DEPOT		
			C	F	H	D		
A801-12	HDC Forward Left Manifold Assembly	Replace		2.8			2, 3, 4, 5, 6	A, B
		Repair		1.0			2, 3, 4, 5, 6	A, B
A801-13	HDC Forward Right Manifold Assembly	Replace		2.8			2, 3, 4, 5, 6	A, B
		Repair		1.0			2, 3, 4, 5, 6	A, B
A801-14	HDC Aft Manifold Assembly	Replace		2.8			2, 3, 4, 5, 6	A, B
		Repair		1.0			2, 3, 4, 5, 6	A, B
A801-15	Main Pump Hydraulic Filter Area	Replace		1.3			3, 5	A, B
A801-16	Interconnect- ing Hydraulic Hoses and Tubes	Replace		1.9			3, 5, 6	A, B
A801-17	DCV Bank	Replace		0.5			5	A, B
A801-18	Hull/Ejector Interference	Replace		1.0			5	A

**Table 2. Tools and Test Equipment.**

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
1	F	Automotive Tool Set (SATS)	4910-01-490-6453	SC 4910-95-A81
2	F	Adapter, Socket Wrench	5120-00-240-8702	11655788-2
3	F	Plug, Hydraulic Tank	5340-01-222-7934	12355501
4	F	Stand, Vehicle	2590-01-228-5802	12355345
5	F	Tool Kit, General Mechanic's: Automotive	5180-01-548-7634	PD484
6	F	Wrench Set, Crowfoot	5120-01-302-4387	5705566

**Table 3. Remarks.**

REMARK CODE	REMARKS
A	Check for proper operation
B	Inspect for leaks, unusual noises

**END OF WORK PACKAGE**



**FIELD MAINTENANCE  
EXPENDABLE AND DURABLE ITEMS LIST**

**INTRODUCTION**

**Scope**

This work package lists expendable and durable items that you will need to operate and maintain the Hydraulic Diagnostic Center (HDC). This list is for information only and is not authority to requisition the listed items. These items are authorized to you by CTA 50-970, Expendable/Durable Items (Except Medical, Class V Repair Parts, and Heraldic Items), CTA 50-909, Field and Garrison Furnishings and Equipment or CTA 8-100, Army Medical Department Expendable/Durable Items.

**Explanation of Columns in the Expendable/Durable Items List**

**Column (1) Item No.** This number is assigned to the entry in the list and is referenced in the narrative instructions to identify the item (e.g., Use brake fluid (WP 0098, Item 5)).

**Column (2) Level.** This column identifies the lowest level of maintenance that requires the listed item (F = Maintainer or ASB).

**Column (3) National Stock Number (NSN).** This is the NSN assigned to the item which you can use to requisition it.

**Column (4) Item Name, Description, Part Number/(CAGEC).** This column provides the other information you need to identify the item. The last line below the description is the part number and the Commercial and Government Entity Code (CAGEC) (in parentheses).

**Column (5) U/I.** Unit of Issue (U/I) code shows the physical measurement or count of an item, such as gallon, dozen, gross, etc.

*Table 1. Expendable and Durable Items List.*

(1) ITEM NO.	(2) LEVEL	(3) NATIONAL STOCK NUMBER (NSN)	(4) ITEM NAME, DESCRIPTION, PART NUMBER/ (CAGEC)	(5) U/I
<b>Lubricating Oil, Engine</b>				
1	F	9150-00-186-6668	Lubricating Oil, Engine OE/HDO-10, 5 gal M2104-3-10W (81349)	CN
<b>Rag, Wiping</b>				
2	F	7920-00-205-1711	Rag, Wiping 7920-00-205-1711 (64067)	BE
<b>Sealing Compound</b>				
3	F	8030-01-299-1762	Sealing Compound 81724 (1PBQ8)	TU
<b>Strap, Tiedown, Electrical</b>				
4	F	5975-00-074-2072	Strap, Tiedown, Electrical MS3367-1-9 (81343)	HD

**END OF WORK PACKAGE**





**FIELD MAINTENANCE  
TOOL IDENTIFICATION LIST**

**INTRODUCTION**

**Scope**

This work package lists all common tools and supplements and special tools/fixtures needed to maintain the Hydraulic Diagnostic Center (HDC).

Most PM-SKOT products have lifetime warranties and replacement capabilities and are supported worldwide through PM-SKOT. The PM-SKOT implemented a Web-based tool replacement and warranty program in May 2005 for tools authorized in SKO. User may access the online program by first accessing the PM-SKOT Web site at <https://pmskot.army.mil> and clicking on the Tool Replacement/Warranty banner.

**Explanation of Columns in the Tool Identification List**

**Column (1) - Item Number.** This number is assigned to the entry in the list and is referenced in the initial setup to identify the item (e.g., Extractor (WP 0090, Item 32)).

**Column (2) - Item Name.** This column lists the item by noun nomenclature and other descriptive features (e.g., Gage, Belt Tension).

**Column (3) - National Stock Number.** This is the National Stock Number (NSN) assigned to the item; use it to requisition the item.

**Column (4) - Part Number/CAGEC.** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity) which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items. The manufacturer's Commercial and Government Entity Code (CAGEC) is also included.

**Column (5) - Reference.** This column identifies the authorizing supply catalog or RPSTL for items listed in this work package.

**Table 1. Tool Identification List.**

(1) ITEM NO.	(2) ITEM NAME	(3) NATIONAL STOCK NUMBER (NSN)	(4) PART NUMBER (CAGEC)	(5) REFERENCE
1	Adapter, Socket Wrench	5120-00-240-8702	B107.10 (05047)	TM 5-2350-262-24P
2	Charging Kit, Pressuring	4940-01-046-7109	12252157 (19200)	TM 5-2350-262-24P
3	Parts Kit, Hydraulic	2590-01-216-8646	5705562 (19207)	TM 5-2350-262-24P
4	Plug, Hydraulic Tank	5120-01-222-7934	12355501 (19207)	TM 5-2350-262-24P
5	Stand, Vehicle Support	2590-01-228-5802	12355345 (19207)	TM 5-2350-262-24P

*Table 1. Tool Identification List - Continued.*

(1) ITEM NO.	(2) ITEM NAME	(3) NATIONAL STOCK NUMBER (NSN)	(4) PART NUMBER /(CAGEC)	(5) REFERENCE
6	Tester, Hydraulic Hose Assembly	4940-00-595-5720	GS5 (08832)	TM 5-2350-262-24P
7	Tool Kit, General Mechanic's: Automotive	5180-01-548-7634	PD484 (19200)	TM 5-2350-262-24P
8	Wrench Set, Crowfoot	5120-01-302-4387	5705566 (19207)	TM 5-2350-262-24P

**END OF WORK PACKAGE**

**FIELD MAINTENANCE  
MANDATORY REPLACEMENT PARTS LIST**

**MANDATORY REPLACEMENT PARTS LIST**

This work package includes a list of all mandatory replacement parts referenced in the task initial setups and procedures. These are items that must be replaced during maintenance whether they have failed or not. This includes items based on usage intervals such as miles, time, rounds fired, etc.

*Table 1. Mandatory Replacement Parts List.*

ITEM NO.	PART NUMBER (CAGEC)	NATIONAL STOCK NUMBER (NSN)	NOMENCLATURE	QTY
1	109155 (15434)	5315-00-839-2325	Pin, Cotter	3
2	1133610 (0Y3H3)	5310-01-583-5824	Washer, Lock	1
3	B1821BH025C075L (80204)	5306-01-175-7558	Bolt, Machine	8
4	B1821BH038C100L (80204)	5306-01-114-0963	Bolt, Machine	11
5	B1821BH038C113L (80204)	5306-01-205-2799	Bolt, Machine	3
6	B1821BH038C200L (80204)	5306-01-194-0591	Bolt, Machine	6
7	B1821BH038C325L (80204)	5305-01-449-7391	Screw, Cap, Hexagon, Head	3
8	MS17829-6C (80205)	5310-00-483-8790	Nut, Self-Locking	2
9	MS17829-8C (80205)	5310-00-595-7421	Nut, Self-Locking	1
10	MS24665-283 (80205)	5315-00-842-3044	Pin, Cotter	1
11	MS27595-019 (96906)	5330-01-118-5705	Retainer, Packing	18
12	MS28774-018 (96906)	5330-00-839-1846	Retainer, Packing	12
13	MS28774-019 (96906)	5330-00-720-3652	Retainer, Packing	12
14	MS28775-018 (81343)	5331-00-618-0799	O-ring	6

*Table 1. Mandatory Replacement Parts List - Continued.*

ITEM NO.	PART NUMBER (CAGEC)	NATIONAL STOCK NUMBER (NSN)	NOMENCLATURE	QTY
15	MS28775-019 (81343)	5331-00-551-8441	O-ring	14
16	MS28775-10 (81343)	5331-01-306-9602	O-ring	1
17	MS28775-118 (81343)	5331-01-514-0923	O-ring	12
18	MS28778-12 (81343)	5331-01-219-7930	O-ring	8
19	MS28778-4 (81343)	5331-00-805-2966	O-ring	27
20	MS28778-6 (81343)	5331-00-804-5695	O-ring	12
21	MS28778-8 (81343)	5331-00-808-0794	O-ring	42
22	MS35333-38 (80205)	5310-00-559-0070	Washer, Lock	8
23	NASM51095-446 (80205)	5306-01-206-8396	Bolt, Machine	4

**END OF WORK PACKAGE**

---

**FIELD MAINTENANCE  
DIAGRAMS**

---

**DIAGRAMS**

The following diagrams are for the M9 ACE Hydraulic Diagnostic Center (HDC):

- M9 ACE HDC Hydraulic Schematic (Sheet 1 of 3). (FO-1)
- M9 ACE HDC Hydraulic Schematic (Sheet 2 of 3). (FO-2)
- M9 ACE HDC Hydraulic Schematic (Sheet 3 of 3). (FO-3)
- Power Cable Assembly W1. (FO-4)
- Upper Cable Assembly W2. (FO-5)
- Lower Cable Assembly W3. (FO-6)
- Umbilical Cable Assembly W4. (FO-7)
- Simplified Electrical Schematic Diagram of HDC System Power Distribution. (FO-8)
- HDC System Electrical Interconnection Diagram. (FO-9)
- Hydraulic Pressure Transducer Electrical Diagram. (FO-10)
- Solenoid Valve Electrical Diagram. (FO-11)
- W2 Wiring Diagram. (FO-12)
- W3 Wiring Diagram. (FO-13)
- W4 Wiring Diagram. (FO-14)

**END OF WORK PACKAGE**



**INDEX**

<u>Subject</u>	<u>WP Sequence No.-Page No.</u>
<b>D</b>	
DIAGRAMS.....	WP 0056-1
DIRECTIONAL CONTROL VALVE (DCV) BANK REPLACEMENT.....	WP 0041-1
<b>E</b>	
EQUIPMENT DESCRIPTION AND DATA.....	WP 0002-1
EXPENDABLE AND DURABLE ITEMS LIST.....	WP 0053-1
<b>G</b>	
GENERAL INFORMATION.....	WP 0001-1
GENERAL MAINTENANCE.....	WP 0043-1
GROUP A501 WINCH INSTALLATION.....	WP 0046-1
GROUP A801 HYDRAULIC DIAGNOSTIC CENTER COMPONENTS.....	WP 0047-1
GROUP AQ01 HYDRAULIC CONTROL INSTALLATION.....	WP 0045-1
<b>H</b>	
HULL/EJECTOR INTERFERENCE REPLACEMENT.....	WP 0042-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) AFT MANIFOLD ASSEMBLY REPAIR.....	WP 0038-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) CIRCUIT BREAKER REPLACEMENT.....	WP 0028-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) DISCONNECT BRACKET REPLACEMENT.....	WP 0027-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) FORWARD LEFT MANIFOLD ASSEMBLY REPAIR.....	WP 0036-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) FORWARD RIGHT MANIFOLD ASSEMBLY REPAIR.....	WP 0037-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) INTERCONNECTING HYDRAULIC HOSES AND TUBES REPLACEMENT.....	WP 0040-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) POWER COMPONENTS REPLACEMENT....	WP 0029-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD ASSEMBLY AND MOUNTING BRACKET REPLACEMENT.....	WP 0034-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) PRIMARY MANIFOLD REPAIR.....	WP 0035-1
HYDRAULIC DIAGNOSTIC CENTER (HDC) STOWAGE BRACKET REPLACEMENT.....	WP 0026-1
<b>I</b>	
INTRODUCTION TO USING THE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM TO TROUBLESHOOT THE M9 ACE HYDRAULIC SYSTEM.....	WP 0004-1
<b>M</b>	
M9 ACE HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM FUNCTIONAL CHECK- OUT.....	WP 0025-1
MAIN PUMP HYDRAULIC FILTER AREA REPLACEMENT.....	WP 0039-1
MAINTENANCE ALLOCATION CHART (MAC) INTRODUCTION.....	WP 0051-1
MANDATORY REPLACEMENT PARTS LIST.....	WP 0055-1
<b>N</b>	
NATIONAL STOCK NUMBER INDEX.....	WP 0048-1

**INDEX - Continued**

<u>Subject</u>	<u>WP Sequence No.-Page No.</u>
<b>P</b>	
PART NUMBER INDEX.....	WP 0049-1
PRESSURE TRANSDUCERS REPLACEMENT.....	WP 0033-1
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS).....	WP 0023-1
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION.....	WP 0022-1
<b>R</b>	
REFERENCES.....	WP 0050-1
REPAIR PARTS AND SPECIAL TOOLS LISTS (RPSTL) INTRODUCTION.....	WP 0044-1
<b>S</b>	
SERVICE UPON RECEIPT.....	WP 0024-1
STANDARD TWO-LEVEL MAC.....	WP 0052-1
<b>T</b>	
THEORY OF OPERATION.....	WP 0003-1
TOOL IDENTIFICATION LIST.....	WP 0054-1
TROUBLESHOOTING INDEX.....	WP 0005-1
TROUBLESHOOTING PROCEDURES - ALL HYDRAULIC FUNCTIONS INOPERATIVE.....	WP 0006-1
TROUBLESHOOTING PROCEDURES - APPARENT HYDRAULIC DIAGNOSTIC CENTER (HDC) SYSTEM PROBLEM.....	WP 0021-1
TROUBLESHOOTING PROCEDURES - APRON AND LEFT-HAND WHEEL CONTROL INOPERATIVE.....	WP 0007-1
TROUBLESHOOTING PROCEDURES - APRON WILL NOT RAISE.....	WP 0008-1
TROUBLESHOOTING PROCEDURES - BUMP STOPS INOPERATIVE.....	WP 0009-1
TROUBLESHOOTING PROCEDURES - EJECTOR CREEPS.....	WP 0010-1
TROUBLESHOOTING PROCEDURES - EJECTOR DOES NOT EXTEND OR RETRACT.....	WP 0011-1
TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE.....	WP 0014-1
TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE.....	WP 0012-1
TROUBLESHOOTING PROCEDURES - FRONT CORNER (LEFT OR RIGHT) RAISES IN UNSPRUNG, BUT NOT SPRUNG MODE.....	WP 0013-1
TROUBLESHOOTING PROCEDURES - HYDRAULIC OIL OVERHEATS.....	WP 0015-1
TROUBLESHOOTING PROCEDURES - LEFT REAR CORNER DOES NOT RAISE IN SPRUNG OR UNSPRUNG MODE.....	WP 0016-1
TROUBLESHOOTING PROCEDURES - REAR OF VEHICLE RAISES IN SPRUNG, BUT NOT UNSPRUNG MODE.....	WP 0017-1
TROUBLESHOOTING PROCEDURES - VEHICLE DOES NOT RESPOND TO OPERATOR CONTROLS.....	WP 0018-1
TROUBLESHOOTING PROCEDURES - WINCH AND RIGHT-HAND WHEEL CONTROL INOPERATIVE.....	WP 0019-1
TROUBLESHOOTING PROCEDURES - WINCH WILL NOT PULL RATED LOAD.....	WP 0020-1
<b>W</b>	
WIRING HARNESS W1 REPLACEMENT.....	WP 0030-1
WIRING HARNESS W2 REPLACEMENT.....	WP 0031-1



## INDEX - Continued

**Subject**

**WP Sequence No.-Page No.**

### W

WIRING HARNESS W3 REPLACEMENT.....

WP 0032-1



<b>RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS</b>						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE <i>Date you filled out this form.</i>	
For use of this form, see AR 25-30; the proponent agency is OAASA.								
<b>TO</b> (Forward to proponent of publication or form) (Include ZIP Code) U.S. Army TACOM Life Cycle Management Command ATTN: AMSTA-LCL-MPP/TECH PUBS 6501 E. 11 Mile Road, Warren, MI 48397-5000						<b>FROM</b> (Activity and location) (Include ZIP Code)  <i>Your mailing address</i>		
<b>PART I – ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS</b>								
PUBLICATION/FORM NUMBER <i>TM Number</i>						DATE <i>Date of the TM</i>	TITLE <i>Title of the TM</i>	
ITEM	PAGE	PARA-GRAPH	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON (Exact wording of recommended change must be given)		
	0007-3					<i>Figure 2, Item 9 should show a lockwasher. Currently shows a flat washer.</i>		
	0018-2					<i>Cleaning and inspection, Step 6, reference to governor support pin (14) is wrong reference. Reference should be change to (12).</i>		
SAMPLE								
TYPED NAME, GRADE OR TITLE						TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE
<i>Your Name</i>						<i>Your Phone Number</i>		<i>Your Signature</i>

<b>TO:</b> <i>(Forward direct to addressee listed in publication)</i> U.S. Army TACOM Life Cycle Management Command ATTN: AMSTA-LCL-MPP/TECH PUBS, MS 727 6501 E. 11 Mile Road, Warren, MI 48397-5000	<b>FROM:</b> <i>(Activity and location) (Include ZIP Code)</i>  Your mailing address	<b>DATE</b>  Date of submission
--	--	---------------------------------------

**PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS**

<b>PUBLICATION NUMBER</b>  TM 5-2350-378-23&P	<b>DATE</b>  30 March 2012	<b>TITLE</b> Field Maintenance Manual Including Repair Parts and Special Tools List for Hydraulic Diagnostic Center (HDC) Supporting Armored Combat Earthmover (ACE), M9
---	----------------------------------	--

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
<div style="font-size: 100px; opacity: 0.5; transform: rotate(-30deg); pointer-events: none;">SAMPLE</div>								

**PART III - REMARKS** *(Any general remarks, recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

<b>TYPED NAME, GRADE OR TITLE</b>  Your name	<b>TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION</b>  Your telephone number	<b>SIGNATURE</b>  Your signature
--	--	--



<b>TO:</b> <i>(Forward direct to addressee listed in publication)</i> U.S. Army TACOM Life Cycle Management Command ATTN: AMSTA-LCL-MPP/TECH PUBS, MS 727 6501 E. 11 Mile Road, Warren, MI 48397-5000	<b>FROM:</b> <i>(Activity and location) (Include ZIP Code)</i>	<b>DATE</b>
--	--	-------------

**PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS**

<b>PUBLICATION NUMBER</b> TM 5-2350-378-23&P	<b>DATE</b> 30 March 2012	<b>TITLE</b> Field Maintenance Manual Including Repair Parts and Special Tools List for Hydraulic Diagnostic Center (HDC) Supporting Armored Combat Earthmover (ACE), M9
---	------------------------------	--

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

**PART III - REMARKS** *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------



<b>TO:</b> <i>(Forward direct to addressee listed in publication)</i> U.S. Army TACOM Life Cycle Management Command ATTN: AMSTA-LCL-MPP/TECH PUBS, MS 727 6501 E. 11 Mile Road, Warren, MI 48397-5000	<b>FROM:</b> <i>(Activity and location) (Include ZIP Code)</i>	<b>DATE</b>
--	--	-------------

**PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS**

<b>PUBLICATION NUMBER</b> TM 5-2350-378-23&P	<b>DATE</b> 30 March 2012	<b>TITLE</b> Field Maintenance Manual Including Repair Parts and Special Tools List for Hydraulic Diagnostic Center (HDC) Supporting Armored Combat Earthmover (ACE), M9
---	------------------------------	--

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

**PART III - REMARKS** *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------





<b>TO:</b> <i>(Forward direct to addressee listed in publication)</i> U.S. Army TACOM Life Cycle Management Command ATTN: AMSTA-LCL-MPP/TECH PUBS, MS 727 6501 E. 11 Mile Road, Warren, MI 48397-5000	<b>FROM:</b> <i>(Activity and location) (Include ZIP Code)</i>	<b>DATE</b>
--	--	-------------

**PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS**

<b>PUBLICATION NUMBER</b> TM 5-2350-378-23&P	<b>DATE</b> 30 March 2012	<b>TITLE</b> Field Maintenance Manual Including Repair Parts and Special Tools List for Hydraulic Diagnostic Center (HDC) Supporting Armored Combat Earthmover (ACE), M9
---	------------------------------	--


PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

**PART III - REMARKS** *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

By Order of the Secretary of the Army:

Official:

  
JOYCE E. MORROW  
*Administrative Assistant to the  
Secretary of the Army*


RAYMOND T. ODIERNO  
*General, United States Army  
Chief of Staff*

1214215

Distribution:

To be distributed in accordance with the initial distribution number (IDN) 256982 requirements for TM 5-2350-378-23&P.






D0001HDC








D0002HDC

FO-2. M9 ACE HDC Hydraulic Schematic (Sheet 2 of 3).

FP-3/FP-4 blank









D0003HDC

FO-3. M9 ACE HDC Hydraulic Schematic (Sheet 3 of 3).






D0004HDC

FO-4. Power Cable Assembly W1.

FP-7/FP-8 blank






Mates with W4P5  
on umbilical cable  
disconnect panel

D0005HDC

FO-5. Upper Cable Assembly W2.

FP-9/FP-10 blank






D0006HDC

FO-6. Lower Cable Assembly W3.

FP-11/FP-12 blank








D0007HDC

FO-7. Umbilical Cable Assembly W4.

FP-13/FP-14 blank






D0008HDC

FO-8. Simplified Electrical Schematic Diagram of HDC System Power Distribution.






D0009HDC

FO-9. HDC System Electrical Interconnection Diagram.






PRESSURE TRANSDUCER ELECTRICAL DIAGRAM

D0010HDC

FO-10. Hydraulic Pressure Transducer Electrical Diagram.








D0011HDC

FO-11. Solenoid Valve Electrical Diagram.

FP-21/FP-22 blank






WIRING DIAGRAM

D0012HDC






WIRING DIAGRAM

D0013HDC

FO-13. W3 Wiring Diagram.

FP-25/FP-26 blank





D0014HDC

FO-14. W4 Wiring Diagram.

FP-27/FP-28 blank





## THE METRIC SYSTEM AND EQUIVALENTS

### LINEAR MEASURE

1 Centimeter=10 Millimeters=0.01 Meters=0.3937 Inches  
 1 Meter=100 Centimeters=1000 Millimeters=39.37 Inches  
 1 Kilometer=1000 Meters=0.621 Miles

### WEIGHTS

1 Gram=0.001 Kilograms=1000 Milligrams=0.035 Ounces  
 1 Kilogram=1000 Grams=2.2 Lb  
 1 Metric Ton=1000 Kilograms=1 Megagram=1.1 Short Tons

### LIQUID MEASURE

1 Milliliter=0.001 Liters=0.0338 Fluid Ounces  
 1 Liter=1000 Milliliters=33.82 Fluid Ounces

### SQUARE MEASURE

1 Sq Centimeter=100 Sq Millimeters=0.155 Sq Inches  
 1 Sq Meter=10,000 Sq Centimeters=10.76 Sq Feet  
 1 Sq Kilometer=1,000,000 Sq Meters=0.386 Sq Miles

### CUBIC MEASURE

1 Cu Centimeter=1000 Cu Millimeters=0.06 Cu Inches  
 1 Cu Meter=1,000,000 Cu Centimeters=35.31 Cu Feet

### TEMPERATURE

$5/9 (^{\circ}\text{F} - 32) = ^{\circ}\text{C}$   
 212°Fahrenheit is equivalent to 100°Celsius  
 90°Fahrenheit is equivalent to 32.2°Celsius  
 32°Fahrenheit is equivalent to 0°Celsius  
 $9/5 (^{\circ}\text{C} + 32) = ^{\circ}\text{F}$

### APPROXIMATE CONVERSION FACTORS

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Inches . . . . .	Centimeters . . . . .	2.540
Feet . . . . .	Meters . . . . .	0.305
Yards . . . . .	Meters . . . . .	0.914
Miles . . . . .	Kilometers . . . . .	1.609
Square Inches . . . . .	Square Centimeters . . . . .	6.451
Square Feet . . . . .	Square Meters . . . . .	0.093
Square Yards . . . . .	Square Meters . . . . .	0.836
Square Miles . . . . .	Square Kilometers . . . . .	2.590
Acres . . . . .	Square Hectometers . . . . .	0.405
Cubic Feet . . . . .	Cubic Meters . . . . .	0.028
Cubic Yards . . . . .	Cubic Meters . . . . .	0.765
Fluid Ounces . . . . .	Milliliters . . . . .	29.573
Pints . . . . .	Liters . . . . .	0.473
Quarts . . . . .	Liters . . . . .	0.946
Gallons . . . . .	Liters . . . . .	3.785
Ounces . . . . .	Grams . . . . .	28.349
Pounds . . . . .	Kilograms . . . . .	0.454
Short Tons . . . . .	Metric Tons . . . . .	0.907
Pound-Feet . . . . .	Newton-Meters . . . . .	1.356
Pounds/Sq Inch . . . . .	Kilopascals . . . . .	6.895
Miles per Gallon . . . . .	Kilometers per Liter . . . . .	0.425
Miles per Hour . . . . .	Kilometers per Hour . . . . .	1.609

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Centimeters . . . . .	Inches . . . . .	0.394
Meters . . . . .	Feet . . . . .	3.280
Meters . . . . .	Yards . . . . .	1.094
Kilometers . . . . .	Miles . . . . .	0.621
Sq Centimeters . . . . .	Square Inches . . . . .	0.155
Square Meters . . . . .	Square Feet . . . . .	10.764
Square Meters . . . . .	Square Yards . . . . .	1.196
Square Kilometers . . . . .	Square Miles . . . . .	0.386
Sq Hectometers . . . . .	Acres . . . . .	2.471
Cubic Meters . . . . .	Cubic Feet . . . . .	35.315
Cubic Meters . . . . .	Cubic Yards . . . . .	1.308
Milliliters . . . . .	Fluid Ounces . . . . .	0.034
Liters . . . . .	Pints . . . . .	2.113
Liters . . . . .	Quarts . . . . .	1.057
Liters . . . . .	Gallons . . . . .	0.264
Grams . . . . .	Ounces . . . . .	0.035
Kilograms . . . . .	Pounds . . . . .	2.205
Metric Tons . . . . .	Short Tons . . . . .	1.102
Newton-Meters . . . . .	Pound-Feet . . . . .	0.738
Kilopascals . . . . .	Pounds per Sq Inch . . . . .	0.145
Km per Liter . . . . .	Miles per Gallon . . . . .	2.354
Km per Hour . . . . .	Miles per Hour . . . . .	0.621

