


TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT
SUPPORT AND GENERAL SUPPORT
MAINTENANCE MANUAL**



TA236113

**TRUCK TRACTOR, YARD TYPE,
43,500 LB GVW, DED, 4x2,
ARMY MODEL M878A1
(OTTAWA MODEL 50)
(NSN 2320-01-121-2102)**

**DIRECT SUPPORT
MAINTENANCE _
PROCEDURES PAGE 3-1**

**GENERAL SUPPORT
MAINTENANCE
PROCEDURES PAGE 4-1**

REFERENCES PAGE A-1

**MAINTENANCE
ALLOCATION
CHART PAGE B-1**

**EXPENDABLE SUPPLIES
AND MATERIALS 1
LIST PAGE C-1**

TORQUE LIMITS PAGE D-1

**ELECTRICAL, HYDRAULIC
AND PNEUMATIC -
DIAGRAMS PAGE E-1**

GLOSSARY PAGE F-1

**ILLUSTRATED LIST OF
MANUFACTURED
ITEMS PAGE G-1**

**ALPHABETICAL INDEX /
INDEX 11**

WARNING

Winterization system heaters operate from 110 Vac commercial power source. Disconnect winterization system cable from receptacle at front bumper before removing winterization system heaters. When installing winterization system heaters, be sure you twist together the same color wire ends. Incorrect wire connections, or exposed wire due to frayed insulation, can cause the engine and body of tractor to be energized at 110 Vac. Serious injury or death can result from contact with energized 110 Vac power lines. If you are injured, obtain medical aid immediately.

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

WARNING

Battery electrolyte is toxic and corrosive. Wear protective goggles and gloves when removing battery caps and checking electrolyte. Avoid contact with skin, eyes, clothes, and don't breathe vapors. Don't smoke or use an open flame near batteries. Batteries release hydrogen, an explosive gas, during charging. Failure to follow this procedure could cause serious injury or death due to batteries exploding.

WARNING

Allow components to cool before removing. Hot oil, steam, and coolant can cause severe injury. If you are scalded or burned, seek medical aid immediately.

WARNING

Before performing a procedure that requires raising tractor, be sure that tractor is securely supported by jack stands; if possible, be sure that chain hoist is bearing some of the weight of vehicle as a safety precaution in the event jack stands collapse. Failure to follow this procedure could result in serious injury or death due to tractor falling. If you are injured, seek medical aid immediately.

WARNING

Never crawl under equipment when performing maintenance unless equipment is blocked securely. Keep clear of equipment when it is raised or lowered. Do not place any part of body between movable and fixed elements of the equipment. Don't allow heavy components to swing while suspended by lifting device. Use extreme caution when working near a cable or chain under tension. When using chain hoist to remove or install parts, be sure hoist is securely fastened to the part and that all slack in chain is taken up. Death or severe injury may result if personnel fail to observe these safety precautions. If you are hurt by a falling object or chain or cable under tension, seek medical aid immediately.

WARNING

Be sure chain hoist is securely fastened to heavy tractor components before removing supporting hardware. Do not allow heavy components to fall freely. Failure to follow these precautions could cause serious injury due to parts falling on you. If you are injured by falling equipment, seek medical aid immediately.

WARNING

Battery box lid is heavy. Secure lid in open position to prevent injury from falling lid. If you are injured, obtain medical aid immediately.

WARNING

Stand out from raised cab unless safety bar is supporting full weight of cab. Keep clear of deck when raising or lowering cab. Failure to do so could cause serious injury or death.

WARNING

Personal injury and property damage can result if vehicle is allowed to move during transmission stall test or hydraulic pressure test. Secure tractor frame to an immovable object, chock all wheels, and apply service brakes before you accelerate engine. Do not permit anyone to stand in front of tractor during test.

WARNING

If hydraulic steering system or fuel system connectors or elbows require replacement, discard hose. If hydraulic steering system hose is reused, hydraulic oil leakage could occur causing loss of steering control. This in turn could cause serious injury or loss of life. If fuel system hose is reused, leakage could occur causing a fire hazard.

WARNING

Be sure tire is completely deflated and valve core is removed before dismounting tire. Failure to do so could cause serious injury due to parts flying off wheel and tire. Don't use oil to lubricate tire when mounting. Oil will cause rubber to deteriorate over a period of time with possible personal injury resulting. Place tire and wheel assembly in a safety cage before inflating tire. Don't overinflate tire. If not properly assembled, inflation may cause the wheel and rim to separate with explosive force causing serious injury or death. If you are injured, seek medical help immediately.

WARNING

Use caution when you remove components under pressure from compression spring. Failure to do so could cause serious injury by parts flying up and hitting your eye. If you are injured, obtain medical aid immediately.

WARNING

Brake linings contain asbestos fibers. Do not generate dust when working on brake system. Don't remove dust or dirt with compressed air. Serious bodily harm may result from breathing asbestos dust.

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when using compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, obtain medical attention immediately.

WARNING

Relieve all pressure from tractor air system before disconnecting air system lines and fittings. Wear safety glasses and stand clear of loosened air line fitting. High pressure air can propel debris at high speed, causing eye injury or blindness. If you are injured, obtain medical aid immediately.

WARNING

When installing air tubing on insert-type fitting, tubing must be installed over insert for secure connection. Installation of fitting without insert will allow air pressure to force tubing j from fitting, resulting in dangerous loss of air pressure.

WARNING

Diesel fuel is highly combustible. Do not smoke or allow sparks or open flames near fuel. Death or severe injury may result if you fail to observe this precaution. If you are burned, obtain medical aid immediately.

WARNING

Do not use quick start switch without cranking engine. Overcharge of ether starting fluid can cause explosion of engine air intake system. Ether is highly flammable. Do not puncture ether cylinder or discard in an open fire. Failure to follow this precaution could cause severe injury.

WARNING

Wear protective goggles and heavy gloves when you remove or install glass. Remove and handle broken glass carefully. Failure to do so could cause serious injury due to glass puncturing or cutting your skin or eye. If you are injured by broken glass, obtain medical aid immediately.

WARNING

Wear safety glasses when using hammer or removing rivets. Don't strike hardened steel parts with steel hammer. Failure to do so could cause injury due to metal chips striking your eyes. Obtain medical attention immediately if you get metal chips in your eyes.

WARNING

Be careful not to come in contact with rotating fan, belts, or other moving parts. To do so will cause serious injury. If you are injured, obtain medical aid immediately.

WARNING

Don't bleach or dye tethers or seat belt. To do so may reduce their strength resulting in seat belt or tether breaking under stress, causing serious injury or death if there is an accident involving stress on these parts.

Refer to FM 21-11 for first aid for injured personnel.

**TECHNICAL MANUAL
ORGANIZATIONAL, DIRECT
SUPPORT AND GENERAL SUPPORT
MAINTENANCE MANUAL**

**TRUCK TRACTOR, YARD TYPE
43,500 LB GVW, DED, 4X2,
ARMY MODEL M878A1
(OTTAWA MODEL 50)
NSN 2320-01-121-2102**

REPORTING OF ERRORS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Tank-Automotive Command, ATTN: DRSTA-MT, Warren, MI 48397-5000 . A reply will be furnished to you.

		Page
CHAPTER 3	DIRECT SUPPORT MAINTENANCE PROCEDURES	3-1
	Chapter Overview	3-1
Section I.	Engine and Cooling Systems Maintenance	3-2
II.	Electrical System Maintenance.....	3-34
III.	Power Train Maintenance.....	3-89
IV.	Brake System Maintenance	3-153
V.	Steering System Maintenance	3-226
VI.	Frame and Towing Attachments, Springs, and Body and Cab Maintenance	3-294
VII.	Accessories Maintenance.....	3-399
VIII.	Hydraulic Systems Maintenance	3-407
IX.	Pre-Embarkation Inspection of Material in Units Alerted for Overseas Shipment	3-475
CHAPTER 4	GENERAL SUPPORT MAINTENANCE PROCEDURES	4-1
	Chapter Overview	4-1
Section I.	Engine and Fuel System Maintenance	4-1
II.	Power Train Maintenance.....	4-2
APPENDIX A	REFERENCES	A-1
B	MAINTENANCE ALLOCATION CHART	B-1
C	EXPENDABLE SUPPLIES AND MATERIALS LIST	C-1
D	TORQUE LIMITS	D-1
E	ELECTRICAL, HYDRAULIC, AND PNEUMATIC DIAGRAMS	E-1
F	GLOSSARY	F-1
G	ILLUSTRATED LIST OF MANUFACTURED ITEMS	G-1
	ALPHABETICAL INDEX	Index 1

**CHAPTER 3
DIRECT SUPPORT MAINTENANCE PROCEDURES**

CHAPTER OVERVIEW

This chapter has some important information that you need to know about the direct support maintenance requirements of the vehicle. This information includes but isn't limited to:

- Maintenance of the various systems and subsystems which the vehicle comprises. These systems and subsystems are listed in the chapter index below.
- Troubleshooting of the various systems and subsystems.
- Refer to TM 9-2815-205-34 for troubleshooting and maintenance of the engine.

Index

Section	Title	Page
I	Engine and Cooling Systems Maintenance	3-2
II	Electrical System Maintenance	3-34
III	Power Train Maintenance	3-89
IV	Brake System Maintenance	3-153
V	Steering System Maintenance	3-226
VI	Frame and Towing Attachments, Springs, and Body and Cab Maintenance	3-294
VII	Accessories Maintenance	3-399
VIII	Hydraulic Systems Maintenance	3-407
IX	Pre-Embarkation Inspection of Material in Units Alerted for Overseas Shipment	3-475

Section I. ENGINE AND COOLING SYSTEMS MAINTENANCE

This section contains the information you need to maintain the:

- Engine
- Cooling System

It gives you instructions on how to troubleshoot problems and repair or replace the components that are within the scope of direct support maintenance.

	Para
Troubleshooting Symptom Index	3-1
Engine Troubleshooting	3-2
Cooling System Troubleshooting	3-3
Engine Maintenance.....	3-4
Cooling System Maintenance.....	3-5
Radiator	3-5a
Fan Shroud.....	3-5b
Fan Drive Assembly	3-5c

NOTE

Refer to TM 9-2815-205-34 for inspection, maintenance, repair, and adjustment of the engine cylinder block, valves and tappets, rocker arm, oil cooler, oil pan, oil inlet tube, and regulator and relief valve.

NOTE

Refer to TM 9-2815-205-34 for test, maintenance, and repair of the fuel injector assemblies and rack, fuel pump assembly, fuel lines, blower assembly, turbo-charger, and governor.

3-1. TROUBLESHOOTING SYMPTOM INDEX

	Para/Malfunction	Page
ENGINE		
Engine lacks power	3-2/1	3-3
COOLING SYSTEM		
Engine overheats or does not reach operating temperature	3-3/1	3-3 j
Cooling system not pressurized	3-3/2	3-4

3-2. ENGINE TROUBLESHOOTING

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

1. ENGINE LACKS POWER

Perform stall test (para 3-17a(3)).

- a. If maximum engine speed is excessive, troubleshoot transmission (para 3-14).
- b. If maximum engine speed is low, refer to TM 9-2815-205-34 for troubleshooting of the engine and its components.

3-3. COOLING SYSTEM TROUBLESHOOTING

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

1. ENGINE OVERHEATS OR DOES NOT REACH OPERATING TEMPERATURE

- Step 1. Shut down engine.
Relieve all air pressure in air system (para 2-41h(1)).
Try to rotate fan by hand.
- a. If fan cannot be rotated by hand, repair fan clutch assembly (para 3-5c).
 - b. If fan can be rotated by hand, proceed to step 2 below.
- Step 2. Disconnect tubing from fitting at top of fan clutch assembly (para 2-15e).
Apply 90 to 120 psi air pressure to fitting.
Check if fan can be rotated by hand with air pressure applied to fitting.
- a. If fan can be rotated by hand, repair fan clutch assembly (para 3-5c).
 - b. If fan cannot be rotated by hand, proceed to step 3 below.
- Step 3. Check radiator and hoses for leakage or damage.
- a. If radiator is leaking or damaged, replace (para 3-5a).
 - b. If hoses are leaking or damaged, replace (para 2-15c).
 - c. If leakage and damage are not observed, refer to TM 9-2815-205-34 for troubleshooting of the engine cooling system.

3-3. COOLING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

2. COOLING SYSTEM NOT PRESSURIZED

Pressure test radiator (para 2-15a(2)).

- a. If pressure drops quickly, radiator has serious leakage. Repair or replace radiator (para 3-5a).
- b. If pressure drops slowly, radiator has seepage or slight leakage; repair or replace radiator (para 3-5a).
- c. If pressure holds steady for two or more minutes, radiator is not leaking. Refer to TM 9-2815-205-34 for troubleshooting of the engine cooling system.

3-4. ENGINE MAINTENANCE

This task covers engine-transmission:

- a. Removal
- b. Cleaning
- c. Inspection/Repair
- d. Installation

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Torque wrench, 1/2 inch drive, 175 pounds foot capacity
- Socket wrench set
- Rubber mallet
- Rubber mallet Maintenance Manual)
- Hoist, 4000 pounds capacity
- Three-branch chain sling
- Transmission jack, wheeled

Personnel Required

Three Automotive Repairers MOS 63H

References

TM 9-2815-205-34 (6V53T Diesel Engine Maintenance Manual)

Troubleshooting References

- Paragraph
- Paragraph
- 3-2 Engine
- 3-3 Cooling system
- 3-14 Transmission

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Automatic transmission fluid Item 8, Appendix C
- Hydraulic sealant Item 20, Appendix C

Equipment Condition

Paragraph	Condition Description
	Tractor parked on level surface, parking brakes applied, and wheels blocked securely.
3-35j	Cab tilted 90 degrees.
2-12b	Engine crankcase drained.
2-12c	Engine-mounted oil filter removed.
2-12d	External engine oil filter lines disconnected.
2-13a	Air cleaner assembly removed; restriction indicator hose disconnected from engine.
2-13b(2)	Fuel lines disconnected from cylinder head, fuel pump, and fuel filters.
2-13c	Fuel filters removed.
2-13d	Quick start removed.
2-13e	Throttle linkage removed from engine.
2-14a	Exhaust pipes removed.
2-14b	Muffler and exhaust stack removed.
2-15a(l)	Radiator drained.
2-15b(2)	Coolant filter assembly, hoses, and fittings removed.
2-15c	Radiator coolant hoses removed and fittings removed from engine.
2-15d	Drive belts, fan, and fan clutch assembly removed.
2-15e	Clutch fan control system removed.
2-24	Belts, alternator assembly, and brackets removed.
2-29	Water level sensor removed.
2-32c	Transmission temperature sender removed.
2-34a	Battery cables disconnected from transmission and starter.
2-35e	Engine-transmission grounding strap removed.
2-41b	Transmission fluid drained.

3-4. ENGINE MAINTENANCE (CONT)**INITIAL SETUP (cont)**Equipment Condition (cont)

Paragraph

Condition Description


2-41e	External transmission oil filter and transmission cooler hoses and fittings removed.
2-41g(l)	Gear shift control cable and linkage removed from transmission.
2-41h(l)	Tubing disconnected from shift lockout cylinder.
2-41i	Modulator cable assembly removed.
2-41j	Transmission oil sampling valve removed.
2-42	Drive shaft disconnected from transmission yoke.
2-51b	Air compressor governor tubing removed, and supply hose disconnected from air compressor and air reservoir.
2-52b	Air strainer removed.
2-52c	Alcohol evaporator removed.
2-58b	Hoses removed from power steering pump and rear cab guard.
2-65c	Rear platform removed.
2-65d	Rear cab guard removed.
2-73a	Cab heater hoses disconnected from engine.
2-73d	Engine oil heater removed.
2-73e	Coolant heater removed.
2-78b(2)	Hydraulic hose brackets removed from transmission.
2-79b	Hydraulic hose assembly between cab tilt pump and left hand hydraulic latch removed.
2-85	Speedometer cable, adapter, and gear assembly removed from transmission.
2-86	Tachometer sender unit removed.
3-5a	Radiator removed.
3-12d	Wiring harness disconnected and removed from engine.
3-17d	Torque converter capscrews removed.
3-42a	Hydraulic pump removed (lines still connected).
3-42b	Power take-off removed.

General Safety Instructions**WARNING**

Do not stand under items being handled by hoist or crane. Do not put any body part between moveable and fixed elements of the equipment. If you are injured, seek medical aid immediately.

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Engine and transmission	Three-branch chain Attach sling		Hook one leg to each engine lifter bracket; hook the third leg to a chain around rear of transmission. Take out slack and apply slight upward pressure



WARNING

Keep clear of engine-transmission during hoisting and swinging to skid cradle. Never allow hands or body to get under engine-transmission. To do so may result in serious injury or death should the sling, a fastening, or the hoist or crane break and drop the engine-transmission during removal or setting it in the cradle. If you are injured obtain medical aid immediately.

2	Engine, front	Two capscrews	Remove	From front engine mount (nuts and washers were removed during para 2-73e step of initial equipment condition)
---	---------------	---------------	--------	---

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
3	Trans- mission mount	Two locknuts, snubbing washers, and capscrews	Remove	Para 3-17f

CAUTION

Lift engine-transmission slowly, watching for any hoses, lines, electrical wiring, or linkage(s) that may have been overlooked. If necessary, lower the engine transmission and disconnect any such items that may be discovered before continuing with removal.

4	Tractor	a. Engine and transmission	a. Remove b. Position	Lift from tractor On skid
5	Engine and transmis- sion	a. Solenoid and 70A circuit breaker	Remove	Para 2-25a
		b. Starter	Remove	Para 2-25b
		c. Engine oil dipstick and tube	Remove	Para 2-12e
		d. Engine oil sampling valve	Remove	Para 2-12f
		e. Oil pressure sender and sensor	Remove	Para 2-32a
		f. Water tempera- ture sender and alarmstat	Remove	Para 2-32d
		g. Shift lockout cylinder and linkage	Remove	Para 2-41h(2)
		h. Air compressor	Remove	Para 2-52d
		i. Power steering pump	Remove from	Para 3-28f adapter
		j. Transmission mount cross- member	Remove	Para 3-17f
		k. Transmission dipstick	Remove	Para 2-41b
		l. Transmission dipstick tube	Remove	Para 2-41k

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
6	Trans- mission, assembly front	a. Transmission	Support	Support transmission with a wheeled transmission jack Para 3-17c(2)
		b. 12 capscrews and lock washers	Remove	
CAUTION				
Install converter retaining strap immediately. Torque converter is now free to move and can fall off.				
		c. Transmission	Remove from engine	Para 3-17c(2)
7	Engine and transmis- sion	Lines, fittings, and component openings created by removal	Seal	Prevents entry of contaminants

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
8	Exterior surfaces	Engine and transmission	Clean	Use cleaning solvent P-D-680 and a stiff brush. Dry with compressed air or clean cloths
INSPECTION/REPAIR				
9	Engine	a. Castings b. Linkages c. Sheet metal	Inspect Inspect Inspect	Refer to TM 9-2815-205-34 (6V53 Diesel Engine Maintenance Manual) for repair or replacement of worn, bent, deformed or broken parts
10	Transmission	a. Castings b. Torque converter	Inspect Inspect	Refer to Chapter 4 for repair or replacement of worn, deformed, or broken parts
INSTALLATION				
11	Transmission,	a. Transmission b. 12 capscrews front and lock washers	Position Install and tighten	On back of engine
12	Engine and transmission	a. Engine oil dipstick and b. Engine oil sampling valve c. Starter d. Solenoid and 70A circuit breaker e. Transmission dipstick tube f. Transmission dipstick g. Power steering pump h. Air compressor i. Transmission mount cross-member	Install tube Install Install Install Install Install Install Install	Para 2-12e Para 2-12 Para 2-25b Para 2-25a Para 2-41k Para 2-41b Install Para 3-28f Para 2-52d Para 3-17f

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
12		j. Shift lockout (cont) cylinder and linkage	Install	Para 2-41h(2)
		k. Water temperature sender and alarmstat	Install	Para 2-32c
		l. Oil pressure sender and sensor	Install	Para 2-32a
		m. Power take-off	Install	Para 3-42b
13	Engine and	a. Three-branch transmiss- chain sling	Attach	Hook one leg to each engine lifter bracket; hook the third leg to a chain around rear of transmission. Take out slack and apply slight upward pressure

WARNING

Keep clear of engine-transmission during hoisting and swinging from skid cradle. Never allow hands or body to get under engine-transmission. To do so may result in serious injury or death should the sling, a fastening, or the hoist or crane break and drop the engine transmission during installation or lifting from the skid.

If you are injured obtain medical aid immediately.

- b. Engine and Lift From skid transmission
- c. Skid Remove

CAUTION

Lower engine-transmission slowly, watching for hoses, lines, electrical wiring, or linkage(s) that may be in the way. If necessary, raise the engine-transmission and move any such items that may be discovered before continuing with installation.

14	Tractor	Engine and transmission	Position	Lower slowly
15	Transmission mount	Two capscrews, snubbing washers, and lock-nuts	Install	Para 3-17f

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
16	Engine, front	Two capscrews	Position	On front engine mount (para 2-73e). Nuts and washers will be installed in step 22k below
17	Engine and transmission	Three-branch chain sling	Disconnect and remove	
18	Engine, rear, underside	Torque converter capscrews	Install	Para 3-17c(2)
19	Transmission	a. Hydraulic pump b. Hydraulic hose brackets c. Modulator cable assembly d. Drive shaft e. Transmission oil sampling valve f. Shift lockout tubing g. Gear shift control cable and linkage h. Battery ground cable i. Speedometer gear assembly, adapter, and cable	Install Install Install Connect Install Connect Install Connect Install	Para 3-42a Para 2-78b(2) Para 2-41i Para 2-42 Para 2-41j Para 2-41h(l) Para 2-41g(1) To transmission only; see para 2-34a Pars 2-85
20	Tractor chassis	a. Rear cab guard b. Muffler and exhaust stack c. Cab tilt hose assembly d. Engine-transmission grounding strap	Install Install Install Install	Para 2-65d Para 2-14b Para 2-79b Para 2-35e

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
21	Tractor, front	a. Radiator	Install	Para 3-5a
		b. Fan clutch assembly, fan, and drive belts	Install; adjust belt tension	Para 2-15d
		c. Radiator coolant hoses and fittings	Install	Para 2-15c
		d. Alcohol evaporator	Install	Para 2-52c
		e. Air strainer	Install	Para 2-52b
22	Engine	a. Air cleaner assembly and restriction indicator hose	Install	Para 2-13a
		b. Fuel lines	Connect	Para 2-13b(2)
		c. Quick start	Install	Para 2-13d
		d. Throttle linkage	Install	Para 2-13e
		e. Exhaust pipes	Install	Para 2-14a
		f. Clutch fan control system	Install	Para 2-15e
		g. Brackets, alternator assembly, and	Install;	Para 2-24 adjust belt tension belts
		h. Water level sensor	Install	Para 2-29
		i. Air compressor governor lines	Install	Para 2-51b
		j. Engine oil heater	Install	Para 2-73d
		k. Coolant heater	Install	Para 2-73e
		l. Tachometer sender unit	Install	Para 2-86
		m. Cab heater hoses	Connect	Para 2-73a
		n. External engine oil filter lines	Connect	Para 2-12d
		o. Wiring harness connect	Install and	Para 3-12d
		p. Engine-mounted oil filter	Install	Para 2-12c

3-4. ENGINE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
23	Rear cab guard	a. Hydraulic steering hoses	Install	Para 2-58b
		b. Fuel filters	Install	Para 2-13c
		c. Coolant filter assembly, fittings, and hoses	Install	Para 2-15b(2)
		d. External transmission oil filter and cooler fittings and hoses	Install	Para 2-41e
		e. Transmission temperature sender	Install	Para 2-32d
24	Engine and transmission	a. Battery cable starter	Connect to	Para 2-34a
		b. Coolant	Install	Para 2-15a(l)
		c. Engine oil	Install	Para 2-12b
		d. Transmission fluid	Install	Para 2-41b
		e. Power steering fluid	Install	Para 2-58c
25	Tractor, front	Cab and deck	Lower to 45 degree position	Para 3-35j
26	Cab tilt pump	Cab	Lower	To normal operating position
27	Cab	Key switch	Engage	Start engine and check for fluid leaks at engine, transmission, and reconnected hoses, lines, and fittings

3-5. COOLING SYSTEM MAINTENANCE

NOTE

Refer to TM 9-2815-205-34 (6V53T Diesel Engine Maintenance Manual) for maintenance/repair of the water pump.

a. Radiator.

- | | | | | |
|-------------------|----|-------------|----|--------------|
| This task covers: | a. | Removal | d. | Inspection |
| | b. | Disassembly | e. | Reassembly |
| | c. | Cleaning | f. | Installation |

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

Socket wrench set, 3/8 inch

Scratch wire brush

Chain hoist, 1/2 ton capacity

Materials/Parts

Cleaning solvent Item 1, Appendix C

Clean cloths Item 2, Appendix C

Personnel Required

Automotive Repairer MOS 63H

References

LO 9-2320-285-12

(M878A1 Lubrication Order)

Troubleshooting References

Paragraph

2-11 Radiator upper tank leaking

2-11 Radiator lower tank leaking

2-11 Radiator core leaking

Equipment Condition

Paragraph Condition Description

Tractor parked on a level surface, parking brake applied and engine off.

3-35j Cab tilted 90 degrees.

2-15a(1) Radiator drained.


2-15c Coolant hoses removed.

2-15f Coolant overflow system kit removed.

2-41e Transmission oil cooler hoses disconnected.

3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).



3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Radiator, top	Chain hoist and sling	Position	As shown
2	RH and LH strut rods at frame	a. Two locknuts (5), washers (6), washers (37), cap-screws (8), and washers (9) b. Two locknuts (10), four washers (11), and two cap-screws (12), and two radiator strut rods (13) c. Two rubber isolators (7)	Loosen and	remove
3	Rear of	a. Eight capscrews radiator (14), lock washers (15), and washers (16) b. Fan shroud (17) secure safely	Remove	Move shroud back over fan,
4	Front of radiator	a. Two locknuts (18), washers (19), and rubber isolators (20) b. Two locknuts (21) and cap-screws (22) c. Two radiator strap assemblies (23) d. Two rubber isolators (35), washers (34), and nuts (33)	Loosen and remove Loosen and remove Remove Remove	Attached to brackets on frame From strap assemblies (23)

3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
5	Front of frame	a. Two locknuts (34) and washers (25)	Loosen and remove	

CAUTION

Use care in lifting radiator out of frame and cab area to avoid bending fins of radiator or puncturing radiator core or tanks.

b. Radiator (28)	Lift	Approximately one inch
c. Shims (27)	Remove if	Note number and location of installed shims
d. Radiator (28)	Remove	Lift out of vehicle

NOTE

Move radiator to a clean flat work area and place it on its back supported by blocks.

e. Two rubber isolators (26)	Remove	Pry out of radiator support frame crossmember
------------------------------	--------	---

DISASSEMBLY

6	Front of radiator	a. Four capscrews (29) and locknut (30)	Loosen and remove	
		b. RH radiator strap bracket (31) and LH radiator strap bracket (32)	Remove	Pull from between radiator frame sides and core gussets
7	Radiator, top rear	a. Two nuts (1), lock washers holes (2), and capscrews (3)	Remove	Note position of mounting
		b. Bracket (4)	Remove	

3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

8	Front of frame	a. Radiator support frame cross-member	Clean	Use cleaning solvent P-D-680 and a stiff brush. Wipe dry using clean cloths Use cleaning solvent P-D-680 and a stiff brush. Dry using clean cloths
		b. RH radiator strap brackets (31 and 32), two radiator strap assemblies (23), strut rods (13), and hardware	Clean	

INSPECTION

9	On bench	a. Radiator strut rods (13)	Check	For bends or kinks
		b. RH and LH radiator strap brackets (31 and 32)	Inspect	For damage to tapped holes. Chase if possible; otherwise replace bracket

REASSEMBLY

10	Front of radiator	a. RH and LH radiator strap brackets (31 and 32)	Position	
----	-------------------	--	----------	--

3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
10 (cont)		b. Four capscrews (29) and lock-nut (30)	Install	
11	Rear of radiator	a. Two nuts (1), lock washers (2), and capscrews (3)	Remove	
		b. Bracket (4)	Position	
		c. Four capscrews (3), lock washers (2), and nuts (1)	Install	
INSTALLATION				
12	Front of engine	Fan shroud (17)	Position and secure	Over fan, as far toward engine as possible. Secure fan shroud in this position temporarily to protect fan blades
13	Radiator support frame cross member	Two rubber isolators (26)	Install	Drive squarely into mounting holes

CAUTION

Move radiator slowly and guide carefully to avoid damaging radiator fins or tanks when installing radiator in following step.

14	Front of frame	a. Chain hoist	Attach	To sling lift holes in top of of radiator
		b. Radiator (28)	Position and	Lift radiator and guide into f install position in front of engine

3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
15	Radiator support frame crossmember	a. Radiator (28) mounting studs	Position	Guide studs into holes in rubber isolators
		b. Shims (27)	Slip onto studs on top of rubber isolators	Use number of shims as noted in step 5c above
		c. Two special washers (25) and lock nuts (24)	Secure lightly	Adjust shimming until radiator sits level then tighten.
16	Radiator straps (23)	Two nuts (33), washers (34), and rubber isolators (35)	Install	Install nuts (33) all the way on stud of strap
17	Front of	a. Two radiator radiator strap assemblies (23)	Install	Insert studs into radiator strap brackets (31 and 33)
		b. Two capscrews (22) and locknuts (21)	Install	Through radiator strap brackets on frame
		c. Two rubber isolators (20), washers (19), and lock nuts (18)	Install	Tighten locknuts (21) above, then snug down locknuts (18) until radiator is squared in frame and secure
18	Radiator side	a. Two radiator strut rods (13), capscrews (12), four washers (11), and two locknuts (10)	Install	Tighten finger tight
		b. Two rubber isolators (7)	Install	Push into strut frame brackets from inside

3-5. COOLING SYSTEM MAINTENANCE (CONT)

a. Radiator (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
18		c. Two capscrews (cont) (8), washers (9), washers (6), washers (37), and locknuts (5)	Install	Tighten locknuts (10 and 5) securely
19	Engine, front	a. Fan shroud (17)	Position	Move forward to radiator; use care to prevent damage to fan blades
		b. Eight capscrews (14), lock washers (15), and washers (6)	Install and tighten	
20	Radiator, bottom	Transmission cooler lines	Install	Para 2-41e
21	Transmission	Dipstick	Check oil level	Add oil if necessary (refer to current lubrication order)
22	Radiator	a. Coolant overflow system kit	Install	Para 2-15f
		b. Radiator hoses	Install	Para 2-15c
		c. Radiator	Refill with coolant	Para 2-15a(1)

NOTE**Operate vehicle and check for leaks; correct as necessary.**

3-5. COOLING SYSTEM MAINTENANCE (CONT)

b. Fan Shroud.

- This task covers:
- a. Removal
 - b. Cleaning
 - c. Inspection/Repair
 - d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Scratch wire brush
- Safety glasses

Welding shop equipment

Hammer

Materials/Parts

Cleaning solvent

Item 1, Appendix C

Clean cloths

Item 2, Appendix C

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph

Condition Description

- 2-15a(1) Parked on level surface; parking brake applied; engine off.
- 2-13a Cab tilted 90 degrees, Air pressure relieved from air system (air reservoir drain cock opened).
- 2-15f Coolant drained from radiator. Air cleaner precleaner removed. Coolant overflow system kit removed.
- 2-15c Radiator hoses removed.
- 2-15d Fan and drive belts removed.
- 2-52c Alcohol evaporator removed.
- 3-5a Right hand radiator strut removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Radiator	a. Chain hoist and sling	Attach	To fan shroud
		b. Fan shroud attaching hardware	Remove	Para 3-5a
		c. Fan shroud	Remove	Use two men and chain hoist; raise and work from under cab carefully to avoid damaging radiator or other parts. Move fan shroud to a flat work surface

3-5. COOLING SYSTEM MAINTENANCE (CONT)

b. Fan Shroud (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

2	Fan shroud		Clean	Use cleaning solvent P-D-680; use wire brush to remove corrosion. Dry using compressed air
---	------------	--	-------	--

INSPECTION/REPAIR

3	Fan shroud		Inspect for cracks breaks dents	Repair cracked or broken welds by grinding off old welds, pounding out dents using hammer and wooden backing block, and rewelding seams
---	------------	--	---------------------------------------	---

INSTALLATION

4	Front of vehicle	a. Fan shroud	Position	Use two men and chain hoist; move fan shroud under cab and lower in position against radiator Para 3-5a
		b. Fan shroud attaching tighten hardware	Install and	
5	Fan shroud, right side	Alcohol evaporator	Install	Para 2-52c

3-5. COOLING SYSTEM MAINTENANCE (CONT)

b. Fan Shroud (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
6	Engine, front	Fan and drive belts	Install	Para 2-15d
7	Frame, right side	Right hand radiator strut	Install	Para 3-5a
8	Engine, front	Radiator hoses	Install	Para 2-15c
9	Radiator, top rear	Coolant overflow system kit	Install	Para 2-15f
10	Air cleaner	Precleaner	Install	Para 2-13a
11	Front of vehicle	Radiator	Fill	With coolant (para 2-15a(1))
12	Cab tilt pump	Cab Lower	To normal operating position	

NOTE**Operate vehicle and check for leaks; correct as necessary.**

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly.

This task covers: a. Disassembly c. Inspection
 b. Cleaning d. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance
 Tool Kit
 Socket wrench set
 Screwdriver
 Socket head screw key set
 Torque wrench
 Retaining ring pliers
 Safety glasses
 Automotive Mechanic's Tool Kit
 Hammer
 Adjusting nut socket
 FSCM 31875 PN B11861
 Vise
 Brass drift
 Arbor press

Materials/Parts

Cleaning solvent Item 1, Appendix C
 Clean cloths Item 2, Appendix C
 Lubricant Item 17, Appendix C
 Sealant Item 19, Appendix C
 Mineral spirits Item 33; Appendix C
 Bearing grease FSCM 31875 PN 808537
 Seal kit FSCM 31875 PN 819883
 Lock washer FSCM 31875 PN 995

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-15d	Fan drive assembly removed.


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY

1	Fan drive assembly	a. Bracket (28)	Clamp	In vise, sheave (27) and air chamber (3) free to rotate
		b. Eight socket head cap-screws (1) and lock washers (2)	Remove and discard	
		c. Air chamber (3)	Remove	Apply air pressure to fitting to aid removal, if necessary
		d. O-rings (4 and 5)	Remove and discard	
		e. Retaining ring (6)	Remove	Use retaining ring pliers
		f. O-ring (7), cartridge (8), and U-cup (9)	Remove	Discard cartridge assembly (6 thru 9)

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).



TA236306

- | | | |
|---------------------------------|----------------------------------|----------------------|
| 1. Socket head
capscrews (8) | 12. Retaining ring | 23. Bearing |
| 2. Lock washers (8) | 13. Spring retainer | 24. Bearing spacer |
| 3. Air chamber | 14. Spring | 25. Bearing spacer |
| 4. O-ring | 15. Bearing | 26. Bearing |
| 5. O-ring | 16. Bearing spacer | 27. Sheave |
| 6. Retaining ring | 17. Bearing | 28. Bracket |
| 7. O-ring | 18. Splined hub | 29. Seal |
| 8. Cartridge | 19. Clutch disc | 30. Nuts (6) |
| 9. U-cup | 20. Journal spacer | 31. Lock washers (6) |
| 10. Adjusting nut | 21. Socket head
capscrews (6) | 32. Studs (6) |
| 11. Lock washer | 22. Clutch lining | |

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
1 (cont)		g. Lock washer (11) tab	Pry	Use screwdriver and hammer to push tab out from adjusting nut (10)
		h. Adjusting nut (10) and lock washer (11)	Remove	Use adjusting nut socket; discard lock washer (11)
		i. Clutch disc assembly (12 thru 19)	Remove	As an assembly
		j. Journal spacer (20)	Remove	
		k. Sheave assembly (21 thru 27)	Remove	As an assembly
		l. Bracket (28)	Remove	From vise

NOTE

Perform step 2 below only if inspection indicates need for replacement of items in clutch disc assembly (12 thru 19).

2	Clutch disc assembly (12 thru 19)	a. Retaining ring (12)	Remove	Press spring retainer (13) to compress spring (14)
		b. Spring retainer (13) and spring (14)	Remove	
		c. Splined hub (18) with bearings (15 and 17) and bearing spacer (16)	Remove	From clutch disc (19)
		d. Bearing (15)	Remove	Press out from splined hub (18)
		e. Bearing spacer (16)	Remove	
		f. Bearing (17)	Remove	Press out from nearest side in splined hub (18); do not press all the way through hub

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

NOTE

Perform step 3 below only if inspection indicates need for replacement of items in sheave assembly (21 thru 27).

3	Sheave assembly (21 thru 27)	a. Six socket head capscrews (21)	Remove	
		b. Clutch lining (22)	Remove	
		c. Spacer (24) sideways	Move	Allows brass drift to be placed on inner race of bearing (23)
		d. Bearing (23)	Remove	Tap with brass drift and hammer around bearing inner race
		e. Two spacers (24 and 25)	Remove	
		f. Bearing (26)	Remove	Tap out using brass drift and hammer
4	Cartridge (8)	Seal (29)	Remove and discard	
5	Air chamber (3)	a. Six nuts (30) and lock washers (31)	Remove	If necessary
		b. Six studs (32)	Remove and discard	Only if necessary for replacement

CLEANING

6	a.	Bearings (15, 17, 23, and 26)	a. Clean b. Pack c. Wrap in paper	Use volatile mineral spirits Use new bearing grease Protects bearings from dust
---	----	-------------------------------	---	---

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b.	All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air
----	-----------------	-------	--

INSPECTION

7	a.	Bearings (15, 17, 23, and 26)	Inspect	Replace if chipped, rough or excessively worn
	b.	Clutch lining (22)	Inspect	Replace if deformed, oily, or if worn to 1/16-inch (new lining is 3/16-inch thick)
	c.	Clutch disc (19) and splined hub (18)	Inspect	Replace if splines worn, cracked, chipped, or bent
	d.	Spacers (16, 20, 24, and 25)	Inspect	Replace if cracked, chipped, or deformed. Replace bearing spacers (24 and 25) as matched set only
	e.	All other parts	Inspect	Replace if cracked, chipped, deformed, or threads damaged

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
8	Air chamber (3)	a. Six new studs (32)	Install, if removed	Coat threads with sealant before installation Hand tight only
		b. Six lock washers (31) and nuts (30)	Install	
		c. New seal (29)	Install	In air chamber (3)
9	Bearings (15, 17, 23, and 26)	Inner seals	Remove, if present	All bearings must be single sealed

NOTE

Perform step 10 below only if items in sheave assembly (21 thru 27) were removed.

10	Sheave assembly (21 thru 27)	a. Bearing (26)	Install	Press in, V of outer race pointing down
		b. Two bearing spacers (24 and 25)	Position	
		c. Bearing (23) pointing down	Install	Press in, V of outer race
		d. Clutch lining (22)	Position	On sheave (27)
		e. Six socket head capscrews (21)	Install	Tighten to 60 pounds inch torque

NOTE

Perform step 11 below only if items in clutch disc assembly (12 thru 19) were removed.

11	Clutch disc assembly (12 thru 19)	a. Bearing (17)	Install	Press into splined hub (18), seal facing outward
		b. Bearing spacer (16)	Position	
		c. Bearing (15)	Install	Press into splined hub (18), seal facing outward
		d. Splined hub (18)	Install	In clutch disc (19)

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		e. Spring (14)	Install	Place spring tang in clutch disc (19) hole
		f. Spring retainer (13)	Install	On spring (14), hole at least two teeth counterclockwise from spring tang
		g. Retaining ring (12)	Install	Compress spring (14) to install; use screwdriver to force tang of spring into hole in spring retainer (13)
12	Fan drive assembly	a. Bracket (28)	Clamp	In vise; shaft up
		b. Sheave assembly (21 thru 27)	Install	On bracket (28) shaft
		c. Journal spacer (20)	Install	
		d. Clutch disc assembly (12 thru 19)	Install	
		e. New lock washer (11)	Position	
		f. Adjusting nut (10)	a. Install	Use adjusting nut socket; tighten to 150 pounds foot torque
		b. Secure	Pry lock washer (11) tab into adjusting nut slot with screwdriver	

NOTE

Use new items 1, 2, and 4 thru 9 from seal kit in following steps.

g.	New U-cup (9)	Install	In bracket (28) cavity, open side down
h.	New O-ring (7)	a. Lubricate b. Install	Use lubricant On cartridge (8)
i.	New cartridge (8)	Install	

3-5. COOLING SYSTEM MAINTENANCE (CONT)

c. Fan Drive Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
12 (cont)	ring (6)	j. New retaining	Install	Use retaining ring pliers
		k. Two new O-rings (4 and 5)	a. Lubricate b. Install	Use lubricant
		l. Air chamber (3)	Position	
		m. Eight new lock washers (2) and socket head cap- screws (1)	Install	Tighten to 15 pounds foot torque

Section II. ELECTRICAL SYSTEM MAINTENANCE

This section contains the information you need to maintain the:

- Alternator
- Starter
- Wiring Harness

It gives you instructions on how to troubleshoot problems and repair or replace the components that are within the scope of direct support maintenance.

Troubleshooting Symptom Index.....	Para 3-6
Alternator Troubleshooting.....	3-7
Starter Troubleshooting.....	3-8
Alternator Maintenance	3-9
Starter Maintenance	3-10
Water Level Warning Kit Maintenance	3-11
Wiring Harness Maintenance	3-12
Cab Harnesses	3-12a
Upper Cab Harness.....	3-12a(1)
Lower Cab Harness.....	3-12a(2)
Chassis Harnesses.....	3-12b
Front Chassis Harness.....	3-12b(1)
Rear Chassis Harness	3-12b(2)
Instrument Panel Harnesses	3-12c
Front Panel Harness	3-12c(1)
Right Corner Panel Harness	3-12c(2)
Right Panel Harness	3-12c(3)
Engine Panel Harness.....	3-12d

3-6. TROUBLESHOOTING SYMPTOM INDEX

NOTE

An electrical system wiring schematic is located at the back of this manual in appendix E.

	Para/Malfunction	Page
ALTERNATOR		
Alternator not operating properly.....	3-7/1	3-35
STARTER		
Starter not operating properly.....	3-8/1	3-35

3-7. ALTERNATOR TROUBLESHOOTING

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

1. ALTERNATOR NOT OPERATING PROPERLY

Perform alternator electrical tests (para 3-9).

If tests indicate parts are defective, replace (para 3-9).

3-8. STARTER TROUBLESHOOTING

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

1. STARTER NOT OPERATING PROPERLY

Step 1. Perform starter bench test (para 3-10).

- a. If test indicates parts are defective, replace (para 3-10).
- b. If test does not indicate parts are defective, proceed to step 2 below.

Step 2. Connect voltmeter leads to ground and starter switch control terminal (single black electrical lead behind shield). Turn key switch to on position.

- a. If voltmeter indicates zero volts, replace starter switch (para 3-10).
- b. If voltmeter indicates 12-14 Vdc, replace solenoid (para 2-25a).

3-9. ALTERNATOR MAINTENANCE

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Testing
 - e. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Combination wrench set
- Socket head screw key set
- Multimeter
- Safety glasses
- Torque wrench
- Puller kit

Fuel and Electrical Systems Tool Kit

Soft mallet

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Light machine oil Item 7, Appendix C
- Felt seal FSCM 16764 PN 825197
- Felt seal FSCM 16764 PN 1955660
- Thin wall tubing

Personnel Required

Electrical Systems Repairer MOS 63G

Equipment Condition

Paragraph Condition Description

2-24 Alternator removed from tractor.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY


1	Housing (8)	a. Five capscrews (1) and cover (2)	Remove	
		b. Nut (3) and washer (4)	Remove	Hold rotor (9) shaft using socket head screw key
		c. Pulley	Remove	If installed; para 2-24
		d. Fan (5)	Remove	
		e. Four capscrews (6)	Remove	
		f. Drive end frame (7) and housing (8)	Scribe	To aid reassembly
		g. Drive end frame (7) with rotor (9)	Remove	From housing (8) as an assembly
		h. Rotor (9)	Remove	Press from drive end frame (7)
		i. Shield (10)	Remove	

3-9. ALTERNATOR MAINTENANCE (CONT)

KEY

- 1. Capscrews (5)
- 2. Cover
- 3. Nut
- 4. Washer
- 5. Fan
- 6. Capscrews (4)
- 7. Drive end frame
- 8. Housing

- 42. Washer
- 43. Bushing
- 44. Washer
- 45. Bolt
- 46. Washer
- 47. Nut
- 48. Relay terminal connector
- 49. Nuts (3)
- 50. Screw
- 51. Lock washer



- 9. Rotor
- 10. Shield
- 11. Outside collar
- 12. Inside collar
- 13. Capscrews and washers (3)
- 14. Inside retainer plate
- 15. Felt seal
- 16. Cup
- 17. Ball bearing
- 18. Outside retainer plate
- 19. Felt seal
- 20. Screws (5)
- 21. Field coil
- 22. Nut
- 23. Screw
- 24. Connector
- 25. Screws (2)

- 26. Washers (2)
- 27. Insulators (2)
- 28. Regulator
- 29. Screw and washer
- 30. Lock washer
- 31. Washers (2)
- 32. Nut
- 33. Lock washer
- 34. Washer
- 35. Nut
- 36. Lock washer
- 37. Washer
- 38. Insulated washer
- 39. Output terminal connector
- 40. Cap
- 41. Bushing

- 52. Screws (2)
- 53. Rectifier bridge
- 54. Insulator
- 55. Diode trio
- 56. Screw
- 57. Bracket
- 58. Capacitor
- 59. Stator assembly
- 60. Grommet
- 61. Bearing
- 62. Bushing
- 63. Washer
- 64. Insulator
- 65. Bolt
- 66. Washers (2)

TA236280

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
1 (cont)		j. Outside collar (11)	Remove	
		k. Inside collar (12)	Remove	
2	Drive end frame (7)	a. Three capscrews (13) and inside retainer plate (14)	Remove	
		b. Cup (16) with felt seal (15)	Remove	
		c. Felt seal (15)	Remove	Separate from cup (16) only if necessary
		d. Ball bearing (17)	Remove	Press from drive end frame (7)
		e. Outside retainer plate (18) and felt seal (19)	Remove	
3	Housing (8)	a. Nut (22)	Remove	
		b. Screw (50) and lock washer (51)	Remove	
		c. Connector (24)	Remove	From regulator (28) and rectifier bridge (53)
		d. Three nuts (49)	Remove	
		e. Three stator (59) leads	Disconnect	From rectifier bridge (53)
4	Relay terminal connector (48)	a. Cap (40)	Remove	
		b. Nut (47)	Loosen	
		c. Relay terminal connector assembly (41 thru 48)	Remove	
		d. Bushing (41), washer (42), bushing (43), washer (44), bolt (45), washer (46), and nut (47)	Remove	From relay terminal connector (48)

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5	Housing (8)	a. Two screws (25), washers (26), and insulators (27)	Remove	
		b. Two field coil (21) leads	Disconnect	From regulator (28)
		c. Screw (23) and washer (63)	Remove	
		d. Diode trio (55) and regulator (28)	Remove	
6	Output terminal connector (39)	a. Screw (29) and lock washer (30)	Remove	
		b. Capacitor (58) lead	Disconnect	Move aside
		c. Nuts (32 and 35)	Loosen	
		d. Output terminal connector assembly (32 thru 39, 65, and 66)	Remove	
		e. Nut (32), washers (33 and 34), nut (35), washers (36, 37, and 38), insulator (64), and bolt (65)	Remove, if necessary	From output terminal connector (39)
7	Rectifier bridge (53)	a. Two screws (52), washers (66), and washers (31)	Remove	
		b. Rectifier bridge (53)	Remove	
		c. Insulator (54)	Remove	

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
8	Housing (8)	a. Screw (56), bracket (57), and capacitor (58)	Remove	
		b. Stator assembly (59)	Remove	
		c. Grommet (60)	Remove	
		d. Five screws (20)	Remove	
		e. Field coil (21)	Remove	
		f. Bearing (61)	Remove	Use thin wall tubing to press from housing (8)
		g. Bushing (62)	Remove	Only if needed for replacement. Use suitable sleeve to press out

CLEANING

CAUTION

Do not clean rotor or stator assembly with cleaning solvent.

9		a. Rotor (9) and stator assembly (59)	Clean	Wipe with clean, absorbent, lintless cloth to remove grease
---	--	---------------------------------------	-------	---

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

CAUTION

Do not spin bearings when drying with compressed air to prevent damage.

9 (cont)		b. All other parts	Clean	Wipe with clean, soft, lint-less cloth moistened with cleaning solvent P-D-680. Dry with compressed air
-------------	--	--------------------	-------	---

INSPECTION


10		a. Cover (2)	Inspect	Replace if cracked or distorted
		b. Fan (5)	Inspect	Replace if cracked, broken, or distorted. Be sure to inspect fan blades
		c. Rotor (9)	Inspect	Replace if cracked, worn, distorted, threads damaged, shaft bent, or slip rings damaged or scored
		d. Ball bearing (17) and bearing (61)	Inspect	Replace if worn, cracked, pitted, or otherwise
		e. Stator assembly (59)	Inspect	Replace if cracked, worn, discolored, unwound, or evidence of overheating
		f. All other parts	Inspect	Replace if cracked, broken, worn, distorted, leads or connectors damaged, or threads damaged

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING

11 a. Field coil (21) Test




Using ohmmeter check:

- a. For grounds. Connect ohmmeter between one field coil lead and housing (sequence A as shown). Field coil is grounded if reading is low
- b. For opens. Connect ohmmeter between two field coil leads (sequence B as shown). Field coil is open if ohmmeter reading is high or infinite
- c. For short circuits. Connect ohmmeter between two field coil leads (sequence B as shown). Winding is shorted if ohmmeter reading is less than 0.2 ohms. Replace field coil if defective

Using ohmmeter connect prod to grounded heat sink and base of one of the three terminals as shown. Observe reading. Reverse prods. Observe reading. If readings are identical, replace rectifier bridge. Repeat procedure with remaining two terminals. Connect prods to insulated heat sink and one of three terminals. Observe reading. Reverse prods. Observe reading. If readings are identical, replace rectifier bridge. Repeat procedure with each of two remaining terminals

b. Rectifier bridge (53) Test



3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


TESTING (cont)

11
(cont)


c. Diode trio (55) Test

Set ohmmeter with 1-1/2 volt cell to lowest resistance range. Connect ohmmeter leads to single connector and one of three stator lead connectors as shown. Observe reading. Reverse ohmmeter leads and observe reading. Repeat procedure with each of two remaining stator lead connectors. There should be one low and one high reading for each test. Readings should not be identical in each test. If readings are the same, replace diode trio

Connect ohmmeter between each stator lead and housing as shown to check for grounds. If ohmmeter reading is low, the stator assembly is grounded. Replace a defective stator assembly



TA236282



TA236283

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING (cont)

11
(cont)

NOTE

It is not possible to check the stator assembly for opens or short circuits without laboratory test equipment. However, if all other checks are normal and alternator does not produce rated output, shorted windings are indicated.

REASSEMBLY

12	Housing (8)	a. Bushing (62)	Install	Use suitable sleeve and press in
		b. Bearing (61)	Install	Use thin wall, tubing to press in. Bearing must be flush with drive end of housing
		c. Grommet (60)	Install	
		d. Stator assembly (59)	Install	
		e. Capacitor (58)	Position	
		f. Bracket (57) and screw (56)	Install	
		g. Field coil (21)	Position	
		h. Five screws (20)	Install and tighten	
		i. Insulator (54)	Install	
		j. Rectifier bridge (53)	Install	
		k. Two screws (52), washers (66), and washers (31)	Install	
13	Output terminal connector (39)	a. Insulated washer (38), washer (37), lock washer (36), nut (35), washer (34), lock washer (33), nut (32), insulator (64) and bolt (65)	Assemble	On top of connector (39)

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
13 (cont)		b. Output terminal connector (39)	Position	On rectifier bridge (53)
		c. Nut (35)	Tighten	
		d. Screw (29) and washer (30)	Install	Through capacitor (58) lead and output terminal connector (39)
14	Housing (8)	a. Regulator (28)	Position	
		b. Screw (23) and washer (63)	Install	
		c. Connector (24)	Position	
		d. Screw (50), nut (22), and lock washer (51)	Install	
		e. Diode trio (55)	Install	
		f. Two screws (25) with washers (26) and insulators (27)	Install	Through field coil (21) leads and diode trio (55) leads
15	Relay terminal connector (37)	a. Nut (47), washer (46), bolt (45), bushing (43), washer (42), and bushing (41)	Assemble	On top of relay terminal connector (48)
		b. Relay terminal connector (48)	Position	On rectifier bridge (53)
		c. Stator assembly (59) leads	Connect	
		d. Three nuts (49)	Install and tighten	
		e. Nut (47)	Tighten	
		f. Cap (40)	Install	

NOTE

Soak felt seals (15 and 19) in light oil before reassembly.

3-9. ALTERNATOR MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
16	Drive end frame (7)	a. Felt seal (19)	Install	
		b. Outside retainer plate (18)	Install	
		c. Ball bearing (17)	Install	Press in
		d. Cup (16)	Install	
		e. Felt seal (15)	Install	
		f. Inside retainer plate (14)	Position	
		g. Three capscrews (13)	Install	
		h. Inside collar (12)	Install	
		i. Outside collar (11)	Install	
		j. Shield (10)	Position	
		k. Rotor (9)	Install	Press in drive end frame (7)
		l. Housing (8) and drive end frame (7)	Assemble	Align scribe marks
		m. Four capscrews (6)	Install	
		n. Fan (5)	Install	
		o. Pulley	Install	Para 2-24
		p. Washer (4) and nut (3)	Install and tighten	Hold rotor (9) shaft using socket head screw key
17	Housing (8)	a. Cover (2)	Position	
		b. Five capscrews (1)	Install and tighten	
18	Engine, rear	Alternator	Install	Para 2-24

3-10. STARTER MAINTENANCE

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Testing
 - e. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

- Tool Kit Clean cloths
- Socket wrench set
- Combination wrench set
- Retaining ring pliers
- Screwdriver
- Torque wrench
- Vise jaw caps
- Safety glasses

Automotive Mechanic's Tool Kit

- Thickness gage
- Hammer
- Punch

Soldering iron, electric

Armature tester FSCM 82386 PN AT-75

Bore micrometer

RPM indicator

Soft metal (brass) rod

Block of wood

Arbor press

from tractor.

Materials/Parts

Cleaning solvent

Item 2, Appendix C

Grease

Engine oil, SAE 20

Electrical tape

Solder

O-ring

O-ring

Gasket

Four brushes

Lubricant,

Delco-Remy

Item 1, Appendix C

Item 3, Appendix C

Item 24, Appendix C

Item 37, Appendix C

Item 41, Appendix C

FSCM 16764 PN 1894642

FSCM 16764 PN 1894643

FSCM 16764 PN 1945476

FSCM 16764 PN 1852883

FSCM 16764 PN 1960954

Personnel Required

Electrical Systems Repairer MOS 63G

Equipment Condition

Paragraph

Condition Description

2-25b


Starter with switch removed

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY

1	Starter	a.	Drive housing (27), switch (35), housing (36), field frame (26), and frame (12)	Scribe	Use center punch to scribe position marks to aid in reassembly
		b.	Two plugs (1) and gaskets (2)	Remove	
		c.	Nut (4)	Remove	
		d.	Electrical lead (22)	Disconnect	From brush plate assembly (16) ground stud
		e.	Nut with washer (51)	Remove	

3-10. STARTER MAINTENANCE (CONT)



TA236263

3-10. STARTER MAINTENANCE (CONT)

KEY

- | | | |
|---------------------------|-----------------------------|---------------------|
| 1. Plugs (2) | 26. Field frame | 51. Nut with washer |
| 2. Gaskets (2) | 27. Drive housing | 52. Screws (5) |
| 3. Screws (2) | 28. Plug | 53. Nut |
| 4. Nut | 29. Wick | 54. Armature |
| 5. Nut | 30. Bushing | 55. Washer |
| 6. Lock washer | 31. Plug | 56. Oil seal |
| 7. Washer | 32. Gasket | 57. O-ring |
| 8. Insulator | 33. Nut | 58. Drive assembly |
| 9. Washer | 34. Screws with washers (4) | 59. Gasket |
| 10. Capscrews (4) | 35. Switch | 60. Washer |
| 11. O-ring | 36. Housing | 61. Bushing |
| 12. Frame | 37. Snap ring | 62. Nut |
| 13. Plug | 38. Retainer | 63. Connector |
| 14. Wick | 39. Spring | 64. Nut |
| 15. Screws (3) | 40. Retainer | 65. Washer |
| 16. Brush plate assembly | 41. Boot | 66. Washer |
| 17. O-ring | 42. Washer | 67. Screws (8) |
| 18. Washer | 43. Plunger | 68. Poleshoes (4) |
| 19. Bushing | 44. Snap ring | 69. Insulator |
| 20. Washer | 45. Shaft | 70. Washer |
| 21. Capscrews (4) | 46. O-ring | 71. Bushing package |
| 22. Electrical lead (BLK) | 47. O-ring | 72. Insulator |
| 23. Brushes (4) | 48. Lever | 73. Field coil |
| 24. Springs (4) | 49. Plug | 74. Stud |
| 25. Capscrews (6) | 50. Wick | |

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

1 (cont)		f. Electrical lead (22)	a. Disconnect	From switch (35) ground terminal
		g. Two screws (3)	b. Remove	Through plug (1) holes in field frame (26)
		h. Four capscrews (10)	Remove	
		i. Frame (12) with brush plate assembly (16)	Remove	As an assembly
	j. Washer (20)	Remove		
2	Frame (12)	a. O-ring (17)	Remove	
		b. Four capscrews (21), springs (24), and brushes (23)	Remove	

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS		
DISASSEMBLY (cont)						
2 (cont)	c.	Nut (5), lock washer (6), washer (7), and insulator (8)	Remove			
		d. Three screws (15) and brush plate assembly (16)	Remove			
		e. O-ring (11), washer (9), and washer (18)	Remove	From brush plate assembly (16)		
		f. Plug (13) and wick (14)	Remove	From frame (12)		
		g. Bushing (19)	Remove	Only if inspection indicates need for replacement		
		3	Drive housing (27)	a. Six capscrews (25), drive housing (27), and gasket (59)	Remove	Discard gasket (59)
				b. Plug (28) and wick (29)	Remove	
c. Drive housing (27)	Support			In soft-faced vise		
d. Bushing (30)	Remove			Use soft metal rod or wood dowel. Strike rod with hammer		
4 (36)	Housing	a. Plug (31), gasket (32), and nut (33)	Remove			
		b. Five screws (52)	Remove			
		c. Housing (36) with drive assembly (58) and washer (60)	Remove	As an assembly		
		d. Snap ring (44)	Remove	Use retaining ring pliers		
		e. Shaft (45)	Remove	Use wood dowel to push out		
		f. Two O-rings (46 and 47)	Remove and discard			

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4 (cont)		g. Drive assembly (58) and washer (60)	Remove	From housing (36)
		h. Lever (48)	Remove	
		i. Plug (49) and wick (50)	Remove	
		j. Washer (55), oil seal (56), and O-ring (57)	Remove	
		k. Housing (36) l. Bushing (61)	Support Remove	In soft-faced vise Use soft metal rod or wood dowel. Strike rod with hammer
5	Switch (35)	a. Four screws with washers (34)	Remove	
		b. Nut (53)	Remove	Disconnect connector (63) from switch (35)
		c. Switch (35)	Remove	From housing (36)
		d. Snap ring (37)	Remove	Use retaining ring pliers
		e. Retainer (38), spring (39), retainer (40), boot (41), washer (42), and plunger (43)	Remove	
6	Field frame (26)	a. Armature (54)	Remove	
		b. Nut (62), connector (63), nut (64), and two washers (65 and 66)	Remove	
		c. Eight screws (67) and four poleshoes (68)	Remove	
		d. Insulator (69)	Remove	Only if inspection indicates need for replacement
		e. Washer (70), bushing package (71), and insulator (72)	Remove	

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
6 (cont)		f. Field coil (73) with stud (74)	Remove	
		g. Stud (74)	Remove	Unsolder and remove only if necessary for replacement
CLEANING				
7		a. Frame (12), brush plate assembly (16), brushes (23), armature (54), drive assembly (58), and field coil (73)	Clean	Wipe with a clean, dry, lint-free cloth only. Do not use cleaning solvent
		b. Electrical lead (22)	Clean	Wipe with clean, dry cloth

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
7 (cont)		c. All other metal parts	Clean	Use clean cloth moistened with cleaning solvent P-D-680; dry with compressed air
INSPECTION				
8		a. Electrical lead (22)	Inspect	Replace if insulation cut or frayed, or conductor or terminals corroded or broken
		b. O-rings (11, 17, and 57) and gaskets (2 and 32)	Inspect	Replace if cracked, worn, damaged, or distorted
		c. Two bushings (30 and 61)	Inspect	Replace if worn, cracked, pitted or burred, or if inside diameter exceeds 0.6250 inch
		d. Armature (54)	Inspect	Replace if cracked, worn, damaged or distorted, or commutator rough or out of round
		e. Drive assembly (58)	Inspect	Replace if worn, damaged, distorted, or pinion teeth cracked, chipped, worn or damaged
		f. Field coil (73)	Inspect	Replace if windings broken or loose, or if cracked, broken or distorted
		g. Springs (24 and 39)	Inspect	Replace if cracked, broken, or permanently set
		h. All other parts	Inspect	Replace if cracked, worn, broken, distorted, or threads damaged

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


TESTING

9

a. Armature (54)

a. Test for grounded winding


Place armature in growler and turn power on. Touch one test probe to armature core, the other probe to commutator, as shown. If test lamp glows, the armature winding or commutator is grounded



TA127139

b. Test for shorted winding

a. Position armature in growler. Turn on power. Use steel blade provided with tester. Hold blade parallel with, and touching, the armature core segment, as shown
 b. Rotate armature slowly one or more revolutions. If the armature is shorted, the steel blade will vibrate. Turn power off
 c. Position armature in growler, as shown. Turn power on



TA127140


3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING (cont)

9

c. Test commutator bars



Follow directions supplied with growler, and test commutator bars for abnormal readings. Abnormal readings will indicate a short, open or poor connection. If testing indicates commutator is grounded, the armature is shorted, or commutator readings indicate a short, open or poor connection, replace armature

b. Field coil (73) Test

Disconnect field coil ground connection. Use test lamp. Connect one test probe of the test lamp to the connector (63) and the other probe to the frame (12). If test lamp lights, the field coils (73) are grounded, remove and replace coils. Touch test probes to each end of the field coil winding. If test lamp does not light, the field coils are open. If coils are open, replace field coil (73).

REASSEMBLY

10

Field frame (26)

- a. Stud (74)
- b. Insulator (72)
- c. Bushing package (71) and washer (70)

- a. Position if removed
- b. Solder Position Install

In field coil (73)

On stud (74)

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
10 (cont)		d. Insulator (69)	Position	Around field coil (73), if removed
		e. Four poleshoes (68) and eight screws (67)	Install and tighten	
		f. Two washers (66 and 65)	Install	
		g. Nut (64), connector (63), and nut (62)	Install; tighten nuts	
		h. Armature (54)	Install	
11	Drive housing (27)	a. Drive housing (27)	Support	In soft-faced vise
		b. Wick (29) and bushing (30)	Lubricate	Soak in SAE 20 engine oil.
		c. Wick (29)	Install	
		d. Bushing (30)	Press in	Use arbor press
		e. Plug (28)	Install	
12	Housing (36)	a. Housing (36)	Support	In soft-faced vise
		b. Wick (50) and bushing (61)	Lubricate	Soak in SAE 20 engine oil
		c. Wick (50)	Install	
		d. Bushing (61)	Install	Use arbor press
		e. Plug (49)	Install	
		f. Oil seal (56) and O-ring (57)	Install	
		g. Washer (60)	a Coat with grease b Install	Holds washer in place
		h. Drive assembly (58)	Lubricate	Use Delco-Remy lubricant FSCM 16764 PN 1960954
		i. Lever (48) and drive assembly (58)	Position	
		j. Two new O-rings (47 and 46)	Install	On shaft (45)
		k. Shaft (45)	Install	
		l. Snap ring (44)	Install	Use retaining ring pliers

3-10. STARTER MAINTENANCE (CONT)


STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
13	Plunger (43)	a. Washer (42), boot (41), retainer (40), spring (39), and retainer (38)	Install	On plunger (43)
		b. Snap ring (37)	Install	On plunger (43); use retaining ring pliers
		c. Plunger assembly (37 thru 43)	Position	Install plunger and assembled parts into switch (35)
		d. Switch (35)	Position	
		e. Four screws with washers (34)	Install and tighten	
		f. Connector (63)	Install	On switch (35) M terminal
		g. Nut (53)	Install and tighten	
14	Field frame (26)	a. Washer (55)	Install	On armature (54)
		b. Housing (36)	Install	Observe caution when inserting plunger (43) and assembled parts into housing
		c. Five screws (52)	Install and tighten	
		d. Nut (33)	Install	
		e. New gasket (32) and plug (31)	Install	
		f. New gasket (59)	Install	
		g. Drive housing (27)	Position	Against housing (36)
		h. Six capscrews (25)	Install	Tighten to 13-17 pounds ft torque
15	Frame (12)	a. Wick (14) and bushing (19)	Lubricated	Soak in SAE 20 engine oil
		b. Wick (14)	Install	
		c. Bushing (19)	Install	Use arbor press, if removed
		d. Washers (18 and 9)	Install	On brush plat assembly (16)
		e. Brush plat assembly (16)	Position	On frame (12)
		f. Three screws (15)	Install and tighten	
		g. O-ring (11)	Install	

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
15 (cont)		h. Insulator (8)	Install	
		i. Washer (7), lock washer (6), and nut (5)	Install	Tighten nut to 20-25 pounds foot torque
		j. Four brushes (23), springs (24), and capscrews (21)	Install	
		k. Plug (13) and O-ring (17)	Install	
16	Field frame (26)	a. Armature (54)	Pull out	Pull armature from field frame (26) just enough to fully expose commutator
		b. Washer (20)	a. Lubricate b. Install	On armature (54)
		c. Frame (12)	Install	On armature (54) Pull up brushes (23) just enough to allow them to slide onto commutator Then push in frame assembly
		d. Four capscrews (10)	Install and tighten	
		e. Two screws (3)	Install	Through plug (1) holes Be sure screws pass through field coil (73) leads
		f. Two plugs (1) and gaskets (2)	Install	
		g. Electrical lead (22)	Position	On brush plate assembly (16) ground stud and switch (35) ground terminal
		h. Nut with washer (51)	Install	Tighten to 16-30 pounds inch torque
		i. Nut (4)	Install	Tighten to 20-25 pounds foot torque

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
17	Insulator (69)	a. Connector (63) b. Starter with switch	Tape Connect	Wrap with electrical tape To test circuit as shown



TA236249


CAUTION

Check pinion clearance quickly to avoid overheating and damaging switch windings.

c. Jumper lead	Momentarily connect	From switch motor (M) terminal (to shift pinion into cranking position)
----------------	---------------------	---

3-10. STARTER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
17 (cont)		d. Drive assembly (58) pinion	Check clearance	Push clutch back as far as possible toward armature; check clearance as shown



TA127143

NOTE

Pinion clearance must measure 0.359 inch to prevent buttons on lever (48) from rubbing on the clutch collar during cranking. If clearance is not correct, nut (33) can be adjusted. If proper clearance can't be achieved, recheck for proper assembly, and replace all worn parts.

e. Starter with switch	Disconnect	From pinion clearance test set-up
f. Connector (63)	a. Remove tape b. Install	On motor (M) terminal of switch (35)
g. Nut (53)	Install	Tighten to 20-25 pounds foot torque

3-11. WATER LEVEL WARNING KIT MAINTENANCE

This task covers:

- a. Disassembly
- b. Cleaning
- c. Inspection
- d. Reassembly

INITIAL SETUP:

Tools

No 2 Common Organizational Maintenance Tool Kit

- Socket head screw key set
- Combination wrench set
- Soldering gun, electric
- Safety glasses

Automotive Mechanic's Tool Kit
Pliers

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

2-29 Water level sensor removed from tractor.


Materials/Parts

- Cleaning solvent
- Clean cloths
- Solder
- Two gaskets

- Item 1, Appendix C
- Item 2, Appendix C
- Item 41, Appendix C
- FSCM 90915 PN 8154

KEY

- 1 Capscrews (12)
- 2 Top cover
- 3 Bottom cover
- 4 Cylinder
- 5 Piston
- 6 Gaskets (2)
- 7 Ring
- 8 Arm assembly
- 9 Washer
- 10 Spring
- 11 Torsion spring
- 12 Torsion arm
- 13 Spring holder
- 14 Locknut
- 15 Contact cover
- 16 Nuts (2)
- 17 Lock washers (2)
- 18 Washers (2)
- 19 Screws (2)
- 20 Contact assembly
- 21 Wiring assembly
- 22 Screw
- 23 Washer
- 24 Sleeve
- 25 Spacer



TA236351

3-11. WATER LEVEL WARNING KIT MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
1	Water level warning kit	a. 12 capscrews (1)	Remove	
		b. Top cover (2) and bottom cover (3)	Separate	
		c. Cylinder (4)	Remove	
		d. Piston (5)	Remove	
		e. Two gaskets (6)	Remove and discard	
		f. Ring (7)	Remove	
		g. Locknut (14) and contact cover (15)	Remove	
		h. Arm assembly (8)	Remove	
		i. Washer (9)	Remove	
		j. Spring (10)	Remove	
		k. Torsion spring (11)	Remove	
		l. Spring holder (13)	Remove	
		m. Screw (22), washer (23), sleeve (24), and spacer (25)	Remove	
		n. Torsion arm (12)	Remove	
		o. Two nuts (16), lock washers (17), washers (18), and screws (19)	Remove	
		p. Contact assembly (20) with wiring assembly (21)	Remove	

NOTE

Perform step 2 below only if replacement of wiring assembly (21) is required.

2	Contact assembly (20)	Three wiring assembly (21) leads	a. Tag b. Remove	Unsolder wire leads connected to contact assembly (20)
---	-----------------------	----------------------------------	---------------------	--

3-11. WATER LEVEL WARNING KIT MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING				
3		a. Wiring assembly (21) and contact assembly (20)	Clean	Wipe with clean, dry cloth
<u>WARNING</u>				
<p>Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.</p> <p>Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.</p>				
		b. All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air or clean cloths
INSPECTION				
4		a. Wiring assembly (21)	Inspect	Replace if insulation cracked or frayed, or conductors corroded or broken
		b. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

3-11. WATER LEVEL WARNING KIT MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
5	Water level warning kit	a. Three wiring assembly (21) leads	Connect	To contact assembly (20), if removed Solder wire leads to contacts
		b. Contact assembly (20)	Position	
		c. Two screws (19), washers (18), lock washers (17), and nuts (16)	Install and	tighten
		d. Three wiring assembly (21) leads	Route	Through top cover (2) hole
		e. Torsion arm (12)	Position	
		f. Spacer (25), sleeve (24), washer (23) and screw (22)	Install	Do not tighten screw
		g. Spring holder (13)	Install	
		h. Torsion spring (11)	Install	
		i. Spring (10)	Install	
		j. Screw (22)	Tighten	Make sure torsion arm (12) is positioned correctly
		k. Washer (9)	Install	
		l. Arm assembly (8)	Install	
		m. Contact cover (15) and locknut (14)	Install	
		n. Ring (7)	Install	
		o. Two new gaskets (6)	Install	
		p. Piston (5)	Install	
		q. Cylinder (4)	Install	
r. Bottom cover (3) and top cover (2)	Mate			
s. 12 capscrews (1)	Install and tighten	Tighten alternately		
6	Transmission cross tie	Water level sensor	Install	Para 2-29

3-12. WIRING HARNESS MAINTENANCE

a. Cab Harnesses.

(1). Upper Cab Harness. This task covers removal and installation.

INITIAL SETUP

Tools

No 1 Common Organizational Maintenance

Tool Kit

Screwdriver

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description


Vehicle parked on level surface, engine off, and parking brake applied

2-34a Battery ground cable disconnected.

2-26g(1) Instrument panel raised.

KEY

- 1. Screws (6)
- 2. Washers (6)
- 3. Clamps (6)
- 4. Upper cab harness



3-12. WIRING HARNESS MAINTENANCE (CONT) I

a. Cab Harnesses (cont).

(1). Upper Cab Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Cab, inside	Upper cab harness (4) connector	Disconnect	Para 2-35a(1)
2	Cab ceiling	a. Roof floodlight connectors	Disconnect	Para 2-31g
		b. Marker light connectors	Disconnect	Para 2-31e
		c. Six screws (1), washers (2), and clamps (3)	Remove	From upper cab harness (4); note locations for installation
3	Cab	Upper cab harness (4)	Remove	From tractor
INSTALLATION				
4	Cab	Upper cab harness (4)	Position	
5	Cab ceiling	a. Six clamps (3), washers (2), and screws (1)	Install	On upper cab harness (4), at locations noted during removal
		b. Marker light connectors	Install	Para 2-31e
		c. Roof floodlight connectors	Install	Para 2-31g
6	Cab, inside	a. Upper cab harness (4) connector	Connect	Para 2-35a(1)
		b. Instrument panel	Lower and secure	Para 2-26g(1)
7	Battery box	Battery ground cable	Connect	Para 2-34a

3-12. WIRING HARNESS MAINTENANCE (CONT)


- a. Cab Harnesses (cont).
- (2). Lower Cab Harness. This task covers removal and installation.

INITIAL SETUP

Personnel Required
Automotive Repairer MOS 63H

Equipment Condition
Paragraph Condition Description

- 2-34a Vehicle parked on level surface, engine off, and parking brake applied. Battery ground cable disconnected.
- 2-26g(1) Instrument panel raised.



STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Cab, inside	Lower cab harness	a Disconnect b Remove	Para 2-35a(2) From cab
INSTALLATION				
2	Cab, inside	a Lower cab harness b Instrument panel	a Position b Connect Lower and secure	In cab Para 2-35a(2) Para 2-26g(1)
3	Battery box	Battery ground cable	Connect	Para 2-34a

3-12. WIRING HARNESS MAINTENANCE (CONT)

b Chassis Harnesses.


(1). Front Chassis Harness. This task covers removal and installation.

INITIAL SETUP

Tools	Equipment Condition	Paragraph	Condition Description
No	1 Common Organizational Maintenance		
Tool Kit	Combination wrench set		Vehicle parked on level surface, engine off, and parking brake applied. Cab tilted 45 degrees.
Materials/Parts		2-34a	Battery ground cable disconnected.
Tie straps	FSCM 96906 PN MS3667-1-9		
Personnel Required			
Automotive Repairer	MOS 63H		

KEY

- 1. Grommets (2)
- 2. Nuts (13)
- 3. Clamps (13)
- 4. Tie straps
- 5. Front chassis harness



TA236245

13-12. WIRING HARNESS MAINTENANCE (CONT)

b. Chassis Harnesses (cont).

(1). Front Chassis Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Cab, under hood	Front chassis harness connectors	Disconnect	Para 2-35b(1)
2	Tractor front	a. Headlights	a Remove b Disconnect	Para 2-31a
		b. Front turn indicator lights	a Remove b Disconnect	Para 2-31d
3	Cab, underside	24V INVERTER switch black/yellow electrical lead	Disconnect	Para 2-26a(9)
4	Corner instrument panel, underside	40A circuit breaker brown/orange electrical lead	Disconnect	Para 2-26e
5	24V inverter	a. Three 24V inverter electrical leads	Disconnect para 2-30	From GND.-, BAT.+ , and IGN. terminals of 24V inverter,
		b. Six 15A circuit breaker electrical leads	Disconnect	From same side of circuit breakers, para 2-30
		c. White (ground) wire	Disconnect	Para 2-30
6	Engine compartment rear grille	Windshield washer pump and reservoir brown/blue electrical lead	Disconnect	Para 2-69c
7	Front chassis harness	a. Two grommets (1)	Remove	Note location for installation
		b. 13 nuts (2) and clamps (3)	Remove	Note location for installation
		c. Tie straps (4)	Cut, remove, and discard	As necessary; note locations for installation

13-12. WIRING HARNESS MAINTENANCE (CONT)

b. Chassis Harnesses (cont).

(1). Front Chassis Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
8	Cab	Front chassis harness (5)	Remove	From tractor
INSTALLATION				
9	Cab	Front chassis harness (5)	Position	
10	Front chassis harness	a. New tie straps (4)	Install	At locations noted during removal
		b. 13 clamps (3) and nuts (2)	Install and tighten	At locations noted during removal
		c. Two grommets (1)	Install	At locations noted during removal
11	Engine compartment rear grille	Windshield washer pump and reservoir brown/blue electrical lead	Connect	Para 2-69c
12	24V inverter	a. Six 15A circuit breaker electrical leads	Connect	Para 2-30
		b. Three 24V inverter electrical leads	Connect	Para 2-30
		c. White (ground) wire	Connect	Para 2-30
13	Corner instrument panel, underside	40A circuit breaker brown/orange electrical lead	Connect	Para 2-26e
14	Cab, underside	24V INVERTER switch black/yellow electrical lead	Connect	Para 2-26a(9)

13-12. WIRING HARNESS MAINTENANCE (CONT) I

b. Chassis Harnesses (cont).

(1). Front Chassis Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
15	Tractor front	a. Front turn indicator lights b. Headlights	a. Connect b. Install a. Connect b. Install	Para 2-31d Para 2-31a
16	Cab, under hood	Front chassis harness connectors	Connect	Para 2-35b(1)
17	Cab tilt pump	Cab Lower	To normal operating position	
18	Battery box	Battery ground cable	Connect	Para 2-34a

13-12. WIRING HARNESS MAINTENANCE (CONT)


- b. Chassis Harnesses (cont).
- (2). Rear Chassis Harness. This task covers removal and installation.

INITIAL SETUP

Tools
 No 1 Common Organizational Maintenance
 Tool Kit
 Combination wrench set

Personnel Required
 Automotive Repairer MOS 63H

Equipment Condition
 Paragraph Condition Description
 2-34a Vehicle parked on level surface, engine off, and parking brake applied. Fifth wheel boom raised. Cab tilted 45 degrees. Battery ground cable disconnected.



STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Tractor, underside	a. Rear chassis harness (3) connector	Disconnect	Para 2-35b(2)
		b. Fuel level sender white and yellow/black electrical leads	Disconnect	Para 2-32b

13-12. WIRING HARNESS MAINTENANCE (CONT) I

b Chassis Harnesses (cont).

(2). Rear Chassis Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2	Tractor rear	a. White ground lead	Disconnect	From tractor protection valve mounting hardware; para 3-24h
		b. Tail and stop lights	a Remove b Disconnect	Para 2-31b
3	Left frame rail	a. Four nuts (1) and clamps (2)	Remove	
		b. Rear chassis harness (3)	Remove	From tractor
INSTALLATION				
4	Left frame rail	a. Rear chassis harness (3)	Position	
		b. Four clamps (2) and nuts (1)	Install	
5	Tractor rear	a. Tail and stop lights	a Connect b Install	Para 2-31b
		b. White ground lead	Connect	Use tractor protection valve mounting hardware; para 3-24h
6	Tractor, underside	a. Fuel level sender white and yellow/black electrical leads	Connect	Para 2-32b
		b. Rear chassis harness (3) connector	Connect	Para 2-35b(2)
7	Cab tilt pump	Cab Lower	To normal operating position	
8	Battery box	Battery ground cable	Connect	Para 2-34a
9	Cab	Fifth wheel boom	Lower fully	

13-12. WIRING HARNESS MAINTENANCE (CONT) I

c. Instrument Panel Harnesses.

(1). Front Panel Harness. This task covers removal and installation.

INITIAL SETUP

Tools

No 1 Common Organizational Maintenance
Tool Kit

Combination wrench set
Screwdriver
parking brake applied.

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description


Vehicle parked on level
surface, engine off, and

2-34a Battery ground cable
disconnected,

2-26g(1) Instrument panel with harness
removed from tractor.

KEY

- 1 Tie straps
- 2 Capscrews (2)
- 3 Fuse block and bulkhead connector
- 4 Front panel harness



TA236248

13-12. WIRING HARNESS MAINTENANCE (CONT) I

c. Instrument Panel Harnesses (cont).

(1). Front Panel Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Instrument panel, underside	a. Turn signal flasher	Unplug	Para 2-26a(10)
		b. Six ignition switch electrical leads	Disconnect	Para 2-26a(1)
		c. Two engine stop switch electrical leads	Disconnect	Para 2-26a(3)
		d. Four dash light electrical leads	Disconnect	Para 2-26d(2)
		e. Three blower switch electrical leads	Disconnect	Para 2-26a(8)
		f. Three hourmeter electrical leads	Disconnect	Para 2-88
		g. Two quick start switch electrical leads	Disconnect	Para 2-26a(2)
		h. Two windshield washer switch electrical leads	Disconnect	Para 2-69c
		i. Four headlight switch electrical leads	Disconnect	Para 2-26a(4)
		j. Two trailer light switch electrical leads	Disconnect	Para 2-26a(7)
		k. FUEL gage and circuit board	a. Disconnect leads b. Remove circuit board	Para 2-26b(3) Para 2-26b(3)
		l. TRANS/TORQUE CONVERTER light socket	Unplug	Para 2-26b(2)

13-12. WIRING HARNESS MAINTENANCE (CONT)

c. Instrument Panel Harnesses (cont).

(1). Front Panel Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
1 (cont)		m. High beam indicator light socket	Unplug	Para 2-26b(1)
		n. Three tachometer electrical leads	Disconnect	Para 2-86
		o. AIR PRESS gage, FUEL gage, speedometer, tachometer, OIL PRESS gage, WATER TEMP gage, and voltmeter gage light sockets	Unplug	Para 2-26d(1)
		p. Two WATER TEMP gage electrical leads	Disconnect	Para 2-87d
		q. Two voltmeter electrical leads	Disconnect	Para 2-26f

NOTE

Do not remove tie straps (1) unless necessary to remove front panel harness (4) from front panel.

r.	Tie straps (1)	Cut, remove, and discard	As necessary; note locations for installation
s.	Front panel harness (4)	Remove	From instrument panel

INSTALLATION

2	Instrument panel, underside	a.	Turn signal flasher	Connect	Para 2-26a(10)
		b.	Six ignition switch electrical leads	Connect	Para 2-26a(1)

13-12. WIRING HARNESS MAINTENANCE (CONT)

c. Instrument Panel Harnesses (cont).

(1). Front Panel Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
2 (cont)		c. Two engine stop switch electrical leads	Connect	Para 2-26a(3)
		d. Four dash light electrical leads	Connect	Para 2-26d(2)
		e. Three blower switch electrical leads	Connect	Para 2-26a(8)
		f. Three hour meter electrical leads	Connect	Para 2-88
		g. Two quick start switch electrical leads	Connect	Para 2-26a(2)
		h. Two windshield washer switch electrical leads	Connect	Para 2-69c
		i. Four headlight switch electrical leads	Connect	Para 2-26a(4)
		j. Two trailer light switch electrical leads	Connect	Para 2-26a(7)
		k. FUEL gage and circuit board	a. Install circuit	Para 2-26b(3)
			b. Connect leads	Para 2-26b(3)
		l. TRANS/TORQUE CONVERTER light socket	Install	Para 2-26b(2)
		m. High beam indicator light socket	Install	Para 2-26b(1)
		n. Three tachometer electrical leads	Connect	Para 2-86

13-12. WIRING HARNESS MAINTENANCE (CONT)

c. Instrument Panel Harnesses (cont).

(1). Front Panel Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
2 (cont)		o. AIR PRESS gage, FUEL gage, speedometer, tachometer, OIL PRESS gage, WATER TEMP gage, and voltmeter gage light sockets	Install	Para 2-26d(1)
		p. Two WATER TEMP gage electrical leads	Connect	Para 2-87d
		q. Two voltmeter electrical leads	Connect	Para 2-26f
		r. New tie straps (1)	Install	At locations noted during removal
3	Cab, inside	Front panel with front panel harness (4)	Install	Para 2-26g(1)
4	Battery box	Battery ground cable	Connect	Para 2-34a

13-12. WIRING HARNESS MAINTENANCE (CONT)

c. Instrument Panel Harnesses (cont).

(2). Right Corner Panel Harness. This task covers removal and installation.

INITIAL SETUP

<u>Tools</u>		<u>Equipment Condition</u>	
No	1 Common Organizational Maintenance	Paragraph	Condition Description
<u>Tool Kit</u>			
	Tool kit, electrical connector		Vehicle parked on level surface, engine off, and parking brake applied.
	Crimping tool		
	Wire stripper		
<u>Personnel Required</u>		2-34a	Cab tilted 45 degrees. Battery ground cable disconnected.
Automotive Repairer MOS 63H			

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


1	Cab	Right corner panel harness (2) connectors	Disconnect	Para 2-35c(2)
2	Instrument panel, underside	a. Ammeter light socket	Unplug	Para 2-26d(1)
		b. WATER LEVEL, WATER TEMP, OIL PRESSURE, and LOW AIR warning light sockets (3)	Unplug	Para 2-26b(4)
		c. Three flood light switch electrical leads	Disconnect	Para 2-26a(6)
		d. Six connectors (1)	Unplug 2-35	From three diodes, para f. Remove diodes
		e. Two water level warning bell electrical leads	Disconnect	Para 2-26c(1)
3	Cab	Right corner panel harness (2)	Remove	From tractor

NOTE

Perform step 4 below only if necessary to replace right corner panel harness (2).


13-12. WIRING HARNESS MAINTENANCE (CONT)

- c. Instrument Panel Harnesses (cont).
- (2). Right Corner Panel Harness (cont).



KEY

- 1. Connectors (6)
- 2. Right corner panel harness
- 3. Light sockets (4)
- 4. Crimp connectors (8)



STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
4	Right corner panel harness (2)	Four light sockets (3)	a. Remove b. Save	Cut light socket leads as close to crimp connectors (4) as possible For installation on new right corner panel harness (2)

13-12. WIRING HARNESS MAINTENANCE (CONT)

- c. Instrument Panel Harnesses (cont).
- (2). Right Corner Panel Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
NOTE				
Perform step 5 below only if new right corner panel harness (2) is being installed.				
5	New right corner panel harness (2)	Four light sockets (3) b. Connect	a. Strip	Strip 1/4 inch insulation from wire ends To right corner panel harness leads as shown with crimp connectors (4)
6	Cab	Right corner panel harness (2)	Position	
7	Instrument panel, underside	a. Ammeter light socket b. WATER LEVEL, WATER TEMP, OIL PRESSURE, and LOW AIR warning light sockets (3) c. Three flood light switch electrical leads d. Six connectors (1) e. Two water level warning bell electrical leads	Install Install Connect Connect Connect	Para 2-26d(1) Para 2-26b(4) Para 2-26a(6) To three diodes, para 2-35f Para 2-26c(1)
8	Cab	Right corner panel harness (2) connectors	Connect	Para 2-35c(2)
9	Cab tilt pump	Cab Lower	To normal operating position	
10	Battery box	Battery ground cable	Connect	Para 2-34a.

13-12. WIRING HARNESS MAINTENANCE (CONT)

c. Instrument Panel Harnesses (cont).

(3). Right Panel Harness. This task covers removal and installation.

INITIAL -SETUP

Materials/Parts


Tags Item 14, Appendix C
 Electrical tape Item 37, Appendix C

Personnel Required
 Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

2-34a Vehicle parked on level surface, engine off, and parking brake applied.
 Battery ground cable disconnected.
 Cab tilted 45 degrees.



STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Cab, under hood	Right panel harness connectors	Disconnect	Para 2-35c(3)
2	Instrument panel, underside	a. Two dash light electrical leads	Disconnect	Para 2-26d(2)

13-12. WIRING HARNESS MAINTENANCE (CONT)

c. Instrument Panel Harnesses (cont).

(3). Right Panel Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2 (cont)		b. Three low air switch electrical leads	Disconnect	Para 2-51c
		c. Two low air pressure buzzer electrical leads	Disconnect	Para 2-26c(2)
		d. White ground lead	Disconnect	Para 2-41g(2)
		e. Right panel harness	Remove	From tractor
INSTALLATION				
3	Instrument panel, underside	a. Right panel harness	Position	
		b. Two dash light electrical leads	Connect	Para 2-26d(2)
		c. Three low air switch electrical leads	Connect	Para 2-51c
		d. White ground lead	Connect	Para 2-41g(2)
		e. Two low air pressure buzzer electrical leads	Connect	Para 2-26c(2)
		f. Loose end of BRN/WHT electrical lead	Tape	Wrap end with electrical tape to prevent short circuit
4	Cab, under hood	Right panel harness connectors	Connect	Para 2-35c(3)
5	Cab tilt pump	Cab Lower	To normal operating position	
6	Battery box	Battery ground cable	Connect	Para 2-34a.

13-12. WIRING HARNESS MAINTENANCE (CONT)

d. Engine Harness. This task covers removal and installation.

INITIAL SETUP

Materials/Parts

Tags Item 14, Appendix C
 Tie straps FSCM 96906 PN MS3667-2-9

Personnel Required


Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

Vehicle parked on level surface, engine off, and parking brake applied.
 Cab tilted 45 degrees.

- 2-34a. Battery ground cable disconnected.
- 2-65d. Heat shield removed.



TA236381

13-12. WIRING HARNESS MAINTENANCE (CONT)

d. Engine Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Tractor	Engine harness connectors	Disconnect	Para 2-35d
2	Corner panel, underside	Ammeter red electrical lead and three 40A circuit breaker orange electrical leads	Disconnect	Para 2-26e
3	Right panel, underside	Low air switch red electrical lead	Disconnect	Para 2-51c
4	Left hand frame rail	a Service brakes stop light switch electrical leads	Disconnect	Para 2-32f(1)
		b Rear chassis harness	Tag and disconnect	Para 2-35b(2)
5	Right hand frame rail	a Two horn relay electrical leads	Disconnect	Para 2-33a
		b Nut, lock washer, and white ground lead	Remove	From frame rail stud; note location for installation
6	Engine	a Thermal switch electrical leads and harness plug	Disconnect	Pars 2-15e
		b Water temperature sender electrical lead	Disconnect	Green/black lead; pars 2-32c
		c Alarmstat electrical lead	Disconnect	Violet lead; para 2-32c
		d Oil pressure sender and sensor electrical leads	Disconnect	Pars 2-32a
		e Solenoid and 70A circuit breaker electrical leads	Disconnect 2-25a	Red and tan/green leads; pars

13-12. WIRING HARNESS MAINTENANCE (CONT)

d. Engine Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
6 (cont)		f Alternator electrical leads	Disconnect	Para 2-24
		g Tachometer sender electrical leads	Disconnect	White, gray, and gray/black leads; para 2-86
		h Water level sensor electrical leads	Disconnect	Para 2-29
		i Ether valve electrical leads	Disconnect	Para 2-13d
		j Engine stop solenoid electrical leads	Tag and disconnect	
		k Transmission temperature sender electrical leads	Disconnect	Para 2-32d
		l Capscrew, lock washer, and white ground lead	Remove	From left hand thermostat housing; note location for installation
7	Rear cab guard	Rear floodlight connector	Disconnect	Para 2-31g
8	Tractor	a Tie straps	Cut, remove, and discard	As necessary to remove engine harness
		b Engine harness	Remove	From tractor
INSTALLATION				
9	Tractor	a Engine harness	Position	As noted during removal
		b New tie straps	Install	If removed
10	Rear cab guard	Rear floodlight connector	Connect	Para 2-31g
11	Engine	a Thermal switch electrical leads and harness plug	Connect	Para 2-15e

13-12. WIRING HARNESS MAINTENANCE (CONT)

d. Engine Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
11 (cont)		b Water temperature sender electrical lead	Connect	Green/black lead; para 2-32c
		c Alarmstat electrical lead	Connect	Violet lead; para 2-32c
		d Oil pressure sender and sensor electrical leads	Connect	Para 2-32a
		e Solenoid and 70A circuit breaker electrical leads	Connect	Red and tan/green leads; para 2-25a
		f Alternator electrical leads	Connect	Para Z-24
		g Tachometer sender electrical leads	Connect	White, gray, and gray/black leads; para 2-86
		h Water level sensor electrical leads	Connect	Para 2-29
		i Ether valve electrical leads	Connect	Para 2-13d
		j Engine stop solenoid electrical leads	Connect	As tagged
		k Transmission temperature sender electrical leads	Connect	Para 2-32d
		l White ground lead, lock washer, and capscrew	Install and tighten	On left hand thermostat housing at location noted during removal
12	Right hand frame rail	a Two horn relay electrical leads	Connect	Para 2-33a

13-12. WIRING HARNESS MAINTENANCE (CONT)

d. Engine Harness (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
12 (cont)		b White ground lead, lock washer, and nut	Install and tighten removal	On frame rail stud at location noted during
13	Left hand frame rail	a Service brakes stop light switch electrical leads	Connect	Para 2-32f(1)
		b Rear chassis harness	Connect	Para 2-35b(2)
		c Heat shield	Install	Para 2-65d
14	Right panel, underside	Low air switch red electrical lead	Connect	Para 2-51c
15	Corner panel, underside	Ammeter red electrical lead and three 40A circuit breaker orange electrical leads	Connect	Para 2-26e
16	Tractor	Engine harness connectors	Connect	Para 2-35d
17	Cab tilt pump	Cab Lower	To normal operating position	
18	Battery box	Battery ground cable	Connect	Para 2-34a

Section III. POWER TRAIN MAINTENANCE


This section contains the information you need to maintain the:

- Transmission including Torque Converter * Front Axle
- Rear Axle

It gives you instructions on how to troubleshoot problems, and repair or replace the components that are within the scope of direct support maintenance.

	Para
Troubleshooting Symptom Index	3-13
Transmission Troubleshooting	3-14
Front Axle Troubleshooting	3-15
Rear Axle Troubleshooting.....	3-16
Transmission Maintenance	3-17
Testing.....	3-17a
Road Test	3-17a(1)
Hydraulic Pressure Test.....	3-17a(2)
Transmission Stall Test	3-17a(3)
Speed Shift Adjustments	3-17b
Replacement	3-17c
Summary Procedure Covering Replacement	3-17c(1)
Detailed Procedure Covering Replacement.....	3-17c(2)
Torque Converter	3-17d
Modulator Assembly	3-17e
Transmission Mount	3-17f
Front Axle Maintenance	3-18
Rear Axle Maintenance	3-19
Axle Assembly	3-19a
Differential	3-19b

3-13. TROUBLESHOOTING SYMPTOM INDEX



	Para/Malfunction	Page
TRANSMISSION		
Transmission fluid is milky	3-14/1	3-90
Transmission overheating	3-14/2	3-90
Low lubrication pressure	3-14/3	3-91
Low main pressure in all ranges.....	3-14/4	3-91
No response to shift lever movement.....	3-14/5	3-92
All automatic shifts occur at too high speed.....	3-14/6	3-92
Individual shift (2-3, 3-4, 4-5) occurs at too high speed.....	3-14/7	3-92
All automatic shifts occur at too low speed	3-14/8	3-93
Individual shift (2-3, 3-4, 4-5) occurs at too low speed.....	3-14/9	3-93
Slow or erratic shifting	3-14/10	3-93
Rough shifting	3-14/11	3-93
Clutch slippage in all forward gears	3-14/12	3-94

13-13. TROUBLESHOOTING SYMPTOM INDEX (CONT)

	Para/Malfunction	Page
TRANSMISSION (Cont)		
Excessive creep in first and reverse	3-14/13	3-94
Insufficient creep in first and reverse	3-14/14	3-94
Excessive vibration	3-14/15	3-94
High stall speed	3-14/16	3-94
Low stall speed	3-14/17	3-95
FRONT AXLE		
Rapid or uneven tire wear	3-15/1	3-95
Hard steering.....	3-15/2	3-95
Cross tube ends wear rapidly	3-15/3	3-96
Steering arm ball stud heavily worn	3-15/4	3-96
Knuckle pins and bushings worn excessively	3-15/5	3-96
Front axle shimmys or vibrates	3-15/6	3-96
REAR AXLE		
Lubricant leaking from differential carrier assembly	3-16/1	3-97

13-14. TRANSMISSION TROUBLESHOOTING I

**MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION**

1. TRANSMISSION FLUID IS MILKY

Inspect engine radiator and transmission oil cooler tank for evidence of damage or wear which allows coolant to contaminate transmission fluid.

- a. If such damage or wear is found, repair or replace radiator and transmission oil cooler tank (para 3-5a). If transmission fluid continues to appear milky, notify general support maintenance.
- b. If no such damage or wear is found, notify general support maintenance.

2. TRANSMISSION OVERHEATING

Check transmission oil cooler tank and engine radiator for clogged fins or obstructions, leakage, or damage.

- a. If oil cooler or radiator fins are clogged, clean; if fins are obstructed, remove obstructions. If transmission oil cooler tank or radiator is leaking or damaged, repair or replace (para 3-5a).
- b. If transmission oil cooler tank and radiator are not clogged, obstructed, leaking, or damaged, notify general support maintenance.

13-14. TRANSMISSION TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

3. LOW LUBRICATION PRESSURE

Step 1. Check fluid level on transmission dipstick with transmission at operating temperature and engine operating.

- a. If fluid level is below ADD mark, add fluid (para 2-41b) to FULL mark.
- b. If fluid level is not below ADD mark, proceed to step 2 below.

Step 2. Examine transmission cooler hoses for leakage or restriction.

- a. If cooler hoses are leaking or restricted, replace and, if necessary, reroute (para 2-41e).
- b. If cooler hoses are not leaking or restricted, proceed to step 3 below.

Step 3. Examine external oil filter for blockage.

- a. If external filter is restricted, replace (para 2-41e).
- b. If external filter is not restricted, notify general support maintenance.

4. LOW MAIN PRESSURE IN ALL RANGES (less than 125 psi with vehicle at 600 rpm idle, in forward drive range, brakes applied) (para 3-17a(2)).

Step 1. Check fluid level on transmission dipstick with transmission at operating temperature and engine operating.

- a. If fluid level is below ADD mark, add fluid (para 2-41b) to FULL mark.
- b. If fluid level is above ADD mark and at or below FULL mark, proceed to step 2 below.

Step 2. Drain fluid, remove transmission oil pan (para 2-41b), and remove oil filter (para 2-41c). Examine oil filter.

- a. If oil filter is clogged, replace (para 2-41c).
- b. If oil filter is not clogged, proceed to step 3 below.

3-14. TRANSMISSION TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

4. LOW MAIN PRESSURE IN ALL RANGES (Cont)

Step 3. Examine seal ring on oil filter tube.

- a. If seal ring is leaking or missing, replace (para 2-41c).
- b. If seal ring is not leaking or missing, notify general support maintenance.

5. NO RESPONSE TO SHIFT LEVER MOVEMENT

Perform main pressure check to see if pressure is low (less than 125 psi with vehicle at 600 rpm idle, in forward range, brakes applied) (para 3-17a(2)).

- a. If main pressure is low, refer to Malfunction 4 above.
- b. If main pressure is not low, notify general support maintenance.

6. ALL AUTOMATIC SHIFTS OCCUR AT TOO HIGH SPEED

Drain fluid and remove oil pan (para 2-41b). Check if shift valve adjusting rings are properly set.

- a. If shift valve adjusting rings are not properly set, adjust them higher the appropriate amount (para 3-17b). If more than one ring is moved in the same direction, move the adjusting ring on the modulator the same amount in the same direction.
- b. If shift valve adjusting rings are properly set, notify general support maintenance.

7. INDIVIDUAL SHIFT (2-3, 3-4, 4-5) OCCURS AT TOO HIGH SPEED

Drain fluid and remove oil pan (para 2-41b). Check if adjusting ring for malfunctioning shift is positioned correctly.

- a. If adjusting ring is not positioned correctly, reposition it to reduce shift point speed the appropriate amount (para 3-17b).
- b. If adjusting ring is positioned correctly, notify general support maintenance.

3-14. TRANSMISSION TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

8. ALL AUTOMATIC SHIFTS OCCUR AT TOO LOW SPEED

Drain fluid and remove oil pan (para 2-41b). Check if shift valve adjusting rings are properly set.

- a. If shift valve adjusting rings are not properly set, adjust them higher the appropriate amount (para 3-17b). If more than one ring is moved in the same direction, move the adjusting ring on the modulator the same amount in the same direction.
- b. If shift valve adjusting rings are properly set, notify general support maintenance.

9. INDIVIDUAL SHIFT (2-3, 3-4, 4-5) OCCURS AT TOO LOW SPEED

Drain fluid and remove oil pan (para 2-41b). Check if adjusting ring for malfunctioning shift is positioned correctly.

- a. If adjusting ring is not positioned correctly, reposition ring to increase shift point speed the appropriate amount (para 3-17b).
- b. If adjusting ring is positioned correctly, notify general support maintenance.

10. SLOW OR ERRATIC SHIFTING

Perform main pressure-check (para 3-17a(2)).

- a. If main pressure is low (less than 125 psi with vehicle at 600 rpm idle in forward drive range, brakes applied), refer to Malfunction 4 above.
- b. If main pressure is not low, notify general support maintenance.

11. ROUGH SHIFTING

Check position of spring adjusting ring on modulator valve assembly.

- a. If position of spring adjusting ring is not correct, adjust (para 3-17b).
- b. If position of spring adjusting ring is correct, notify general support maintenance.

3-14. TRANSMISSION TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

12. CLUTCH SLIPPAGE IN ALL FORWARD GEARS

Perform main pressure test (para 3-17a(2)).

- a. If main pressure is low (less than 125 psi with vehicle at 600 rpm idle, in forward range, brakes applied), refer to Malfunction 4 above.
- b. If main pressure is not low, notify general support maintenance.

13. EXCESSIVE CREEP IN FIRST AND REVERSE

Check idle throttle setting.

- a. If setting is too high, adjust idle throttle setting lower (refer to TM 9-2815-205-34 to tune engine).
- b. If setting is not too high, notify general support maintenance.

14. INSUFFICIENT CREEP IN FIRST AND REVERSE

Check idle setting.

- a. If setting is too low, adjust higher (refer to TM 9-2815-205-34 to tune engine).
- b. If setting is not too low, notify general support maintenance.

15. EXCESSIVE VIBRATION

Examine all mounting capscrews for looseness.

- a. If capscrews are loose, tighten (para 3-17c(2)).
- b. If capscrews are not loose, notify general support maintenance.

16. HIGH STALL SPEED (para 3-17a(3))

Check fluid level on transmission dipstick with transmission at operating temperature and engine operating.

- a. If fluid is below ADD mark, add fluid (para 2-41b) to FULL mark. -_-
- b. If fluid level is above ADD mark and at or below FULL mark, notify general support maintenance.

3-14. TRANSMISSION TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

17. LOW STALL SPEED (para 3-17a(3))

Examine engine for inadequate performance.

- a. If performance is poor, repair or replace parts causing problems (refer to TM 9-2815-205-34 for repair and replacement of engine components).
- b. If performance is adequate, notify general support maintenance.

3-15. FRONT AXLE TROUBLESHOOTING

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

1. RAPID OR UNEVEN TIRE WEAR

Check toe-in setting (para 3-28c).

- a. If toe-in not properly adjusted, adjust (para 3-28c).
- b. If toe-in properly adjusted, proceed to Malfunction 2 below.

2. HARD STEERING

Step 1. Check that knuckle pins are adequately lubricated.

- a. If knuckle pins are not adequately lubricated, lubricate (para 2-43a).
- b. If knuckle pins are adequately lubricated, proceed to step 2 below.

Step 2. Check steering knuckle end play (para 3-18).

- a. If end play is excessive, repair as necessary (para 3-18).
- b. If end play is within acceptable range, troubleshoot steering system (para 3-27).

3-15. FRONT AXLE TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

3. CROSS TUBE ENDS WEAR RAPIDLY

- Step 1. Check that tie rod ends are adequately lubricated.
- a. If not adequately lubricated, lubricate (para 3-28c).
 - b. If adequately lubricated, proceed to step 2 below.
- Step 2. Check if protective boots on tie rod ends are damaged.
- a. If damaged, replace tie rod ends (para 3-28c).
 - b. If not damaged, check front axle toe-in setting (para 3-28c).

4. STEERING ARM BALL STUD HEAVILY WORN

- Step 1. Check that front axle is adequately lubricated.
- a. If not adequately lubricated, replace steering arm ball (para 3-18) and lubricate axle (para 2-43a).
 - b. If adequately lubricated, proceed to step 2 below.
- Step 2. Check if steering link is over tightened.
- a. If over tightened, loosen (para 3-28e).
 - b. If not over tightened, check front axle for binding and repair or replace as necessary (para 3-18).

5. KNUCKLE PINS AND BUSHINGS WORN EXCESSIVELY

Check that scheduled lubrication of these parts is performed as specified in para 2-43a and that correct lubricant is used.

Lubricate at interval specified in current lubrication order; use correct lubricant.

6. FRONT AXLE SHIMMYS OR VIBRATES

Check steering knuckle end play (para 3-18).


- a. If end play is excessive, repair as necessary (para 3-18).J
- b. If end play is within acceptable range, replace damaged front wheels (para 2-57) or adjust or replace front axle hubs (para 2-43b).

3-16. REAR AXLE TROUBLESHOOTING

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

1. LUBRICANT LEAKING FROM DIFFERENTIAL CARRIER ASSEMBLY

- Step 1. Check axle breather for damage or clogged condition.
- If axle breather is damaged or clogged, clean or replace it.
 - If axle breather is not damaged or clogged, proceed to step 2 below.
- Step 2. Check if lubricant is leaking between axle housing and differential carrier assembly.



TA236374

- If lubricant is leaking between axle housing and differential carrier assembly, remove differential carrier assembly, clean mating surfaces, apply sealant, and reinstall (para 3-19b).
- If lubricant is not leaking between axle housing and differential carrier assembly, notify general support maintenance.

3-17. TRANSMISSION MAINTENANCE

a. Testing.

(1) Road Test.

This task covers road testing of the tractor to verify proper transmission operation.

INITIAL SETUP:

Materials/Parts

Note pad

Pen

Personnel Required

Wheel Vehicle Mechanic MOS 63B

Equipment Condition

Paragraph Condition Description

Parked on level surface; parking
brake applied; engine off.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING

1	Tractor cab	a. Engine b. Brakes c. Tractor	Start Release Operate	Operate the tractor in all positions of the gear shift lever to check for slipping and variations in shifting. Note whether the shifts are harsh or spongy. Record this information on your note pad. Observe closely for slipping or engine speed flareups. Record this information
---	----------------	--------------------------------------	-----------------------------	--

NOTE

Slipping or flareup in any gear range usually indicates clutch problems.

d. Gear shift lever	Position	Place gear shift lever in the drive (2-5) position so that all automatic upshifts can occur
------------------------	----------	---

13-17. TRANSMISSION MAINTENANCE (CONT)

- a. Testing (cont).
 - (1) Road Test (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING (cont)

CAUTION

The 1-2 upshift is a manual shift, and will not be tested. Do not operate tractor at full throttle when gear shift lever is in 1st gear (creeper) range.

e	Tractor		Drive	From a standing start, drive tractor at full throttle until the 4-5 shift occurs
f	Engine speed		Note	Note and record engine speed at which each upshift occurs
g	Tractor		Park	Park tractor in designated area
h	Engine		Turn off	
i	Brakes		Apply	
j	Engine speeds		Compare	Compare data recorded in step
f	to data in table below			

<u>Upshift</u>	<u>Engine Speed (rpm)</u>
2-3	2200
3-4	2600
4-5	2600

k	All information		Report	Report all data gathered during road test to the proper maintenance personnel
---	-----------------	--	--------	---

13-17. TRANSMISSION MAINTENANCE (CONT)

a. Testing (cont).

(2) Hydraulic Pressure Test.

This task covers hydraulic pressure testing of the transmission.

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit

Adjustable open end wrench

Fitting

Pressure gage, 190 psi capacity

Materials/Parts

Clean cloths Item 2, Appendix C

Note pad



Pen

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph	Condition Description
	Parked on level surface; engine off.
	Tractor frame securely fasten to an immovable object.
	All wheels chocked.
	Service brakes applied.
2-65c	Rear platform removed.



TA236383

KEY

1. Main pressure tap

2. Governor pressure tap

13-17. TRANSMISSION MAINTENANCE (CONT)

a. Testing (cont).

(2) Hydraulic Pressure Test (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TESTING				
<u>WARNING</u>				
Personal injury and property damage can result if vehicle is allowed to move during the hydraulic pressure test. Be sure tractor frame is secured to an immovable object, service brakes are applied, and all wheels are chocked before accelerating engine. Do not permit anyone to stand in front of tractor during hydraulic pressure test.				
1	Transmission, left side	a Main pressure tap (1) plug b Fitting c Pressure gage	Remove Install Install	
2	Tractor cab	Engine	Start	
3	Tractor cab	a Gear shift lever b Engine	Position Accelerate	Place gear shift lever in drive (2-5) position Accelerate engine to 600 rpm
4	Transmission, left side	Pressure gage	Observe	Gage should indicate 125 psi minimum. Record actual reading on note pad
5	Tractor cab	Engine	Accelerate	Accelerate engine to 1200 rpi
6	Transmission, left side	Pressure gage	Observe	Gage should indicate within 165-190 psi range Record actual reading on note pad
7	Tractor cab	a Engine b Gear shift c Engine	Decelerate Position Stop	Place gear shift lever in neutral (N) position
8	Transmission, left side	a Pressure gage and fitting b Main pressure tap (1) plug	Remove Install	

3-17. TRANSMISSION MAINTENANCE (CONT)

a. Testing (cont).

(2) Hydraulic Pressure Test (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TESTING (cont)				
8 (cont)		c Governor pressure tap (2) plug	Remove	
		d Fitting and pressure gage	Install	
9	Tractor cab	a Engine	Start	Place gear shift lever in Accelerate engine to 1500 rpm
		b Gear shift lever	Position drive (2-5) position	
		c Engine	Accelerate	
10	Transmission, left side	Pressure gage	Observe	Gage should indicate within 54-58 psi range Record actual reading on note pad
11	Tractor cab	a Engine	Decelerate	Place gear shift lever in neutral (N) position
		b Gear shift lever	Position	
		c Engine	Stop	
12	Transmission, left side	a Pressure gage and tee fitting	Remove	
		b Governor pressure tap (2) plug	Install	
13	Transmission, right side	Tee fitting and pressure gage	Install transmission	In oil cooler line at top of
14	Tractor cab	a Engine	Start	Place gear shift lever in neutral (N) position Accelerate engine to 2000 rpm
		b Gear shift lever	Position	
		c Engine	Accelerate	
15	Transmission, right side	Pressure gage	Observe	Gage should indicate within 23-30 psi range Record actual reading on note pad

13-17. TRANSMISSION MAINTENANCE (CONT)

- a. Testing (cont).
 - (2) Hydraulic Pressure Test (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TESTING (cont)				
16	Tractor cab	a Engine b Gear shift lever c Engine	Decelerate Position Shut down	Place gear shift lever in neutral (N) position
17	Transmission, right side	a Pressure gage and tee fitting b Oil cooler line	Remove Connect	
18	Tractor, rear	Rear platform	Install	Para 2-65c

13-17. TRANSMISSION MAINTENANCE (CONT)

a. Testing (cont).

(3) Transmission Stall Test.

This task covers stall testing of the tractor transmission.

INITIAL SETUP:

Materials/Parts

Note pad
Pen

Personnel Required

Wheel Vehicle Mechanic MOS 63B

References

TM 9-2815-205-34 (6V53T Diesel Engine Maintenance Manual)

Equipment Condition

Paragraph Condition Description

Parked on level surface; engine off.
Tractor frame securely fastened to an immovable object.
All wheels chocked.
Service brakes applied.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING

WARNING

Do not perform stall test while simply applying tractor service brakes; tractor will move at full throttle even with service brakes applied. Personal injury and property damage can result if vehicle is allowed to move during stall test. Be sure tractor frame is secured to an immovable object, service brakes are applied, and all wheels are chocked before accelerating engine. Do not permit anyone to stand in front of tractor during stall test.

1	Tractor cab	a. Engine	a Start	
---	-------------	-----------	---------	--

13-17. TRANSMISSION MAINTENANCE (CONT)

a. Testing (cont).

(3) Transmission Stall Test (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

TESTING (cont)

CAUTION

Do not perform stall test for more than 30 seconds, due to rapid heating of transmission fluid. Overheating of fluid can damage transmission. Keep a constant check on fluid temperature leaving the torque converter and do not allow it to exceed 300 degrees F. If this temperature is reached before ending the stall test, shift transmission into neutral and run engine at 1200/1500 rpm for two minutes to cool transmission fluid.

b. Tachometer	b. Accelerate Observe	Accelerate to full throttle Tachometer reading shall be 1821 + 25 rpm
---------------	--------------------------	---

NOTE

If maximum speed delivered is less than 1796 rpm, engine is not delivering full power, and should be tuned (see TM 9-2815-205-34).

If maximum speed delivered is more than 1846 rpm, refer to transmission troubleshooting.

c. Engine d. All information	Shut down Report	Report all data gathered during transmission stall test to proper maintenance personnel
---------------------------------	---------------------	--

3-17. TRANSMISSION MAINTENANCE (CONT)

- b. Speed Shift Adjustments.

This task covers speed shift adjustments of the transmission.

INITIAL SETUP:

Tools

Adjusting ring tool
FSCM 26095 PN J-24314

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

- 3-17a(1) Parked on level surface; parking brake applied; engine off. Transmission road test completed and shift points recorded.
- 2-41b Transmission fluid drained and oil pan removed.
- 2-65c Rear platform removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

ADJUSTMENTS

NOTE

Refer to data gathered in paragraph 3-17a(l) to determine requirements for speed shift adjustments.


Adjust the force on only the springs for valves that do not upshift at the proper engine speed.

Clockwise rotation of adjusting rings raises shift points; counterclockwise rotation lowers shift points. Each notch of adjustment changes shift point approximately 40 rpm.

1	Shift signal valve	Adjusting ring	Adjust	Use adjusting ring tool J-24314
---	--------------------	----------------	--------	---------------------------------

3-17. TRANSMISSION MAINTENANCE (CONT)

b. Speed Shift Adjustments (cont).



13-17. TRANSMISSION MAINTENANCE (CONT)

b. Speed Shift Adjustments (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

ADJUSTMENT (cont)**NOTE**

If more than one shift signal valve spring requires adjustment, it may be necessary to adjust the spring force on the modulator valve one position in the same direction as adjustment for signal valves. If all upshift points are either too high or too low, by approximately the same amount, adjust the modulator valve only.

2	Modulator valve	Adjusting ring	Adjust	Use adjusting ring tool J-24314
3	Transmission, underside	a Oil pan	Clean and install	Para 2-41b
		b Transmission fluid	Install	Para 2-41b
4	Tractor, rear	Rear platform	Install	Para 2-65c

13-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement.

(1) Summary Procedure Covering Replacement.

INITIAL SETUP:Tools

No. 1 Common Organizational Maintenance

Tool Kit

Adjustable open end wrench

Socket wrench set

Adjustable auto wrench

Retaining ring pliers

Puller kit

Socket head screw key set

Automotive Mechanic's Tool Kit

Hammer

Hammer

Pliers

Screwdriver

Screwdriver

Center punch

Drive pin punch

Grease gun

Torque wrench, 700 pounds foot capacity

Three-strand sling

Hoist, 1000 pounds capacity

Soft hammer

Clamping type filter wrench

Materials/Parts

Cleaning solvent

Item 1, Appendix C

Clean cloths

Item 2, Appendix C

Transmission fluid

Item 8, Appendix C

Personnel Required

Two Automotive Repairers MOS 63H

3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(1) Summary Procedure Covering Replacement (cont).

List of Tasks

Task No.	Task	Task Ref.	Troubleshooting Ref. No. (Para)
1.	Park tractor over maintenance bay	-	-
2.	Tilt cab 45 degrees	-	2-77
3.	Remove rear platform	2-65c	2-60
4.	Drain transmission fluid and remove dipstick	2-41b	2-37
5.	Remove drive shaft	2-42	2-38
6.	Remove transmission temperature sender	2-32e	2-37
7.	Remove hoses and fittings from transmission	2-41e	2-37
8.	Remove transmission oil sampling valve	2-41j	2-37
9.	Disconnect battery ground cable	2-34a	2-18
10.	Remove hydraulic pump (lines still connected)	3-42a	3-40
11.	Remove power take-off	3-42b	3-40
12.	Disconnect gear shift linkage and lever	2-41g(1)	2-37
13.	Remove shift lockout cylinder	2-41h(1), 2-41h(2)	2-37
14.	Disconnect modulator cable	2-41i	2-37
15.	Disconnect speedometer cable; remove adapter and gear assembly	2-85	2-81
16.	Remove rear cab guard	2-65d	2-60
17.	Remove water level sensor	2-29	2-19
18.	Remove transmission dipstick tube	2-41k	2-37
19.	Remove transmission mount	3-17f	3-14

3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement.

This task covers the detailed procedure for replacing the transmission.

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Combination wrench set
- Socket wrench set

Automotive Mechanic's Tool Kit

- Drive pin punch

Torque wrench, 700 pounds foot capacity

Three-strand sling

Hoist, 1000 pounds capacity

Materials/Parts

Transmission fluid Item 8, Appendix C

Converter retain-

ing strap FSCM 73342 PN 6837993

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description

Vehicle parked over maintenance bay, engine off, and parking brake applied.

Cab tilted 45 degrees.

Rear of engine supported (with jack from below or chain from above).

2-29 Water level sensor removed.

2-65c Rear platform removed.

Equipment Condition (cont)

Paragraph Condition Description

- 2-65d Rear cab guard removed.
- 2-41i Modulator cable disconnected from transmission.
- 2-42 Drive shaft removed.
- 3-42a Hydraulic pump removed (lines still connected).
- 2-85 Speedometer cable, adapter, and gear assembly removed from transmission.
- 2-32e Transmission temperature sender disconnected from transmission.
- 2-41b Transmission dipstick removed.
- 2-41j Transmission oil sampling valve removed.
- 2-41k Transmission dipstick tube removed.
- 2-34a Battery ground cable disconnected from transmission.
- 3-42b Power take-off removed.
- 2-41h(l) Shift lockout cylinder air lines disconnected.
- 2-41h(2) Shift lockout removed (transmission mount capscrews reinstalled).
- 2-41g(1) Gear shift linkage and lever removed.
- 2-41e External oil filter hoses and fittings removed from transmission.



3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

KEY

- 1. Capscrew
- 2. Lock washer
- 3. Hose clamp bracket
- 4. Capscrew
- 5. Lock washer
- 6. Bracket
- 7. Retainer nut
- 8. Output flange
- 9. Capscrews (4)



- 10. Lock washers (4)
- 11. Access plates (2)
- 12. Capscrews (6)
- 13. Capscrews (12)
- 14. Lock washers (12)
- 15. Transmission
- 16. Converter retaining strap
- 17. Capscrews (2)
- 18. Locknuts (2)

TA236370

13-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

NOTE

The transmission is normally removed by lowering from the tractor. If a suitable maintenance bay is not available, remove transmission from top of tractor or remove spare tire carrier, battery box, and other components as necessary to allow removal by lowering with a transmission jack.

1	Trans- mission, rear	a	Capscrew (1), lock washer (2), and hose clamp bracket (3)	Remove
		b	Capscrew (4), lock washer (5), and bracket (6)	Remove
		c	Retainer nut (7)	Remove and scribe

NOTE

Retainer nut (7) may be reused up to a maximum of five times. Each time retainer nut is removed, use scribe or punch to deeply scribe one of its flats as a record of its use. Discard a retainer nut that has been used a maximum of five times.

d.	Output flange (8)	Remove
----	----------------------	--------

3-17. TRANSMISSION MAINTENANCE (CONT)


c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

2	Trans- mission	a Three-strand sling and hoist	Attach	Attach to transmission as shown
---	-------------------	--------------------------------------	--------	------------------------------------



TA236371

		b Hoist	Operate	Operate hoist to take slack out of sling
3	Engine flywheel housing, bottom	a Four capscrews (9) and lock washers (10)	Remove	Support access plates (11)
		b Two access plates (11)	Remove	
		c Six capscrews (12)	Remove	Remove capscrews securing torque converter flex plate to engine flywheel

3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

4	Trans- mission, front	a. Transmission mount cross- member	Remove	Para 3-17f
		b. 12 capscrews (13) and lock washers (14)	Remove	

CAUTION

In step (5) below, route hoses away from transmission as necessary to prevent three-strand sling from damaging hoses as transmission is moved and lowered from tractor.

5	Trans- mission	a. Transmission (15)	Move	Use hoist to move transmis- sion rearward just far enough to allow clearance for converter retaining strap
---	-------------------	-------------------------	------	--

CAUTION

Install torque converter retaining strap immediately. Torque converter is now free to move and can fall from transmission housing.

		b. Converter retaining strap (16)	Position	Against torque converter
		c. Two capscrews (17) and locknuts (18)	Install	Secures converter retaining strap (16) to transmission housing
		d. Transmission (15)	Remove	From tractor. Use sling and hoist to lower transmis- sion; then disconnect hoist from sling
6	Rear axle ends	Brake air chamber springs	Cage	Para 2-51c(2)
7	Tractor tow	Tractor	Tow	From maintenance bay shackles

3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
8	Trans- mission	a. Hoist b. Transmission (15)	Reattach Remove	To sling Use sling and hoist to remove transmission from maintenance bay; then remove sling and hoist
INSTALLATION				
9	Trans- mission	a. Three-strand sling and hoist b. Transmission (15)	Attach Position	To transmission Use sling and hoist to lower transmission into maintenance bay; then remove hoist
10	Tractor tow shackles	Tractor	Tow	Tow tractor into maintenance bay and position over transmission
11	Rear axle ends	Brake air chamber springs	Uncage	Para 2-51c(2)
12	Trans- mission	a. Hoist	a. Attach b. Operate	To sling Operate hoist to take slack out of sling

CAUTION

When raising transmission into tractor, route hoses away from transmission as necessary to prevent three-strand sling from damaging hoses.

		b. Transmission (15)	Raise	Use sling and hoist to raise transmission into position
13	Trans- mission, front	a. Two locknuts (18), cap- screws (17), and converter retaining strap (16)	Remove	

3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
13 (cont)		b. 12 lock washers (14) and	Install	Secures transmission (15) to engine flywheel housing capscrews (13)
		c. Transmission mount	Install	Para 3-17f
14	Trans- mission	Sling and hoist	Detach and remove	
15	Engine flywheel(12) housing, bottom	a. Six capscrews	Install	Secures torque converter flex plate to engine flywheel
		b. Two access plates (11)	Position	
		c. Four lock washers (10) and capscrews (9)	Install	
16	Trans- mission, rear	a. Bracket (6)	Position	Tighten to 700 pounds foot torque
		b. Capscrew (4) and lock washer (5)	Install	
		c. Hose clamp bracket (3)	Position	
		d. Lock washer (2) and capscrew (1)	Install	
		e. Output flange (8)	Install	
		f. Retainer nut (7)	Install	
17	Trans- mission	a. External oil filter hoses and fittings	Install	Para 2-41e
		b. Gear shift linkage and lever	Install	Para 2-41g(1)
		c. Shift lockout cylinder	Install	Para 2-41h(2)

3-17. TRANSMISSION MAINTENANCE (CONT)

c. Replacement (cont).

(2) Detailed Procedure Covering Replacement (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
17 (cont)		d. Shift lockout air lines	Connect	Para 2-41h(l)
		e. Power take-off	Install	Para 3-42b
		f. Battery ground cable	Connect	Para 2-34a
		g. Oil sampling valve	Install	Para 2-41j
		h. Transmission dipstick tube	Install	Para 2-41k
		i. Transmission temperature sender	Install	Para 2-32e
		j. Speedometer gear assem- bly, adapter, and cable	Install	Para 2-85
		k. Hydraulic pump	Install	Para 3-42a
		l. Drive shaft	Install	Para 2-42
		m. Modulator cable	Install and adjust	Para 2-41i
		n. Water level sensor	Install	Para 2-29
	o. Transmission dipstick	a. Check fluid level b. Install	Para 2-41b	
18	Tractor chassis	a. Rear cab guard	Install	Para 2-65d
		b. Rear platform	Install	Para 2-65c
19	Cab tilt pump	Cab	Lower	To normal operating position

3-17. TRANSMISSION MAINTENANCE (CONT)

d. Torque Converter. This task covers removal and installation.

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

Socket wrench handle, 1/2 inch drive

Socket wrench set, 1/2 inch drive

Machinist's steel rule

Hoist

Torque converter lifter J-6795-01

Flat bar, 6 inches long

Materials/Parts

Clean cloths Item 2, Appendix C

Oil soluble grease Item 9, Appendix C

Two nuts FSCM 73342 PN 9416484

Personnel Required


Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
3-17c(2)	Transmission removed from vehicle. Transmission mounted front side up in stand.

KEY

1. Torque converter
2. Nuts (2)
3. Oil seal



TA236094

3-17. TRANSMISSION MAINTENANCE (CONT)

d. Torque Converter (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Torque converter (1)	a. Torque converter lifter b. Two nuts (2) c. Torque con-	Position Install Lift off using hoist attached to ring in converter (1)torque converter lifter. Lift straight up and remove to table	
		d. Two nuts (2) e. Torque converter lifter	Remove Remove	

INSTALLATION

NOTE

Before installing torque converter (1), be sure that oil seal (3) is lubricated with oil-soluble grease and is seated in its groove in oil pump hub.

2	Torque converter (1)	a. Torque converter lifter b. Two nuts (2)	Position Install	
3	Front of transmission	Torque converter (1)	Install using hoist attached to ring in torque converter lifter. Lower onto transmission while rotating to engage flats on torque converter hub with flats in transmission oil pump. Also, splines of turbine hub (inside torque converter) must engage splines of transmission turbine shaft. When seated, measure distance from transmission mounting flange to torque converter cover, as shown. If distance is greater than required 9/16 inch raise torque converter, rotate to align pump hub flats, and reseal. Then remove torque converter lifter	



3-17. TRANSMISSION MAINTENANCE (CONT)

e. Modulator Assembly. This task covers:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Torque wrench
- Socket head screw key set
- Safety glasses

Retaining ring pliers FSCM 79136 PN 2100

Materials/Parts

Cleaning solvent	Item 1, Appendix C
Clean cloths	Item 2, Appendix C
Transmission fluid	Item 8, Appendix C
Petrolatum	Item 9, Appendix C
Detergent	Item 27, Appendix C

Personnel Required


Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-41i	Modulator cable O-ring removed.

KEY

- 1. Retaining ring
- 2. Plunger
- 3. Capscrews (5)
- 4. Lock washers (5)
- 5. Cover
- 6. Gasket
- 7. Pin
- 8. Lever
- 9. Retainer
- 10. Spring
- 11. Thimble
- 12. Setscrew
- 13. Cable
- 14. O-ring
- 15. Housing



TA236240

3-17. TRANSMISSION MAINTENANCE (CONT)

e. Modulator Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
1	Modulator cable(1) assembly	a. Retaining ring	Remove	Use retaining ring pliers
		b. Plunger (2)	Remove	
		c. Five capscrews (3) and lock washers (4)	Remove	
		d. Cover (5)	Remove	
		e. Gasket (6)	Remove	
		f. Cable (13) core	Retract	Pull at free end of cable
		g. Pin (7)	Remove	Pull from lever (8) and bore in housing; note position of lever for reassembly
		h. Lever (8) and retainer (9)	a. Remove as assembly	Rotate lever and retainer outward about cable core through 90 degrees; then compress spring to cable end of housing to remove
		b. Separate		

NOTE

Keep cable (13) core retracted when performing the following step.

i. Spring (10) and thimble (11)	a. Remove as assembly	Compress thimble and spring away from cable (13) to remove
j. Setscrew (12)	b. Separate	Only if necessary to replace cable (13), O-ring (14), or housing (15)
k. Cable (13)	Remove	Twist housing (15) slightly and pull cable to remove
l. O-ring (14)	Remove	

CLEANING

2	a. Gasket (6) and O-ring (14)	Clean	Use clean, dry cloth only
	b. Cable (13)	Clean	Use clean cloth moistened with detergent; dry using clean cloths

3-17. TRANSMISSION MAINTENANCE (CONT)

e. Modulator Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
2 (cont)			<u>WARNING</u>	
			<p>Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.</p> <p>Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.</p>	
		c. All other parts	Clean	Use cleaning solvent P-D-680; dry using compressed air
INSPECTION				
3		a. Gasket (6) and O-ring (14) or deteriorated	Inspect	Replace if cut, cracked, or
		b. Spring (10)	Inspect	Replace if cracked, deformed, or permanently set
		c. Cable (13)	Inspect	Replace if kinked, binding, or otherwise damaged
		d. All other parts	Inspect	Replace if cracked, broken, or threads damaged
REASSEMBLY				
4	Modulator cable assembly	a. O-ring (14)	a. Position b. Lubricate	On cable (13) Apply thin film of petrolatum to outside of O-ring

3-17. TRANSMISSION MAINTENANCE (CONT)

e. Modulator Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
4 (cont)		b. Cable (13)	Install	Twist housing (15) slightly and push cable until large groove in cable hub aligns with setscrew (12) hole
		c. Setscrew (12)	Install	Tighten to 20-25 pounds inch
		d. Thimble (11)	Position	In spring (10)
		e. Cable (13) core	Retract	Pull at free end of cable
		f. Thimble (11) and spring (10)	Install	Compress thimble and spring, align thimble with cable core, and release spring
		g. Lever (8)	Position	In retainer
		h. Lever (8) and	Install	Rotate lever and retainer retainer (9) inward about cable core through 90 degrees
		i. Pin (7)	Install	Push into lever (8) and bore in housing (15)
		j. Gasket (6) and cover (5)	Position	On housing (15)
		k. Five capscrews (3) and locktorque washers (4)	Install	Tighten to 35-40 pounds inch

CAUTION

Tapered end of plunger (2) must be inserted first in following step.

l. Plunger (2)	Install	Push tapered end first into housing (15)
m. Retaining ring (1)	Install	Use retaining ring pliers

3-17. TRANSMISSION MAINTENANCE (CONT)

f. Transmission Mount.

This task covers: a. Removal c. Inspection/Repair
 b. Cleaning d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Scratch wire brush
- Adjustable open end wrench
- Combination wrench set
- Safety glasses

Hoist

Sling 2-65c

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Detergent Item 27, Appendix C

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description

Parked on level surface, engine off, and parking brake applied.

Rear platform removed.

2-29 Water level sensor and bracket removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REMOVAL

1 Trans-
mission
housing

Hoist and sling

Attach

To rear of transmission housing as shown. Apply sufficient lifting force to relieve stress on transmission housing and engine flywheel housing when transmission mount is removed






3-17. TRANSMISSION MAINTENANCE (CONT)

f. Transmission Mount (cont).

KEY

- 1. Capscrews (8)
- 2. Lock washers (8)
- 3. Locknuts (8)
- 4. Capscrews (8)
- 5. Washers (8)
- 6. Brackets (2)
- 7. Locknuts (2)
- 8. Snubbing washers (2)
- 9. Capscrews (2)
- 10. Crossmember
- 11. Locknuts (4)
- 12. Capscrews (4)
- 13. Rubber mounts (2)



TA236346

3-17. TRANSMISSION MAINTENANCE (CONT)

f. Transmission Mount (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2	Trans- mission mount	a. Eight capscrews (1) and lock washers (2)	Remove	Support shift lockout bracket and shift cable bracket
		b. Eight locknuts (3), capscrews (4), and washers (5)	Remove	
		c. Two brackets (6)	Remove	
		d. Two locknuts (7), snubbing washers (8), and capscrews (9)	Remove	

CAUTION

Transmission may have to be raised slightly to remove crossmember (10). Do not raise high enough to damage fan or fan shroud at front of engine.

e. Crossmember (10)	a. Tilt	Tilt crossmember diagonally and slide back over transmission
f. Four locknuts (11) and capscrews (12)	b. Remove Remove	
g. Two rubber	Remove	From tractor frame members mounts (13)

CLEANING

3	a. Two rubber mounts (13)	Clean	Use mild detergent solution. Rinse with clear water; dry thoroughly
---	---------------------------	-------	---

3-17. TRANSMISSION MAINTENANCE (CONT)

f. Transmission Mount (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

3
(cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

		b. All other parts	Clean	Use cleaning solvent P-D-680 and stiff bristled brush; dry thoroughly with compressed air
--	--	--------------------	-------	---

INSPECTION/REPAIR

4

a. Two brackets (6) and crossmember (10)	Inspect for broken welds cracks	Repair broken welds or cracks by welding. Replace a bracket or crossmember beyond economical repair distortion
b. Two rubber mounts (13)	Inspect for cracks breaks wear	Replace if necessary
c. All other parts	Inspect for cracks breaks distortion damaged threads	Replace if necessary

3-17. TRANSMISSION MAINTENANCE (CONT)

f. Transmission Mount (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
5	Trans- mission mount	a. Two rubber mounts (13)	Position	On tractor frame members
		b. Four capscrews (12) and locknuts (11)	Install	
		c. Crossmember (10)	a. Install b. Tilt	Tilt crossmember (10) diagonally and slide back over transmission and into position
		d. Two capscrews (9), snubbing washers (8), and locknuts (7)	Install	
		e. Two brackets (6)	Position	
		f. Eight washers (5), capscrews (4), and locknuts (3)	Install	
		g. Eight lock washers (2) and capscrews (1)	Install	In two brackets (6) and shift lockout bracket and shift cable bracket
		h. Hoist and sling	Remove	
6	Crossmember (10), left	Water level sensor and bracket side	Install	Para 2-29
7	Tractor, rear	Rear platform	Install	Para 2-65c
8	Tractor	Cab	Lower	To normal driving position

3-18. FRONT AXLE MAINTENANCE

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Open end wrench set
- Torque wrench
- Hammer
- Safety glasses
- Vise jaw caps
- Screwdriver
- Machinist's vise

Automotive Mechanic's Tool Kit

- Pry bar
- Hammer
- Pliers
- Machinist's rule

Brass drift

Jack

Two dollies

Arbor press

Dial indicator

Bushing removal and installation tool

Upper knuckle bushing reamer

Lower knuckle bushing reamer

Block of wood

Personnel Required

Two Automotive Repairers MOS 63H

References

LO 9-2320-285-12 (M878A1
Lubrication Order)

Equipment Condition

Paragraph	Condition Description
	Parked on level surface; parking brake applied; engine off. Rear wheels blocked. Front end supported, and hoist in place.
2-57	Front wheels and tires removed.
3-28e	Drag link disconnected.
2-43b	Hubs and drums removed.
2-51d(1)	Brake chambers removed.
2-50a	Front axle brakes and backing plates removed.
2-64	Shock absorbers removed.
3-28c	Tie rod removed.

Materials/Parts

Cleaning

solvent Item 1, Appendix C

Clean cloths Item 2, Appendix C

Light machine

oil Item 7, Appendix C

Tags Item 14, Appendix C

Cotter pins FSCM 78500 PN K2616


Cotter pins FSCM 78500 PN K2412

Four gaskets FSCM 78500 PN 2008Q823

Two oil seals FSCM 78500 PN A1205X1428

Two oil seals FSCM 78500 PN A1205B1432

3-18. FRONT AXLE MAINTENANCE



TA236093

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Tractor, front(4)	a. Axle center	Support	With jack under center of axle
		b. Eight jam nuts (1)	Remove	
		c. Eight nuts (2)	Remove	
		d. Eight cap-screws (3)	Remove	
		e. Axle center (4)	Lower	Onto two dollies. Remove jack
		f. Two spring spacers (5)	Remove	
		g. Two brackets (6)	Remove	
		h. Two upper spring pads (7)	Remove	
		i. Axle center (4)	Remove	Roll dollies out from under tractor; then mount axle center in suitable holding fixture
DISASSEMBLY				
2	Left steering knuckle (31)	a. Cotter pin (8) (8) and nut (9)	Remove; discard pin	
		b. Ball (10)	Remove	Use bronze drift and hammer; then tap out
		c. Cotter pin (11) and nut (12)	Remove; discard pin	

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when hammering.

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when hammering.


d.		Steering arm (13) with key (14)	Remove	Use bronze drift and hammer; then tap out
e.		Key (14)	Remove	
f.		Three cap-screws (15) and washers (16)	Remove	
g.		Cap (17) and gasket (18)	Remove	Discard gasket (18)
h.		Grease fitting (19)	Remove	Only if needed for replacement
i.		Three cap-screws (20) and washers (21)	Remove	
j.		Cap (22) and gasket (23)	Remove	Discard gasket (23)
k.		Grease fitting (24)	Remove	Only if needed for replacement
l.		Nut (25)	Loosen	Only if inspection indicates that screw (26) needs replacing
m.		Screw (26)	Remove	Only if needed for replacement
n.		Two nuts (27)	Remove	

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when hammering.

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		o. Two keys (28 and 29)	Remove	Use bronze drift and hammer; tap out from threaded end
		p. Knuckle pin (30)	Remove	Use bronze drift and hammer; drive out
3	Vise	q. Steering knuckle (31)	Remove	From axle center (4)
		a. Steering knuckle (31)	Position	Bottom side up in soft jawed vise with upper knuckle boss between vise jaws. Tighten vise
		b. Thrust bearing (32)	Remove	
		c. Oil seal (33)	Remove and discard	
		d. Shims (34)	Remove	Wire shims together to prevent loss. Tag shims, indicating from which steering knuckle they were removed
		e. Oil seal (35)	Remove and discard	Only if inspection indicates need for replacement. Pry out carefully with screwdriver
		f. Bushings (36 3-134 and 37)	Press out	Only if inspection indicates need for replacement. Use arbor press and bushing removal and installation tool



TA236094

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

NOTE

Repeat step 3 above for the right steering knuckle.

4	Axle center (4)	a. Two drive screws (38)	Remove	Only if axle center (4) or identification plate (39) is to be replaced
		b. Identification plate (39)	Remove	

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

5		a. Axle center (4) and steering knuckles (31)	Clean	Use clean cloths moistened with cleaning solvent P-D-680; dry with compressed air
---	--	---	-------	---

3-18. FRONT AXLE MAINTENANCE



STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
5 (cont)		b. Thrust bearings (32)	Clean	Use cleaning solvent P-D-680. Immerse bearings in cleaning solvent and move up and down. Remove bearing. Strike larger side of cone against block of wood to dislodge solidified particles of lubricant. Immerse again in cleaning solvent. Repeat process until bearings are clean. Dry using dry compressed air. Direct air stream across bearing. Do not spin bearings when drying. Rotate bearings slowly by hand to facilitate drying
		c. All other parts	Clean	Use cleaning solvent P-D-680. Immerse parts in cleaning solvent and move slowly up and down to dissolve all particles of lubricant. Dry parts with compressed air or clean cloths
INSPECTION				
6		a. Axle center (4)	Inspect	Replace if cracked, distorted or otherwise damaged
		b. Grease fittings (19 and 24)	Inspect	In caps (17 and 22). Clear bores with compressed air. Replace if cracked, broken, or bore clogged
		c. Thrust bearings (32)	Inspect	Inspect all rollers, cages and cups for wear, chips, nicks, damage and distortion. Replace bearing if any of these conditions are observed. After inspection, immerse in clean light oil and wrap in clean lintless cloth or paper

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
6 (cont)		d. Bushings (36 and 37)	Inspect	Inspect for flaking, cracking, or excessive wear. Replace if any of these conditions are observed
		e. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
REASSEMBLY				
7	Axle center (4)	a. Identification plate (39)	Position	On axle center (4), if removed
		b. Two drive screws (38)	Install	
8	Steering knuckle(36) (31)	a. New bushing	Install	If removed. Use arbor press and bushing removal and installation tool. Align oil holes in bushing with oil holes in steering knuckle. Press new bushing into knuckle about 1/8 inch; relieve press pressure. Press bushing in another 1/2 inch; relieve press pressure. Press bushing in until flush with surface of upper seal counterbore
		b. New bushing (37)	Install	If removed. Use arbor press and bushing removal and installation tool (refer to step 14a above). Press bushing in until flush with inside surface of lower knuckle boss

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
8 (cont)		c. New bushing (36)	Ream	Clamp steering knuckle (31), right side up, in soft jawed vise with lower knuckle boss between vise jaws. Use upper knuckle bushing reamer



TA236095

CAUTION

In following step, be sure you do not damage upper bushing (36) when inserting lower bushing reamer.


d. Lower knuckle bushing reamer	Insert	Turn reamer slightly in non-cutting direction while inserting. Don't turn more than one-quarter turn, or cutting edges of reamer may be damaged
---------------------------------	--------	---

3-18. FRONT AXLE MAINTENANCE


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

8 (cont)		e. New bushing (37)	Ream	Use lower knuckle bushing reamer
-------------	--	------------------------	------	-------------------------------------



NOTE 1. ALL DIMENSIONS SHOWN IN INCHES.




TA236096

f. Steering knuckle (31)	Position	Bottom side up in soft jawed vise with upper knuckle boss between vise jaws. Tighten vise
g. New oil seal (35)	a. Position	In steering knuckle counter- bore with rubber lip facing up


WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when hammering.

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
8 (cont)			b. Install	Place small block of wood over seal. Insert bronze drift through lower knuckle boss, and in contact with wood block. Use hammer, and tap bronze drift until seal bottoms. Check at intervals to be sure seal is being seated squarely
		h. Thrust bearing (32)	Position	In hand, with thrust bearing gasket facing down
		i. New oil seal (33)	Install	On thrust bearing (32). Snap seal over chamfered side
				
TA236278				
		j. Steering knuckle (31)	Remove	From vise
9	Axle center (4)	a. Steering knuckle (31)	Position	On left end of axle center (4). Be sure knuckle pin bore in end of axle center is clean and dry

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9 (cont)		b. Thrust bearing (32) and oil seal (33)	Install	Slide between lower face of axle center end and lower knuckle boss. Be sure to seat bottom side of thrust bearing (32) on face of lower knuckle yoke. Seal (33) must be centered below bottom face of axle center
				 <p style="text-align: right;">TA236279</p>
		c. Steering knuckle (31)	Raise	With jack. Take up all clearance between lower knuckle boss, thrust bearing (32), and lower face of axle center end. Be sure steering knuckle yoke holes are aligned with holes in axle center end and thrust bearing (32)

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when hammering.


3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9 (cont)		d. Knuckle pin (30)	Install	Align knuckle pin flat with holes for keys (28 and 29). Install pin with brass hammer through steering knuckle yoke, axle center, and thrust bearing. Install pin so that bottom pin surface is 0.1 to 0.2 inch above the bottom surface of steering knuckle (31)

NOTE

All torque limits specified in steps 16 thru 24 below apply to parts lightly coated with rust preventive oil. Increase torques 10 percent for dry parts. Decrease torques 10 percent for parts heavily coated with oil.

10	Steering knuckle (31)	a. Keys (2 and 28)	Install	Tighten to 38 pounds foot torque With C clamp or magnetic base as shown. Place dial indicator plunger on end of knuckle pin (30) so it is parallel with knuckle pin centerline. Then, zero dial indicator
		b. Two nuts (27)	Install	
		c. Dial indicator	Attach	



TA236097

CAUTION

Place a piece of cardboard or heavy tape between pry bar and axle center (4) to prevent grooving axle center.

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

10
(cont)

- d. Steering knuckle (31)
- e. Dial indicator

- a. Turn
- b. Lift
- Read

To extreme left turn position
With pry bar
Repeat readings with steering knuckle (31) in straight ahead and extreme right turn positions to get true clearance readings. Clearance shall be within 0.005 to 0.025 inch through full range of turn. Record readings



- f. Two nuts (27), keys (28 and 29), and knuckle pin (30)

Remove

See steps 2n thru 2p above

- g. Two shims (34)

Install

Install shims required as determined in step 10e
See step 9d above

- h. Knuckle pin (30)

Install

- i. Keys (28 and 29) and two nuts (27)

Install

See steps 10a and 10b above

11 Steering knuckle (31), bottom

- a. New gasket (18) and cap (17)
- b. Three washers (16) and cap-torque screws (15)

Position

Install

Tighten to 25 pounds foot

3-18. FRONT AXLE MAINTENANCE

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		c. New grease fitting (19)	Install	
12	Steering knuckle (31), top (21) and cap-screws (20)	a. New gasket (23) and cap (22) b. Three washers c. New grease fitting (24)	Position Install Install	Tighten to 25 pounds foot torque
13	Steering knuckle(19 and 24) (31), top and bottom	Grease fittings	Lubricate	Refer to current lubrication order
14	Steering knuckle (31), top	a. Key (14) b. Steering arm (13) c. Nut (12) d. New cotter	Install Install Install Install and pin (11)spread	In steering arm (13) In steering knuckle (31) Tighten initially to 650 pounds foot torque. Then tighten to 1025 pounds foot torque
15	Steering arm (13)	a. Ball (10) b. Nut (9) c. New cotter pin (8)	Install Install Install and spread	In steering arm (13) Tighten initially to 287 pounds foot torque. Then, tighten to 450 pounds foot torque
16	Steering knuckle (31)	Nut (25) and screw (26)	Install	If removed. Do not tighten at this time

NOTE

Steps 8 thru 16 above cover reassembly of the left steering knuckle. Repeat steps 8 thru 16 to reassemble the right steering knuckle.

3-18. FRONT AXLE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
17	Tractor, front	a. Axle center (4)	a. Position	Use suitable hoist. Position axle center on two dollies. Roll dollies into position under front of tractor
			b. Support	
		b Two upper spring pads (7)	Position	On top of spring
		c Two spring spacers (5) and brackets (6)	Position	On axle center (4)
		d Axle center (4)	Raise	Into position
		e Eight cap-screws (3)	Install	
		f Eight nuts (2) foot torque	Install	Tighten to 310-330 pounds
		g Eight jam nuts (1)	Install	Tighten to 75 pounds foot torque
h Jack	Remove			
18	Front axle	a Tie rod	Install	Para 3-28c
		b Brakes and backing plates	Install	Para 2-50a
		c Brake chambers	Install	Para 2-51c(l)
		d Hubs and drums	Install	Para 2-43b
		e Drag link	Install	Para 2-58e
		f Shock absorbers	Install	Para 2-64
		g Front wheels and tires	Mount	Para 2-57
		h Lubrication fittings	Lubricate	Para 2-43a
		i Front axle stops	Adjust	Loosen nut (25) on left side and adjust screw (26) to allow 3/4-inch clearance between tire and any part of frame and drag link. Then tighten nut (25) to 58 pounds foot torque and repeat for right side
		j Axle alignment	Check	Para 2-58d

3-19. REAR AXLE MAINTENANCE

a. Assembly. This task covers replacement of the rear axle assembly.

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

Adjustable open end wrench

Socket wrench set

Chain hoist

Two jack stands

Roller jack

supported by chain hoist.

Materials/Parts

Axle lubricant Item 6, Appendix C

Fifth wheel boom fully raised

Personnel Required

Two Wheel Vehicle Mechanics MOS 63B

Equipment Condition

Paragraph Condition Description

Vehicle parked on level surface, engine off, and parking brake applied. Front wheels blocked. Rear of tractor chassis

Two jack stands supporting rear of tractor chassis.

and blocked.

2-51c Rear axle brakes air chambers removed.


2-42 Drive shaft removed.

2-57 Rear wheels removed.

2-44a Axle lubricant drained.

KEY

- | | | |
|---------------------|----------------------|--------------------|
| 1. Nuts (4) | 6. Axle assembly | 11. Pads (2) |
| 2. Capscrews (4) | 7. Locating pads (2) | 12. Bushings (12) |
| 3. Torque links (4) | 8. Nuts (12) | 13. Capscrews (12) |
| 4. Capscrews (8) | 9. Washers (12) | 14. Washers (12) |
| 5. Clamp plates (2) | 10. Spacers (2) | |



TA236373

3-19. REAR AXLE MAINTENANCE (CONT)

- a. Axle Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL**WARNING**

Be sure front wheels are securely blocked so that tractor cannot roll off jack stands; be sure that chain hoist is bearing some of the weight of vehicle as a safety precaution in the event jack stands collapse. Failure to follow this procedure could result in serious injury or death due to tractor falling. If you are injured, obtain medical aid immediately.

1	Rear axle, right side	Two nuts (1), capscrews (2), and torque links (3)	Remove	
---	-----------------------	---	--------	--

NOTE

Repeat step 1 above on left side of rear axle.

2	Axle assembly (6)	Roller jack	Position	Position under axle assembly (6) to support assembly
3	Rear axle, right side	Four capscrews (4) and clamp plate (5)	Remove	

NOTE

Repeat step 3 above on left side of rear axle.

4	Axle assembly (6)	a Axle assembly (6)	Remove	Lower axle assembly (6) clear of chassis and roll out from under vehicle
		b Two locating pads (7)	Remove	From top of axle assembly (6)
5	Right hand frame rail	a Six nuts (8) and washers (9)	Remove	Support spacer (10)
		b Spacer (10)	Lower	

3-19. REAR AXLE MAINTENANCE (CONT)

a. Axle Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

5 (cont)		c. Spacer (10), pad (11), and six bushings (12)	Remove	
		d. Six capscrews (13) and washers (14)	Remove	

NOTE

Repeat step 5 above on left hand frame rail.

INSTALLATION

6	Frame rails	a. 12 capscrews (13) and washers (14)	Install	
		b. 12 bushings (12) and two pads (11)	Assemble	On spacer (10)
		c. Two spacers (10)	Position	On capscrews (8)
		d. 12 nuts (8) and washers (9)	Install and tighten	
7	Axle assembly (6)			

WARNING

Be sure vehicle is properly supported before proceeding. Failure to do so could cause serious injury or death due to vehicle falling on you. If you are injured, obtain medical aid immediately.

a. Two locating pads (7)	Position	On dowels on axle assembly (6) ends
b. Axle assembly (6)	a. Position	Use roller jack; position axle assembly against spacers (10)
	b. Raise	Raise axle assembly; check to see that holes in vehicle frame align with holes in spacers (10)

3-19. REAR AXLE MAINTENANCE (CONT)

a. Axle Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
7 (cont)		c. Two clamp plates (5)	Position	
		d. Eight capscrews (4)	Install and tighten	
		e. Four torque links (3)	Position	On clamp plates (5)
		f. Four capscrews (2) and nuts (1)	Install and tighten	Secures torque links (3) to frame rails
8	Tractor, rear	a. Drive shaft	Install	Para 2-42
		b. Rear axle brakes air chambers	Install	Para 2-51c
9	Rear axle	Axle lubricant	Install	Para 2-44a
10	Tractor, rear	a. Rear wheels	Install	Para 2-57
		b. Two jack stands	Remove	
		c. Fifth wheel boom	a. Remove blocks b. Lower	

3-19. REAR AXLE MAINTENANCE (CONT)

b. Differential. This task covers removal, cleaning, and installation.

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Scratch wire brush
- Socket wrench set
- Safety glasses
- Torque wrench, 175 pounds foot capacity

- Pry bar
- Soft hammer
- Roller jack

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Axle lubricant Item 6, Appendix C
- Silicone rubber sealant Item 40, Appendix C

Equipment Condition

Paragraph Condition Description


- Vehicle parked on level surface, engine off, parking brake applied, and front wheels blocked.
- Rear end supported.
- 2-44a Rear axle housing drained.
- 2-57 Rear wheels removed.
- 2-42 Propeller shaft removed.
- 3-42d Fifth wheel boom raised fully and supported with hoist.
- Hydraulic cylinders disconnected from bottom shaft. Bottom shaft and spacer tube removed.
- 2-44b Rear axle shafts pulled from differential.

Personnel Required

Two Automotive Repairers MOS 63H

KEY

- 1. Capscrews (12)
- 2. Lock washers (12)
- 3. Nuts (2)
- 4. Lock washers (2)
- 5. Differential



TA236366

3-19. REAR AXLE MAINTENANCE (CONT)

b. Differential (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Rear axle, center	a. Differential (5)	Support	With roller jack
		b. 12 capscrews (1) and lock washers (2)	Remove	
		c. Two nuts (3)	Loosen only	Do not remove, to prevent differential (5) from falling
(5)	differential away from axle housing	d. Differential	Loosen	Tap with soft hammer to break
		e. Two nuts (3) and lock washers (4)	Remove	
		f. Differential (5)	Remove	Use small pinch bar with rounded end to straighten assembly in housing bore. Be sure not to damage any mating surfaces. Lower jack to allow differential to be wheeled out from under tractor

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-19. REAR AXLE MAINTENANCE (CONT)

b. Differential (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
2		Differential (5) and axle housing mating surfaces	Clean	Use cleaning solvent P-D-680 and stiff bristled brush to remove sealant; dry using compressed air
INSTALLATION				
3	Axle housing	a. Silicone rubber sealant	Apply	To mating surfaces of axle using and differential)
		b. Differential (5)	Position	Place on roller jack. Posi- tion under front of rear xle, and raise. Position lange of differential 1/4 nch onto axle housing tuds
		c. Two lock washers (4) and nuts (3)	Install	Do not tighten
		d. Six lock wash- ers (2) and capscrews (1)	Install	Equally spaced around differ- ntial (5). Hand tighten nly
		e. Six lock wash- ers (2) and capscrews (1)	Install	In remaining holes
		f. 12 capscrews (1)	Tighten	Tighten alternately to 70 pounds foot torque
		g. Roller jack	Lower and Remove	
4	Rear axle	a. Rear axle shafts	Install	Para 2-44b
		b. Propeller shaft	Install	Para 2-42
		c. Rear axle	Lubricate	Para 2-44a
5	Tractor, bottom rear	Spacer tube, bottom shaft, and hydraulic cylinder rod caps	Install	Para 3-42d
6	Rear axle ends	Rear wheels	Install	Para 2-57

Section IV. BRAKE SYSTEM MAINTENANCE

This section contains the information you'll need to maintain the:

- Treadle Valve
- Hand Brake Controls
- Brake Controls
- Air Compressor

This section tells you how to troubleshoot problems, and repair or replace the components that are within the scope of direct support maintenance.

Troubleshooting Symptom Index.....	Para 3-20
Treadle Valve and Brake Controls Troubleshooting.....	3-21
Air Compressor Troubleshooting	3-22
Treadle Valve Maintenance.....	3-23
Brake Controls Maintenance.....	3-24
Air Control Valve.....	3-24a
Quick Release Valves	3-24b
Trailer Hand Brake Control Valve.....	3-24c
Double Check Valve.....	3-24d
Automatic Drain Valve.....	3-24e
Ratio Reducing Valve.....	3-24f
Relay Valve	3-24g
Tractor Protection Valves	3-24h
Air Compressor Assembly Maintenance	3-25
Air Compressor Governor	3-25a
Air Compressor Assembly.....	3-25b

3-20. TROUBLESHOOTING SYMPTOM INDEX

	Para/Malfunction	Page
TREADLE VALVE AND BRAKE CONTROLS		
Rapid pressure drop after engine is shut down (brakes released)	3-21/1	3-154
Rapid pressure drop after engine is shut down (brakes applied).....	3-21/2	3-154
Pressure builds up slowly.....	3-21/3	3-154
Pressure too high, or compressor won't cut out.....	3-21/4	3-155
Parking (spring) brakes won't release.....	3-21/5	3-155
Parking (spring) brake won't apply	3-21/6	3-157
Front and rear service brakes release slowly.....	3-21/7	3-158
Front service brakes release slowly	3-21/8	3-158
Rear service brakes release slowly.....	3-21/9	3-158
Trailer brakes do not release	3-21/10	3-159
Trailer service brakes do not function (cab guard).....	3-21/11	3-159
Trailer service brakes do not function (rear of tractor)	3-21/12	3-161
AIR COMPRESSOR		
Pressure too high, or air compressor won't cut out.....	3-22/1	3-161
Air compressor knocks.....	3-22/2	3-161

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

1. RAPID PRESSURE DROP AFTER ENGINE IS SHUT DOWN (BRAKES RELEASED)

- Step 1. Check automatic drain valve at air supply reservoir for air exhaust.
- If moderate to severe exhaust of air is observed, repair automatic drain valve (para 3-24e).
 - If constant slight exhaust of air is observed, proceed to step 2 below.
- Step 2. Check treadle valve (para 3-23), air compressor governor (para 2-52d), air reservoirs (para 2-51b), safety valve (para 2-51b), and one way check valve (para 2-51b) for air leaks.
- If a component is leaking air, repair or replace (para 3-23, 2-52d, or 2-51b).
 - If components are not leaking air, replace air compressor discharge valves (para 3-25b).

2. RAPID PRESSURE DROP AFTER ENGINE IS SHUT DOWN (BRAKES APPLIED)

Check shift lockout air cylinder, brake air chambers, treadle valves, quick release valves, relay valve, ratio reducing valve, and tractor protection valves for air leaks.

- If a component is leaking air, repair or replace (para 2-41h(1), 2-51d(1), 2-51d(2), 3-23, 3-24b, 3-24g, 3-24f, or 3-24h).
- If components are not leaking air, troubleshoot AIR PRESS gage (para 2-83).

3. PRESSURE BUILDS UP SLOWLY

Check air compressor governor adjustment (paragraph 2-52d).

- If governor doesn't cut out at 118-120 psi, or doesn't cut in at 100-102 psi, repair (para 3-25a).
- If governor cut out and cut in pressures are correct, refer to Malfunction 1 above. If the malfunction is not corrected in Malfunction 1, repair or replace air compressor (para 2-52e or 3-25b).

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)
--

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

4 PRESSURE TOO HIGH, OR COMPRESSOR WON'T CUT OUT

- | | | |
|--------|---|---|
| Step 1 | Remove air compressor governor (para 3-25a).
Check for obstruction in passage between air compressor and governor. | <ul style="list-style-type: none"> a If passage is clogged, clean. b If passage is not clogged, proceed to step 2 below. |
| Step 2 | Install replacement air compressor governor (para 3-25a).
Check air compressor governor adjustment (para 2-52d). | <ul style="list-style-type: none"> a If malfunction is corrected, repair or replace air compressor governor (para 2-52d). b If malfunction is not corrected, clean air compressor cylinder head (para 3-25b); repair or replace stuck inlet valves or leaking unloader grommets and back-up rings (para 3-25b), if necessary. |

5 PARKING (SPRING) BRAKES WON'T RELEASE

- | | | |
|--------|---|---|
| Step 1 | With AIR PRESS gage indicating 60 psi minimum and PARKING BRAKE valve pushed down fully, check emergency quick release valve, emergency port of rear axle brakes air chambers, and PARKING BRAKE valve for air leaks. | <ul style="list-style-type: none"> a If a component is leaking air, repair or replace (para 3-24b, 2-51d(2), or 3-24a). b If components are not leaking air, proceed to step 2 below. |
| Step 2 | Open drain cock on service air reservoir to relieve air system pressure.
Disconnect air brake tubing from elbow connector at emergency quick release valve (para 2-51a).
Install calibrated air pressure gage on tubing.
Close drain cock on service air reservoir.
Start engine and allow air system to charge to at least 60 psi pressure.
Push PARKING BRAKE valve in fully.
Watch AIR PRESS gage and test gage indications. | <ul style="list-style-type: none"> a If test gage indication differs from AIR PRESS gage indication by more than 10 psi, repair or replace PARKING BRAKE valve (para 3-24a). |

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

5 PARKING (SPRING) BRAKES WON'T RELEASE (Cont)

- b If test gage indication is within 10 psi of AIR PRESS gage indication, proceed to step 3 below.
- Step 3 Open drain cock on service air reservoir to relieve air system pressure.
Disconnect air brake tubing from elbow connector at emergency quick release valve (para 2-51a).
Install calibrated air pressure gage on tubing.
Close drain cock on service air reservoir.
Start engine and allow air system to charge to at least 60 psi pressure.
Pull PARKING BRAKE valve out fully.
Watch AIR PRESS gage and test gage indications.
- a If test pressure gage does not indicate zero psi immediately, repair or replace PARKING BRAKE valve (para 3-24a).
- b If test pressure gage immediately indicates zero psi, open service air reservoir drain cock to relieve air system pressure. Then proceed to step 4 below.
- Step 4 Disconnect hose from fitting at emergency port of one rear axle brake air chamber.
Install calibrated pressure gage on hose.
Close drain cock on service air reservoir.
Start engine and allow air system to build to at least 60 psi pressure.
Push PARKING BRAKE valve in fully.
Watch AIR PRESS gage and test gage indications.
- a If test gage indication differs from AIR PRESS gage indication by more than 10 psi, repair or replace emergency quick release valve (para 3-24b).
- b If test gage indication is within 10 psi of AIR PRESS gage indication, proceed to step 5 below.
- Step 5 Disconnect hose from fitting at emergency port of the other rear axle brake air chamber (see step 4 above).
Install calibrated pressure gage on hose.
Close drain cock on service air reservoir.
Start engine and allow air system to build to at least 60 psi pressure.
Push PARKING BRAKE valve in fully.
Watch AIR PRESS gage and test gage indications.

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)
--

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

5 PARKING (SPRING) BRAKES WON'T RELEASE (Cont)

- a If test gage indication differs from AIR PRESS gage indication by more than 10 psi, repair or replace emergency quick release valve (para 3-24b).
- b If test pressure gage indication is within 10 psi of AIR PRESS gage indication, troubleshoot rear axle brakes (para 2-46, Malfunction 12).

6 PARKING (SPRING) BRAKE WON'T APPLY

- Step 1 Pull up PARKING BRAKE valve fully.
Open drain cock on service air reservoir.
Loosen fitting at hose connecting emergency port of rear axle brake air chamber to emergency quick release valve.

WARNING

Wear safety glasses, and stand clear of loosened air hose fitting. High pressure can propel debris at high speed, causing eye injury or blindness.

- a If air discharges from loosened fitting, repair or replace emergency quick release valve (para 3-24b).
- b If air does not discharge from loosened fitting, proceed to step 2 below.

- Step 2 Close drain cock on service air reservoir.
Start engine and allow air system to build to at least 60 psi pressure.
Pull up PARKING BRAKE valve fully.
Loosen fitting at hose connecting emergency port of rear axle brake air chamber to emergency quick release valve.

WARNING

Wear safety glasses, and stand clear of loosened air hose fitting. High pressure can propel debris at high speed, causing eye injury or blindness.

- a If air discharges from loosened fitting, repair or replace PARKING BRAKE valve (para 3-24a).
- b If air does not discharge from loosened fitting, repair rear axle brake air chambers (para 2-51d(I) or 2-51d(2)).

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)
--

MALFUNCTION**TEST OR INSPECTION****CORRECTIVE ACTION****7 FRONT AND REAR SERVICE BRAKES RELEASE SLOWLY**

Check if all brakes release slowly.

- a If front and rear brakes release slowly, repair brake treadle valve (para 3-23).
- b If front brakes release slowly and rear brakes release normally, proceed to Malfunction 8, step 1 below.
- c If rear brakes release slowly and front brakes release normally, proceed to Malfunction 9, step 1 below.

8 FRONT SERVICE BRAKES RELEASE SLOWLY

Step 1 Disconnect supply and delivery air lines from ratio reducing valve (para 2-51a).
Connect supply air line to delivery air line.
Check release time of front service brakes.

- a If brakes release normally, repair or replace ratio reducing valve (para 3-24f).
- b If brakes do not release normally, proceed to step 2 below.

Step 2 Replace relay valve (para 3-24g).
Check release time of front service brakes.

- a If front service brakes on both sides release slowly, repair brake treadle (para 3-23).
- b If front service brakes on both sides release normally, no further action required.
- c If front service brake on one side releases normally, and front service brake on other side releases slowly, repair or replace front axle brake air chambers on affected side (para 2-51d(l)).

9 REAR SERVICE BRAKES RELEASE SLOWLY

Replace service quick release valve (para 3-24b).
Check release time of rear service brakes.

- a If rear service brakes on both sides release normally, no further action required.

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

9 REAR SERVICE BRAKES RELEASE SLOWLY (Cont)

- b If rear service brakes on both sides release slowly, repair brake treadle (para 3-23).
- c If rear service brake on one side releases normally, and rear service brake on other side releases slowly, repair or replace rear axle brake air chamber on affected side (para 2-51d(2)).

10 TRAILER BRAKES DO NOT RELEASE

Relieve air system of all pressure (para 2-41h(1)).
 Disconnect air line from emergency side of tractor protection valve (hose from air control valve to tractor protection valve).
 Install calibrated air pressure gage.
 Start engine and allow air system to build to 100 psi pressure.
 Depress tractor protection valve.
 Watch test gage.

- a If test gage indication is within 10 psi of AIR PRESS gage indication, repair or replace tractor protection valve (para 3-24h).
- b If test gage indicates zero psi or differs from AIR PRESS gage indication by more than 10 psi, repair or replace air control valve (para 3-24a).

11 TRAILER SERVICE BRAKES DO NOT FUNCTION (CAB GUARD)

- Step 1 Relieve air system of all pressure (para 2-41h(l)).
 Disconnect air hose connecting brake treadle valve to double check valve (located at bottom of tractor protection valve).
 Start tractor and allow air system to build to 100 psi pressure.
 Install calibrated air pressure gage on hose.
 Depress brake treadle valve fully.
 Watch test gage.
 Test gage shall indicate air system pressure (same as AIR PRESS gage indication).
- a If test gage indication differs by more than 10 psi from AIR PRESS gage indication, repair or replace brake treadle valve (para 3-23).
 - b If test gage indication is within 10 psi of AIR PRESS gage indication, proceed to step 2 below.

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

11. TRAILER SERVICE BRAKES DO NOT FUNCTION (CAB GUARD) (Cont)

- Step 2. Relieve air system of all pressure (para 2-41h(1)).
 Disconnect air hose connecting brake treadle valve to double check valve (located at bottom of tractor protection valve).
 Start tractor and allow air system to build to 100 psi pressure.
 Push down trailer hand brake control valve fully.
 Check for air exhaust at open port of double check valve.
- a. If air is exhausting from double check valve, replace (para 3-24d).
 - b. If air is not exhausting from double check valve, proceed to step 3 below.
- Step 3. Relieve air system of all pressure (para 2-41h(1)).
 Disconnect hose connecting trailer hand brake control valve to double check valve (located at bottom of tractor protection valve).
 Install calibrated air pressure gage on hose.
 Start the tractor and allow air system to build to 100 psi pressure.
 Push down trailer hand brake control valve fully.
 Watch test gage.
 Test gage shall indicate air system pressure (same as AIR PRESS gage indication).
- a. If test gage indication is within 10 psi of AIR PRESS gage indication, proceed to step 4 below.
 - b. If test gage indication differs from AIR PRESS gage indication by more than 10 psi, replace trailer hand brake control valve (para 3-24c).
- Step 4. Relieve air system of all pressure (para 2-41h(1)).
 Disconnect hose connecting trailer hand brake control valve to double check valve (located at bottom of tractor protection valve).
 Start the tractor and allow air system to build to 100 psi pressure.
 Depress brake treadle valve.
 Check for air exhaust at open port of double check valve.
- a. If air is exhausting from double check valve, replace (para 3-24d).
 - b. If air is not exhausting from double check valve, repair or replace tractor protection valve (para 3-24h).

3-21. TREADLE VALVE AND BRAKE CONTROLS TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

12. TRAILER SERVICE BRAKES DO NOT FUNCTION (REAR OF TRACTOR)

Relieve air system of all pressure (para 2-41h(1)).
 Disconnect air hose connecting brake treadle valve to double check valve (located at bottom of tractor protection valve).
 Start tractor and allow air system to build to 100 psi pressure.
 Install calibrated air pressure gage on hose.
 Depress brake treadle valve fully.
 Watch test gage.
 Test gage shall indicate air system pressure (same as AIR PRESS gage indication).

If test gage indication differs by more than 10 psi from AIR PRESS gage indication, repair or replace brake treadle valve (para 3-23).

3-22. AIR COMPRESSOR TROUBLESHOOTING

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

1. PRESSURE TOO HIGH, OR AIR COMPRESSOR WON'T CUT OUT

Install replacement air compressor governor (para 2-52d).
 Perform air compressor governor adjustment (para 2-52d).

- a. If malfunction is corrected, repair or replace air compressor governor (para 2-52d).
- b. If malfunction is not corrected, clean air compressor cylinder head (para 3-25b); replace stuck inlet valves or leaking unloader grommets and back-up rings (para 3-25b), if necessary.

2. AIR COMPRESSOR KNOCKS

Remove air compressor (para 2-52e).
 Check air compressor cylinder head for carbon deposits.
 Check air compressor for worn or damaged front bearing.

- a. If cylinder head contains carbon deposits, clean (para 3-25b).
- b. If front bearing is worn or damaged, replace (para 3-25b).

3-23. TREADLE VALVE MAINTENANCE

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Socket wrench set
- Torque wrench
- Safety glasses
- Retaining ring pliers

Automotive Mechanic's Tool Kit

- Punch
- Hammer
- Pliers

fittings removed from treadle

Materials/Parts

- Cleaning solvent
- Clean cloths
- Pneumatic grease
- Two cotter pins
- Cotter pin
- O-ring
- O-ring
- O-ring

- valve.
- Item 1, Appendix C
- Item 2, Appendix C
- Item 35, Appendix C
- FSCM 06853 PN 210067
- FSCM 06853 PN 210492
- FSCM 06853 PN 239643
- FSCM 06853 PN 239136
- FSCM 06853 PN 239645

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description

- Vehicle parked on level surface, engine off, and wheels blocked.
- 2-41h(1) All air pressure relieved. Shift lockout group lines and
- 2-51a Air brake lines and fittings removed from treadle valve.
- 2-53 Trailer brakes lines and fittings removed from treadle valve.
- 3-33b Unlatch valve lines and fittings removed from treadle valve.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

- | | | | | |
|---|-------------|---|--------|----------------------------|
| 1 | Cab, inside | a. Two capscrews (1), nuts (2) and lock washers (3) | Remove | |
| | | b. Brake treadle valve assembly | Remove | Lift from top of cab floor |


DISASSEMBLY

- | | | | | |
|---|----------------|---|--------|---------------------------|
| 2 | Cab, underside | a. Retaining ring (4) | Remove | Use retaining ring pliers |
| | | b. Valve insert assembly (items 26 thru 35) | Remove | |

3-23. TREADLE VALVE MAINTENANCE (CONT)

KEY

1. Capscrews (2)
2. Nuts (2)
3. Lock washers (2)
4. Retaining ring
5. Cotter pins (2)
6. Fulcrum pin
7. Treadle
8. Cotter pin
9. Roller pin
10. Roller
11. Boot
12. Plunger
13. Capscrews (3)
14. Lock washers (3)
15. Mounting plate
16. Valve body
17. Stop button
18. Retainer
19. Piston
20. Piston return spring
21. O-ring
22. Capscrew
23. Washer
24. Spring seat
25. Rubber spring
26. O-ring
27. Screw
28. Washer
29. Diaphragm
30. Preload spring
31. Valve
32. Spring
33. O-ring
34. Retainer
35. Seat



TA236276

3-23. TREADLE VALVE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3	Valve body (16)	a. Two cotter pins (5)	Remove and discard	
		b. Fulcrum pin (6)	Remove	Use punch and hammer
		c. Treadle (7)	Remove	
		d. Cotter pin (8)	Remove and discard	
		e. Roller pin (9)	Remove	Use punch and hammer
		f. Roller (10)	Remove	
		g. Boot (11) and plunger (12)	Remove	From treadle valve assembly
		h. Three capscrews (13) and lock washers (14)	Remove	
		i. Mounting plate (15) and valve body (16)	Separate	
		j. Stop button (17)	Remove	
4	Piston assembly	a. Retainer (18)	Remove	Depress piston assembly,
		b. Piston (19) and piston return spring (20)	Remove	
		c. O-ring (21)	Remove and discard	
		d. Capscrew (22)	Remove	
		e. Washer (23), spring seat (24), and rubber spring (25)	Remove	
5	Valve insert assembly (items 26 thru 35)	a. O-ring (26)	Remove and discard	
		b. Screw (27)	Remove	
		c. Washer (28) and diaphragm (29)	Remove	
		d. Preload spring (30)	Remove	Depress and hold valve (31), then remove preload spring
		e. Valve (31), spring (32), O-ring (33), and retainer (34)	Remove	From seat (35). Discard O-ring

3-23. TREADLE VALVE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Diesel fuel is highly combustible Do not smoke or allow open flames or sparks into the area. Death or severe injury may result if personnel fail to observe this precaution If you are burned, obtain medical aid immediately.

6	a	Boot (11), plunger (12), and rubber spring (25)	Clean	Wipe with clean cloth moistened with clean diesel fuel. Dry with clean cloths
---	---	--	-------	---

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

	b.	All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air
--	----	--------------------	-------	--

INSPECTION

7	a.	Boot (11), plunger (12), and rubber spring (25)	Inspect or deteriorated	Replace if cracked, broken,
---	----	--	----------------------------	-----------------------------

3-23. TREADLE VALVE MAINTENANCE (CONT)

**MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION**

INSPECTION (cont)

7 (cont)	b. Valve body (16)	Inspect	Replace entire brake treadle valve assembly if valve body (16) is cracked, broken, excessively worn, or bores or threads damaged
	c. Piston (19) and valve (31)	Inspect	Replace if cracked, broken, or scored
	d. Piston return spring (20), preload spring (30), and spring (32)	Inspect	Replace if cracked, broken, or permanently set
	e. Diaphragm (29)	Inspect	Replace if cracked, broken, inflexible, or deteriorated
	f. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

NOTE

Lightly coat piston (19), new O-rings (21, 26, and 33), and bores in valve body (16) with pneumatic grease before reassembly.

8	Valve body (16)	Piston (19), new O-rings (21, 26, and 33), and bores in valve body (16)	Lubricate	Use pneumatic grease
9	Valve insert assembly (items 26 thru 35)	a. Preload spring (30)	Position	In seat (35)
		b. Diaphragm (29)	Install	

NOTE

In following step, washer (28) must be installed with lips pointing out.

c. Washer (28)	Install	
d. Screw (27)	Install	Tighten securely

3-23. TREADLE VALVE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9 (cont)		e. New O-ring (33) and retainer (34)	Install	On valve (31)
		f. Spring (32)	Install	On seat (35)
		g. Valve (31)	Install	In seat (35). Press valve down until preload spring (32) snaps, and holds assembly together
		h. New O-ring (26)	Install	
10	Cab, underside	a. Valve insert assembly (items 26 thru 35)	Install	In valve body (16)
		b. Retaining ring (4)	Install down.	Press valve insert assembly. Use retaining ring pliers to install
NOTE				
Be sure retaining ring (4) snaps into ring groove in valve body (16) to lock valve insert assembly in place.				
11	Piston assembly	a. Rubber spring (25)	Install	In piston (19)
		b. Spring seat (24), washer (23), and capscrew (22)	Install	Tighten capscrew (22) to 50 pounds inch torque
		c. New O-ring (21)	Install	
		d. Piston return spring (20)	Install	On piston (19)
		e. Piston (19)	Install	In valve body (16)
		f. Retainer (18)	Install	Depress piston assembly, then install. Be sure retainer prongs snap over groove in valve body (16)
12	Valve body (16)	a. Stop button (17)	Install	
		b. Mounting plate (15)	Position	On valve body (16)
		c. Three lock washers (14) and capscrews (13)	Install and tighten	

3-23. TREADLE VALVE MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
12 (cont)		d. Plunger (12) and boot (11)	Install	On treadle valve assembly
		e. Roller (10)	Install	On roller pin (9)
		f. Roller pin (9)	Install	Use punch and hammer to
		install in treadle (7)		
		g. New cotter pin (8)	Install and spread	
		h. Treadle (7)	Position	On treadle valve assembly
	i. Fulcrum pin (6)	Install	Use punch and hammer	
	j. Two new cotter pins (5)	Install and spread		
INSTALLATION				
13	Cab, inside	Brake treadle valve assembly	Position	Through top of cab floor
14	Cab, underside	Brake lines and fittings	Connect and 3-33b	Para 2-41h(1), 2-51a, 2-53,
15	Cab, inside	Two capscrews (1), lock washers (3), and nuts (2)	Install and tighten	
16	Air pressure	Restore	Para 2-41h(l)	
17	Instrument panel	Air pressure gage	Observe	For two minutes. Depress brake treadle. If air pressure drops more than four psig per minute, brake treadle valve is defective, or there is leakage

NOTE

If pressure drops more than four psig per minute in step 17 above, test for leaks as follows.

18		All connections	Test for leaks	Apply soapy water solution to all connections. Depress brake treadle. If leak is found, tighten connection. Then repeat step 17 above. If no leak is found, treadle valve assembly is defective and must be replaced
----	--	-----------------	----------------	--

3-24. BRAKE CONTROLS MAINTENANCE

a. Air Control Valve.

This task covers: a. Removal d. Inspection
 b. Disassembly e. Reassembly
 c. Cleaning f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit
 Adjustable open end wrench
 Socket wrench set
 Torque wrench
 Screwdriver
 Screwdriver set
 Automotive Mechanic's Tool Kit
 Pliers

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description

Materials/Parts

Cleaning solvent Item 1, Appendix C
 Clean cloths Item 2, Appendix C
 Gasket FSCM 06853 PN 293426
 Spool assembly FSCM 06853 PN 101570
 Spool assembly FSCM 06853 PN 101569
 Maintenance kit FSCM 06853 PN 101557

Parked on level surface, engine off, and parking brake applied.
 2-41h(l) All air pressure relieved.
 2-51a Tractor brakes lines and fittings removed from air control valve.
 2-53a Trailer brakes lines and fittings removed from air control valve.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


1	Right hand instrument panel	a. Pin (1) b. Red button (2) c. Pin (3) d. Yellow button (4)	Press out Remove Press out Remove	
2	Cab, underside	a. Plug (5) b. Four locknuts (6) c. Valve assembly (7)	Remove Remove Remove	While assistant holds screws (8) from above From tractor
3	Cab, inside	Four screws (8)	Remove	

DISASSEMBLY

4	Air control valve	a. Four screws (9) b. Cover plate (10) c. Four screws (11)	Remove Remove Remove	
---	-------------------	--	----------------------------	--

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

a. Air Control Valve (cont).



TA236267

KEY

- | | | |
|-------------------|--------------------|------------------------|
| 1. Pin | 10. Cover plate | 19. O-ring |
| 2. Red button | 11. Screws (4) | 20. O-ring |
| 3. Pin | 12. Cover plate | 21. O-ring |
| 4. Yellow button | 13. Spool assembly | 22. Locknuts (4) |
| 5. Plug | 14. Spool assembly | 23. Washers (8) |
| 6. Locknuts s(4) | 15. Valve spool | 24. Identification tag |
| 7. Valve assembly | 16. Shuttle | 25. Screws (4) |
| 8. Screws (4) | 17. Return spring | 26. Gasket |
| 9. Screws (4) | 18. O-ring | |

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

4 (cont)	d.	Cover plate (12)	Remove	
	e.	Spool assembly (13)	Remove and	discard
	f.	Spool assembly (14)	Remove and	discard
	g.	Valve spool (15)	Remove	Use long nose pliers. Grasp spool webbing, twist, and pull free
	h.	Shuttle (16)	Remove	
	i.	Return spring (17)	Remove	

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

a. Air Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4 (cont)		j. Four O-rings (18, 19, 20, and 21)	Remove and discard	
		k. Four locknuts (22), eight washers (23), identification tag (24) and four screws (25)	Remove	
		l. Valve assembly (7)	Separate	Into two halves
		m. Gasket (26)	Remove and discard	

CLEANING

CAUTION

Do not immerse or clean the air control valve, or its parts, in any solvent-type cleaner.

5		a. Valve assembly (7)	Clean	Use clean, dry, lint-free cloth; wipe vigorously; be sure to clean valve bores
		b. Two cover plates (10 and 12), shuttle (16), and return spring (17)	Clean	Use clean, dry cloth
		c. Valve spool (15) and bore of valve spool (15)	Clean	Use clean, dry, lint-free cloth. Be sure to remove all old gasket material

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

- a. Air Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

- | | | | |
|--|--------------------|-------|--|
| | d. All other parts | Clean | Use cleaning solvent P-D-680; allow to air dry |
|--|--------------------|-------|--|

INSPECTION

- | | | | |
|---|---|--|----------------------|
| 6 | a. Valve assembly (7) | Inspect for cracks
deformation
scored bores | Replace if defective |
| | b. Two cover plates (10 and 12), valve spool (15), shuttle (16), and return spring (17) | Inspect for cracks
breaks
distortion
other damage | Replace if defective |
| | c. All other parts | Inspect for cracks
deformation
damaged threads | Replace if defective |

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

a. Air Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY

7	Air control valve	a. New gasket (26) assembly (7)	Position	Between halves of valve
		b. Halves of valve assembly (7)	Mate	
		c. Four screws (25), identification tag (24), eight washers (23), and four locknuts (22)	Install and tighten	
		d. Four new O-rings (18, 19, 20, and 21)	Install	On valve spool (15) and shuttle (16)
		e. Return spring (17) and shuttle (16)	Install	In bore of valve spool (14)
		f. Valve spool (15)	Install	Insert into valve bore until flush with top of housing
		g. New spool assembly (14)	Install	
		h. New spool assembly (13)	Install	

NOTE

Cover plates (10 and 12) are identical. Install cover plates with their convex sides up, and so that their stepped sides interlock.

i. Cover plate (12)	Position	
j. Four screws (11)	Install and tighten	Tighten to 25 pounds inch torque
k. Cover plate (10)	Position	
l. Four screws (9)	Install and tighten	Tighten to 25 pounds inch torque

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

a. Air Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
8	Cab, inside	Four screws (8)	Insert	Through instrument panel holes
9	Cab, underside	a. Valve assembly (7)	Position	On screws (8)
		b. Four locknuts (6)	Install and tighten	Tighten alternately to 25 pounds inch torque while assistant holds screws (8) from above
		c. Plug (5)	Install	Tighten to 10 pounds foot torque
NOTE				
Be sure you install yellow button (4) and red button (2) in their proper positions in following step.				
10	Right hand instrument panel	a. Yellow button (4)	Install	Rotate button until wording reads horizontally
		b. Pin (3)	Press in	
		c. Red button (2)	Install	Rotate button until wording reads horizontally
		d. Pin (1)	Press in	
11	Cab, underside	Air control valve fittings and lines	Connect	Para 2-51a and 2-53a
12	Tractor	Air pressure	Restore	Para 2-41h(l)

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

b. Quick Release Valves.

This task covers:

- | | | | |
|---|-------------|---|--------------|
| a | Removal | d | Inspection |
| b | Disassembly | e | Reassembly |
| c | Cleaning | f | Installation |

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Screwdriver
- Torque wrench
- Safety glasses

Materials/Parts

- | | |
|------------------|----------------------|
| Cleaning solvent | Item 1, Appendix C |
| Clean cloths | Item 2, Appendix C |
| Teflon tape | Item 43, Appendix C |
| Diaphragm | FSCM 06853 PN 245835 |
| O-ring | FSCM 06853 PN 242837 |



Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

2-41h(l)	Vehicle parked on level surface, engine off, and parking brake applied.
2-51a	All air pressure relieved. Air lines and fittings removed from quick release valves.



TA236269

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

b. Quick Release Valves (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Rear frame, above left brake air chamber	Quick release valve	Remove from	Turn counterclockwise fitting
2	Rear frame, above right brake air chamber	Quick release valve	Remove from	Turn counterclockwise fitting

DISASSEMBLY

3	Valve, quick release	a	Four screws (1)	Remove	
		b	Cover (2) and body (3)	Separate	
		c	Insert (4)	Remove	
		d	Diaphragm (5) and O-ring (6)	Remove and	discard

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

b. Quick Release Valves (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
4		All parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air
INSPECTION				
5	pitted	a Cover (2) and body (3)	Inspect	Replace if cracked, broken, or mating surface is
		b Insert (4)	Inspect	Replace if cracked or damaged
		c Screws (1)	Inspect	Replace if cracked, broken, or threads damaged
REASSEMBLY				
6	Valve, quick release	a New gasket (6) and new diaphragm (5)	Install	In body (3)
		b Insert (4)	Install	
		c Cover (2) and body (3)	Mate	
		d Four screws (1)	Install and	Tighten to 23 pounds foot torque
INSTALLATION				
NOTE				
Wrap Teflon tape around threads of all male fittings before installation to prevent leakage.				
7	Rear frame, above right tractor brake air chamber	Quick release valve	Install on	Turn clockwise; flat side fitting facing front of
8	Rear frame, above left tractor brake air chamber	Quick release valve	Install on	Turn clockwise; flat side fitting facing front of
9	Valves, quick release	Fittings and air lines	Install and	Para 2-51a tighten

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

c. Trailer Hand Brake Control Valve.

- This task covers:
- a Removal
 - b Disassembly
 - c Cleaning
 - d Inspection
 - e Reassembly
 - f Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Socket wrench set
- Screwdriver set
- Screwdriver
- Torque wrench
- Brush
- Safety glasses
- Automotive Mechanic's Tool Kit
- Hammer
- Punch
- Punch

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph	Condition Description
	Vehicle parked on level surface, engine off, and wheels blocked.
2-41h(1)	All air pressure relieved.
2-53a	Trailer hand brake control air lines and fittings removed.

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Lubricant Item 17, Appendix C
- Pin FSCM 06853 PN 241556
- Maintenance kit FSCM 06853 PN 276122

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

- | | | | | |
|---|-----------------------|---|-------------------------------------|---------|
| 1 | Steering wheel column | a | Valve assembly | Support |
| | | b | Two screws (1) and lock washers (2) | Remove |
| | | c | Clamp (3) | Remove |
| | | d | Body (4) | Remove |

DISASSEMBLY



- | | | | | |
|---|----------|---|------------------------|-----------------------|
| 2 | Head (7) | a | Pin (5) | Press-out and discard |
| | | b | Handle (6) | Remove |
| | | c | Head (7) | Remove |
| | | d | Two grommets (8 and 9) | Remove and discard |
| | | e | Knob (10) | Pull off Handle (6) |

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

c. Trailer Hand Brake Control Valve (cont).

KEY

1. Screws (2)
2. Lock washers (2)
3. Clamp
4. Body
5. Pin
6. Handle
7. Head
8. Grommet
9. Grommet
10. Knob
11. Lock washer
12. Screws (2)
13. Cover
14. Gasket
15. Spring
16. Cam
17. Cam follower
18. Adjusting ring
19. Piston
20. Return spring
21. Grommet
22. Screws (2)
23. Lock washers (2)
24. Inlet valve seat
25. Grommet
26. Exhaust valve
27. Valve guide
28. Spring
29. Inlet valve
30. Stem



TA236270

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

c. Trailer Hand Brake Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3	Cover	a Lock washer (13)	Remove	(11)
		b Two screws (12)	Remove	
		c Cover (13) and body (4)	Separate	
		d Gasket (14)	Remove and	discard
		e Spring (15)	Remove	
		f Cam (16)	Remove	
		g Cam follower (17)	Remove	
		h Adjusting ring (18)	Remove	
4	Body (4)	a Piston (19)	Remove	
		b Return spring (20)	Remove	
		c Grommet (21)	Remove and	discard
		d Two screws (22) and lock washers (23)	Remove	
		e Inlet valve seat (24)	Remove	
		f Grommet (25)	Remove and	discard
		g Punch	Insert	
		h Valve guide (27)	Depress	
		i Exhaust valve (26)	Remove	
		j Valve guide (27)	Remove	
		k Spring (28)	Remove	
		l Inlet valve (29)	Remove	
		m Stem (30)	Remove	

CLEANING

5	a	All rubber parts	Clean	Use clean, dry cloth
---	---	------------------	-------	----------------------

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

c. Trailer Hand Brake Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

5
(cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b.	All remaining parts	Clean	Use cleaning solvent P-D-680 and stiff bristle brush; dry thoroughly with compressed air
----	---------------------	-------	--

INSPECTION

6

a.	All rubber parts	Inspect	Replace if worn or deteriorated
b.	All other parts	Inspect	Replace if cracked, broken, or damaged

REASSEMBLY

7 Control

Bores of body (4), valve, hand brake	Lubricate cover (13), cam (16), cam follower (17), and new grommet (21)	Use lubricant
--------------------------------------	---	---------------

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

c. Trailer Hand Brake Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
8	Body (4)	a Stem (30)	Install	Lubricate with soap before installing in inlet valve (29)
		b Inlet valve (29)	Install	In inlet valve seat (24)
		c Punch	Insert	Into supply port, to hold inlet valve (29) against its seat
		d Spring (28) and valve guide (27)	a b	Position On inlet valve seat (24) Depress
		e Exhaust valve (26)	Install	On stem (30)
		f New grommet (25)	Position	On inlet valve seat (24)
		g Inlet valve seat (24)	Install	In body (4)
		h Two lock washers (23) and screws (22)	Install	Tighten screws (22) to 60-80 -- pounds inch
		i Return spring (20)	Install	In body (4)
		j New grommet (21)	Install	On piston (19)
		k Piston (19)	Install	
9 (13)	Cover	a Adjusting ring (18)	Install	Screw in, until flush with top of cover (13)
		b Cam follower (17)	Install	
		c Cam (16)	Install	
		d Spring (15) and new gasket (14)	Position	
		e Cover (13) and body (4)	Mate	
		f Two screws (12)	Install	Tighten to 75-95 pounds inch
		g Lock washer (11)	Position	

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

c. Trailer Hand Brake Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
10	Head (7)	a Knob (10) b New grommet (9) c New grommet (8) d Read (7) e Handle (6) f New pin (5)	Install Install Position Position Install Press in	Push onto handle (6) In head (7)
INSTALLATION				
11	Steering wheel column	a Body (4) b Clamp (3) c Two lock washers (2) and screws (1)	Position Position Install	Against steering wheel column Against body (4) Tighten screws (1) to 180-220 pounds inch
12	Cab, underside	a Fittings and lines b Air pressure c Fittings and lines	Connect Restore Inspect	Para 2-53a Para 2-41h(l) For leakage, with engine stopped and while
	operating control			trailer hand brake valve

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

d. Double Check Valve.

This task covers:

- a Removal
- b Disassembly
- c Cleaning
- d Inspection
- e Reassembly
- f Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Pipe wrench
- Safety glasses

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

Materials/Parts

Cleaning solvent

Clean cloths

Grease

Teflon tape

O-ring

- Item 1, Appendix C
- Item 2, Appendix C
- Item 35, Appendix C
- Item 43, Appendix C
- FSCM 06853 PN 239658

2-41h(l)
2-53a

Vehicle parked on level surface, engine off, and parking brake applied. All air pressure relieved. Air brake lines and fittings removed from double check valve.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


for	1 Rear cab guard	a	Double check valve	Remove	From tractor protection valve (note position of ports
		b	Nipple (1)	Remove	installation) From body (9) or tractor protection valve
		c	Plug (2)	Remove	From body (9)

DISASSEMBLY

2	Body (9)	a	Two capscrews (3) and washers (4)	Remove
		b	Cap (5)	Remove
		c	O-ring (6)	Remove
		d	Shuttle (7) and shuttle guide (8)	Remove


3-24. BRAKE CONTROLS MAINTENANCE (CONT)

d. Double Check Valve (cont).



KEY

- 1. Nipple
- 2. Plug
- 3. Capscrews (2)
- 4. Washers (2)
- 5. Cap
- 6. O-ring
- 7. Shuttle
- 8. Shuttle guide
- 9. Body



TA236241

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

d. Double Check Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3		All parts	Clean	Use cleaning solvent P-D-680; dry using compressed air
---	--	-----------	-------	--

INSPECTION

4	a	O-ring (6)	Inspect	Replace if cracked, cut, or deteriorated
	b	Shuttle (7), shuttle guide (8), and body (9)	Inspect	Replace valve as an assembly if parts gouged, pitted, or cracked
	c	All other parts	Inspect	Replace if cracked, broken, or threads damaged

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

d. Double Check Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
5	Body (9)	a Bore of body (9), shuttle guide (8), shuttle (7), and O-ring (6)	Lubricate	Apply light film of grease
		b Shuttle guide (8) and shuttle (7)	Position	In body (9)
		c O-ring (6)	Position	In groove of cap (5)
		d Cap (5)	Position	On body (9)
		e Two capscrews (3) and washers (4)	Install and tighten	
INSTALLATION				
6	Rear cab guard	a Plug (2)	a	Tape Wrap threads with Teflon tape
		b Install Nipple (1)	a	Tape Wrap threads with Teflon tape
		b Install Double check valve removal	In tractor protection valve Install	In nipple (1); tighten to position noted during
		d Fittings and air lines	Install and connect	To double check valve (para 2-53a)
7	Cab	Air pressure	Restore	Para 2-41h(l)
8	Rear cab guard treadle	Double check valve, lines, and fittings	Inspect	Check for leaks while assistant operates brake and trailer hand brake control valve

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

e. Automatic Drain Valve.

This task covers:

- a. Disassembly
- b. Cleaning
- c. Inspection
- d. Reassembly

INITIAL SETUP

Tools

No 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Socket head screw key set
- Scratch wire brush
- Torque wrench 2-51b
- Safety glasses

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description


Automatic drain valve removed from air reservoir.

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Teflon tape Item 43, Appendix C
- Maintenance kit FSCM 06853 PN 282134

KEY

- 1 Capscrews (4)
- 2 Lock washers (4)
- 3 Cover
- 4 Valve
- 5 Valve guide
- 6 Seal ring
- 7 Adapter
- 8 Pipe plug
- 9 Body



TA236233

TA236233

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

e. Automatic Drain Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
1	Body (9)	a Four screws (1) and lock washers (2)	Remove	Support cover (3)
		b Valve (4), valve guide (5), and seal ring (6)	Remove	Lift from cover (3); then discard
		c Adapter (7)	Remove	From body (9)
		d Pipe plug (8)	Remove	Only if necessary for replacement

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

2		All parts	Clean	Use cleaning solvent P-D-680 and stiff bristle brush; dry thoroughly with compressed air
---	--	-----------	-------	--

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

e. Automatic Drain Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION				
3		a Cover (3) and body (9)	Inspect	Replace if cracked, warped, or otherwise damaged
		b All other parts	Inspect	Replace if cracked, broken, or threads damaged

REASSEMBLY

NOTE

Wrap Teflon tape around threads of pipe plug (8) and adapter (7) before installation.

4	Body (9)	a Pipe plug (8)	Install and	If removed tighten
		b Adapter (7)	a b	Install Large end in body (9) Tighten To 130-170 pounds inch

NOTE

In the following steps, use new items 4 thru 6 included in automatic drain valve maintenance kit.

c	Seal ring (6)	Position	In cover (3) groove
d	Valve (4) and valve guide (5)	Position	Place valve (4) into valve guide (5) and position in cover (3)
e	Cover (3)	Position	On body (9) Be sure valve (4) does not move out
f	Four capscrews (1) and lock washers (2)	Install	place Tighten capscrews (1) to 80-120 pounds inch

of

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

f Ratio Reducing Valve.

This task covers:

- a Removal
- b Disassembly
- c Cleaning
- d Inspection
- e Reassembly
- f Installation

INITIAL SETUP

Tools

No 1 Common Organizational Maintenance

Tool Kit

- Socket wrench set
- Screwdriver set
- Screwdriver
- Scratch wire brush
- Safety glasses
- Automotive Mechanic's Tool Kit
- Pliers

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

Vehicle parked on level surface, engine off, and parking brake applied. Cab tilted 45 degrees. All air pressure relieved. Air brake lines and fittings removed from ratio reducing valve.

Materials/Parts

- Cleaning solvent
- Clean cloths
- Lubricant
- Maintenance kit
- 2-41h(1)
- 2-51a
- Item 1, Appendix C
- Item 2, Appendix C
- Item 17, Appendix C
- FSCM 06853 PN 289500

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

- | | | | | | |
|---|---------------------|---|---|--------|------------------------|
| 1 | Cab deck, underside | a | Two capscrews (1), nuts (2), and lock washers (3) | Remove | Support valve assembly |
| | | b | Valve assembly | Remove | From deck |

DISASSEMBLY



- | | | | | | |
|---|----------------------|---|--|--------|--|
| 2 | Ratio reducing valve | a | Four screws (4) | Remove | |
| | | b | Cover (5) | Remove | Lift from body (15) |
| | | c | Piston (6) and O-ring (7) | Remove | Discard O-ring (7) |
| | | d | Springs (8 and 9) | Remove | Discard springs (8 and 9) |
| | | e | Piston (10), valve (11), and O-rings (12 and 13) | Remove | Discard O-rings (12 and 13) and valve (11) |
| | | f | Spring (14) | Remove | From body (15) |

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

f. Ratio Reducing Valve (cont).

KEY

- 1. Capscrews (2)
- 2. Nuts (2)
- 3. Lock washers (2)
- 4. Screws (4)
- 5. Cover
- 6. Piston
- 7. O-ring
- 8. Spring
- 9. Spring
- 10. Piston
- 11. Valve
- 12. O-ring
- 13. O-ring
- 14. Spring
- 15. Body



TA236231

TA236231

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

f. Ratio Reducing Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3		All parts	Clean	Use cleaning solvent P-D-680 and stiff bristle brush; dry thoroughly with compressed air
---	--	-----------	-------	--

INSPECTION

4	a	Spring (14)	Inspect	Replace if cracked or permanently set
	b	All other parts	Inspect	Replace if cracked, broken, or threads damaged

REASSEMBLY

NOTE

Use new items 7, 8, 9, 11, 12, and 13 included in ratio reducing valve maintenance kit.

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

f. Ratio Reducing Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS	
REASSEMBLY (cont)					
5	Ratio reducing valve	a	Bores of body (15), cover (5), pistons (6 and 10), and O-rings (7, 12, and 13)	Lubricate	
		b	Spring (14)	Install	In body (15)
		c	Two O-rings (12 and 13)	Install	On piston (10)
		d	Valve (11)	Install	In piston (10)
		e	Piston (10)	Install	In body (15)
		f	Springs (8 and 9)	Install	
		g	O-ring (7)	Install	On piston (6)
		h	Piston (6)	Install	
		i	Cover (5)	Position	On body (15)
		j	Four screws (4)	Install and tighten	
INSTALLATION					
6	Cab deck, underside	a	Valve assembly	Position	On cab deck
		b	Two capscrews (1), lock washers (3), and nuts (2)	Install and tighten	
		c	Air brake lines and fittings	Connect	Para 2-51a
7 position	Cab tilt pump	Cab		Lower To normal operating	
8	Cab	Air pressure	Restore	Para 2-41h(1)	
9	Deck, underside	Ratio reducing valve, lines, and fittings	Inspect	Check for leaks	

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

g Relay Valve.

This task covers:

- a Removal
- b Disassembly
- c Cleaning
- d Inspection
- e Reassembly
- f Installation

INITIAL SETUP

Tools

No 1 Common Organizational Maintenance
Tool Kit

Socket wrench set
Screwdriver set Paragraph
Screwdriver
Scratch wire brush Vehicle parked on level
Retaining ring pliers surface, engine off, and
Safety glasses parking brake applied.
Automotive Mechanic's Tool Kit 2-41h(1)
Pliers 2-51a
Torque wrench removed from relay valve.

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Condition Description

All air pressure relieved.
Air brake lines and fittings

Materials/Parts

Cleaning solvent Item 1, Appendix C
Clean cloths Item 2, Appendix C
Pneumatic grease Item 35, Appendix C
Teflon tape Item 43, Appendix C
Maintenance kit FSCM 06853 PN 287370

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Front frame crossmember, center	a	Two capscrews (1), nuts (2), and lock washers (3)	Remove	Support relay valve assembly
		b	Relay valve	Remove assembly	From crossmember

DISASSEMBLY



2	Relay valve	a	Screw (4)	Remove	
		b	Exhaust cover (5)	Remove	
		c	Adapter (6)	Remove	From cover (11)
		d	O-ring (7) and diaphragm (8)	Remove and	discard

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

g. Relay Valve (cont).

KEY

- 1. Capscrews (2)
- 2. Nuts (2)
- 3. Lock washers (2)
- 4. Screw
- 5. Exhaust cover
- 6. Adapter
- 7. O-ring
- 8. Diaphragm
- 9. Capscrews (2)
- 10. Capscrews (2)
- 11. Cover
- 12. O-ring
- 13. Piston
- 14. Seat



- 15. Sealing ring
- 16. Screw
- 17. Washer
- 18. Diaphragm
- 19. Screws (4)
- 20. Cover
- 21. Retaining ring
- 22. O-ring
- 23. Washer
- 24. Retainer
- 25. Spring
- 26. Valve
- 27. Retainer
- 28. Body

TA236232

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

g. Relay Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

2
(cont)

NOTE

Scribe or otherwise match mark cover (11) and body (28) to aid in reassembly.

e		Capscrews (9 and 10)	Remove	
f		Cover (11) body (28)	Remove	Tap gently and separate from
g		O-ring (12)	Remove and discard	
h		Piston (13)	Remove	
i		Seat (14)	Remove	
j		Sealing ring (15)	Remove and	discard
k		Screw (16) and washer (17)	Remove	
l		Diaphragm (18)	Remove and	discard
m		Four screws (19)	Remove	Support cover (20)
n		Cover (20)	Remove	

NOTE

Discard items 21 thru 27 in the following steps. New items 21 thru 27 are included in the relay valve maintenance kit.

o		Retaining ring (21)	Remove	Use retaining ring pliers
p		O-ring (22)	Remove	
q		Washer (23)	Remove	
r		Retainer (24)	Remove	
s		Spring (25)	Remove	
t		Valve (26)	Remove	
u		Retainer (27)	Remove	

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

g. Relay Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3		All parts	Clean	Use cleaning solvent P-D-680 and stiff bristle brush; dry thoroughly with compressed air
---	--	-----------	-------	--

INSPECTION

4	a	Cover (11) and body (28)	Inspect	Replace if cracked, warped, or damaged
	b	All other parts	Inspect	Replace if cracked, broken, or threads damaged

REASSEMBLY

NOTE

Use new items 7, 8, 12, 15 and 18, and new valve assembly (21 thru 27) included in relay valve maintenance kit.

3-24. BRAKE CONTROLS MAINTENANCE (CONT)
--

g. Relay Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
5	Relay valve	a Bores of body (28), cover (11), piston (13), O-rings (7, 12 and 22) and sealing ring (15)	Lubricate	Use pneumatic grease
		b Spring (25)	Position	On valve (26)
		c Retainer (24)	Install	
		d Washer (23)	Install	
		e O-ring (22)	Install	
		f Retaining ring (21)	Install	Use retaining ring pliers
		g Valve (26) and retainer (27)	Position	In body (28)
		h Cover (20)	Position	
		i Four screws (19)	Install and tighten	
		j Diaphragm (18) (20)	Position	Between guide ribs in cover
		k Washer (17) and screw (16)	Install and tighten	
		l Sealing ring (15)	Position	
		m O-ring (12)	Install	On piston (13)
		n Seat (14) and piston (13)	Install	
		o Cover (11)	Position	On body (28), with match marks aligned
		p Capscrews (9 and 10)	Install	Tighten to 120-150 pounds inch
		q Diaphragm (8) and O-ring (7)	Position	In cover (11)

NOTE

Wrap Teflon tape around threads of adapter (6) before installation.

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

g. Relay Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
5 (cont)		r Adapter (6)	Install	Tighten to 180-200 pounds inch
		s Exhaust cover (5)	Position	On cover (11)
		t Screw (4)	Install and	tighten
INSTALLATION				
6	Front frame crossmember, center	a Relay valve assembly	Position	
		b Two capscrews (1), nuts (2), and lock washers (3)	Install and tighten	
		c Air brake lines and fittings	Connect	Para 2-51a
7	Cab	Air pressure	Restore	Para 2-41h(1)
8	Front frame crossmember	Relay valve, lines and fittings	Inspect	Check for leaks

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

h. Tractor Protection Valves.

This task covers:

- a Removal
- b Disassembly
- c Cleaning
- d Inspection
- e Reassembly
- f Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Socket wrench set
- Screwdriver set
- Screwdriver
- Scratch wire brush
- Retaining ring pliers
- Safety glasses
- Automotive Mechanic's Tool Kit
- Pliers

Materials/Parts

- Cleaning solvent
- Clean cloths
- Lubricant
- Maintenance kit
- Item 1, Appendix C
- Item 2, Appendix C
- Item 17, Appendix C
- FSCM 06853 PN 280858

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
	Vehicle parked on level surface, engine off, and parking brake applied.
2-41h(1)	All air pressure relieved.
2-51a	Tractor brake tubing and fittings removed from tractor protection valves.
2-53a	Trailer brake tubing and fittings removed from tractor protection valves.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (CAB GUARD)




1	Rear cab guard	a	Double check valve	Remove	Para 3-24d
		b	Two nuts (1), lock washers (2), and capscrews (3)	Remove valve	Support tractor protection
		c	Tractor protection valve	Remove	From rear cab guard

REMOVAL (REAR FRAME)

2	Rear frame	a	Two nuts (1), lock washers (2), and capscrews (3)	Remove	Support tractor protection valve; note location of white ground wire for installation
		b	Tractor protection valve	Remove	From rear frame


3-24. BRAKE CONTROLS MAINTENANCE (CONT)

h. Tractor Protection Valves (cont).



KEY

- 1. Nuts (2)
- 2. Lock washers (2)
- 3. Capscrews (2)
- 4. Retaining ring
- 5. Seat
- 6. Screw
- 7. Washer
- 8. Diaphragm
- 9. O-ring
- 10. Spring
- 11. Plunger
- 12. O-ring
- 13. O-ring
- 14. Retaining ring
- 15. Retainer
- 16. Valve
- 17. Body



TA236135

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

h. Tractor Protection Valves (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS	
DISASSEMBLY					
3	Tractor protection valve plunger	a	Retaining ring (4)	Remove	Use retaining ring pliers
		b	Insert assembly (5 thru 16)	a b	Remove From body (17) Position On smooth surface; (11) down
		c	Screw (6), washer (7), and diaphragm (8)	Remove	While holding seat (5) down against spring (10) pressure Discard
		d	O-ring (9)	Remove and	discard
		e	Spring (10)	Remove	
		f	Plunger (11)	Remove	
		g	O-rings (12 and 13)	Remove and	discard
		h	Retaining ring (14)	Remove	Use retaining ring pliers
		i	Retainer (15) and valve (16)	Remove	From plunger (11)

CLEANING**WARNING**

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-24. BRAKE CONTROLS MAINTENANCE (CONT)

h. Tractor Protection Valves (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
4		All parts	Clean	Use cleaning solvent P-D-680 and stiff bristle brush; dry with compressed air

INSPECTION

5		a Body (17)	Inspect	Replace if cracked or damaged
		b Seat (5) and plunger (11)	Inspect	Replace if cracked, scored, or damaged
		c Spring (10)	Inspect	Replace if cracked or permanently set
		d All other parts	Inspect	Replace if cracked, broken, or threads damaged

REASSEMBLY**NOTE**

Use new items 4, 8, 9, 10, and 12 thru 15 included in tractor protection valve maintenance kit.

6	Tractor protection valve	a Bores of body (17), plunger (11), seat (10), and O-rings (9, 12, and 13)	Lubricate	
		b Valve (16), retainer (15) and O-rings (12 and 13)	Install	On plunger (11)
		c Retaining ring (14)	Install	Use retaining ring pliers
		d Plunger (11)	Install	In body (17)
		e Diaphragm (8), washer (7), and screw (6)	Install	On seat (5)
		f Spring (10)	Install	
		g O-ring (9)	Install	
		h Seat assembly (5 thru 8)	Install	In body (17)
		i Retaining ring (4)	Install	Use retaining ring pliers

3-24. BRAKE CONTROLS MAINTENANCE (CONT)**h. Tractor Protection Valves (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (REAR FRAME)				
7	Rear frame	a. Tractor protection valve and white ground wire	Position	As noted during removal
		b. Two capscrews (3), lock washers (2), and nuts (1)	Install and tighten	
		c. Fittings and tubing	Install and connect	Para 2-51a and 2-53a
INSTALLATION (REAR CAB GUARD)				
8	Rear cab guard	a. Tractor protection valve	Position	
		b. Two capscrews (3), lock washers (2), and nuts (1)	Install and	
		c. Double check valve	Install	Para 3-24d
		d. Fittings and tubing	Install and connect	Para 2-51a and 2-53a

NOTE

Restore air pressure (para 2-41h(l)) and check for leaks using soap solution before returning tractor to operation.

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

a. Air Compressor Governor.

This task covers: a. Disassembly
b. Cleaning

c. Inspection
d. Reassembly

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Wire brush
- Retaining ring pliers
- Socket wrench set
- Screwdriver set
- Safety glasses

Personnel Required

Automotive Repairer MOS 63H


Equipment Condition

Paragraph Condition Description

2-52d Governor removed from air compressor.

Materials/Parts

Cleaning solvent	Item 1, Appendix C
Clean cloths	Item 2, Appendix C
Lubricant	Item 17, Appendix C
Detergent	Item 27, Appendix C



3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE**a. Air Compressor Governor (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
1	Compressor governor	a. Rubber cover (1)	Remove	Turn counterclockwise
		b. Snap ring (2)	Remove	Use retaining ring pliers
		c. Adjustment assembly (3 thru 8)	Remove	Pull from bore as an assembly
2	Adjustment assembly (3 thru 8) seat (4)	a. Nut (3)	Remove	From adjusting screw (8)
		b. Upper spring	Remove	Turn counterclockwise
		c. Spring (5)	Remove	
		d. Two lower spring seats (6) and guide (7)	Remove and separate	From adjusting screw (8)
3	Body (19)	a. Exhaust stem (9) and spring (10)	Remove	
		Piston (11)	Remove	
4	Piston (11) packings (12)	a. Two preformed piston (11)	Remove	From grooves in outside of
		b. Washer (13) and grommet (14)	Remove	
		c. Spring (15) and valve (16)	Remove	
5	Body (19)	a. Four pipe plugs (17)	Remove	
		b. Two filters (18)	Remove	From body (19)

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE (CONT)

a. Air Compressor Governor (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

6	a.	All metal parts	Clean	Use cleaning solvent P-D-680 and stiff bristled brush; dry with compressed air
	b.	All rubber	Clean	Use mild solution of parts detergent and water; dry using clean cloths
	c.	Piston (11) and body (19)	Clean	Clean air passages using compressed air

INSPECTION

7	a.	Body (19)	Inspect	Replace if cracked, broken, or damaged
	b.	Piston (11) or scored	Inspect	Replace if cracked, corroded,
	c.	Springs (5, 10, and 15)	Inspect	Replace if cracked, broken, or permanently set

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE**a. Air Compressor Governor (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
7 (cont)		d. Adjustment assembly (3 thru 8)	Inspect	Replace as an assembly if damaged
		e. All other parts	Inspect	Replace if cracked, broken, excessively worn, or threads damaged
REASSEMBLY				
8	Compressor governor	Body (19), piston (11), two preformed packings (12), and guide (7)	Lubricate	
9	Body (19)	a. Two filters (18)	Install	Press into body bores with eraser end of pencil In side of body (19)
		b. Four pipe plugs (17)	Install and tighten	
10	Piston (11)	a. Valve (16) and spring (15)	Position	In piston (11)
		b. Grommet (14) and washer (13)	Install	
		c. Two preformed packings (12)	Install	In piston (11) grooves
11	Adjustment assembly (3 thru 8)	a. Two lower spring seats (6) and guide (7)	Position	On adjusting screw (8)
		b. Spring (5)	Position	On spring seat (6)

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

a. Air Compressor Governor (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

11
(cont)

c. Upper spring seat (4)

a. Install
b. Adjust

Turn clockwise
Turn upper spring seat (4) for 1-7/8 inch distance between top of upper spring seat and bottom of adjusting screw as shown



TA236235

d. Nut (3)

Install and tighten

Secures upper spring seat adjustment

12 Body (19)

a. Piston (11)
b. Spring (10) and exhaust stem (9)
c. Adjustment assembly (3 thru 8)
d. Snap ring (2)
e. Rubber cover (1)

Install
Install
Position
Install
Install

In body (19) bore
In body (19) bore
Use retaining ring pliers
Turn clockwise

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly.

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly

INITIAL SETUP

Tools

- No. 1 Common Organizational Maintenance Tool Kit
 - Scratch wire brush
 - Socket wrench set
 - Torque wrench
 - Screwdriver set
 - Safety glasses
- Automotive Mechanic's Tool Kit
 - Pliers, round nose
 - Thickness gage
 - Punch
 - Machinist's rule
 - Hammer
- Bit set, socket head screw
- Soft-faced mallet
- Piston ring expander
- Piston ring compressor
- Micrometer
- Inside micrometer
- Bore gage
- Brass drift
- Arbor press
- Holding fixture

Materials/Parts

- Cleaning solvent
 - Clean cloths
 - Engine oil, SAE 30
 - Mineral spirits
 - High temperature cup grease
 - Maintenance kit
 - Four sealing rings
 - Oil seal
 - Four wrist pin buttons
 - Four lock straps
- Item 1, Appendix C
 - Item 2, Appendix C
 - Item 24, Appendix C
 - Item 33, Appendix C
 - Item 34; Appendix C
 - FSCM 06853 PN 287043
 - FSCM 06853 PN 292437
 - FSCM 06853 PN 243053
 - FSCM 06853 PN 292392
 - FSCM 06853 PN 249959

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-52e	Air compressor removed from tractor.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY

WARNING


Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

KEY

- 1. Key
- 2. Unloader plungers (2)
- 3. Screws (6)
- 4. Cylinder head
- 5. Gasket
- 6. Inlet valve springs (2)
- 7. Inlet valves (2)
- 8. Inlet valve guides (2)
- 9. Inlet valve seats (2)
- 10. Discharge valve seats (2)
- 11. Discharge valves (2)
- 12. Springs (2)
- 13. Rivets (4)
- 14. Plate
- 15. Grommets (2)
- 16. Back-up rings (2)



TA236271

- 17. Unloader plunger guides (2)
- 18. Crankcase
- 19. Unloader pistons (2)
- 20. Front bearing
- 21. Bolts (2)
- 22. Lock straps (2)
- 23. Connecting rod cap

- 24. Bearing insert
- 25. Bearing insert
- 26. Connecting rod
- 27. Piston
- 28. Wrist pin buttons (2)
- 29. Wrist pin
- 30. Bushing
- 31. Piston rings (2)
- 32. Expander ring
- 33. Oil ring
- 34. Screws (4)

- 35. Lock washers (4)
- 36. Rear end cover
- 37. Sealing rings (2)
- 38. Gasket
- 39. Thrust washer
- 40. Sealing rings (2)
- 41. Screws (4)
- 42. Lock washers (4)
- 43. Front end cover
- 44. Gasket
- 45. Oil seal
- 46. Unloader spring
- 47. Spring saddle
- 48. Spring seat
- 49. Crankshaft

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE**b. Air Compressor Assembly (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
<u>WARNING</u>				
Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.				
1	Compressor	Exterior	a. Clean b. Scribe	Use cleaning solvent P-D-680 and stiff bristled brush; dry with compressed air Use punch to make identifying marks for proper reassembly on: a. End covers (36 and 43), to indicate their relationship to crankcase' (18) b. Drive end of crankshaft (49) relative to front end cover (43) and crankcase (18) c. Cylinder head (4) relative to crankcase (18)
2	Crankshaft (49)	Key (1)	Remove	
3	Cylinder head (4)	a. Six screws (3) b. Cylinder head (4) sharply c. Gasket (5) d. Two inlet valve springs (6)	Remove a. Tap b. Separate Remove and discard	With soft-faced mallet From crankcase (18)

NOTE

In following step remove two large valve seats (10) using socket head screw bit. The two smaller slotted valve stops in cylinder head are not separately replaceable.

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE**b. Air Compressor Assembly (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3		e. Two discharge (cont) valve seats (10), discharge valves (11), and springs (12)	Remove	Turn discharge valve seats (10) counterclockwise using socket head screw bit
4	Crankcase (18)	a. Unloader spring (46)	Remove	Pry out using screwdriver blade between spring and spring saddle (47)
		b. Spring saddle (47)	Lift and	From unloader plungers (2) remove
		c. Spring seat (48)	Remove	
		d. Two unloader plungers (2) remove with plunger guides (17)	Lift and	Use round nose pliers
		e. Inlet cavity	Cover	With clean cloth

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

f.	Governor mounting pad unloader port	Apply air pressure (19)	To raise unloader pistons
g.	Two grommets (15), back-up rings (16), and unloader pistons (19)	Remove	Use round nose pliers
h.	Two inlet valves (7)	Remove	
i.	Two inlet valve guides (8)	Remove	
j.	Two inlet valve seats (9)	Remove	

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4 (cont)		k. Four rivets (13) and plate (14)	Remove	Only if necessary to replace damaged plate (14)
NOTE				
Before removing connecting rods (26), mark each connecting rod and mating cap (23) to identify their relationship during reassembly.				
5	Crankshaft (49)	a. Connecting rod cap (23) and connecting rod (26)	Scribe	Use punch to scribe marks
		b. Crankshaft (49) is at its lowest point	Rotate	Until connecting rod cap (23)
		c. Two lock straps (22)	Straighten prongs	
		d. Two bolts (21) and lock straps (22)	Remove	Discard lock straps (22)
		e. Connecting rod cap (23) and bearing insert (24)	Remove	Discard bearing insert (24)
		f. Piston (27) and connecting crankcase (18) rod (26)	Remove	Push out through top of
		g. Bearing insert (25)	Remove and discard	
		h. Two wrist pin buttons (28)	Remove and discard	
		i. Wrist pin (29)	Press out	
		j. Connecting rod (26) and piston (27)	Separate	
		k. Bushing (30) Press out and discard		
6	Piston	Two piston rings (27) (31), expander ring (32), and oil ring (33)	Remove	Use piston ring expander

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

NOTE

Repeat steps 5 and 6 above for removal and disassembly of remaining piston and connecting rod.

7	Crankcase (18)	a. Four screws (34) and lock washers (35)	Remove	
		b. Rear end cover (36)	Remove	
		c. Two sealing rings (37) and gasket (38)	Remove and discard	
		d. Thrust washer (39)	Remove	

NOTE

Do not attempt to remove crankshaft rear bearing. If inspection reveals an unserviceable rear bearing, a new rear end cover (36) assembly must be installed.

		e. Four screws (41) and lock washers (42)	Remove	
		f. Front end cover (43)	Remove	
		g. Gasket (44) and two sealing rings (40)	Remove and discard	
		h. Oil seal (45)	Press out and discard	
		i. Crankshaft (49)	a. Rotate	So that front crankpin is in alignment with cutout in bearing bore in crankcase (18)
		b.	Tap rear end	Use rawhide mallet. Tap until front bearing (20) is forced out of its bore in crankcase

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
7 (cont)		j. Front bearing (20)	Remove	
		k. Crankshaft (49)	Press out	

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.


Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

8		a. All parts	Clean	Use cleaning solvent P-D-680 and stiff bristled brush; dry with compressed air
		b. Cylinder head (4)	Clean	Remove all carbon deposits from discharge cavities. Remove rust and scale from cooling cavities. Scrape all foreign matter from all surfaces. Use shop air to clear all cavities
		c. Crankcase (18)	Clean	Remove all carbon deposits from inlet and unloader passages. Use shop air to clear unloader passages and oil passages. Run wire through oil passages

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
8 (cont)		d. Rear end cover (36) and front end cover (43)	Clean	Use shop air to clear oil passages; then run wire through oil passages
		e. Bearing in rear end cover (36) and front bearing (20)	Clean	Use mineral spirits; wipe dry with clean, dry cloth. Do not spin bearing (20) with compressed air
		f. Crankshaft (49)	Clean	Use shop air to clear oil passages; then run wire through oil passages
INSPECTION				
9		a. Key (1) b. Cylinder head (4)	Inspect a. Inspect b. Measure/ inspect	Replace if cracked or broken Replace if cracked, or mating surfaces pitted Distance of travel of two discharge valves (11). Travel must not exceed 0.057 inch. Replace cylinder head if this measurement is exceeded, or if valve stop bores are excessively scored
		c. Two inlet valve springs (6), two springs (12), and unloader spring (46) d. Two inlet valves (7) and inlet valve guides (8)	Inspect Inspect	Replace if cracked, broken, or permanently set Replace as an assembly if either is scratched or nicked



TA236211

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
9 (cont)		e. Crankcase (18)	a. Inspect	Replace if cracked, oil passages blocked, threads damaged, or other damage is apparent
			b. Check cylinder bores inside diameter for taper	Use inside micrometer or bore gage. Check below top ring location and at several points down length. If taper is more than 0.002 inch, replace crankcase
			c. Check cylinder bores out-of-roundness	Use bore gage. Measure lengthwise just below top ring location at four points 90 degrees from each other. If out-of-roundness exceeds 0.001 inch, replace crankcase
		f. Piston (27)	a. Inspect	Replace if cracked, scored, or if piston ring grooves are enlarged
			b. Measure outside diameter	Use micrometer. Measure piston in relationship to cylinder bore diameter. Diametral clearance is between 0.002 inch minimum, to 0.004 inch maximum. Replace piston if it does not fall within these clearance tolerances
		g. Piston rings (31), expander ring (32), and oil ring (33)	a. Inspect	Replace if cracked, scored, or excessively worn
			b. Check fit of rings in piston	Use ring expander to install rings. Use thickness gage to check fit. Piston ring clearance is between 0.002 inch minimum, to 0.004 inch maximum. Oil ring clearance is between 0.001 inch minimum to 0.003 inch maximum. Replace two piston rings (31) and/or oil ring (32) if clearances are excessive

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSPECTION (cont)

9
(cont)

c. Check gap clearance

Install piston with rings in cylinder bore. Use thickness gage to check fit. Clearance is 0.002 inch minimum to 0.010 inch maximum. Replace two piston rings (31) and/or oil rings (32) if clearances are excessive



TA236212

NOTE

Repeat steps 9f and 9g above for inspection of remaining piston and associated hardware.

h.	Rear end cover (36) with rear crankshaft bearing	Inspect	Replace if rear end cover is cracked, broken, or oil passages blocked, or if bearing is excessively worn or has flat spots
i.	Crankshaft (49)	a. Inspect b. Check journal diameters	Replace if cracked, scored, or threads damaged Use micrometer. Diameter should be 1.1242 to 1.1250 inches. Replace crankshaft if excessively scored or worn out-of-round. If journal wear or damage is not excessive, the crankshaft should be reground for oversize connecting rod bearing inserts (24 and 25)

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
9 (cont)			c. Check main journal bearing surface to bearings clearance	Install front bearing (20) on , crankshaft (49), and press crankshaft into bearing on rear end cover (36). Use thickness gage. Clearance must not exceed 0.0065 inch. Replace crankshaft if clearance is excessive
		j. All other parts	Inspect	Replace if cracked, broken, worn, or threads damaged
REASSEMBLY				
10	Crankcase (18) (45)	a. New oil seal	a. Lubricate	Use SAE 30 oil
		b. New gasket (44) and two new (18) sealing rings (40)	b. Install	In front end cover (43)
		c. Front end cover (43)	Position	On front end of crankcase (18); align with scribe marks on crankcase made before disassembly
		d. Four lock washers (42) and screws (41)	Install	Tighten to 15-18 pounds foot torque
		e. Bearing (20)	a. Lubricate	Use high temperature cup grease
			b. Install	On front end of crankshaft (49)
		f. Crankshaft (49)	Install	Align with scribe marks on crankcase (18) made before disassembly. Use arbor press to install in crankcase, making certain not to damage oil seal (45)
		g. Two new sealing rings (37)	a. Lubricate	Use SAE 30 oil
			b. Install	Into grooves in rear of crankcase (18)
		h. New gasket (38)	Position	
		i. Thrust washer (39)	Install	On crankshaft (49)

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE**b. Air Compressor Assembly (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
10 (cont)		j. Rear end cover (36),	Position	On rear end of crankcase (18); align with scribe marks on crankcase made before disassembly
		k. Four lock washers (35) torque and screws (34)	Install	Tighten to 15-18 pounds foot

NOTE

Steps 11 and 12 below cover reassembly and installation of one piston, connecting rod, and associated hardware.

11	Piston (27)	a. New bushing (30)	a. Align	Align oil hole in bushing (30) with oil hole in connecting rod (26)
			b. Press in	Until flush with connecting rod
			c. Ream	Or hone bushing (30) to provide 0.0001 inch minimum to 0.0006 inch maximum clearance on wrist pin (29)
			d. Lubricate	Use SAE 30 oil
			d. Lubricate	Position
		b. Connecting rod (26)		
		c. Wrist pin (29)	Install	Use hand pressure
		d. Two new wrist pin buttons (28)	Install	
		e. Two piston rings (31), expander ring (32), and oil ring (33)	Install	Use ring expander. Install rings with pipmarks up; stagger ring gaps around the piston
12	Crankshaft (49)	a. Crankshaft (49)	Rotate	So that journal will be at its lowest point

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE**b. Air Compressor Assembly (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
12 (cont)		b. Connecting rod (26), crankshaft (49), wrist pin (29), piston (27), and rings (31, 32, and 33)	Lubricate	Use SAE 30 oil
		c. New bearing insert (25) (26)	a. Lubricate b. Position	Use SAE 30 oil Press into connecting rod
		d. Piston (27) and connecting rod (26)	Install	Through top of crankcase (18) using piston ring compressor
		e. New bearing insert (24)	a. Lubricate b. Position	Use SAE 30 oil Press into rod cap (23)
		f. Connecting rod cap (23) and two new lock straps (22)	Position	On crankshaft (49). Locking slots on connecting rod (26) and connecting rod cap (23) must be adjacent
		g. Two bolts (21)	Install	Tighten to 120-150 pounds inch
		h. Lock straps (22)	Bend tabs	Secures bolts (21)
		i. Two bearing inserts (24 and 25) and journal on crankshaft (49)	Check clearance	Use thickness gage. Clearance must not be less than 0.0003 inch nor more than 0.0021 inch

NOTE

Repeat steps 11 and 12 above for reassembly and installation of remaining piston, connecting rod, and associated hardware.

13	Crankcase (18)	a. Two new back-up rings (16) and two new grommets (15)	Install	In unloader piston bores
----	----------------	---	---------	--------------------------

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
13 (cont)		b. Two new unloader pistons (19)	Install	Carefully, into unloader piston bores
		c. Two new unloader plungers (2)	Position	In unloader plunger guides
		d. Two unloader plungers (2) and unloader plunger guides (17)	Install	Over tops of unloader pistons (19)
		e. New unloader spring seat (48)	Install	In crankcase (18) inlet cavity
		f. New spring saddle (47)	Position	Between unloader plunger guides (17), so that forks of saddle are centered on plunger guides
		g. New unloader	Install	Make certain unloader spring (46) seats both in crankcase (18) and on spring saddle (47)
		h. Two inlet valve seats (9) and guides (8)	Install	
		i. Two inlet	Install	On inlet valve guides (8) valves (7)
	14	Cylinder head (4)	a. Two inlet valve springs (6)	Install
b. Two discharge valve springs (12), two discharge valves (11), and two discharge valve seats (10)			Install	Tighten discharge valve seats (10) to 50-60 pounds foot

3-25. AIR COMPRESSOR ASSEMBLY MAINTENANCE

b. Air Compressor Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
15	Crankcase (18)	a. New gasket (5)	Position	On crankcase (18)
		b. Cylinder head (4)	Position	On crankcase (18); align scribe marks made before disassembly
		c. Six screws (3)	Install and tighten	Tighten to 25-30 pounds foot torque
		d. Plate (14)	Position	If removed
		e. Four new rivets (13)	Install	
16	Crankshaft (49)	Key (1)	Install	

Section V. STEERING SYSTEM MAINTENANCE

This section contains the information you will need to maintain the steering system.

It gives you information on how to troubleshoot problems and repair or replace the components that are within the scope of direct support maintenance.

	Para
Troubleshooting Symptom Index.....	3-26
Steering System Troubleshooting	3-27
Steering System Maintenance.....	3-28
Steering Column.....	3-28a
Universal Joint.....	3-28b
Tie Rod.....	3-28c
Power Steering Gear.....	3-28d
Steering Linkage and Ball Sockets.....	3-28e
Power Steering Pump	3-28f

3-26. TROUBLESHOOTING SYMPTOM INDEX

	Para/Malfunction	Page
STEERING SYSTEM		
Steering wheel stops turning before tractor front wheels hit stop blocks	3-27/1	3-226
Too much play in steering wheel.....	3-27/2	3-227
Tractor wanders over road	3-27/3	3-227
No recovery	3-27/4	3-228
Shimmy.....	3-27/5	3-230
Oversteering or darting.....	3-27/6	3-230
High steering effort in one direction.....	3-27/7	3-231
High steering effort in both directions.....	3-27/8	3-233
Lost motion at steering wheel.....	3-27/9	3-234
Power steering pump not delivering oil.....	3-27/10	3-235
Power steering pump making noise	3-27/11	3-236

3-27. STEERING SYSTEM TROUBLESHOOTING

**MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION**

1. STEERING WHEEL STOPS TURNING BEFORE TRACTOR FRONT WHEELS HIT STOP BLOCKS

Check that power steering gear sector shaft is centered.

- a. If not centered, center power steering gear sector shaft (para 3-28d).
- b. If centered, proceed to step 4 below.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

2. TOO MUCH PLAY IN STEERING WHEEL

Step 1. Check that power steering gear sector shaft is properly adjusted (does not have lash).

- a. If sector shaft is not properly adjusted, adjust (para 3-28d).
- b. If sector shaft is properly adjusted, proceed to step 2 below.

Step 2. Remove universal joint (para 3-28b).
Check universal joint components for wear or damage.

- a. If universal joint components are worn or damaged, replace components (para 3-28b).
- b. If components are not worn or damaged, proceed to step 3 below.

Step 3. Remove and disassemble power steering gear (para 3-28d). Check for damage to sector shaft gear and rack piston teeth.

- a. If gear or teeth are damaged, replace (para 3-28d).
- b. If gear and teeth are not damaged, overhaul power steering gear (para 3-28d).

3. TRACTOR WANDERS OVER ROAD

Step 1. Remove universal joint (para 3-28b).
Check universal joint components for wear or damage.

- a. If universal joint components are worn or damaged, replace components (para 3-28b).
- b. If components are not worn or damaged, proceed to step 2 below.

Step 2. Check if power steering gear mounting capscrews are loose.

- a. If power steering gear mounting capscrews are loose, tighten (para 3-28d).
- b. If power steering gear mounting capscrews are tight, proceed to step 3 below.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

3. TRACTOR WANDERS OVER ROAD (Cont)

Step 3. Check that power steering gear sector shaft is centered.

- a. If sector shaft is not centered, center (para 3-28d).
- b. If sector shaft is centered, proceed to step 4 below.

Step 4. Check if power steering gear worm shaft locknut is loose.

- a. If locknut is loose, tighten and secure (para 3-28d).
- b. If locknut is secure, overhaul or replace power steering gear (para 3-28d).

4. NO RECOVERY

Step 1. Check universal joint components for wear or damage.

- a. If universal joint components are worn or damaged, replace (para 3-28b).
- b. If universal joint components are not worn or damaged, proceed to step 2 below.

Step 2. Check for binding in universal joint assembly.

- a. If universal joint assembly is binding, correct as necessary (para 3-28b).
- b. If universal joint assembly is not binding, proceed to step 3 below.

Step 3. Check steering column components for binding.

- a. If components are binding, replace (para 3-28a).
- b. If components are not binding, proceed to step 4 below.

Step 4. Remove power steering reservoir dipstick (para 2-58c).

Attach a vacuum pump to power steering reservoir fill opening. Operate pump several minutes to create a vacuum inside the reservoir.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

4. NO RECOVERY (Cont)**NOTE**

If you do not draw enough air out of the power steering reservoir, hydraulic oil will gush out of hose when performing the following procedure (some loss of oil is normal).

With vacuum pump operating, disconnect power steering pump main supply hose at power steering pump (para 2-58b).

Connect 10 GPM flowmeter inlet hose to power steering pump.

Connect flowmeter outlet hose to main supply hose disconnected from power steering pump.

Turn off vacuum pump and disconnect from power steering reservoir.

Set flowmeter volume control for 10 US GPM and open flowmeter load valve.

Check power steering reservoir oil level; add oil if level is low (para 2-58c).

Start vehicle engine and operate at 1200 RPM.

Close flowmeter load valve until flowmeter pressure gage indicates 100 psi.

Flowmeter volume reading should be 4.0 GPM.

- a. If flowmeter volume reading is not 4.0 GPM, remove and repair power steering pump (para 3-28f).
- b. If flowmeter volume reading is 4.0 GPM, proceed to step 5 below.

Step 5.

Increase engine speed to 1500 RPM.

If necessary, readjust flowmeter load valve to obtain 100 psi pressure indication.

Flowmeter volume reading should be 5.5 GPM.

- a. If flowmeter volume reading is not 5.5 GPM, remove and repair power steering pump (para 3-28f).
- b. If flowmeter volume reading is 5.5 GPM, shut down engine, connect and turn on vacuum pump, and disconnect flowmeter. Reconnect power steering pump main supply hose to pump (para 2-58b), and turn off and disconnect vacuum pump. Check oil level; add oil if level is low (para 2-58c). Then proceed to step 6 below.

Step 6.

Remove power steering gear (para 3-28d).

Remove valve assembly from power steering gear (para 3-28d). Carefully remove valve spool from valve assembly. Check valve spool for damage or wear.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

4. NO RECOVERY (Cont)

- a. If valve spool is damaged or worn, replace valve assembly (para 3-28d).
- b. If valve spool is not damaged or worn, notify general support maintenance.

5. SHIMMY

Check ball sockets and drag link for wear or looseness.

- a. If ball sockets are loose, tighten (para 3-28e); if components are worn, replace (para 3-28e).
- b. If ball sockets and drag link are not worn or loose, refer to Malfunction 3 above.

6. OVERSTEERING OR DARTING

Step 1. Check ball sockets and drag link for wear or looseness.

- a. If ball sockets are loose, tighten (para 3-28e); if components are worn, replace (para 3-28e).
- b. If ball sockets and drag link are not worn or loose, proceed to step 2 below.

Step 2. Check if front axle alignment is correct.

- a. If front axle alignment is not correct, adjust (para 3-28c).
- b. If front axle alignment is correct, proceed to step 3 below.

Step 3. Check steering column components for binding.

- a. If components are binding, replace components (para 3-28a).
- b. If components are not binding, proceed to step 4 below.

Step 4. Check if power steering gear sector shaft adjustment is too tight.

- a. If adjustment is too tight, readjust (para 3-28d).
- b. If adjustment is correct, proceed to step 5 below.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

6. OVERSTEERING OR DARTING (Cont)

Step 5. Remove power steering gear (para 3-28d).
Remove valve assembly from power steering gear (para 3-28d).
Check if valve spool is sticking in valve assembly.

- a. If valve spool is sticking in valve assembly, clean valve spool and inspect it for burrs, wear or damage (para 3-28d). Replace valve assembly (para 3-28d) if spool is burred, worn, or damaged. If spool is not burred, worn, or damaged, reinstall in valve assembly (para 3-28d) and recheck for sticking. Replace valve assembly if necessary (para 3-28d).

b. If valve spool is not sticking in valve assembly, notify general support maintenance.

7. HIGH STEERING EFFORT IN ONE DIRECTION

Step 1. Remove power steering reservoir dipstick (para 2-58c).
Attach a vacuum pump to power steering reservoir fill opening.
Operate pump several minutes to create a vacuum inside the reservoir.

NOTE

If you do not draw enough air out of the power steering reservoir, hydraulic oil will gush out of hose when performing the following procedure (some loss of oil is normal).

With vacuum pump operating, disconnect power steering pump main supply hose at power steering pump (para 2-58b).

Connect 10 GPM flowmeter inlet hose to power steering pump.

Connect flowmeter outlet hose to main supply hose disconnected from power steering pump.

Turn off vacuum pump and disconnect from power steering reservoir.

Set flowmeter volume control for 10 US GPM and open flowmeter load valve.

Check power steering reservoir oil level; add oil if level is low (para 2-58c).

Start vehicle engine and operate at 1200 RPM. Close flowmeter load valve until flowmeter pressure gage indicates 100 psi.

Flowmeter volume reading should be 4.0 GPM.

- a. If flowmeter volume reading is not 4.0 GPM, remove and repair power steering pump (para 3-28f).

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

7. HIGH STEERING EFFORT IN ONE DIRECTION (Cont)

b. If flowmeter volume reading is 4.0 GPM, proceed to step 2 below.

Step 2. With engine operating at 1500 RPM, gradually close flowmeter load valve (adjust engine speed as required to maintain 1500 RPM) until flowmeter pressure gage indication is 1750 psi. Flowmeter volume reading should be 4.5 to 5.5 GPM.

a. If flowmeter volume reading is not 4.5 to 5.5 GPM or if pressure can not be maintained, remove and repair power steering pump (para 3-28f).

b. If flowmeter volume reading is 4.5 to 5.5 GPM, shut down engine, connect and turn on vacuum pump, and disconnect flowmeter. Reconnect power steering pump main supply hose to pump, and turn off and disconnect vacuum pump. Check oil level; add oil if level is low (para 2-58c). Then proceed to step 3 below.

Step 3. Remove universal joint (para 3-28b).

Check universal joint components for wear or damage that could cause binding.

a. If universal joint components are worn or damaged, replace components (para 3-28b).

b. If components are not worn or damaged, proceed to step 4 below.

Step 4. Check if power steering gear worm shaft locknut is loose.

a. If locknut is loose, tighten and secure (para 3-28d).

b. If locknut is secure, proceed to step 5 below.

Step 5. Remove and disassemble power steering gear (para 3-28d) and check seals for damage.

a. If seals are damaged, replace (para 3-28d).

b. If seals are not damaged, overhaul or replace power steering gear (para 3-28d).

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

8. HIGH STEERING EFFORT IN BOTH DIRECTIONS

- Step 1. Remove universal joint (para 3-28b).
Check universal joint components for wear or damage that could cause binding (para 3-28b).
- a. If universal joint components are worn or damaged, replace components (para 3-28b).
 - b. If components are not worn or damaged, proceed to step 2 below.
- Step 2. Check power steering pump delivery (perform steps 1 and 2 of Malfunction 7 above).
- a. If flow is low or pressure is low, proceed to step 3 below.
 - b. If flow and pressure are not low, proceed to step 5 below.
- Step 3. Remove control valve assembly from power steering pump (para 3-28f).
Inspect control valve for burrs or other deformities which could cause it to stick in valve bore.
Check control valve spring for cracks, breaks, and loss of tension.
- a. If control valve sticks in valve bore, is burred, or is otherwise deformed, replace (para 3-28f). If spring is cracked, broken, or permanently set, replace (para 3-28f).
 - b. If control valve assembly is not defective, reinstall (para 3-28f). Then proceed to step 4 below.
- Step 4. Remove power steering pump from engine (para 3-28f).
Check gear and coupling for wear or damage, and missing or broken gear teeth.
- a. Replace gear or coupling if worn or damaged, or gear teeth missing or broken (para 3-28f).
 - b. If gear and coupling are not worn or damaged and gear teeth are not missing or broken, reinstall power steering pump (para 3-28f). Proceed to step 5 below.
- Step 5. Remove power steering gear (para 3-28d).
Remove valve assembly from power steering gear (para 3-28d).
Carefully remove valve spool from valve assembly.
Check valve spool for damage or wear or other deformities which could cause it to stick in valve bore.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

8. HIGH STEERING EFFORT IN BOTH DIRECTIONS (Cont)

- a. If valve spool is damaged, worn, or sticks in valve bore, replace valve assembly (para 3-28d).
- b. If valve spool is not damaged or worn, proceed to step 6 below.

Step 6. Disassemble power steering gear (para 3-28d) and check seals for damage.

- a. If seals are damaged, replace (para 3-28d).
- b. If seals are not damaged, overhaul or replace power steering gear (para 3-28d).

9. LOST MOTION AT STEERING WHEEL

Step 1. Check ball sockets for looseness and wear.

- a. If ball sockets are loose, tighten (para 3-28e); if components are worn, replace components (para 3-28e).
- b. If ball sockets are not loose or worn, proceed to step 2 below.

Step 2. Check if pitman arm is loose on power steering gear sector shaft.

- a. If pitman arm is loose, tighten nut (para 3-28d).
- b. If pitman arm is not loose, proceed to step 3 below.

Step 3. Check if power steering gear mounting capscrews are loose.

- a. If power steering gear mounting capscrews are loose, tighten (para 3-28d).
- b. If power steering gear mounting capscrews are tight, proceed to step 4 below.

Step 4. Check if universal joint mounting screws are loose.
Grasp slip yoke and move side to side. There should be only slight movement.

- a. If a large amount of movement is felt, remove, repair, and reinstall universal joint (para 3-28b).
- b. If slight movement only is felt, proceed to step 5 below.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

9. LOST MOTION AT STEERING WHEEL (Cont)

- Step 5. Check power steering gear adjustments.
- a. If power steering gear is not properly adjusted, adjust (para 3-28d).
 - b. If power steering gear is properly adjusted, overhaul or replace power steering gear (para 3-28d).

10. POWER STEERING PUMP NOT DELIVERING OIL

- Step 1. Remove control valve assembly from power steering pump (para 3-28f).
Clean control valve (para 3-28f).
Install control valve in bore and slide back and forth.
Check if control valve sticks in bore.
- a. If control valve is sticking and a gritty feeling is noted on valve outer diameter, polish with crocus cloth (avoid removal of excess material or rounding of valve edges during this operation). If control valve continues to stick, replace (para 3-28f).
 - b. If control valve does not stick, reinstall control valve assembly (para 3-28f). Then proceed to step 2 below.
- Step 2. Remove power steering pump (para 3-28f).
Check gear and coupling for damage, wear, or missing teeth.
- a. If gear or coupling is damaged, worn, or teeth missing, replace (para 3-28f).
 - b. If gear and coupling are not damaged or worn and teeth are not missing, proceed to step 3 below.
- Step 3. Check power steering pump key and shaft for damage or wear.
- a. If key or shaft are damaged or worn, replace (para 3-28f).
 - b. If key and shaft are not damaged or worn, proceed to step 4 below.

3-27. STEERING SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

10. POWER STEERING PUMP NOT DELIVERING OIL (Cont)

- Step 4. Disassemble power steering pump (para 3-28f).
Examine rotor slots for dirt, grime, or small metal chips.
Clean rotor and vanes and reassemble pump (para 3-28f). Check for free vane movement.
- a. If vane movement is not free, replace rotor and vanes (para 3-28f).
 - b. If vane movement is free, overhaul or replace power steering pump (para 3-28f).

11. POWER STEERING PUMP MAKING NOISE

- Step 1. Remove power steering pump (para 3-28f).
Check that gear and coupling are correctly aligned and secure.
- a. If gear and coupling are not correctly aligned or are loose, repair or replace (para 3-28f).
 - b. If gear and coupling are correctly aligned and secure, proceed to step 2 below.
- Step 2. Disassemble power steering pump (para 3-28f).
Check shaft seal, bearings, and pump cartridge assembly (ring, rotor, pins, and vanes) for wear or damage.
- If shaft seal, bearings, or pump cartridge assembly parts are worn or damaged, replace (para 3-28f).

3-28. STEERING SYSTEM MAINTENANCE

a. Steering Column.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

- No. 1 Common Organizational Maintenance Tool Kit
- Socket wrench set
- Screwdriver set
- Vise jaw caps
- Mechanical puller kit
- Safety glasses
- Hammer
- Brass drift

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Grease Item 15, Appendix C
- Mineral spirits Item 33, Appendix C
- Dust cap FSCM 77640 P/N 029085
- Sealant, Weatherban FSCM 04963 P/N 202

Equipment Condition Paragraph

Condition Description

- Vehicle parked on level surface, engine off, front wheels centered, and parking brake applied.
- 2-33b Horn button removed.
- 2-58a Steering wheel removed.
- 2-27 Steering column wiring harness pins disconnected from connector housing; turn signal and hazard switch assemblies removed from steering column.
- 3-24c Trailer hand brake control removed.
- 3-28b Universal joint bottom yoke disconnected from power steering gear shaft.
- 3-35e Floor mat pulled back from steering column enclosure.

Personnel Required

Two Automotive Repairers MOS 63H

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


1	Cab, underside	Eight locknuts (9) and washers (10)	Remove	While assistant inside cab prevents capscrews (11) from turning
2	Cab, inside	a. Eight capscrews (11)	Remove	
		b. Two capscrews (1), lock washers (2), and bracket (3)	Remove	Support steering column (8)
		c. Steering column (8) with universal joint and enclosure (12)	Lift and remove	From cab

3-28. STEERING SYSTEM MAINTENANCE (CONT)

a. Steering Column (cont).

KEY

- 1. Capscrews (2)
- 2. Lock washers (2)
- 3. Bracket
- 4. Locknuts (2)
- 5. Capscrews (2)
- 6. Washers (2)
- 7. Bracket
- 8. Steering column
- 9. Locknuts (8)
- 10. Washers (8)
- 11. Capscrews (8)
- 12. Steering column enclosure
- 13. Plug
- 14. Spacer
- 15. Spring seat
- 16. Upper ball bearing
- 17. Steering shaft
- 18. Dust cap
- 19. Spring
- 20. Spring seat
- 21. Lower ball bearing
- 22. Nuts (2)
- 23. Washers (2)
- 24. Clamp bolts (2)
- 25. Housing
- 26. Tube
- 27. Reinforcing ring



TA236272

3-28. STEERING SYSTEM MAINTENANCE (CONT)**a. Steering Column (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
3	Steering column (8)	a. Plug (13)	Remove	Only if necessary for replacement
		b. Two locknuts (4), cap-screws (5), washers (6), and bracket (7)	Remove	
		c. Universal joint top yoke	Disconnect	From steering shaft (17); para 3-28b
		d. Steering column enclosure (12)	Remove	From steering column (8)
DISASSEMBLY				
4	Steering column (8)	a. Steering column (8)	Position	In soft-jawed vise
		b. Two nuts (22), washers (23), and clamp bolts (24)	Remove	
		c. Housing (25) and tube (26)	Separate	
		d. Spacer (14), spring seat (15), and upper ball bearing (16)	Remove	Remove upper ball bearing (16) using brass drift and hammer
		e. Steering shaft (17)	Remove	From tube (26)
		f. Dust cap (18), spring (19), and spring seat (20)	Remove	Discard dust cap (18)
		g. Lower ball bearing (21)	Remove	Use bearing puller
		h. Reinforcing ring (27)	Remove	

3-28. STEERING SYSTEM MAINTENANCE (CONT)

a. Steering Column (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

NOTE

Do not use compressed air to dry ball bearings.

5		a. Ball bearings (16 and 21)	Clean	Wash in mineral spirits; allow to air dry. When dry, repack with grease
---	--	---------------------------------	-------	---

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

		b. All other metal parts	Clean	Use cleaning solvent P-D-680; dry with compressed air. Be sure you remove all traces of old sealant from cab floor and steering column enclosure (12)
--	--	-----------------------------	-------	--

INSPECTION

6		a. Spring (19)	Inspect	Replace if cracked, broken, distorted, or compressed
		b. Ball bearings (16 and 21)	Inspect	Replace if cracked, exces- sively worn, or has flat spots

3-28. STEERING SYSTEM MAINTENANCE (CONT)**a. Steering Column (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
6 (cont)		c. Steering shaft (17)	Inspect	Replace if cracked, bent, or splines damaged
		d. Steering column enclosure (12)	Inspect	Replace if cracked, distorted or weldments broken
		e. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
REASSEMBLY				
7	Steering column (8)	a. Tube (26)	Position	In soft-jawed vise On tube (26)
		b. Reinforcing ring (27)	Install	
		c. Tube (26) and housing (25)	Mate	
		d. Two clamp bolts (24), washers (23), and nuts (22)	Install and tighten	
		e. Lower ball bearing (21)	a. Lubricate	Pack with grease On steering shaft (17)
		f. Spring seat (20)	b. Install	
		g. Spring (19)	Install	
		h. New dust cap (18)	Install	
		i. Steering shaft (17)	Install	In tube (26)
		j. Upper ball bearing (16)	Install	On steering shaft (17)
		k. Spring seat (15)	Install	
l. Spacer (14)	Install			
INSTALLATION				
8	Steering column (8)	a. Steering column enclosure (12)	Position	On steering column (8)
		b. Universal joint top yoke	Connect	To steering shaft (17); para 3-28b

3-28. STEERING SYSTEM MAINTENANCE (CONT)

a. Steering Column (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
9	Cab, inside	a. Steering column enclosure (12)	a. Seal	Apply 1/8-inch bead of sealant to base
			b. Position	On cab floor, with capscrew holes aligned
		b. Eight capscrews (11)	Insert	In base of steering column enclosure (12)
		c. Bracket (3)	Position	
		d. Two lockwashers (2) and capscrews (1)	Install	Do not tighten
		e. Bracket (7) f. Two capscrews (5), washers (6), and locknuts (4)	Position Install	Do not tighten
10	Cab, underside	a. Eight washers (10) and locknuts (9)	Install and tighten	While assistant inside cab prevents capscrews (11) from turning
		b. Universal joint bottom yoke	Connect	To power steering gear shaft; para 3-28b
11	Cab, inside	a. Capscrews (1 and 7)	Tighten	While assistant holds steering column (8) in correct position
		b. Floor mat	Position	Over base of steering column enclosure (12); para 3-35f
		c. Plug (13)	Install	If removed
12	Steering column (8)	a. Turn signal control and hazard warning switch	Install	Para 2-27
		b. Steering wheel	Install	Para 2-58a
		c. Horn button	Install	Para 2-33b
		d. Trailer hand brake control	Install	Para 3-24c
13	Cab	Steering	Test	Test steering operation; check for binding or unusual noise

3-28. STEERING SYSTEM MAINTENANCE (CONT)

b. Universal Joint.

This task covers:

- a. Removal
- b. Disassembly
- c. Cleaning
- d. Inspection
- e. Reassembly
- f. Installation

INITIAL SETUP

Tools

- No. 1 Common Organizational Maintenance Tool Kit
 - Socket wrench set
 - Vise jaw caps
 - Scratch wire brush
 - Retaining ring pliers
 - Safety glasses
- No. 2 Automotive Maintenance Tool Kit
 - Lubricating kit
 - Grease gun
- Automotive Mechanic's Tool Kit
 - Punch
 - Pliers
 - Hammer
- Brass rod

Materials/Parts

- Cleaning solvent
- Clean cloths
- Grease
- Engine oil, SAE 30
- Seal
- Two journals
- Item 1, Appendix C
- Item 2, Appendix C
- Item 3, Appendix C
- Item 24, Appendix C
- FSCM 95019 P/N 10-16-83
- FSCM 95019 P/N 10-14-29

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition Paragraph

Condition Description

Parked on level surface; parking brake applied; engine off.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


1	Bottom yoke (9)	a. Locknut (1) and capscrew (2) b. Bottom yoke (9)	Remove Disconnect	 From steering gear
2	Cab, inside	Steering column with universal joint	Remove from vehicle	Para 3-28a
3	Steering column and universal joint	a. Nut (3), cap-screw (4), and lock washer (19) b. Top yoke (14) c. Universal joint	Remove Disconnect a. Position b. Scribe mark	From steering column shaft In soft jawed vise Use punch to scribe mark on slip yoke (15) and splined yoke (18) to aid in reassembly

3-28. STEERING SYSTEM MAINTENANCE (CONT)

b. Universal Joint (cont).

KEY

- 1. Locknut
- 2. Capscrew
- 3. Nut
- 4. Capscrew
- 5. Retaining rings (4)
- 6. Bushings (4)
- 7. Center cross
- 8. Seals (4)
- 9. Bottom yoke
- 10. Retaining rings (4)
- 11. Bushings (4)
- 12. Center cross
- 13. Seals (4)
- 14. Top yoke
- 15. Splined yoke
- 16. Seal cap
- 17. Seal
- 18. Slip yoke
- 19. Lock washer



TA236273

3-28. STEERING SYSTEM MAINTENANCE (CONT)**b. Universal Joint (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
4		a. Four retaining rings (5)	Remove	Use retaining ring pliers
		b. Four bushings (6) and seals (8)	Remove	Use brass rod having a diameter slightly smaller than bushing diameter; tap rod using hammer to remove bushings
		c. Center cross (7)	Remove	Separates bottom yoke (9) and splined yoke (15)
		d. Four retaining rings (10)	Remove	Use retaining ring pliers
		e. Four bushings (11) and seals (13)	Remove	Use brass rod having a diameter slightly smaller than bushing diameter; tap rod using hammer to remove bushings
		f. Center cross (14)	Remove	Separates top yoke (14) from slip yoke (18)
		g. Seal cap (16)	Bend tabs	
		h. Splined yoke (15)	Remove	From slip yoke (18)
		i. Seal cap (16)	Remove	
		j. Seal (17)	Remove and discard	

CLEANING**WARNING**

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-28. STEERING SYSTEM MAINTENANCE (CONT)**b. Universal Joint (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
<u>WARNING</u>				
Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.				
5		All parts	Clean	Use cleaning solvent P-D-680; use wire brush to remove corrosion. Dry using compressed air
INSPECTION				
6		a. Bottom yoke (9) and top yoke (14)	Inspect for cracks breaks distortion	Replace if any defects observed
		b. Splined yoke (15) and slip yoke (18)	Inspect for cracks distortion breaks chipped splines damaged teflon coating	Replace if any defects observed
		c. Remaining parts	Inspect for cracks breaks distortion damage stripped threads	Replace if any defects observed
REASSEMBLY				
7		a. All unpainted surfaces	Protect from corrosion	Wipe using clean cloth moistened with SAE 30 engine oil
		b. Cross (12)	Position	In top yoke (14) and slip yoke (18)

3-28. STEERING SYSTEM MAINTENANCE (CONT)**b. Universal Joint (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
7 (cont)		c. Four bushings (11) and seals (13)	Install	In top yoke (14) and slip yoke (18)
		d. Top yoke (14) and slip yoke (18)	Position	In soft jawed vise
		e. Soft jawed vise	Close jaws	Seats bushings (11); repeat for other ends of cross (12)
		f. Four bushings (11)	Depress	Use brass rod or discarded bushing to set bushings below retaining ring grooves
		g. Four retaining rings (10)	Install	Use retaining ring pliers

NOTE

Perform steps 7b thru 7g to install cross (7), bushings (6), and retaining rings (5) in bottom yoke (9) and splined yoke (15).

		h. Slip yoke (18)	Position	In soft jawed vise
		i. Seal cap (16) and new seal (17)	Install	Over splines on splined yoke (15)
		j. Splined yoke (15)	Insert	In slip yoke (18); line up scribe marks made in step 3c above
		k. Seal cap (16)	Bend tabs	Into grooves of splined yoke (15)
		l. Cross (7 and 12) and slip yoke (18)	Lubricate	Use grease gun

INSTALLATION

8	Universal joint	a. Top yoke (14)	Position	On steering column shaft
		b. Lock washer (19), capscrew (4), and nut (3)	Install and tighten	

3-28. STEERING SYSTEM MAINTENANCE (CONT)**b. Universal Joint (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
9	Cab	a. Steering column, universal joint, and column enclosure	Install	Para 3-28a
		b. Bottom yoke (9)	Connect	To steering gear
		c. Locknut (1) and capscrew (2)	Install and tighten	
10	Steering system	Steering	Check operation	

3-248

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod.

This task covers: a. Removal d. Installation
 b. Cleaning e. Adjustment
 c. Inspection

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance
 Tool Kit
 Socket wrench set
 Torque wrench
 Open end wrench set
 Hammer
 Safety glasses
 Bronze drift
 Full floating turning radius gage plate
 Trammel bar
 Jack

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph

Condition Description

Parked on level surface;
 parking brake applied; engine
 off.
 Rear wheels blocked.

Materials/Parts

Cleaning solvent Item 1, Appendix C
 Clean cloths Item 2, Appendix C
 Penetrating oil Item 44, Appendix C
 Cotter pins FSCM 78500 P/N K2412
 Cotter pins FSCM 78500 P/N K2616
 Chalk

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Left side steering knuckle	Cotter pin (1) and nut (2)	Remove	Discard cotter pin (1)
2	Right side steering knuckle	a. Cotter pin (1) and nut (2)	Remove	Discard cotter pin (1)

WARNING



Don't strike hardened steel parts with steel hammer. To do so could cause metal chips to hit your eyes causing you serious injury. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when using a hammer.

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod (cont).

KEY

- 1. Cotter pins (2)
- 2. Nuts (2)
- 3. Nuts (2)
- 4. Bolts (2)
- 5. Clamps (2)
- 6. Tie rod ends (2)
- 7. Cross tube
- 8. Cotter pins (2)
- 9. Nuts (2)
- 10. Tie rod arms (2)
- 11. Keys (2)
- 12. Steering knuckles (2)



TA236274

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2 (cont)		b. Tie rod end (6)	Separate	Use brass drift and hammer; separate tie rod end (6) from tie rod arm (10)
3	Left side steering knuckle	a. Tie rod end (6)	Separate	Use brass drift and hammer; separate tie rod end (6) from tie rod arm (10)
		b. Cross tube (7)	Lower to ground	
		c. Cotter pin (8) and nut (9)	Remove	Discard cotter pin (8)

WARNING

Don't strike hardened steel parts with steel hammer. To do so could cause metal chips to hit your eyes causing you serious injury. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety glasses when using a hammer.

d. Tie rod arm (10)	Separate	Use brass drift and hammer; separate tie rod arm (10) from steering knuckle (12)
e. Key (11)	Remove	

NOTE

Perform steps 3c through 3e above to remove remaining tie rod arm (10).

4	Tie rod	a. Nut (3) and bolt (4)	Remove	
		b. Tie rod end (6)	Remove	Turn left tie rod end clockwise to remove; turn right tie rod end counterclockwise to remove
		c. Two clamps (5)	Remove	

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

5		All parts	Clean	Use cleaning solvent P-D-680; dry using clean cloths
---	--	-----------	-------	--

INSPECTION

6	a.	Two clamps (5)	Inspect for: cracks distortion breaks	Replace if defects observed
	b.	Two tie rod ends (6) and tie rod arms (10)	Inspect for: cracks distortion damaged threads bent condition	Replace if defects observed
	c.	Cross tube (7)	Inspect for: cracks bent condition	Replace if defects observed
	d.	Two keys (11)	Inspect for: cracks distortion chipping	Replace if defects observed
	e.	Remaining parts	Inspect for: cracks breaks damaged threads bent condition	Replace if defects observed

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
7	Left side steering knuckle	a. Key (11) b. Tie rod arm (10) c. Nut (9)	Install Install Install	In tie rod arm (10) In steering knuckle (12) Tighten to initial torque of 550 pounds foot; To align cotter pin holes in nut with holes in tie rod arm (10), tighten to 740 pounds foot. If final torque is exceeded, remove nut (9) and repeat this step
		d. New cotter pin (8)	Install and spread	
NOTE				
Perform step 7 above to install right side tie rod arm (10).				
8	Cross tube (7)	a. Two clamps (5) b. Two bolts (4) and nuts (3)	Install Install	On ends of cross tube (7) Don't tighten nut (3)
9	Front of vehicle	Two steering knuckles (12)	Position	In straight ahead position
10	Cross tube (7)	Two tie rod ends (6)	Install in cross tube	Turn right tie rod end clockwise to install; turn left tie rod end counterclockwise to install. Screw in equal amounts until studs on tie rod ends align with tapered holes in tie rod arms (10)
11	Tie rod arms (10)	a. Two tie rod ends (6)	Install	In tie rod arms (10)

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod (cont);

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
11 (cont)		b. Two nuts (2)	Install	Tighten to initial torque of 350 pounds foot. To align cotter pin holes in nut with holes in tie rod end (6), tighten to a final value of 475 pounds foot torque. If final torque is exceeded, remove nut (2) and repeat this step
		c. Two new cotter pins (1)	Install and spread	
		d. Two nuts (3) and bolts (4)	Tighten	Tighten to initial torque of 40 pounds foot. Then tighten to a maximum of 55 pounds foot torque
ADJUSTMENT				
12	Vehicle, rear	Rear wheels	Block	
13	Vehicle, front	a. Front axle	Raise from ground	Use jack
		b. Front tires	Whiten center area of both tires around entire circumference with chalk	
		c. Scribe or other pointed instrument	Position and scribe line	Against whitened part of each tire; scribe must be held firmly in place so that a single line is scribed all the way around the tire
		d. Full floating turning radius gage plate	Position	Under each front tire
		e. Front axle plates	Lower	Lower front tires onto gage
		f. Sliding scale end of trammel bar (located on gage plate)	Set to zero	
		g. Trammel bar	Position at rear of tires; adjust pointers to line up with scribe lines and lock in place (scale should be set to zero)	

3-28. STEERING SYSTEM MAINTENANCE (CONT)

c. Tie Rod (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
ADJUSTMENT (cont)				
13 (cont)		h. Trammel bar	Position at front of tires. Adjust scale end so that pointers line up with scribe marks	
		i. Scale	Read toe-in or toe-out. Toe-in should be 1/16 +1/16 inch. If necessary, perform steps j thru n below to adjust toe-in	
		j. Two nuts (3)	Loosen	
		k. Two tie rod ends (6)	Lubricate	With penetrating oil
		l. Cross tube (7)	Rotate	Forward rotation reduces toe-in; rearward rotation increases toe-in
		m. Toe-in	Recheck	Repeat steps f thru l above until toe-in is 1/16 +1/16 inch
		n. Two nuts (3)	Tighten	Secures toe-in adjustment
		o. Front axle	Raise from ground	Use jack
		p. Two gage plates	Remove	From under front tires
		q. Front axle	Lower	Then remove jack and rear wheel blocks

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Testing
 - g. Installation and adjustment

INITIAL SETUP

Tools

- | | | |
|---|----------------------|-------------------------|
| Automotive Mechanic's Tool Kit | Wheel bearing grease | Item 16, Appendix C |
| Socket wrench set, 1/2 inch drive | Degreasing solvent | Item 18, Appendix C |
| Flat tip screwdriver | Stud sealant | Item 19, Appendix C |
| No. 1 Common Organizational Maintenance Tool Kit | Hydraulic sealant | Item 20, Appendix C |
| Mechanical puller kit | Cellophane tape | Item 21, Appendix C |
| Vise with jaw caps | Hydraulic oil | Item 22, Appendix C |
| Socket wrench handle, 1/2 inch drive | Seal kit | FSCM 77640 P/N HF640000 |
| Socket wrench set, 3/4 inch drive | | |
| Torque wrench, 1/2 inch drive, 175 pounds foot capacity | | |
| Torque wrench, 3/4 inch drive, 600 pounds foot capacity | | |
| Retaining ring pliers | | |
| Sharpening stone | | |
| Safety glasses | | |
| Mandrel | | FSCM 77640 P/N GA1913 |
| Soft hammer | | |
| Torque wrench, 1/2 inch drive, 20 pounds inch capacity | | |
| Two gallon container | | |
| Pressure gage, 0-2000 psi | | |
| Tee | | |

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
	Vehicle parked on level surface, front wheels centered and engine off.
2-58b	Cab tilted 90 degrees. Hydraulic steering lines and fittings removed from power steering gear.
3-28e	Drag link ball socket disconnected from pitman arm on power steering gear.
3-5a	Radiator removed.

Materials/Parts

- | | |
|------------------|---------------------|
| Cleaning solvent | Item 1, Appendix C |
| Clean cloths | Item 2, Appendix C |
| Grease | Item 15, Appendix C |

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Steering gear	a. Nut and large lock washer	Remove	
		b. Pitman arm	Remove	Use mechanical puller
2	Front left frame rail, inside	Four capscrews and lock washers	Remove	Support steering gear



3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

3	Front left frame rail, outside	Steering gear	Remove	
---	--------------------------------	---------------	--------	--



TA236268

DISASSEMBLY


4	Steering gear	a.	Top cover assembly (1) worm shaft	Rotate to "straight ahead" position	Rotate until index mark on sector shaft (2) is perpendicular to centerline of worm shaft
		b.	Six capscrews (3)	Loosen and remove	
		c.	Pitman arm nut	Install	Para 3-28e
		d.	Side cover (4)	Remove	Lightly tap threaded end of sector shaft (2) with a soft hammer to loosen seal ring (5). Drain oil from steering gear before removing side cover (4) and sector shaft (2) as an assembly
		e.	Pitman arm nut	Remove	Para 3-28e
		f.	Seal ring (5)	Remove and discard	

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

KEY

- | | | |
|---------------------------|---------------------|----------------------------|
| 1. Top cover assembly | 11. Housing | 28. Seal ring |
| 2. Sector shaft | 12. Rack piston | 29. Locknut |
| 3. Capscrews (6) | 13. Seal ring | 30. Adjusting screw |
| 4. Side cover | 14. Nut | 31. Back-up washer |
| 5. Seal ring | 15. Adjusting screw | 32. O-ring |
| 6. Seal | 16. Retaining ring | 33. Bearing |
| 7. Socket head screws (4) | 17. Seal | 34. Retaining ring |
| 8. Trunnion cover | 18. Seal ring | 35. Lock washer |
| 9. Capscrews (4) | 19. Washer | 36. Locking screw |
| 10. Washers (4) | 20. Back-up washer | 37. Ball return guides (2) |
| | 21. Vent plug | 38. Ball nut |
| | 22. Bearing | 39. Balls (14) |
| | 23. Retainer | 40. Balls (14) |
| | 24. Thrust insert | 41. Poppet seat |
| | 25. Seal | 42. Lock washer |
| | 26. Seal ring | 43. Poppet |
| | 27. Washer | 44. Seal ring |
| | | 45. O-ring |
| | | 46. Seal |
| | | 47. Seal cup |
| | | 48. Retaining ring |
| | | 49. Retaining washer |
| | | 50. Back-up washer |
| | | 51. Washer |
| | | 52. Seal ring |



TA236108

3-28. STEERING SYSTEM MAINTENANCE (CONT)**d. Power Steering Gear (cont).**

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4 (cont)		g. Seal (6)	Remove	
		h. Four socket head screws (7)	Loosen and remove	
		i. Trunnion cover (8)	Remove	
		j. Four capscrews (9) and washers (10)	Remove	
		k. Top cover assembly (1) worm shaft	Rotate	Until top cover assembly (1) slides 3/4 inch from housing (11). Drain oil from housing before proceeding
		l. Top cover assembly (1) with rack piston (12)	Remove as an assembly	
	m. Seal ring (13)	Remove and discard	From housing (11) or top cover assembly (1)	
5	Sector shaft (2)	a. Nut (14)	Remove	From adjusting screw (15)
		b. Adjusting screw (15)	Turn clockwise	Until side cover (4) disengages from adjusting screw (15) and sector shaft (2)
		c. Retaining ring (16)	Remove	Use retaining ring pliers
		d. Seal (17) and seal ring (18)	Remove and discard	
		e. Washer (19) and back-up washer (20)	Remove	From side cover (4)
		f. Vent plug (21)	Remove and discard	

CAUTION

Do not nick or scratch surface of side cover (4) in following step. Remove bearing (22) only if required for replacement.

g.	Bearing (22)	Remove	From side cover (4) using puller
----	--------------	--------	----------------------------------

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)5
(cont)**NOTE**

Remove retainer (23) and adjusting screw (15) only if required for replacement.

h	Retainer (23)	Remove	Unstake from two locations in sector shaft (2) and unscrew
i	Adjusting screw (15)	Remove	From retainer (23). Discard retainer

NOTE

Do not attempt to remove thrust insert (24). Thrust insert is press fit in the sector shaft (2) and is not serviceable separately.

6	Trunnion cover (8)	a	Seal (25) and seal ring (26)	Remove and discard	
		b	Washer (27)	Remove and discard	
7	Housing (11)	a	Seal ring (28)	Remove and discard	
		b	Locknut (29)	Loosen and remove	From adjusting screw (30)
		c	Adjusting screw (30)	Remove	From housing (11)
		d	Back-up washer (31) and O-ring (32)	Remove and discard	

NOTE

Remove bearing (33) and retaining ring (34) only if necessary for replacement.

e	Bearing (33)	Remove	Press from housing (11)
f	Retaining ring (34)	Remove from bearing (33)	Use retaining ring pliers


3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

8	Rack piston (12)	a. Lock washer (35)	Unlock	Carefully pry flattened tab of lock washer (35) from face of locking screw (36)
---	------------------	---------------------	--------	---



		b. Locking screw (36)	Remove	From rack piston (12)
		c. Lock washer (35)	Remove and discard	

CAUTION

Do not remove the rack piston (12) until you are instructed to do so. The ball nut (38) must be taped to prevent accidental disassembly of the ball return guides (37) and balls (39 and 40) before you remove the rack piston (12).

		d. Rack piston (12)	Rotate	Until teeth are positioned downward
--	--	---------------------	--------	-------------------------------------

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


DISASSEMBLY (cont)

8
(cont)

e. Ball nut (38)

Tape

Carefully disengage rack piston (12) until 1 inch of ball nut (38) is exposed. Wipe exposed surface of ball nut (38) with cleaning solvent P-D-680 and allow to air dry. Then apply cellophane tape over ball return guide (37) opening in ball nut (38) to prevent loss of parts



f Rack piston (12)

Remove

Carefully pull from ball nut (38) and top cover assembly (1) worm shaft


NOTE

Remove poppet seat (41), lock washer (42), and poppet (43) only if required for replacement.

g Lock washer (42)

Unlock

Carefully pry flattened tab of lock washer (42) from face of poppet seat (41)



h. Poppet seat (41) and lock washer (42)

Remove and discard

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
8 (cont)		i Poppet (43)	Remove	From bore in rack piston (12). Discard poppet (43)
NOTE				
Remove seal ring (44) and O-ring (45) only if required for replacement.				
		j Seal ring (44) and O-ring (45)	Remove	Carefully pull from groove at large end of rack piston (12)
9	Top cover assembly (1)	a Seal (46) and seal cup (47)	Remove	Cut, remove, and discard
		b Retaining ring (48)	Remove	Use retaining ring pliers

NOTE

In the following step, set the parts aside in the order and position of removal to aid in reassembly.

c.	Retaining washer (49), back-up washer (50), and washer (51)	Remove	Carefully pull from end of top cover assembly (1) worm shaft
----	---	--------	--

CAUTION

Be sure the cellophane tape and mandrel do not separate from the ball nut (38) in the following step. The ball nut assembly is not serviced separately. If a ball accidentally falls from the ball nut, replace the ball nut, balls, and ball return guides with a new assembly.

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


DISASSEMBLY (cont)

9
(cont)

d. Ball nut (38)

Remove

Press small end of mandrel against hole in end of top cover assembly (1) worm shaft. Maintain pressure against mandrel while rotating ball nut (38) clockwise to remove from worm shaft. When ball nut is fully seated on mandrel, remove mandrel with ball nut and set aside with large end of mandrel positioned on work surface.



e. Seal ring (52)

Remove and discard

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors.

Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
10		a Top cover assembly (1) and ball nut (38)	Clean	Wipe exterior only using a clean, lint free cloth moistened with cleaning solvent P-D-680 Set these assemblies aside and allow to air dry Do not use compressed air to dry these parts
		b Bearings (22 and 33)	Clean	Use cleaning solvent P-D-680. Immerse bearings in cleaning solvent and move slowly up and down until bearings are thoroughly clean Dry using moisture free compressed air Direct air stream across bearing Do not spin bearing while drying Rotate bearing slowly by hand to facilitate drying
		c All other parts	Clean	Use cleaning solvent P-D-680. Dry thoroughly with moisture free compressed air

NOTE

Do not use cloths to dry internal parts.

INSPECTION

11		a Back-up washers (20 and 50) and washers (10, 19, 49, and 51)	Inspect	Replace if cracked, pitted, scored, or excessively worn
		b Retaining rings (16, 34, and 48)	Inspect	Replace if cracked or broken
		c Sector shaft (2)	Inspect	Replace if cracked or bent, if seal area is pitted, corroded, or excessively worn, if gear teeth are chipped or pitted, if serrations are damaged or worn smooth, or if threads are damaged

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
11 (cont)		d Side cover (4) and trunnion cover (8)	Inspect	Replace if cracked or broken, or if lapped face nicked, burred, or scored
		e Top cover as- sembly (1)	a Inspect	Replace if cracked or broken, if lapped face nicked, burred, or scored, if seal area is pitted, corroded, or excessively worn, if gear teeth are chipped or pitted, if ser- rations are damaged or worn smooth, or if threads damaged
			b Check rotation	Grasp top cover assembly (1) while rotating worm shaft with torque wrench Worm shaft should rotate at 3-5 pounds inch

NOTE

The housing will operate satisfactorily even with severe scratches in the rack piston bore. Wear in the rack piston bore is not cause for housing replacement unless it is causing excessive internal leakage.

		f Housing (11)	Inspect	Check that housing is thor- oughly cleaned, and that mating surfaces are free from nicks and burrs. Clean up using a soft hone Replace housing if cracked, or if threads are damaged
		g Bearings (22)	Inspect	Inspect bearing rollers and and 33) cages for wear, chips, nicks, cracks, damage, and distortion If any of these conditions are ob- served, replace bearing. After inspection, immerse bearing in clean hydraulic oil and wrap in clean lintless cloth or paper

3-28. STEERING SYSTEM MAINTENANCE (CONT) I

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
11 (cont)		h Screws (3, 7, 9, 15, 30, and 36) and nuts (14 and 29)	Inspect threads damaged	Replace if worn, or if
		i Seals (6 and 44) and O-ring (45)	Inspect	Replace if cracked, deformed, or excessively worn
		j Rack piston (12)	Inspect	Check that outer ground surfaces are free from nicks and burrs. Clean up using a soft hone. Replace rack piston if cracked, or if threads are damaged
		k Ball nut (38)	Inspect	For completeness Replace as an assembly if ball return guides (37) or balls (39 and 40) have been removed from ball nut (38)

REASSEMBLY

12	Top cover assembly (1)	a Seal ring (52)	Install	Retain using clean grease
----	------------------------	------------------	---------	---------------------------

CAUTION

Be sure the cellophane tape and mandrel do not separate from the ball nut (38) in the following step. If a ball accidentally falls from the ball nut, replace the ball nut, balls, and ball return guides with a new assembly.

		b Ball nut (38)	Install	Press small end of mandrel with ball nut attached against hole in end of top cover assembly (1) worm shaft. Maintain pressure against mandrel while rotating ball nut (38) counterclockwise to install fully on worm shaft. Then remove mandrel
--	--	-----------------	---------	---

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

12
(cont)

NOTE

Install the following six parts on the worm shaft as shown




c	Washer (51)	Install with counter bore side
d	Seal (46)	Install
e	Seal cup (47)	Install with clean grease
f	Back-up washer (50)	Compress the five previously installed parts and install
g	Retaining washer (49)	retaining ring (48) using retaining ring pliers. Be
h	Retaining ring (48)	sure the retaining ring is completely seated in groove of top cover assembly (1) worm shaft and is engaged in recessed area of retaining washer (49)

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
12 (cont)		i Ball nut (38)	Check rotation	Check for bind and completeness of assembly by rotating ball nut clockwise and counterclockwise through its full travel on worm shaft The ball nut must rotate smoothly in both directions at all locations on the worm
		j Seal ring (13)	Install	Coat with clean grease, slide over ball nut (38), and position on top cover assembly (1.)
13	Rack piston (12)	a O-ring (45)	Install	Coat with clean hydraulic oil, and urge onto groove at large end of rack piston (12)
		b Seal ring (44)	Install	Apply degreasing solvent to threads of poppet seat (41) and poppet bore in rack Allow to air dry 10 minutes, then lightly coat threads of poppet seat with stud sealant. Immediately install poppet seat (41) with lock washer (42) and tighten to 25-30 pounds foot . Bend tab of lock washer against face of poppet seat as shown
		c Poppet (43)	Install	
		d Poppet seat (41) and lock washer (42)	Install, tighten, and secure piston (12)	
e Lock (36)		Apply degreasing solvent to threads of locking screw (36) and corresponding bore in rack piston (12). Allow to air dry 10 minutes		



3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

13
(cont)

f Rack piston
(12)

Install


Carefully slide large end of rack piston over worm shaft of top cover assembly (1). Align conical hole in ball nut (38) with locking screw bore in rack piston, and slide ball nut into rack piston until 1 inch of ball nut is exposed. Remove cellophane tape from ball nut, and slide ball nut into rack piston. Be sure conical hole in ball nut is aligned with corresponding bore in rack piston



g Locking screw
(36) and lock
washer (35)

Install,
tighten,
and secure

Lightly coat threads of locking screw (36) with hydraulic sealant. Immediately install locking screw (36) with lock washer (35) and tighten to 30-35 pounds foot. Bend tab of lock washer against face of locking screw as shown



14 Side cover
(4)

b Bearing (22)

Install, if
removed

Press in until flush
Position side cover (4) on wooden block. Press bearing (22) into bore of side cover fully

c Back-up washer
(20)

Install

d Washer (19)

Install

e Seal ring (18)
and seal (17)

Assemble and
install

Position so OIL SIDE stamping is visible after installation

f Retaining ring
(16)

Install

Use retaining ring pliers

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
14 (cont)		g Seal ring (5)	Install	Coat with clean grease, and press into side cover groove
15	Sector shaft (2)	a Sector shaft (2)	Position and clamp	Clamp serrated end in soft-jawed vise so that gear end faces upward
		b Adjusting screw (15)	Install	Coat screw head with wheel bearing grease and press into bore at gear end of sector shaft
		c Retainer (23)	Install	Slide over adjusting screw (15) and thread into sector shaft until adjusting screw has no end play. Then stake retainer to sector shaft at the two slots provided
		d Sector shaft (2)	Position	Coat the adjusting screw end of sector shaft (2) with clean grease, and slide into side cover (4) until adjusting screw (15) contacts side cover
		e Adjusting screw (15)	Turn counter-clockwise	Use a screwdriver to turn adjusting screw until threads engage. Continue turning adjusting screw until firm resistance is felt
		f Nut (14)	Install	Tighten hand tight only
16	Housing (11)	a Retaining ring (34)	Install	On bearing (33) using retaining ring pliers
		b Bearing (33)	Install	Position housing (11) on wooden block to protect side cover face. Press bearing (33) into bore of housing until retaining ring (34) contacts housing
		c Back-up washer (31)	Install	On non-threaded end of adjusting screw (30)
		d O-ring (32)	Install	Thoroughly coat with clean grease and install against back-up washer (31)

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
16 (cont)		e Adjusting screw (30)	Install	Screw into tapped hole in housing until 7/8 inch of thread is exposed
		f Locknut (29)	Install	Tighten hand tight only
		g Rack piston (12)	Install:	Thoroughly lubricate O-ring (45) and bore in housing (11) with clean hydraulic oil. Position rack piston (12) so teeth will be visible through side cover opening in housing. Compress O-ring (45) while sliding rack piston into bore of housing
		h Top cover assembly (1)	Position	Align oil transfer holes in top cover assembly (1) with corresponding holes in housing, then press top cover assembly against housing
		i Four capscrews (9) and washers (10)	Install	Alternately tighten to 70-80 pounds foot
		j Rack piston (12)	Position	Watch rack piston through side cover hole in housing, and rotate rack piston to mark on centerline
		k Sector shaft (2) and side cover (4)	Install	So the center of sector shaft gear engages center of rack piston teeth
		l Six capscrews (3)	Install	Alternately tighten to 150-170 pounds foot
	m Adjusting screw (15)	Adjust:	Rotate worm shaft of top cover assembly (1) 90 degrees each side of center using torque wrench and note indications. Turn adjusting screw (15) clockwise until torque wrench indicates 15-20 pounds inch. Back out adjusting screw one full turn and note torque wrench indications. Then turn adjusting screw clockwise to increase torque 2-4 pounds inch at or below 45 degrees each side of center. Tighten nut (14) to 20-25 pounds foot, and check that input torque at any point of rotation is at or below 15 pounds inch	

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
16 (cont)		n Seal ring (28)	Install	Cover serrations on sector shaft (2) with a single layer of cellophane tape. Lightly coat sector shaft and seal ring (28) with clean grease. Then slide seal ring over sector shaft and position over retaining ring (34)
		o Washer (27)	Install	In trunnion cover (8)
		p Seal ring (26) and seal (25)	Assemble and install	In trunnion cover (8) Position so OIL SIDE stamping is visible after installation
		q Trunnion cover (8)	Install	Slide over sector shaft (2) and position against housing (11). Be sure seal ring (28) is correctly positioned over retaining ring (34)
		r Four socket head screws (7)	Install	Alternately tighten to 13-23 pounds foot
	s Seal (6)	Install	Pack with wheel bearing grease and press over trunnion cover (8). Then remove cellophane tape from sector shaft (2)	

TESTING

WARNING

If steering gear does not pass the following test, it is defective and must not be returned to service. Disassemble the defective steering gear as necessary to replace binding or defective parts; then repeat the tests.

3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TESTING (cont)				
17		Input torque	Test: Rotate top cover assembly (1) worm shaft through five cycles of full rotation and repeat input torque check (step 16m above). Input torque must not exceed 15 pounds inch over full input shaft rotation of 95 degrees and sector shaft must not bind or have lash when in center position	
18		Reverse torque	Test: Rotate sector shaft (2) from stop-to-stop using torque wrench and note indications. Reverse torque for full gear travel must not exceed 50 pounds foot in either direction	

NOTE

If steering gear is to be stored, plug one valve port and fill remaining valve port with clean hydraulic oil. Rotate top cover assembly (1) worm shaft while filling to remove air. Then plug remaining valve port.

INSTALLATION AND ADJUSTMENT

19	Front left frame rail	a	Steering gear	Position	On outside of frame rail, with mounting holes aligned
		b	Four capscrews and lock washers	Install	Tighten alternately to 320 pounds foot
20	Steering gear	a	Sector shaft (2)	Center	Rotate top cover assembly (1) worm shaft fully clockwise to stop; then rotate counterclockwise 3.1 turns to center sector shaft (2)
		b	Pitman arm	Position	Install vertically, with index mark on pitman arm aligned with mark on steering gear shaft

3-28. STEERING SYSTEM MAINTENANCE (CONT) I

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION AND ADJUSTMENT (cont)				
20 (cont)		c Nut and large lock washer	Install	Tighten to 500 pounds foot
		d Hydraulic steering lines and fittings	Connect	Para 2-58b
		e Pressure gage and tee	Connect	To front port on steering gear; then connect pressure hose from power steering pump to tee
21	Tractor, front	a Radiator	Install	Pars 3-5a
		b Cab	Lower	To normal operating position
22	Rear cab guard	Power steering reservoir	Fill	Para 2-58c
23	Tractor, front	a Steering axle stops	Adjust	Para 3-18
		b Drag link	Adjust and connect	Para 3-28e
24	Instrument panel	a Key switch	Turn on	To start engine. Run engine at 1300 rpm
		b Steering wheel	Turn	From side to side several times
25	Steering gear	Pressure gage	Watch	While assistant holds steering wheel at right stop. Pressure gage reading shall drop from about 1750 psi to 1000 psi or less. Then return steering wheel to center position

NOTE

If pressure in previous step did not drop to 1000 psi or less, perform step 26 below. If pressure did drop to 1000 psi or less, go to step 27 below.


3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSTALLATION AND ADJUSTMENT (cont)

26	Steering gear, bottom	a Locknut b Adjusting screw	Loosen Adjust	Until pressure gage reading drops from about 1750 psi to 1000 psi or less while assistant turns steering wheel completely to the right. Then return steering wheel to center position
----	-----------------------	--------------------------------	------------------	---




27	Steering	c Locknut Pressure gage	Tighten Watch	To 20-25 pounds foot While assistant holds steering wheel at left stop. Pressure gage reading shall drop from about 1750 psi to 1000 psi or less. Then return steering wheel to center position
----	----------	----------------------------	------------------	--

NOTE

If pressure in previous step did not drop to 1000 psi or less, perform step 28 below. If pressure did drop to 1000 psi or less, go to step 29.

28	Steering gear, top	a Locknut b Adjusting screw	Loosen Adjust	Until pressure gage reading drops from about 1750 psi to 1000 psi or less while assistant turns steering wheel completely to the left. Then return steering wheel to center position
----	--------------------	--------------------------------	------------------	--



3-28. STEERING SYSTEM MAINTENANCE (CONT)

d. Power Steering Gear (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION AND ADJUSTMENT (cont)				
28 (cont)		c Locknut	Tighten	To 20-25 pounds foot
29	Instrument panel	Key switch	Turn off	Press engine stop button to shut down engine
30	Steering gear	a Two gallon container	Position	Under steering gear
		b Pressure gage and tee	Remove	From pressure line and steering gear port
		c Pressure line	Connect	To steering gear port
		d Two gallon container	Remove	Dispose of used oil properly
31	Rear cab guard	Power steering reservoir	Fill	Para 2-58c

3-277

3-28. STEERING SYSTEM MAINTENANCE (CONT)

e. Steering Linkage and Ball Joints.

- This task covers:
- | | |
|----------------|-----------------|
| a. Removal | d. Inspection |
| b. Disassembly | e. Reassembly |
| c. Cleaning | f. Installation |

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Adjustable open end wrench
- Socket wrench set
- Combination wrench set
- Safety glasses
- Lubricating kit
- Grease gun
- Bit set, screwdriver

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description


Vehicle parked on level surface, engine off, and parking brake applied. Front wheels pointed straight ahead.

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Grease - Item 3, Appendix C
- Cotter pin FSCM 90915 PN 90831083
- Cotter pin

KEY

- | | |
|------------------------|-------------------------|
| 1. Cotter pin | 19. Rubber boot |
| 2. Plug | 20. Capscrew |
| 3. Spring | 21. Lock washer |
| 4. Body | 22. Nut |
| 5. Rubber boot | 23. Lubrication fitting |
| 6. Ball seat | 24. Link |
| 7. Ball seat | |
| 8. Lubrication fitting | |
| 9. Capscrew | |
| 10. Lock washer | |
| 11. Nut | |
| 12. Clamp | |
| 13. Cotter pin | |
| 14. Plug | |
| 15. Spring | |
| 16. Body | |
| 17. Ball seat | |
| 18. Ball seat | |



3-278

TA236220

F

3-28. STEERING SYSTEM MAINTENANCE (CONT)

e. Steering Linkage and Ball Sockets (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Front axle, steering gear	a Rubber boot (5)	Disconnect	Disconnect two metal tabs and open; pull over lubrication fitting (8)
		b Cotter pin (1)	Remove and discard	
		c Plug (2) and spring (3)	Remove	
		d Pitman arm	Move	Move pitman arm forward
		e Body (4) and rubber boot (5)	Remove	Pull from pitman arm ball stud
		f Two ball seats (6 and 7)	Remove	From body (4)
2	Front axle, steering arm	a Rubber boot (19)	Disconnect	Disconnect two metal tabs and open; pull over lubrication fitting (23)
		b Cotter pin (13)	Remove and discard	
		c Plug (14) and spring (15)	Remove	Unscrew
		d Body (16) link (24)	Remove	Slide forward and lift from
		e Two ball seats (17 and 18)	Remove	From body (16)
		f Rubber boot (19)	Remove	From steering arm ball stud

DISASSEMBLY**NOTE**

Do not interchange ball socket parts (1 thru 12 and 13 thru 23) Ball socket assemblies are not identical.

3	Steering linkage	a Lubrication fitting (8)	Remove	From body (4)
		b Capscrew (9), lock washer (10), and nut (11)	Remove	
		c Body (4)	Remove	From link (24)
		d Clamp (12)	Separate	From body (4)

3-28. STEERING SYSTEM MAINTENANCE (CONT)

e. Steering Linkage and Ball Sockets (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3 (cont)		e Capscrew (20), lock washer (21), and nut (22)	Remove	
		f Body (16)	Remove	From link (24)
		g Lubrication fitting (23)	Remove	From plug (23)

CLEANING

4		a Rubber boots (5 and 19)	Clean	Use clean, dry cloth only
---	--	------------------------------	-------	---------------------------

WARNING

Dry cleaning solvent (PD680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately.

If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately. Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

		b All other parts	Clean	Use cleaning solvent P-D-680; dry with compressed air
--	--	-------------------	-------	--

INSPECTION

5		a Ball seats (6, 7, 17, and 18)	Inspect	Replace if cracked, broken, or excessively worn
		b Springs (3 and 15)	Inspect	Replace if cracked, broken, or permanently set

3-28. STEERING SYSTEM MAINTENANCE (CONT)

e. Steering Linkage and Ball Sockets (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
5 (cont)		c All other parts	Inspect	Replace if cracked, broken, bent, distorted, or threads damaged
REASSEMBLY				
6	Steering linkage	a Body (16)	Install	On link (24). Be sure body is installed on correct end of link
		b Capscrew (20), lock washer (21), and nut (22)	Install	Do not tighten
		c Clamp (12)	Install	On body (4)
		d Body (4)	Install	On link (24)
7	Frame, left hand side, front	a Tires and frame rails	Measure	Measure the distance between frame rail and tire at both front and rear, left and right. Adjust front wheels until both measurements agree to within 1/8 inch
		b Pitman arm	Adjust position	Turn steering wheel fully right or left, until steering wheel begins to feel spongy. Then turn wheel 3.1 turns in opposite direction to center pitman arm
INSTALLATION				
8	Front axle, steering arm	a Rubber boot (19) Install		
		b Ball seat (18)	a Lubricate b Install	Use grease On body (16), flat side facing link (24)
		c Body (16)	Install	On steering arm ball stud
		d Ball seat (17)	a Lubricate	Use grease
		b Install		In body (16), concave side facing link (24)
		e Spring (15) and plug (14)	Install and tighten	Tighten plug (14), then back off until slot aligns with body (16) cotter pin hole
f New cotter pin (13)	Install and spread			

3-28. STEERING SYSTEM MAINTENANCE (CONT)

e. Steering Linkage and Ball Sockets (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
9	Front axle, steering gear	a Link (24)	Adjust	Adjust overall length of link until body (4) lubrication fitting opening is centered on ball stud of pitman arm. Be sure bend in link is at center of tractor. Also be sure same amount of link thread is engaged by each ball socket assembly
		b Rubber boot (5)	Install	On pitman arm ball stud
		c Ball seat (7)	a Lubricate	Lubricate Use grease
		b Install facing link (24)	In body (4), flat side	
		d Pitman arm	Move	Move pitman arm forward just enough to allow installation of body (4)
		e Body (4)	Install	On pitman arm ball stud
		f Ball seat (6)	a Lubricate b Install	Use grease In body (4), concave side facing link (24)
		g Spring (3) and plug (2)	Install and tighten	Tighten plug (2), then back off until slot aligns with body (4) cotter pin hole
		h New cotter pin (1)	Install and spread	
		i Capscrew (9), lock washer (10), and nut (11)	Install and tighten	On clamp (12)
		j Lubrication fitting (8)	Install	In body (4)
		k Rubber boot (5)	Secure	Wrap around ball socket assembly and bend tabs to secure
		l Lubrication fitting (8)	Lubricate	Use grease gun and grease
10	Front axle, steering arm	a Capscrew (20) and nut (22)	Tighten	
		b Rubber boot (20)	Secure	Wrap around ball socket assembly and bend tabs to secure
		c Lubrication fitting (23)	a Install b Lubricate	In plug (14) Use grease gun and grease

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Socket wrench set
- Torque wrench
- Vise jaw caps
- Retaining ring pliers
- Puller kit
- Safety glasses
- Automotive Mechanic's Tool Kit
- Hammer
- Drive pin punch
- Soft mallet
- Bronze bar
- Wooden block

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Non-hardening sealant Item 10, Appendix C
- Hydraulic oil Item 22, Appendix C drained.

- Seal kit FSCM 32705 PN 922904
- Manifold kit FSCM 32705 PN 923845
- Washer FSCM 32705 PN 28931
- Locknut FSCM 90915 PN 90002940

Personnel Required

Automotive Repairer MOS 63H

References

LO 9-2320-285-12
(M878A1 Lubrication Order)

Equipment Condition

Paragraph	Condition Description
	Parked on level surface; parking brake applied; engine off.
2-58b	Cab tilted 45 degrees.
	Hydraulic steering lines and fittings removed from pump.
2-58c	Power steering reservoir


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Engine, rear	a	Two capscrews (1) and lock washers (2)	Remove	
		b	Power steering pump assembly (3)	Remove	
		c	Gasket (40) discard	Remove and	
		d	Locknut (42) and washer (41)	Remove	Discard locknut (42)
		e	Gear (11)	Remove	Use gear puller
		f	Key (29)	Remove	

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).



TA236277

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

KEY

1	Capscrews (2)	15	Manifold	29	Key
2	Lock washers (2)	16	Gasket	30	Bearing
3	Power steering pump assembly	17	Capscrews (4)	31	Shaft seal
4	Capscrew	18	Cover	32	Retaining ring
5	Capscrews (4)	19	Spring	33	Bearing
6	Adapter	20	Pressure plate	34	Body
7	Gasket	21	Ring	35	Pin
8	Capscrews (4)	22	Pins (2)	36	Plug
9	Lock washers (5)	23	Rotor	37	O-ring
10	Plate	24	Vanes (10)	38	Control valve
11	Gear	25	O-ring	39	Spring
12	Coupling	26	O-ring	40	Gasket
13	Screw	27	Retaining ring	41	Washer
14	Washer	28	Shaft	42	Locknut

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

1 (cont)	g	Capscrew (4), four cap- screws (5), and five lock washers (9)	Remove	
	h	Adapter (6) and gasket (7)	Remove	Discard gasket (7)
	i	Coupling (12)	Remove	Pull out

CAUTION

In following step, be careful not to drop anything into gear cover. If parts or foreign matter are dropped into gear cover, gear cover must be removed to gain access to, and remove these parts. Failure to do so will cause serious damage to engine.

j	Four capscrews (8)	Remove	Only if drive plate (10) is to be replaced
k	Drive plate (10)	Remove	Only if damaged

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
<u>WARNING</u>				
Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.				
Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.				
2	Power steering pump assembly (3)	a Pump exterior	Clean	Wash exterior using cleaning solvent P-D-680; dry with compressed air
		b Screw (13) and washer (14)	Remove	Discard washer (14)
		c Manifold (15) and gasket (16)	Remove	Discard gasket (16)
		d Power steering pump assembly (3)	Clamp	In soft jawed vise with vise jaws contacting body (34) and capscrews (17) facing up
		e Four capscrews (17)	Remove	
		f Cover (18) and spring (19)	Remove	
		g Ring (21)	Hold securely	
		h Pressure plate (20)	Remove	Lift up over pins (22)
		i Ring (21)	Remove	Lift up over pins (22)
		j. Two pins (22)	Remove	
		k Rotor (23)	Remove	Lift over shaft (28); vanes (24) will fall out

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		l. Ten vanes (24)	Remove	
		m 0-rings (25 and 26)	Remove and discard	
3	Body (34)	a Body (34)	Invert	Remove body from vise. Invert so that retaining ring (27) is facing up. Reclamp in vise
		b Retaining ring (27)	Remove	Use retaining ring pliers
		c Shaft (28)	Remove	Use bronze bar and mallet to tap out
		d Bearing (30)	Remove	Use puller
		e Shaft seal (31)	Remove and discard	
		f Retaining ring (32)	Remove	Use retaining ring pliers
		g Bearing (33)	Remove	Use puller
		h Body (34)	Remove	From vise
4	Cover (18)	a Cover (18)	Clamp	In soft jawed vise
		b Pin (35)	Remove	Use pin punch and hammer to drive out
		c Plug (36) and 0-ring (37)	Remove	Discard 0-ring
		d Control valve (38)	Remove	
		e Spring (39)	Remove	

CLEANING**WARNING**

Dry cleaning solvent (PD680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes .and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

5		a Bearing (33)	Clean	Use cleaning solvent P-D-680. Immerse bearing in cleaning solvent and move slowly up and down. Remove bearing. Strike larger side of cone against block of wood to dislodge solidified particles of lubricant. Immerse again in cleaning solvent. Repeat process until bearing is thoroughly clean. Dry using moisture free compressed air. Direct air stream across bearing. Do not spin bearings when drying. Rotate bearings slowly by hand to facilitate drying
		b All other parts	Clean	Use cleaning solvent P-D-680; dry with compressed air

INSPECTION

6		a Adapter (6) and plate (10)	Inspect	Replace if cracked, broken, or distorted
		b Gear (11) and coupling (12)	Inspect	Replace if cracked, broken, distorted or teeth pitted, nicked, scored, or badly worn

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSPECTION (cont)

6
(cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

c		Manifold (15) and cover (18)	Inspect	Replace if cracked, broken, or distorted. Clean bores with compressed air
d		Springs (19 and 39)	Inspect	Replace if cracked, broken, distorted, or permanently set
e		Pressure plate (20), ring (21), rotor (23), and vanes (24)	Inspect	Inspect surfaces subject to wear. Light scoring may be removed from faces of body or wear plate with crocus cloth (by placing cloth on flat surface), medium India stone or by lapping. Check edges of vanes for wear. Vanes must not have excessive play in slots or burrs on edge. Replace if necessary. Check each rotor slot for sticky vanes or wear. Vanes should drop in rotor slot by their own weight when both slot and vane are dry

NOTE

Replace ring (21), rotor (23), and vanes (24) if inspection indicates any one part needs replacement.

f		Shaft (28)	Inspect	Replace if worn, cracked, broken, distorted, or splines or threads damaged
g		Bearing (30)	Inspect	Replace if cracked, broken, distorted, or worn

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
6		h. Bearing (33)	Inspect	Inspect all rollers, cages (cont) and cups for wear, chips, nicks, cracks, damage, and distortion. If any of these conditions are observed, replace bearing. After inspection, immerse in clean light oil and wrap in clean lintless cloth or paper

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to-eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

i. Body (34)	Inspect	Replace if cracked, broken, distorted, or threads damaged. Clean bores with compressed air
j. Control valve	Inspect	Replace if cracked, broken, (38) or distorted. Check for freedom of movement in bore of cover (18)

REASSEMBLY

NOTE

Immerse all internal parts in clean hydraulic oil before reassembly. Shake off excess oil during reassembly, but don't wipe.

7	Cover (18)	a Cover (18)	Clamp	In soft jawed vise
		b Spring (39), control valve (38), new O-ring (37), and plug (36)	Install	In cover (18)
		c Pin (35)	Install	Use pin punch and hammer
		d Cover (18)	Remove	From vise

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
8	Body (34)	a Bearing (30)	Install	Use suitable sleeve and arbor press
		b New shaft seal (31)	Install	Use suitable sleeve and arbor press
		c Bearing (33)	Install	On shaft (28)
		d Retaining ring (32)	Install	Use retaining ring pliers
		e Body (34)	Clamp	In soft jawed vise
		f Shaft (28)	Install	Use bronze bar and mallet to tap in
		g Retaining ring (27)	Install	Use retaining ring pliers
		h Body (34)	Invert	Remove body from vise and invert. Reclamp vise
9	Body (34)	a New O-rings (26 and 25)	Install	
		b Two pins (22)	Install	
		c Ring (21)	Install	Observe correct direction of rotation
		d Rotor (23)	Install	Spline chamfer down
		e 10 vanes (24)	Install	Install in rotor (23) with rounded edges facing ring (21)
		f Pressure plate (20)	Install	Slide onto pins (22)
		g Spring (19)	Install	
		h Cover (18)	Position	On body (34)
		i Four capscrews (17)	Install	Tighten to 28 pounds foot torque
		j Power steering pump assembly (3)	Remove	From vise
		k New gasket (16)	Position	
		l Manifold (15)	Position	
		m New washer (14)	Position	
		n Screw (13)	Install	Tighten to 95 pounds inch torque
INSTALLATION				
10	Engine rear right side	a Drive plate (10)	Position	If removed

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
10 (cont)		b Four capscrews (8)	Install	Tighten to 35 pounds foot torque
		c Coupling (12)	Install	
		d New gasket (7) and adapter (6)	Position	Apply light coat of gasket sealer to gasket (7)
		e Four capscrews, (5), capscrew (4), and five lock washers (9)	Install	Capscrew (4) installs in bottom hole of adapter (6)
		f Capscrew (4)	Tighten	To 35 pounds foot torque
		g Capscrews (5)	Tighten	To 53 pounds foot torque
11	Power steering pump assembly (3)	a Key (29)	Install	In shaft (28)
		b Gear (11)	Install	
		c Washer (41) and new locknut (42)	Install	
		d Locknut (42)	Tighten	To 70-80 pounds foot torque
12	Engine, rear	a New gasket (40)	a Seal	Apply thin film of non-hardening sealant to both sides
		b Position	On pump (3)	
		b Power steering pump assembly (3) with gasket (40)	Position	
		c Two lock washers (2) and capscrews (1)	Install	Tighten to 35 pounds foot torque
13	Power steering pump (3)	Hydraulic steering fittings and lines	Install and connect	Para 2-58b
14	Steering gear	Hose	Connect	Para 2-58b
15	Rear cab guard	Power steering reservoir	Fill	Use clean hydraulic oil (refer to current lubrication order). Fill to correct level

3-28. STEERING SYSTEM MAINTENANCE (CONT)

f. Power Steering Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
16	Cab	a Tractor engine	Start	Run engine for five minutes to allow hydraulic oil to warm
		b Steering wheel	Rotate	Turn steering wheel through full travel four or five times to bleed air from system and to check operation
		c Tractor engine	Shut down	
17	Engine, rear	All connections	Check	For leaks Tighten fittings as necessary
18	Rear cab guard	Power steering reservoir	Check	Fill with clean hydraulic oil as necessary (refer to current lubrication order)

Section VI. FRAME AND TOWING ATTACHMENTS, SPRINGS, AND BODY AND CAB MAINTENANCE

This section contains the information you will need to maintain the:

- Frame
- Fifth Wheel
- Springs and Spring Seats
- Body and Cab

It gives you instructions on how to troubleshoot problems and repair or replace the components that are within the scope of direct support maintenance.

Troubleshooting Symptom Index	Para 3-29
Fifth Wheel Troubleshooting	3-30
Springs and Spring Seats Troubleshooting.....	3-31
Body and Cab Troubleshooting.....	3-32
Fifth Wheel Maintenance	3-33
Unlatch Cylinder.....	3-33a
Unlatch Valve.....	3-33b
Fifth Wheel	3-33c
Fifth Wheel Boom	3-33d
Springs and Spring Seats Maintenance.....	3-34
Body and Cab Maintenance.....	3-35
Cab Mounts	3-35a
Door	3-35b
Cab and Deck.....	3-35c
Rear Cab Panel	3-35d
Floor Mat.....	3-35e
Windshield	3-35f
Right Side and Rear Window.....	3-35g
Vent Windows.....	3-35h
Seat.....	3-35i
Upper Seat Assembly.....	3-35i(1)
Seat Suspension	3-35i(2)
Cab Tilt	3-35j

3-29 TROUBLESHOOTING SYMPTOM INDEX

FIFTH WHEEL

	Para/Malfunction	Page
Fifth wheel jaws don't open	3-30/1	3-295
SPRINGS AND SPRING SEATS		
Vehicle vibrates excessively during bumps	3-31/1	3-297
Springs squeak or groan	3-31/2	3-297
BODY AND CAB		
Seat squeaks or binds in up and down travel.....	3-32/1	3-297
Seat bounces excessively after a bump, or bottoms or tops out too easily	3-32/2	3-298
Harsh bump when seat bottoms or tops out.....	3-32/3	3-298

3-29. TROUBLESHOOTING SYMPTOM INDEX (CONT)

Para/Malfunction	Page	
Seat binds, or does not, slide smoothly, when adjusted backward or forward	3-32/4	3-298
Weight adjustment handle feels loose, has no tension	3-32/5	3-298
Seat or back cushions are separating from pans	3-32/6	3-299
Seat has collapsed	3-32/7	3-299
Door sticks, or will not open or close.....	3-32/8	3-299
Door window will not raise or lower, or will not travel smoothly	3-32/9	3-300
Right side or rear window will not close fully	3-32/10	3-300
Right side or rear window will not slide or will not slide smoothly	3-32/11	3-301
Cab drafty	3-32/12	3-301
Cab vibrates excessively	3-32/13	3-301

3-30. FIFTH WHEEL TROUBLESHOOTING

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

1. FIFTH WHEEL JAWS DON'T OPEN

Step 1. Check if secondary lock handle is out (unlocked position).

- a. If secondary lock handle is in (locked position), pull hair pin clip from secondary lock handle, pull secondary lock handle out, and reinsert hair pin clip outside fifth wheel plate (prevents secondary lock handle from returning to locked position).
- b. If secondary lock handle is out (unlocked position), proceed to step 2 below.

Step 2. Pull out fifth wheel trip rod fully while watching fifth wheel jaws.

- a. If fifth wheel jaws open, proceed to step 4 below.
- b. If fifth wheel jaws don't open, proceed to step 3 below.

Step 3. Check if fifth wheel jaws are adequately lubricated. Inspect fifth wheel jaw spring.

- a. If fifth wheel jaws are not adequately lubricated, lubricate (para 2-63d).
- b. If fifth wheel jaw spring is broken, replace (para 3-33c).
- c. If fifth wheel jaws are adequately lubricated and fifth wheel jaw spring is not broken, disassemble fifth wheel jaw components and replace as required (para 3-33c).

3-30. FIFTH WHEEL TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. FIFTH WHEEL JAWS DON'T OPEN (Cont)

Step 4. Start vehicle engine and operate at 1200 rpm to build up air system pressure; then check indication on AIR PRESS gage.

- a. If AIR PRESS gage indicates less than 100 psi, troubleshoot air system (refer to para 2-47 or 2-48).
- b. If AIR PRESS gage indicates at least 100 psi, proceed to step 5 below.

WARNING

Wear safety glasses and stand clear when loosening air system fittings. High pressure air can propel debris at high speed, causing eye injury or blindness.

Step 5. Loosen hose connector at fitting on fifth wheel unlatch cylinder (para 3-33a).

Have assistant depress brake pedal and momentarily press FIFTH WHEEL UNLATCH CONTROL; listen for air discharge from loosened hose connector.

- a. If air discharges from loosened hose connector, replace fifth wheel unlatch cylinder (para 3-33a).
- b. If air does not discharge from loosened hose connector, proceed to step 6 below.

WARNING

Wear safety glasses and stand clear when loosening air system fittings. High pressure air can propel debris at high speed, causing eye injury or blindness.

Step 6. Loosen elbow at fifth wheel unlatch valve (para 3-33b). Have assistant depress brake pedal; listen for air discharge from loosened elbow.

- a. If air discharges from loosened elbow, repair fifth wheel unlatch valve (para 3-33b).
- b. If air does not discharge from loosened elbow, troubleshoot air system at brake treadle valve (para 2-47 or 3-21).

3-31. SPRINGS AND SPRING SEATS TROUBLESHOOTING

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. VEHICLE VIBRATES EXCESSIVELY DURING BUMPS

Check if springs are cracked, damaged, or permanently set.

- a. If springs are cracked, damaged, or permanently set, replace both springs (para 3-34).
- b. If springs are not cracked, damaged, or permanently set, troubleshoot shock absorbers (para 2-61).

2. SPRINGS SQUEAK OR GROAN

Step 1. Check if springs are cracked or damaged.

- a. If springs are cracked or damaged, replace both springs (para 3-34).
- b. If springs are not cracked or damaged, proceed to step 2 below.

Step 2. Check if springs are adequately lubricated.
Check if lubrication fittings are damaged.

- a. If springs are not adequately lubricated, lubricate (para 3-34).
- b. If lubrication fittings are damaged, replace (para 3-34).

3-32. BODY AND CAB TROUBLESHOOTING

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. SEAT SQUEAKS OR BINDS IN UP AND DOWN TRAVEL

Step 1. Check for wear on all parts that pivot.

- a. If parts are excessively worn, replace (para 3-35i(1) or 3-35i(2)).
- b. If parts are not excessively worn, proceed to step 2 below.

Step 2. Check shock absorber for leaks.
Remove shock absorber (para 3-35i(2)) and check its operation.

- a. If shock absorber is leaking, replace (para 3-35i(2)).

3-32. BODY AND CAB TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

-
1. SEAT SQUEAKS OR BINDS IN UP AND DOWN TRAVEL (Cont)
 - b. If shock absorber operation is jerky, replace (para 3-35i(2)).

 2. SEAT BOUNCES EXCESSIVELY AFTER A BUMP, OR BOTTOMS OR TOPS OUT TOO EASILY

Check shock absorber for leaks.
Remove shock absorber (para 3-35i(2)) and check its operation.

 - a. If shock absorber is leaking, replace (para 3-35i(2)).
 - b. If shock absorber operation is jerky, replace (para 3-35i(2)).

 3. HARSH BUMP WHEN SEAT BOTTOMS OR TOPS OUT

Step 1. Check for worn, damaged, or missing bottom or topping bumpers.

 - a. If bottom or topping bumpers are worn, damaged, or missing, replace (para 3-35i(1) or 3-35i(2)).
 - b. If bottom and topping bumpers are not worn, damaged, or missing, proceed to step 2 below.

Step 2. Check shock absorber for leaks.
Remove shock absorber (para 3-35i(2)) and check its operation.

 - a. If shock absorber is leaking, replace (para 3-35i(2)).
 - b. If shock absorber operation is jerky, replace (para 3-35i(2)).

 4. SEAT BINDS, OR DOES NOT SLIDE SMOOTHLY, WHEN ADJUSTED BACKWARD OR FORWARD

Check for worn, damaged, or bent parts at roller channels.

If parts are worn, damaged, or bent, replace (para 3-35i(1) or 3-35i(2)).

 5. WEIGHT ADJUSTMENT HANDLE FEELS LOOSE, HAS NO TENSION

Step 1. Check if tension spring is bent, broken, or missing.

 - a. If tension spring is bent, broken, or missing, replace (para 3-35i(2)).
 - b. If tension spring is not bent, broken, or missing, proceed to step 2 below.

3-32. BODY AND CAB TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

5. WEIGHT ADJUSTMENT HANDLE FEELS LOOSE, HAS NO TENSION (Cont)

Step 2. Check if weight adjustment handle does not engage adjuster stud or is broken.

- a. If weight adjustment handle does not engage adjuster stud, reconnect (para 3-35i(2)).
- b. If weight adjustment handle is broken, replace (para 3-35i(2)).

6. SEAT OR BACK CUSHIONS ARE SEPARATING FROM PANS

Check for missing cushion fastener clips.

- a. If cushion fastener clips are missing, replace pan (para 3-35i(1)).
- b. If cushion fastener clips are not missing, disassemble and reassemble cushion and pad on pan (para 3-35i(1)).

7. SEAT HAS COLLAPSED

Check seat suspension metal parts for broken condition.

- a. If parts are broken, replace (para 3-35i(2)).
- b. If parts are not broken, disassemble and reassemble seat suspension; replace missing parts (para 3-35i(2)).

8. DOOR STICKS, OR WILL NOT OPEN OR CLOSE

Step 1. Check outside and inside panels for cracks, damage, or warpage.

- a. If panels are cracked, damaged, or warped, repair or replace (para 3-35b).
- b. If panels are not cracked, damaged, or warped, proceed to step 2 below.

Step 2. Check inner handle, outer handle, lock, and linkage rod assembly for damage.

If parts are damaged, replace (para 3-35b).

3-32. BODY AND CAB TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

9. DOOR WINDOW WILL NOT RAISE OR LOWER, OR WILL NOT TRAVEL SMOOTHLY

Step 1. Check window for obstructions.

- a. If obstructions are found, remove.
- b. If obstructions are not found, proceed to step 2 below.

Step 2. Check if window crank engages window regulator.

- a. If window crank does not engage window regulator, repair (para 3-35b).
- b. If window crank engages window regulator, proceed to step 3 below.

Step 3. Check window regulator for cracks, breaks, or stiff operation.

- a. If window regulator is cracked, broken, or operates stiffly, replace (para 3-35b).
- b. If window regulator is not cracked or broken, and operates smoothly, proceed to step 4 below.

Step 4. Check if glass channel engages window regulator.
Check if window regulator tab or glass channel is broken.

- a. If window regulator tab is not inserted in glass channel slot, insert (para 3-35b).
- b. If window regulator tab or glass channel is broken, replace (para 3-35b).

10. RIGHT SIDE OR REAR WINDOW WILL NOT CLOSE FULLY

Step 1. Check window for obstructions.

- a. If obstructions are found, remove.
- b. If obstructions are not found, proceed to step 2 below.

Step 2. Check if latch parts are bent or damaged.

- a. If latch parts are bent or damaged, replace (para 3-35g).
- b. If latch parts are not bent or damaged, proceed to step 3 below.

3-32. BODY AND CAB TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

-
10. RIGHT SIDE OR REAR WINDOW WILL NOT CLOSE FULLY (Cont)
- Step 3. Check if glass frame or outer frame is bent, damaged, or distorted.
- If glass frame or outer frame is bent, damaged, or distorted, replace (para 3-35g).
11. RIGHT SIDE OR REAR WINDOW WILL NOT SLIDE OR WILL NOT SLIDE SMOOTHLY
- Step 1. Check window for obstructions.
- If obstructions are found, remove.
 - If obstructions are not found, proceed to step 2 below.
- Step 2. Check if glass frame or outer frame is bent, damaged, or distorted.
- If glass frame or outer frame is bent, damaged, or distorted, replace (para 3-35g).
12. CAB DRAFTY
- Step 1. Check cab door felt strips, felt channel, and weatherstrip for distortion, tears, cracks, or excessive wear.
- If felt strips, felt channel, or weatherstrip are distorted, torn, cracked, or excessively worn, replace (para 3-35b).
 - If felt strips, felt channel, and weatherstrip are not distorted, cracked, or excessively worn, proceed to step 2 below.
- Step 2. Check if steering column enclosure is inadequately sealed.
- If steering column is inadequately sealed, seal (para 3-28a).
13. CAB VIBRATES EXCESSIVELY
- Step 1. Check if cab deck latch brackets fully engage hydraulic latches.
- If latch brackets do not fully engage hydraulic latches, troubleshoot cab tilt hydraulic system (para 2-77).
 - If latch brackets fully engage hydraulic latches, proceed to step 2 below.

3-32. BODY AND CAB TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

13. CAB VIBRATES EXCESSIVELY (Cont)

Step 2. Check cab mount locknuts for looseness.

- a. If locknuts are loose, tighten (para 3-35a).
- b. If locknuts are tight, proceed to step 3 below.

Step 3. Check if cab mounts are cracked, torn, deteriorated, or missing.

- a. If cab mounts are cracked, torn, deteriorated, or missing, replace (para 3-35a).
- b. If cab mounts are not cracked, torn, deteriorated, or missing, proceed to step 4 below.

Step 4. Check cab and deck for cracks, breaks, or distortion.

- a. If cab and deck are cracked, broken, or distorted, repair; if beyond repair, replace (para 3-35c).
- b. If cab and deck are not cracked, broken, or distorted, check door and windows for source of vibration; repair if necessary (para 3-35b or 3-35g).

3-33. FIFTH WHEEL MAINTENANCE

- a. Unlatch Cylinder.

This task covers:

- a. Removal
- b. Cleaning
- c. Inspection
- d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Combination wrench set
- Adjustable open end wrench
- Safety glasses

Personnel Required

Wheel Vehicle Mechanic MOS 63B

Equipment Condition

Paragraph Condition Description

Parked on level surface;
parking brake applied; engine
off.

Materials/Parts

Cleaning solvent

Clean cloths

Item 1, Appendix C

Item 2, Appendix C

2-41(1)

All air pressure relieved.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


1	Fifth wheel	a	Air hose (1)	Disconnect	From connector (8)	
		b	Locknut (2) and cap-screw (3)	Remove		
		c	Locknut (4) and cap-screw (5)	Remove		
		d	Unlatch cylinder (6)	Remove		From tractor
		e	Air filter (7)	Remove		Rotate counterclockwise
		f	Connector (8) and elbows (9 and 10)	Remove		

CLEANING

2		a	Air hose (1)	Clean	Wipe with clean cloth moistened with clean diesel fuel
---	--	---	--------------	-------	--



3-33. FIFTH WHEEL MAINTENANCE

a. Unlatch Cylinder (cont).



KEY

- 1. Air hose
- 2. Locknut
- 3. Capscrew
- 4. Locknut
- 5. Capscrew
- 6. Unlatch cylinder
- 7. Air filter
- 8. Connector
- 9. Elbow
- 10. Elbow



3-33. FIFTH WHEEL MAINTENANCE (CONT)

- a. Unlatch Cylinder (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

2
(cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately. Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b	Unlatch cylinder (6)	Clean	Wipe exterior with clean cloth moistened with cleaning solvent P-D-680; dry thoroughly with clean cloths
c	All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air

INSPECTION

3

a	Air hose (1)	Inspect	Replace if cracked, broken, deteriorated, or fittings damaged
b	Unlatch cylinder (6)	Inspect	Replace if leaking, distorted, cracked, welds broken, or otherwise damaged

3-33. FIFTH WHEEL MAINTENANCE (CONT)

a. Unlatch Cylinder (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
3 (cont)		c Air filter (7)	Inspect	Replace if cracked, broken, or plugged
		d All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
INSTALLATION				
4	Unlatch cylinder (6)	a Elbows (9 and 10) and connector (8)	Install and	tighten
		b Air filter (7)	Install	Rotate clockwise
5	Fifth wheel	a Unlatch cylinder (6)	Position	In tractor
		b Capscrew (5) and locknut (4)	Install and tighten to pivot	Do not overtighten; unlatch cylinder (6) must be free
		c Capscrew (3) and locknut (2)	Install and tighten to pivot	Do not overtighten; unlatch cylinder (6) must be free
		d Air hose (1)	Connect	
6	Air tank	Air pressure	Restore	See para 2-41h(l)
7	Tractor cab	Fifth wheel unlatch control	Push	With fifth wheel jaws closed, depress brake pedal and push fifth wheel unlatch control
8	Fifth wheel	Fifth wheel jaws	Observe	Performing step 7 above should open fifth wheel jaws without any binding or sticking

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve.

This task covers:

- | | | | |
|---|-------------|---|--------------|
| a | Removal | d | Inspection |
| b | Disassembly | e | Repair |
| c | Cleaning | f | Reassembly |
| | | g | Installation |

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Combination wrench set
- Knife
- Screwdriver
- Safety glasses

Automotive Mechanic's Tool Kit

- Rule
- Pliers

- | | |
|------------|--------------------------|
| Grommet | FSCM 06853 PN 214749 |
| Seal ring | FSCM 06853 PN 236728 |
| Tie straps | FSCM 96906 PN MS3667-1-9 |

Personnel Required

Two Wheel Vehicle Mechanics MOS 63B

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

Materials/Parts

Cleaning

solvent

Item 1, Appendix C

Clean cloths

Item 2, Appendix C

Tags

Item 14, Appendix C

Lubricant

Item 17, Appendix C

Thread sealant

Item 29, Appendix C

Diesel fuel

Item 45, Appendix C

2-41h(1)

2-63e

2-65d

Parked on level surface, engine off, and parking brake applied.

Cab tilted 45 degrees.

All air pressure relieved.

Boom platform removed.

Heat shield removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


1	Cab, underside, unlatch valve (29)	a	Tie strap (1)	Cut, remove,	Note location for installation and discard	
		b	Connector (3)	Loosen		
		c	Hose (2) with connector (3)	a	Tag	
		b		Disconnect	From fitting (5)	
		d	Elbow (8) nut	Loosen		
		e	Tubing (4) with nut	Tag and	From elbow (8) disconnect	
		f	Fitting (5) and elbow (6)	Remove	From unlatch valve (29); note position of elbow for installation	
		g	Plug (7)	Remove		
		h	Elbow (8)	Remove	Note position of elbow for installation	
i	Four tie straps (9)	Cut, remove,	Note locations for installation and discard			

3-33. FIFTH WHEEL MAINTENANCE (CONT)


b. Unlatch Valve (cont).

KEY

- 1. Tie strap
- 2. Hose (BLK)
- 3. Connector
- 4. Tubing (BLK)
- 5. Fitting
- 6. Elbow
- 7. Plug
- 8. Elbow
- 9. Tie straps (4)
- 10. Nut
- 11. Clamp
- 12. Elbow
- 13. Tie strap
- 14. Nut
- 15. Clamp
- 16. Tie straps (9)
- 17. Connector
- 18. Tie straps (3)
- 19. Nuts (3)
- 20. Clamps (3)
- 21. Screws (2)
- 22. Nuts (2)
- 23. Lock washers (2)
- 24. Guard



- 25. Button
- 26. Nut
- 27. Screws (2)
- 28. Dial plate
- 29. Unlatch valve
- 30. Pin
- 31. Plunger
- 32. Spring
- 33. Grommet
- 34. Nut
- 35. Seal ring
- 36. Spring
- 37. Valve



TA236315

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS	
REMOVAL (cont)					
2	Cab, underside, treadle valve	a Elbow (12) nut	Loosen		
		b Nut (10) and clamp (11)	Remove		
		c Tubing (4) with nuts	a	Disconnect	From elbow (12)
		d Elbow (12)	b	Remove	From tractor
			Remove	From treadle valve; note position of elbow for installation	
3	Cab front, underside	a Tie strap (13)	Cut, remove,	Note location for installation and discard	
		b Nut (14) and clamp (15)	Remove		
4	Cab frame, underside, and rear of cab guard left hand side	Nine tie straps (16)	Cut, remove,	Located between front of and discard	
				frame	
5	Unlatch cylinder, under fifth wheel	a Three tie straps (18)	Cut, remove,	Note locations for installation and discard	
		b Three nuts (19) and clamps (20)	Remove		From fifth wheel boom; note locations for installation
		c Connector (17) with hose (2)	Disconnect	From unlatch cylinder fitting located under fifth wheel	
		d Hose (2) with connectors (3 and 17)	Remove	From tractor as an assembly	
6	Cab tilt pump	Cab Lower	To normal driving position		
7	Tractor cab	a Hood	Open		
		b Two screws (21), nuts (22), and lock washers (23)	Remove	Have assistant remove nuts (22) and lock washers (23) from underside	
		c Guard (24)	Remove		
		d Nut (26)	Remove		
		e Button (25)	Remove	Rotate counterclockwise	
		f Nut (26)	Remove		

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS	
REMOVAL (cont)					
7 (cont)		g Two screws (27) and dial plate (28)	Remove	Have assistant support unlatch valve (29) from underside	
		h Unlatch valve	Remove		
DISASSEMBLY					
8	Unlatch valve (29)	a Pin (30)	Remove	From plunger (31)	
		b Plunger (31)	Remove		
		c Spring (32)	Remove		
		d Grommet (33)	Remove and discard		
		e Nut (34)	Remove		Rotate counterclockwise
		f Seal ring (35)	Remove and discard		
		g Spring (36)	Remove		
		h Valve (37)	Remove		
CLEANING					
9		a Hose (2) and tubing (4)	Clean	Wipe with clean cloth moist- ened with clean diesel fuel; dry with clean cloth	
		b Guard (24), button (25), and dial plate (28)	Clean	Wipe with clean, dry cloth	

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

9
(cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

	c	All other parts	Clean	Use cleaning solvent P-D-680; dry with compressed air
--	---	-----------------	-------	--

INSPECTION

10
observed

	a	Hose (2) with connectors (3 and 17)	Inspect for:	Replace as an assembly if cracks any defects are wear chafing breaks damaged threads
--	---	---	--------------	---

	b	Tubing (4) cracks chafing kinks wear	Inspect for:	Replace if defects are observed Refer to step 11 below for replacement
--	---	--	--------------	--

	c	Unlatch valve (29)	Inspect for:	Replace if defects are cracks observed breaks nicked or pitted sealing surfaces
--	---	-----------------------	--------------	--

does not
plunger
into

	d	Plunger (31)	Inspect for:	Replace if defects observed cracks or if plunger stem breaks move freely when distortion (31) is inserted
--	---	--------------	--------------	---

for
tubing


	e	All other parts	Inspect for:	unlatch valve (29) Replace if defective. Refer cracks to step 11 below breaks replacement of damaged threads elbows (8 and 12)
--	---	-----------------	--------------	--

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REPAIR				
11	Tubing (4)	a. Tubing (4) b. Nut c. Insert	Cut Remove Remove, if	Between nut and sleeve Slide from tubing Pull from tubing only if necessary

separated from fitting



TA236242

NOTE

Repeat steps 11a thru 11d above to disassemble remaining elbow (8 or 12).

determine proper	e	Tubing (4)	Cut to proper	Use new tubing; use old tubing to
	f	Nut	Position	length Slide onto tubing; threaded end out
	g	New sleeve	Position	Slide onto tubing
separated from fitting	h	Insert	Install, if	Push into tubing only if necessary

WARNING

Tubing must be installed over insert for secure connection. Installation of connector without insert will allow air pressure to force tubing from fitting, resulting in dangerous loss of air pressure.

	i	Tubing	Install	Push onto insert until seated inside fitting
	j	Nut	Tighten	Hand tight only; prevents loss of sleeve before installation

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REPAIR (cont)

NOTE

Repeat steps lie thru lid above to install remaining elbow (8 or 12).

REASSEMBLY

NOTE

Apply thin film of lubricant to valve bore and all internal parts before reassembly.

STEP	LOCATION	ITEM	ACTION	REMARKS	
12	Unlatch valve (29)	a Plug (7)	a	Coat threads	Use pipe thread sealant
		b Valve (37)	b	Install	Tighten securely
		c Spring (36)		Install	
		d New seal ring (35)		Install	
		e Nut (34)		Install	Tighten securely
		f New grommet (33)		Install	On plunger (31)
		g Spring (32)		Install	
		h Plunger (31) and pin (30)		Install	

INSTALLATION

STEP	LOCATION	ITEM	ACTION	REMARKS
13	Tractor cab	a Unlatch valve (29)	Install	Have assistant install from underside
		b Dial plate (28) and two screws (27)	Install	
		c Nut (26) and button (25)	Install	
		d Guard (24)	Position	
		e Two screws (21), lock washers (23), and nuts (22)	Install and tighten from underside	Have assistant install lock washers (23) and nuts (22)
		f Hood	Close	
14	Cab tilt pump	Cab	Tilt 45 degrees	

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
15	Cab, underside, unlatch valve (29)	a Elbow (6) and fitting (5)	a	Coat threads Use pipe thread sealant
		b Install noted during removal		Tighten elbow (6) to position
		b Connector (3) with hose (2)	Connect and	To fitting (5) tighten
		c Elbow (8) during removal	Install	Tighten to position noted
		d Elbow (8) nut with tubing (4)	Connect	To elbow (8)
		e Three new tie straps (9)	Install	At locations noted during removal
		f Hose (2) with connectors (3 and 17)	Route	
		g Clamp (15) and nut (14)	Install and	tighten
16	Cab, underside, treadle valve	h New tie strap (13)	Install removal	At location noted during
		a Elbow (12) during removal	Install	Tighten to position noted
		b Elbow (12) nut with tubing (4)	Connect	To elbow (12)
		c Clamp (11) and nut (10)	Install and	tighten
17	Fifth wheel,	d New tie strap (9)	Install removal	At location noted during
		Connector (17) with hose (2) unlatch cylinder	Connect and	To unlatch cylinder fitting tighten
18	Fifth wheel			
		a Hose (2) with connector (3)	Route	Along left hand frame rail
		b Nine new tie straps (16)	Install	Between front of frame and rear of cab guard at locations noted during removal
		c Heat shield	Install	Para 2-65d

3-33. FIFTH WHEEL MAINTENANCE (CONT)

b. Unlatch Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
18 (cont) during		d Three clamps (20) and nuts (19)	Install and	On fifth wheel boom at tighten locations noted
		e Three new tie straps (18)	Install	removal At locations noted during removal
19	Cab tilt pump	Cab	Lower	To normal driving position
20	Tractor	Air pressure	Restore	Para 2-41h(1)
21	Tractor cab	Brake pedal	Depress	Depress brake pedal, push unlatch valve, and check that fifth wheel jaws open
22	Fifth wheel boom	Boom platform	Install	Para 2-63e

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel.

This task covers:	a	Removal	d	Inspection/Repair
	b	Disassembly	e	Reassembly
	c	Cleaning	f	Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Wire brush
- Adjustable open end wrench
- Safety glasses
- Hammer

Automotive Mechanic's Tool Kit

- Pliers
- Punch
- Grease gun

Hoist

Capscrew	FSCM 74410 PN XB2083
Two capscrews	FSCM 74410 PN XB-BR118C7
Two lock washers	FSCM 74410 PN XB-E536
Never-Seez	

Personnel Required

Two Wheel Vehicle Mechanics MOS 63B

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

Parked on level surface; parking brake applied; engine off.

Materials/Parts

Cleaning solvent	Item 1, Appendix C
Clean cloths	Item 2, Appendix C
Grease	Item 3, Appendix C
Engine oil	Item 24, Appendix C
Two cotter pins FSCM 74410 PN XB5	

2-63e	Fifth wheel boom platform removed.
3-33a	Fifth wheel unlatch cylinder removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

WARNING

Fifth wheel weighs 300 pounds. Stand clear of fifth wheel when removing or installing. Failure to follow this procedure could result in severe injury. If you are injured, seek medical attention immediately.

NOTE


Fifth wheel components may be disassembled and repaired with fifth wheel installed on boom. Remove only if replacement of fifth wheel or removal of boom is required.

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel (cont).

KEY

1. Capscrews (2)
2. Lock washers (2)
3. Fifth wheel
4. Capscrew
5. Washers (2)
6. Cam roller
7. Capscrew
8. Locknut
9. Washers (2)
10. Cam roller
11. Cam plate
12. Trip rod
13. Spring
14. Washer
15. Roll pin
16. Torsion spring
17. Secondary lock
18. Handle
19. Sliding yoke
20. Spring
21. Yoke shank
22. Lubrication fittings (2)
23. Cotter pins (2)
24. Lock pins (2)
25. Jaws (2)
26. Spring
27. Bushings (2)



TA236316

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
1	Tractor, rear, fifth wheel (3)	a Suitable hoist	a b	Attach Take strain To fifth wheel (3) To relieve weight of fifth wheel from
	capscrews (1)	b Two capscrews (1) and lock washers (2)	Remove and	discard
		c Fifth wheel (3)	Remove	Lower onto suitable work surface; then detach hoist
DISASSEMBLY				
2	Fifth wheel (3)	a Capscrew (4)	Remove	
		b Two washers (5)	Remove	
		c Cam roller (6)	Remove	
		d Capscrew (7)	Remove and	discard
		e Locknut (8)	Remove	
		f Two washers (9)	Remove	
		g Cam roller (10)	Remove	
		h Cam plate (11)	Remove	From end of trip rod (12)
		i Trip rod (12)	Remove	
		j Spring (13) and washer (14)	Remove	
		k Roll pin (15)	Remove	
		l. Torsion spring (16), secondary lock (17), and handle (18)	Remove	
		m Secondary lock (17) and handle (18)	Separate	
		n Sliding yoke (19)	Remove	
		o Spring (20) and yoke shank (21)	Remove	
		p Two lubrication fittings (22)	Remove	
		q Two cotter pins (23)	Remove and	discard
		r Two lock pins (24)	Remove	
		s Two jaws (25)	Remove	
		t Spring (26)	Remove	

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont) 3	Fifth wheel boom, Use	Two bushings (27)	Remove	Only if inspection indicates need for replacement.
	top rear			suitable drift and hammer to remove

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

4		All parts	Clean	Use cleaning solvent P-D-680 and stiff bristled brush. Dry thoroughly with compressed air or clean cloths
---	--	-----------	-------	---

INSPECTION/REPAIR

5		a Fifth wheel (3)	Inspect	Inspect for broken welds and cracks. Repair by
welding.				Inspect machined top surface for scores and rough spots Repair by
polishing				with crocus cloth or stone. Replace a fifth wheel that is beyond economical
repair				

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION/REPAIR (cont)				
5 (cont)		b Jaws (25)	Inspect	Replace as a set if cracked, broken, worn, or distorted
		c Bushings (27)	Inspect	Replace if cracked, worn, or flat spots. Remove with hammer and sleeve or drift
		d Springs (13, 16, 20, and 26)	Inspect	Replace if cracked, broken, distorted, or permanently set
		e All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
REASSEMBLY				
6	Fifth wheel boom, top rear	Two bushings (27)	Install	Use suitable sleeve and hammer to install, if removed

NOTE

Lightly coat all parts with clean engine oil before reassembly.

7	Fifth wheel (3)	a. Spring (26)	Install	
---	-----------------	----------------	---------	--

NOTE

Lubricate holes in jaws (25) with Never-Seez or equivalent, before installing.

b	Two jaws (25)	a	Lubricate
c	Two lock pins (24)	b	Install
d	Two new cotter pins (23)		Install and spread
e	Trip rod (12)		Push in To latch jaws (25)
f	Two lubrication fittings (22)		Install
g	Spring (20)		Install On yoke shank (21)
h	Yoke shank (21) and sliding yoke (19)		Install

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
7 (cont)		i Handle (18), secondary lock (17), torsion spring (16), and roll pin (15)	Install	
		j Washer (14), spring (13), and trip rod (12)	Install	
		k Cam plate (11)	Install	On end of trip rod (12)
		l. Cam roller (10)	Position	
		m Two washers (9)	Position	
		n New capscrew (7) and locknut (8)	Install	
		o Cam roller (6)	Position	
	p Two washers (5)	Position		
	q Capscrew (4)	Install		

INSTALLATION

8	Tractor, rear, fifth wheel (3)	a Suitable hoist	Attach	To fifth wheel (3)
---	--------------------------------	------------------	--------	--------------------

WARNING

Fifth wheel weighs 300 pounds. Stand clear of fifth wheel when removing or installing. Failure to follow this procedure could result in severe injury. If you are injured, seek medical attention immediately.

		b Fifth wheel (3)	Position	Over boom support brackets, until fifth wheel holes align with bushings (27)
		c Two new cap-screws (1) and lock washers (2)	Install	

3-33. FIFTH WHEEL MAINTENANCE (CONT)

c. Fifth Wheel (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
8 (cont)		d Hoist	Remove	
		e Fifth wheel (3)	Lubricate	Use grease gun and grease to lubricate two lubrication fittings (22)
		f Fifth wheel unlatch cylinder	Install	Para 3-33a
		g Fifth wheel boom platform	Install	Para 2-63e
9	Tractor cab	Fifth wheel control	Depress	Momentarily depress fifth wheel control to check for proper opening of fifth wheel jaws

3-33. FIFTH WHEEL MAINTENANCE (CONT)

d. Fifth Wheel Boom.

This task covers:

- a Removal
- b Cleaning

- c Inspection/Repair
- d Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Adjustable open end wrench
- Safety glasses
- Hammer

Automotive Mechanic's Tool Kit

- Punch
- Hammer

Hoist

Materials/Parts

- Cleaning solvent
- Clean cloths

- Item 1, Appendix C
- Item 2, Appendix C

Equipment Condition

Paragraph Condition Description



	Parked on level surface; parking brake applied; engine off.
2-78b(2)	Hydraulic lines and fittings removed from boom.
2-63e	Boom platform removed.
3-42d	Hydraulic cylinders and pins removed from boom.
3-33a	Fifth wheel unlatch cylinder removed.
3-33c	Fifth wheel removed.
2-34a	Front battery removed.

Personnel Required

Two Automotive Repairers MOS 63H

References

LO 9-2320-285-12
(M878A1 Lubrication Order)



TA236317

KEY

- 1. Lubrication fittings (2)
- 2. Locknut
- 3. Washer
- 4. Pivot shaft
- 5. Boom
- 6. Bushings (2)

3-33. FIFTH WHEEL MAINTENANCE (CONT)

d. Fifth Wheel Boom (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Tractor, rear	a Two lubrication fittings (1)	Remove	
		b Sling	Attach	To center of boom (5)
		c Hoist	Attach	To sling
		d Boom (5)	Raise	To vertical position
		e Locknut (2)	Loosen	Loosen locknut (2) until flush with pivot shaft (4)
		f Locknut (2) and pivot shaft (4)	Tap	Tap with hammer to loosen
		g Locknut (2) and washer (3)	Remove	
		h Pivot shaft (4)	Remove	Slide from tractor
		i Boom (5)	Remove	Lift from tractor
		j Hoist and sling	Detach and remove	

NOTE

Do not remove two bushings (6) unless inspection indicates need for replacement.

k. Two bushings (6)	Remove	Use hammer and suitable sleeve or drift
---------------------	--------	---

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-33. FIFTH WHEEL MAINTENANCE (CONT)

d. Fifth Wheel Boom (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

2		All parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air or clean cloths
---	--	-----------	-------	--

INSPECTION/REPAIR

3		a. Pivot shaft (4)	Inspect	Replace if cracked, broken, or distorted
		b. Boom (5)	Inspect	Inspect for cracks and broken welds. Repair by welding. Replace a boom beyond economical repair
		c. Two bushings (6)	Inspect	Replace if cracked, worn, or flat spotted
		d. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

INSTALLATION

4	Tractor, rear(6)	a. Two bushings	Install	Use suitable sleeve and hammer
		b. Sling	Attach	To center of boom (5)
		c. Hoist	Attach	To sling
		d. Boom (5)	Position	In tractor. Keep boom (5) raised in vertical position
		e. Pivot shaft (4)	Install	Slide into tractor and boom
		f. Washer (3) and locknut (2)	Install	
		g. Boom (5)	Lower	
		h. Hoist and sling	Detach and remove	
		i. Two lubrication fittings (1)	a. Install b. Lubricate	Refer to current lubrication order

3-33. FIFTH WHEEL MAINTENANCE (CONT)

d. Fifth Wheel Boom (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
5	Fifth wheel boom	a. Fifth wheel	Install	Para 3-33c
		b. Fifth wheel unlatch cylinder	Install	Para 3-33a
		c. Hydraulic cylinders	Install	Para 3-42d
		d. Hydraulic lines and fittings	Install	Para 2-78b(2)
		e. Boom platform	Install	Para 2-63e
6	Battery box	Front battery	Install	Para 2-34a
7	Tractor cab	Boom and fifth wheel	Check	For proper operation

3-34. SPRINGS AND SPRING SEATS MAINTENANCE

- This task covers:
- a. Removal
 - b. Cleaning
 - c. Inspection
 - d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Safety glasses
- Combination wrench set
- Adjustable open end wrench

Grease gun

Arbor press

Jack

Soft hammer

Materials/Parts

Cleaning solvent Item 1, Appendix C3-18

Clean cloths Item 2, Appendix C

Grease Item 3, Appendix C

References

LO 9-2320-285-12
(M878A1 Lubrication Order)

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

Parked on level surface;
parking brake applied; engine
off.
Rear wheels blocked.
Front of tractor supported.
Front axle removed.

Personnel Required

Two Automotive Repairers MOS 63H

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

WARNING



Never crawl under equipment when performing maintenance unless equipment is blocked securely. Keep clear of equipment when it is raised or lowered. Do not allow heavy components to swing while suspended by lifting device. Exercise extreme caution when working near a cable or chain under tension. Death or severe injury may result if personnel fail to observe this safety precaution. If you are hurt by a falling object or chain or cable under tension, seek medical aid immediately.

1	Right spring (7), front	<ul style="list-style-type: none"> a. Spring (7) b. Locknut (1) and washer (2) c. Spring pin assembly (3) d. Spring (7) front 	<ul style="list-style-type: none"> Support Remove Remove Lower to 	<ul style="list-style-type: none"> With jack Tap out with soft hammer With jack; then remove jack ground
---	-------------------------------	---	---	---

3-34. SPRINGS AND SPRING SEATS MAINTENANCE (CONT)

KEY

- 1. Locknut
- 2. Washer
- 3. Spring pin assembly
- 4. Locknut
- 5. Washer
- 6. Spring pin assembly
- 7. Spring
- 8. Locknut
- 9. Washer
- 10. Spring pin assembly
- 11. Inner spring shackle
- 12. Shackle assembly
- 13. Lubrication fitting
- 14. Lubrication fittings (2)
- 15. Bushing
- 16. Bushing
- 17. Bushing



TA236363

3-34. SPRINGS AND SPRING SEATS MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2	Right spring (7), rear	a. Spring (7) b. Locknut (4) and washer (5) c. Spring pin assembly (6) d. Spring (7) rear	Support Remove Remove Lower to	With jack Tap out with soft hammer With jack; then remove jack ground
3	Right frame rail	a. Locknut (8) and washer (9) b. Spring pin assembly (10) c. Spring shackles (11 and 12)	Remove Remove Remove	Support shackles (11 and 12); then tap out with soft hammer
4	Spring pins (3, 6, and 10)	Lubrication fittings (13 and 14)	Remove	
5	Spring (7)	Two bushings (15 and 16)	Remove	Drive out with arbor press only if inspection indicates replacement is required
6	Right frame rail	Bushing (17)	Remove	Drive out with suitable sleeve and hammer only if inspection indicates replacement is required

NOTE

Repeat steps 1 thru 6 above for removal of left front spring.

CLEANING

7		a. Bushings (15, 16, and 17)	Clean	Wipe with clean, dry cloth
---	--	------------------------------	-------	----------------------------

3-34. SPRINGS AND SPRING SEATS MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
7 (cont)			<u>WARNING</u>	
		Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.		
		b. All other parts	Clean	Use cleaning solvent P-D-680; dry with clean cloths
INSPECTION				
8		a. Spring pin assemblies (3, 6, and 10)	Inspect	Replace if cracked, scored, corroded, distorted, or threads damaged
		b. Springs (7)	Inspect	Replace as matched pair if either spring is cracked, broken, distorted, or otherwise damaged
		c. Spring shackles (11 and 12)	Inspect	Replace if cracked, corroded, distorted, or mounting holes elongated
		d. Lubrication fittings (13 and 14)	Inspect	Replace if cracked, broken, clogged, or threads damaged
		e. Bushings (15, 16, and 17)	Inspect	Replace if cracked, corroded, scored, excessively worn, or otherwise damaged
		f. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
INSTALLATION				
9	Spring (7)	Two bushings (15 and 16)	Press in	Use arbor press

3-34. SPRINGS AND SPRING SEATS MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSTALLATION (cont)

CAUTION

Exercise care when installing bushing (17) to prevent damage to inside diameter.

10	Right frame rail	a. Bushing (17)	Install	Drive in using suitable sleeve and hammer
----	------------------	-----------------	---------	---

NOTE

In following step, make sure shackle assembly (12) is positioned outside the frame rail, with two bars positioned away from tractor.

		b. Shackle assembly (12) and inner spring shackle (11)	Position	On right frame rail
		c. Spring pin assembly (10)	Install	Secures shackles (11 and 12) to frame rail
		d. Washer (9) and locknut (8)	Install and tighten(10)	Secures spring pin assembly
11	Right spring (7), rear	a. Spring (7) end	a. Raise and support	With jack
		b. Position		Between shackles (11 and 12)
		b. Spring pin assembly (6)	Install	Secures rear of spring (7) to shackles (11 and 12)
		c. Washer (5) and locknut (4)	Install and tighten	Secures spring pin assembly (6)
		d. Jack	Lower and remove	
12	Right spring (7), front	a. Spring (7) end	a. Raise and support	With jack
			b. Position	Between front frame rail mounting weldments
		b. Spring pin assembly (3)	Install	Secures front of spring (7) to front frame rail
		c. Washer (2) and locknut (1)	Install and tighten	Secures spring pin assembly (3)

3-34. SPRINGS AND SPRING SEATS MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
13	Spring pins (3, 6, and 10)	a. Lubrication fitting (13)	Install	In spring pin assembly (3)
		b. Lubrication fittings (14)	Install	In spring pin assemblies (6 and 10)
		c. Lubrication fittings (13 and 14)	Lubricate	Use grease gun (refer to current lubrication order)

NOTE

Repeat steps 9 thru 13 above for installation of left front spring.

14	Front springs (7)	Front axle	Install	Para 3-18
----	----------------------	------------	---------	-----------

3-35. BODY AND CAB MAINTENANCE

a. Cab Mounts.

This task covers: a. Removal c. Inspection
 b. Cleaning d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance
 Tool Kit
 Adjustable open end wrench
 Socket wrench set
 Safety glasses

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description

Materials/Parts

Cleaning solvent Item 1, Appendix C
 Clean cloths Item 2, Appendix C
 Detergent Item 27, Appendix C
 Four wood blocks, Cab tilted 45 degrees.
 2 by 4 by 5 inches

2-65h Vehicle parked on level surface, engine off, and parking brake applied. Cab grille removed. Engine hood open.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Cab, rear	Two capscrews (1) and locknuts (2)	Remove	Have assistant positioned inside cab to remove capscrews (1)
2	Cab tilt pump	Cab	Lower	To normal operating position
3	Cab, right side	Two capscrews (3) and locknuts (4)	Remove	From engine hood posts
4	Cab, front	Three capscrews (5) and locknuts (6)	Remove	

WARNING


When using chain hoist to remove or install parts, be sure chain hoist is securely fastened to the part and that all slack in chain is taken up. Failure to do so could cause serious injury due to the part falling on you. If you are injured by falling equipment, obtain medical aid immediately.

3-35. BODY AND CAB MAINTENANCE

a. Cab Mounts.

KEY

- 1. Capscrews (2)
- 2. Locknuts (2)
- 3. Capscrews (2)
- 4. Locknuts (2)
- 5. Capscrews (3)
- 6. Locknuts (3)
- 7. Cab mounts (7)



TA236222

3-35. BODY AND CAB MAINTENANCE

a. Cab Mounts.

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
5	Cab, top	a. Hoist b. Cab	Attach Raise	Raise cab and insert four wood blocks between cab and cab deck weldment. Then lower cab onto wood blocks
6	Cab deck	Seven cab mounts (7)	Remove	Lift from cab deck weldment
CLEANING				
7		a. Cab mounts (7)	Clean	Wipe with clean cloth moistened with mild detergent solution. Dry thoroughly with clean cloth

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b. Capscrews and locknuts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air
---------------------------	-------	--

3-35. BODY AND CAB MAINTENANCE

a. Cab Mounts.

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION				
8		a. Cab mounts (7)	Inspect	Replace if cracked, torn, or deteriorated
		b. Capscrews and locknuts	Inspect	Replace if cracked, broken, or threads damaged
INSTALLATION				
9	Cab deck weldment	Seven cab mounts (7)	Position	Align cab mount holes with holes in cab deck weldment

WARNING

When using chain hoist to remove or install parts, be sure chain hoist is securely fastened to the part and that all slack in chain is taken up. Failure to do so could cause serious injury due to the part falling on you. If you are injured by falling equipment, obtain medical aid immediately.

10	Cab, top	Cab	Lower	Raise cab, remove wood blocks, and lower cab onto cab mounts
11	Cab, front	Three capscrews (5) and locknuts (6)	Install and tighten	Assistant positioned inside cab
12	Cab, right side	Two capscrews (3) and locknuts (4)	Install and tighten	
13	Cab tilt pump	Cab	Tilt 45 degrees	
14	Cab, rear	Two capscrews (1) and locknuts (2)	Install and tighten	Have assistant positioned inside cab to hold capscrews (1)
15	Cab tilt	Cab	Lower	To normal operating position pump
16	Cab, front	Cab grille	Install	Para 2-65h
17	Cab, right side	Engine hood	Close and latch	

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door.

This task covers: a. Disassembly c. Inspection/Repair
 b. Cleaning d. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Screwdriver
- Safety glasses
- Socket wrench set
- Screwdriver set
- Pop rivet tool 14 feet

Automotive Mechanic's Tool Kit

- Hammer
- Pliers
- Pliers
- Punch

Heavy gloves

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Adhesive Item 11, Appendix C
- Detergent Item 27, Appendix C
- 18 pop rivets FSCM 90915 PN 90004155

- Felt strip, FSCM 90915 PN 90004041
5 feet
- 8 drive rivets FSCM 90915 PN 90005330
- Felt channel, FSCM 90915 PN 90002698
8 feet
- Weatherstrip, FSCM 90915 PN 90004040
FSCM 90915 PN 90831005
- Three cotter pins FSCM 90915 PN 90005292
- Tape, 2 feet

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph	Condition Description
2-65i	Door handle and arm rest removed, door window lowered fully, and door removed from tractor.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY


NOTE

Position door on work surface with inside of door facing up.

1	Door, inside	Screw (1), window crank (2), spring (3), and shield (4)	Remove	
2	Access panel (6)	a. Six capscrews (5) b. Access panel (6) c. Cotter pin (9) and clevis pin (10)	Remove Raise Remove Remove	Discard cotter pin (9)

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).



TA236330

KEY

- | | | |
|-------------------|--------------------|----------------------|
| 1. Screw | 16. Washer | 31. Felt strip |
| 2. Window crank | 17. Capscrews (4) | 32. Window glass |
| 3. Spring | 18. Locknuts (4) | 33. Glass channel |
| 4. Shield | 19. Lock | 34. Tape |
| 5. Capscrews (6) | 20. Cotter pin | 35. Capscrews (4) |
| 6. Access panel | 21. Clevis pin | 36. Nuts (4) |
| 7. Rivets (4) | 22. Clevis | 37. Window regulator |
| 8. Inner handle | 23. Linkage rod | 38. Rivets (4) |
| 9. Cotter pin | 24. Locknut | 39. Felt strip |
| 10. Clevis pin | 25. Lock cylinder | 40. Rivets (10) |
| 11. Clevis | 26. Rivets (4) | 41. Felt channel |
| 12. Capscrews (4) | 27. Outer handle | 42. Weatherstrip |
| 13. Handle box | 28. Capscrews (20) | 43. Outside panel |
| 14. Linkage rod | 29. Inside panel | 44. Capscrews (2) |
| 15. Cotter pin | 30. Rivets (4) | |

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		d. Access panel (6)	Remove	From inside panel (29)
		e. Four capscrews (12)	Remove	
		f. Handle box (13)	Remove	

WARNING

Wear protective goggles when removing rivets. Failure to do so could cause serious injury due to metal chips striking your eyes. If you injure your eyes, obtain medical aid immediately.

		g. Four rivets (7)	Remove	Only if inner handle (8) or handle box (13) require replacement
		h. Inner handle (8)	Remove	Only if inspection indicates need for replacement
3	Inside panel (29)	a. 26 capscrews (28)	Remove	
		b. Two capscrews (44)	Remove	
		c. Inside panel (29)	Remove	

WARNING

Wear protective goggles when removing rivets. Failure to do so could cause serious injury due to metal chips striking your eyes. If you injure your eyes, obtain medical aid immediately.

		d. Four rivets (30)	Remove	Only if felt strip (31) requires replacement
		e. Felt strip (31)	Remove and discard	Only if inspection indicates need for replacement

WARNING

Wear protective goggles and heavy gloves when removing window glass (32). Remove and handle broken glass carefully. Failure to do so could cause serious injury due to glass puncturing or cutting your skin. If you are injured by broken glass, obtain medical aid immediately.

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3 (cont)		f. Window glass (32)	Remove	
		g. Glass channel (33)	Remove	
		h. Tape (34)	Remove and discard	
		i. Four capscrews (35) and nuts (36)	Remove	
		j. Window regulator (37)	Remove	
	4	Lock (19)	a. Cotter pin (15)	Remove and discard
b. Washer (16)			Remove	
c. Linkage rod (14) and clevis (11)			Remove	
d. Clevis (11) and linkage rod (14)			Separate	Pull clevis (11) from linkage rod (14) only if inspection indicates need for replacement of linkage rod (14) or clevis (11)
e. Four capscrews (17) and locknuts (18)			Remove	
f. Lock (19)			Remove	From door
g. Cotter pin (20)			Remove and discard	
h. Clevis pin (21) and clevis (22)			Remove	
i. Linkage rod (23)			Remove	
j. Locknut (24) and lock cylinder (25)			Remove	

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

4
(cont)

WARNING

Wear protective goggles when removing rivets. Failure to do so could cause serious injury due to metal chips striking your eyes. If you injure your eyes, obtain medical aid immediately.

k. Four rivets (26)	Remove	Only if outer handle (27) requires replacement
l. Outer handle (27)	Remove	Only if inspection indicates need for replacement

5 Outside panel (43)

WARNING

Wear protective goggles when removing rivets. Failure to do so could cause serious injury due to metal chips striking your eyes. If you injure your eyes, obtain medical aid immediately.

a. Four rivets (38)	Remove	Only if felt strip (39) requires replacement
b. Felt strip (39) discard	Remove and	Only if inspection indicates need for replacement
c. 10 rivets (40)	Remove	Only if felt channel (41) requires replacement
d. Felt channel (41)	Remove and discard	Only if inspection indicates need for replacement
e. Weatherstrip (42)	Remove and discard	

CLEANING

6

a. Window glass (32)	Clean	Wipe with clean cloth moistened with mild detergent solution. Rinse with clear water; dry thoroughly with clean cloths
b. Glass channel (33)	Clean	Wipe with clean, dry cloth

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

6
(cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

		c. All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air or clean cloths
--	--	--------------------	-------	--

INSPECTION/REPAIR

7

		a. Spring (3)	Inspect	Replace if cracked, broken, or permanently set
		b. Inner handle (8), handle box (13), and outer handle (27)	Inspect	Replace if cracked, broken, or otherwise damaged
		c. Linkage rods (14 and 23)	Inspect or distorted	Replace if cracked, broken,
		d. Lock cylinder (25)	Inspect	Replace if cracked, broken, plugged, or inoperative
		e. Window regulator (37)	Inspect	Replace if cracked, broken, distorted, or does not operate smoothly

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION/REPAIR (cont)				
7 (cont)		f. Inside panel (29) and access panel (6)	Inspect for cracks and dents	Repair cracked metal by welding. Repair small dents by pounding out with hammer and backing block. Clean repaired surfaces of all paint with abrasive cloth; then apply primer and spray paint. Replace a panel beyond economical repair
		g. Felt strips (31 and 39) and felt channel (41)	Inspect	Replace if distorted, torn, cracked, or excessively worn
		h. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
REASSEMBLY				
8	Outside panel (43)	a. New weather-strip (42)	Install	Use adhesive
		b. New felt channel (41)	Position	If removed
		c. 10 new rivets (40)	Install	Use pop rivet tool, if removed
		d. New felt strip (39)	Position	If removed
		e. Four new rivets (38)	Install	Use pop rivet tool, if removed
		f. Outer handle (27)	Position	If removed
		g. Four rivets (26)	Install	Use rivet setter and hammer, if removed
9	Lock (19)	a. Lock cylinder (25)	Position	
		b. Locknut (24)	Install	Secures lock cylinder (25)
		c. Linkage rod (23)	Install	
		d. Clevis (22) and clevis pin (21)	Install	
		e. New cotter pin (20)	Install and spread	

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9 (cont)		f. Lock (19) g. Four capscrews (17) and locknuts (18)	Position Install and	In outside panel (43) Secures lock (19) tighten
10	Inside panel (29)			

WARNING

Wear protective goggles and heavy gloves when handling window glass (32). Handle glass carefully. Failure to do so could cause serious injury if glass breaks and punctures or cuts your skin. If you are injured by broken glass, obtain medical aid immediately.

		a. New tape (34)	Install	
		b. Glass channel (33)	Install	On window glass (32)
		c. Window glass (32)	Position	Against inside panel (29)
		d. New felt strip (31)	Install	If removed
		e. Four new rivets (30)	Install	Use pop rivet tool, if removed
		f. Window regula- tor (37)	Position	Insert tab of window regulator into slot in glass channel (33)
		g. Four capscrews (35) and nuts (36)	Install and	Secures window regulator (37) tighten
		h. Inside panel (29) (32) is lowered fully	Position	Make sure window regulator (37) with window glass
		i. Two capscrews (44)	Install and tighten	
		j. 26 capscrews (28)	Install and	Secures inside panel (29) tighten
11	Access panel (6)	a. Linkage rod (14)	Install	
		b. Washer (16)	Install	
		c. New cotter pin (15)	Install and spread	

3-35. BODY AND CAB MAINTENANCE (CONT)

b. Door (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		d. Handle box (13)	Position	
		e. Four capscrews (12) tighten	Install and	Secures handle box (13)
		f. Inner handle (8)	Position	If removed
		g. Four new rivets (7)	Install	Use rivet setter and hammer, if removed
		h. Clevis (11) and clevis pin (10)	Install	Insert clevis (11) in linkage rod (14), if removed
		i. New cotter pin (15)	Install and spread	
		j. Access panel (6)	Position	
		k. Six capscrews (5)	Install and tighten	Secures access panel (6)
12	Door, inside	Shield (4), spring (3), window crank (2), and screw (1)	Install	
13	Door, sides	Door	Check	Operate lock, window regulator, and inner and outer handles; check for smooth operation
14	Cab, left hand side	Door, handle, and arm rest	Install	Para 2-65i

3-35. BODY AND CAB MAINTENANCE (CONT)

c. Cab and Deck.

This task covers removal and installation of the cab and deck.

INITIAL SETUP

Tools

Lift sling 2-41h(1)
 Hoist, 3000 pound capacity 2-51a

Materials/Parts

Two wood blocks, 2 by 4 by 5 inches 2-53a
 Two wood beams, 4 by 4 inches by 8 feet 2-78a

Personnel Required

Two Automotive Repairers MOS 63H 3-28b

Equipment Condition

Paragraph	Condition Description		
	Vehicle parked on level surface, engine off, and parking brake applied.	2-35e	All air pressure relieved.
2-85	Speedometer cable removed.	2-31f	Air lines disconnected from frame bulkhead fittings and tractor protection valve.
2-34a	Battery ground cable disconnected.	2-35c	Air lines disconnected from frame bulkhead fittings.
2-13a	Air restriction indicator hose removed.	2-70b	Fifth wheel control cable disconnected from fifth wheel control and removed from cab.
2-13e	Throttle linkage cable removed from cab.	2-73b	Universal joint disconnected from power steering gear.
2-15a(1)	Coolant system drained.	3-35g	Fifth wheel unlatch valve hose disconnected and removed from cab.
2-41g(1)	Transmission gear shift control cable disconnected from gear shift control and removed from cab.	3-42b	Ground strap removed.
			Trailer lighting cable disconnected and removed from cab.
			Chassis wiring harness disconnected from cab.
			Inside mirror removed.
			Heater lines disconnected from bottom of cab deck.
			Right side window removed.
			Power take-off cable disconnected and removed from cab.


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Cab tilt pump	a. Cab deck	a. Raise	Enough to disengage deck from cab latches
		b. Block		Insert two wood blocks between cab deck and frame rails to prevent cab from engaging latches
		b. Cab tilt pump	Release	Release all pressure

3-35. BODY AND CAB MAINTENANCE (CONT)

c. Cab and Deck (cont).



TA236224

3-35. BODY AND CAB MAINTENANCE (CONT)

c. Cab and Deck (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2	Cab	a. Two wood beams	Position	Through right side window opening and cab door window opening
		b. Lift sling	a. Position	Above cab
		b. Attach c. Hoist	Attach	To two wood beams To lift sling. Take up slack and check balance
3	Cab deck	a. Tilt cylinder	Disconnect	From cab deck; para 3-43b
		b. Safety bar	Disconnect	Para 3-43e
		c. Cab pivot pins	Remove	Para 2-65k

WARNING

When using hoist to remove or install parts, be sure hoist is securely fastened to the part and that all slack in hoist is taken up. Failure to do so could cause serious injury due to the part falling on you. If you are injured by falling equipment, obtain medical aid immediately.

4	Cab	a. Cab and deck	Remove	Lift carefully and slowly; make sure all cables, hoses, and electrical leads are disconnected
		b. Hoist	Remove	From lift sling
		c. Lift sling	Remove	Support wood beams
		d. Two wood beams	Remove	From cab

INSTALLATION

5	Cab	a. Two wood beams	Position	Through right side window opening and cab door window opening
		b. Lift sling	a. Position	Above cab
		b. Attach c. Hoist	Attach	To two wood beams To lift sling. Take up slack and check balance

3-35. BODY AND CAB MAINTENANCE (CONT)

c. Cab and Deck (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSTALLATION (cont)

WARNING

When using hoist to remove or install parts, be sure hoist is securely fastened to the part and that all slack in hoist is taken up. Failure to do so could cause serious injury due to the part falling on you. If you are injured by falling equipment, obtain medical aid immediately.

6	Tractor frame	Cab and deck	Lower	Position slowly and carefully so pivot pin holes are aligned
7	Cab deck	a. Cab pivot pins	Install	Para 2-65k

NOTE

Keep cab and deck resting on wood blocks for following two steps.

		b. Safety bar	Connect	Para 3-43e
		c. Tilt cylinder	Connect	Para 3-43b
8	Cab	a. Speedometer	Connect	Para 2-85
		b. Hoist	Remove	From lift sling
		c. Lift sling	Remove	Support wood beams
		d. Two wood beams	Remove	From cab
9	Cab tilt pump	Cab and deck	Tilt 45 degrees	
10	Cab and deck	a. Power take-off cable	Install	Para 3-42b
		b. Heater lines	Connect	Para 2-73b
		c. Chassis harness	Connect	Para 2-35c
		d. Trailer lighting cable	Install and connect	Para 2-31f
		e. Ground strap	Connect	Para 2-35e
		f. Fifth wheel unlatch air line	Connect	Para 3-33b

3-35. BODY AND CAB MAINTENANCE (CONT)

c. Cab and Deck (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
10 (cont)		g. Steering column universal joint	Connect	Para 3-28b
		h. Fifth wheel control cable	Connect	Para 2-78a
		i. Air lines	Connect	Para 2-53a
		j. Air lines	Connect	Para 2-51a
		k. Transmission shift cable	Connect	Para 2-41g(1)
		l. Throttle linkage cable	Connect	Para 2-13e
		m. Air restriction indicator hose	Connect	Para 2-13a
		n. Right side window	Install	Para 3-35g
		o. Inside mirror	Install	Para 2-70b
11	Battery box	Battery ground cable	Connect	Para 2-34a
12	Cab tilt	Cab	Lower	To normal operating position pump
13	Radiator	Coolant system	Fill	Para 2-15a(1)

3-35. BODY AND CAB MAINTENANCE (CONT)

d. Rear Cab Panel.

This task covers: a. Removal c. Inspection
 b. Cleaning d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance
Tool Kit
Adjustable open end wrench
Socket wrench set
Safety glasses

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

Materials/Parts

Cleaning solvent Item 1, Appendix C
Clean cloths Item 2, Appendix C
Caulk

Vehicle parked on level surface, engine off, and parking brake applied.
2-65j Rear window guard removed.
3-35g Rear window removed.
2-65m Paper compartment removed.


STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Cab rear, inside	a. 18 capscrews (1) and washers (2)	Remove	
		b. Rear cab panel (3)	Remove	
CLEANING				
2		a. Rear cab panel (3) and cab opening	Clean	Remove caulk by scraping

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-35. BODY AND CAB MAINTENANCE (CONT)

d. Rear Cab Panel (cont).



TA236223

KEY

- 1. Capscrews (18)
- 2. Washers (18)
- 3. Rear cab panel

3-35. BODY AND CAB MAINTENANCE (CONT)

d. Rear Cab Panel (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
2 (cont)		b. Capscrews (1) and washers (2)	Clean	Use cleaning solvent P-D-680 and dry with clean cloths
INSPECTION				
3		a. Rear cab panel (3)	Inspect	Replace if cracked or badly damaged
		b. All other parts	Inspect	Replace if cracked, corroded, or threads damaged
INSTALLATION				
4	Cab rear, inside(3)	a. Rear cab panel	Position	In cab opening
		b. 18 capscrews (1) and washers (2)	Install and tighten	
		c. Caulk	Apply	Apply bead of caulk all the way around seam between rear cab panel and cab
5	Rear cab panel (3), outside	a. Rear window b. Rear window guard	Install Install	Para 3-35g Para 2-65j
6	Rear cab panel (3), inside	Paper compartment	Install	Para 2-65m

3-35. BODY AND CAB MAINTENANCE (CONT)

e. Floor Mat.

- This task covers:
- a. Removal
 - b. Cleaning
 - c. Inspection
 - d. Installation

INITIAL SETUP

Materials/Parts


- Clean cloths Item 2, Appendix C
- Detergent Item 27, Appendix C

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-651	Vehicle parked on level surface, engine off, and parking brake applied. Seat belt floor brackets removed from cab floor.
2-71b	Warning triangle box and mount removed.



3-35. BODY AND CAB MAINTENANCE (CONT)

e. Floor Mat (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Cab floor	Floor mat	Remove	<ul style="list-style-type: none"> a Lift over dimmer switch b Lift over treadle valve c Pull up and away from around seat d Remove from cab
CLEANING				
2		Floor mat	Clean	Use clean cloth moistened with detergent-water solution; allow to air dry
NOTE				
Do not install floor mat until foam backing is completely dry.				
INSPECTION				
3		Floor mat	Inspect	Replace if cracked, torn, or deteriorated
INSTALLATION				
4	Cab floor	a Floor mat	Install	<ul style="list-style-type: none"> a Position around seat b Place over treadle valve c Place over dimmer switch d Smooth out any buckling and tug at floor mat edges to position properly
		b Seat belt floor brackets	Install	Para 2-651
		c Warning triangle mount and box	Install	Para 2-71b

3-35. BODY AND CAB MAINTENANCE (CONT)

- | | | | |
|----------------|-------------------|-------------|-----------------|
| f. Windshield. | This task covers: | a. Removal | c. Inspection |
| | | b. Cleaning | d. Installation |

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit
 Knife
 Safety glasses
 Heavy gloves

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

Vehicle parked on level surface, engine off, and parking brake applied.

Materials/Parts

Clean cloths	Item 2, Appendix C
Detergent	Item 27, Appendix C
Rubber channel	FSCM 90915 PN 90004067

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

WARNING

Wear protective goggles and heavy gloves when removing windshield (1). Do not break glass out of rubber channel (2). Remove and handle broken glass carefully. Failure to do so could cause serious injury due to glass puncturing or cutting your skin.


1	Tractor cab, outside	a	Rubber channel (2) lock tab	Open	Pull rubber channel (2) lock tab open all the way around rubber channel (2)
		b	Rubber channel (2) lip	Peel	Peel rubber channel (2) lip away from top of windshield (1); then, peel away from sides of windshield
		c	Windshield (1)	a Push out b Pull up	Push outward at top of windshield (1) Pull windshield up and out of rubber channel in lower flange area
		d	Rubber channel (2)	c Remove Remove	Remove from windshield opening flange of cab

3-35. BODY AND CAB MAINTENANCE (CONT)

f. Windshield (cont).

KEY

- 1. Windshield**
- 2. Rubber channel**



TA236331

3-35. BODY AND CAB MAINTENANCE (CONT)

f. Windshield (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING				
2	a	Windshield (1)	Clean	Wipe with clean cloth moistened with mild detergent solution Rinse with clear water; dry thoroughly with clean, dry, lintless cloth
		b Rubber channel (2)	Clean	Wipe with clean cloth
INSPECTION				
3		a Windshield (1)	Inspect	Replace if cracked, broken, or distorted
		b Rubber channel (2)	Inspect	Replace if cracked, torn, or deteriorated
INSTALLATION				

NOTE

Perform step 4 below only if rubber channel (2) requires replacement.

4	Tractor cab, inside	New rubber channel (2)	a Position	Position rubber channel (2) in windshield (1) opening flange of cab to determine proper length required
5	Tractor cab, outside	a Rubber channel (2)	b Cut a Lubricate	Cut to proper length Generously lubricate rubber channel (2) with detergent-water solution
			b Install	Install in windshield (1) opening flange

WARNING

Wear protective goggles and heavy gloves when installing windshield (1) Failure to do so could cause serious injury due to glass puncturing or cutting your skin If you are injured by broken glass, obtain medical aid immediately.

3-35 BODY AND CAB MAINTENANCE (CONT)

f. Windshield (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
5 (cont)		b Windshield (1)	Position and hold	Set bottom of windshield in rubber channel from outside of cab. Hold windshield against rubber channel
		c Rubber channel (2) lip	Pull	Pull rubber channel (2) lip over sides of windshield (1); then pull over top of windshield
		d Windshield (1)	Tap	Gently tap windshield with heel of hand to set windshield firmly in position
		e Rubber channel (2) lock tab	Close	Push in lock tab all the way around rubber channel (2)

3-359

3-35. BODY AND CAB MAINTENANCE (CONT)

g. Right Side and Rear Window.

This task covers:

- a. Removal
- b. Disassembly
- c. Cleaning
- d. Inspection
- e. Reassembly
- f. Installation

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit
 Knife
 Screwdriver
 Screwdriver set
 Safety glasses
 Heavy gloves

Personnel Required

Two Wheel Vehicle Mechanics MOS 63B (Metal Work Repairer MOS 44B for glass replacement only)

Equipment Condition

Paragraph	Condition Description
2-65	Vehicle parked on level surface, engine off, and parking brake applied. Rear window guard open (for rear window replacement only).

Materials/Parts

Cleaning solvent	Item 1, Appendix C
Clean cloths	Item 2, Appendix C
Detergent	Item 27, Appendix C
Rubber channel	FSCM 90915 PN 90004067

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

WARNING

Wear protective goggles and heavy gloves when removing glass. Do not break glass out of frame or glazing channels. Remove and handle broken glass carefully. Failure to do so could cause serious injury due to glass puncturing or cutting your skin. If you are injured by broken glass, obtain medical aid immediately.


1	Tractor cab, outside	a	Rubber channel (2) lock tab	Open	Pull open lock tab all the way around rubber channel (2)
		b	Rubber channel (2) lip	Peel	Peel rubber channel (2) lip away from top of outer frame (1); then, peel away from sides of windshield
		c	Outer frame (1)	a Push out b Pull up c Remove	Push outward at top of outer frame (1) Pull outer frame up and out of rubber channel (2) in lower flange area Remove from tractor

3-35. BODY AND CAB MAINTENANCE (CONT)

g. Right Side and Rear Window (cont).

KEY

- 1. Outer frame
- 2. Rubber channel
- 3. Screws (6)
- 4. Latch bases (2)
- 5. Screw
- 6. Stop
- 7. Screws (4)
- 8. End frames (2)
- 9. Center seals (2)
- 10. Glass panels (2)
- 11. Glazing channels (2)
- 12. Screws (4)
- 13. Latch bodies (2)
- 14. Latches (2)
- 15. Springs (2)
- 16. Vinyl channel
- 17. Glass frames (2)



TA236332

3-35. BODY AND CAB MAINTENANCE (CONT)

g. Right Side and Rear Window (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
1 (cont)		d Rubber channel (2)	Remove	Remove from window frame opening flange of cab
DISASSEMBLY				
2	Window assembly	a Outer frame (1)	Lay flat	On flat working surface, with inside of window facing upward
		b Six screws (3) and two latch bases (4)	Remove	
		c Outer frame (1)	Remove	Grasp left hand side of outer frame (1) and carefully spread until front half of window assembly can be separated from outer frame; then slide rear half of window assembly forward and separate from outer frame
		d Screw (5) and stop (6)	Remove	
		e Four screws (7)	Remove	
		f Two end frames (8)	Remove	
		g Two center seals (9)	Remove	Pull from end frames (8)
		h Vinyl channel (16)	Remove	Pull from glass frames (17)
		i Two glass panels (10)	Remove (11)	Slide from glazing channels
		j Two glazing channels (11)	Remove	Pull from glass frames (17)
		k Four screws (12)	Remove	
		l Two latch bodies (13), latches (14), and springs (15)	Remove	

3-35. BODY AND CAB MAINTENAIICE (CONT)

g. Right Side and Rear Window (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING				
3		a All glass, rubber, and vinyl parts	Clean	Wipe with clean cloth moistened with mild detergent solution. Rinse with clear water; dry thoroughly with clean, dry, lintless cloth

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b	All other parts	Clean	Wipe with clean cloth moistened with cleaning solvent P-D-680; dry thoroughly with compressed air or clean cloths
---	-----------------	-------	---

INSPECTION

4	a	Outer frame (1), two glass frames (17), and two end frames (8)	Inspect	Replace if cracked, broken, distorted, or otherwise damaged
---	---	--	---------	---

3-35 BODY AND CAB MAINTENANCE (CONT)

g. Right Side and Rear Window (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
4 (cont)		b Two glass panels (10)	Inspect	Replace if cracked, broken, scratched, or distorted
		c All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
REASSEMBLY				
5	Window assembly	a Vinyl channel (16)	Install	In glass frames (17)
		b Two springs (15), latches (14), and latch bodies (13)	Position	On glass frames (17)
		c Four screws (12)	Install and tighten	
		d Two glazing channels (11)	Install	In glass frames (17)
		e Two glass panels (10)	Install	Slide into glazing channels (11)
		f Two center seals (9)	Install	In end frames (8)
		g Two end frames (8)	Install	
		h Four screws (7)	Install	
		i Screw (5) and stop (6)	Install	
		j Two glass frames (17)	Install	In outer frame (1) Glass frame (17) without stop (6) installs on inside track; glass frame with stop installs on outside track
		k Two latch bases (4)	Position	
l Six screws (3)	Install and tighten			

3-35. BODY AND CAB MAINTENANCE (CONT)

g. Right Side and Rear Window (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
NOTE				
Perform step 6 below only if rubber channel (2) requires replacement.				
6	Tractor cab, inside	New rubber channel (2)	a Position	Position rubber channel (2) in outer frame opening flange of cab to determine proper length required
			b Cut	Cut to proper length
7	Tractor cab, outside	a Rubber channel (2)	a Lubricate	Generously lubricate rubber channel (2) with detergent-water solution
			b Install	Install in outer frame (1) opening flange
		b Outer frame (1)	Install	Set bottom end of outer frame in rubber channel (2) from outside of cab
		c Rubber channel (2) lip	Pull	Pull rubber channel (2) lip over sides of outer frame (1); then pull over top of outer frame
		d Outer frame (1)	Tap	Gently tap outer frame with heel of hand to firmly set outer frame in position
		e Rubber channel (2) lock tab	Close	Push in lock tab all the way around rubber channel (2)
8	Tractor cab	Rear window guard	Install	See para 2-65j, if removed

3-35. BODY AND CAB MAINTENANCE (CONT)

h. Vent Windows.

This task covers:

- a. Removal
- b. Cleaning
- c. Inspection
- d. Installation

INITIAL SETUP:

Tools

No. 1 Common Organizational Maintenance Tool Kit
 Knife
 Safety glasses
 Heavy gloves

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description

Vehicle parked on level surface, engine off, and parking brake applied.

Materials/Parts

Clean cloths Item 2, Appendix C
 Detergent Item 27, Appendix C
 Rubber channel FSCM 90915 PN 90004067

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


WARNING

Wear protective goggles and heavy gloves when removing vent window. Do not break glass out of rubber channel. Remove and handle broken glass carefully. Failure to do so could cause serious injury due to glass puncturing or cutting your skin.

1	Tractor cab, outside	a	Rubber channel lock tab	Open	Pull rubber channel lock tab open all the way around rubber channel
		b	Rubber channel lip	Peel	Peel rubber channel lip away from top of vent window; then, peel away from sides of vent window
		c	Vent window	a Push out b Pull up	Push outward at top of window Pull window up and out of rubber channel in lower flange area
		d	Rubber channel	c Remove Remove	Remove from vent window opening flange of cab

3-35 BODY AND CAB MAINTENANCE (CONT)

h. Vent Windows (cont).



TA236226

3-35 BODY AND CAB MAINTENANCE (CONT)

h. Vent Windows (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING				
2		a Vent window	Clean	Wipe with clean cloth moistened with mild detergent solution. Rinse with clear water; dry thoroughly with clean, dry, lintless cloth
		b Rubber channel	Clean	Wipe with clean cloth
INSPECTION				
3		a Vent window	Inspect	Replace if cracked, broken, or distorted
		b Rubber channel	Inspect	Replace if cracked, torn, or deteriorated

INSTALLATION**NOTE**

Perform step 4 below only if rubber channel requires replacement.

4	Tractor cab, inside	New rubber channel	a	Position	Position rubber channel in vent window opening flange of cab to determine proper length required
			b	Cut	Cut to proper length
5	Tractor cab, outside	a Rubber channel	a	Install	Install in vent window opening flange
			b	Lubricate	Generously lubricate rubber channel with detergent-water solution

WARNING

Wear protective goggles and heavy gloves when installing vent window. Failure to do so could cause serious injury due to glass puncturing or cutting your skin. If you are injured by broken glass, obtain medical aid immediately.

3-35. BODY AND CAB MAINTENANCE (CONT)

h. Vent Windows (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
5 (cont)		b Vent window and hold	Position	From outside of cab, set bottom of vent window in rubber channel Hold vent window against rubber channel
		c Rubber channel lip	Pull	Pull rubber channel lip over sides of vent window; then pull over top of window
		d Vent window	Tap	Gently tap vent window with heel of hand to set window firmly in position
		e Rubber channel lock tab	Close	Push in lock tab all the way around rubber channel

3-369

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat.

(1) Upper Seat Assembly.

This task covers:

- a. Removal
- b. Cleaning
- d. Inspection/Repair
- e. Reassembly

INITIAL SETUP:

Tools

No 1 Common Organizational Maintenance
 Tool Kit rings
 Retaining ring pliers
 Socket wrench set
 Screwdriver 0.005 inch shim stock
 Safety glasses
 Automotive Mechanic's Tool Kit
 Hammer Two Automotive Repairers MOS 63H
 Pliers
 Equipment Condition
 Materials/Parts
 Cleaning
 solvent Item 1, Appendix C
 Clean cloths Item 2, Appendix C
 Detergent Item 27, Appendix C
 Two snap rings

Three snap
 FSCM 71044 PN 24427-801
 Two cotter pins FSCM 71044 PN 359103-002
 Glue

Personnel Required


Paragraph	Condition Description
	2-651 Upper seat assembly and suspension assembly removed from tractor.
	FSCM 71044 PN 25989-801

KEY

- | | | |
|---------------------------|-------------------------------|-------------------------------|
| 1. Screw | 18. Washers(6) | 33. Latch and handle assembly |
| 2. Nut | 19. Right hand roller channel | 34. Spring |
| 3. Spring | 20. Left hand roller channel | 35. Roll pin |
| 4. Rollers(2) | 21. Snap rings(2) | 36. Latch bar |
| 5. Rollers(2) | 22. Shaft | 37. Roll pin |
| 6. Cotter pins(2) | 23. Snap ring | 38. Plastic knob |
| 7. Springs(2) | 24. Endplate | 39. Spring |
| 8. Latch assembly | 25. Spring | 40. Isolation handle |
| 9. Snap rings(2) | 26. Knob assembly | 41. Plate and latch assembly |
| 10. Pivot shaft | 27. Bushing | 42. Rubber bumper |
| 11. Seat cushion assembly | 28. Bushing | 43. Screw |
| 12. Capscrews(4) | 29. Cam assembly | 44. Washer |
| 13. Lockwashers(4) | 30. Cam | 45. Edge welts |
| 14. Washers(4) | 31. Right hand pivot bracket | 46. Back pan |
| 15. Back cushion assembly | 32. Left hand pivot bracket | 47. Cover and pad |
| 16. Capscrews(6) | | 48. Seat cushion pan |
| 17. Lockwashers(6) | | 49. Cover and pad |

i. Seat (cont).

(1) Upper Seat Assembly (cont).



3-371

TA236326

3-35 BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY				
1	Latch assembly (8)	a Latch assembly (8) handle	Pull	Pull to its forward most position
		b Isolation handle (40)	Unlock	
		c Seat pan (48)	Push forward	Push far enough forward to expose screw (1)
		d Screw (1) and nut (2)	Remove	
		e Spring (3)	Remove	
		f Plate and latch assembly (41)	Slide	Slide forward to expose two rollers (4)
		g Two rollers (4)	Remove	
		h Plate and latch assembly (41)	Tilt forward	Tilt forward; then pull rearward to expose two rollers (5)
		i Two rollers (5)	Remove	

NOTE

Be sure springs (7) clear shafts on rear bracket assembly and latch assembly (8) clears rear bracket assembly slot when removing upper seat assembly from suspension assembly.

j	Upper seat assembly	a Remove	Lift upper seat assembly from suspension assembly
		b Invert	Turn upper seat assembly upside down
k	Latch assembly (8) tabs	Bend down	
l	Two springs (7)	Unhook	Unhook front of springs (7) from tabs
m	Two cotter pins (6)	Remove and discard	
n	Two springs (7)	Remove	

3-372

3-35. BODY AND CAB MAINTENANCE (CONT) I

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


DISASSEMBLY (cont)

1
(cont)

o Plate and latch assembly (41)

Insert screwdriver

Insert screwdriver in slot at front of plate and latch assembly as shown. Pry upward on latch bar (36) to allow roll pin (37) in latch bar to clear hole in plate and latch assembly.



NOTE

Latch bar (36) is used for seat tilt adjustment, and roll pin (37) is used to center and hold latch bar.

		p Latch bar (36)	Tap	Continue prying up on latch bar. Tap latch bar to one side until latch bar disengages from slots in latch and handle assembly (33)
2	Cushion assemblies (11 and 15)	a Two snap rings (9) b Pivot shaft (10)	Remove and discard Remove	Use retaining ring pliers

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		c Seat cushion assembly (11)	Lift up	
		d Latch bar (36)	Disengage	From slots in latch and handle assembly (33)
1		e Seat cushion assembly (11)	Remove	
		f Latch assembly (8)	Remove	
		g Four capscrews (12), lock washers (13), and washers (14)	Remove	
		h Back cushion assembly (15)	Remove	
3	Plate and latch assembly (41)	a Six capscrews (16), lock washers (17), and washers (18)	Remove	
		b Two roller channels (19 and 20)	Remove	
		c Two snap rings (21)	Remove and discard	Use retaining ring pliers
		d Shaft (22)	Remove	
		e End plate (24)	Push in	
		f Snap ring (23)	Remove and discard	
		g End plate (24)	Remove	
		h Spring (25)	Remove	
		i Knob assembly (26)	Remove	
		j Cam assembly (29)	Move	Push cam assembly (29) to left
		k Bushing (27)	Remove	
l Cam assembly (29)	Move	Push cam assembly (29) to right		

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3 (cont)		m Bushing (28)	Remove	
		n Cam assembly (29)	Remove	
		o Cam (30)	Remove	
		p Two pivot brackets (31 and 32)	Remove	
4	Latch and handle assembly (33)	a Spring (34)	Unhook	
		b Roll pin (35)	Remove	
		c Latch and handle assembly (33)	Remove	
		d Spring (34)	Remove	
		e Latch bar (36)	Remove	
		f Roll pin (37)	Remove	
		g Plastic knob (38)	Remove	
		h Spring (39)	Remove	Unhook from isolation handle (40) and plate and latch assembly (41)
		i Rubber bumper (42)	Remove	
		j Screw (43) and washer (44)	Remove	
		k Two edge welts (45)	Remove	

NOTE

Do not remove covers and pads (47 and 49) from back pan (46) and seat cushion pan (48) unless inspection indicates need for replacement. If cover and pad is removed, leave clips fastened to pan (46 or 48).

CLEANING

5		a All vinyl, rubber, and plastic parts	Clean	Wipe with clean cloth moistened with mild detergent solution. Rinse thoroughly with clear water; dry thoroughly with clean cloths
---	--	--	-------	---

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

5 (cont)		b Two edge welts (45)	Clean	Wipe with clean, dry cloth
-------------	--	--------------------------	-------	----------------------------

WARNING

Dry cleaning solvent (PD680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately. Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

		c All other parts	Clean	Use cleaning solvent P-D-680; dry with compressed air
--	--	-------------------	-------	---

INSPECTION/REPAIR

6	a	Cushion assemblies (11 and 15)	Inspect for: rips tears worn areas deterioration	Repair small rips or tears by sewing Replace a vinyl cover and pad beyond economical repair
	b	All other parts	Inspect for: cracks breaks distortion damaged threads	Replace if defective

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
NOTE				
Heat back cover (47) with steam, hot air, or infrared lamps prior to and during installation. If these heat sources are not available, place cover in direct sunlight approximately 15 minutes before installation.				
7	Cushion assemblies (11 and 15)	a Cover (47) b Cover and pad (47)	Heat a Glue b Roll over c Fasten	Glue cover and pad to back pan (46) Roll cover over edge of pad Fasten to edge of back pan (46) by inserting plastic welt into clips where provided
8	Latch and handle assembly (33)	a Two edge welts (45) b Washer (44) and screw (43) c Rubber bumper (42) d Spring (39) e Plastic knob (38) f Roll pin (37) g Latch bar (36) (33) h Spring (34) (33) i Latch and handle assembly (33) j Roll pin (35) k Spring (34)	Install Install and tighten Install Install Install Install Install Install Install Attach	In latch and handle assembly On latch and handle assembly
9	Plate and latch assembly (41)	a Two pivot brackets (32 and 31) b Cam (30) c Cam assembly (29)	Position Install a Install b Move	On cam assembly (29) In pivot brackets (31 and 32) Push cam assembly to right

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS		
REASSEMBLY (cont)						
9 (cont)		d Bushing (28)	Install			
		e Cam assembly (29)	Move	Push cam assembly to left		
		f Bushing (27)	Install			
		g Knob assembly (26)	Install			
		h Spring (25)	Install			
		i End plate (24)	Install	Then push in		
		j New snap ring (23)	Install	Use retaining ring pliers		
		k End plate (24)	Release			
		l Shaft (22)	Install			
		m Two new snap rings (21)	Install	Use retaining ring pliers		
		n Two channel rollers (19 and 20)	Position			
		o Six washers (18), lock washers (17), and capscrews (16)	Install and tighten			
		10	Cushion assemblies (11 and 15)	a Back cushion assembly (15)	Position	
				b Four washers (14), lock washers (13), and capscrews (12)	Install and tighten	
11	Plate and latch assembly (41)	a Plate and latch assembly (41)	Tilt forward			
		b Two rollers (5)	Install			
		c Plate and latch assembly (41)	Slide forward			
		d Two rollers (4)	Install			
		e Isolation channels	Adjust			

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)			NOTE	
			Use 0.005 inch shim stock for adjustment.	
		f Plate and latch assembly (41)	Slide forward will go	Slide forward as far as it
		g Isolation handle (40)	Lock out	
		h Three capscrews (16)	Loosen	On left side of plate and latch assembly (41)
		i Shim stock	a Position	Place shim stock between right hand roller channel (19) and right rear roller (4). Push roller channel assemblies together, and tighten capscrew (16) at rear left only
			b Remove	
		j Plate and latch assembly (41)	Slide Slide to rearmost position	
		k Isolation handle (40)	Lock out	
		l Shim stock	a Position	Place shim stock between right hand roller channel (19) and right front roller (5). Push roller channel assemblies together; then tighten two capscrews (16) at left front and center
			b Remove	
		m Isolation handle (40)	Engage	If travel is not satisfactory, readjust to tighten or loosen as required

3-35. BODY AND CAB MAINTENANCE (CONT)

- i. Seat (cont).
- (1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

12 Cushion assemblies (11 and 15)

NOTE

Heat seat cover (49) with steam, hot air or infrared lamps prior to and during installation. If these heat sources are not available, place cover in direct sunlight approximately 15 minutes before installation.

		a Cover (49)	Heat	
		b Cover and pad (49)	a Glue	Glue cover and pad to seat cushion pan (48)
			b Roll over	Roll cover over edge of pad
			c Fasten	Fasten to edge of seat cushion pan (48) by inserting plastic welt into clips where provided
		c Seat cushion assembly (11)	Install	
		d Latch bar (36)	Engage	In slots in latch and handle assembly (33)
		e Latch assembly (8)	Install	
		f Seat cushion assembly (11)	Push down	
		g Pivot shaft (10)	Install	
		h Two new snap rings (9)	Install	Use retaining ring pliers
13	Latch assembly (8)	a Latch bar (36)	Press down	Insert screwdriver in slot at front of plate and latch assembly (41) Press down on latch bar (36); then tap latch bar until it engages in slots in latch and handle assembly (33). Continue pressing down on latch bar until roll pin (37) engages hole in plate and latch assembly (41)

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(1) Upper Seat Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
13 (cont)		b Two springs (7)	Position	
		c Two new cotter pins (6)	Install and spread	
		d Latch assembly (8) tabs	Bend up	
		e Two springs (7)	Attach	
		f Upper seat assembly	Install	On suspension assembly
		g Spring (3)	Install	
		h Capscrew (1) and nut (2)	Install and tighten	
14	Cab floor, inside	Upper seat assembly and suspension assembly	Install	Para 2-65g

3-35 BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension.

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly

INITIAL SETUP

Tools

No 1 Common Organizational Maintenance Tool Kit

- Retaining ring pliers
- Socket wrench set
- Screwdriver
- Safety glasses

Automotive Mechanic's Tool Kit

- Hammer
- Pliers
- Punch

Wood block, 2 by 4 by 5 Punch

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Detergent Item 27, Appendix C

- Snap ring FSCM 71044 PN 26343-801
- Two roll pins FSCM 71044 PN 22705-801
- Two roll pins FSCM 71044 PN 22526-801
- Nine roll pins FSCM 71044 PN 22525-801
- Drive lock pin FSCM 71044 PN 24129-801

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-651	Upper seat assembly and suspension assembly removed from tractor.
3-35i(1)	Upper seat assembly removed.


KEY

- | | | |
|--------------------------|-----------------------------|------------------------------|
| 1 Springs (2) | 25 Ball bearing | 48 Center pins (2) |
| 2 Locknut | 26 Insert | 49 Upper pivot arm |
| 3 Nut | 27 Pivot bushing | 50 Pivot arm assembly |
| 4 Washer | 28 Roll pin | 51 Flanged bearing |
| 5 Spacer | 29 Weight adjustment handle | 52 Locknut |
| 6 Snap rings (2) | 30 Drive lock pin | 53 Thrust washer |
| 7 Roll pin | 31 Roll pin | 54 Nut |
| 8 Pivot lever assembly | 32 Roll pins (2) | 55 Capscrew |
| 9 Wear plate | 33 Lower hinge pin | 56 Roll pin |
| 10 Clevis pin | 34 Upper hinge pin | 57 Miter gear |
| 11 Spacer | 35 Lower arm assembly | 58 Height adjustment handle |
| 12 Washer | 36 Rubber spring assembly | 59 Flanged bearing |
| 13 Rubber spacer | 37 Roll pin | 60 Thrust washer |
| 14 Shock absorber | 38 Adjuster clevis | 61 Vertical adjuster bracket |
| 15 Capscrew | 39 Flanged bearings (2) | 62 Roll pin |
| 16 Nut | 40 Flanged bearings (4) | 63 Tube |
| 17 Lock washer | 41 Flanged bearing | 64 Thrust washer |
| 18 Release lever | 42 Upper arm assembly | 65 Roll pin - |
| 19 Roll pins (2) | 43 Flanged bearings (2) | 66 Miter gear |
| 20 Hinge pins (2) | 44 Flanged bearings (4) | 67 Adjuster stud |
| 21 Rear bracket assembly | 45 Rubber bumper | 68 Base- |
| 22 Roll pin | 46 Roll pin | 69 Spring support bracket |
| 23 Adjuster stud | 47 Roll pin | |
| 24 Washers (2) | | |

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).



TA236328

3-35 BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS	
DISASSEMBLY					
1	Shock absorber (14)	a	Height adjustment handle (58)	Turn raise shock absorber rod to its highest position	Turn handle clockwise to its highest position
		b	Two springs (1)	Remove	
		c	Locknut (2)	Remove	
		d	Nut (3), washer (4), and spacer (5)	Remove	
		e	Shock absorber (14) rod	Push down	
		f	Two snap rings (6)	Remove and discard	Use retaining ring pliers
		g	Roll pin (7)	Remove and discard	
		h	Pivot lever assembly (8)	Remove	
		i	Wear plate (9)	Remove	
		j	Clevis pin (10)	Remove	
		k	Spacer (11), washer (12), rubber spacer (13), and shock absorber (14)	Remove	
		l	Capscrew (15), nut (16), and lock washer (17)	Remove	
		m	Release lever (18)	Remove	
2	Rear	a	Two roll pins bracket assembly (21)	Remove and (19)	discard

CAUTION

One end of each hinge pin (20) is serrated. Do not drive serrated end of hinge pin through rear bracket assembly (21).

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		b. Two hinge pins (20)	Remove	Use suitable drift and hammer. Drive hinge pins (20) out through right side of rear bracket assembly (21)
		c. Rear bracket assembly (21)	Remove	Lift off
3	Spring support bracket (69)	a. Roll pin (22)	Remove and discard	
		b. Adjuster stud (23)	Remove	Rotate counterclockwise
		c. Two washers (24)	Remove	
		d. Ball bearing (25), insert (26), and pivot bushing (27)	Remove	
		e. Roll pin (28)	Remove and discard	
		f. Weight adjustment handle (29)	Remove	
		g. Drive lock pin (30)	Remove and discard	
		h. Three roll pins (31 and 32)	Remove and discard	

CAUTION

One end of each hinge pin (33 and 34) is serrated. Do not drive serrated end of hinge pin through spring support bracket (69) assembly.

i.		Two hinge pins (33 and 34)	Remove	Use suitable drift and hammer. Drive hinge pins (33 and 34) out through left side of spring support bracket (69) assembly
j.		Spring support bracket (69)	Swing down	

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4	Arm assemblies (35, 42, and 50)	a. Lower arm assembly (35) and rubber spring assembly (36)	Remove	
		b. Roll pin (37)	Remove and discard	
		c. Adjuster clevis (38)	Remove	

NOTE

Do not remove two flanged bearings (39), four flanged bearings (40), or flanged bearing (41) unless inspection indicates need for replacement.

d. Upper arm assembly (42)	Remove
----------------------------	--------

NOTE

Do not remove two flanged bearings (43) or four flanged bearings (44) unless inspection indicates need for replacement.

e. Rubber bumper (45)	Remove
f. Two roll pins (46 and 47)	Remove and discard
g. Two center pins (48)	Remove
h. Upper pivot arm (49)	Remove
i. Pivot arm assembly (50)	Remove

NOTE

Do not remove flanged bearing (51) unless inspection indicates need for replacement.

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5	Vertical adjustment bracket (61)	a. Locknut (52) and thrust washer (53)	Remove	
		b. Nut (54) and capscrew (55)	Remove	
		c. Roll pin (56)	Remove and discard	
		d. Miter gear (57)	Remove	
		e. Height adjustment handle (58) and flanged bearing (59)	Remove	
		f. Thrust washer (60)	Remove	
		g. Vertical adjustment bracket (61)	Remove	
6	Base (68)	a. Roll pin (62)	Remove and discard	
		b. Tube (63)	Remove	
		c. Thrust washer (64)	Remove	
		d. Roll pin (65)	Remove and discard	
		e. Miter gear (66)	Remove	
		f. Adjuster stud (67)	Remove	
CLEANING				
7		a. All vinyl, rubber, and plastic parts	Clean	Wipe With clean cloth moistened with detergent solution. Rinse thoroughly with clear water; dry thoroughly with clean cloths

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

b. Shock absorber (14)	Clean	Wipe exterior with clean cloth moistened with cleaning solvent P-D-680; dry with clean cloths
c. All other parts	Clean	Use cleaning solvent P-D-680; dry with clean cloths

INSPECTION

8	a. Two springs (1)	Inspect	Replace if cracked, broken, distorted, or permanently set
	b. All bearings	Inspect	Replace if cracked, worn, distorted, or flat spotted
	c. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

9	Base (68)	a. Adjuster stud (67)	Install	In tube (63)
		b. Miter gear (66)	Install	
		c. New roll pin (65)	Install	
		d. Thrust washer (64)	Install	

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9 (cont)		e. Tube (63) f. New roll pin (62)	Position Install	In base (68)
10	Vertical adjustment bracket (61)	a. Vertical adjustment bracket (61) b. Thrust washer (60) c. Flanged bearing (59), height adjustment handle (58), miter gear (57), and new roll pin (56) d. Capscrew (55) and nut (54)	Position Position Install Install	
11	Arm assemblies (35, 42, and 50)	a. Pivot arm assembly (50) b. Upper pivot arm (49) c. Two center pins (48) d. Two new roll pins (47 and 46) e. Rubber bumper (45) f. Base (68) g. Thrust washer (53) and locknut (52) h. Adjuster clevis (38)	Position Position Install Install Install Install Install Position	In base (68) In base (68) In spring support bracket (69). Exercise care to guide adjuster stud (67) through vertical adjustment bracket (61) In rubber spring assembly (36)

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		i. New roll pin (37)	Install	
		j. Rubber spring assembly (36)	Install	In lower arm assembly (35)

NOTE

Be sure flanged bearing (41) is installed in rubber spring assembly (36), and flanged bearings (40 and 39) are installed in lower arm assembly (35).

12	Spring support bracket (69)	a. Spring support bracket (69)	Raise	
		b. Lower arm assembly (35), pivot arm (50), and flanged bearing (51)	Install	

NOTE

Be sure adjuster clevis (38) is on top of pivot arm (50) before proceeding.

		c. Lower hinge pin (33)	Install	Insert from left side of spring support bracket (69)
		d. New roll pin (31)	Install	

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

12
(cont)

e. 2 by 4 by 5
inch wood
block

Position

Under support rod of lower
arm assembly (35) as shown.
Wood block holds lower arm
assembly in raised position
and also raises adjuster
clevis (38) to permit
installation of adjuster
stud (23)



f. Screwdriver

Insert

Insert screwdriver, and raise
rubber spring assembly (36)
as shown

g. New drive lock
pin (30)

Install

In adjuster stud (23)

h. Pivot bushing
(27) and
insert (26)3-391

Install

i. Ball bearing
(25) and two
washers (24)

Install

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
12 (cont)		j. Adjuster stud (23)	Install	Rotate clockwise
		k. New roll pin (22)	Install	
		l. Weight adjustment handle (29)	Install	
		m. New roll pin (28)	Install	
13	Rear bracket	a. Upper arm assembly (42) assembly (21)	Position	In rear bracket assembly (21)

NOTE

Be sure flanged bearings (43 and 44) are installed in upper arm assembly (42).

b. One hinge pin (20)	Install	Insert from right side of rear bracket assembly (21)
c. One new roll pin (19)	Install	
d. Lower arm assembly (35)	Position	In rear bracket assembly (21)
e. One hinge pin (20)	Install	Insert from right side of rear bracket assembly (21)
f. One new roll pin (19)	Install	
g. Upper arm assembly (42)	Position	In spring support bracket (69)

NOTE

Insert upper hinge pin (34) from left side of spring support bracket (69).

h. Upper hinge pin (34)	Install	From left side of spring support bracket (69)
i. Two new roll pins (32)	Install	

3-35. BODY AND CAB MAINTENANCE (CONT)

i. Seat (cont).

(2) Seat Suspension (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
14	Shock absorber (14)	a. Release lever (18) b. Capscrew (15) lock washer (17), and nut (16) c. Shock absorber (14), rubber spacer (13), washer (12), and spacer (11) d. Wear plate (9) and pivot lever assembly (8) e. Clevis pin (10) and new roll pin (7) f. Two new snap rings (6) g. Spacer.(5) and washer (4) h. Nut (3) i. Locknut (2) j. Two springs (1)	Position Install Install Position Install Install Install Install Install	In rear bracket assembly (21) Use retaining ring pliers Install hand tight only, so shock absorber (14) can't pivot
15	Seat suspension	Upper seat assembly	Install	Para 3-35i(1)
16	Cab, inside	Upper seat assembly and suspension assembly	Install	Para 2-651

3-35. BODY AND CAB MAINTENANCE (CONT)

j. Cab Tilt. This task covers tilting cab 90 degrees.

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit
 Socket wrench set
 Come-a-long (block-and-tackle device)

Personnel Required

Four Automotive Repairers MOS 63H


Equipment Condition

Paragraph Condition Description

Materials/Parts

Cleaning solvent Item 1, Appendix C
 Clean cloths Item 2, Appendix C
 Thread sealant Item 29, Appendix C

Parked on level surface;
 parking brake applied; engine
 off.
 Cab tilted 45 degrees.



TA236157

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------



TILTING CAB TO 90 DEGREES

1	Frame rail, right side	a. Capscrew (1)	Remove	From safety bar (2)
		b. Tilt pump control valve	Turn counter-clockwise	
2	Frame rail, left side	a. Nut (3), cap-screw (4), and pin (5)	Remove cylinder (6)	From top of cab tilt

3-35. BODY AND CAB MAINTENANCE (CONT)

j. Cab Tilt (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TILTING CAB TO 90 DEGREES (cont)				
2 (cont)		b. Cab tilt cylinder (6) c. Nut (7) and capscrew (8)(9) d. Steering joint assembly (9)	Push down on rod Remove Pull up	Swing cylinder out of way From steering joint assembly From steering gear box





3 Cab deck, left side

a. Nut (11) and clamp (12)

Remove

From bottom of cab deck




TA236321

3-35. BODY AND CAB MAINTENANCE (CONT)

j. Cab Tilt (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TILTING CAB TO 90 DEGREES (cont)				
3 (cont)		b. Two tie straps (13 and 14) c. Come-a-long (15) hook	Cut, remove and discard Attach	To bracket (16)



4	5th wheel boom	a. Come-a-long (15) hook b. Come-a-long (15)	Attach a. Release b. Lock	To crossmember (17) Provide some slack Prevents cable slippage
---	----------------	---	-------------------------------------	--

NOTE

Four personnel are required to perform the following step.

3-35. BODY AND CAB MAINTENANCE (CONT)

j. Cab Tilt (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
TILTING CAB TO 90 DEGREES (cont)				
5	Tractor, front	a. Cab and deck b. Safety bar (2)	Pull forward Lift	Raise out of first notch, past second notch, until downward weight of cab is supported entirely by come-a-long
6	5th wheel boom	Come-a-long (15)	a. Release b. Check c. Remove	Gradually release until cab is tilted 90 degrees, and safety bar (2) rests in third notch Come-a-long must be slack, with all weight of cab and deck resting on safety bar From tractor
LOWERING CAB TO 45 DEGREES				
1	Cab deck, left side	One come-a-long (15) hook	Attach	To bracket (16)
2	5th wheel boom	Come-a-long (15)	Attach hook	To crossmember (17)
NOTE				
Four personnel are required to perform the following step.				
3	Tractor, front	a. Cab and deck b. Come-a-long (15) c. Cab and deck	Hold forward Tighten Release	Prevents cab from falling back to 45 degree position Raise cab from 90 degree to 45 degree position After safety bar (2) drops into its first notch
4	Frame rail, right side	a. Safety bar (2) b. Capscrew (1)	Check a. Seal b. Install	All weight of cab must rest on safety bar, and come-a-long must be slack Apply thread sealant threads On safety bar; tighten

3-35. BODY AND CAB MAINTENANCE (CONT)

j. Cab Tilt (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
LOWERING CAB TO 45 DEGREES (cont)				
5	5th wheel boom	Come-a-long (15)	Remove	From tractor
6	Cab deck, left side	a. Nut (11) and clamp (12)	Install	At bottom of cab deck
		b. Two new tie straps (13 and 14)	Install	
7	Frame rail, left side	a. Steering joint assembly (9)	Position	On steering gear box
		b. Nut (7) and capscrew (8)	Install and tighten	On steering joint assembly (9)
		c. Cab tilt cylinder (6)	Pull up on rod	Swing cylinder into position
		d. Nut (3), capscrew (4), and pin (5)	Install and tighten	Through top of cab tilt cylinder (6)
8	Cab tilt pump	Cab	Lower	To normal operating position

Section VII. ACCESSORIES MAINTENANCE

This section contains the information you will need to maintain the cab heater.

It gives you instructions on how to troubleshoot problems and repair or replace the components that are within the scope of direct support maintenance.

Troubleshooting Symptom Index	Para 3-36
Heater Troubleshooting	3-37
Heater Maintenance	3-38

3-36. TROUBLESHOOTING SYMPTOM INDEX

	Para/Malfunction	Page
HEATER		
Cab heater doesn't heat cab	3-37/1	3-399
Fresh air door will not open or close	3-37/2	3-400
Windshield will not defrost	3-37/3	3-400

3-37. HEATER TROUBLESHOOTING

MALFUNCTION		
TEST OR INSPECTION		
CORRECTIVE ACTION		

1. CAB HEATER DOESN'T HEAT CAB

- Step 1. Remove motor (para 3-38).
 Connect 12 Vdc power source to motor electrical leads.
 Check if motor shaft rotates.
 - a. If motor shaft does not rotate, replace motor (para 3-38).
 - b. If motor shaft rotates, proceed to step 2 below.

- Step 2. Check heater core for leaks, cracks, distortion, or obstructions.
 - a. If heater core is leaking, cracked, or distorted, replace (para 3-38); if obstructed, clean (para 3-38).
 - b. If heater core is not leaking, cracked, distorted, or obstructed, proceed to step 3 below.

- Step 3. Check blower wheel for cracks, distortion, obstructions.
 Check if setscrew is loose or missing.
 - a. If obstructions are found, remove; if blower wheel is cracked, or distorted, replace (para 3-38).
 - b. If setscrew is loose or missing, replace (para 3-38).

3-37. HEATER TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

2. FRESH AIR DOOR WILL NOT OPEN OR CLOSE

Check heater housing for cracks, bent condition, bent or cracked fresh air door, or broken bellcrank.

If housing is cracked or bent, fresh air door is cracked or bent, or bellcrank is broken, replace housing (para 3-38).

3. WINDSHIELD WILL NOT DEFROST

Check for cracked, broken, or missing strap link.

Check for missing strap link nuts.

a. If strap link is cracked, broken, or missing, replace (para 3-38).

b. If strap link nuts are missing, replace (para 3-38).

3-38. HEATER MAINTENANCE

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Screwdriver
- Key set, socket head screw
- Socket wrench set
- Hose clamp pliers
- Scratch wire brush
- Safety glasses
- Tool kit, electrical connector
- Crimping tool
- Wire stripper

- Detergent
 - Rubber seal, self-adhesive
 - Gasket, motor
 - Two wire connectors
- Item 27, Appendix C
FSCM 59502
PN 4111-N-W/PSA
FSCM 90915 PN 90007293
FSCM 77060 PN 2965867

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-73a	Cab heater removed from tractor.

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


DISASSEMBLY

1	Motor (14)	a. Two clamps (1)	Move	Loosen with hose clamp pliers and slide to center of hose (2)
		b. Hose (2)	Disconnect and remove	
		c. Two clamps (1)	Remove	Use hose clamp pliers
		d. Four screws (3)	Remove	Support motor (14)
		e. Plate (8) with motor (14)	Remove	
		f. Setscrew (4)	Loosen	
		g. Blower wheel (5)	Remove	Pull from motor (14) shaft
		h. Setscrew (4)	Remove	If necessary
		i. Two nuts (6) and washers (7)	Remove	
		j. Plate (8)	Separate	From motor (14)
		k. Gasket (9)	Remove and discard	

3-38. HEATER MAINTENANCE (CONT)

KEY

- 1. Clamps (2)
- 2. Hose
- 3. Screws (4)
- 4. Setscrew
- 5. Blower wheel
- 6. Nuts (2)
- 7. Washers (2)
- 8. Plate
- 9. Gasket
- 10. Wire connectors (2)
- 11. Connector shell
- 12. Electrical lead (RED)
- 13. Electrical lead (ORG)
- 14. Motor
- 15. Plastic bushings (2)
- 16. Nuts (2)
- 17. Strap link
- 18. Wrapper and scroll
- 19. Screws (6)
- 20. Housing
- 21. Rubber seal
- 22. Heater core
- 23. Screws (4)
- 24. Distributor
- 25. Screws (4)
- 26. Collars (2)



TA236325

3-38. HEATER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

NOTE

Tag connector shell (11) and electrical leads (12 and 13) before removing wire connectors (10) to aid in reassembly.

		1. Two wire connectors (10)	a. Unplug b. Remove and discard	From connector shell (11) Only if necessary for replacement. Cut electrical leads (12 and 13) as close to wire connectors (10) as possible
2	Heater core (22)	a. Two plastic bushings (15) b. Six screws (19) c. Housing (20) d. Rubber seal (21)	Remove Remove Remove and discard	 Only if necessary for replacement

CAUTION

Lift heater core (22) carefully in following step to prevent damage to core.

3	Distributor (24)	e. Heater core (22) a. Four screws (23) b. Distributor (24) c. Four screws (25) d. Two collars (26) e. Two nuts (16) and strap link (17)	Lift and remove Remove Remove Remove Lift and remove Remove	
---	------------------	---	--	--

CLEANING

4		a. Rubber seal (21)	Clean	Wipe with clean dry cloth only
---	--	---------------------	-------	--------------------------------

3-38. HEATER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
4 (cont)		b. Hose (2), connector shell (11), plastic bushings (15), and collars (26)	Clean	Use clean cloth moistened with mild detergent; dry using clean cloths

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

		c. Motor (14)	Clean	Wipe exterior only with cloth moistened in cleaning solvent P-D-680; dry with clean cloths
		d. Heater core (22)	a. Clean	Clean exterior with stiff bristled brush and compressed air at 20-25 psi
			b. Flush	Connect water supply to core and flush tubes; then everse connection and flush in opposite direction
		e. All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air or clean cloths

3-38. HEATER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION				
5		a. Motor (14)	Inspect	Replace if burned out or otherwise defective
		b. Blower wheel (5)	Inspect	Replace if cracked, broken, distorted, or vanes damaged
		c. Heater core (22)	Inspect	Replace if leaking, cracked, distorted, or threads damaged
		d. Hose (2)	Inspect	Replace if cracked, split, or deteriorated
		e. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

CAUTION

Lower heater core (22) carefully in following step to prevent damage to core.

6	Heater core (22)	a. Heater core (22)	Install	Peel protective paper backing from seal; then press adhesive side into position
		b. New rubber seal (21)	Install, if removed	
		c. Housing (20)	Position	
		d. Six screws (19)	Install and tighten	
		e. Two plastic bushings (15)	Install	
7	Distributor (24)	a. Two collars (26)	Position	
		b. Four screws (25)	Install and tighten	
		c. Strap link (17)	Position	
		d. Two nuts (16)	Install and tighten	
		e. Distributor (24)	Position	
		f. Four screws (23)	Install and tighten	

3-38. HEATER MAINTENANCE (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
8	Motor (14)	a. Plate (8) with new gasket (9)	Position	On motor (14)
		b. Two nuts (6) and washers (7)	Install	Tighten nuts (6) evenly
		c. Setscrew (4)	Install	If removed
		d. Blower wheel (5)	Position	Align setscrew with flat on motor shaft
		e. Setscrew (4)	Tighten	
		f. Plate (8) with motor (14)	Position	
		g. Four screws (3)	Install and tighten	
		h. Two clamps (1)	Position	Open with hose clamp pliers and slide to center of hose (2)
		i. Hose (2) with clamps (1)	Install	
		j. Two clamps (1)	Install	Loosen with hose clamp pliers and slide to ends of hose

NOTE

Perform following steps only if necessary to install wire connectors (10) or connector shell (11).

k. Electrical leads (12 and 13)	Strip 1/4 inch insulation from ends	
l. New wire connectors (10)wires	a. Install on	Crimp securely
	b. Push into	As tagged in step 1 above connector shell (11)

Section VIII. HYDRAULIC SYSTEMS MAINTENANCE

This section contains the information you need to maintain the:

- * Fifth Wheel Hydraulic System
- * Cab Tilt Hydraulic System

It gives you instructions on how to troubleshoot problems and repair or replace the components that are within the scope of direct support maintenance.

	Para
Troubleshooting Symptom Index	3-39
Fifth Wheel Hydraulic System Troubleshooting	3-40
Cab Tilt Hydraulic System Troubleshooting	3-41
Fifth Wheel Hydraulic System Maintenance	3-42
Hydraulic Pump	3-42a
Power Take-Off	3-42b
Hydraulic Control Valve	3-42c
Hydraulic Cylinders	3-42d
Cab Tilt Hydraulic System Maintenance	3-43
Hydraulic Pump	3-43a
Hydraulic Cylinder	3-43b
Hydraulic Latches	3-43c
Hold Down Assembly a	3-43d
Safety Bar	3-43e

3-39. TROUBLESHOOTING SYMPTOM INDEX

	Para/Malfunction	Page
FIFTH WHEEL HYDRAULIC SYSTEM		
Fifth wheel doesn't lift	3-40/1	3-408
Fifth wheel lifts slowly	3-40/2	3-410
Fifth wheel creeps downward	3-40/3	3-411
Fifth wheel doesn't lower	3-40/4	3-411
Hydraulic oil foaming	3-40/5	3-413
Hydraulic oil overheating	3-40/6	3-413
CAB TILT HYDRAULIC SYSTEM		
Cab won't raise to 45 degrees	3-41/1	3-414
Cab won't lower or stops part way down	3-41/2	3-414
Hydraulic latches or hydraulic cylinder leak fluid.....	3-41/3	3-414
Hydraulic pump leaks fluid at filler plug or vent	3-41/4	3-414

3-40. FIFTH WHEEL HYDRAULIC SYSTEM TROUBLESHOOTING

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. FIFTH WHEEL DOESN'T LIFT

WARNING

Keep clear of fifth wheel boom moving parts to prevent serious injury or death.

Step 1. Check for full movement of fifth wheel hydraulic control valve metering spool.

Have assistant operate 5th WHEEL control lever; watch movement of hydraulic control valve metering spool.

- a. If metering spool does not move fully to "raise" or "lower" positions, repair or replace hydraulic control valve or cable (para 3-42c and 2-78a).
- b. If control valve metering spool moves fully to "raise" and "lower" positions, proceed to step 2 below.

Step 2. Check hydraulic control valve relief pressure.

Disconnect hoses from two top ports of fifth wheel hydraulic control valve and install a pressure gage in each port.

CAUTION

Do not hold 5th WHEEL control lever back for more than 30 seconds at a time. Failure to follow this procedure could result in damage to the fifth wheel hydraulic pump.

With vehicle engine at governed speed, have assistant pull back 5th WHEEL control lever fully; watch both pressure gages.

- a. If pressure gage in top rear port indicates 2000 psi and pressure gage in top front port indicates approximately zero psi, proceed to Malfunction 3, step 2, below.
- b. If pressure gage in top rear port indicates less than 2000 psi, but more than 1500 psi, adjust hydraulic control valve relief pressure (para 3-42c). If pressure increases to 2000 psi without turning adjusting screw in all the way, return tractor to normal operation. If pressure does not increase when adjusting screw is turned, proceed to Malfunction 2, step 2, below.
- c. If pressure gage in top rear port indicates less than 1500 psi, proceed to Malfunction 2, step 2, below.

3-40. FIFTH WHEEL HYDRAULIC SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

1. FIFTH WHEEL DOESN'T LIFT (Cont)

- d. If pressure gages indicate approximately equal pressure, fifth wheel hydraulic control valve is defective; repair or replace (para 3-42c)
- e. If both pressure gages indicate zero psi, proceed to step 3 below.

WARNING

Keep clear of fifth wheel boom moving parts to prevent serious injury or death.

Step 3. Have assistant operate PTO control; watch movement of power take-off shift lever.

- a. If shift lever does not move fully to "power take-off engaged" position when PTO control is pulled out fully, adjust or replace PTO control cable (para 3-42b).
- b. If shift lever moves fully to "power take-off engaged" position when PTO control is pulled out fully, proceed to step 4 below.

Step 4. Check hydraulic pump key for sheared condition.

- a. If sheared, replace (para 3-42a).
- b. If not sheared, proceed to step 5 below.

Step 5. Start vehicle engine and watch power take-off output shaft for rotation.

- a. If power take-off output shaft rotates, repair or replace fifth wheel hydraulic pump (para 3-42a).
- b. If power take-off output shaft does not rotate, repair or replace power take-off (para 3-42b). If malfunction is not corrected, notify general support maintenance (transmission may require overhaul).

3-40. FIFTH WHEEL HYDRAULIC SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

2. FIFTH WHEEL LIFTS SLOWLY

Step 1. Check hydraulic control valve relief pressure (para 3-42c).

- a. If pressure is less than 2000 psi, but more than 1500 psi, adjust (para 3-42c). If pressure increases to 2000 psi without turning adjusting screw in all the way, refer to para 2-76, Malfunction 2, step 1. If 2000 psi pressure is not obtained or adjusting screw must be turned in all the way to obtain 2000 psi, proceed to step 2 below.
- b. If pressure is 2000 psi or less than 1500 psi, proceed to step 2 below.

Step 2. Install pressure gage in hydraulic control valve relief pressure check point (para 3-42c).

Install flowmeter at hose connecting hydraulic pump and hydraulic control valve.

CAUTION

Do not hold 5th WHEEL control lever back for more than 30 seconds at time. Failure to follow this procedure could result in damage to hydraulic pump.

With vehicle engine operating at governed speed, have assistant pull back 5th WHEEL control lever fully. Watch pressure gage and flowmeter. Pressure shall be 2000 psi with a flow rate of at least 10 GPM.

NOTE

With engine at governed speed, maximum performance is 14 GPM flow rate and 2000 psi relief pressure.

- a. If flow rate is less than 10 GPM, hydraulic pump is defective; repair or replace (para 3-42a).
- b. If flow rate is between 10 and 14 GPM, but relief pressure is less than 2000 psi, hydraulic control valve is defective; repair or replace (para 3-42c).

3-40. FIFTH WHEEL HYDRAULIC SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

3. FIFTH WHEEL CREEPS DOWNWARD

Step 1. Check if hydraulic control valve metering spool is in neutral position.

- a. If metering spool is not in neutral position, repair hydraulic control valve or cable as required (para 3-42c and 2-78a).
- b. If metering spool is in neutral position, proceed to step 2 below.

Step 2. Lower fifth wheel boom fully.

Disconnect hose from bleed valve (para 2-87b(2)) and cap the hose and bleed valve.
Raise fifth wheel boom fully and check for downward creep.

- a. If fifth wheel boom does not creep downward, bleed valve is defective; replace (para 2-78b(2)).
- b. If fifth wheel boom creeps downward, lower fifth wheel boom fully, reconnect hose to bleed valve, and proceed to step 3 below.

Step 3. Raise fifth wheel boom fully; support boom in raised position.

Disconnect two fifth wheel hydraulic cylinder hoses from the down-stroke ends of hydraulic cylinders (para 2-78b(2)) and cap the hoses.

Install a pressure gage in each hydraulic cylinder port.

Have an assistant pull back 5th WHEEL control lever fully; watch pressure gages.

- a. If pressure gages indicate approximately zero psi and do not increase, hydraulic control valve is leaking internally; repair or replace (para 3-42c).
- b. If pressure gage indicates increased pressure, hydraulic cylinder is leaking internally; repair or replace (para 3-42d).

4. FIFTH WHEEL DOESN'T LOWER

Step 1. Check hydraulic cylinder rods for bent or jammed condition.

- a. If hydraulic cylinder rods are bent or jammed, repair or replace cylinders (para 3-42d).
- b. If hydraulic cylinder rods are not bent or jammed, proceed to step 2 below.

3-40. FIFTH WHEEL HYDRAULIC SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

4. FIFTH WHEEL DOESN'T LOWER (Cont)

WARNING

Keep clear of fifth wheel boom moving parts to prevent serious injury or death.

Step 2. Check movement of fifth wheel hydraulic control valve metering spool.

Have assistant push 5th WHEEL control lever fully forward; watch movement of hydraulic control valve metering spool.

- a. If metering spool does not move to the fully "down" position, repair or replace 5th WHEEL control lever or cable (para 2-78a).
- b. If metering spool moves to the fully "down" position, proceed to step 3 below.

Step 3. Rotate handle of bleed valve to fully open (horizontal) position.

- a. If fifth wheel lowers, close bleed valve and proceed to step 5 below.
- b. If fifth wheel does not lower, proceed to step 4 below.

Step 4. Support fifth wheel boom.

Check hose assemblies between bleed valve and hydraulic cylinders for restrictions (sharp bends, blockage).

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when using compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

- a. If hoses are blocked, use compressed air (30 psi maximum) to remove blockage; if hoses remain blocked, replace (para 2-78b(2)).
- b. If hoses are not blocked, replace bleed valve (para 2-78b(2)). If malfunction is not corrected, proceed to step 5 below.

3-40. FIFTH WHEEL HYDRAULIC SYSTEM TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

4. FIFTH WHEEL DOESN'T LOWER (Cont)

Step 5. Lower fifth wheel boom fully using bleed valve.

Remove hydraulic cylinder velocity fuses (para 2-78b(2)).

Try to raise and lower fifth wheel boom.

- a. If fifth wheel boom lowers, velocity fuses are contaminated by foreign material; replace (para 2-78b(2)).
- b. If fifth wheel boom does not lower, hydraulic control valve is defective; repair or replace (para 3-42c).

5. HYDRAULIC OIL FOAMING

WARNING

Do not remove filler cap when hydraulic oil is hot. Hot oil can cause severe injury.

Remove hydraulic reservoir filler cap and check for proper viscosity hydraulic oil (compare thickness of oil to that of oil from new container).

- a. If oil from reservoir has the same consistency as sample oil, repair or replace hydraulic pump (para 3-42a).
- b. If oil from reservoir has different consistency than sample oil, drain and flush hydraulic system and replace oil filters (para 2-78c and 2-78b(1)).

6. HYDRAULIC OIL OVERHEATING

Check hydraulic control valve relief pressure (para 3-42c).

- a. If pressure is less than 2000 psi, adjust (para 3-42c). If pressure does not increase to 2000 psi, repair or replace hydraulic control valve (para 3-42c).
- b. If pressure is 2000 psi, refer to para 2-76, Malfunction 5, step 1.

3-41. CAB TILT HYDRAULIC SYSTEM TROUBLESHOOTING
--

MALFUNCTION
TEST OR INSPECTION**CORRECTIVE ACTION**

1. CAB WON'T RAISE TO 45 DEGREES

Check if cab tilt hydraulic pump operates and hydraulic latches release.

- a. If cab tilt hydraulic pump operates and hydraulic latches release, hydraulic cylinder is defective; repair or replace (para 3-43b).
- b. If cab tilt hydraulic pump does not operate, repair or replace (para 3-43a).
- c. If hydraulic latches do not release, , replace (para 3-43c).

2. CAB WON'T LOWER OR STOPS PART WAY DOWN

Repair or replace cab tilt hydraulic pump relief valve (para 3-43a).

3. HYDRAULIC LATCHES OR HYDRAULIC CYLINDER LEAK FLUID

Replace a defective hydraulic latch (para 3-43c); repair or replace defective hydraulic cylinder (para 3-43b).

4. HYDRAULIC PUMP LEAKS FLUID AT FILLER PLUG OR VENT

Check if fluid level is too high.

- a. If fluid level is too high, remove reservoir (para 2-79a) and pour off excess fluid (dispose of used fluid properly).
- b. If fluid level is correct, purge cab tilt hydraulic system (para 3-43b).

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE

a. Hydraulic Pump.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Retaining ring pliers
- Puller kit
- Safety glasses
- Torque wrench
- Vise jaw caps
- Socket head screw key set
- Machinist's vise

Automotive Mechanic's Tool Kit

- Hammer
- Soft plastic hammer
- Straightedge

removed from hydraulic pump.

Materials/Parts

- Cleaning solvent
- Clean cloths
- Hydraulic oil
- Service parts kit
- Lubriplate
- Aero-lube grease
- Block of wood
- Sleeve

- Item 2, Appendix C
- Item 22, Appendix C
- FSCM 64294 PN 46099-6

Personnel Required

Automotive Repairer MOS 63H

References

LO 9-2320-285-12
(M878A1 Lubrication Order)

Equipment Condition

Paragraph	Condition Description
	Vehicle parked on level surface, engine off, and parking brake applied.
2-78b(2)	Hydraulic lines and fittings
2-65c	Rear platform removed.
Item 1, Appendix C	

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Transmission, right hand side	a. Two capscrews (19) and lock washers (20)	Remove	Support hydraulic pump
		b. Hydraulic pump	Remove	Pull from power take-off

DISASSEMBLY

CAUTION


Exercise care when using vise to avoid distorting any parts. If vise is used, clamp vise jaws across rear of cover (14).

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

KEY

- 1. Key
- 2. Socket head screws (4)
- 3. Washers (4)
- 4. Socket head screws (4)
- 5. Washers (4)
- 6. Pump body
- 7. Wear plate
- 8. Sealing ring
- 9. Load seal
- 10. Preload seal



- 11. Idler gear
- 12. Drive gear
- 13. Dowel pins (2)
- 14. Cover
- 15. Bearings (2)
- 16. Bearings (2)
- 17. Retaining ring
- 18. Seal
- 19. Capscrews (2)
- 20. Lock washers (2)

TA236318

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2	Hydraulic pump	a. Key (1)	Remove and discard	
		b. Four socket head screws (2) and washers (3)	Remove	Discard washers (3)
		c. Four socket head screws (4) and washers (5)	Remove	Discard washers (5)

CAUTION

Do not attempt to pry pump sections apart in following step. Prying could scratch mating surfaces and cause a leak.

d. Pump body (6)	a. Tap lightly	Use soft plastic hammer; tap lightly to loosen
b. Remove		
e. Wear plate (7) and sealing ring (8)	Remove and discard	
f. Load seal (9) and preload seal (10)	Remove and discard	
g. Idler gear (11)	Remove	
h. Drive gear (12)	Remove	

NOTE

Remove two dowel pins (13) only if inspection indicates need for replacement.

i. Two dowel pins (13)	Remove
------------------------	--------

NOTE

Remove bearings (15 and 16) only if inspection indicates need for replacement.

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		j. Two bearings (15)	Remove	Turn pump body (6) upside down, then tap against block of wood to loosen bearings

NOTE

If bearings (15) are extremely tight and difficult to remove, it indicates operation with dirty hydraulic oil.

k. Two bearings (16)	Remove	Turn cover (14) upside down, then tap against block of wood to loosen bearings
l. Retaining ring (17) discard	Remove and	Use retaining ring pliers

NOTE

Exercise care not to damage seal recess in following step.

m. Seal (18)	Remove	Use bearing puller
--------------	--------	--------------------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3		All parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air
---	--	-----------	-------	--

INSPECTION

4		a. Pump body (6) and cover (14)	Inspect	Place a straightedge across machined surfaces that mate pump body (6) with cover (14), to check for warped mating surfaces. Replace if warped, cracked, broken, or distorted
		b. Idler gear (11) and drive gear (12)	Inspect	Replace as set if teeth cracked, broken, or missing, or shafts cracked or distorted
		c. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

NOTE

Lightly coat all parts with clean hydraulic oil before reassembly.

5	Hydraulic pump	a. All interior parts	Lubricate	Use clean hydraulic oil
---	----------------	-----------------------	-----------	-------------------------

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

5
(cont)**CAUTION**

Place body (6) on soft wood block to prevent marring mating surfaces.

b.		New seal (18)	Install	In pump body (6) with metal case to outside of pump. Force seal firmly into place with suitable sleeve, or press into pump body
c.		New retaining	Install	Use retaining ring pliers ring (17)
d.		Two bearings (16)	Install	In cover (14)
e.		Two dowel pins (13)	Install	Use soft plastic hammer; tap into cover (14)
f.		Two bearings (15)	Install	In pump body (6)
g.		Drive gear (12) and idler gear (11)	Install	In cover (14)
h.		Seal (18)	Lubricate	Fill space between lips with Lubriplate Aero-lube grease
i.		New preload seal (10), load seal (9), and sealing ring (8)	Assemble	On new wear plate (7)
j.		New wear plate (7)	Install	Install with wear surface facing gears (11 and 12)
k.		Pump body (6)	Position	Against cover (14)
l.		Four new washers (5) and screws (4)	Install	Do not tighten
m.		Four new washers (3) and screws (2)	Install	Do not tighten
n.		Pump shaft	Rotate	
o.		Screws (2 and 4)	Tighten	Tighten alternately to 140 pounds inch torque
p.		Four screws (4)	Tighten	To 370 pounds inch torque
q.		Four screws (2)	Tighten	To 200 pounds inch torque
r.		New key (1)	Position	In drive gear (12) shaft keyway

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
6	Transmission, right hand side	a. Hydraulic pump b. Two capscrews (19) and lock washers (20)	Position Install and tighten	On power take-off
7	Hydraulic system	Lines and fittings	Install	Para 2-78b(2)
8	Cab	Key switch	Turn on	Run engine at idle to allow hydraulic pump to break in slowly
9	Bleed valve	Hydraulic system	Bleed	Open bleed valve until air is purged from system
10	Cab	Fifth wheel control lever	Pull	With power take-off engaged and engine at fast idle, pull fifth wheel lever back to raise fifth wheel
11	Hydraulic reservoir	Hydraulic system	Fill	Add hydraulic oil (para 2-78c)
12	Hydraulic system	All connections	Inspect	Check for leaks
13	Cab	Key switch	Turn off	
14	Tractor	Rear platform	Install	Para 2-65c

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Retaining ring pliers
- Puller kit
- Safety glasses
- Torque wrench
- Socket wrench set
- Socket head screw key set

Automotive Mechanic's Tool Kit

- Pliers
- Hammer

Soft plastic hammer

Straightedge

Sleeve

Dial indicator

Arbor press

Brass drift

Gaskets:

- 0.010 inch FSCM 95019 PN 22-P-24-1
- 0.020 inch FSCM 95019 PN 22-P-24-2
- 0.010 inch FSCM 95019 PN 35-P-9-1
- 0.020 inch FSCM 95019 PN 35-P-9-2
- Gasket FSCM 95019 PN 35-P-8
- O-ring FSCM 95019 PN 28-P-49
- Oil seal FSCM 95019 PN 28-P-52
- Tie straps FSCM 96906 PN MS3667-1-9
- Block of wood

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

Vehicle parked on level surface, engine off, and parking brake applied.
Rear platform removed.
Transmission fluid drained.
Hydraulic pump removed and set aside (pump hoses connected).

Materials/Parts

Cleaning

- solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Mineral spirits Item 33, Appendix C

- 2-65c
- 2-41b
- 3-42a

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

CAUTION

Do not strike power take-off housing with hammer.

- | | | | | |
|---|--|---|----------------------|--|
| 1 | Transmission, right hand side (2), and | a. Setscrew (6)
b. Nut (1), screw clamp (3) | Loosen
Remove | |
| | | c. PTO cable (4)
d. Pivot pin (5) and setscrew (6) | Disconnect
Remove | Pull from pivot pin (5)
From shift lever (33) |


3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2	Corner instrument panel, top nut (8)	a. Nut (9) b. Knob (7) and c. Nut (9)	Loosen Remove Remove	From PTO cable (4) shaft
3	Cab tilt pump	Cab	Tilt 45 degrees	
4	Under cab hood	a. Three tie straps (10) b. Nut (11) and clamp (12) c. PTO cable (4) d. Lock washer (13) and nut (14)	Remove Remove Remove Remove	Cut and discard From corner instrument panel From PTO cable (4)
5	Frame, left hand side	a. Heat shield b. Three tie straps (15)	Remove Remove	Para 2-65d Cut and discard
6	Behind rear cab guard	a. Tie strap (16) b. Clamp (19), nut (17), and washer (18) c. PTO cable (4)	Remove Remove Remove	Cut and discard From external engine oil filter From tractor
7	Transmission, right hand side	a. PTO hose (20) b. Four capscrews (21), bracket (22), cover (23), and gasket (24) c. Four nuts (25) and copper gaskets (26) d. Capscrew (27) and copper gasket (28) e. PTO assembly f. Socket head screw (29)	Disconnect and remove Remove Remove Remove Support Loosen	From power take-off; para 2-41e Discard gasket (24) From transmission housing only; do not attempt to remove from power take-off

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).



TA236319

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

KEY

- | | | |
|--------------------|------------------------|----------------------------|
| 1. Nut | 24. Gasket | 47. Spacer |
| 2. Screw | 25. Nuts (4) | 48. Retaining ring |
| 3. Clamp | 26. Copper gaskets (4) | 49. Socket head screws (4) |
| 4. PTO cable | 27. Capscrew | 50. Open end bearing cap |
| 5. Pivot pin | 28. Copper gasket | 51. Gaskets (AR) |
| 6. Setscrew | 29. Socket head screw | 52. Oil seal |
| 7. Knob | 30. Gasket | 53. Capscrews (4) |
| 8. Nut | 31. Capscrew | 54. Closed end bearing cap |
| 9. Nut | 32. Washer | 55. Gaskets (AR) |
| 10. Tie straps (3) | 33. Shift lever | 56. Bearing cup |
| 11. Nut | 34. Washer | 57. Bearing cone |
| 12. Clamp | 35. Shifter plate | 58. Lock ring |
| 13. Lock washer | 36. O-ring | 59. Spacer |
| 14. Nut | 37. Poppet | 60. Output shaft |
| 15. Tie straps (3) | 38. Spring | 61. Output gear |
| 16. Tie strap | 39. Pipe plug | 62. Bearing cup |
| 17. Nut | 40. Setscrew | 63. Bearing cone |
| 18. Washer | 41. Idler shaft | 64. Studs (2) |
| 19. Clamp | 42. Thrust washer | 65. Studs (2) |
| 20. PTO hose | 43. Thrust washer | 66. End fitting |
| 21. Capscrews (4) | 44. Drive gear | 67. Collar |
| 22. Bracket | 45. Input gear | 68. Housing |
| 23. Cover | 46. Needle rollers (2) | |

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

7 (cont)		g. Power take-off	Remove	Pull from transmission
		h. Socket head screw (29)	Remove	From power take-off
		i. Gasket (30)	Remove and discard	

DISASSEMBLY

8	Cover (23)	a. Capscrew (31), washer (32), shift lever (33), and washer (34)	Remove	
		b. Shifter plate (35)	Remove	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
8 (cont)		c. O-ring (36), poppet (37), and spring (38)	Remove	Discard O-ring (36)
9 (44)	Drive gear	a. Pipe plug (39) b. Setscrew (40) c. Idler shaft (41) d. Thrust washers (42 and 43) e. Drive gear (44) and input gear (45) f. Two needle rollers (46) and spacer (47)	Remove Remove Remove Remove Remove and separate Remove	Use brass drift and hammer From drive gear (44)
10	Housing (68)	a. Retaining ring (48) b. Four socket head screws (49) c. Open end bearing cap (50) d. Gaskets (51) e. Oil seal (52) f. Four capscrews (53) g. Closed end bear- ing cap (54) h. Gaskets (55)	Remove Remove a. Tap b. Remove Remove and discard Remove and discard Remove	Use retaining ring pliers Use plastic hammer to loosen From housing (68) Press from open end bearing cap (50) Use plastic hammer to loosen Remove from housing (68)
11 (61)	Output gear	a. Bearing cup (56) b. Bearing cone (57) c. Lock ring (58) d. Spacer (59)	Remove Remove Remove Remove	Use puller

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
11 (cont)		e. Output shaft (60)	Remove	From output gear (61)
		f. Output gear (61)	Remove	From housing (68)
		g. Open end bearing cap (50)	Position	On block of wood with PTO side down
		h. Bearing cup (62)	Remove	Use sleeve and hammer
		i. Bearing cone (63)	Remove	Use puller

NOTE

Remove studs (64 and 65) only if inspection indicates need for replacement. Note location to aid in reassembly.

12	Transmission housing	a. Two studs (64)	Remove
		b. Two studs (65)	Remove

NOTE

Remove end fitting (66) and collar (67) only if inspection indicates need for replacement.

13	PTO cable (4)	End fitting (66) and collar (67)	Remove
----	---------------	----------------------------------	--------

CLEANING

14		a. Bearings (46, 57, and 63)	Clean using mineral spirits. Immerse bearings and slowly move up and down. Remove bearings from mineral spirits and strike larger side of bearing (57 and 63) cone flat against a block of wood to dislodge solidified particles of lubricant. Immerse again in mineral spirits and repeat procedure until bearings are thoroughly clean. Dry bearings using moisture-free compressed air. Direct air stream across bearings to avoid spinning. Do not spin bearings when drying them; bearings may be rotated slowly by hand to facilitate drying
----	--	------------------------------	--

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

14
(cont)

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b.	All other parts	Clean	Use cleaning solvent P-D-680; dry thoroughly using compressed air or clean cloths
----	-----------------	-------	---

INSPECTION

15

a.	PTO cable (4), end fitting (66), and collar (67)	Inspect	Replace cable if broken, frayed, kinked or otherwise damaged. Replace end fitting or collar if damaged
b.	Spring (38)	Inspect	Replace if cracked, broken, distorted, or permanently set
c.	Bearing caps (50 and 54) and housing (68)	Inspect	Place a straightedge across machined surfaces to check for warped mating surface. Replace if warped, cracked, broken, or distorted
d.	Bearings (46, (57, and 63)	Inspect	Replace if chipped, nicked, worn, or flat spotted. If bearing is replaced, replace bearing and cup as a set

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
15 (cont)		e. Gears (44, 45, and 61)	Inspect	Replace if cracked, broken, distorted, teeth missing, nicked, or pitted
		f. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged
REASSEMBLY				
16	PTO cable (4)	Collar (67) and end fitting (66)	Install	If removed
17	Transmission housing	a. Two studs (65)	Install	If removed
		b. Two studs (64)	Install	If removed
18	Output gear (61)	a. Lock ring (58)	Install	On output shaft (60)
		b. Bearing cone (63)	a. Position b. Install	On output shaft (60) Press or drive into place with soft hammer or arbor press
		c. Output gear (61)	Install	In housing (68)
		d. Output shaft (60)	Install	Through output gear (61)
		e. Spacer (59)	Install	
		f. Bearing cone (57)	Position	On output shaft (60)
		g. Housing (68)	Invert	
		h. Bearing cone (57)	Install	Press or drive into place with soft hammer or arbor press
		i. Bearing cup (56)	Install	In closed end bearing cap (54); press or drive in with soft hammer or arbor press
		j. Bearing cup (62)	Install	In open end bearing cap (50); press or drive in with soft hammer or arbor press
19	Housing (68)	a. New gaskets (55)	Position	Initially use two 0.020 inch gaskets; use more as needed
		b. Closed end bearing cap (54)	Position	Offset of bearing cap opposite input gear (45)

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS			
REASSEMBLY (cont)							
19 (cont)		c. Four capscrews (53)	Install and tighten	Initially use two 0.020 inch gaskets; use more as needed Offset of bearing cap opposite input gear (45) On housing (68) Check that shaft turns freely and that end play does not exceed 0.006 inch Use suitable sleeve and hammer to seat fully			
		d. New gaskets (51)	Position				
		e. Open end bearing cap (50)	Position				
		f. Four socket head screws (49)	Install and tighten				
		g. Dial indicator	Position				
		h. Output shaft (60)	Check				
		i. Dial indicator	Remove				
		j. Oil seal (52)	Install				
		20	Drive gear (44)		a. Input gear (45)	Lay flat	On top of input gear (45) In housing (68), with setscrew (40) side down In housing (68), until idler shaft breaks through inside wall of housing
					b. Drive gear (44)	Position	
c. One needle roller (46)	Install						
d. Spacer (47)	Install						
e. One needle roller (46)	Install						
f. Idler shaft (41)	a. Position b. Install						

NOTE

Groove in idler shaft (41) must align with setscrew hole in housing (68).

g. Thrust washer (43)	Position	In housing (68), to align with idler shaft (41) hole
h. Gear assembly	Install	In housing (68)
i. Idler shaft (41)	Install	Use soft hammer to tap in
j. Thrust washer (42)	Install	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
20 (cont)		k. Idler shaft (41)	Install	Until flush with housing (37)
		l. Setscrew (40)	Install	
		m. Pipe plug (39)	Install	In housing (68)
		n. Retaining ring (48) and socket head screw (29)	Install	
21	Cover (23)	a. Spring (38), poppet (37), and new O-ring (36)	Install	
		b. Shifter plate (35)	Install	
		c. Washer (34)	Install	
		d. Shift lever (33)	Install	
		e. Washer (32) and capscrew (31)	Install	

INSTALLATION

NOTE

Gasket (30) thickness must be selected to provide 0.005 to 0.025 inch backlash between input gear (45) and transmission PTO drive gear.

22	Transmission, right hand side	a. New gasket (30)	Install	On power take-off On transmission Tighten capscrew to 33 pounds foot torque
		b. Power take-off	Position	
		c. Copper gasket (28) and capscrew (27)	Install	
		d. Four copper gaskets (26) and nuts (25)	Install	
		e. Socket head Tighten screw (29)		

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
23	Power takeoff	a. Gasket (24)	Position	On cover (23) On housing (68). Be sure shifter plate (35) engages input gear (45)
		b. Cover (23)	Position	
		c. Bracket (22)	Position	Para 2-41e
		d. Four capscrews (21)	Install and tighten	
		e. PTO hose (20)	Install	
24	Under cab hood	a. Nut (14) and lock washer (13)	Install	On PTO cable (4)
		b. PTO cable (4)	a. Install b. Route	Through corner instrument panel from bottom To power take-off
		c. Three new tie straps (10)	Install	Tighten nut (11)
		d. Clamp (12) and nut (11)	Install	
25	Frame, left hand side	a. Three new tie straps (15)	Install	Para 2-65d
		b. Heat shield	Install	
26	External engine oil filter	a. Clamp (19), washer (18), and nut (17)	Install	Tighten nut (17)
		b. New tie strap (16)	Install	
27	Cab tilt pump	Cab	Lower	To normal operating position
28	Corner instrument panel, top	a. Nut (9)	Install and tighten	
		b. Nut (8) and knob (7) tighten	Install and	
		c. Knob (7)	Push in fully	
29	Transmission, right hand side	a. Pivot pin (5) and setscrew (6)	Position In shift lever (33)	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Power Take-off (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
29 (cont)		b. PTO cable (4)	a. Install	Push cable wire into pivot pin (5) hole
		c. Clamp (3), screw (2), and nut (1)	b. Position Install	In clamp (3) Tighten nut (1)
		d. Setscrew (6)	Tighten	
		e. Hydraulic pump	Install	Para 3-42a
30	Tractor rear	Rear platform	Install	Para 2-65c
31	Tractor cab	a. Engine	a. Start	
		b. Power take-off	b. Run	Run at fast idle
		c. Fifth wheel lever	Engage Pull	Pull lever back to check for proper system operation

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve.

- This task covers:
- | | |
|----------------|-----------------|
| a. Removal | e. Reassembly |
| b. Disassembly | f. Installation |
| c. Cleaning | g. Adjustment |
| d. Inspection | |

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Socket wrench set
- Torque wrench
- Retaining ring pliers
- Safety glasses

Pressure gage, 3000 psi

Materials/Parts

- | | |
|------------------|------------------------|
| Cleaning solvent | Item 1, Appendix C |
| Clean cloths | Item 2, Appendix C |
| Hydraulic oil | Item 22, Appendix C |
| Retaining ring | FSCM 02249 PN 0914-001 |
| Two O-ring seals | FSCM 02249 PN 7694-001 |
| Washer | FSCM 02249 PN 1213-001 |
| O-ring | FSCM 02249 PN 0926-001 |
| Gasket | FSCM 02249 PN 0923-001 |
| O-ring | FSCM 02249 PN 2706-001 |
| Cotter pin | FSCM 02249 PN 929-001 |
| Cotter pin | FSCM 02249 PN 086-001 |

Personnel Required

Three Automotive Repairers MOS 63H

References

LO 9-2320-285-12
(M878A1 Lubrication Order)

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

- | | |
|----------|---|
| | Vehicle parked on level surface, engine off, and parking brake applied. |
| 2-63e | Boom platform removed. |
| 2-65c | Rear platform removed. |
| 2-78b(1) | Hydraulic reservoir drained. |
| 2-78b(2) | Hydraulic lines and fittings / removed from hydraulic control valve. |
| 2-78a | Fifth wheel control cable disconnected from control valve. |

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL


- | | | | | |
|---|----------------------|--|--------------------------|-------------------------------|
| 1 | Left hand frame rail | a. Cotter pin (1) | Remove and discard | |
| | | b. Pin (2) | Remove | |
| | | c. Cotter pin (3) | Remove and discard | Remove from link (4) |
| | | d. Link (4) | a. Separate
b. Remove | Separate two sections of link |
| | | e. Handle (5) | Remove | |
| | | f. Three locknuts (6), cap-screws (7), and washers (8) | Remove | |

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

- 1. Cotter pin
- 2. Pin
- 3. Cotter pin
- 4. Link
- 5. Handle
- 6. Locknuts (3)
- 7. Capscrews (3)
- 8. Washers (3)
- 9. Elbow
- 10. Rubber bonnet

- 11. Retaining ring
- 12. Stop disc
- 13. Screw
- 14. Lock washer
- 15. Stop collar
- 16. Centering spring
- 17. Stop washer



- 18. O-ring seal
- 19. Metering spool
- 20. O-ring seal
- 21. Check plug
- 22. O-ring
- 23. Check poppet
- 24. Acorn nut
- 25. Jam nut
- 26. Adjusting screw
- 27. Washer
- 28. O-ring
- 29. Body
- 30. Ball
- 31. Spring guide
- 32. Relief spring
- 33. Gasket
- 34. Seat
- 35. O-ring
- 36. Poppet
- 37. Housing
- 38. Pipe plug
- 39. Tee
- 40. Locknuts (2)
- 41. Capscrews (2)
- 42. Plate

TA236320

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
1 (cont)		g. Hydraulic control valve	Remove	Lift from plate (42)
		h. Two locknuts (40) and cap-screws (41)	Remove	Support plate (42)
		i. Plate (42)	Remove	

DISASSEMBLY

NOTE

Set parts aside in order of removal to aid in reassembly.

2	Hydraulic control valve	a. Elbow (9)	Remove	
		b. Rubber bonnet (10)	Remove	
		c. Retaining ring (11)	Remove and discard	Use retaining ring pliers
		d. Stop disc (12)	Remove	
		e. Screw (13) and lock washer (14)	Remove	
		f. Stop collar (15) and centering spring (16)	Remove	
		g. Stop washer (17)	Remove	
		h. Metering spool (19)	Move	Push spool (19) into housing (37) from O-ring seal (18) end until O-ring seal (18) is exposed
		i. O-ring seal (18)	Remove and discard	
		j. Metering spool (19)	Remove	From housing (37)
		k. O-ring seal (20)	Remove and discard	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		l. Check plug (21), O-ring (22), and check poppet (23)	Remove	Discard O-ring (22)
		m. Acorn nut (24) and jam nut (25)	Remove	
		n. Adjusting screw (26)	Remove	
		o. Washer (27) and O-ring (28)	Remove and discard	
		p. Body (29)	Remove	
		q. Ball (30), spring guide (31), and relief spring (32)	Remove	
		r. Gasket (33)	Remove and discard	
		s. Seat (34), O-ring (35), and poppet (36)	Remove	Discard O-ring (35)
CLEANING				
3		a. Rubber bonnet (10)	Clean	Wipe with clean cloth moistened with water only. Dry thoroughly with clean cloth

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and seek medical aid immediately.

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

3
(cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

b.	All other parts	Clean	Use cleaning solvent P-D-680; dry with compressed air
----	-----------------	-------	---

INSPECTION

4
(19)

a.	Metering spool	Inspect	Replace hydraulic control valve if metering spool is cracked, broken, burred, or does not slide easily in bore of housing (37)
b.	Housing (37)	Inspect	Replace hydraulic control valve if housing is cracked, broken, burred, or does not easily accept metering spool (19)
c.	Springs (16 and 32)	Inspect	Replace if cracked, broken, distorted, or permanently set
d.	All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

NOTE

Immerse all inner control valve parts in clean hydraulic oil to provide initial lubrication.

5	Inner parts (13 thru 36)	All inner parts (13 thru 36)	Lubricate	Immerse in clean hydraulic oil
---	--------------------------	------------------------------	-----------	--------------------------------

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
6	Hydraulic control valve	a. Poppet (36), new O-ring (35), and seat (34)	Install	In housing (37)
		b. Relief spring (32)	Install	On relief spring guide (31)
		c. New O-ring (28)	Install	On adjusting screw (26)
		d. Jam nut (25) and acorn nut (24)	Install	On adjusting screw (26)
		e. New washer (27)	Install	In body (29)
		f. Ball (30)	Install	In seat (34)
		g. New gasket (33)	Position	Against body (29)
		h. Adjusting screw (26) assembly (24 thru 33)	Install	In housing (37). Tighten jam nut (25) and acorn nut (24) hand tight only
		i. Check poppet (23), new O-ring (22), and check plug (21)	Install	
		j. Metering spool (19)	a. Install	Install threaded end first from O-ring seal (18) end of housing (37)
			b. Move	Push spool far enough into housing to expose O-ring seal (20) groove in spool
	k. New O-ring seal (20)	Install		

NOTE

Exercise care that O-ring seal (20) is not twisted or rolled in O-ring groove.

l. Metering spool (19)	Move	Pull spool into housing (37) far enough to expose O-ring (18) groove in spool
m. New O-ring seal (18)	Install	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

6
(cont)

NOTE

Exercise care that O-ring seal (18) is not twisted or rolled in O-ring groove.

n.	Lock washer (14), stop collar (15), centering spring (16), and stop washer (17)	Assemble	On screw (13)
o.	Screw (13)	Install	Tighten to 10 pounds foot torque
p.	Stop disc (12)	Install	
q.	New retaining ring (11)	Install	Use retaining ring pliers
r.	Rubber bonnet (10)	Install	
s.	Elbow (9)	Install and tighten	

INSTALLATION

7 Left hand frame rail

a.	Plate (42)	Position	On frame rail; align mounting holes
b.	Two capscrews (41) and locknuts (40)	Install and	Secures plate (42) tighten
c.	Hydraulic control valve	Position	On plate (42); align mounting holes
d.	Three washers (8), cap- screws (7), and locknuts (6)	Install and	tighten
e.	Handle (5)	Position	
f.	Link (4)	Install	
g.	New cotter pin (3)	Install and spread	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
7 (cont)		h. Pin (2)	Install	Push through center hole in handle (5) and hole in metering spool (19)
		i. New cotter pin (1)	Install and spread	
8	Hydraulic control valve and fittings	a. Control cable b. Hydraulic lines	Connect Install	Para 2-78a Para 2-78b(2)
9	Hydraulic system	a. Hydraulic reservoir b. Hydraulic system	Fill Bleed	To proper level Bleed hydraulic system by opening bleed valve and alternately raising and lowering fifth wheel until air is purged from system
		c. Hydraulic reservoir	Check	Check fluid level. Add fluid to maintain proper level (see current lubrication order)
ADJUSTMENT				
10	Fifth wheel boom boom	a. Fifth wheel b. Pipe plug (38) c. 3000 psi pressure gage	Lower fully Remove Install	From tee (39) In tee (39)
11	Hydraulic control valve	a. Acorn nut (24) b. Jam nut (25)	Remove Loosen	
12	Tractor cab	a. Engine b. Power take-off c. Engine	Start Engage Operate	At 2500 rpm

CAUTION

Do not hold fifth wheel control lever back for more than 15 seconds at a time.

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT) I

c. Hydraulic Control Valve (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
ADJUSTMENT (cont)				
12 (cont)		d. Fifth wheel control lever	Pull back	To raise fifth wheel
NOTE				
Use assistants for the following steps.				
13	Fifth wheel boom	3000 psi pressure gage	Watch	While performing step 14 below
14	Hydraulic control valve	a. Adjusting screw (26)	Turn	Adjust screw for 2000 psi indication on pressure gage
		b. Jam nut (25)	Tighten	When pressure gage indicates 2000 psi
15	Tractor cab	a. Fifth wheel control lever	Push forward	To lower fifth wheel fully
		b. Engine	Turn off	
16	Fifth wheel boom	a. 3000 psi pressure gage	Remove	From tee (39)
		b. Pipe plug (38)	Install	In tee (39)
		c. Boom platform	Install	Para 2-63e
17	Rear platform	Rear platform	Install	Para 2-65c

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection/Repair
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance
Tool Kit

- Socket wrench set, 3/4 inch drive
- Torque wrench, 3/4 inch drive,
600 pounds foot

- Hand hammer
- Lubricating kit
- Safety glasses
- Brass drift

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Chassis grease Item 3, Appendix C
- Medium grit emery cloth Item 4, Appendix C
- Degreasing solvent Item 18, Appendix C
- Hydraulic oil Item 22, Appendix C
- Stud lock compound Item 23, Appendix C
- Seal kit FSCM 89642 PN 272-2175

Personnel Required

Automotive Repairer MOS 63H

References

LO 9-2320-285-12
(M878A1 Lubrication Order)

Equipment Condition

Paragraph Condition Description

Vehicle parked on level surface, engine off, and parking brake applied. Fifth wheel boom elevated fully and supported with hoist. Hydraulic lines and fittings removed from hydraulic cylinder to be removed.

2-78b(2)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

NOTE



Before performing step 1 below, mark rod cap (3) and mating end of rod (12) using center punch and hammer to ensure correct alignment during reassembly.

1	Hydraulic cylinder, bottom	a. Four nuts (1) and lock washers (2)	Remove	Support rod cap (3)
		b. Rod cap (3)	Remove	
		c. Four capscrews (4)	Remove	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

1. Nuts (4)
2. Lock washers (4)
3. Rod cap
4. Capscrews (4)
5. Locknut
6. Capscrew
7. Pin
8. Cylinder
9. Bearing
10. Retaining ring
11. Gland
12. Rod
13. Locknut



14. Piston
15. Solid seal
16. O-ring
17. Wiper
18. Rod seal
19. O-ring
20. Back-up ring
21. Drive screws (2)
22. Identification plate
23. Lubrication fitting
24. Lubrication fitting
25. Locknuts (2)
26. Capscrews (2)
27. Shaft
28. Spacer tube
29. Insert

TA236115

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
2	Hydraulic cylinder, top	a Locknut (5) and capscrew (6)	Remove	Use brass drift and hammer if necessary Push cylinder down fully; then lift from tractor
		b Pin (7)		
		c Hydraulic cylinder (8)	Remove	

NOTE

Perform steps 1 and 2 above to remove remaining hydraulic cylinder. Perform steps 3 and 4 below only if inspection indicates replacement of shaft (27) or spacer tube (28) is required.

3	Tractor, rear, left side	Left rear tires and wheels	Remove	Para 2-57
4	Chassis rear, bottom	a Two locknuts (25) and capscrews (26)	Remove	If necessary, tap right end of shaft (27) with brass drift and hammer; then support spacer tube (28) while removing shaft (27)
		b Shaft (27) and spacer tube (28)	Remove	
5	Cylinder (8)	a Bearing (9)	Remove	Only if worn or damaged Rotate until end of retaining ring (10) is visible in slot in cylinder (8) barrel Pry retaining ring (10) part of the way out of groove in gland (11) Rotate until retaining ring (10) is completely dis-engaged from cylinder (8)
		b Gland (11)	Position	
		c Retaining ring (10)	Pry up	
		d Gland (11)	Position	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5 (cont)		e. Retaining ring (10)	Remove and discard	
		f. Gland (11) and rod (12)	Remove	Pull from cylinder (8) as an assembly
6	Rod (12)	a. Locknut (13)	Remove and discard	
		b. Piston (14) with solid seal (15)	Remove	
		c. Solid seal (15) and insert (29)	Remove and discard	Remove from piston (14)
		d. Gland (11)	Remove	Pull from rod (12)
		e. O-ring (16)	Remove and discard	
7	Gland (11)	a. Wiper (17)	Remove and discard	
		b. Rod seal (18)	Remove and discard	
		c. O-ring (19)	Remove and discard	
		d. Back-up ring (20)	Remove and discard	
8	Cylinder (8)	a. Two drive screws (21) and identification plate (22)	Remove replacement	Only if required for
		b. Two lubrication fittings (23 and 24)	Remove (3)	From cylinder (8) and rod cap

NOTE

Repeat steps 5 thru 8 above to disassemble remaining hydraulic cylinder.

1342. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING**WARNING**

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

9		All parts	Clean	Use cleaning solvent P-D-680; dry with compressed air
INSPECTION/REPAIR				
10		a. Rod (12)	Inspect	Replace if bent, deeply grooved, or scored. Remove nicks or scratches with medium grit emery cloth polishing with a rotary motion
		b. Cylinder (8)	Inspect	Replace if deeply grooved, scored, or damaged. Remove nicks or scratches inside cylinder with medium grit emery cloth polishing with a rotary motion
		c. Bearing (9)	Inspect	Replace if worn, cracked, or split
		d. All other parts	Inspect	Replace if cracked, split, grooved, or otherwise damaged

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY

11 Gland (11)

NOTE

Lubricate the following parts with clean hydraulic oil prior to installation.

a.	New rod seal (18)	Install	Grooved side toward piston end
b.	New wiper (17)	Install	Chamfered side toward rod end
c.	New back-up ring (20)	Install	Butt against rod end of groove in gland (11)
d.	New O-ring (19)	Install	

CAUTION

Use extreme care when performing following step not to damage wiper (17), rod seal (18), or O-ring (19).

12	Rod (12)	a. Gland (11) with wiper (17), rod seal (18) and rings (19 and 20)	Install	As an assembly
		b. New O-ring (16)	Lubricate and install	Use clean hydraulic oil
		c. Piston (14)	Lubricate and install	Coat entire piston with clean hydraulic oil. Slide piston over O-ring (16) and butt against rod (12)
		d. New insert (29) and solid seal (15)	Lubricate and install	Use clean hydraulic oil
		e. New locknut (13)	Install	Coat threads of rod (12) and locknut (13) with degreasing solvent and allow to air dry ten minutes. Lightly coat threads of rod and locknut with stud lock compound; then tighten locknut to 375 pounds foot. Allow to air dry before testing cylinder

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
<u>CAUTION</u>				
Take care not to damage rings (19 and 20) or solid seal (15) when performing following step.				
13	Cylinder (8)	a. Cylinder (8)	Lubricate	Lightly coat inside diameter with clean hydraulic oil
		b. Rod (12) with piston (14) and gland (11)	Install	As an assembly. Compress solid seal (15) while sliding piston (14) into cylinder, and compress rings (19 and 20) while sliding gland (11) into cylinder
		c. Gland (11)	Position	Rotate until hole in gland (11) is visible in slot in cylinder (8) barrel
		d. Retaining ring (10)	Position	Engage retaining ring (10) in hole in gland (11)
		e. Gland (11)	Rotate	Rotate gland (11) until retaining ring (10) is completely drawn into cylinder (8)
		f. Identification plate (22)	Position and install	Use new drive screws (21), if removed
		g. Two lubrication fittings (23 and 24)	Install	Straight fitting (24) in rod cap (3); 90 degree fitting (23) in cylinder (8)

NOTE

Repeat steps 11 thru 13 above to reassemble remaining hydraulic cylinder.

INSTALLATION

NOTE

Perform steps 14 and 15 below only if shaft (27) and spacer tube (28) were removed; otherwise, proceed to step 16.

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
14	Chassis rear, bottom	a. Shaft (27)	Position	Push into chassis bore from left side until 2-3 inches of shaft protrudes inside chassis
		b. Spacer tube (28)	Position	Push one end over short portion of shaft (27), and align free end with remaining chassis bore
		c. Shaft (27)	Install	Push through spacer tube (28) and into right side chassis bore. Align capscrew holes
		d. Two capscrews (26) and locknuts (25)	Install and tighten	
15	Tractor rear, left side	Left rear tires and wheels	Install	Para 2-57
16	Fifth wheel boom, top rear	a. Hydraulic cylinder (8)	Position	Position top of cylinder (8) between bores of boom, with cylinder ports facing rear of tractor
		b. Pin (7)	Install	Tap into bores of boom and bearing (9); then align capscrew hole
		c. Capscrew (6) and locknut (5)	Install and tighten	
17	Chassis rear, bottom	a. Spacer tube (28)	Slide	On shaft (27), away from hydraulic cylinder being installed
		b. Rod (12) (27)	Extend	Positions rod (12) on shaft
		c. Rod cap (3)	Position	Under rod (12) with holes aligned
		d. Four capscrews (4), lock washers (2), and nuts (1)	Install and tighten	

3-42. FIFTH WHEEL HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hydraulic Cylinders (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
NOTE				
Repeat steps 16 and 17 above to install remaining hydraulic cylinder.				
18	Hoist	a. Fifth wheel boom	Lower fully	While lowering hoist
		b. Hoist	Disconnect	From fifth wheel boom
19	Hydraulic cylinders	a. Four lubrication fittings (23 and 24)	Grease	Refer to current lubrication order
		b. Hydraulic lines and fittings	Install	On fifth wheel hydraulic cylinders, para 2-78b(2)
20	Hydraulic system	a. Hydraulic system	Bleed	Bleed hydraulic system by opening bleed valve and alternately raising and lowering fifth wheel until air is purged from system
		b. Hydraulic reservoir	Check	Check fluid level. Add fluid to maintain proper level (see current lubrication order)

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE

a. Hydraulic Pump.

This task covers: a. Disassembly c. Inspection
 b. Cleaning d. Reassembly

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Retaining ring pliers
- Combination wrench set
- Safety glasses
- Socket wrench set
- Key set, socket head screw
- Torque wrench

Automotive Mechanic's Tool Kit

- Hammer
- Pliers
- Punch

Vise

Container

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C

Transmission

- fluid Item 8, Appendix C
- Loctite Item 29, Appendix C
- Seal and pack- FSCM 26953
- ing kit P/N KH5003-30-01
- Three cotter FSCM 26953 P/N B1016-058
- pins FSCM 26953 P/N A8081-049
- Retaining ring

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

2-79a Hydraulic pump removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY


1	Pump body (1), bottom	a.	Four socket head screws (4)	Remove	
		b.	Reservoir (5)	Remove	Dispose of used fluid properly
		c.	Preformed packing (6)	Remove and discard	
		d.	Retaining ring (7)	Remove and discard	Use retaining ring pliers
		e.	Screen (8)	Remove	
		f.	Outlet seat (9)	Remove	Do not disassemble
		g.	O-ring (10), washer (12), and O-ring (11)	Remove and discard	
		h.	Flow control assembly (13)	Remove	Do not disassemble

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

KEY

- | | |
|---------------------------|-------------------|
| 1. Pump body | 41. Plunger |
| 2. Pump cylinder | 42. Seal |
| 3. Preformed packing | 43. Beam link pin |
| 4. Socket head screws (4) | 44. Spring washer |
| 5. Reservoir | 45. Spring washer |
| 6. Preformed packing | 46. Beam |
| 7. Retaining ring | 47. Back-up ring |
| 8. Screen | 48. Quad ring |
| 9. Outlet seat | 49. Cotter pin |
| 10. O-ring | 50. Washer |
| 11. O-ring | 51. Link pin |
| 12. Washer | 52. Spring washer |
| 13. Flow control assembly | |
| 14. O-ring | |
| 15. Relief valve | |
| 16. Copper gasket | |
| 17. Inlet seat | |
| 18. O-ring | |
| 19. Retaining ring | |
| 20. Screen | |
| 21. Pin | |
| 22. Plug | |
| 23. Lock screw | |
| 24. Lock spring | |
| 25. Ball | |
| 26. Setscrew | |
| 27. Handle | |
| 28. Seal | |
| 29. Preformed packing | |
| 30. Spindle | |
| 31. Plug | |
| 32. Vent fitting | |
| 33. Filler plug | |
| 34. Cotter pin | |
| 35. Washer | |
| 36. O-ring | |
| 37. Link | |
| 38. Piston pin | |
| 39. Cotter pin | |
| 40. Washer | |



TA236323

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
1 (cont)		i. O-ring (14)	Remove and discard	
		j. Relief valve (15)	Remove	Do not disassemble
		k. Copper gasket (16)	Remove and discard	
		l. Inlet seat (17)	Remove	Do not disassemble
		m. O-ring (18)	Remove and discard	
2	Pump body (1), sides	a. Retaining ring (19)	Remove	Use retaining ring pliers
		b. Screen (20)	Remove	
		c. Pin (21)	Remove	
		d. Plug (22) and O-ring (36)	Remove	
		e. Lock screw (23)	Remove	
		f. Lock spring (24)	Remove	
		g. Ball (25)	Remove	
		h. Setscrew (26)	Remove	
		i. Handle (27)	Remove	
		j. Seal (28)	Remove and discard	
		k. Preformed packing (29)	Remove and discard	
		l. Spindle (30)	Remove	
		m. Plug (31)	Remove	
3	Pump body (1), top	a. Vent fitting (32)	Remove	
		b. Filler plug (33)	Remove	
		c. Cotter pin (34)	Remove and discard	
		d. Washer (35)	Remove	
		e. Piston pin (38)	Remove	
		f. Cotter pin (39)	Remove and discard	
		g. Washer (40)	Remove	
		h. Beam link pin (43)	Remove	
		i. Beam (46)	Remove	

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3 (cont)		j. Two spring washers (44 and 45)	Remove	
		k. Cotter pin (49)	Remove and discard	
		l. Washer (50)	Remove	
		m. Link pin (51)	Remove	
		n. Link (37)	Remove	
		o. Spring washer (52)	Remove	
		p. Plunger (41)	Remove	
		q. Seal (42), back-up ring (47), and quad ring (48)	Remove and discard	
		r. Pump cylinder (2)	Remove	From pump body (1); do not disassemble
		s. Preformed packing (3)	Remove and discard	

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

1343. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
4		All parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air or clean cloths
INSPECTION				
5		a. Reservoir (5)	Inspect	Replace if cracked, broken, distorted, or otherwise damaged
		b. Screens (8 and 20)	Inspect	Replace if cracked, broken, or mesh damaged. Use compressed air to clear a clogged screen
		c. Pump cylinder (2) and pump body (1)	Inspect	Replace if cracked, broken, sealing surfaces pitted or nicked, or threads damaged
		d. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

NOTE

Apply light coat of clean transmission fluid to plunger (41) and all packing and seals before reassembly.

6	Pump body (1), top	a. New preformed packing (3)	Install	On pump cylinder (2)
		b. Pump cylinder (2)	Install	In pump body (1)
		c. New quad ring (48), new back-up ring (47), and new seal (42)	Install	
		d. Plunger (41)	Install	
		e. Link (37)	Position	
		f. Spring washer (52) and link pin (51)	Install	
		g. Washer (50)	Install	
		h. New cotter pin (49)	Install and spread	

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
6 (cont)		i. Beam (46)	Install	
		j. Two spring washers (45 and 44) and beam link pin (43)	Install	
		k. Washer (40)	Install	
		l. New cotter pin (39)	Install and spread	
		m. Piston pin (38)	Install	
		n. Washer (35)	Install	
		o. New cotter pin (34)	Install and spread	
		p. Vent fitting (32)	Install	
7	Pump body (1), sides	a. Plug (31)	a. Coat	Apply light coat of Loctite to plug threads
		b. Install		
		c. New preformed packing (29) and new seal (28)	b. Spindle (30) Install	Install Carefully press seal (28) into pump body (1)
		d. Spindle (30) clockwise	Position	Turn shaft fully counter-
		e. Handle (27)	a. Install b. Position	On spindle (30) Against pin (21) in released position
		f. Setscrew (26)	a. Coat	Apply light coat of Loctite to setscrew threads
		g. Ball (25)	b. Install	
		h. Lock spring (24)	Install	
		i. Lock screw (23)	Install	
		j. O-ring (36) and plug (22)	Install	
		k. Pin (21)	Install	
		l. Screen (20)	Install	
		m. Retaining ring (19)	Install	


3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

8 (1), bottom	Pump body	a. New O-ring (18) b. Inlet seat (17)	Install Install	On inlet seat (17) Tighten to 20 pounds foot torque
---------------------	-----------	--	--------------------	--



TA236163

		c. New copper gasket (16)	Install	On relief valve (15)
		d. Relief valve (15)	Install	Tighten to 5 pounds foot torque
		e. New O-ring (14)	Install	On flow control assembly (13)
		f. Flow control assembly (13)	Install	Tighten to 20 pounds foot torque
		g. New O-ring (11), washer (12), and O-ring (10)	Install	
		h. Outlet seat (9)	Install	Tighten to 20 pounds foot torque
		i. Screen (8) and new retaining ring (7)	Install	
		j. New preformed packing (6)	Position	On reservoir (5)
		k. Reservoir (5)	Position	Against pump body (1)
		l. Four socket head screws (4)	Install and tighten	Tighten evenly

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

a. Hydraulic Pump (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9	Pump body (1), top	a. Hydraulic pump	Fill	With clean transmission fluid
		b. Filler plug (33)	Install and tighten	
		c. Hydraulic pump	a. Test b. Install and service	Operate beam (46) and watch for fluid pumping out of screen (20) Para 2-79a

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Hydraulic Cylinder.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance
Tool Kit

- Retaining ring pliers
 - Adjustable open end wrench
 - Safety glasses
 - Combination wrench set
- Automotive Mechanic's Tool Kit
- Hammer
 - Punch

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Grease Item 3, Appendix C
- Transmission fluid Item 8, Appendix C
- Service parts kit FSCM 26953 P/N KC1502

2-79a Vehicle parked on level surface, engine off, and parking brake applied. Cab tilted 45 degrees; safety bar engaged. Hydraulic pressure relieved; lines and fittings removed.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Cab, underside	a. Locknut (1)	Remove	Do not drive pin toward radiator
		b. Capscrew (2)	Remove	
		c. Upper pin (3)	Remove	
		d. Locknut (4)	Remove	Remove from tractor
		e. Capscrew (5)	Remove	
		f. Lower pin (6)	Remove	
		g. Hydraulic cylinder (7)	Remove	

DISASSEMBLY

CAUTION

Do not hammer cylinder rod (15) in following steps.


2	Hydraulic cylinder	a. Velocity fuse (8)	Remove
---	--------------------	----------------------	--------

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Hydraulic Cylinder (cont).

KEY

- | | |
|-----------------------|--------------------|
| 1. Locknut | 13. Adapter |
| 2. Capscrew | 14. Retaining ring |
| 3. Upper pin | 15. Cylinder rod |
| 4. Locknut | 16. Lock ring |
| 5. Capscrew | 17. Snap ring |
| 6. Lower pin | 18. Housing |
| 7. Hydraulic cylinder | |
| 8. Velocity fuse | |
| 9. Reducing bushing | |
| 10. Gland nut | |
| 11. Wiper | |
| 12. Packing | |



TA236324

1343. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Hydraulic Cylinder (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		b. Reducing bushing (9)	Remove	
		c. Gland nut (10) with wiper (11)	Remove	
		d. Wiper (11)	Remove and discard	
		e. Packing (12)	Remove and discard	
		f. Adapter (13)	Remove and discard	
		g. Retaining ring (14)	Remove and discard	Use retaining ring pliers
		h. Cylinder rod (15)	Remove	
		i. Lock ring (16)	Remove	
		j. Snap ring (17)	Remove	

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Hydraulic Cylinder (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
3		All parts	Clean	Use cleaning solvent P-D-680; dry thoroughly with compressed air
INSPECTION				
4		a. Cylinder rod (15) and housing (18)	Inspect	Replace hydraulic cylinder assembly if cracked, broken, distorted, or contact areas worn
		b. All other parts	Inspect	Replace if cracked, broken, distorted, or threads damaged

REASSEMBLY

CAUTION

Do not hammer cylinder rod (15) in following steps.

5	Hydraulic cylinder	a. Packing (12) and three rings (14, 16, and 17)	Lubricate	Use clean transmission fluid
		b. Snap ring (17) and lock ring (16)	Install	
		c. Cylinder rod (15)	Install	
		d. New retaining ring (14)	Install	
		e. New adapter (13) and new packing (12)	Install	Packing (12) cup side down
		f. New wiper (11)	a. Install	In gland nut (10), wiper lip out
		b. Lubricate	Apply clean grease to wiper lip	
		g. Gland nut (10) with wiper (11)	Install	

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

b. Hydraulic Cylinder (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
5 (cont,)		h. Reducing bushing (9)	Install	
		i. Velocity fuse (8)	Install	
INSTALLATION				
6	Cab, underside	a. Hydraulic cylinder (7)	Position	In tractor
		b. Lower pin (6)	Install	
		c. Capscrew (5) and locknut (4)	Install	
		d. Upper pin (3)	Install	
		e. Capscrew (2) and locknut (1)	Install	
7	Hydraulic hose assemblies	Lines and fittings	Install and connect	Para 2-79a. Do not tighten fitting at base of hydraulic cylinder (7)
WARNING				
Keep clear of deck when cab is raised or lowered. Failure to follow this procedure could result in severe injury or death. If you are injured, obtain medical aid immediately.				
8	Hydraulic system	System	Purge	Purge system by operating hydraulic pump to alternately raise and lower cab deck until clear fluid emerges from loose hose connection; then slowly lower cab deck and tighten hose fitting
9	Hydraulic pump	Hydraulic pump reservoir	Check level	Add transmission fluid if necessary

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Latches.

- This task covers:
- a. Removal
 - b. Cleaning
 - c. Inspection
 - d. Installation

INITIAL SETUP

Tools

- No. 1 Common Organizational Maintenance Tool Kit
- Adjustable open end wrench
- Combination wrench set
- Safety glasses
- Hulk bolt installation gun, 7.4 amperes
- FSCM 92940 P/N LR1375

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

- | | |
|-----------|--|
| Paragraph | Condition Description |
| | Vehicle parked on level surface, engine off, and parking brake applied. |
| | Cab tilted 45 degrees; safety bar engaged. |
| 2-79b | Hydraulic pressure relieved; hose assemblies and fittings removed from hydraulic latches |

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Frame rail, left hand side	<ul style="list-style-type: none"> a. Four locknuts (1), washers (2), and capscrews (3) b. Hydraulic latch (4) 	<ul style="list-style-type: none"> Remove Remove 	<ul style="list-style-type: none"> Support hydraulic latch (4) Lower from bracket
---	----------------------------	--	--	---

NOTE

Perform steps i.c. thru i.f. below only if necessary to remove bracket (9 or 10).



c.	Transmission mount	Remove	Para 3-17f
d.	Two locknuts (5) and capscrews (6)	Remove	
e.	Hulk bolt (7) and collar (8)	a. Cut b. Remove and discard	Support bracket (9)
f.	Left bracket (9)	Remove	

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Latches (cont).

KEY

- 1. Locknuts (8)
- 2. Washers (8)
- 3. Capscrews (8)
- 4. Hydraulic latches (2)
- 5. Locknuts (4)
- 6. Capscrews (4)
- 7. Huck bolts (2)
- 8. Collars (2)
- 9. Left bracket
- 10. Right bracket



TA236230

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Latches (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

NOTE

Repeat step 1 above at right hand frame rail to remove remaining hydraulic latch (4) and bracket (10).

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

2		All parts	Clean	Use cleaning solvent P-D-680; dry with compressed air
---	--	-----------	-------	---

INSPECTION

3		a. Hydraulic latches (4)	Inspect	Replace if leaking, cracked, or latch arm shows excessive wear
		b. All other parts	Inspect	Check for cracks, wear, and thread damage. Replace if necessary

INSTALLATION

4	Frame rail, left hand side	a. Left bracket (9)	Position	On left frame rail
---	----------------------------	---------------------	----------	--------------------

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

c. Hydraulic Latches (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
4 (cont)		b. Two capscrews (6) and locknuts (5)	Install	Do not tighten
		c. New collar (8) and huck bolt (7)	Install	Use huck bolt installation gun
		d. Two capscrews (6)	Tighten	
		e. Hydraulic latch Position (4)	Under bracket (9)	
		f. Four capscrews (3), washers (2), and locknuts (1)	Install and tighten	

NOTE

Repeat step 4 above to install remaining bracket (10) and hydraulic latch (4) at right hand frame rail.

5	Tractor frame	Transmission mount	Install, if removed	Para 3-17f
6	Hose assemblies	Lines and fittings	Connect	Para 2-79b
7	Cab tilt cylinder	Fitting	Loosen	
8	Tractor frame, right hand side	Cab tilt pump	Operate	Alternately raise and lower cab. Continue to purge air from hydraulic system until clear fluid emerges from loose hose fitting; then slowly lower cab
9	Cab tilt cylinder	Fitting	Tighten	
10	Tractor frame, sides	Hydraulic latches (4)	Inspect	Check that hydraulic latches (4) engage hold-down brackets properly with cab and deck lowered fully

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hold Down Assembly.

This task covers:

- a. Removal
- b. Cleaning

- c. Inspection/Repair
- d. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance Tool Kit

- Adjustable open end wrench
- Socket wrench set
- Safety glasses

Welding shop equipment

Materials/Parts

Cleaning solvent
Clean cloths

Item 1, Appendix C
Item 2, Appendix C

Personnel Required



Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph

Condition Description

Vehicle parked on level surface, engine off, and parking brake applied. Cab tilted 45 degrees; safety bar engaged.



TA236229

KEY

- 1. Capscrews (4)
- 2. Washers (8)
- 3. Locknuts (4)
- 4. Hold-down bracket

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hold Down Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Rear cab deck weldment, left hand side	a. Four capscrews (1), locknuts (3), and eight washers (2)	Remove	Support hold-down bracket (4)
		b. Hold-down bracket (4)	Remove	Lower from deck

NOTE

Repeat step 1 above to remove right hand hold-down bracket.

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

2		All parts	Clean	Use cleaning solvent P-D-680; dry using compressed air
---	--	-----------	-------	--

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

d. Hold Down Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION/REPAIR				
3		a. Hold-down brackets (4)	Inspect	Repair broken welds or cracks by welding; replace a hold-down bracket beyond economical repair
		b. Capscrews (1), washers (2), and locknuts (3)	Inspect	Replace if cracked, broken, or threads damaged
INSTALLATION				
4	Rear cab deck weldment, left hand side	a. Hold-down bracket (4)	Position	From bottom of deck
		b. Four capscrews (1), eight washers (2), and four locknuts (3)	Install	Do not tighten
NOTE				
Repeat step 4 above to install right hand hold-down bracket.				
5	Cab tilt	Cab pump	Lower	To normal operating position; lower slowly, and be sure that hold-down brackets (4) engage V-shaped cradles on left and right latches
6	Rear cab deck weldment, left and right sides	Capscrews (1) and locknuts (3)	Tighten	

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

e. Safety Bar.

This task covers:

- a. Removal
- b. Cleaning

- c. Inspection
- d. Installation

INITIAL SETUP

Tools

- No. 1 Common Organizational Maintenance Tool Kit
- Adjustable open end wrench
- Socket wrench set
- Safety glasses

Hoist

Materials/Parts

- Cleaning solvent
- Clean cloths
- Thread sealant

- Item 1, Appendix C
- Item 2, Appendix C
- Item 29, Appendix C

Personnel Required


Automotive Repairer MOS 63H

Equipment Condition.

Paragraph

Condition Description

Vehicle parked on level surface, engine off, and parking brake applied. Cab tilted 45 degrees.



KEY

- 1. Capscrew
- 2. Locknut
- 3. Capscrew
- 4. Pin
- 5. Safety bar

TA236227


3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

e. Safety Bar (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Cab deck weldment,	Hoist	Attach as shown	Secures deck in 45 degree position
---	--------------------	-------	-----------------	------------------------------------



TA236228

WARNING

Do not stand under items being secured by hoist. Do not put any body part between moveable and fixed elements of the equipment. If you are injured, seek medical aid immediately.

2	Cab deck weldment, right hand side	a. Capscrew (1) and locknut (2)	Remove	
		b. Capscrew (3)	Remove	
		c. Pin (4)	Remove	
		d. Safety bar (5)	Remove	Support safety bar (5) From bracket on frame

3-43. CAB TILT HYDRAULIC SYSTEM MAINTENANCE (CONT)

e. Safety Bar (cont) .

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING				
<u>WARNING</u>				
Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air and medical attention immediately. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water and obtain medical aid immediately.				
3	All parts	Clean		Use cleaning solvent P-D-680; dry with clean cloths
INSPECTION				
4		a. Pin (4) and safety bar (5)	Inspect	Replace if cracked, bent, or otherwise damaged
		b. All other parts	Inspect	Replace if cracked, corroded, or threads damaged
INSTALLATION				
5	Cab deck weldment, right hand side	a. Safety bar (5) b. Pin (4) c. Capscrew (1) and locknut (2) d. Capscrew (3)	Position Install Install and tighten Install and tighten	In bracket on frame Align hole in pin (4) with hole in cab deck bracket Apply thread sealant to threads
6	Cab deck weldment	Hoist	Disconnect	
7	Cab tilt pump	Cab	Lower	To normal operating position

**Section IX. PRE-EMBARKATION INSPECTION OF MATERIAL IN UNITS
ALERTED FOR OVERSEAS SHIPMENT**

Refer to the following publications for pre-embarkation inspection in units alerted for overseas shipment:

TB 740-97-1	Preparation for Shipment
TM 38-230-1	Packaging of Material
TM 38-230-2	Preservation and Packaging
TM 38-236	Preparation for Air Shipment
TM 55-2200-001-12	Block and Rail Transport

3-475/(3-476 blank)

**CHAPTER 4
GENERAL SUPPORT MAINTENANCE PROCEDURES**

CHAPTER OVERVIEW

This chapter has some important information that you need to know about the general support maintenance requirements of the vehicle. This information includes:

- Repair of the engine components.
- Repair of the fuel system components.
- Repair of the transmission including its torque converter.
- Repair of the differential.

Index

Section	Title	Page
I	Engine and Fuel System Maintenance	4-1
II	Power Train Maintenance.....	4-2

Section I. ENGINE AND FUEL SYSTEM MAINTENANCE

This section references the information you need to repair the engine and fuel system components at the general support maintenance level.

Para	Title	Page
	Engine Maintenance.....	4-1
	Fuel System Maintenance	4-2

4-1. ENGINE MAINTENANCE

NOTE

Refer to TM 9-2815-205-34 for repair of the engine components.

4-2. FUEL SYSTEM MAINTENANCE

NOTE

Refer to TM 9-2815-205-34 for repair of the fuel injector assemblies, blower assembly, turbocharger, and governor.

Section II. POWER TRAIN MAINTENANCE

This section contains the information you need to repair the torque converter, transmission, and differential at the general support maintenance level.

Para

Torque Converter	4-3
Transmission	4-4
Transmission Housing.....	4-4a
Main Shaft and Gear Unit Assembly	4-4b
Forward Clutch and Shaft Assembly	4-4c
Fourth Clutch Assembly	4-4d
Third Clutch, Center Support, and Second Clutch Assemblies.....	4-4e
First Clutch Assembly.....	4-4f
Low Planetary, Low Clutch, and Adapter Housing Assemblies.....	4-4g
Modulated Lockup Valve Assembly	4-4h
Low Shift Valve Assembly	4-4i
Control Valve Assembly	4-4j
Governor and Rear Cover Assembly	4-4k
Oil Pump and Front Support Assembly.....	4-4l
Differential	4-5

4-3. TORQUE CONVERTER I

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly
 - e. Adjustment

INITIAL SETUP

Tools

- No 2 Common Organizational Maintenance
- Tool Kit Clean cloths
- Socket wrench handle, 1/2 inch drive
- Socket wrench set, 1/2 inch drive
- Torque wrench, 1/2 inch drive, 175 pounds foot capacity
- Retaining ring pliers
- Mechanical puller kit
- Twist drill set
- Safety glasses
- Rubber mallet
- Dial indicator
- Arbor press
- Drill press
- Bushing installer J-24648
- Stator thrust bearing installer J-23549
- Stator roller retainer ring J-24218-1
- Converter end play gage J-24470
- Brass hammer
- Base plate J-29521-1 3-17c(2)
- Top plate J-29521-2
- Capscrew 5/8-11 x 3.25
- Fixture stand J-25587-1
- Rivet removing pin J-29121-3
- Rivet punch J-29121-1

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Item 2, Appendix C
- Automatic trans- Item 8, Appendix C
- mission oil
- Oil-soluble grease Item 9, Appendix C
- Ring FSCM 73342 PN 6770822
- Ring FSCM 73342 PN 6758036
- Seal ring FSCM 73342 PN 6753866
- Seal ring FSCM 73342 PN 6753866
- Locking strips FSCM 73342 PN 6769631
- Gasket FSCM 73342 PN 6759971
- Hook type ring FSCM 73342 PN 6830187

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition


Paragraph Condition Description

Transmission removed from
vehicle.
3-17d Torque converter removed from
transmission.

4-3. TORQUE CONVERTER (CONT)

KEY

- 1. Converter pump hub
- 2. Spacer
- 3. Cover assembly
- 4. Spacer retainers
- 5. Spacers
- 6. Locknuts
- 7. Piston
- 8. Bearing race
- 9. Snap ring
- 10. Seal ring retainer
- 11. Ring
- 12. Bushing
- 13. Ring
- 14. Converter pump assembly



- 15. Plate
- 16. Plate
- 17. Seal ring
- 18. Bearing assembly
- 19. Bearing race
- 20. Turbine
- 21. Stator assembly
- 22. Race
- 23. Rollers
- 24. Springs
- 25. Bearing assembly
- 26. Bearing assembly
- 27. Bearing race
- 28. Roller bearing
- 29. Seal ring
- 30. Locking strips
- 31. Capscrews

- 32. Gasket
- 33. Hook type ring
- 34. Washer
- 35. Washer
- 36. Rivet
- 37. Washer
- 38. Washer
- 39. Cam
- 40. Stator
- 41. Capscrews


TA236033

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


DISASSEMBLY

- | | | | | |
|---|------------------------|----------------------------------|---------|---|
| 1 | Converter pump hub (1) | Converter end play gage assembly | Install | As shown. Hold center screw of converter end play gage assembly and tighten nut |
|---|------------------------|----------------------------------|---------|---|



TA236034

- | | | | | |
|---|--------------------------------|----------------|---------|---|
| 2 | Torque converter end play gage | Dial indicator | Install | As shown. Set dial to zero. Check end play by lifting on center screw of converter end play gage as far as possible. Note measurement |
|---|--------------------------------|----------------|---------|---|



TA236035

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
NOTE				
End play more than 0.025 inch indicates need to replace worn torque converter parts and select new spacer (2). End play not more than 0.025 inch means same spacer (2) can be used on reassembly (except when replacing major parts).				
3	Cover assembly (3)	a Six spacer retainers (4)	Remove	
		b Six spacers (5)	Remove	
		c 24 locknuts (6)	Remove	
		d Cover assembly (3)	Remove	Place on table with piston (7) up
		e Bearing race (8)	Remove	
		f Snap ring (9) (7)	Remove	Push down on center of piston
		g Piston (7)	Remove	Turn cover assembly (3) over and bump on wood surface
		h Seal ring retainer (10) and ring (11)	Remove	Discard ring (11)
		i Bushing (12) necessary	Remove	Remove only if inspection shows replacement is necessary Use mechanical puller kit
4	Piston (7)	Ring (13)	Remove	Discard
5	Converter pump assembly (14)	a Plate (15)	Remove	
		b Plate (16)	Remove	
6	Plate (16)	Seal ring (17)	Remove	Discard
7	Converter pump assembly (14)	a Bearing assembly (18)	Remove	
		b Bearing race (19)	Remove	
		c Spacer (2)	Remove	
		d Turbine (20)	Remove	

14-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
7 (cont)		e Stator assembly (21) and race (22)	Remove	Grasp outside of stator assembly (21) with fingers and inside of race (22) with thumbs and remove both unit. Place stator (21) on table, race (22) upward
as a assembly				
8	Stator assembly (21)	a Race (22) while lifting b 10 rollers (23) and springs (24) c Bearing assembly (25)	Remove Remove Remove	Rotate race (22) clockwise Remove only if inspection shows replacement is sary. Use mechanical kit. Remove carefully so don't damage bore
neces- puller you				
9	Converter pump hub (1)	a Bearing assembly (26) b Bearing race (27) c Roller bearing (28)	Remove Remove Remove	
10	Converter pump assembly (14)	Seal ring (29)	Remove	Discard
11	Converter pump hub (1)	a Four locking strips (30) b Eight cap-screws (31) c Four locking strips (30)	Flatten corners Remove Remove	Discard
12	Converter pump assembly (14)	a Converter pump hub (1) b Gasket (32)	Remove Remove	Discard
13	Converter pump hub (1)	Hook type ring (33)	Remove	Discard

4-3. TORQUE CONVERTER (CONT)


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

NOTE

Don't disassemble stator assembly (21) unless replacement of washers (34 and 35) or rivets (36) is

14	Stator assembly (21)	a Rivets (36)	Remove	
----	----------------------	---------------	--------	--



Place stator assembly on drill press, formed rivet side up. Drill rivets, removing formed heads, using 3/8 inch drill. Place stator rivet base under stator assembly (21), as shown, and top plate on top. Be sure that holes in stator rivet base are under rivets. Install cap screw to hold plates together. Tighten to 60 pounds foot. Place removing, installing and swaging fixture on hydraulic press. Install rivet removing pin into re- moving, installing and swaging fixture head and tighten retainer thumb screw. Place stator assembly (21) drilled rivet side up. Press rivets (36) from stator assembly (21) with rivet removing pin. Remove removing, installing and swaging fixture, cap screw, top plate, and stator rivet base

		b. Washers (34, 35, 37 and 38), cam (39) and stator (40)	Remove	
--	--	--	--------	--

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety goggles when hammering.

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
15 necessary	Converter pump assem- bly (14)	Capscrews (41)	Remove	If inspection shows replace- ment is with brass hammer

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.


16		a All parts except cover assembly (3) and con- verter pump assembly (14)	Clean	Use cleaning solvent P-D-680. Immerse parts in cleaning solvent and move up and down until all old lubri- cant and foreign material is dissolved Dry parts thoroughly after removal from cleaning solvent with moisture free compressed air or clean cloths. Don't use compressed air on any bearings
----	--	--	-------	--

4-3. TORQUE CONVERTER (CONT)


STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
16 (cont)		b Cover assembly (3) and converter pump assembly (14)	Clean	Use clean cloths moistened with cleaning solvent P-D-680 Dry with moisture free compressed air
Be				sure not to lose any cap-screws (41) from converter pump assembly (14)
INSPECTION				
17		a Stator (40) and cam (39)	Inspect	Inspect for cracks, distortion, and swollen rivet holes If either part is defective, replace entire stator assembly (21). Check rivet holes for burrs. Deburr if necessary
		b Bearing assembly	Inspect	Lubricate with automatic (25) transmission fluid. Replace race (22) over bearing assembly (25) in hub of stator assembly (21) Rotate bearing assembly (25) while pressing on race (22). Leave bearing assembly (25) in stator assembly (21) if there is no roughness or binding If defective, remove See step 8c
		c Race (22)	Inspect	Inspect bearing ends for smoothness. Replace if there are any marks or scratches
		d Bushing (12)	Inspect	Inspect for scratches and scoring. Replace if necessary See step 3i
		e Washers (34 and 35) and rivets (36)	Inspect	Inspect for cracks, distortion and other damage. Check to see if rivets are bent or broken. Replace if necessary. See step 14a-
b		f All other parts	Inspect	Inspect for any damage making them defective. Replace if necessary

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
18	Stator assembly pocket (21)	a Cam (39) and stator (40)	Assemble	If stator assembly (21) was disassembled. Cam positioned as shown



- b. Washers (37 and 38) Position One on each side of stator (37)
- c. New washers (34 and 35) Position If removed
- d. New rivets (36)




Line up rivet holes and install new rivets from rear to front of stator (40). Install top and base plates, as shown, making sure rivet heads are between holes. Install retaining capscrew and strike top plate with rubber mallet to seat parts. Tighten cap- screw to 60 pounds foot. Place stator assembly (21) on fixture stand. Install rivet punch in fixture head and tighten thumb screw. Apply about 8000 pound load with press to swage rivet. Swage second rivet 180 degrees from first. Swage third rivet 60 degrees from second. Swage fourth rivet 180 degrees from third, etc., until all rivets are swaged. Remove capscrew, top plate, and base plate

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

18 (cont)	e	New bearing assembly (25)	Install	Only if removed earlier. Use bearing installer to drive bearing assembly into bore of stator assembly (21). Be sure pressure is born by outer shell of bearing assembly only. Install until top of outer shell is 0.025 to 0.035 inch above the shoulder in the side plate as shown
--------------	---	---------------------------	---------	--




TA236039

gasket hub	19	Converter pump assembly (14)	a New gasket (32) b Converter pump hub (1)	Position Position	Must be dry Line up holes in converter pump assembly (14), (32), and converter pump (1)
			c Four new locking strips (30)	Position	
			d Eight cap-screws (31)	Install	Tighten to 9-11 pounds foot
			e Locking strips (30)	Bend corners	Against heads of capscrews

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
19 (cont)				
				WARNING
				Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety goggles when hammering.
		f New capscrews (41)	Install	Any that need replacement. Be sure any weights are in original positions
Use				brass hammer
		g New seal ring (29)	Install	
20	Converter pump hub (1)	a Roller bearing (28)	Install	
		b Bearing race (27)	Install	Lugged side first
		c Bearing assembly (26)	Install	
		d New hook type ring (33)	Install	Into groove
21	Stator assembly (21)	a Cam (39)	Grease	Oil-soluble grease into bottom of cam pockets
		b Stator roller retainer ring	Install	As shown




TA236041

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

21 (cont)		c 10 rollers (23) and springs (24)	Install	As shown Rollers (23) installed in shallow ends of pockets. Open end of springs touch rollers and face center of cam (39)
--------------	--	--	---------	---




TA236040

TA236040

		d Race (22)	Install	Shoulder side first until it touches rollers, as shown in step 21b Turn race (22) clockwise and push down. Lift stator assembly and pull cord to remove retainer Push and rotate race until all the way down. Turn counterclockwise to lock stator assembly (21)
22	Converter pump assembly (14)	a Stator assembly (21)	Install	Carefully turn on its edge on table. Grasp outside of stator assembly (21) with fingers and inside of race (22) with thumbs. Don't let race fall out. Turn stator assembly upside down and install
		b Turbine (20)	Install	Install original if end play before disassembly was satisfactory and no new
		c Spacer (2)	Install	

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
22	(cont)			parts affecting end play are installed. Otherwise, do not
				install spacer (2) at this time
		d Bearing race (19)	Install	Outer lip up
		e Bearing assembly (18)	Install	Grease first with oil-soluble grease
23	Plate (16)	New seal ring (17)	Install	
24	Converter pump assembly (14)	a Plate (16)	Install	Line up balance marks
		b Plate (15)	Install	
Install 25 assembly	Cover (12) (3)	a New bushing	If original was removed. Use	bushing installer, as shown. After installation, bushing (12) inside diameter should BE 0.9990 to 1.0010 inch



TA236042

TA236042

		b Seal ring retainer (10)	Install	Onto hub, smaller end first
26	Seal ring retainer (10)	New ring (11)	Install	
27	Piston (7)	New ring (13)	Install	

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
as shown, in cover assembly		release	Place pencil line,	
28	Cover	a Piston (7)	Install	Piston (7) must engage guide pins in cover assembly (3) or lockup clutch will not RELEASE. Place pencil line, as shown, in cover assembly in line with pin nearest assembly hole in piston (7) when balance marks line up. Use pencil mark as guide to line up piston (7) with pin. If piston is seated properly, distance from cover assembly mounting surface to piston is about 1-1/2 inches
TA236043				
TA236043				
29	Converter pump assembly (14)	b Snap ring (9)	Install	With hand, push down on piston (7)
		c Bearing race (8)	Install	Inner lip first in hub Retain with oil-soluble grease
		a Cover assembly (3)	Position	Aline balance marks on cover assembly (3), plate (16), and converter pump (14)
30	Cover assembly (3)	b 24 locknuts (6)	Install	Tighten to 19-23 pounds foot
		a Spacers (5)	Install	Onto cover assembly drive studs
		b Spacer retainers (4)	Install	

4-3. TORQUE CONVERTER (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

30
(cont)

NOTE

Repeat steps 1 and 2 to check end play on reassembled torque converter, even if original spacer (2) was installed in step 22c. If end play is not within 0.001-0.025 inch, repeat steps 3a-d and 7a-c to partly disassemble torque converter. Install correct spacer (2) as listed below.

Dial Indicator Reading	Spacer to Use	Dimension of Spacer
less than 0.0177	None	
0.0177-0.034	Gold	0.015
0.034-0.049	Silver	0.030
0.049-0.062	Plain	0.042
0.062-0.079	Black	0.060
0.079-0.093	Copper	0.075

Perform steps 22d-e, 29, and 30 to reassemble torque converter. Then perform steps 1 and 2 to double check end play.

4-4. TRANSMISSION

a. Transmission Housing.

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly

INITIAL SETUP

Tools

- | | | |
|--|-----------------------------|------------------------|
| No 2 Common Organizational Maintenance | Crocus cloth | Item 12, Appendix C |
| Tool Kit | Selector seal | FSCM 73342 PN 23010610 |
| Socket wrench handle, 1/2 inch drive | Cover gasket | FSCM 73342 PN 6774323 |
| Socket wrench set, 1/2 inch drive | Lube valve | |
| Torque wrench, 1/2 inch drive, | adapter gasket | FSCM 73342 PN 6884872 |
| | 175 pounds foot capacity | Two socket head |
| Mechanical puller kit | screws | FSCM 73342 PN 6882586 |
| Safety glasses | | |
| Arbor press | Personnel Required | |
| Seal remover J-26401 | Automotive Repairer MOS 63H | |
| Seal installer J-26282 | | |

Materials/Parts

- | | | | |
|------------------------------|-------------------------|------|---|
| Cleaning solvent | Item 1, Appendix C | | |
| Clean cloths | Item 2, Appendix C | 4-4b | All internal transmission parts and rear cover removed. |
| Automatic transmission fluid | thru Item 8, Appendix C | 4-41 | |
| Nonhardening sealant | Item 10, Appendix C | | |

Equipment Condition
Condition Description

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY


1 (28)	Housing	a	Nut (1)	Remove	
		b	Shaft retainer pin (2)	Remove	
		c	Nut (3)	Remove	
		d	Lever (4) and manual selector shaft (5)	Remove	Hold lever (4) in one hand and carefully pull manual selector shaft (5) through selector seal (6)
		e	Selector seal (6)	Remove	Use seal remover Discard
		f	Plug (7) and washer (8)	Remove	
		g	Plug (9)	Remove	
		h	Capscrew (10) and retainer (11)	Remove	

4-4. TRANSMISSION (CONT)

a. Transmission Housing (cont).

KEY

- 1. Nut
- 2. Shaft retainer pin
- 3. Nut
- 4. Lever
- 5. Manual selector shaft
- 6. Selector seal
- 7. Plug
- 8. Washer
- 9. Plug
- 10. Capscrew
- 11. Retainer
- 12. Capscrew
- 13. Washer
- 14. Plug



- 15. Capscrews
- 16. Cover
- 17. Gasket
- 18. Socket head screws
- 19. Lube valve adapter
- 20. Gasket
- 21. Lube valve
- 22. Lube valve spring
- 23. Valve guide tube
- 24. Plug
- 25. Drive screw
- 26. Name plate
- 27. Vent assembly
- 28. Housing

TA236057

TA236057

4-4. TRANSMISSION (CONT)

a. Transmission Housing (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
1 (cont)		i Capscrew (12) and washer (13)	Remove	
		j Plug (14)	Remove	
		k Six capscrews (15)	Remove	
		l Cover (16) and gasket (17)	Remove	Discard gasket (17)
		m Two socket head screws (18)	Remove	Discard
		n Lube valve adapter (19) and adapter gasket (20)	Remove	Discard adapter gasket (20)
		o Assembly consisting of lube valve (21), lube valve spring (22) and valve guide tube (23)	Remove	Only if replacement is necessary. Pull from housing
		p Plug (24)	Remove	
		q Drive screw (25) and	Remove	Only if replacement is necessary Be sure new
		name plate	name plate (26)	
	r Vent assembly (27)	Remove	Only if replacement is necessary	

4-4. TRANSMISSION (CONT)

a. Transmission Housing (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

2		a All parts except housing (28)	Clean	Use dry cleaning solvent P-D-680. Move up and down in solvent until all old lubricant, dirt and grease are removed. Dry with clean cloths or with moisture-free compressed air
		b Housing (28)	Clean	Use clean cloths moistened with dry cleaning solvent P-D-680. Dry with clean cloths or with moisture-free compressed air

INSPECTION

3	a	Housing (28)	Inspect	Inspect for cracks, distortion and other damage, especially surfaces where housing mates
---	---	--------------	---------	--

14-4. TRANSMISSION (CONT)

a. Transmission Housing (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
3 (cont)				with other components. Check all holes for distortion, gouges, and damage to threads. Replace if necessary
		b Manual selector shaft (5)	Inspect	Inspect for burrs Remove with crocus cloth. Replace if necessary
		c All other parts	Inspect	Inspect for damage to all threads. Check for cracks, distortion, and other damage. Replace any items if necessary
REASSEMBLY				
4	Housing (28)	a Vent assembly (27)	Install	If old vent assembly (27) was removed. Don't over-tighten. Be careful not to distort or crush vent assembly stem
		b Drive screw (25) and new name plate (26)	Install	If old name plate (26) was removed. Stamp all information from old name plate onto new one
		c Plug (24)	Install	
		d New assembly consisting of lube valve (21), lube valve spring (22), and valve guide tube (23)	Install	If old assembly was removed. Press in
		e Lube valve adapter (19) and new adapter gasket (20)	Position	
		f Two new socket head screws (18)	Install	Tighten to 9-11 pounds foot

4-4. TRANSMISSION (CONT)

a. Transmission Housing (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
4 (cont)		g Cover (16) and new gasket (17)	Position	
		h Six capscrews (15)	Install	Tight enough to prevent leakage
		i Plug (14)	Install	Tight enough to prevent leakage
		j Capscrew (12) and washer (13)	Install	
		k Capscrew (10) and retainer (11)	Install	
		l Plug (9)	Install	Tight enough to prevent leakage
		m Plug (7) and washer (8)	Install	Tighten to 50-60 pounds foot
		n Selector seal (6)	Install away from tool	Place into seal installer, lip Apply nonhardening sealant to outer edge Install in bore. Lubricate inner bore of selector seal (6) with automatic transmission fluid
		o Manual selector shaft (5)	Install	Carefully push through selector seal (6)
		p Lever (4)	Position	So that selector valve pin projects toward inside of housing (28)
		q Nut (3)	Install	Tighten to 15-20 pounds foot
		r Shaft retainer pin (2)	Install	
		s Nut (1)	Install	

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly.

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly

INITIAL SETUP

Tools

No 2 Common Organizational Maintenance

Tool Kit

- Flat tip screwdriver
- Twist drill set
- Retaining ring pliers
- Mechanical puller kit
- Safety glasses
- Thickness gage
- Slip joint pliers
- Arbor press, 10 ton capacity, adjustable bed of 25 inches minimum opening

Drill press

Lathe

Soft-jawed vise

Main and output shaft orifice installer

J-24369

Sun gear shaft bushing installer

J-24468

Front planetary bushing installer

J-24469

Planetary carrier rebuild tool kit

J-25587-01

Removing, installing and swaging

fixture J-25587-1

Pin remover and installer adapter

J-25587-2

Support block J-25587-3

Support block J-25587-4

Pin remover and installer spacer

J-25587-6

Pin installer J-25587-11

Pin installer J-25587-12

Pin installer J-25587-13

Pin remover J-25587-16

Bottom swaging tool holder J-25587-17

Four 3/4 inch loading pins J-25587-18

Six 1/2 inch loading pins J-25587-22

Two swaging tools J-25587-23

Two swaging tools J-25587-27

Four 3/4 inch guide pins J-25587-48

Six 1/2 inch guide pins J-25587-50

Materials/Parts

Cleaning solvent

Item 1, Appendix C

Item 2, Appendix C

Item 9, Appendix C

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

4-4e

Main shaft and gear unit assembly removed from transmission

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY

1	Main shaft and gear unit assembly	a	Thrust washer (1)	Remove	Main shaft and gear assembly positioned shaft (4) end up
		b	Thrust washer (2)	Remove	
		c	Front sun gear (3)	Remove	
		d	Thrust washer (5)	Remove	


4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
1 (cont)		e Front planetary carrier assembly (6)	Remove	
		f Thrust washer (7)	Remove	
		g Center sun gear shaft assembly (8)	Remove	
2	Center sun gear shaft assembly (8)	Two spring pins (9)	Remove	Only if inspection shows replacement is necessary
3	Shaft and bushings (10)	Two bushings (11)	Remove	Only if inspection shows replacement is necessary. Position shaft (12) in vise with soft jaws and use mechanical puller kit to remove bushings (11)
4	Drum (13)	a Bearing assembly (14) and roller bearing race (15)	Remove	
		b Internal snap ring (16)	Remove	
		c Gear (17)	Remove	
		d Center planetary carrier assembly (18)	Remove	
		e Main shaft assembly (19) and attached parts	Remove	
5	Gear (20)	a External snap ring (21)	Remove	
		b Shaft (4)	Remove	
6	Shaft (4)	Lube orifice plug (22)	Remove	Only if inspection shows replacement is necessary

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).



TA236074

TA236074

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

KEY

1	Thrust washer	24	Snap ring
2	Thrust washer	25	Internal snap ring
3	Front sun gear	26	Rear planetary carrier assembly
4	Shaft	27	Bearing assembly
5	Thrust washer	28	Pinion set
6	Front planetary carrier assembly	29	Bushing
7	Thrust washer	30	Flange and carrier assembly
8	Center sun gear shaft assembly	31	Pins
9	Spring pins	32	Thrust washers
10	Shaft and bushings	33	Pinion thrust washers
11	Bushings	34	Pinion set
12	Shaft	35	Rollers
13	Drum	36	Carrier
14	Bearing assembly	37	Pins
15	Roller bearing race	38	Thrust washers
16	Internal snap ring	39	Pinion washers
17	Gear	40	Pinion set
18	Center planetary carrier assembly	41	Rollers
19	Main shaft assembly	42	Carrier
20	Gear	43	Pins
21	External snap ring	44	Thrust washers
22	Lube orifice plug	45	Pinion thrust washers
23	Gear	46	Rollers

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

7	Gear (23)	a	Snap ring (24)	Remove	
		b	Gear (20)	Remove	
8	Drum (13)	a	Internal snap ring (25)	Remove	
		b	Rear planetary carrier assembly (26)	Remove	
9	Rear planetary carrier assembly (26)		Bearing assembly (27)	Remove	If necessary, rotate pinion set (28) to help dislodge bearing assembly (27)

NOTE

Disassemble front, center, and rear planetary carrier assemblies (6, 18, and 26) only if inspection shows replacement of parts is necessary.

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
10	Front planetary carrier assembly (6)	Bushing (29)	Remove	Press out
11	Flange and carrier assembly (30)	a Six pins (31)	Remove:	Use drill press and drill bit slightly smaller than diameter of pins (31). Drill into rear end of pins (31). Do not drill into flange and carrier assembly (30). Place removing, installing and swaging fixture on arbor press. Place flange and carrier assembly (30) on fixture, drilled ends of pins (31) up. Install pin remover into fixture. Press pins (31) from flange and carrier assembly (30). Remove flange and carrier assembly (30) from arbor press
		b 12 thrust washers (32), 12 pinion thrust washers (33), pinion set (matched set of six pinions) (34), and 120 rollers (35)	Remove	

NOTE

Repeat step 11 to disassemble center planetary carrier assembly (18). Center planetary carrier assembly (18) consists of carrier (36), four pins (37), eight thrust washers (38), eight pinion washers (39), pinion set (matched set of four pinions) (40), and 72 rollers (41). Be sure in step 11a to drill into the front ends of pins (37).

Repeat step 11 to disassemble rear planetary carrier assembly (26). Rear planetary carrier assembly (26) consists of carrier (42), four pins (43), eight thrust washers (44), eight pinion thrust washers (45), 72 rollers (46), and pinion set (matched set of four pinions) (28). In step 11a be sure to use pin remover and installer adapter, and pin remover and installer spacer, to support rear planetary carrier assembly (26) in removing, installing and swaging fixture.

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

12		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt and old lubricant. Dry thoroughly with clean, dry, lintless cloths or with compressed air. Don't use compressed air to dry bearing assembly (14) and rollers (35, 41, and 46)
----	--	-----------	-------	--

INSPECTION

13	a	Front, center, and rear planetary carrier assemblies (6, 18, and 26)	Inspect	Inspect for worn, overheated, or contaminated condition. Inspect rollers (35, 41, and 46) for roughness and binding in operation. Check play of pinion sets (28, 34, and 40) by inserting thick-
----	---	---	---------	--

end

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
13 (cont)				ness gage between carriers (30, 36, and 42) and thrust washers (32, 38, and 44). End play must be within 0.008-0.031 inch. If you notice any defective conditions, replace part. Replace entire pinion set (28, 34, and 40) if any individual pinion is damaged. Refer to steps 10 and 11.
		b Bearing assembly (14)	Inspect	Inspect for roughness or binding in operation. Inspect for worn, galled, or bent condition. If you notice any of these conditions, replace part
		c Two spring pins (9)	Inspect	Inspect for worn, bent or broken condition. Replace if necessary. Refer to step 2
		d Two bushings (11)	Inspect	Inspect for galling, scratches or other wear. Replace if necessary. Refer to step 3
		e Lube orifice plug (22)	Inspect	Inspect for worn, bent or broken condition. Replace if necessary. Refer to step 6
		f All other parts	Inspect	Inspect for worn, bent or broken condition. Closely examine all gear teeth for any damage. Replace part if necessary

REASSEMBLY

NOTE

If the front, center, or rear planetary carrier assemblies (6, 18, or 26) were not disassembled, start with step 17. Otherwise start with steps 14 through 16 for reassembly of any planetary carrier assemblies that were disassembled.

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
14	Front planetary carrier assembly (6)	<ul style="list-style-type: none"> a. 120 rollers (35), twelve thrust washers (32), and twelve pinion thrust washers (33) b. Six groups, each consisting of two thrust washers (32), two pinion thrust washers (33), pinion (34) and 20 rollers (35) c. Six groups, each consisting of two thrust washers (32), two pinion thrust washers (33), pinion (34), and 20 rollers (35) d. Six 1/2 inch guide pins 	<ul style="list-style-type: none"> Lubricate Assemble. Insert 1/2 inch loading pins into pinions (34). Install rollers (35) around 1/2 inch loading pins. Install pinion thrust washers (33) and thrust washers (32) as shown in exploded view Install Install 	<ul style="list-style-type: none"> Use oil-soluble grease Flange and carrier assembly (30) rear end up Larger diameters first. Push out 1/2 inch loading pins

CAUTION

In following step, don't put any pressure on flange and carrier assembly (30), or you will distort it.

- e. Six pins (31)
 - Install removing, installing and swaging fixture onto arbor press. Install flange and carrier assembly (30) onto fixture. Install pin installer J-25587-13 into fixture, so that cutaway part will clear bosses of flange and carrier assembly (30) when pins (31) are pressed in. One at a time, place pins (31) on pilot ends of

4-4. TRANSMISSION (CONT)


b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)


14
(cont)

f. Six pins (31)



1/2 inch guide pins. Press into flange and carrier assembly (30) until pin installer touches flange and carrier assembly. Swage. Remove flange and carrier assembly (30) from removing, installing and swaging fixture. Install bottom swaging tool holder into fixture. Install one swaging tool J-25587-27 into bottom swaging tool holder and one into fixture. Lubricate both ends of pins (31) with oil-soluble grease. Position flange and carrier assembly (30) rear end up on fixture. Use support block J-25587-4 to level flange and carrier assembly while lower swaging tool is supporting lower end of pin (31). One pin at a time, apply pressure gradually (about two tons) to swage ends of pins against flange and carrier assembly (30), as shown. Pinion set (34) must rotate freely and have 0.008-0.031 inch end play. Remove flange and carrier assembly from fixture. Remove bottom swage tool holder from fixture

Use front planetary bushing installer to press bushing (29) into flange and carrier assembly to dimension shown



4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
14 (cont)		h. Bushing (29)	Bore	Use lathe to bore bushing (29) to diameter shown, step 14g. Bushing bore must be square with surface of flange and carrier assembly (30) within 0.001 inch
15	Center planetary carrier assembly (18)	a. 72 rollers (41), eight thrust washers (38), and eight pinion washers (39)	Lubricate	Use oil-soluble grease
		b. Four groups, each consisting of two thrust washers (38), two pinion washers (39), pinion (40), and 18 rollers (41)	Assemble	Insert 3/4 inch loading pins into pinions (40). Install rollers (41) around 3/4 inch loading pins. Install pinion washers (39) and thrust washers (38) as shown in exploded view
		c. Four groups, each consisting of two thrust washers (38), two pinion washers (39), pinion (40) and 18 rollers (41)	Install	Carrier (36) front end up
		d. Four 3/4 inch guide pins	Install	Larger diameters first. Push out 3/4 inch loading pins

CAUTION

In following step, don't put any pressure on carrier (36), or you will distort it.

- e. Four pins (37) Install carrier (36) onto removing, installing and swaging fixture. Install pin installer J-25587-11 into fixture, so that cutaway parts will clear bosses of carrier

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
16 (cont)		d. Four groups, each consisting of two thrust washers (44), two pinion thrust washers (45), pinion (28) and 18 rollers (46)	Install	Carrier (42) rear end up
		e. Four 3/4 inch guide pins	Install	Larger diameters first. Push out 3/4 inch loading pins


CAUTION

In following step, don't put any pressure on carrier (42), or you will distort it.

- | | |
|-------------------|--|
| f. Four pins (43) | Install. Install carrier (42) onto fixture, using pin remover and installer adapter, and pin remover and installer spacer. Install pin installer J-25587-12 into fixture so that cutaway part will clear bosses of carrier (42) when pins (43) are pressed in. One at a time, place pins (43) on pilot ends of 3/4 inch guide pins. Press into carrier (42) until pin installer touches carrier |
| g. Four pins (43) | Swage. Remove carrier (42), pin remover and installer adapter, and pin remover and installer spacer from removing, installing and swaging fixture. Install bottom swaging tool holder into fixture. Install one swaging tool J-25587-23 into bottom swaging tool holder and one into fixture. Lubricate both ends of pins (43) with oil-soluble grease. Position carrier (42) rear end up on fixture. Use support block J-25587-3 to level carrier while lower swaging tool is supporting lower end of pin (43). One pin at a time, apply pressure gradually (about three tons) to swage ends of pins (43) |

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont) 16 (cont)				against carrier (42), as shown. Pinion set (28) must rotate freely and have 0.008-0.031 inch end play. Remove carrier from fixture
				
17	Shaft (4)	New lube orifice plug (22)	Install	If old lube orifice plug (22) was removed. Use main and output shaft orifice installer. Install small-orificed end first. Press in until front of plug is recessed 0.140-0.180 inch below front end of shaft (4)
18	Center sun gear shaft assembly (8)	Two new spring pins (9)	Install	If old spring pins (9) were removed. Split in pin must be toward an adjacent spline tooth. Press in until outer end of pin (9) is flush with, to 0.010 inch below, top of spline teeth

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)
19 Shaft and
(cont) bushings

a. New front
bushing

Install

If old bushing (11) was removed. Use sun gear shaft bushing installer. Use proper step, as shown. Front bushing (11) should be installed to depth of 0.400-0.420 inch in shaft (12)




TA236077

b. New rear
bushing (11)

Install

If old bushing (11) was removed. Use sun gear shaft bushing installer. Use proper step, as shown. Rear bushing (11) should be installed to depth of 0.650-0.670 inch in shaft (12)

b. New rear
bushing (11) Install



TA236078

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont) 19 (cont)		c. Both bushings (11)	Bore	Use lathe to bore bushings (11) to 1.5640 to 1.5655 inches diameter. Bores must be concentric with outside diameter of shaft (12) with- in 0.002 inch
20	Rear planetary(27) carrier (26)	Bearing assembly	Install	If bearing assembly (27) was removed and rear planetary carrier assembly (26) was not repaired
21	Drum (13)	a. Rear planetary carrier assembly (26) b. Internal snap ring (25)	Install Install	Drum front side down
22	Gear (23)	a. Gear (20) b. Snap ring (24)	Install Install	Into rear of gear (23)
23	Gear (20)	Shaft (4)	Install	Into front of gear (20)
24	Shaft (4)	External snap ring (21)	Install	
25	Drum (13) attached parts	a. Shaft (4) and	Install	Gear (20) must sit against rear planetary carrier assembly (26)
26	Shaft (4)	a. Roller bearing race (15) b. Bearing assembly (14)	Install Install	Position drum (13) so that front of shaft (4) is up. Roller bearing race (15) inner lip up. Retain with oil-soluble grease Coat first with oil-soluble grease
27	Drum (13)	a. Center plan- etary carrier assembly (18) b. Gear (17) c. Internal snap ring (16)	Install Install Install	Pinion set (40) first Outer splines first

4-4. TRANSMISSION (CONT)

b. Main Shaft and Gear Unit Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
27 (cont)		d. Center sun gear shaft assembly (8)	Install	Larger diameter first. To sit on bearing assembly (14)
28	Front planetary carrier assembly (6)	Thrust washer (7) on rear hub	Install	Retain with oil-soluble grease
29	Drum (13) carrier assembly (6)	Front planetary	Install	
30	Front sun gear (3)	Thrust washer (5) on rear hub	Install	Retain with oil-soluble grease
31	Center sun gear shaft(3) assembly (8)	Front sun gear splines of front sun gear (3) match with locations of spring pins (9)	Install	Be sure that missing internal
32	Main shaft and gear unit assembly	a. Thrust washer (2)	Install	Retain with oil-soluble grease
		b. Thrust washer (1)	Install	Retain with oil-soluble grease

NOTE

For installation into transmission, refer to paragraph 4-4e.

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 2 Common Organizational Maintenance

Tool Kit

- Flat tip screwdriver
- Hand hammer
- Hand cold chisel
- Machinist's steel rule
- Safety glasses
- Retaining ring pliers
- Arbor press
- Forward and fourth clutch spring compressor J-6438-01
- Forward clutch gage J-26913
- Shim stock, 10 pieces, 3/32 by 0.020 by 3 inches

- Oil-soluble grease Item 9, Appendix C
- Hook type seal ring FSCM 73342 PN 6839163
- Five forward clutch discs FSCM 73342 PN 6834370
- Lip type ring FSCM 73342 PN 6833981
- Hook type seal rings FSCM 73342 PN 6833999
- Lip type ring FSCM 73342 PN 8623121

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition

Paragraph Condition Description
Oil pump and front support group removed from transmission.

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C4-41
- Automatic transmission fluid Item 8, Appendix C

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Transmission	Forward clutch and shaft assembly (1)	Remove	Grasp and lift
---	--------------	---------------------------------------	--------	----------------

DISASSEMBLY


2	Forward clutch and shaft assembly (1)	a. Bearing race (2), bearing assembly (3), and bearing race (4)	Remove	
		b. Hook type seal ring (5)	Remove	Discard

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

KEY

- 1. Forward clutch and shaft assembly
- 2. Bearing race
- 3. Bearing assembly
- 4. Bearing race
- 5. Hook type seal ring
- 6. Hook type seal rings
- 7. External snap ring
- 8. PTO drive gear
- 9. Internal snap ring




- 10. Hub
- 11. Hub
- 12. Bearing race
- 13. Bearing assembly
- 14. Bearing race
- 15. Forward clutch discs
- 16. Forward clutch plates
- 17. Turbine shaft and clutch housing assembly
- 18. Spring retainer
- 19. External snap ring
- 20. Clutch piston return spring
- 21. Forward clutch piston
- 22. Lip type ring
- 23. Lip type ring
- 24. Check balls
- 25. Pin
- 26. Valve plug
- 27. Valve spring
- 28. Centrifugal valve

TA236058

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		c. Two hook type seal rings (6)	Remove	Discard
		d. External snap ring (7)	Compress	Position forward clutch and shaft assembly (1) shaft downward through hole in work table. Locate external snap ring gap. At cutout nearest gap, press external snap ring into housing groove. Slip piece of shim stock between snap ring and PTO drive gear (8). Repeat on other side of external snap ring gap. Working around PTO drive gear (8), continue to compress external snap ring and insert pieces of shim stock at three inch intervals, as shown
		e. PTO drive gear (8)	Remove	
		f. External snap ring (7)	Remove	
		g. Internal snap ring (9)	Remove	
		h. Hub (10)	Remove	
		i. Hub (11)	Remove	
		j. Bearing race (12), bearing assembly (13), and bearing race (14)	Remove	



4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		k. Five forward clutch discs (15) and five forward clutch plates (16)	Remove	Discard five forward clutch discs (15) only
		l. Turbine shaft and clutch housing assembly (17)	Place in press	
		m. Spring retainer (18)	Depress	Use forward and fourth clutch spring compressor, as shown



		n. External snap ring (19)	Remove	As shown, step 2m
		o. Spring retainer (18) and clutch piston return spring	Remove	Remove forward and fourth clutch spring compressor from press
3	Forward(20) clutch piston (21)	Lip type ring (22)	Remove	Discard

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4	Turbine shaft and clutch housing assembly (17)	a. Lip type ring (23)	Remove	Return turbine shaft and clutch housing assembly (17) to work table. Discard lip type ring (23)
		b. Two check balls (24)	Remove	Only if inspection shows replacement is necessary. Remove staked metal from bores to free check balls (24)
		c. Pin (25)	Remove	Depress valve plug (26)
		d. Valve plug (26) and valve spring (27)	Remove	
		e. Centrifugal	Remove valve (28)	

CLEANING

WARNING'

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
5		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt, grease, and old lubricant. Dry thoroughly, using clean cloths or moisture-free compressed air. Don't dry bearing assemblies (3 and 13) with compressed air
INSPECTION				
6		a. Bearing assemblies (3 and 13)	Inspect	Insert into respective bearing races (2 and 4; 12 and 14) and check for smooth operation. If you notice roughness or binding, replace part
		b. Clutch piston return spring (20)	Inspect	Replace if bent, broken, or permanently set
		c. PTO drive gear (8)	Inspect	Check for broken teeth, cracks, distortion, or other damage. If you find any of these conditions, replace part
		d. Valve plug (26), valve spring (27), and centrifugal valve (28)	Inspect	Inspect for worn, bent, broken or distorted condition. If any of these conditions is found, replace part. Be sure that replacement part has same color coding as part replaced. Valve plug (26), valve spring (27), and centrifugal valve (28) must have same color coding
		e. Two check balls (24)	Inspect	Replace if they don't move freely in bores. See step 4b
		f. All other parts	Inspect	Inspect for worn, bent, broken, or distorted condition. If you find any of these conditions, replace part

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
7	Turbine shaft and clutch housing assembly (17)	a. Centrifugal valve (28)	Install	Conical end first
		b. Valve spring (27) and valve plug (26)	Position	
		c. Pin (25)	Install	Depress valve plug (26)
		d. Two new check balls (24)	Install	Position turbine shaft and clutch housing assembly (17) with shaft downward through hole in work table. Install new check balls (24) if old check balls were removed. Place check balls in bores. Stake each bore at three equally spaced places. Check balls must move when installed
		e. New lip type ring (23)	Install	Lubricate with automatic transmission fluid. Install so that lip faces fluid pressure side of forward clutch piston (21)
8	Forward clutch piston (21)	New lip type ring (22)	Install	Lubricate with transmission fluid. Install so that lip faces fluid pressure side of forward clutch piston (21)
9	Turbine shaft and clutch housing assembly (17)	a. Forward clutch piston (21)	Install	Be sure not to distort lip type rings (22 and 23)
		b. Five forward clutch plates (16) and five new forward clutch discs (15)	Install	Soak all forward clutch discs (15) in automatic transmission fluid for at least two minutes before installation. Install all forward clutch discs and plates (15 and 16) alternately, as shown in exploded view
		c. Hub (10)	Install	
		d. Internal snap ring (9)	Install	

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

10 Forward clutch clearance check

Clearance between hub (10) and top forward clutch disc (15)

Measure

Hold hub (10) up against internal snap ring (9), as shown. Insert forward clutch gage. When correct clearance is achieved, first step of forward clutch gage will fit, second step will not. If clearance is excessive, replace parts in following order to achieve correct clearance: 1) Any or all of forward clutch plates (16); 2) Hub (10). If clearance is still excessive, install thicker forward clutch piston (21). If clearance is insufficient, install thinner forward clutch piston (21). After installing any part, recheck clearance



NOTE

Parts removed in steps 11a through 11c below should be saved for reinstallation.

11 Turbine shaft and clutch housing (17)

- a. Internal snap ring (9)
- b. Hub (10)
- c. 10 forward clutch discs and plates (15 and 16)

Remove
Remove
Remove

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		d. Clutch piston return spring (20) and spring retainer (18)	Position	Place turbine shaft and clutch housing assembly (17) in press
		e. External snap ring (19)	Position	
		f. Spring retainer (18)	Depress	Use forward and fourth clutch spring compressor, as shown
		g. External snap ring (19)	Install	As shown, step 11f. Remove forward and fourth clutch spring compressor

CAUTION

Use oil-soluble grease to retain bearing races (12 and 14) and bearing assembly (13). Movement of these parts off center will cause improper installation of, and extensive damage to, forward clutch and shaft assembly (1).

		h. Bearing race (12)	Install	Position turbine shaft and clutch housing assembly shaft downward through hole in work table. Install bearing race (12) outer lip first
12	Hub (11)	a. Bearing race (14)	Install	Flat side first
		b. Bearing assembly (13)	Install	
13	Turbine shaft and clutch housing assembly (17)	a. Hub (11)	Install	Outer splines first
		b. Five forward clutch plates (16) and five forward clutch discs (15)	Install	Plates removed in step 11c. Install alternately, as shown in exploded view
		c. Hub (10)	Install	Hub (10) removed in step 11b

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
13 (cont)		d. Internal snap ring (9)	Install	Internal snap ring removed in step 11a
		e. External snap ring (7)	Install	
		f. PTO drive gear (8)	Install	Chamfered inside diameter first. Engage with external snap ring (7)

NOTE

Retain bearing races (2 and 4) and bearing assembly (3) with oil-soluble grease.

g. Bearing race (4)	Install	Flat side first
h. Bearing assembly (3)	Install	
i. Bearing race (2)	Install	Outer lip first

NOTE

Retain hook type seal rings (5 and 6) with oil-soluble grease.

j. Two new hook type seal rings (6)	Install	Invert forward clutch and shaft assembly (1)
k. New hook type seal ring (5)	Install	

INSTALLATION


NOTE

To ease installation of forward clutch and shaft assembly (1) in step 14, align fourth clutch plates in transmission and direct compressed air into fourth clutch apply port. Compressed air will apply fourth clutch and keep fourth clutch plates from moving while inserting forward clutch and shaft assembly (1).

4-4. TRANSMISSION (CONT)

c. Forward Clutch and Shaft Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
14	Transmission	Forward clutch and shaft assembly (1)	Install	Be sure bearing races (2 and 4) and bearing assembly (3) are securely retained on hub (11). If bearing race (2) will not adhere, place it on fourth clutch assembly hub in transmission. Lower forward clutch and shaft assembly (1), engaging splines on hub (10) with fourth clutch plates. When correctly installed, front surface of forward clutch and shaft assembly (1) is about 1/2 inch behind forward edge of PTO opening



4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly.

- This task covers:
- a. Removal
 - b. Disassembly
 - c. Cleaning
 - d. Inspection
 - e. Reassembly
 - f. Installation

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Flat tip screwdriver
- Hand hammer
- Hand cold chisel
- Safety glasses
- Retaining ring pliers
- Forward and fourth clutch spring compressor J-6438-01
- Clutch spring compressor base J-24204-2
- Fourth clutch gage J-26917

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Automatic transmission fluid Item 8, Appendix C
- Oil-soluble grease Item 9, Appendix C
- Four fourth clutch discs FSCM 73342 PN 6834370
- Ring FSCM 73342 PN 6833981
- Ring FSCM 73342 PN 8623121

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
4-4c	Forward clutch and turbine shaft group removed from transmission.


STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Transmission	Fourth clutch assembly (1)	Remove	Grasp spring retainer (2) and lift. Remove to work table
DISASSEMBLY				
2	Fourth clutch assembly (1)	a. Two bearing races (3 and 4) and bearing assembly (5)	Remove	You may need to remove bearing race (4) from center support hub in transmission

4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly (cont).

KEY

- 1. Fourth clutch assembly
- 2. Spring retainer
- 3. Bearing race
- 4. Bearing race
- 5. Bearing assembly
- 6. External snap ring
- 7. Piston return spring
- 8. Internal snap ring
- 9. Plate
- 10. Fourth clutch discs
- 11. Fourth clutch plates
- 12. Piston
- 13. Ring
- 14. Housing assembly
- 15. Ring
- 16. Check balls



TA236062


4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

2 (cont)		b. Spring retainer (2)	Depress	Use forward and fourth clutch spring compressor and clutch spring compressor base, as shown
-------------	--	---------------------------	---------	---



		c. External snap ring (6)	Remove	As shown, step 2b
		d. Spring retainer (2) and piston return spring (7)	Remove	Remove forward and fourth clutch spring compressor and clutch spring compressor base
		e. Internal snap ring (8)	Remove	
		f. Plate (9)	Remove	
		g. Eight fourth clutch discs and plates (10 and 11)	Remove	Discard four fourth clutch discs (10) only. Reuse only if new fourth clutch discs aren't available
		h. Piston (12)	Remove	
3	Piston (12)	Ring (13)	Remove	Discard

4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
4	Housing assembly (14)	a. Ring (15) b. Four check balls (16)	Remove Remove	Discard Only if inspection shows replacement is necessary. Remove staked metal from bores to free check balls (16)

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

5		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt, grease, and old lubricant. Dry thoroughly, using clean cloths
---	--	-----------	-------	---

4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
5 (cont)				or moisture-free compressed air. Don't dry bearing assembly (5) with compressed air
INSPECTION				
6		a. Bearing assembly (5)	Inspect	Insert into bearing races (3 and 4) and check for smooth operation. If you notice roughness or binding, replace part
		b. Piston return spring (7)	Inspect	Replace if bent, broken, or permanently set
		c. All other parts	Inspect	Inspect for worn, bent, broken, or distorted condition. If you find any of these conditions, replace part
REASSEMBLY				
7	Housing assembly (14)	a. Four new check balls (16)	Install	If old check balls (16) were removed. Place check balls in bores. Stake each bore at three equally spaced places. Check balls must move when installed
		b. New ring (15)	Install	Lubricate with automatic transmission fluid. Install so that lip faces fluid pressure side of piston (12)
8	Piston (12)	a. New ring (13)	Install	Lubricate with automatic transmission fluid. Install so that lip faces fluid pressure side of piston (12)
9	Housing assembly (14)	a. Piston (12)	Install	Be sure not to distort rings (13 and 15)

4-4. TRANSMISSION (CONT)


d. Fourth Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

9 (cont)		b. Four fourth clutch plates (11) and four new fourth clutch discs (10)	Install	Soak all fourth clutch discs (10) in automatic transmission fluid for at least two minutes before installation. Install all fourth clutch plates and discs (10)
		c. Plate (9)	Install	
		d. Internal snap ring (8)	Install	
	10	Fourth clutch clearance check	Clearance between plate (9) and top fourth clutch disc (10)	

As shown. Insert fourth clutch gage. When correct clearance is achieved, first step of fourth clutch gage will fit, second step will not. If clearance is excessive, replace parts in following order to achieve correct clearance: 1) Any or all of fourth clutch plates (11); 2) Plate (9). If clearance is still excessive, install thicker piston (12). If clearance is insufficient, install thinner piston (12). After installing any part, recheck clearance



11	Housing assembly (14)	a. Piston return spring (7) and spring retainer (2)	Position
----	-----------------------	---	----------


4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

11 (cont)		b. External snap ring (6) c. Spring retainer (2)	Position Depress	Use forward and fourth clutch spring compressor and clutch spring compressor base, as shown
--------------	--	---	---------------------	---



d. External snap ring (6)			Install	As shown, step 11c. Remove forward and fourth clutch spring compressor and clutch spring compressor base
---------------------------	--	--	---------	--

NOTE

Use oil-soluble grease to retain bearing races (3 and 4) and bearing assembly (5).

4-4. TRANSMISSION (CONT)

d. Fourth Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		e. Bearing race (3)	Install	Outer lip first
		f. Bearing assembly (5)	Install	
		g. Bearing race (4)	Install	Flat side up

INSTALLATION

NOTE

To ease installation of fourth clutch assembly (1) in step 12, align third clutch plates in transmission.

12	Transmission	Fourth clutch assembly (1)	Install	Be sure bearing races (3 and 4) and bearing assembly (5) are securely retained on housing assembly (14). If bearing race (4) will not adhere, place it on center support hub in transmission. Grasp spring retainer (2) and lower fourth clutch assembly (1) onto center support hub, engaging splines on housing assembly (14) with third clutch plates
----	--------------	----------------------------	---------	--

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies.

- | | | |
|-------------------|--|--|
| This task covers: | a. Removal
(1) Third clutch, center support, and second clutch assemblies
(2) Main shaft and gear unit assembly
b. Disassembly
c. Cleaning | d. Inspection
e. Reassembly
f. Installation
(1) Main shaft and gear unit assembly
(2) Third clutch, center support, and second clutch assemblies |
|-------------------|--|--|

INITIAL SETUP

Tools

No. 1 Common Organizational Maintenance

Tool Kit

- Socket wrench handle, 1/2 inch drive
- Socket wrench set, 1/2 inch drive
- Torque wrench, 1/2 inch drive, 175 pounds foot capacity
- Flat tip screwdriver
- Safety glasses

0-1 inch micrometer

Arbor press

Center support lifter J-24455

Gear unit lifter J-24454

Hoist

Sun lamp

Diagonal cutting pliers

Center support bushing installer J-24794

Lock ring installer J-24453

Compressor base J-24475-1

Compressor bar J-24475-2

Two capscrews 3/8-16 by 1-1J4 inches

Center bolt J-23717-1

Snapping gage J-24208-4

Second clutch gage J-26915

Third clutch gage J-26916

- | | |
|---------------------|------------------------|
| Oil filter | FSCM 73342 PN 23010654 |
| Ring seal | FSCM 73342 PN 6761244 |
| Capscrew | FSCM 73342 PN 23013398 |
| Washer | FSCM 73342 PN 9422847 |
| Three discs | FSCM 73342 PN 6835720 |
| Five rings | FSCM 73342 PN 9414220 |
| Ring | FSCM 73342 PN 6834354 |
| Lip type seal rings | FSCM 73342 PN 6883035 |

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

4-4d	Fourth clutch assembly removed from transmission.
------	---

Materials/Parts


- | | |
|--------------------------|-----------------------|
| Cleaning solvent | Item 1, Appendix C |
| Clean cloths | Item 2, Appendix C |
| Transmission oil | Item 8, Appendix C |
| Oil-soluble grease | Item 9, Appendix C |
| Three third clutch discs | FSCM 73342 PN 6835720 |
| Seal rings | FSCM 73342 PN 6836772 |
| Lip type seal rings | FSCM 73342 PN 6833986 |

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

KEY

- | | |
|------------------------|------------------------|
| 1. Internal snap ring | 7. Snap ring |
| 2. Plate | 8. Support |
| 3. Third clutch discs | 9. Seal rings |
| 4. Third clutch plates | 10. Internal snap ring |
| 5. Capscrew | 11. Discs |
| 6. Washer | 12. Plates |
| | 13. Plate |
| | 14. Oil filter |
| | 15. Ring seal |
| | 16. Piston |
| | 17. Piston |



- | |
|--------------------------------|
| 18. Lip type seal ring |
| 19. Lip type seal ring |
| 20. Rings |
| 21. Spring retainer ring |
| 22. Piston return springs |
| 23. Lip type seal ring |
| 24. Lip type seal ring |
| 25. Rings |
| 26. Ring |
| 27. Piston return springs |
| 28. Bushing and center support |
| 29. Bushing |
| 30. Check ball |

TA236065

4-4. TRANSMISSION (CONT)


e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Transmis- sion	a. Internal snap ring (1)	Remove	
		b. Plate (2)	Remove	
		c. Three third clutch discs (3) and third clutch plates (4)	Remove	Discard third clutch discs (3) only. Reuse only if new third clutch discs (3) aren't available
		d. Capscrew (5) and washer (6)	Remove	From bottom center of trans- mission. Discard capscrew (5)
		e. Snap ring (7)	Remove	

CAUTION

Center support fits tightly into transmission. If necessary to ease removal, heat the transmission housing slightly. A sun lamp, or a current of warm air is enough. Don't use torch, or you will distort transmission housing. If you feel center support binding during removal, tap down and lift again.

f.	Support (8) and attached parts	Remove	Attach center support lifter into recess between seal rings (9) on support hub, as shown. Lift up. Remove to work table
----	--------------------------------------	--------	---



TA236066

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont.)


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

1
(cont)

g. Main shaft
and gear unit
assembly

Remove Attach gear unit lifter behind splines of main shaft and gear unit assembly, as shown. Attach hoist to ring on gear unit lifter and remove main shaft and gear unit assembly. Set aside on work table. Refer to paragraph 4-4b for exploded view and repair instructions



h. Internal snap ring (10)
i. Three discs (11) and plates (12)
j. Plate (13)

Remove
Remove
Remove

Discard discs (11) only. Reuse only if new discs (11) aren't available

2 Support (8)

a. Oil filter (14) and ring seal (15)
b. Pistons (16 and 17)

Remove
Remove

Discard both

3 Piston (16)

a. Lip type seal ring (18)
b. Lip type seal ring (19)

Remove
Remove

Discard
Discard

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
3 (cont)		c. Four rings (20)	Remove	Only if inspection shows piston (16) or attached parts must be replaced. Cut rings (20) off with diagonal cutting pliers to prevent damage to piston projections
		d. Spring retainer ring (21)	Remove	
		e. 20 piston return springs (22)	Remove	

NOTE

Repeat step 3 for piston (17), lip type seal rings (23 and 24), four rings (25), ring (26), and 20 piston return springs (27).

4	Bushing and center support (28)	a. Two seal rings (9)	Remove	Discard
		b. Bushing (29)	Remove	Only if inspection shows replacement is necessary. Mark location of bushing notch in relation to support (8). Press out
		c. Check ball (30)	Remove	
CLEANING				

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)

WARNING

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

5		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt and old lubricant. Dry thoroughly with compressed air or with clean, dry, lintless cloths
---	--	-----------	-------	--

INSPECTION

6	a.	Bushing (29)	Inspect	Inspect for scoring, galling, other wear. Replace if necessary. See step 4b
	b.	Pistons (16 and 17) and attached parts	Inspect	Inspect for worn, bent, or broken condition, especially projections on pistons (16 and 17). If you notice any of these conditions, replace part. See steps 3c-e
	c.	All other parts	Inspect	Inspect for worn, bent, or broken condition. If you notice any of these conditions, replace part

REASSEMBLY

7	Support (8)	a. New check ball (30)	Install	If old check ball (30) was removed
---	-------------	------------------------	---------	------------------------------------


4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

7 (cont)		b. New bushing (29)	Install	If old bushing (29) was removed. Press in as shown. Use center support bushing installer. New bushing (29) requires no reaming
-------------	--	------------------------	---------	--



c		Piston (16)	Install	If piston (16) and attached parts were disassembled earlier
d		20 piston return springs (22)	Install	
e		Spring retainer ring (21)	Install	


4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

7 (cont)		f. Four new rings (20)	Install	Use lock ring installer. As you install rings (20), compress piston return springs (22) by forcing spring retainer ring (21) down into cavity. This will push piston (16) to bottom of cavity, assuring correct clutch clearance later
-------------	--	---------------------------	---------	--



		g. Piston (16)	Remove	
8	Piston (16)	a. New lip type seal ring (19)	Install	Lubricate first with oil- soluble grease. Lip must face piston cavity of support (8)
		b. New lip type seal ring (18)	Install	Lubricate first with oil- soluble grease. Lip must face piston cavity of support (8)

NOTE

Repeat steps 7c-f and 8 for piston (17), 20 piston return springs (27), ring (26), four new rings (25), and new lip type seal rings (23 and 24).

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
9	Support (8)	a Piston (17)	Install	Closed end of cone first. Be sure ring seal (15) seats against shoulder of bushing and center support (28)
		b New oil filter (14) and new ring seal (15)	Install	

INSTALLATION

NOTE

Before final installation, measurement must be taken to determine correct snap ring (7) to be used Also, second clutch clearance must be checked To do these, remaining assemblies must be removed from transmission housing.

10	Transmis- sion	a First clutch assembly	Remove	Para 4-4f
		b Governor and rear cover assembly	Remove	Para 4-4k
		c Low planetary, low clutch, and adapter housing as- semblies	Remove	Para 4-4g
		d Plate (13)	Install	Transmission positioned torque converter end up
		e Three new discs (11) and three plates (12)	Install	Soak new discs (11) in trans- mission fluid for at least two minutes first. Install alternately, as shown in exploded view
		f. Internal snap ring (10)	Install	

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


INSTALLATION (cont)

10

g. Support (8)

Install

Attach center support lifter into recess between seal ring grooves on support hub, as shown. Lower support (8) into transmission making sure that threaded hole in support (8) aligns with hole for capscrew (5) in transmission. Seat support (8) firmly against internal snap ring (10). Remove center support lifter.



h. New capscrew (5) and washer (6)


Install

Finger tight only

i. Support (8)

Compress

Install compressor base over hub of support (8), as shown. Install compressor bar and center bolt, as shown. Use two capscrews. Apply five pounds foot torque to center bolt



4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


INSTALLATION (cont)

10 (cont)		j. Clearance between top of support (8) and top of snap ring groove in transmission	Measure	Use snapping gage, as shown, step 10f. Select correct snap ring (7) as listed
--------------	--	---	---------	---

Measured Clearance (Inch)	Snap Ring Thickness (Inch)	Snap Ring Color
0.150-0.154	0.148-0.150	Blue
0.154-0.157	0.152-0.154	Yellow
0.157-0.160	0.155-0.157	Green
0.160-0.164	0.158-0.160	Red

k. Selected snap ring (7)	Install	Then remove center bolt, cap-screws, compressor bar, and compressor base
---------------------------	---------	--


11	Second clutch clearance check	Clearance between plate (13) and transmission housing	Measure	Turn transmission output end up. Use second clutch gage, as shown. If required clearance of 0.049-0.111 inch is achieved, first step of clutch gage will fit, second step won't. If clearance is not correct, remove discs (11) and plates (12) and measure total thickness. Replace any or all plates (12) to achieve correct clearance. A thinner or thicker plate (13) is also available
----	-------------------------------	---	---------	---



4-4. TRANSMISSION (CONT)


e. Third Clutch, Center Support, and Second Clutch

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
12	Transmission	a Low planetary, low clutch, and adapter housing assemblies	Install	Repair first, if necessary. Para 4-4g
		b Governor and rear cover assembly	Install	Repair first, if necessary. Para 4-4k
		c Center support and second clutch assemblies	Remove	Turn transmission torque converter end up. Refer to steps d-f, h-j. Keep center support and second clutch assemblies together for later installation
		d First clutch assembly	Install	Repair first, if necessary. Para 4-4f
		e Main shaft and gear unit assembly	Install	Repair first, if necessary. Para 4-4b Be sure that thrust washer is retained with oil-soluble grease to rear of main shaft and gear unit assembly. Attach gear unit lifter behind splines, as shown. Attach hoist to ring on gear unit lifter and lower into transmission. Be sure main shaft and gear unit assembly is fully seated against first clutch assembly and all gears and splines are engaged



4-4. TRANSMISSION (CONT)


e. Third Clutch, Center Support, and Second Clutch

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
12 (cont)		f. Plate (13) g. Three discs (11) and plates (12)	Install Install	Same plate removed in step 12c Same discs and plates removed n step 12c. Install alternately, as shown in exploded view
		h. Internal snap ring (10)	Install	Then check to be sure thrust washer is in place on front of main shaft and gear unit assembly
13	Support (8)	Piston (16)	Install	Be sure not to distort lip type seal rings (18 and 19)
14	Transmission	a. Bushing and center support (28), and attached parts	Install	Attach center support lifter into recess between seal ring grooves on support hub, as shown. Lower support (8) into transmission, making sure that threaded hole in support (8) aligns with hole for capscrew (5) in transmission. Also, be sure that gap in internal snap ring (10) is between any two tangs on ring (26). Seat support (8) firmly against internal snap ring (10). Remove center support lifter
				
		b. Capscrew (5) and washer (6)	Install	Same capscrew and washer removed in step 12c. Finger tight only

4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
14 (cont)		c Snap ring (7)	Install	Snap ring (7) selected in step 10j. Place gap between any two tangs on spring retainer ring (21)
		d Capscrew (5)	Tighten	To 39-46 pounds foot
15	Bushing and center support (28)	Two new seal rings (9)	Install	Retain with oil-soluble grease
16	Transmission	a Three third clutch plates (4) and three new third clutch discs (3)	Install	Soak third clutch discs (3) in transmission fluid for at least two minutes first. Install alternately, as shown in exploded view. Insert clutch plates (4) so that three sets of double tangs are positioned as shown below



- b Plate (2) Install
- c Internal snap ring (1) Install


4-4. TRANSMISSION (CONT)

e. Third Clutch, Center Support, and Second Clutch Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSTALLATION (cont)

17	Third clutch clearance check	Clearance between internal snap ring (1) and plate (2)	Measure	Use third clutch gage, as shown. If required clearance of 0.050-0.114 is achieved, first step of third clutch gage will fit, second step won't. If clearance is not correct, remove third clutch plates (4) and third clutch discs (3) and measure total thickness. Replace any or all third clutch plates (4) to achieve correct clearance. A thinner or thicker plate (2) is also available
----	------------------------------	--	---------	---



4-4. TRANSMISSION (CONT)

f. First Clutch Assembly.

- This task covers:
- a. Removal
 - b. Cleaning
 - c. Inspection
 - d. Installation

INITIAL SETUP

Tools

No. 2 Common Organizational Maintenance Tool Kit

- Socket wrench handle, 1/2 inch drive
- Socket wrench set, 1/2 inch drive
- Flat tip screwdriver
- Safety glasses
- Retaining ring pliers
- First clutch gage J-26914
- 0-1 inch micrometer

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Transmission fluid Item 8, Appendix C
- Oil-soluble grease Item 9, Appendix C
- Discs FSCM 73342 P/N 6835687

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition


Paragraph Condition Description

4-4e Third clutch, center support, and second clutch assemblies removed from transmission; main shaft and gear unit assembly removed from transmission.

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Trans- mission	Assembly consist- ing of gear (1), hub (2), and internal snap ring (3)	Remove	
2	Gear (1)	a Internal snap ring (3)	Remove	Only if inspection shows re- placement of parts is neces- sary
		b Hub (2)	Remove	
3	Trans- mission	a Internal snap ring (4)	Remove	Discard six discs (6) only. Reuse only if new discs aren't available
		b Plate (5)	Remove	
		c Six discs (6) and six plates (7)	Remove	

4-4. TRANSMISSION (CONT)

f. First Clutch Assembly (cont).



KEY

- 1. Gear
- 2. Hub
- 3. Internal snap ring
- 4. Internal snap ring
- 5. Plate
- 6. Discs
- 7. Plates

TA236079

4-4. TRANSMISSION (CONT)

f. First Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

4		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt and old lubricant. Dry thoroughly with clean, dry, lintless cloths or with compressed air
---	--	-----------	-------	--


INSPECTION

5	a.	Gear (1) and hub (2)	Inspect	Inspect for worn, bent or broken condition. Look for galling and damaged teeth. Replace part if necessary
	b.	All other parts	Inspect	Inspect for worn, bent, or broken condition. Examine for deep scratches. If you notice any of these conditions, replace part

4-4. TRANSMISSION (CONT)

f. First Clutch Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION				
6	Gear (1)	a. Hub (2) b. Internal snap ring (3)	Install Install	If removed earlier If removed earlier
7	Trans- mission	a. Assembly consisting of gear (1), hub (2), and internal snap ring (3)	Install	Be sure that splines on hub (2) engage splines on low sun gear in adapter housing. Also be sure that thrust washer is properly positioned on hub of adapter housing
		b. Six plates (7) and six new discs (6)	Install	Soak discs (6) in clean transmission fluid for at least two minutes before installation. Install plates (7) and discs (6) alternately, as shown in exploded view Flat side first
		c. Plate (5)	Install	
		d. Internal snap ring (4)	Install	
8	First clutch clearance check	Clearance between internal snap ring (4) and plate (5)	Measure	Use first clutch gage, as shown. If the correct clearance of 0.074-0.147 inch is achieved, first step of gage will fit, second step won't. If clearance isn't correct; remove discs (6) and plates (7) and measure total thickness. Replace any or all plates (7) to achieve correct clearance. Thinner and thicker plates (5) are also available



4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies.

- This task covers:
- | | |
|----------------|-----------------|
| a. Removal | d. Inspection |
| b. Disassembly | e. Reassembly |
| c. Cleaning | f. Installation |

INITIAL SETUP

Tools

No. 2 Common Organizational Maintenance

Tool Kit

- Flat tip screwdriver
- Sharpening stone
- Twist drill set
- Socket head screw key set
- Retaining ring pliers
- Safety glasses

Thickness gage

Lathe

Depth micrometer

Arbor press

Drill press

Low and first clutch spring compressor
J-24452

Clutch spring compressor base J-24204-2
Removing, installing and swaging fixture
J-25587-1

Pin remover J-25587-16

Six 5/8 inch loading pins J-25587-20

Six 5/8 inch guide pins J-25587-49

Pin installer J-25587-8

Bottom swaging tool holder J-25587-17

Two swaging tools J-25587-25

Support block J-25587-3
mission.

Low planetary bushing installer J-24472

Two adapter housing guide screws
J-1927-1

Materials/Parts

Cleaning solvent Item 1, Appendix C

Clean cloths Item 2, Appendix C

Transmission fluid Item 8, Appendix C

Oil-soluble grease Item 9, Appendix C

Discs FSCM 73342 P/N 6835720

Adapter housing

gasket FSCM 73342 P/N 6837442

Lip type seal ring FSCM 73342 P/N 6883035

Two lip type seal

rings FSCM 73342 P/N 6883031

Lip type seal ring FSCM 73342 P/N 6883033

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

4-4k	Governor and rear cover assembly removed from trans-
------	---


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Trans- mission	Gear (1)	Remove	
2	Gear (1)	Thrust washer (2)	Remove	
3	Trans- mission	Carrier assembly (3)	Remove	

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).




TA236089

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL (cont)				
4	Carrier assembly (3)	Thrust washer (4)	Remove	
5	Transmission	a. Low sun gear (5)	Remove	
		b. Thrust washer (6)	Remove	
		c. Six plates (7) and five discs (8)	Remove	Discard discs (8) only. Reuse only if new discs aren't available
(9)		d. Adapter housing	Remove	From transmission
6	Adapter housing (9)	Thrust washer (10)	Remove	
7	Transmission	Adapter housing gasket (11)	Remove	Discard
DISASSEMBLY				
8	Rear cover assembly	a. Spring retainer (12)	Depress	Place low and first clutch spring compressor on spring retainer, as shown. Install clutch spring compressor base and tighten screw



4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
8 (cont)		b. External snap ring (13)	Remove	As shown, step 8a Remove clutch spring compressor base and low and first clutch spring compressor
		c. Spring retainer (12)	Remove	
		d. 26 piston release springs (14)	Remove	
		e. Low clutch piston (15)	Remove	
9	Low clutch piston (15)	a. Lip type seal ring (16)	Remove	Discard
		b. Lip type seal ring (17)	Remove	Discard

NOTE

Disassemble carrier assembly (3) only if inspection shows replacement of parts is necessary.

10	Carrier and bushing assembly (19)	a. Bushing (20)	Remove	Press out
		b. Six pins (21)	Remove. Use drill press and drill bit slightly smaller than diameter of pins (21). Drill into rear ends of pins (21). Do not drill into carrier and bushing assembly (19). Place removing, installing and swaging fixture on arbor press. Place carrier and bushing assembly (19) on fixture, drilled ends of pins (21) up. Install pin remover into fixture. Press pins (21) from carrier and bushing assembly (19). Remove carrier and bushing assembly (19) from arbor press	

4-4. TRANSMISSION (CONT)


g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

10 (cont)		c. 12 thrust washers (22), 12 pinion thrust washers (23), pinion set (matched set of six pinions) (24), and 114 rollers (25)	Remove	
11	Adapter housing (9)	a. Plug (18) b. Spring retainer (26)	Remove Depress	

Adapter housing on work table, piston up, as shown. Install low and first clutch spring compressor. Attach clutch spring compressor base and tighten base screw



		c. External snap ring (27)	Remove	
		d. Spring retainer (26)	Remove	
		e. 26 piston release springs (28)	Remove	

As shown, step 11b. Remove clutch spring compressor base and low and first clutch spring compressor

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
11 (cont)		f. First clutch piston (29)	Remove	
12	First clutch piston (29)	a. Lip type seal ring (30)	Remove	Discard
		b. Lip type seal ring (31)	Remove	Discard

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

13		a. All parts, except adapter housing (9)	Clean	Use cleaning solvent P-D-680. Immerse in solvent and move up and down to remove all dirt and old lubricant. Dry thoroughly with compressed air or with clean, dry, lintless cloths
----	--	--	-------	--

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
13 (cont)		b. Adapter housing (9)	Clean	Wipe with clean cloths moistened with cleaning solvent P-D-680. Remove all dirt and old lubricant. Dry thoroughly with compressed air or with clean, dry, lintless cloths
INSPECTION				
14		a. Carrier assembly (3)	Inspect	Inspect for worn, overheated, or contaminated condition. Inspect rollers (25) for roughness and binding in operation. Check end play of pinion set (24) by inserting thickness gage between carrier and bushing assembly (19) and thrust washers (22). End play must be 0.008 to 0.031 inch. Inspect bushing (20) for galling and scratches. If you notice any defective conditions, replace part. Replace entire pinion set (24) if any individual pinion is damaged. Refer to step 10
		b. Gear (1) and low sun gear (5)	Inspect	Inspect for cracks, distortion, and wear. Inspect teeth and splines for wear, pitting, nicks, cracks or scores. Remove small nicks with suitable sharpening stone. Replace if necessary
		c. Adapter housing (9)	Inspect	Inspect for cracks, distortion, and wear. Inspect gasket surfaces for scratches, other wear. Replace if necessary
		d. Piston release springs (14)	Inspect	Replace if broken, bent, or permanently set and 28)

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
14 (cont)		e. All other parts	Inspect	Inspect for worn, cracked, bent or broken condition. If any of these conditions are noted, replace part

REASSEMBLY

NOTE

If carrier assembly (3) was disassembled, start with step 15. Otherwise, proceed to step 16.

15	Carrier and bushing assembly (19)	a. 114 rollers (25), twelve thrust washers (22), and twelve pinion thrust washers (23)	Lubricate	Use oil-soluble grease
		b. Six groups, each consisting of two thrust washers (22), two pinion thrust washers (23), pinion (24), and 19 rollers (25)	Assemble. Insert 5/8 inch loading pins into pinions (24). Install rollers (25) around 5/8 inch loading pins. Install pinion thrust washers (23) and thrust washers (22) as shown in exploded view	
		c. Six groups, each consisting of two thrust washers (22), two pinion thrust washers (23), pinion (24), and 19 rollers (25)	Install	Carrier and bushing assembly (19) rear end up
		d. Six 5/8 inch guide pins	Install	Larger diameters first. Push out 5/8 inch loading pins

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

15
(cont)

CAUTION


In following step, don't put any pressure on carrier and bushing assembly (19), or you will distort it.

e. Six pins (21)

Install. Install removing, installing and swaging fixture onto arbor press. Install carrier and bushing assembly (19) onto fixture. Install pin installer into fixture, so that cutaway part will clear bosses of carrier and bushing assembly (19) when pins (21) are pressed in. One at a time, place pins (21) on pilot ends of 5/8 guide pins. Press into carrier and bushing assembly (19) until pin installer touches carrier and bushing assembly

f. Six pins (21)

Swage. Remove carrier and bushing assembly (19) from removing, installing and swaging fixture. Install bottom swaging tool holder into fixture. Install one swaging tool into bottom swaging tool holder and one into fixture. Lubricate both ends of pins (21) with oil-soluble grease. Position carrier and bushing assembly (19) rear end up on fixture. Use support block to level carrier and bushing assembly while lower swaging tool is supporting lower end of pin (21). One pin at a time, apply pressure gradually (about three tons) to swage ends of pins against carrier and bushing assembly (19), as shown. Pinion set (24) must rotate freely and have end play of 0.008 to 0.031 inch. Remove carrier and bushing assembly (19) from fixture. Remove bottom swaging tool holder and removing, installing and swaging fixture from arbor press



4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

If old bushing (20) was removed. Use low planetary bushing installer to press bushing (20) into carrier and bushing assembly (19) to dimension shown

15
(cont)

g. New bushing
(20)

Install



h. Bushing (20)

Bore

Use lathe to bore bushing (20) to diameter shown, step 15g. Bushing bore must be square with surface of carrier and bushing assembly (19) within 0.001 inch

16 First clutch piston (29)

a. New lip type seal ring (31)

Install

Lubricate with oil-soluble grease. Be sure .lip faces fluid pressure side of first clutch piston (29)

b. New lip type seal ring (30)

Install

Lubricate with oil-soluble grease. Be sure lip faces fluid pressure side of first clutch piston (29)

17 Adapter housing (9)

a. Plug (18)
b. First clutch piston (29)

Install
Install

Tight enough to prevent leaks
Aline lug on first clutch piston (29) with recess in adapter housing (9). Be sure not to distort lip type seal rings (30 and 31)


4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

17 (cont)		c. 26 piston re- lease springs (28)	Install	
		d. Spring retainer (26)	Install	Cupped side first
		e. External snap ring (27)	Position	
		f. Spring retainer (26)	Depress	Install low and first clutch spring compressor, as shown. Attach clutch spring compressor base and tighten base screw




		g. External snap ring (27)	Install	As shown, step 17f. Remove clutch spring compressor base and low and first clutch spring compressor. Turn adapter housing piston side down on work table
		h. Six plates (7) and five new discs (8)	Install	Soak discs in clean trans- mission fluid for at least two minutes before installa- tion. Install alternately, as shown in exploded view

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
18	Low clutch piston (15) (17)	a. New lip type seal ring	Install	Lubricate with transmission fluid. Install so that lip faces fluid pressure side of low clutch piston (15)
		b. New lip type seal ring (16)	Install	Lubricate with transmission fluid. Install so that lip faces fluid pressure side of low clutch piston (15)
19	Rear cover assembly	a. Low clutch piston (15)	Install	Rear cover assembly front side up. Be sure not to distort lip type seal rings (16 and 17)
		b. 26 piston release springs (14)	Install	
		c. Spring retainer (12)	Install	Cupped side first
		d. External snap ring (13)	Position	
		e. Spring retainer (12)	Depress	Place low and first clutch spring compressor on spring retainer (12), as shown. Install clutch spring compressor base and tighten screw.



4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
19 (cont)	f.	External snap ring (13)	Install	As shown, step 19e. Remove clutch spring compressor base and low and first clutch spring compressor
	g.	Rear cover assembly gasket	Install	Refer to para 4-4k for exploded view of governor and rear cover assembly
20	Low clutch clearance check (7)	Clearance between piston (15) and top plate	Measure, as shown. Use depth micrometer to measure and record distance A (top of adapter housing (9) to top plate (7)). Press firmly with hand on plates and discs (7 and 8) at point of measurement. Use depth micrometer to measure and record distance B (top of piston (15) to top of rear cover assembly gasket). For clearance, subtract B from A. Clearance must be 0.081 to 0.139 inch. Clearance closer to minimum dimension will mean longer clutch pack life. If necessary, replace any or all plates (7) to achieve correct clearance	



4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

20
(cont)

NOTE

It may be necessary to choose a low clutch piston (15) with a different thickness to achieve correct clearance if adapter housing (9) or rear cover was replaced.

21	Adapter housing	Six plates (7) and five discs (8)	Remove	Keep together for later reinstallation
----	-----------------	-----------------------------------	--------	--


INSTALLATION

22	Transmission	New adapter housing gasket (11)	Install	
23	Adapter housing (9)	Thrust washer (10)	Install	Retain with oil-soluble grease
24	Transmission	Adapter housing (9)	Install	Use two adapter housing guide screws to maintain adapter housing gasket alignment
25	Adapter housing (9)	a Thrust washer (6)	Install	
		b Low sun gear (5)	Install	
26	Carrier assembly (3)	Thrust washer (4)	Install	Retain with oil-soluble grease
27	Low sun gear (5)	Carrier assembly (3)	Install	
28	Gear (1)	Thrust washer (2)	Install	Retain with oil-soluble grease
29	Carrier assembly (3)	Gear (1)	Install	Be sure thrust washer (4) is centered in carrier assembly (3)

4-4. TRANSMISSION (CONT)

g. Low Planetary, Low Clutch, and Adapter Housing Assemblies (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
30	Adapter housing (9)	Six plates (7) and five discs (8)	Install	Same plates (7) and discs (8) removed in step 21 Install alternately, as shown in exploded view Position three sets of double tangs on plates (7) as shown If plates (7) are not positioned properly, they will move under load



NOTE

Refer to para 4-4k for installation of governor and rear cover assembly.

4-4. TRANSMISSION (CONT)

h. Modulated Lockup Valve Assembly.

This task covers:

- a. Removal
- b. Disassembly
- c. Cleaning
- d. Inspection
- e. Reassembly
- f. Installation

INITIAL SETUP:

Tools

No. 2 Common Organizational Maintenance Tool Kit
 Socket wrench handle, 1/2 inch drive
 Socket wrench set, 1/2 inch drive
 Flat tip screwdriver
 Torque wrench, 1/2 inch drive, 175 pounds foot capacity
 Safety glasses
 Valve body adjusting ring tool J-24314

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
2-41c	Transmission oil filter removed.

Materials/Parts

Cleaning solvent	Item 1, Appendix C
Clean cloths	Item 2, Appendix C
Crocus cloth	Item 12, Appendix C

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Transmis- sion	a	Three capscrews (1)	Remove	Hold modulated lockup valve assembly (2) firmly while removing last capscrew (1)
		b	Modulated lock-up valve assembly (2)	Remove	

DISASSEMBLY

NOTE

Before disassembly, note position of ring (3) in relation to pin (4). During reassembly, ring (3) must be installed in same position, or transmission will not operate properly.


2	Valve body (5)	a	Pin (4)	Remove	Depress ring (3) with screwdriver
---	----------------	---	---------	--------	-----------------------------------

4-4. TRANSMISSION (CONT)

h. Modulated Lockup Valve Assembly (cont).

KEY

- 1. Capscrews
- 2. Modulated lockup valve assembly
- 3. Ring
- 4. Pin
- 5. Valve body
- 6. Stop
- 7. Spring
- 8. Valve



TA236055

4-4. TRANSMISSION (CONT)

h. Modulated Lockup Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2 (cont)		b Ring (3), stop (6), and spring (7)	Remove	
		c Valve (8)	Remove	

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

3	All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt, grease, and old lubricant. Dry thoroughly using clean, dry, lintless cloths or moisture-free compressed air	
---	-----------	-------	---	--

4-4. TRANSMISSION (CONT)

h. Modulated Lockup Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION				
4		a Valve body (5)	Inspect	Inspect oil passages and valve bore for cleanliness. If not perfectly clean, reclean Inspect for burrs. Deburr with crocus cloth if necessary Inspect valve bore for cracks, wear, damage and distortion. Replace if necessary
		b Valve (8)	Inspect	Inspect for wear, damage and distortion; if any of these conditions are observed, replace valve
		c Spring (7)	Inspect	Replace if cracked, worn, distorted, broken or permanently set
		d All other parts	Inspect	Inspect for wear, damage, cracks, and distortion; replace part if any of these conditions are observed
REASSEMBLY				
5	Valve body (5)	a Valve (8)	Install	Smaller diameter first
		b Spring (7)	Install	
		c Stop (6)	Install	Undrilled end first
		d Ring (3)	Position	
		e Pin (4)	Install	Depress ring (3) Pin (4) must go through stop (6) and retain ring (3) Be sure that ring (3) is in same position as before disassembly Use valve body adjusting ring tool, if necessary
INSTALLATION				
6	Transmission	a Modulated lockup valve assembly (2)	Position	
		b Three capscrews (1)	Install	Tighten to 9-11 pounds foot torque

4-4. TRANSMISSION (CONT)

i. Low Shift Valve Assembly.

This task covers:

- a. Removal
- b. Disassembly
- c. Cleaning
- d. Inspection
- e. Reassembly
- f. Installation

INITIAL SETUP:

Tools

No 2 Common Organizational Maintenance Tool Kit

- Socket wrench handle, 1/2 inch drive
- Socket wrench set, 1/2 inch drive
- Flat tip screwdriver
- Torque wrench, 1/2 inch drive, 175 pounds foot capacity
- Safety glasses

Valve body adjusting ring tool J-24314

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph Condition Description

2-41c Transmission oil filter removed.

Materials/Parts

- Cleaning solvent Item 1, Appendix C
- Clean cloths Item 2, Appendix C
- Crocus cloth Item 12, Appendix C


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Control valve body	a	Five capscrews (1)	Remove	
		b	Low clutch tube (3)	Remove	
		c	Trimmer tube (4)	Remove	
		d	Drive tube (2)	Remove	
2	Transmission	a	Seven capscrews (5)	Remove	
		b	Valve assembly (6)	Remove	
		c	Separator plate (7)	Remove	
		d	Two capscrews (8)	Remove	
		e	Oil transfer plate (9) and two governor tubes (10)	Remove	As an assembly

4-4. TRANSMISSION (CONT)

i. Low Shift Valve Assembly (cont).



4-4. TRANSMISSION (CONT)

- i. Low Shift Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY**NOTE**

Before disassembly, note position of stop adjusting ring (11) in relation to retainer pin (12). During reassembly, stop adjusting ring (11) must be installed in same position, or transmission will not operate properly.

3	Valve body (13)	a	Retainer pin (12)	Remove	Depress stop adjusting ring (11)
		b	Stop adjusting ring (11), washer (14), valve stop (15), and spring (16)	Remove	
		c	Valve (17)	Remove	Depress valve stop (19)
		d	Retainer pin (18)	Remove	
		e	Valve stop (19) and spring (20)	Remove	
		f	Valve (21)	Remove	

CLEANING**WARNING**

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

4-4. TRANSMISSION (CONT)

- i. Low Shift Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

CLEANING (cont)**WARNING**

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

4		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all dirt, grease, and old lubricant. Dry thoroughly using clean cloths or moisture-free compressed air
---	--	-----------	-------	--

INSPECTION

5	a	Valve body (13)	Inspect	Inspect oil passages and valve bore for cleanliness. If not perfectly clean, reclean. Inspect for burrs. Deburr with crocus cloth if necessary. Inspect valve bores for cracks, wear, damage and distortion. Replace if necessary.
	b	Valves (17 and 21)	Inspect	Inspect for wear, damage and distortion; if any of these conditions are observed, replace valve.
	c	Springs (16 and 20)	Inspect	Replace if cracked, worn, distorted, broken or permanently set.
	d	All other parts	Inspect	Inspect for wear, damage, cracks, and distortion; replace part if any of these conditions are observed.

4-4. TRANSMISSION (CONT)

i. Low Shift Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY				
6	Valve body (13)	a Valve (21)	Install Position	Into longer bore
		b Spring (20) and valve stop (19)		
		c Retainer pin (18)	Install	Depress valve stop (19)
		d Valve (17)	Install	Stem end first
		e Spring (16), valve stop (15), washer (14), and stop adjusting ring (11)	Position	
		f Retainer pin (12)		
INSTALLATION				
7	Transmission	a Oil transfer plate (9) and two governor tubes (10)	Position	As an assembly Be sure governor tubes are securely installed into control valve body holes
		b Two capscrews (8)	Install	Don't tighten at this time
		c Seven capscrews (5)	Install	Temporarily, to aline oil transfer plate (9)
		d Two capscrews (8)	Tighten	To 9-11 pounds foot
		e Seven capscrews (5)	Remove	
		f Separator plate (7)	Position	
		g Valve assembly (6)	Position	
		h Seven capscrews (5)	Install	Don't tighten at this time

4-4. TRANSMISSION (CONT)

i. Low Shift Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
8	Control valve body	a Drive tube (2)	Position	Seat firmly in bores
		b Trimmer tube (4)	Position	Seat firmly in bores
		c Low clutch tube (3)	Position	Seat firmly in bores
		d Five capscrews (1)	Install	Don't tighten at this time
9	Transmission	a 18 capscrews (1)	Tighten	Working from center outward, tighten all capscrews holding control valve body to transmission Tighten to 9-11 pounds foot
		b Seven capscrews (5)	Tighten	To 9-11 pounds foot

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly.

This task covers:

- a. Removal
- b. Disassembly
- c. Cleaning
- d. Inspection
- e. Reassembly
- f. Installation

INITIAL SETUP:

Tools

No 2 Common Organizational Maintenance Tool Kit
 Socket wrench handle, 1/2 inch drive
 Socket wrench set, 1/2 inch drive
 Flat tip screwdriver
 Torque wrench, 1/2 inch drive, 175 pounds foot capacity
 Safety glasses
 Valve body adjusting ring tool J-24314
 Small parts bins

Personnel Required

Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
4-4h	Modulated lockup valve assembly removed.
4-4i	Low shift valve assembly removed.

Materials/Parts

Cleaning solvent	Item 1, Appendix C
Clean cloths	Item 2, Appendix C
Oil-soluble grease	Item 9, Appendix C
Crocus cloth	Item 12, Appendix C
Rubber band	Item 13, Appendix C
Small identification tags	Item 14, Appendix C


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL

1	Transmis- sion	a	Valve (1)	Retain	Use rubber band to secure to pad on control valve body (2), as shown, step 1g
		b	Capscrew (3)	Remove	
		c	Roller and spring (4)	Remove	
		d	Two top capscrews (5)	Loosen	Use to support control valve body (2) while removing other capscrews (5)
		e	Remaining capscrews (5)	Remove	
		f	Two top capscrews (5)	Remove	Hold control valve body (2) firmly

J4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).



TA236052

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

KEY

1	Valve	41	Inner spring
2	Control valve body	42	Outer spring
3	Capscrew	43	Trimmer plug
4	Roller and spring	44	Third clutch valve
5	Capscrews	45	Trimmer plug
6	Modulator valve actuator pin	46	First clutch valve
7	Governor pressure check ball	47	Trimmer plug
8	Modulator valve body	48	Second clutch trimmer valve
9	Capscrews	49	Trimmer plug
10	Retainer pin	50	Fourth clutch trimmer valve
11	Retainer pin	51	Valve stop
12	Retainer pin	52	Retainer pin
13	Retainer pin	53	3-4 relay valve spring
14	Retainer pin	54	3-4 relay valve
15	Spring adjusting ring	55	Spacer
16	Spring adjusting ring	56	2-3 relay valve spring
17	Spring adjusting ring	57	2-3 relay valve
18	Spring adjusting ring	58	Washer
19	Spring adjusting ring	59	Valve stop pin
20	Valve stop pin	60	Spring
21	Washer	61	Valve
22	Modulator valve spring	62	Valve stop
23	Modulator spring	63	2-3 shift spring
24	Separator plate kit	64	2-3 modulator valve
25	Retainer pin	65	2-3 shift valve
26	Priority valve	66	Valve stop
27	Spring	67	3-4 shift spring
28	Valve stop pin	68	3-4 modulator valve
29	Check ball	69	3-4 shift valve
30	Trimmer cover	70	Valve stop
31	Capscrews	71	4-5 shift spring
32	Valve stop	72	4-5 modulator valve
33	Outer spring	73	4-5 shift valve
34	Valve stop	74	Valve stop
35	Inner spring	75	4-5 relay spring
36	Outer spring	76	4-5 relay valve
37	Valve stop	77	Trimmer regulator stop
38	Inner spring	78	Straight pin
39	Outer spring	79	Trimmer regulator spring
40	Valve stop	80	Trimmer regulator valve


4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REMOVAL (cont)

1 (cont)		g Control valve body (2)	Remove	In downward and outward direction to clear modulator valve actuator pin (6) from housing, as shown. Do not lose governor pressure check ball (7). Place control valve body (2) on work bench, modulator valve body (8) up
-------------	--	--------------------------	--------	---



h	Governor pressure check ball (7)	Remove	Note location for reassembly
---	----------------------------------	--------	------------------------------

DISASSEMBLY

CAUTION

Many springs in the control valve body (2) look alike. Don't mistake one for another. If the wrong spring is put into a valve bore, the transmission will not operate properly. As you remove each spring, carefully tag it with its item number for correct reassembly.

4-4. TRANSMISSION (CONT)I

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
2	Modulator valve body (8)	a Three capscrews (9)	Remove	
		b Modulator valve body (8)	Remove	
NOTE				
Before removing retainer pins (10, 11, 12, 13 and 14), carefully note or sketch the position of spring adjust- ing rings (15, 16, 17, 18 and 19). It is very important that these spring adjusting rings are reinstalled later in the same positions. If not, transmission shift points will change.				
3	Modulator valve body (8)	a Retainer pin (10)	Remove	Depress spring adjusting ring (15)
		b Spring adjust- ing ring (15), valve stop pin (20), washer (21), modulator valve spring (22), modula- tor valve (23), and mod- ulator valve actuator pin (6)	Remove	
4	Control valve body (2)	a Separator plate kit (24)	Remove	Slide lengthwise to remove from retainer pin (25)
		b Priority valve (26), spring (27), and valve stop pin (28)	Remove	
		c Check ball (29)	Remove	Note location for reassembly
		d Control valve body (2)	Reposition	Turn flat side down on wood table or on wood blocks
5	Trimmer cover (30)	a Eight capscrews (31)	Remove	Trimmer cover (30) is spring loaded and must be held firmly while removing capscrews (31)

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5 (cont)		b Trimmer cover (30)	Remove	
		c Valve stop (32) and outer spring (33)	Remove	
		d Valve stop (34), inner spring (35), and outer spring (36)	Remove	
		e Valve stop (37), Remove inner spring (38), and outer spring (39)		
		f Valve stop (40), inner spring (41), and outer spring (42)	Remove	
		g Trimmer plug (43) and third clutch valve (44)	Remove	
		h Trimmer plug (45) and first clutch valve (46)	Remove	
		Trimmer plug (47) and second clutch trimmer valve (48)	Remove	
		j Trimmer plug (49) and fourth clutch trimmer valve (50)	Remove	

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
NOTE				
To remove any retainer pin it may be necessary to grasp the control valve body (2) and tap it lightly on a block of wood while depressing the valve and spring assembly behind retainer pin. This will help dislodge the retainer pins.				
6	Valve stop (51)	a Retainer pin (52)	Remove	Depress valve stop (51)
		b Valve stop (51) and 3-4 relay valve spring (53)	Remove	
		c 3-4 relay valve (54)	Remove	
7	Spacer (55)	a Retainer pin (52)	Remove	Depress spacer (55)
		b Spacer (55) and 2-3 relay valve spring (56)	Remove	
		c 2-3 relay valve (57)	Remove	
8	Spring adjusting ring (16)	a Retainer pin (11)	Remove	Depress spring adjusting ring (16)
		b Spring adjusting ring (16), washer (58), and valve stop pin (59)	Remove	
		c Spring (60)	Remove	
		d Valve (61)	Remove	
9	Control valve body (2)	Valve (1)	Remove	Remove rubber band and slide out

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
10	Spring adjusting ring (17)	a Retainer pin (12)	Remove	Depress spring adjusting ring (17)
		b Spring adjusting ring (17), valve stop (62), and 2-3 shift spring (63)	Remove	
		c 2-3 modulator valve (64)	Remove	
		d 2-3 shift valve (65)	Remove	
11	Spring adjusting ring (18)	a Retainer pin (13)	Remove	Depress spring adjusting ring (18)
		b Spring adjusting ring (18), valve stop (66), and 3-4 shift spring (67)	Remove	
		c 3-4 modulator valve (68)	Remove	
		d 3-4 shift valve (69)	Remove	
12	Spring adjusting ring (19)	a Retainer pin (14)	Remove	Depress spring adjusting ring (19)
		b Spring adjusting ring (19), valve stop (70), and 4-5 shift spring (71)	Remove	
		c 4-5 modulator valve (72)	Remove	
		d 4-5 shift valve (73)	Remove	
13	Valve stop (74)	a Retainer pin (25)	Remove	Depress valve stop (74)
		b Valve stop (74) and 4-5 relay spring (75)	Remove	

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
13 (cont)		c 4-5 relay valve (76)	Remove	
14	Trimmer regulator stop (77)	a Straight pin (78)	Remove	Depress trimmer regulator stop (77)
		b Trimmer regula- tor stop (77), and trimmer regu- lator spring (79)	Remove	
		c Trimmer regula- tor valve (80)	Remove	

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using clean- ing solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
15		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in cleaning solvent and move slowly up and down until parts are thoroughly cleaned Dry parts thoroughly using compressed air or clean cloths
INSPECTION				
16		a Control valve body (2)	Inspect	Inspect all oil passages for cleanliness If not perfectly clean, reclean. Inspect for burrs Deburr if necessary Inspect valve bores for cracks, wear, damage and distortion Replace if necessary
		b All valves	Inspect	Inspect for wear, damage and distortion; if any of these conditions are observed, replace part
		c All springs	Inspect	Replace if cracked, worn, distorted, broken, or permanently set
		d Check balls (7 and 29)	Inspect	Inspect for flat or out of round condition, cracks, or other damage. Replace if any of these conditions are observed
		e Separator plate kit (24)	Inspect	Inspect for broken, bent, or scratched condition Replace if necessary
		f All other parts	Inspect	Inspect for wear, damage, cracks, and distortion; replace part if any of these conditions are observed

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY



NOTE

Check position of all valves, springs, plugs and other parts before installation. Install all spring adjusting rings (15, 16, 17, 18, and 19) in positions they held before disassembly. If necessary to achieve original positions, use valve body adjusting ring tool. Other- wise, transmission will not operate properly. All valves, when dry, should move freely in their bores. Refer to illustration on following page for valve bore positions. Control valve body (2) is shown flat side down.


17	Bore A	a	Valve (61)	Install	
		b	Spring (60)	Install	
		c	Valve stop pin (59), washer (58), and spring adjusting ring (16)	Position	
		d	Retainer pin (11)	Install	Depress spring adjusting ring (16). Retainer pin (11) must go through valve stop pin (59) and retain spring adjusting ring (16)
18	Bore B	a	2-3 shift valve (65)	Install	Shorter land first
		b	2-3 modulator valve (64)	Install	Smaller end first
		c	2-3 shift spring (63), valve stop (62), and spring adjusting ring (17)	Position	
		d	Retainer pin (12)	Install	Depress spring adjusting ring (17). Retainer pin (12) must go through valve stop (62) and retain spring adjusting ring (17)
19	Bore C	a	3-4 shift valve (69)	Install	Smaller end first

4-4. TRANSMISSION (CONT)


j. Control Valve Assembly (cont).




SECTION E-E




SECTION B-B



SECTION A-A



SECTION D-D



SECTION F-F

TA236054

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
19 (cont)		b 3-4 modulator valve (68)	Install	Smaller end first
		c 3-4 shift spring (67), valve stop (66), and spring adjusting ring (18)	Position	
		d Retainer pin (13)	Install	Depress spring adjusting ring (18). Retainer pin must go through valve stop (66) and retain spring adjusting ring (18)
20	Bore D	a 4-5 shift valve (73)	Install	Smaller end first
		b 4-5 modulator valve (72)	Install	Smaller end first
		c 4-5 shift spring (71), valve stop (70), and spring adjusting ring (19)	Position	
		d Retainer pin (14)	Install	Depress spring adjusting ring (19). Retainer pin (14) must go through valve stop (70) and retain spring adjusting ring (19)
21	Bore E	a 4-5 relay valve (76)	Install	
		b 4-5 relay spring (75) and valve stop (74)	Position	
		c Retainer pin (25)	Install	Depress valve stop (74)
22	Bore F	a Trimmer regulator valve (80)	Install	Smaller end first

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
22 (cont)		b Trimmer regulator spring (79) and trimmer regulator stop (77)	Position	
		c Straight pin (78)	Install	Depress trimmer regulator stop (77)
23	Bore G	a Third clutch valve (44)	Install	Open end first
		b Trimmer plug (43), outer spring (33), and valve stop (32)	Install	
24	Bore H	a First clutch valve (46)	Install	Open end first
		b Trimmer plug (45), outer spring (36), inner spring (35), and valve stop (34)	Install	
25	Bore I	a Second clutch trimmer valve (48)	Install	Open end first
		b Trimmer plug (47), outer spring (39), inner spring (38), and valve stop (37)	Install	
26	Bore J	a Fourth clutch trimmer valve (50)	Install	Open end first
		b Trimmer plug (49), outer spring (42),	Install	

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
26 (cont)		inner spring (41), and valve stop (40)		
27	Outer springs (33, 36, 39, and 42)	a Trimmer cover (30)	Position	Press against springs
		b Eight capscrews (31)	Install	Tighten to 9-11 pounds foot
28	Bore K	a 3-4 relay valve (54)	Install	
		b 3-4 relay valve spring (53) and valve stop (51)	Position	
		c Retainer pin (52)	Install	Depress valve stop (51)
29	Bore L	a 2-3 relay valve (57)	Install	Larger end first
		b 2-3 relay valve spring (56) and spacer (55)	Position	
		c Retainer pin (52)	Install	Depress spacer (55)
30	Modulator valve body (8), bore M	a Modulator valve actuator pin (6)	Install	Smaller end first
		b Modulator valve (23)	Install	Longer end first
		c Modulator valve spring (22), washer (21), valve stop pin (20), and spring adjust- ing ring (15)	Position	
		d Retainer pin (10)	Install	Depress spring adjusting ring (15) Retainer pin must go through valve stop pin (20) and retain spring adjusting ring (15)

4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
31	Control valve body (2)	Check ball (29)	Install	In original position. See section B-B of illustration. Retain with oil-soluble grease
32	Bore N	a Valve stop pin (28) and spring (27)	Install	
		b Priority valve (26)	Install	Open end first
33	Control valve body (2)	Separator plate kit (24)	Position	Aline bolt holes. Slide slot onto retainer pin (25)
34	Separator plate kit (24)	a Modulator valve body (8)	Position.	Aline bolt holes
		b Three capscrews (9)	Install	Double check alinement of bolt holes in separator plate kit (24) and control valve body (2) Tighten to 9-11 pounds foot
35	Bore 0	Valve (1)	Install	Drilled end first. Secure with rubber band to pad on control valve body (2)


4-4. TRANSMISSION (CONT)

j. Control Valve Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSTALLATION

36	Transmission	a Governor pressure check ball (7)	Install	In original position, as shown
----	--------------	------------------------------------	---------	--------------------------------



b	Control valve body (2)	Position	Be sure to insert modulator valve actuator pin (6) into bore in housing, as shown
c	Capscrews (5)	Install	Do not tighten at this time
d	Valve (1)	Position	Remove rubber band. Engage groove with pin on lever
e	Roller and spring (4)	Position	Engage with any notch on lever
f	Capscrew (3)	Install	Tighten to 9-11 pounds foot

NOTE

Final tightening of capscrews (5) is done after installation of low shift valve (paragraph 4-4i). Testing and adjustment (paragraphs 3-17a and 3-17b) are done after transmission is installed in vehicle.

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly.

This task covers:

- | | |
|-----------------------|------------------------|
| a. Removal | d. Inspection |
| b. Disassembly | e. Reassembly |
| c. Cleaning | f. Installation |

INITIAL SETUP:

Tools

No. 2 Common Organizational Maintenance

Tool Kit

- Socket wrench handle, 1/2 inch drive
- Socket wrench set, 1/2 inch drive
- Flat tip screwdriver
- Hand hammer
- Mechanical puller kit
- Safety glasses
- Torque wrench, 1/2 inch drive, 175 pounds foot capacity
- Sharpening stone
- Retaining ring pliers

Brass drift

Lifting tool

Hoist

Arbor press

Bearing and gear remover J-22912-01

Output shaft oil seal and dust shield remover assembly J-24171

Low and first clutch spring compressor J-24452

Clutch spring compressor base for low, first, fourth clutches J-24204-2

Rear bearing installer J-24447

Output shaft oil seal installer J-24620

Dust shield installer J-24198

Main and output shaft orifice installer J-24369

Output shaft bearing installer J-24451

Driver handle J-8092

Steel sleeve (2.375 I.D. by 2.875 O.D. by 1.750 inches long)

Driver handle J-24202-4

Adapter housing guide screws J-1927-1

Materials/Parts

- | | |
|-----------------------|------------------------|
| Cleaning solvent | Item 1, Appendix C |
| Clean cloths | Item 2, Appendix C |
| Light machine oil | Item 7, Appendix C |
| Transmission fluid | Item 8, Appendix C |
| Non-hardening sealant | Item 10, Appendix C |
| Gasket | FSCM 73342 PN 6837442 |
| Governor service kit | FSCM 73342 PN 6880353 |
| Governor cover gasket | FSCM 73342 PN 23011670 |
| Governor weight pins | FSCM 73342 PN 8623232 |
| Oil seal | FSCM 73342 PN 6773311 |
| Dust shield | FSCM 73342 PN 6757563 |
| Governor filter kit | FSCM 73342 PN 6884749 |
| Governor filter | FSCM 73342 PN 6882687 |
| 0-ring seal | FSCM 73342 PN 6882689 |

Personnel Required

Automotive Repairer MOS 63H


Equipment Condition

Paragraph	Condition Description
-----------	-----------------------

3-17c(2) Transmission removed from vehicle.

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).



TA236082

4-4. TRANSMISSION (CONT)


k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Rear cover assembly (1)	a. Four capscrews (2)	Remove	
		b. Governor cover (3)	Remove	
		c. Governor cover gasket (4)	Remove	Discard
		d. Governor assembly (5)	Remove	
2	Transmission (6) and washers (7)	a. 14 capscrews	Remove	
		b. Rear cover assembly (1)	Remove	Attach lifting tool and hoist to shaft (8) behind locknut (9). Lift from adapter housing and place on work table
		c. Gasket (10)	Remove	Discard
3	Rear cover assembly (1) attached parts	a. Locknut (9)	Remove	
		b. Shaft (8) and	Remove	
4	Shaft (8)	a. Spacer (11)	Remove	
		b. Speedometer drive gear (12)	Remove	
DISASSEMBLY				
5	Shaft and plug gear (14) assembly (13)	a. Governor drive	Remove	Place shaft and plug assembly (13) on arbor press, small end up. Install bearing and gear remover so that flat side of plates contact front edge of governor drive gear teeth. Press shaft down
		b. Spring pin (16)	Remove	
		c. Roller bearing (15) if necessary	Remove	Use bearing and gear remover
		d. Needle bearing (17)	Remove	Only if inspection shows replacement is necessary. Use mechanical puller kit

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5 (cont)		e. Cup plug (18)	Remove	Only if inspection shows replacement is necessary
6	Cover (19)	a. Dust shield (20)	Remove	Use output shaft oil seal and dust shield remover assembly, as shown. Discard



- b. Oil seal (21) Remove Use output shaft oil seal and dust shield remover assembly as shown above. Discard
- c. Internal snap ring (22) Remove

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

6
(cont)


WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to you. Seek medical attention immediately if you get chips in your eyes. Always wear safety goggles when hammering.

- | | | |
|----|-------------------|---------|
| d. | Ball bearing (23) | Remove |
| e. | Spring retainer | Depress |

Use hammer and brass drift against outer race

Refer to para 4-4g for exploded view of, and repair instructions for, low clutch components. Place low and first clutch spring compressor on spring retainer, as shown. Install clutch spring compressor base and tighten screw



- | | | |
|----|---------------------------|--------|
| f. | External snap ring | Remove |
| g. | Spring retainer | Remove |
| h. | 26 piston release springs | Remove |
| i. | Piston | Remove |
| j. | Plug (24) | Remove |
| k. | Plug (25) | Remove |

As shown, step 6e. Remove clutch spring compressor base and low and first clutch spring compressor

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
6 (cont)		l. Plug (26)	Remove	
		m. Governor filter (27)	Remove	Discard
		n. O-ring seal (28)	Remove	Discard
		o. Outer race (29)	Remove	Only if inspection shows replacement is necessary. Use mechanical puller kit
		p. Pin (30)	Remove	Only if inspection shows replacement is necessary
		q. Drain tube (31)	Remove	Only if inspection shows replacement is necessary
		r. Plug (32)	Remove	Only if inspection shows replacement is necessary
7	Governor assembly (5)	Two governor weight pins (33)	Remove	Only if governor service kit, consisting of two governor weight pins (33) and governor cover gasket (4) is available. Follow directions in governor service kit for disassembly of governor assembly (5)

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
<u>WARNING</u>				
Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.				
8		a. All parts, except cover (19), roller bearing (15), ball bearing (23), and needle bearing (17)	Clean	Use cleaning solvent P-D-680. Immerse in solvent and move up and down to remove all dirt and old lubricant. Dry thoroughly with compressed air or with clean, dry, lintless cloths
		b. Cover (19)	Clean	Wipe with clean cloths moistened with cleaning solvent P-D-680. Remove all dirt and old lubricant. Dry thoroughly with compressed air or with clean, dry, lintless cloths
		c. Roller bearing (15), ball bearing (23), and needle bearing (17)	Clean	Use cleaning solvent P-D-680. Immerse bearings in cleaning solvent and slowly move up and down. Remove bearings from cleaning solvent and strike larger side of cone flat against a block of wood to dislodge solidified particles of lubricant. Immerse again in cleaning solvent and repeat above operation until bearings are thoroughly clean. Dry thoroughly with clean, dry, lintless cloths

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION				
9		a. Roller bearing (15), outer race (29), ball bearing (23), and needle bearing (17)	Inspect	Inspect for wear, chipping, or nicks. Inspect for roughness or binding in operation. Replace if necessary. If defects are found in either roller bearing (15) or outer race (29), replace both as a matched set. After inspection, dip bearings in clean, light machine oil and wrap in clean, lintless cloth for protection until installed
		b. Shaft (8)	Inspect	Inspect splines for wear, pitting, nicks, cracks or scores. Remove small nicks with suitable sharpening stone. Inspect shaft for bent, sprung, or twisted condition; replace if necessary
		c. All other parts	Inspect	Inspect for worn, cracked, bent or broken condition. If any of these conditions are noted, replace part
REASSEMBLY				
10	Governor assembly (5)	Two new governor weight pins (33)	Install	Follow directions in governor service kit for reassembly of governor assembly
11	Cover (19)	a. Plug (24)	Install	Tight enough to prevent leaks
		b. Plug (25)	Install	Tight enough to prevent leaks
		c. New plug (32)	Install	If old plug (32) was removed. Tighten enough to prevent leaks
		d. New governor filter (27)	Install	Open end first
		e. New O-ring seal (28)	Install	
		f. Plug (26)	Install	Tight enough to prevent leaks

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

11
(cont)

g. New pin (30)

Install

If old pin (30) was removed. Install to dimension shown. It is critical to be accurate about pin's location and concentricity with governor bore




TA236085

h. New drain tube (31)

Install

If old drain tube (31) was removed. Press tube in to dimension shown




TA236086

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		i. Piston	Install	Refer to para 4-4g for exploded view of low clutch components. Be sure lip type seal rings are lubricated with transmission fluid. Install carefully, being sure not to distort lip type seal rings
		j. 26 piston release springs	Install	
		k. Spring retainer	Install	Cupped side first
		l. External snap ring	Position	
		m. Spring retainer	Depress	Place low and first clutch spring compressor on spring retainer, as shown. Install clutch spring compressor base and tighten screw




n.		External snap ring	Install	As shown, step 11m. Remove clutch spring compressor base and low and first clutch spring compressor
o.		Ball bearing (23)	Install	Use rear bearing installer to seat firmly against cover (19)

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
11 (cont)		p. Internal snap ring (22)	Install	Beveled side toward rear of transmission
		q. New oil seal (21)	Install	Coat outer edge with non-hardening sealant. Place on output shaft oil seal installer, spring-loaded side away from installer. Drive oil seal (21) into bore until its rear surface is 1.03 to 1.07 inch below rear face of cover (19)
		r. New dust shield (20)	Install	Place onto dust shield installer, concave side first. Coat outer edge with non-hardening sealant. Drive dust shield (20) into bore until it is flush with, to 0.040 inch below, rear face of cover (19)
		s. New outer race (29)	Install	If old outer race (29) was removed. Install, inner lip first, until front of outer race (29) is 0.080 to 0.090 inch below front surface of bore
12	Shaft (8)	a. New cup plug (18)	Install	If old cup plug (18) was removed. Place on end of main and output shaft orifice installer. Install into shaft (8) as shown



TA236087

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------


REASSEMBLY (cont)

12
(cont)

b. New needle bearing (17)

Install

If old needle bearing (17) was removed. Place on end of output shaft bearing installer, numbered end of bearing facing installer. Attach driver handle J-8092 to installer. Install needle bearing (17) as shown



c. Roller bearing (15)

Install

Place shaft (8) on arbor press, small end down. Place roller bearing (15), chamfered end first, onto shaft. Install steel sleeve, rear bearing installer, and driver handle J-24202-4. Press roller bearing against shoulder on shaft. Remove driver handle J-24202-4, rear bearing installer, and steel sleeve

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
12 (cont)		d. Spring pin (16)	Install	Press in until it extends 0.150 to 0.170 inch above surface
		e. Governor drive gear (14)	Install	Slot first. Aline slot with spring pin (16). Place rear bearing installer over shaft next to governor drive gear (14). Install driver handle J-24202-4 and press
governor				drive gear into place
INSTALLATION				
13	Adapter housing	Shaft and plug assembly (13)	Install	Into low planetary gear
14	Shaft and plug assembly (13)	a. Speedometer drive gear (12)	Install	
		b. Spacer (11)	Install	
15	Adapter housing	a. New gasket (10)	Install	First install two adapter housing guide screws. Then lower rear cover assembly onto adapter housing
		b. Rear cover assembly (1)	Install	
		c. 12 capscrews (6) and washers (7)	Install	Do not tighten at this time
		d. Two remaining capscrews (6) and washers (7)	Install	First remove two adapter housing guide screws. Do not tighten at this time
		e. 14 capscrews (6)	Tighten	Tighten two capscrews (6) 180 degrees apart to 33 pounds foot. Move about 90 degrees around adapter housing and repeat procedure. Tighten remaining opposite pairs of capscrews to 33 pounds foot. Repeat entire procedure, tightening all capscrews to 67-80 pounds foot

4-4. TRANSMISSION (CONT)

k. Governor and Rear Cover Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
16	Rear cover assembly (1)	a. Governor assembly (5)	Install	
		b. New governor cover gasket (4) and governor cover (3)	Position	
		c. Four capscrews (2)	Install	Tighten to 15-20 pounds foot
		d. Locknut (9)	Install	Be sure all threads are clean. Loosely install several turns to prevent loss before installation of output flange

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly.

- This task covers:
- | | |
|----------------|-----------------|
| a. Removal | d. Inspection |
| b. Disassembly | e. Reassembly |
| c. Cleaning | f. Installation |

INITIAL SETUP

Tools

No. 2 Common Organizational Maintenance Tool Kit

- Socket wrench handle, 1/2 inch drive
- Socket wrench set, 1/2 inch drive
- Torque wrench, 1/2 inch drive, 175 pounds foot capacity
- Straightedge
- Thickness gage
- Measuring scale
- Hand hammer
- Retaining ring pliers
- Mechanical puller kit
- Safety glasses

Hoist

- Arbor press
- Sun lamp
- Front support lifter assembly J-24473
- Valve pin remover J-24412-2
- Slide hammer J-6125-1
- Pressure regulator and lockup spring compressor J-24459
- Centering band J-24461
- Soft headed mallet
- Oil seal installer J-26912
- Driver handle J-24202-4
- Front support bearing installer J-24457
- Driver handle J-8092
- Valve pin installer J-24458
- Two headless guide screws J-24315-1
- Bushing installer J-24648

Materials/Parts

- | | |
|----------------------|-----------------------|
| Cleaning solvent | Item 1, Appendix C |
| Clean cloths | Item 2, Appendix C |
| Oil-soluble grease | Item 9, Appendix C |
| Nonhardening sealant | Item 10, Appendix C |
| Oil seal | FSCM 73342 PN 6881597 |
| Valve guide | FSCM 73342 PN 6834410 |
| Gasket | FSCM 73342 PN 6837602 |
| Seal ring | FSCM 73342 PN 6834525 |

Personnel Required


Automotive Repairer MOS 63H

Equipment Condition

Paragraph	Condition Description
3-17d	Torque converter removed.

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).



KEY

- 1. Capscrews
- 2. Washers
- 3. Gasket
- 4. Seal rings
- 5. Bearing race
- 6. Bearing assembly
- 7. Seal ring
- 8. Bearing assembly
- 9. Valve guide
- 10. Spring
- 11. Converter pressure regulator valve
- 12. Pressure regulator spring


- 13. Lockup valve spring
- 14. Internal snap ring
- 15. Internal snap ring
- 16. Valve stop
- 17. Pressure regulator valve
- 18. Valve stop
- 19. Lockup valve
- 20. Capscrews
- 21. Capscrews
- 22. Support assembly
- 23. Body
- 24. Support
- 25. Plug
- 26. Drive gear
- 27. Driven gear
- 28. Oil seal

TA236044

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REMOVAL				
1	Oil pump and front support	Capscrews (1) and washers (2)	Remove	
2	Transmission	Oil pump and front support group	Remove	Firmly attach front support lifter assembly as shown. Attach a hoist to lifter assembly and carefully lift oil pump and front support. Oil pump and front support group fit tightly in transmission and may bind when housing is cold. Use sun lamp or draft of warm air to heat housing if necessary. If oil pump and front support group bind, tap down and lift again. Place on table. Remove lifter assembly



DISASSEMBLY

3	Oil pump and front support (4) group	a. Gasket (3)	Remove	Discard
		b. Two seal rings	Remove	
		c. Bearing race (5) and bearing assembly (6)	Remove	From support- assembly (22) or transmission
		d. Seal ring (7)	Remove	Discard Only if inspection shows replacement is necessary. Use mechanical puller kit
		e. Bearing assembly (8)	Remove	


4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

3 (cont)		f. Valve guide (9)	Remove	Only if parts replacement is necessary. Attach valve pin remover to head of valve guide (9) as shown. Attach slide hammer and remove. Discard valve guide (9)
-------------	--	--------------------	--------	---



		g. Spring (10) and converter pressure regulator valve (11)	Remove	Only if replacement is necessary
--	--	--	--------	----------------------------------

WARNING

Pressure regulator spring (12) and lockup valve spring 4-137 (13) in step 3h-j are under about 65 pounds compression. If instructions are not followed carefully, springs may injure you. If injured, seek medical attention immediately.

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
3 (cont) compressor compressor		h. Internal snap rings (14 and 15)	Remove	Attach pressure regulator and lockup spring as shown. Tighten screw to remove all pressure from internal snap rings (14 and 15). Remove internal snap rings. Carefully remove screws on spring compressor. Remove spring compressor
		i. Valve stop (16), pressure regulator spring (12), and pressure regulator valve (17)	Remove	
		j. Valve stop (18), lock-up valve spring (13), and lockup valve (19)	Remove	
		k. 14 capscrews (20 and 21)	Remove	
		l. Support assembly (22) and body (23)	Separate	
4	Support (24)	Plug (25)	Remove	If necessary to replace parts

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5	Body (23)	a. Drive gear (26) and driven gear (27)	Remove	
		b. Oil seal (28)	Remove	Discard

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

6		All parts	Clean	Use cleaning solvent P-D-680. Immerse parts in solvent and move up and down to remove all old lubricant, dirt, and grease. Dry thoroughly with clean, lintless cloths or moisture-free compressed air
---	--	-----------	-------	---

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION				
7		a. Support (24) and sleeve	Inspect	Do not separate. If you feel movement between support (24) and sleeve, or if sleeve is damaged, replace sleeve and support (24) as an assembly
		b. Body (23), drive gear (26), and driven gear (27)	Inspect	Replace all three parts if any one is damaged. Position body (23) flat side up and install drive gear (26) and driven gear (27) into it. Place straightedge across body and gears. Check with thickness gage for clearance between straightedge and each gear. If clearance is more than 0.0024 inch, replace gears. If clearance is still more than 0.0024 inch, replace body (23), drive gear (26), and driven gear (27) as a unit
		c. Pressure regulator spring (12) and lock-up valve spring (13)	Inspect	Replace if cracked, worn, distorted, broken or permanently set
		d. Pressure regulator valve (17) and lock-up valve (19) replace part	Inspect	Inspect for wear, damage, bent or broken condition and distortion; if any of these conditions are observed,
		e. Capscrews (1, 20, and	Inspect	Replace any capscrews that are bent or have damaged
	threads	21)		
		f. Bearing assemblies (6 and 8)	Inspect	Replace if bearing binds or drags
		g. All other parts	Inspect	Inspect for wear, damage, cracks, and distortion; replace part if any of these conditions are observed

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY

NOTE

If oil seal installer is not available for step 8 below, press oil seal (28) 0.050-0.070 inch below front surface of body (23).

8	Body (23)	New oil seal (28)	Install	Place oil seal (28) on oil seal installer with spring loaded lip facing away from tool. Attach driver handle. Coat outside oil seal diameter with nonhardening sealant. Drive oil seal (28) into body (23) as shown. Remove oil seal installer and apply oil-soluble grease to inside of seal
---	-----------	-------------------	---------	---



TA236048

9	Support (24)	New plug (25)	Install	If removed during disassembly. Press to shoulder of support (24)
10	Oil pump and front support group	Body (23)	Position	Front side down on table
11	Body (23)	a. Drive gear (26) and driven gear (27)	Install	
		b. Support (24)	Position	Line up bolt holes in body (23) and support (24)


4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

12	Oil pump and front support group	a. Two capscrews (20 and 21)	Install	180 degrees apart. Tighten one or two threads Around body (23) and support, as shown
		b. Centering band	Install	



TA236049

c. Remaining cap-screws (20 and 21)	Install	Be sure centering band is tight. Fit between body (23) and support (24) must be perfectly smooth. Tighten 12 5/16-18 cap screws (21) to 17-20 pounds foot. Tighten 3/8-16 cap screws (20) to 36-43 pounds foot
-------------------------------------	---------	--

NOTE


4-142 If bearing installer is not available for step 13 below, press bearing assembly (8), numbered end up, into sleeve until it is 1.240-1.260 inches from face of hub, as shown.

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY




13 Sleeve

New bearing assembly (8)

Install

If original was removed. Numbered end up. Use front support bearing installer and driver handle, as shown. Bearing assembly must not move while withstanding a 200 pound load in direction indicated by arrow in drawing for note above



4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
14	Oil pump and front support group	a. Lockup valve (19), lockup valve spring (13), and valve stop (18)	Install	
		b. Pressure regulator valve (17), pressure regulator spring (12), and valve stop (16)	Install	
		c. Internal snap rings (14 and 15)	Install	Attach pressure regulator and lockup spring compressor as shown in step 3h. Place internal snap rings (14 and 15) onto compressor screws before compressing lockup valve spring (13) and pressure regulator spring (12). Compress springs and install snap rings. Remove compressor

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if you get metal chips in your eyes. Always wear safety goggles when hammering.

NOTE

If valve pin installer is not available for step 14d, drive in valve guide (9) to extend 1.16-1.20 inches beyond finished surface.

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
14 (cont)		d. Converter pressure regulator valve (11), spring (10), and valve guide (9)	Install	Place valve guide (9) onto valve pin installer. Place converter pressure regulator valve (11) and spring (10) onto valve guide (9). Install by striking end of valve pin installer with hammer
		e. Seal ring (7)	Install	Lubricate first with oil-soluble grease. Be sure seal ring (7) is not twisted
INSTALLATION				
15	Transmission housing	a. Gasket (3)	Install	Be sure that seal rings at bottom of turbine shaft are retained with oil-soluble grease
16	Oil pump and front support group	a. Bearing assembly (6) and bearing race (5)	Install	Retain with oil-soluble grease
		b. Two seal rings (4)	Install	
17	Transmission housing	Two headless guide screws	Install	
18	Sleeve	Front support lifter and hoist assembly	Attach	As shown, step 2
19	Transmission housing	a. Oil pump and front support group	Install	Line up all holes. Lower onto two headless guide screws. Remove front support lifter assembly
		b. 10 capscrews (1) and washers (2)	Install	Hand tight

4-4. TRANSMISSION (CONT)

1. Oil Pump and Front Support Assembly (cont).

STEP	LOCATION	ITEM	ACTION	REMARKS
INSTALLATION (cont)				
19 (cont)		c. Two headless guide screws	Remove	
		d. Two remaining capscrews (1) and washers (2)	Install	Hand tight
		e. 12 capscrews (1) and washers (2)	Tighten	Tighten first two capscrews 180 degrees apart to 15 pounds foot. Move about 90 degrees around capscrew circle and repeat with next capscrew pair. Tighten rest of capscrew pairs. Repeat entire process, tightening all to 24-32 pounds foot

4-5. DIFFERENTIAL

- This task covers:
- a. Disassembly
 - b. Cleaning
 - c. Inspection
 - d. Reassembly
 - e. Adjustment

INITIAL SETUP

Tools

- Automotive Mechanic's Tool Kit
 - Diagonal cutting pliers
 - Center punch
 - Socket wrench set, 1/2 inch drive
- No. 1 Common Organizational Maintenance Tool Kit
 - Twist drill set
 - Socket wrench set, 3/4 inch drive
 - Fixed open end wrench set
 - Safety glasses
 - Torque wrench, 1/2 inch drive, 175 pounds foot capacity
 - Torque wrench, 3/4 inch drive, 600 pounds foot capacity
 - Mechanical puller kit
- No. 2 Common Organizational Maintenance Tool Kit
 - Hand hammer
 - Flat tip screwdriver
 - Socket wrench handle, 1/2 inch drive
 - Electric portable drill, 1/2 inch
 - Pry bars (2)
- Dial indicator
- Arbor press
- Differential repair stand
 - FSCM 78500 PN 3-11546
- Yoke holding tool

Materials/Parts

- Cleaning solvent
 - Clean cloths
 - Chassis grease
 - Emery cloth
 - Soft lock wire
 - Axle lubricant
 - Light machine oil
 - Linseed oil
 - Red lead
 - Cotter pins
 - Oil seal
 - Gasket
- Item 1, Appendix C
 Item 2, Appendix C
 Item 3, Appendix C
 Item 4, Appendix C
 Item 5, Appendix C
 Item 6, Appendix C
 Item 7, Appendix C
 Item 46, Appendix C
 Item 47, Appendix C
 FSCM 78500 PN 1199R2176
 FSCM 78500 PN A1805S149
 FSCM 78500 PN 2808Z728

Personnel Required

Two Automotive Repairers MOS 63H

Equipment Condition


Paragraph	Condition Description
3-19b	Differential removed from axle and mounted in repair stand.

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY

1	Differential carrier housing (1)	a. Differential bearing cap (2)	Mark	Use center punch and hammer to identify one differential bearing cap (2) and differential carrier housing (1) for proper reassembly Only if necessary for replacement
		b. Two tacks (3)	Remove	
		c. Plate (4)	Remove	

4-5. DIFFERENTIAL (CONT)



TA236100

4-5. DIFFERENTIAL(CONT)

KEY

- | | | |
|----------------------------------|------------------------------|---------------------------|
| 1. Differential carrier housing | 21. Yoke | 43. Capscrews (2) |
| 2. Differential bearing caps (2) | 22. Slinger | 44. Bearing retainer |
| 3. Tacks (2) | 23. Nut | 45. Bearing |
| 4. Plate | 24. Washer | 46. Key |
| 5. Capscrews (4) | 25. Bearing cage | 47. Bearing |
| 6. Washers (4) | 26. Capscrews (7) | 48. Bearing cup |
| 7. Adjusting nuts (2) | 27. Bushings (2) | 49. Capscrews (6) |
| 8. Bearing cups (2) | 28. Drive pinion | 50. Lock washers (6) |
| 9. Case half | 29. Shims (AR) | 51. Cross shaft cover |
| 10. Case half | 30. Oil seal | 52. Shims (AR) |
| 11. Helical spur gear | 31. Outer bearing | 53. Bearing cup |
| 12. Capscrews (12) | 32. Outer bearing cup | 54. Inspection hole cover |
| 13. Washers (12) | 33. Inner bearing cup | 55. Capscrews (4) |
| 14. Nuts (12) | 34. Inner bearing | 56. Gasket |
| 15. Side gear thrust washers (2) | 35. Fill plug | 57. Front cover |
| 16. Side gears (2) | 36. Bearing spacer | 58. Capscrews (4) |
| 17. Thrust washers (4) | 37. Cross shaft bearing cage | 59. Lock washers (4) |
| 18. Pinions (4) | 38. Capscrews (6) | 60. Gasket |
| 19. Spider | 39. Lock washers (6) | 61. Fill plug |
| 20. Bearings (2) | 40. Drive gear | 62. Cotter pins (2) |
| | 41. Shims (AR) | 63. Lock washers (4) |
| | 42. Cross shaft | |

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

DISASSEMBLY (cont)

1 (cont)	d.	Two cotter pins (62)	Remove	
	e.	Four capscrews (5) and washers (6)	Remove	
	f.	Two differential bearing caps (2)	Remove	
	g.	Two adjusting nuts (7)	Remove	
	h.	Two bearing cups (8)	Remove	
	i.	Differential case and gear assembly	Lift out	Insert bar through differential case and gear assembly

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
1 (cont)			NOTE	
				Removal of bushings (27) is not required. These bushings are for a two-speed shaft which is not installed in this differential carrier.
2	Differential case and gear assembly	a. Case halves (9 and 10) b. 12 capscrews (12), washers (13), and nuts (14) c. Helical spur gear (11) d. Case halves (9 and 10) e. Two side gear thrust washers (15), two side gears (16), four thrust washers (17), four pinions (18), and spider (19)	Mark Remove Remove Separate Remove	Use punch to mark for correct alignment during reassembly Cut lock wire first
3	Differential case halves (9 and 10)	Two bearings (20)	Remove	Remove only if inspection shows replacement is necessary. Use mechanical puller kit
4	Yoke (21)	Nut (23) and washer (24)	Remove	Use yoke holding tool
5	Bearing cage (25)	a. Seven capscrews (26)	Remove	

WARNING

Do not strike hardened steel pieces with steel hammer. Metal chips could cause serious injury to your eyes. Seek medical attention immediately if metal chips get in your eyes. Always wear safety glasses when hammering.

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
5 (cont)		b. Bearing cage (25)	Remove	If bearing cage (25) is not free, tap loose using hammer and brass drift on inner face of drive pinion (28) or use puller screws in holes provided
		c. Shims (29)	Remove	Wire together
		d. Drive pinion (28)	Remove	Press from bearing cage (25)
		e. Yoke (21)	Remove	Discard
		f. Oil seal (30)	Remove	
		g. Outer bearing (31)	Remove	
		h. Outer bearing cup (32)	Remove	Only if inspection shows outer bearing (31) should be replaced. Press from bearing cage (25)
		i. Inner bearing cup (33)	Remove	Only if inspection shows inner bearing (34) should be replaced. Press from bearing cage (25)
		j. Fill plug (35)	Remove	Only if inspection shows replacement is necessary
		k. Slinger (22)	Remove	From yoke (21) only if damaged
		6	Drive pinion (28)	a. Bearing spacer (36)
b. Inner bearing (34)	Remove			Only if inspection shows replacement is necessary. Use mechanical puller kit to remove from drive pinion (28)
7	Cross shaft bearing cage (37)	a. Six capscrews (38) and lock washers (39)	Remove	
		b. Cross shaft bearing cage (37)	Remove	With pry bar between back of drive gear (40) and carrier housing (2)
		c. Shims (41)	Remove	Wire together

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
8	Differential(42) carrier housing (1)	Cross shaft	Remove	Shift left, tilt, and lift out drive gear side first
9	Cross shaft (42)	a. Two capscrews (43)	Remove	
		b. Bearing retainer (44)	Remove	
10	Drive gear (40) and bearing (45)	Cross shaft (42) and key (46)	Remove	Press out. Don't lose key (46)
11	Cross shaft (42)	Bearing (47)	Remove	Remove if necessary for replacement. Use mechanical puller kit
12	Cross shaft bearing cage (37)	Bearing cup (48)	Remove	Only if inspection shows replacement is necessary. Use mechanical puller kit
13	Differential carrier housing (1) cover (51) and shims (52)	a. Six capscrews (49) and lock washers (50)	Remove	Only if necessary to remove cross shaft cover (51)
		b. Cross shaft to bearing cup (53). Wire shims together	Remove	Only if necessary for access
		c. Bearing cup (53)	Remove	Only if inspection shows replacement is necessary. Use mechanical puller kit
14	Inspection hole cover (54)	a. Four capscrews (55) and lock washers (63)	Remove	
		b. Inspection hole cover (54) and gasket (56)	Remove	Discard gasket
15	Front cover (57)	a. Four capscrews (58) and lock washers (59)	Remove	

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
DISASSEMBLY (cont)				
15 (cont)		b. Front cover (57) and gasket (60)	Remove	Discard gasket
16	Differential carrier housing (1)	Fill plug (61)	Remove	Remove only if necessary

CLEANING

WARNING

Dry cleaning solvent (P-D-680), used to clean parts is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flame or excessive heat and don't smoke when using it. Failure to do so could cause serious injury. If you become dizzy while using cleaning solvent, get fresh air immediately, and get medical attention. If contact with skin or clothes is made, flush with large amounts of water. If contact with eyes is made, wash eyes with water immediately, and obtain medical aid immediately.

Compressed air must not exceed 30 psi. Wear safety glasses when drying parts with compressed air. Failure to do so could cause serious injury to eyes and possible blindness. If you hurt your eyes or if a foreign object is blown into your eyes, seek medical attention immediately.

17		a. Bearings (31 and 45)	Clean	Use cleaning solvent P-D-680. Soak in cleaning solvent; then remove and strike flat of bearing against block of wood to dislodge solidified lubricant particles. Dry with clean, soft, lintless, absorbent cloths. Don't use compressed air to dry bearings
----	--	-------------------------	-------	---

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
CLEANING (cont)				
17 (cont)		b. Differential carrier housing (1) and helical spur gear (11)	Clean	Use clean cloths moistened with dry cleaning solvent P-D-680. Dry with compressed air
		c. All other parts	Clean	Use cleaning solvent P-D-680. Immerse in solvent and move up and down to remove all old lubricant and dirt. Dry with clean, soft, lintless, absorbent cloths or with compressed air. Don't use compressed air on any bearings
INSPECTION				
18		a. Bearings (20, 31, 34, 45, and 47), bearing cups (8, 32, 33, 48, and 53)	Inspect	Check for wear, pitting, or damage; replace part if any of these conditions are observed. See steps 3, 5h-i, 6b, and 11 through 13
		b. Drive pinion (28)	Inspect	Check gear teeth and splines for nicked, cracked, broken, scored, or worn condition. Remove burrs or nicks with soft hone or crocus cloth. Replace badly damaged or worn part
NOTE				
Drive pinion (28) and drive gear (40) must be replaced as a matched set.				
		c. Two adjusting nuts (7)	Inspect	Check for wear, damage and nicks. Check threads for damage. If any of these conditions are observed, replace part

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
INSPECTION (cont)				
18 (cont)		d. Bearing cage (25) and differential carrier housing (1)	Inspect	Check for cracks, breaks, burrs, and damage to machined surfaces. Remove burrs and minor surface irregularities with soft hone or crocus cloth. Replace cracked or damaged parts
		e. Yoke (21)	Inspect	Check for cracks, burrs, twisted splines, and other damage. Remove burrs with soft hone or crocus cloth. Replace part if cracked or splines badly twisted
		f. Helical spur gear (11), side gears (16), and pinions (18)	Inspect	Inspect for wear, damage, cracks, pits and scoring. Inspect gear teeth and pinion bushings for wear, cracks and damage. If any of these conditions are observed, replace part

NOTE

Helical spur gear (11) and cross shaft (42) must be replaced as a matched set. Pinions (18) and side gears (16) must be replaced as a set.

g. Case halves (9 and 10), spider (19), and thrust washers (17)	Inspect	Inspect for wear, cracks, pits, scoring, damage and distortion. If any of these conditions are observed, replace part
---	---------	---

NOTE

Replace thrust washers (17) in sets; combination of old and new thrust washers will result in premature failure.

h. All other parts	Inspect	Inspect for wear, damage, cracks, pits and distortion. If any of these conditions are observed, replace part
--------------------	---------	--

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

INSPECTION (cont)

NOTE

Immediately after performing inspection, coat all parts with light oil to prevent corrosion.

REASSEMBLY

NOTE

Lubricate all parts and inner walls of differential case (9 and 10) with axle lubricant (refer to current lubrication order). Torque limits given apply to parts coated with machine oil; for dry parts, increase torques 10 percent; for parts coated with axle lubricant, decrease torques 10 percent.

19	Differential(61) carrier housing (1)	a. Fill plug	Install	If fill plug (61) was removed. Tighten to 35 pounds foot
		b. New gasket (60) and front cover (57)	Position	
		c. Four capscrews (58) and lock washers (59)	Install	Tighten to 35-50 pounds foot
		d. New gasket (56) and inspection hole cover (54)	Position	
		e. Four capscrews (55) and lock washers (63)	Install	Tighten to 35-50 pounds foot
		f. New bearing cup (53)	Press on	If old bearing cup (53) was removed
		g. Correct shims (52) and cross shaft cover (51)	Position	If removed earlier
		h. Six capscrews (49) and lock washers (50)	Install	If removed earlier. Tighten capscrews (49) to 130-165 pounds foot. If cross shaft cover (51) wasn't removed, double check torque values

4-5. DIFFERENTIAL (CONT)


STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
20	Drive gear (40)	Cross shaft (42) and key (46)	Install	Press in, with key (46) in line with keyway
21	Cross shaft (42)	a. New bearing (47)	Install	If old bearing (47) was removed. Press onto end opposite drive gear (40)
		b. Bearing (45)	Install	Press onto drive gear (40) end
		c. Bearing retainer (44)	Position	
		d. Two capscrews (43)	Install	Tighten to 130-165 pounds foot
22	Cross shaft bearing cage (37)	New bearing cup (48)	Install	If old bearing cup was removed. Press in
23	Differential carrier housing (1)	a. Bearings (45 and 47) and bearing cups (48 and 53)	Lubricate	With light machine oil
		b. Cross shaft (42)	Install	Tilt to put end opposite drive gear (40) in first
		c. Shims (41)	Position	Be sure you install same shims removed earlier. Aline all holes
		d. Cross shaft bearing cage (37)	Install	Tap with soft mallet
		e. Six capscrews (38) and lock washers (39)	Install	Tighten to 130-165 pounds foot

NOTE

Rotate cross shaft (42) several times before checking bearing preload to assure full bearing contact.

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
24	Cross shaft (42)	Pound scale preload	Check bearing	Pull horizontally on soft wire wrapped around cross shaft (42) as shown



NOTE

Example: If cross shaft (42) spur gear has diameter of 4 inches, radius would be 2 inches. 5 pounds pull on scale would equal 10 pounds inch bearing preload torque. Use rotating, not starting torque. Add shims (41) on side opposite drive gear (40) to reduce preload. Subtract shims (41) to increase preload. Correct preload torque is 5-15 pounds inch.

25	Drive pinion (28)	New inner bearing (34)	Install	If old bearing (34) was removed. Press onto drive pinion shaft (28)
26	Bearing cage (25)	a. New outer bearing cup (32)	Install	If old outer bearing cup (32) was removed. Press firmly against bearing cage shoulder. Lubricate with light oil
		b. New inner bearing cup (33)	Install	If old inner bearing cup (33) was removed. Press firmly against bearing cage shoulder. Lubricate with light oil
		c. Drive pinion (28)	Position	


4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
26 (cont)		d. Bearing spacer (36)	Install	Onto drive pinion (28) shaft, bevel side toward shaft shoulder
		e. Outer bearing (31)	Install	Press onto drive pinion

NOTE

While still in press, rotate bearing cage (25) several times to assure normal bearing contact.

f. Pound scale pinion (28) bearing preload	Check drive	Pull horizontally on soft wire wrapped around bearing cage (25) as shown, while bearing cage is still in press, under 14 tons of pressure
---	-------------	---




NOTE

You can also check preload with yoke (21) installed and nut (23) tightened to 800-1100 pounds foot. Example: Assume bearing cage (25) diameter is 6 inches; radius would be 3 inches. Five pounds pull on scale would equal 15 pounds inch bearing preload torque. Use rotating, not starting torque. Use thinner bearing spacer (36) to increase or thicker spacer to decrease bearing preload if turning torque is not within 5-15 pounds inch. Remove bearing cage (25) from press.

g. Oil seal (30)	Install	Coat outer edge with non-hard- ening sealer and press firm- ly against bearing cage (25)
------------------	---------	--

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
26 (cont)		h. Slinger (22)	Install	Fill with chassis grease and position on yoke (21)
		i. Yoke (21)	Install	Press firmly against outer bearing (31)
27	Differential carrier housing (1)	a. Shims (29) and bearing cage (25)	Position	Install same shims removed earlier. Be sure oil passage holes in differential carrier housing (2), shims (29), and bearing cage (25) line up
		b. Capscrews (26)	Install	Tighten to 130-165 pounds foot
		c. Plate (4) and two tacks (3)	Install	
28	Yoke (21)	Nut (23) and washer (24)	Install	Hold yoke (21) with tool. Tighten nut (23) to 800-1100 pounds foot
29	Drive gear backlash check	a. Drive gear (40) and drive pinion (28)	Check back-	Attach dial indicator as shown. Record reading. If necessary adjust as described in step 29b



4-5. DIFFERENTIAL (CONT)



STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
29 (cont)		b. Shims (41 and 52)	Adjust backlash	Adjust to 0.020-0.026 inch. To move drive gear (40) away from drive pinion (28), take shims (41) from pack under cross shaft bearing cage (37) and add to pack under cross shaft cover (51). To move drive gear (40) toward drive pinion (28), switch shims in opposite direction. Remove dial indicator

NOTE


Used gear sets develop wear patterns. Do not adjust backlash too close, or wear patterns will overlap. Check by rotating drive gear (40). If there is overlap, rotation will be rough. Adjust backlash to get smooth rotation. New gear sets should rotate smoothly within backlash specification.

30	Gear tooth contact check contact	a. Drive gear teeth	Paint and check tooth	Coat about 12 teeth with mixture of red lead and linseed oil. Rotate drive gear (40) through one complete revolution in each direction. Compare tooth pattern against following
		b. Shims (29, 41, and 52) contact	Adjust gear tooth	If necessary. To move drive pinion (28) away from drive gear (40), add shims (29) under bearing cage (25). To move drive pinion toward drive gear, remove shims from bearing cage. See step 38b to move drive gear (40) away from or toward drive pinion (28). Obtain correct tooth contact pattern without changing backlash. See step 29

4-5. DIFFERENTIAL (CONT)




ALL CONTACT BEARINGS SHOWN BELOW ARE ON RIGHT HAND SPIRAL RING GEAR — THE DRIVE IS ON THE CONVEX SIDE OF THE TOOTH.




CONDITION 1

TYPICAL PREFERRED BEARING ON BOTH SIDES OF TOOTH WHILE UNDER A LIGHT LOAD




CONDITION 2

TOE BEARING ON BOTH SIDES OF TOOTH-GEAR SET NOISY. TO MOVE BEARING TOWARD HEEL INCREASE BACKLASH WITHIN LIMITS BY MOVING GEAR AWAY FROM PINION.




CONDITION 3

HEEL BEARING ON BOTH SIDES OF TOOTH-GEAR SET NOISY AND COULD RESULT IN EARLY GEAR FAILURE. TO MOVE BEARING TOWARD TOE DECREASE BACKLASH WITHIN LIMITS BY MOVING GEAR TOWARD PINION.



CONDITION 4

LOW BEARING ON GEAR AND HIGH BEARING ON PINION. CORRECT BY PULLING PINION AWAY FROM GEAR. INCREASE MOUNTING DISTANCE BY ADDING SHIMS BETWEEN BEARING CAGE AND DIFFERENTIAL HOUSING.



CONDITION 5

HIGH BEARING ON GEAR AND LOW BEARING ON PINION. CORRECT BY MOVING PINION IN TOWARD GEAR. DECREASE MOUNTING DISTANCE BY REMOVING SHIMS FROM BETWEEN BEARING CAGE AND DIFFERENTIAL HOUSING.



BACKLASH

BACKLASH SHOULD BE MEASURED WITH A DIAL INDICATOR RIGIDLY MOUNTED WITH THE STEM PERPENDICULAR TO THE TOOTH SURFACE AT THE EXTREME HEEL.

TA236104

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
31	Differential case and gear assembly	a. All parts and case (9 and 10) inner walls b. Side gear thrust washer (15) and side gear (16) c. Helical spur gear (11)	Lubricate Install Position	Axle lubricant In case half (10) On case half (10)
32	Spider (19)	Four pinions (18) and thrust washers (17)	Install	
33	Case half (10)	Spider (19)	Install	
34	Spider (19)	Side gear (16) and side gear thrust washer (15)	Install	
35	Case half (10)	a. Case half (9) b. Four capscrews (12), washers (13), and nuts (14) c. Remaining capscrews (12), washers (13), and nuts (14)	Position Install Install	Aline mating marks Equally spaced around case half (9). Check assembly for free rotation Tighten all capscrews (12) to 150-190 pounds foot and install lock wire
36	Case halves (9 and 10)	New bearings (20)	Press on	If old bearings (20) were removed

CAUTION

In step 37, adjusting nuts (7) are cross threaded if differential bearing caps (2) do not seat properly. Remove caps and reposition adjusting nuts. If you force caps into place, you will cause irreparable damage to differential carrier housing (1).

4-5. DIFFERENTIAL (CONT)

STEP	LOCATION	ITEM	ACTION	REMARKS
REASSEMBLY (cont)				
37	Differential carrier housing (1)	a. Two bearing cups (8), two adjusting nuts (7), and differential bearing caps (2)	Position	
		b. Four capscrews (5) and four washers (6)		Tighten to 470-550 pounds foot
		c. Bearing cups (8)	Check fit	Must be hand press fit in bores. Use emery cloth, if necessary. Use blued bearing cup to check fit as you go
		d. Differential bearing caps (2)	Remove	
		e. Bearings (20) and bearing cups (8)	Lubricate	With axle lubricant
38	Bearings (20)	Bearing cups (8)	Install	
39	Differential carrier housing (1)	a. Differential case and gear assembly	Install	Place bar through differential case and gear assembly and position assembly in differential carrier housing
		b. Adjusting nuts (7)	Insert	Turn hand tight against bearing cups (8)

CAUTION

In step 39c, adjusting nuts (7) are cross threaded if differential bearing caps (2) do not seat properly. Remove caps and reposition adjusting nuts. If you force caps into place, you will cause irreparable damage to differential carrier housing (1).

c. Differential bearing caps (2)	Position	Tap lightly into position
----------------------------------	----------	---------------------------

4-5. DIFFERENTIAL (CONT)


STEP	LOCATION	ITEM	ACTION	REMARKS
------	----------	------	--------	---------

REASSEMBLY (cont)

39 (cont)		d. Four capscrews (5), and washers (6)	Install	Tighten to 470-550 pounds foot
		e. Helical spur gear (11)	Position	Line up with cross shaft (42) spur pinion by turning adjusting nuts (7)

ADJUSTMENT

40	Differential bearing preload	a. Adjusting nuts	Tighten	Attach dial indicator and tighten adjusting nuts (7) as shown to get 0.000 inch end play in bearings (20). Rotate several times to get proper bearing contact
----	------------------------------	-------------------	---------	---



TA236105

		b. Adjusting nuts (7)	Set bearing preload	Tighten each adjusting nut (7) one notch from 0.000 inch end play position
		c. Four capscrews (5)	Check torque	Tighten to 470-550 pounds foot
		d. Two new cotter pins (62)	Install	

APPENDIX A

REFERENCES

A-1. SCOPE

This appendix lists all forms and publications pertinent to the major item materiel and associated equipment.

A-2. FORMS

DA Form 2028-2	Recommended Changes to Equipment Technical Publications
DA Form 2404	Equipment Inspection and Maintenance Work Sheet
DD Form 6	Packaging Improvement Report
SF 368	Quality Deficiency Report

A-3. FIELD MANUALS

FM 5-20	Camouflage
FM 9-207	Operation and Maintenance of Ordnance Materiel in Cold Weather (0 degrees F to -65 degrees F)
FM 21-11	First Aid for Soldiers
FM 21-40	Chemical, Biological, Radiological, and Nuclear Defense
FM 21-305	Manual for Wheeled Vehicle Driver
FM 31-70	Basic Cold Weather Manual
FM 31-71	Northern Operations
FM 43-2	Metal Body Repair and Related Operations
FM 55-30	Driver Selection and Training (Wheeled Vehicles)
FM 90-6	Mountain Operations

A-4. TECHNICAL BULLETINS

TB 43-0209	Color, Marking, and Camouflage Painting of Military Vehicles, Construction Equipment, and Materials Handling Equipment
TB 43-0210	Army Oil Analysis Program
TB 740-97-1	Preparation for Shipment
TB 740-97-2	Preservation for Shipment and Storage (US Army)
TB 750-651	Use of Antifreeze Solutions and Cleaning Compounds in Engine Cooling System

A-5. TECHNICAL MANUALS

TM 3-220	Chemical, Biological, and Radiological (CBR) Decontamination
TM 9-214	Inspection, Care, and Maintenance of Antifriction Bearings
TM 9-237	Welding Theory and Application
TM 9-247	Materials Used for Cleaning, Preserving, Abrading, and Cementing Ordnance Materiel and Related Materiels Including Chemicals
TM 9-2320-285-10	Operator's Manual: Truck Tractor, Yard Type, M878A1
TM 9-2320-285-24P	Organizational, Direct Support, and General Support Maintenance Repair Parts and Special Tools List: Truck Tractor Yard Type, M878A1

A-5. TECHNICAL MANUALS (CONT)

TM 9-2610-200-20	Organizational Care, Maintenance and Repair: Pneumatic Tires, Inner Tubes, and Radial Tires
TM 9-2815-205-34	Direct Support and General Support Maintenance Manual: Engine, Diesel (Detroit Diesel Series 6V53T)
TM 9-2815-205-34P	Direct Support and General Support Maintenance Repair Parts and Special Tools List: Engine, Diesel (Detroit Diesel Series 6V53T)
TM 9-6140-200-14	Operation and Organizational Maintenance Manual for Lead Acid Storage Batteries
TM 9-8000	Principles of Automotive Vehicles
TM 38-230-1	Packaging of Material
TM 38-230-2	Preservation and Packaging
TM 38-236	Preparation for Air Shipment
TM 55-2200-001-12	Block and Rail Transport
TM 740-90-1	Administrative Storage of Equipment
TM 743-200-1	Storage of Material Handling Equipment
TM 743-200-2	Storage Modernization
TM 743-200-3	Storage MHE Equipment
TM 750-244-6	Procedures for Destruction of Tank Automotive Equipment to Prevent Enemy Use
TM 750-254	Cooling Systems: Tactical Vehicles

A-6. MISCELLANEOUS PUBLICATIONS

AR 385-40	Accident Reporting and Records
AR 385-55	Prevention of Motor Vehicle Accidents
DA Pam 738-750	The Army Maintenance Management System (TAMMS)
LO 9-2320-285-12	Lubrication Order: Truck Tractor, Yard Type, M878A1
SB 38-100	Preservation, Packaging, Packing and Marking Materials, Supplies, and Equipment Used by the Army

APPENDIX B
MAINTENANCE ALLOCATION CHART
Section I. INTRODUCTION

B-1. GENERAL

- a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance categories.
- b. The Maintenance Allocation Chart (MAC) in section II designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component will be consistent with the capacities and capabilities of the designated maintenance categories.
- c. Section III lists the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from section II.
- d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

B-2. MAINTENANCE FUNCTIONS

Maintenance functions will be limited to and defined as follows:

- a. Inspect. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (i.e., by sight, sound, or feel).
- b. Test. To verify serviceability by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. Service. Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.
- d. Adjust. To maintain or regulate, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.
- e. Align. To adjust specified variable elements of an item to bring about optimum or desired performance.
- f. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments or test, measuring, and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

B-2. MAINTENANCE FUNCTIONS (CONT)

g. Remove/Install. To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

h. Replace. To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the 3rd position code of the SMR code.

i. Repair. The application of maintenance services or other maintenance actions to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. Overhaul. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

k. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment and components.

B-3. EXPLANATION OF COLUMNS IN THE MAC, SECTION II

a. Column 1 Group Number. Column 1 lists functional group code numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the next higher assembly.

b. Column 2 Component/Assembly. Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

c. Column 3 Maintenance Function. Column 3 lists the functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph B-2.)

B-3. EXPLANATION OF COLUMNS IN THE MAC, SECTION II (CONT)

d. Column 4 - Maintenance Category. Column 4 specifies, by the listing of a work time figure in the appropriate subcolumn(s), the category of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance categories, appropriate work time figures will be shown for each category. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance/quality control time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance categories are as follows:

- C.....Operator/crew
- O.....Organizational maintenance
- F.....Direct support maintenance
- H.....General support maintenance

e. Column 5 - Tools and Equipment. Column 5 specifies, by code, those common tool sets (not individual tools) and special tools, TMDE, and support equipment required to perform the designated function.

f. Column 6 - Remarks. This column shall, when applicable, contain a letter code, in alphabetic order, which shall be keyed to the remarks contained in Section IV.

B-4. EXPLANATION OF COLUMNS IN TOOL AND TEST EQUIPMENT REQUIREMENTS, SECTION III

a. Column 1 - Reference Code. The tool and test equipment reference code correlates with a code used in the MAC, Section II, Column 5.

b. Column 2 - Maintenance Category. The lowest category of maintenance authorized to use the tool or test equipment.

c. Column 3 - Nomenclature. Name or identification of the tool or test equipment.

d. Column 4 - National Stock Number. The National stock number of the tool or test equipment.

e. Column 5 - Tool Number. The manufacturer's part number.

B-5. EXPLANATION OF COLUMNS IN REMARKS, SECTION IV

a. Column 1 - Reference Code. The code recorded in column 6, Section II.

b. Column 2 - Remarks. This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

**Section II. MAINTENANCE ALLOCATION CHART
FOR
TRUCK TRACTOR, YARD TYPE M878A1**

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
01	<u>ENGINE</u>								
0100	Engine	Inspect Service Adjust Replace Repair	0.1 0.5		2.5 12	32.7		1	
	Engine Mount	Inspect Replace			0.1 2.0				
0101	Block, Cylinder	Inspect Replace Repair			0.1			1	
	Heads, Cylinder	Replace Repair				10.1 12.0			
0102	Crankshaft	Inspect Replace Repair				0.3 20.0 8.0		1	
	Damper, Vibration	Replace			4.5				
	Bearings, Main Replace	Inspect				1.0 6.0			
	Seals, Main	Replace			7.2				
0103	Flywheel	Replace Repair				6.9 1.0		1	
	Flywheel Housing	Replace Repair				9.5 1.5			
0104	Pistons and Connect- ing Rods								
	Pistons	Replace				16.0			
	Connecting Rods	Replace				16.0			
		B-4							

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS		
			C	O	F	H	D				
0105	Valves and Tappets	Adjust Replace			1.5			1			
						4.0					
	Timing Gears	Replace					3.5				
	Arm, Rocker	Replace					2.5				
	Camshafts	Replace					12.5				
0106	Bearings	Replace					4.0	1			
	Oil Pump and Front Cover	Replace Repair					3.5 2.0				
	Filter, Oil	Service Replace		0.5 1.0							
	Lines and Filter, External Repair	Service Replace			0.5 1.0 1.0						
	Cooler, Oil	Inspect Test Replace Repair			0.5 1.0 3.0		11.5				
	Dipstick and Tube	Replace		0.1							
	Oil Pan	Replace			2.0						
	Oil Inlet Tube	Replace			2.5						
	Valve, Regulator and Relief	Replace			0.2						
	Valve, Breather	Service			0.2						
	0108	Manifolds	Replace			2.0				1	
	0109	Accessory Drive, Alternator	Replace		1.0					1	
Repair				2.0							

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
03	<u>FUEL SYSTEM</u>								
0301	Injector Assembly, Fuel Repair	Test Replace			2.0 1.0 1.5	2.01			
	Rack, Fuel Injector	Adjust Replace			1.0 1.3				
0302	Pump Assembly, Fuel	Test Replace Repair		0.5 1.5	1.0		1		
	Fuel Crossover Lines	Replace			1.0				
0304	Air Cleaner Assembly	Service Replace Repair		0.1 1.0	1.0		1		
	Air Cleaner	Replace Restriction Indicator		1.0					
0305	Air Inlet	Replace		1.0			1		
	Blower, Gear Driven	Replace Repair			6.0	4.0			
	Turbocharger	Replace Repair			2.0	3.0			
0306	Tank, Fuel	Service Replace Repair	0.2	3.0 1.5			1		
	Lines and Fittings, Fuel	Inspect Replace	0.1	1.0					
0308	Governor	Adjust Replace Repair			1.0 6.0	2.0	1		
0309	Filters, Fuel	Service Replace	0.2	0.3			1		

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
0311	Ether Kit, Engine Starting	Service Replace		0.3 1.0				1	
0312	Accelerator and Throttle Linkage	Adjust Replace Repair		0.3 0.5 0.5				1	
04	<u>EXHAUST</u>								
0401	Exhaust Pipes	Replace		1.5				1	
	Muffler	Replace		2.0					
05	<u>COOLING SYSTEM</u>								
0501	Radiator	Test Service Replace Repair	0.2	0.1	8.0 4.0			1	
	Heat Exchanger	Replace Repair		3.0	4.0				
0502	Shroud, Fan	Replace Repair			1.51 1.0				
0503	Thermostats	Test Replace		0.2 1.5				1	
	Water Manifold	Replace		1.0					
	Filter, Coolant	Service Replace		0.3 1.0					
	Hoses	Replace		0.5					
0504	Pump, Water	Replace Repair		2.5 2.0				1	
	Seal, Water	Replace		2.0					
0505	Fan	Replace		1.5				1	
	Belts, Fan Drive	Adjust Replace		0.2 1.7					

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
06	Fan Drive Assembly	Replace Repair		1.5	2.0				
	<u>ELECTRICAL SYSTEM</u>								
0601	Alternator	Test Replace Repair		1.0 1.3	2.0			1	
0603	Belts, Drive	Adjust Replace		0.3 1.4					
	Starter	Test Replace Repair		1.4 2.0	3.0			1	
0607	Cable	Replace		1.5					
	Solenoid and Circuit Breaker	Test Replace		0.4 1.5					
0608	Instrument Panel	Replace Repair		1.5	3.0			1	
	Circuit Breaker	Test Replace		0.5 2.0					
0608	Switches	Test Replace		0.4 0.5				1	
	Turn Signal Control	Replace Repair		0.4 0.6					
0608	Engine Warning Kit	Test Replace		0.5 1.0					
	Water Level Warning Kit	Test Replace Repair		0.4 0.5	1.0				
0608	Inverter, 12-to-24 Volt	Test Replace		0.5 1.0					

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
0609	Headlights	Test Adjust Replace	0.1	0.2 0.4				1	
	Tail, Park, Turn, and Marker Lights	Test Replace	0.1	0.3					
	Trailer Light Circuits	Test Replace		0.5 1.0					
	Flood Lights	Test Replace	0.1	0.3					
0610	Sending Units and Switches	Replace		0.5				1	
0611	Horn and Relay	Adjust Test Replace	0.1	0.5 1.0				1	
	Switch, Horn	Replace		0.5					
0612	Batteries	Test Service Replace	0.5	0.6 0.4				1	
	Cables, Battery	Replace		0.4					
	Box, Battery	Replace Repair		1.0 1.0					
0613	Wiring Harness	Test		2.5				1	
		Replace			10.0				
		Repair		2.8					
07	<u>TRANSMISSION</u>								
0708	Torque Converter	Replace Repair			10.0	6.0		1	
0710	Transmission	Test			0.5			1	
		Adjust			0.9				
		Service		0.2					
		Replace Repair			6.5	16.0			
		B-9							

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
	Mount, Transmis- sion	Replace Repair		2.0 1.0					
	Shift Linkage	Adjust Replace Repair		1.0 2.0 1.0					
	Shift Lock	Repair		1.0					
	Modulator Cable Assembly	Replace Repair		1.0	1.0				
0721	Filter	Replace		0.5				1	
09	<u>PROPELLER SHAFTS</u>								
0900	Shaft Assembly and U-Joints	Service Replace		0.2 1.0				1	
10	<u>FRONT AXLE</u>								
1000	Axle Assembly	Service Replace Repair		1.0	6.0 8.0			1	
	Hub and Drum	Replace		1.0					
	Bearings and Seals	Replace		1.6					
	Steering Knuckle	Service Replace		0.1	0.7				
11	<u>REAR AXLE</u>								
1100	Axle Assembly	Service Replace		1.0	6.0			1	
	Axle Shaft, Hub, and Drum	Replace		8.0					
	Bearings and Seals	Replace		1.6					
1102	Differential	Service Replace Repair		1.0	9.0		9.0		

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
12	<u>BRAKES</u>								
1202	Service Brakes	Adjust Replace Repair		0.5 3.0 4.0				1	
1206	Linkage, Mechanical	Adjust Replace Repair		1.0	3.0 2.0			1	
1208	Lines and Fittings, Air	Replace Repair		2.2 1.6				1	
	Reservoirs, Air	Service Replace	0.1	1.1					
	Switch, Low Air Pressure	Test Replace		0.5 1.0					
	Brake Air Chambers	Adjust Replace Repair		0.5 2.0 2.2					
	Treadle Valve	Replace Repair			2.0 3.0				
	Valve, Air Control	Replace Repair			2.0 2.0				
	Hand Brake Control	Replace Repair			2.0 2.0				
1209	Air Compressor Assembly Including Belts	Service Adjust Replace Repair		0.2 1.0 3.0	1.0			1	
	Air Strainer	Service Replace		0.4 0.4					
	Alcohol Evaporator	Service Replace	0.1	2.0					

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
1211	Governor, Air Compressor	Adjust Replace Repair		0.3 0.5	1.0				
	Lines and Couplings, Trailer Brakes	Inspect Replace Repair	0.1	1.0 1.5			1		
	Hose Tender	Replace Repair		1.0 0.3					
13	<u>WHEELS</u>								
1311	Hub Assembly	Service Adjust Replace		1.0 0.5 1.0			1		
	Drum	Replace Repair		2.0	3.0				
	Bearings and Seals	Replace		1.6					
1313	Tires	Service Replace Repair	0.3	2.1 1.3			1		
14	<u>STEERING</u>								
1401	Wheel, Steering	Replace		0.5			1		
	Column, Steering	Replace Repair			4.0 3.5				
	Universal Joint	Replace			2.5				
	Tie Rod	Align Replace			0.3 1.5				
	Power Steering Gear	Adjust Test Replace Repair			0.5 0.5 6.8 8.0				
	Linkage and Ball Sockets	Replace			2.0				

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
1410	Hydraulic Pump, Steering	Test Replace Repair			0.2 3.0 3.0			1	
1411	Lines and Fittings, Hydraulic Steering	Replace Repair		0.6 1.0				1	
	Hydraulic Filter and Reservoir	Service Replace		0.5 1.0					
15	<u>FRAME AND TOWING ATTACHMENTS</u>								
1501	Grille, Frame	Replace		0.5				1	
1503	Shackles and Hooks, Tow	Replace		0.5				1	
1504	Spare Tire Mount	Replace Repair		1.0 1.0				1	
1506	Fifth Wheel	Service Replace Repair		0.2	3.0 2.0			1	
	Unlatch Cylinder	Replace			1.0				
	Unlatch Valve	Replace Repair			1.5 1.0				
	Platform and Latch, Boom	Replace		1.0					
16	<u>SPRINGS AND SHOCK ABSORBERS</u>								
1601	Springs and Spring Seats	Service Replace		0.2	4.0			1	
1604	Shock Absorbers	Replace		1.8				1	
18	<u>BODY AND CAB</u>								
1801	Cab Mounts	Replace			3.0			1	

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) EQUIPMENT	(6) TOOLS AND REMARKS
			C	O	F	H	D		
1802	Panel and Engine Shroud	Replace Repair		0.5	0.3				
	Door	Replace Repair		2.0	6.0				
	Guard, Rear Window	Replace Repair		0.3 0.5					
	Side Step	Replace		0.5				1	
	Windshield	Replace			1.2				
1806	Seat Belt and Seat	Replace Repair		0.5	1.5			1	
1808	Tool Box	Replace		0.3				1	
22	<u>ACCESSORY ITEMS</u>								
2202	Arm and Wiper	Replace		0.2				1	
	Windshield Wiper Motor and Switch	Replace		1.0					
	Windshield Washer and Motor	Service Replace	0.2	0.5					
	Mirrors, Rearview	Adjust Replace	0.1	0.3					
	Sun Visor	Replace Repair		0.3 0.5					
	First Aid Kit	Replace		0.3					
	Air Horn and Valve	Adjust Replace Repair		0.2 1.0 1.0					
2207	Heater, Personnel	Replace Repair		2.0	2.0			1	
	Heaters, Winterization	Replace Repair		2.0 2.0					

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL					(5) TOOLS AND EQUIPMENT	(6) REMARKS
			C	O	F	H	D		
2210	Junction Box	Replace		1.0					
24	Plates, Data and Instruction	Replace		0.5				1	
	<u>HYDRAULIC AND FLUID SYSTEMS</u>								
2401	Hydraulic Pump, Fifth Wheel	Replace Repair	4.0		2.0			1	
2402	Power Take-off	Replace Repair			2.0 4.0				
2402	Fifth Wheel Control Valve	Adjust Replace Repair			1.0 2.0 3.0			1	
2403	Pump, Cab Tilt	Replace Repair		2.0	3.0				
2403	Hydraulic Control Lever and Linkage, Fifth Wheel	Adjust Replace Repair		1.0 2.0 1.0				1	
2404	Filters, Hydraulic	Service Replace		0.5 1.0					
2404	Hydraulic Cylinder, Cab Tilt	Inspect Replace Repair	0.1		2.0 2.0			1	
2406	Latches, Hydraulic Safety Bar	Replace Replace			1.0 1.0				
2406	Lines and Fittings	Replace		1.0				1	
2407	Hydraulic Cylinders, Fifth Wheel	Inspect Replace Repair	0.1		1.0 2.0			1	
2408	Reservoir, Hydraulic	Service Replace	0.2	2.0				1	
		B-15							

Section II. MAINTENANCE ALLOCATION CHART - Continued

(1) GROUP NUMBER	(2) COMPONENT ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL					(5) TOOLS AND EQUIPMENT	(6) REMARKS
			C	O	F	H	D		
47	<u>GAGES. NON-ELECTRIC</u>								
4701	Shaft, Speedometer	Replace			0.5		1		
	Tachometer	Replace			0.5				
4702	Gages, Pressure	Replace			0.5		1		
4703	Hourmeter	Replace			1.0		1		

**SECTION III. TOOL AND TEST EQUIPMENT REQUIREMENTS
FOR
TRUCK TRACTOR, YARD TYPE M878A1**

(1) TOOL OR TEST EQUIPMENT REF CODE	(2) MAINTENANCE LEVEL	(3) NOMENCLATURE	(4) NATIONAL/NATO STOCK NUMBER	(5) TOOL NUMBER
Unless otherwise noted, all maintenance functions can be accomplished with the tools contained in the following tool sets. No special tools are required.				
1	F	Shop Equipment, Contact Maintenance: Truck Mounted	4940-00-294-9518	LIN T10138
	F	Shop Equipment, General Purpose Repair: Semitrailer Mounted	4940-00-287-4894	LIN T10549
	O, F	Shop Equipment, Organizational Repair: Light Truck Mounted	4940-00-294-9516	LIN T13152
	F	Tool Kit, Automotive Fuel and Electrical System Repair	4910-00-754-0655	LIN W32456
	O, F, H	Tool Kit, Auto Maintenance: Org. Maintenance Common No. 1	4910-00-754-0654	LIN W32593
	O, F, H	Tool Kit, Auto Maintenance: Org. Maintenance Common No. 2	4910-00-754-0650	LIN W32730
	O, F, H	Tool Kit, Automotive Maintenance: Light Weight	5180-00-177-7033	LIN W33004
B-16				

SECTION III. TOOL AND TEST EQUIPMENT REQUIREMENTS - Continued

(1) TOOL OR TEST EQUIPMENT REF CODE	(2) MAINTENANCE LEVEL	(3) NOMENCLATURE	(4) NATIONAL/NATO STOCK NUMBER	(5) TOOL NUMBER
	F, H	Tool Kit, Master Mechanic: Equipment Maintenance and Repair	5180-00-699-5273	LIN W45060
	F, H	Wrench Set, Socket: 3/4" Drive Hex Type	5130-00-357-5135	LIN Y75239
	F, H	Wrench, Torque: 3/4" Drive 100-500 lb-ft Capacity	5120-00-542-5577	LIN Y84966
	F, H	Shop Equipment, Fuel and Electrical System Engine	4910-00-754-0714	LIN T30414
	F, H	Shop Set, Fuel and Electrical System Supplemental No. 2	4910-00-390-7775	LIN T30688
	F	Test Set, Diesel Injector	4910-00-317-8265	LIN V73742
	O, F, H	Shop Equipment, Automotive Maintenance and Repair: Org. Supplemental No. 1 Less Power	4910-00-754-0653	LIN W32867
	F, H	Shop Equipment, Machine Shop	3740-00-754-0708	LIN T15644
	F, H	Tool Kit, Machinist	5280-00-511-1950	LIN W44512
	O, F	Shop Equipment, Welding	3740-00-357-7268	LIN T16714
	O, F	Tool Kit, Body and Fender Repair	5180-00-754-0643	LIN W33689

Section IV. REMARKS

Reference Code	Remarks
A	All repair and replacement of parts performed by organizational maintenance limited to authorized items listed in Maintenance Allocation Chart.

**APPENDIX C
EXPENDABLE SUPPLIES AND MATERIALS LIST**

Section I. INTRODUCTION

C-1. SCOPE

This appendix lists expendable consumable maintenance supplies you will need to operate and maintain the M878A1 yard tractor. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

C-2. EXPLANATION OF COLUMNS

a. Column 1 - Item Number. This number is assigned to the entry in the listing and is referenced in the Materials/Parts portion of Initial Setup to identify the material (e.g., "Clean cloths, Item 2, Appendix C").

b. Column 2 - Level. This column identifies the lowest level of maintenance that requires the listed item.

C - Operator/Crew
O - Organizational Maintenance
F - Direct Support Maintenance
H - General Support Maintenance

c. Column 3 - National Stock Number. This is the National stock number assigned to the item; use it to request or requisition the item.

d. Column 4 - Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parenthesis, if applicable.

e. Column 5 - Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two character alphabetical abbreviation (e.g., ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

SECTION II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION PART NO. AND FSCM	(5) UNIT OF MEAS.
1	C	6850-00-264-9038 6850-00-285-8012 7920-00-205-1711	SOLVENT: Dry Cleaning P-D-680, Type II (81348) 5 GAL CAN 55 GAL DRUM RAGS, COTTON: Wiping GAA, GREASE, AUTOMOTIVE AND ARTILLERY MIL-G-10924 (81349)	EA EA BL
2	C	9150-00-065-0029 9150-00-935-1017 9150-00-190-0904 9150-00-190-0905 9150-00-190-0907	2-1/4 OZ TUBE 14 OZ CARTRIDGE EA 1 LB CAN 5 LB CAN 35 LB CAN	EA EA EA EA
3	O	5350-00-192-5047 5350-00-192-5049 5350-00-192-5051 9505-00-087-3956	CLOTH, ABRASIVE: Al-oxide, jean-cloth- backing, closed coat, 9 x 11 sh, 50-sh sheave (81348) P-C-451A, Type a, Class 1 GRIT NO. 80 (GR 1/0) GRIT NO. 120 (GR 3/0) GRIT NO. 180 (GR 5/0)	EA EA EA
4	O	9150-01-035-5395	WIRE, LOCK: Cs, Zinc Ctd, 0.020 Dia MS20995F20 (96906)	SL
5	O	9150-00-273-2389 9150-00-231-6689 9150-00-281-2060	OIL, HYPOID: SAE 95W/140 MIL-L-2105 (81349) 5 Gal Can OIL, LUBRICATING: General Purpose, MIL-L-644 (81349)	EA EA EA
6	O	9150-00-698-2382 9150-00-657-4959 9150-00-250-0926	FLUID, AUTOMATIC TRANSMISSION: Dexron II 1 QT CAN 5 GAL CAN GREASE, OIL-SOLUBLE: Petrolatum VV-P-236 (81348)	EA EA EA
7	F	8030-00-252-3391 8030-00-873-4792 8040-00-109-2481	SEALANT, NON-HARDENING: Permatex No 2 MIL-S-45180 Type II (81349) 11 Oz Tube 1 Qt Container	EA EA
8	O	5350-00-221-0872	ADHESIVE: Weatherstrip, Black 8011 (04963) 5 Oz Tube	EA
9	O	7510-00-243-3437	CLOTH, ABRASIVE: Crocus, ferric oxide and quartz, jean-cloth-backing, exposed coat, 9 x 11 sh, 50-sh sheave (81348) P-C-458, 42-C-20420-50	EA EA
10	O	7530-00-082-2661	BANDS, RUBBER: ZZ-R-001415 (81348) LABELS, PAPER: Pressure-sensitive Adhesive UU-L-001644 (81348)	EA EA
11	H			
12	O			
13	H			
14	O			

SECTION II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION PART NO. AND FSCM	(5) UNIT OF MEAS.
15	F		GREASE: Lubriplate Compound 907 (77640 PN 045113), or	
16	O	9150-00-663-9795	Mobil Temp 1 or 2 (77640 PN 045231)	EA
17	F		GREASE, WHEEL BEARING: MIL-G-18709 (81349) 6.5 Lb Can	EA
18	F	8030-00-181-8372	LUBRICANT: Grease, Barium-base (06853 Spec. BW-204-M, PN 240176)	EA
19	F	8030-01-142-3131	SOLVENT, DEGREASING: Locquic Primer MIL-S-22473 Grade T (81349) 6 Oz Can	EA
20	F		SEALANT, STUD: MIL-S-46163 Type II Grade 0 (80244)	EA
21	F	7510-00-558-1305	SEALANT, HYDRAULIC: Loctite No 569 56931 (05972) 50 ml Bottle	EA
22	C		TAPE, PRESSURE-SENSITIVE ADHESIVE: Cellophane and Cellulose Acetate L-T-90 (81348)	RL
		9150-00-252-6383	OIL, HYDRAULIC: Petroleum Base, MIL-H-5606 (81349)	EA
		9150-00-223-4134	1 QT CAN	EA
		9150-00-265-9408	1 GAL CAN	EA
23	F	8030-01-109-8208	55 GAL DRUM	EA
24	C		SEALANT, STUD LOCK: Loctite No 86 (05972) MIL-S-22473 Grade AVV (81349)	EA
		9150-00-188-9858	OIL, LUBRICATING, ENGINE: MIL-L-2104 (81349)	EA
		9150-00-188-9859	SAE 30, 5 GAL CAN	EA
		9150-00-188-9860	SAE 30, 55 GAL DRUM	EA
		9150-00-188-9861	SAE 40, 5 GAL CAN	EA
25	C		SAE 40, 55 GAL DRUM	EA
		6850-00-243-1992	ANTIFREEZE, ENGINE: Ethylene Glycol, Inhibited O-A-548 (81348)	EA
		6850-00-644-1409	1 GAL CAN	EA
26	O	9150-00-140-4434	55 GAL DRUM	EA
27	C		GREASE: Lubriplate Mag 1 087-056 (92739)	EA
		7930-00-559-9616	DETERGENT: General Purpose P-D-220 (81348)	EA
		7930-00-559-9617	1 GAL	EA
28	O	7510-01-026-4661	5 GAL	EA
29	O	8030-01-014-5869	TAPE, PRESSURE-SENSITIVE ADHESIVE: Masking UU-T-00106 (81348)	RL
			SEALANT, THREAD: MIL-STD-46163 (81349) 50 ml Bottle	EA
			C-3	

SECTION II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION PART NO. AND FSCM	(5) UNIT OF MEAS.
30	O	6810-00-201-0907	ALCOHOL: Denatured O-E-760 Grade III (81348) 5 GAL CAN	EA
		6810-00-201-0904	55 GAL DRUM	EA
31	O	8135-00-634-3292	TAPE, PRESSURE-SENSITIVE ADHESIVE: Waterproof PPP-T-0066 Type IV (81348)	RL
32	O	7510-00-419-9564	INK, MARKING STENCIL: Opaque (porous and non-porous surfaces) TT-I-1795 (81348)	EA
33	O	8010-00-246-6112	THINNER, PAINT: Mineral Spirits, Volatile, 'Odorless' TT-T-291 (81348)	EA
34	O		GREASE, HIGH TEMPERATURE: Cup	EA
35	F		GREASE, PNEUMATIC: Dow Corning 55-M MIL-I-4343 (81349)	
			291126 (06853) 1/4 Oz Tube	EA
			291127 (06853) 2 Oz Tube	EA
36	O	6810-00-249-9354	SULFURIC ACID, ELECTROLYTE: O-S-801 Class III (81348) 1 Gal	EA
37	O	5970-00-644-3167	INSULATION TAPE, ELECTRICAL: Pressure- sensitive adhesive, plastic, general purpose HH-I-595 (81348)	RL
38	O	8030-00-753-4953	COMPOUND, ANTISEIZE: MIL-A-13881 (81349)	EA
39	C		ALCOHOL, METHYL: Methanol O-M-232 (81348)	
		6810-00-597-3608	1 GAL CAN	EA
		6810-00-275-6010	5 GAL CAN	EA
		6810-00-224-8353	55 GAL DRUM	EA
40	O	8040-01-168-0440	ADHESIVE, AIR-DRYING: Silicone rubber MIL-A-25457 (81349)	EA
41	O	3439-00-965-0066	SOLDER: SN 60 lead-tin alloy QQ-S-571 (81348)	SL
42	C	6810-01-127-4246	ALCOHOL: Isopropyl TT-I-735 (81348)	EA
43	O	8030-00-889-3534	TAPE, ANTISEIZE: tetrafluoroethylene, with dispenser MIL-T-27730 (81349)	RL
44	O	9150-00-261-7899	OIL, PENETRATING: VV-P-216 (81348)	EA
45	C	9140-00-286-5294	FUEL, DIESEL: Type DF2 to -20 degrees F VV-F-800 (81348)	BL
46	H	8010-00-152-3245	LINSEED OIL: Mixture, thinned TT-L-190 (81348)	EA
47	H	8010-00-239-5725	RED LEAD: TT-R-191 (81348)	EA
			C-4	

APPENDIX D TORQUE LIMITS

D-1. GENERAL

This appendix provides general torque limits for fasteners. Special torque values are indicated in the maintenance procedures for applicable components. The general torque values given in this appendix shall be used when specific torque values are not indicated in the maintenance procedures.

D-2. TORQUE LIMITS

Torque limits are listed in table D-1 for dry fasteners and in table D-2 for wet fasteners. Dry fasteners are defined as fasteners on which no lubricants are applied to the threads; wet fasteners are defined as fasteners on which special graphited or moly-disulphide greases or other extreme pressure lubricants are applied to the threads. Table D-3 lists minimum breakaway torque values for locknuts.

Table D-1. Torque Limits for Dry Fasteners

SIZE		TORQUE			
		SAE GRADE NO. 5		SAE GRADE NO. 8	
INCHES	MILLIMETERS	POUNDS FOOT	NEWTON METERS	POUNDS FOOT	NEWTON METERS
1/4	6.35	9- 11	12.2- 14.9	12- 15	16.3- 20.3
5/16	7.94	17- 20	23.1- 27.8	24- 29	32.5- 39.3
3/8	9.53	35- 42	47.5- 57.0	45- 54	61.0- 73.2
7/16	11.11	54- 64	73.2- 86.8	70- 84	94.9- 113.9
1/2	12.70	80- 96	108.5- 130.2	110- 132	149.2- 179.0
9/16	14.29	110- 132	149.2- 179.0	160- 192	217.0- 260.4
5/8	15.88	150- 180	203.4- 244.1	220- 264	298.3- 358.0
3/4	19.05	270- 324	366.1- 439.3	380- 456	515.3- 518.3
7/8	22.23	400- 480	542.4- 650.9	600- 720	813.6- 976.3
1	25.40	580- 696	786.5- 943.8	900-1080	1220.4-1464.5
1-1/8	25.58	800- 880	1084.8-1193.3	1280-1440	1735.7-1952.8
1-1/4	31.75	1120-1240	1518.7-1681.4	1820-2000	2467.9-2712.0
1-3/8	34.93	1460-1680	1979.8-2278.1	2380-2720	3227.3-3688.3
1-1/2	38.10	1940-2200	2630.6-2983.2	3160-3560	4285.0-4827.4

Table D-2. Torque Limits for Wet Fasteners

SIZE		TORQUE			
		SAE GRADE NO. 5		SAE GRADE NO. 8	
INCHES	MILLIMETERS	POUNDS FOOT	NEWTON METERS	POUNDS FOOT	NEWTON METERS
1/4	6.35	8- 10	10.8- 13.6	11- 13	14.9- 18.3
5/16	7.94	15- 18	20.4- 25.1	21- 26	29.2- 35.3
3/8	9.53	31- 38	42.8- 51.6	40- 48	55 - 65.9
7/16	11.11	48- 57	65.9- 78.2	63- 75	85.6- 102.6
1/2	12.70	72- 86	97.9- 117.6	99- 119	134.6- 161.8
9/16	14.29	99- 119	134.6- 161.8	144- 173	195.8- 235.2
5/8	15.88	135- 162	183.6- 220.3	198- 237	269.2- 323
3/4	19.05	243- 291	330.4- 396.4	342- 410	465.1- 557.6
7/8	22.23	360- 432	489.6- 587.5	540- 648	734.4- 881.2
1	25.40	522- 626	709.9- 851.3	810- 972	1101.6-1321.9
1-1/8	25.58	720- 792	979.2-1077.1	1152-1296	1566.7-1762.5
1-1/4	31.75	1008-1116	1370.8-1517.7	1638-1800	2227.6-2448
1-3/8	34.93	1314-1512	1787 -2056.3	2142-2448	2430.3-3329.2
1-1/2	38.10	1746-1980	2374.5-2692.8	2844-3204	3867.8-4357.4

Table D-3. Locknut Breakaway Torque Values

THREAD SIZE	MINIMUM BREAK-AWAY TORQUE (POUNDS INCH)
10-32	2.0
1¼-28	3.5
5/16-24	6.5
3/8-24	9.5
7/16-20	14.0
1/2-20	18.0
9/16-18	24.0
5/8-18	32.0
¾-16	50.0
7/8-14	70.0
1-12	90.0
1-1/8-12	117.0
1-1/4-12	143.0
<p style="text-align: center;">NOTE</p> <p>To determine breakaway torque, thread locknut onto screw or bolt until at least two threads stick out. Locknut shall not make contact with a mating part. Stop the locknut. Torque necessary to begin turning locknut again is the breakaway torque. Do not reuse locknuts that do not meet minimum breakaway torque.</p>	

APPENDIX E ELECTRICAL, HYDRAULIC, AND PNEUMATIC DIAGRAMS

Section I. INTRODUCTION

E-1. GENERAL

This appendix contains hydraulic diagrams, a pneumatic diagram, and an electrical diagram. Also included in this appendix is a description of how to use the electrical diagram as an aid to troubleshooting (section II). Section III contains the diagrams (figures E-2 thru E-7).

E-2. DIAGRAMS

The hydraulic diagrams are located in figures E-2 thru E-5. Figure E-3 shows the hydraulic oil flow when the fifth wheel is raised. Figure E-4 shows the hydraulic oil flow when the fifth wheel is lowered. The pneumatic diagram is located in figure E-6, and the electrical diagram is located in figure E-7.

Section II. HOW TO USE ELECTRICAL SCHEMATIC AS AN AID TO TROUBLESHOOTING

E-3. OVERVIEW

a. Figure E-7, your Electrical Diagram, is designed to help you understand the electrical circuits associated with this vehicle. It is generally referred to as a "schematic" and uses "symbols" to represent real components. It is not drawn to scale (as in a blueprint) nor does the location of the symbols represent actual location of components in the vehicle. It is a simple "picture" of how the circuits and components are connected together.

b. To quickly find a malfunction or trouble in the electrical system and repair it requires an understanding of how the system operates and a method for checking it out. "Troubleshooting" provides the "method" for check out procedures and your technical manual (Troubleshooting tables and schematics) provides the "operating principles".

E-4. TROUBLESHOOTING

Troubleshooting is the systematic (step-by-step) isolation of a malfunction or trouble to the faulty component, harness connector, or wire. It is a guide that helps develop a routine or "way" of finding troubles in any electrical system or circuit. As you become more familiar with this vehicle and gain experience, you will find ways to shorten these procedures and decrease down time. BEFORE you attempt to make any repairs or checks, do the following:

E-4. TROUBLESHOOTING (CONT)

- a. Find out how the system works under normal conditions and how to operate it.
- b. Make sure the malfunction or trouble reported to you "really" exists. ("Dead batteries" could end up as a "failure to start" because of a faulty neutral start switch or the transmission shift lever not fully engaged in neutral.) Try to duplicate the trouble so you can be sure you're on the right track.
- c. Check troubleshooting index for most likely cause, then identify the circuit that is malfunctioning.
- d. Study the electrical schematic to learn which components, harnesses, or wires could contribute to or cause the malfunction.


NOTE

Remember, when tracing circuits on the electrical diagram, that you should always start at the positive (+) side of the batteries. Current will flow outward from that point through the circuits and return to the negative (-) side of the batteries by way of ground wires and the vehicle frame.

- e. Make necessary tests and checks to isolate circuit or component as outlined in the troubleshooting section of this technical manual.
- f. Make repairs, if you're sure. If not, continue to isolate the malfunction, or ask for help from your supervisor.
- g. After repairs, make sure everything has been reconnected and tightened.
- h. Make operational checks to verify that the system or circuit is functioning properly again.

E-5. TROUBLESHOOTING LOGIC TREE


Figure E-1 is a Troubleshooting logic tree. It is designed to help you develop a quick logical way of approaching an electrical troubleshooting problem.



TA127509

Figure E-1. Logic Tree Troubleshooting Technique.


Section III. DIAGRAMS



TA236406

Figure E-2. Power Steering Hydraulic Diagram.


1. Hydraulic Pump
2. Hydraulic Control Valve
3. Hydraulic Cylinder
4. Velocity Fuse
5. Bleed Valve
6. Suction Line Filter
7. Return Line Filter and Relief Valve
8. Hydraulic Reservoir



TA236407



Figure E-3. Fifth Wheel Hydraulic Diagram (raising).

1. Hydraulic Pump
2. Hydraulic Control Valve
3. Hydraulic Cylinder
4. Velocity Fuse
5. Bleed Valve
6. Suction Line Filter
7. Return Line Filter and Relief Valve
8. Hydraulic Reservoir




TA236408

Figure E-4. Fifth Wheel Hydraulic Diagram (lowering).



TA236409

Figure E-5. Cab Tilt Hydraulic Diagram.



TA236410

Figure E-6. Pneumatic Diagram.

APPENDIX F
GLOSSARY

ABBREVIATIONS

A	Annually
ACC	Accessories
AMP	Ampere
AR	Army Regulation
AR	As required
ATTN	Attention
B	Biennially
BAT	Battery
BL	Bulk
BLK	Black
BLU	Blue
BRN	Brown
CC	Cubic centimeter
CONT	Continued
DA	Department of the Army
DD	Department of Defense
DED	Diesel engine driven
DMWR	Depot maintenance work requirements
EA	Each
EIR	Equipment improvement recommendation
EQPT	Equipment
F	Fahrenheit
FM	Field Manual
FSCM	Federal Supply Code for Manufacturers
GAA	Grease, Automotive and Artillery
GAL	Gallon
GND	Ground
GRA	Gray
GRN	Green
GVW	Gross vehicle weight
H	Hours
I.D	Inside diameter
IGN	Ignition
LB	Pound
LIN	Line item number
LO	Lubrication order
MAC	Maintenance Allocation Chart
MI	Miles
MOS	Military Occupational Specialty
MPH	Miles per hour
MTOE	Modified table of organization and equipment
N	Neutral
NATO	North Atlantic Treaty Organization
NO	Number
NSN	National stock number

GLOSSARY-Continued

O.D.....	Outside diameter
ORG.....	Orange
oz.....	Ounce
PARA.....	Paragraph
PMCS.....	Preventive maintenance checks and services
PN.....	Part Number
PRESS.....	Pressure
PSI.....	Pounds per square inch
PT.....	Pint
PTO.....	Power take-off
Q.....	Quarterly
QA.....	Quality assurance
QC.....	Quality control
QT.....	Quart
R.....	Reverse
REF.....	Reference
RPM.....	Revolutions per minute
RPSTL.....	Repair parts and special tools list
S.....	Semiannually
SAE.....	Society of Automotive Engineers
SB.....	Service bulletin
SF.....	Standard Form
SMR.....	Source, Maintenance, and Recoverability Code
ST.....	Starter
TAMMS.....	The Army Maintenance Management System
TB.....	Technical Bulletin
TEMP.....	Temperature
TM.....	Technical Manual
TMDE.....	Test, Measurement, and Diagnostic Equipment
U/M.....	Unit of measure
V.....	Volt
Vac.....	Volt (alternating current)
Vdc.....	Volt (direct current)
VIO.....	Violet
WET.....	White
YEL.....	Yellow

**APPENDIX G
ILLUSTRATED LIST OF MANUFACTURED ITEMS**

G-1. INTRODUCTION

This appendix includes complete instructions for making items authorized to be manufactured or fabricated by organizational and direct support maintenance. A part number index in alpha-numeric order is provided for cross referencing the part number of the item to be manufactured to the figure which covers fabrication criteria. All bulk materials needed for manufacture of an item are listed by NSN in a tabular list on the illustration.


G-2. MANUFACTURED ITEMS PART NUMBER INDEX

PART NUMBER	FIGURE	PART NUMBER	FIGURE	PART NUMBER	FIGURE
000069541-22	G-1	004857167-36	G-1	011612678-61	G-1
000670454-130	G-1	004857167-40	G-1	011647803-12	G-1
001002589-36	G-1	004857167-47	G-1	011647803-24	G-1
001101947-8	G-1	008174451-28	G-1	011647803-80	G-1
001101947-26	G-1	008174451-40	G-1	011666205-2.5	G-1
001101947-30	G-1	008174451-49	G-1	011666205-18	G-1
001101947-78	G-1	008174451-50	G-1	011792936-16	G-1
001135484-39	G-1	008174451-53	G-1	011792936-27	G-1
001135484-41	G-1	008174451-327	G-1	011792936-28	G-1
001770102-10	G-1	010144915-33	G-1	011792936-33	G-1
003174824-22	G-1	010144915-35	G-1	011792937-16	G-1
004211279-6	G-1	010144915-42	G-1	011792937-27	G-1
004211279-55	G-1	010703394-37	G-1	011792937-71	G-1
004434746-27	G-1	010703394-49	G-1	011792938-34	G-1
004434746-32	G-1	010703394-65	G-1	011792938-123	G-1
004434746-84	G-1	010748373-42	G-1	011792939-12	G-1
004434746-120	G-1	010748373-52	G-1	011792939-21	G-1
004512727-24	G-1	011612678-5	G-1	011792939-45	G-1
004512727-55	G-1	011612678-20	G-1	011792939-53	G-1
004644421-5	G-1	011612678-28	G-1	011792939-55	G-1
004644421-14	G-1	011612678-32	G-1	011792940-60	G-1
004644421-15	G-1	011612678-38	G-1	011792940-136	G-1
004644421-16	G-1	011612678-42	G-1	011805152-34	G-1
004857167-16	G-1	011612678-60	G-1		

G-3. MANUFACTURED ITEMS ILLUSTRATIONS

Figure G-1, a simplified line drawing, illustrates all items authorized to be manufactured or fabricated by organizational and direct support maintenance personnel. All dimensions and information necessary for manufacture are included. The Part Number column of the table lists the part numbers of the items to be manufactured, and the Description column describes the items. The Dimension and Materials columns provide information on the size of each item and the material from which it shall be manufactured.

ILLUSTRATED LIST OF MANUFACTURED ITEMS - Continued



TA127505

Figure G-1. Manufactured Items.

Part Number	Description	Dimension (Inches)		NSN
		A	B	
000069541-22	Hose, Power Steering Pump	0.62	22	4720-00-006-9541
000670454-130	Hose, Steering Gear Box	0.41	130	4720-00-067-0454
001002589-36	Copper Tubing, Evaporator	0.12	36	4710-00-100-2589
001101947-26	Hose, Front Brake Chamber	0.62	26	4720-00-110-1947
001101947-30	Hose, Xmsn Oil Filter	0.62	30	4720-00-110-1947
001101947-30	Hose, Xmsn Oil Cooler	0.62	30	4720-00-110-1947
001101947-78	Hose, Xmsn Oil Filter	0.62	78	4720-00-110-1947
001101947-8	Hose, Supply Air Tank	0.62	8	4720-00-110-1947
001135484-39	Hose, Protection Valve	0.50	39	4720-00-113-5484
001135484-41	Hose, Brake Treadle Valve	0.50	41	4720-00-113-5484
001770102-10	Hose, Control Valve Supply	0.37	10	4720-00-177-0102
003174824-22	Hose, Power Steering Pump	0.31	22	4720-00-317-4824
004211279-6	Hose, Protective Wrap	1.50	6	4720-00-421-1279
004211279-55	Hose, Protective Wrap	1.50	55	4720-00-421-1279
004434746-120	Hose, Restriction Indicator	0.25	120	4720-00-443-4746
004434746-27	Hose, Air Pressure Gage	0.25	27	4720-00-443-4746
004434746-32	Hose, Air Pressure Gage	0.25	32	4720-00-443-4746
004434746-84	Hose, Air Horn Valve	0.25	84	4720-00-443-4746
004512727-24	Hose, Fuel Tank	0.50	24	4720-00-451-2727
004512727-55	Hose, Fuel Pump	0.50	55	4720-00-451-2727
004644421-5	Hose, Xmsn Sampling Valve	0.19	5	4720-00-464-4421
004644421-14	Hose, Xmsn Sampling Valve	0.19	14	4720-00-464-4421
004644421-15	Hose, Engine Sampling Valve	0.19	15	4720-00-464-4421
004644421-16	Hose, Xmsn Sampling Valve	0.19	16	4720-00-464-4421
004857167-16	Hose, Engine Fuel Supply	0.31	16	4720-00-485-7167
004857167-36	Hose, Fuel Tank	0.31	36	4720-00-485-7167
004857167-40	Hose, Fuel Pump	0.31	40	4720-00-485-7167
004857167-47	Hose, Engine Fuel Supply	0.31	47	4720-00-485-7167
008174451-28	Hose, Front Brake Chamber	0.31	28	4720-00-817-4451
008174451-327	Hose, Unlatch Cylinder	0.31	327	4720-00-817-4451
008174451-40	Hose, Double Check Valve	0.31	40	4720-00-817-4451
008174451-49	Hose, Ratio Reducing Valve	0.31	49	4720-00-817-4451
008174451-50	Hose, Air Control Valve	0.31	50	4720-00-817-4451

ILLUSTRATED LIST OF MANUFACTURED ITEMS - Continued

Part Number	Description	Dimension (Inches)		NSN
		A	B	
008174451-53	Hose, Quick Release Valve	0.31	53	4720-00-817-4451
010144915-33	Hose, Hand Brake Control	0.37	33	4720-01-014-4915
010144915-35	Hose, Air Control Valve	0.37	35	4720-01-014-4915
010144915-42	Hose, Unlatch Valve	0.37	42	4720-01-014-4915
010703394-37	Hose, Air Tank Check Valve	0.62	37	4720-01-070-3394
010703394-49	Hose, Relay Valve	0.62	49	4720-01-070-3394
010703394-65	Hose, Service Air Tank	0.62	65	4720-01-070-3394
010748373-42	Hose, Engine Oil Pan	0.31	42	4720-01-074-8373
010748373-52	Hose, Engine Oil Filter	0.31	52	4720-01-074-8373
011612678-20	Heater Hose, Silicone	0.62	20	4720-01-161-2678
011612678-28	Heater Hose, Silicone	0.62	28	4720-01-161-2678
011612678-32	Heater Hose, Silicone	0.62	32	4720-01-161-2678
011612678-38	Heater Hose, Silicone	0.62	38	4720-01-161-2678
011612678-42	Heater Hose, Silicone	0.62	42	4720-01-161-2678
011612678-5	Heater Hose, Silicone	0.62	5	4720-01-161-2678
011612678-60	Heater Hose, Silicone	0.62	60	4720-01-161-2678
011612678-61	Heater Hose, Silicone	0.62	61	4720-01-161-2678
011647803-12	Hose, Windshield Washer	0.19	12	4720-01-164-7803
011647803-24	Hose, Windshield Washer	0.19	24	4720-01-164-7803
011647803-80	Hose, Windshield Washer	0.19	80	4720-01-164-7803
011666205-18	Hose, Radiator Inlet	2.25	18	4720-01-166-6205
011666205-2.5	Hose, Radiator Inlet	2.25	2.5	4720-01-166-6205
011792936-16	Nylon Tubing, Orange	0.50	16	4720-01-179-2936
011792936-27	Nylon Tubing, Orange	0.50	27	4720-01-179-2936
011792936-28	Nylon Tubing, Orange	0.50	28	4720-01-179-2936
011792936-33	Nylon Tubing, Orange	0.50	33	4720-01-179-2936
011792937-16	Nylon Tubing, Blue	0.50	16	4720-01-179-2937
011792937-27	Nylon Tubing, Blue	0.50	27	4720-01-179-2937
011792937-71	Nylon Tubing, Blue	0.50	71	4720-01-179-2937
011792938-123	Nylon Tubing, Orange	0.37	123	4720-01-179-2938
011792938-34	Nylon Tubing, Orange	0.37	34	4720-01-179-2938
011792939-12	Nylon Tubing, Blue	0.37	12	4720-01-179-2939
011792939-21	Nylon Tubing, Blue	0.37	21	4720-01-179-2939
011792939-45	Nylon Tubing, Blue	0.37	45	4720-01-179-2939
011792939-53	Nylon Tubing, Blue	0.37	53	4720-01-179-2939
011792939-55	Nylon Tubing, Blue	0.37	55	4720-01-179-2939
011792940-136	Nylon Tubing, Red	0.50	136	4720-01-179-2940
011792940-60	Nylon Tubing, Red	0.50	60	4720-01-179-2940
011805152-34	Nylon Tubing, Red	0.37	34	4720-01-180-5152

ALPHABETICAL INDEX

Subject	Para	Subject	Para
A		C	
Adapter Housing Assembly	4-4g	Cab	
Adjustment		deck	3-35c
hydraulic control valve,		door	3-35b
fifth wheel	3-42c	floor mat	3-35e
power steering gear	3-28d	harnesses	
speed shift, transmission	3-17b	see Wiring Harnesses	
tie rod	3-28c	heater	
torque converter	4-3	maintenance	3-38
Air Compressor Assembly		troubleshooting	3-37
maintenance	3-25b	maintenance	3-35c
troubleshooting	3-22	mounts	3-35a
Air Compressor Governor		troubleshooting	3-32
maintenance	3-25a	Cab Tilt	
troubleshooting	3-22	hold down assembly	3-43d
Air Control Valve		hydraulic cylinder	3-43b
maintenance	3-24a	hydraulic latches	3-43c
troubleshooting	3-21	hydraulic pump	3-43a
Alternator		90 degrees	3-35j
maintenance	3-9	safety bar	3-43e
testing	3-9	troubleshooting	3-41
troubleshooting	3-7	Cable, Modulator Assembly	3-17e
Automatic Drain Valve		Center Support Assembly	4-4e
maintenance	3-24e	Chassis Harnesses	
troubleshooting	3-21	see Wiring Harnesses	
Axle		Clutch	
see Front Axle		see Fan Drive Assembly	
see Rear Axle		see Transmission	
B		Control Valve Maintenance	
Ball Sockets and Steering		air control valve	3-24a
Linkage		fifth wheel	3-42c
maintenance	3-28e	trailer hand brake	3-24d
troubleshooting	3-27	transmission	4-4j
Boom, Fifth Wheel	3-33d	Cooling System	
Brake Controls Troubleshooting 3-21		fan drive assembly	3-5c
Brake System Maintenance		fan shroud	3-5b
air compressor assembly	3-25b	radiator	3-5a
air compressor governor	3-25a	troubleshooting	3-3
air control valve	3-24a	Cylinder, Hydraulic	
automatic drain valve	3-24e	see Hydraulic Cylinder	
double check valve	3-24d	Cylinder, Pneumatic	
quick release valve	3-24b	see Unlatch Cylinder	
ratio reducing valve	3-24f	D	
relay valve	3-24g	Deck, Cab	3-35c
tractor protection valve	3-24h	Diagrams	E-1
trailer hand brake control	3-24c	Differential	
treadle valve	3-23	direct support maintenance	3-19b

ALPHABETIC INDEX - Continued

Subject	Para	Subject	Para
D (Cont)		F (Cont)	
Differential (Cont)		Fifth Wheel System (Cont)	
general support maintenance	4-5	hydraulic pump	3-42a
troubleshooting	3-16	power take-off	3-42b
Door, Cab		unlatch cylinder	3-33a
maintenance	3-35b	unlatch valve	3-33b
troubleshooting	3-32	hydraulic system trouble-	
Double Check Valve		shooting	3-40
maintenance	3-24d	repair	3-33c
troubleshooting	3-21	troubleshooting	3-30
Drain Valve, Automatic		First Clutch Assembly	4-4f
see Automatic Drain Valve		Floor Mat	3-35e
Drive Assembly, Fan	3-5c	Forward Clutch and Shaft	
Drive Axle		Assembly	4-4c
see Rear Axle		Fourth Clutch Assembly	4-4d
E		Front Axle	
Electrical System Maintenance		maintenance	3-18
alternator	3-9	troubleshooting	3-15
front chassis wiring		Front Chassis Wiring Harness	3-12b(1)
harness	3-12b(Front Panel Wiring Harness	3-12c(1)
front panel wiring harness	3-12c(Front Support and Oil Pump	4-41
lower cab wiring harness	3-12a(G	
rear chassis wiring harness	3-12b(Gear Unit Assembly Maintenance, Transmission	4-4b
right corner panel wiring		Glass	
harness	3-12c(see Window or Windshield	
right panel wiring harness	3-12c(Governor	
starter	3-10	air compressor	3-25a
upper cab wiring harness	3-12a(transmission	4-4k
water level warning kit	3-11	H	
Engine		Harnesses, Wiring	
maintenance	3-4	see Wiring Harnesses	
repair	3-4	Heater, Cab	
troubleshooting	3-2	maintenance	3-38
wiring harness	3-12d	troubleshooting	3-37
Engine-Transmission Removal	3-4	Hold Down Assembly, Cab Tilt	3-43d
Expendable Supplies and		Housing, Transmission	4-4a
Materials List	C-1	Hydraulic Control Valve,	
F		Fifth Wheel	3-42c
Fan Drive Assembly	3-5c	Hydraulic Cylinder Maintenance	
Fan Shroud	3-5b	cab tilt	3-43b
Fifth Wheel System		fifth wheel	3-42d
boom	3-33d	Hydraulic Latches, Cab Tilt	3-43c
fifth wheel	3-33c	Hydraulic Pump	
hydraulic control valve	3-42c	cab tilt	3-43a
hydraulic cylinders	3-42d		

ALPHABETICAL INDEX - Continued

Subject	Para	Subject	Para
H (Cont)		O	
Hydraulic Pump (Cont)		Oil Pump and Front Support	4-41
fifth wheel	3-42a		
power steering	3-28f	P	
Hydraulic System, Fifth Wheel		Panel, Rear Cab	3-35d
see Fifth Wheel System		PARKING BRAKE Valve	
		see Air Control Valve	
I		Pedal, Brake	3-23
Index, Symptom		Power Steering Gear	
see Troubleshooting		adjustment	3-28d
Instrument Panel Harnesses		maintenance	3-28d
see Wiring Harnesses		testing	3-28d
		troubleshooting	3-27
J		Power Steering Pump	
Jaws, Fifth Wheel		maintenance	3-28f
see Unlatch, Fifth Wheel		troubleshooting	3-27
Joint, Universal		Power Take-off	
see Universal Joint,		maintenance	3-42b
Steering		troubleshooting	3-40
		Protection Valves Maintenance	
L		see Tractor Protection	
Latches, Hydraulic		Valves Maintenance	
see Hydraulic Latches		PTO (Power Take-off)	3-42b
Lockup Valve, Modulated	4-4h	Publications References	A-1
Logic Tree, Troubleshooting	E-5	Pump, Hydraulic	
Low Clutch Assembly	4-4g	see Hydraulic Pump	
Low Planetary Assembly	4-4g	see Power Steering Pump	
Low Shift Valve Assembly	4-4i	Q	
Lower Cab Wiring Harness	3-12a(2)	Quick Release Valve	
		maintenance	3-24b
		troubleshooting	3-21
M		R	
MAC B-1		Radiator	3-5a
Main Shaft, Transmission	4-4b	Ratio Reducing Valve	
Maintenance Allocation Chart	B-1	maintenance	3-24f
Manufactured Items	G-1	troubleshooting	3-21
Mat, Floor	3-35e	Rear Axle	
Modulated Lockup Valve		maintenance	3-19a
Assembly	4-4h	troubleshooting	3-16
Modulator Assembly	3-17e	Rear Cab	
Mounts		panel	3-35d
cab	3-35a	window	3-35g
transmission	3-17f	Rear Chassis Wiring Harness	3-12b(2)

ALPHABETICAL INDEX - Continued

Subject	Para	Subject	Para
R (Cont)		S (Cont)	
Rear Cover Assembly Maintenance, Transmission	4-4k	Steering Linkage and Ball Sockets	
Rear End		maintenance	3-28e
see Differential		troubleshooting	3-27
Rear Window	3-35g	Steering Pump, Power	
Reducing Valve, Ratio		see Power Steering Pump	
see Ratio Reducing Valve		Steering System	
References, Publications	A-1	power steering gear	3-28d
Relay Valve		power steering pump	3-28f
maintenance	3-24g	steering column	3-28a
troubleshooting	3-21	steering linkage and ball sockets	3-28e
Release Valve, Quick		tie rod	3-28c
see Quick Release Valve		universal joint	3-28b
Right Corner Panel Wiring Harness	3-12c(2)	troubleshooting	3-27
Right Panel Wiring Harness	3-12c(3)	Supplies and Materials List	C-1
Right Side Window	3-35g	Suspension, Seat	3-35i(2)
Rod, Tie		Symptom Index	
see Tie Rod		see Troubleshooting	
S		T	
Safety Bar, Cab Tilt	3-43e	Testing	
Seat		alternator	3-9
suspension maintenance	3-35i(2)	power steering gear	3-28d
troubleshooting	3-32	transmission	
upper assembly maintenance	3-35i(1)	hydraulic pressure test	3-17a(2)
Second Clutch Assembly Maintenance	4-4e	road test	3-17a(1)
Shaft, Main, Transmission	4-4b	stall test	3-17a(3)
Shroud, Fan	3-5b	Third Clutch Assembly	4-4e
Speed Shift Adjustment, Transmission	3-17b	Tie Rod	
Spitter Valve		adjustment	3-28c
see Automatic Drain Valve		maintenance	3-28c
Springs and Spring Seats		troubleshooting	3-27
maintenance	3-34	Tilt, Cab	
troubleshooting	3-31	see Cab Tilt	
Starter		Torque Converter	
maintenance	3-10	adjustment	4-3
troubleshooting	3-8	direct support maintenance	3-17d
Steering Column		general support maintenance	4-3
maintenance	3-28a	Torque Limits	D-1
troubleshooting	3-27	Tractor Protection Valves	
Steering Gear, Power		maintenance	3-24h
see Power Steering Gear		troubleshooting	3-21
		TRAILER AIR SUPPLY Valve	
		see Air Control Valve	

ALPHABETICAL INDEX - Continued

Subject	Para	Subject	Para
T (Cont)		T (Cont)	
Trailer Hand Brake Control		Troubleshooting (Cont)	
maintenance	3-24c	cab tilt hydraulic system	3-41
troubleshooting	3-21	cooling system	3-3
Transmission		engine	3-2
direct support maintenance		fifth wheel	3-30
hydraulic pressure test	3-17a(2)	fifth wheel hydraulic	
modulator assembly	3-17e	system	3-40
mount	3-17f	front axle	3-15
replacement, detail		heater	3-37
procedure	3-17c(2)	logic tree	E-5
replacement, summary		rear axle	3-16
procedure	3-17c(1)	springs and spring seats	3-31
road test	3-17a(1)	starter	3-8
speed shift adjustments	3-17b	steering system	3-27
stall test	3-17a(3)	symptom index	
torque converter	3-17d	accessories	3-36
troubleshooting	3-14	body and cab	3-29
general support maintenance		brake system	3-20
adapter housing assembly	4-4g	cooling system	3-1
center support assembly	4-4e	electrical system	3-6
control valve assembly	4-4j	engine	3-1
first clutch assembly	4-4f	frame	3-29
forward clutch and shaft		hydraulic systems	3-39
assembly	4-4c	power train	3-13
fourth clutch assembly	4-4d	springs	3-29
gear unit assembly	4-4b	steering system	3-26
governor assembly	4-4k	towing attachments	3-29
housing	4-4a	transmission	3-14
low clutch assembly	4-4g	treadle valve	3-21
low planetary assembly	4-4g		
low shift valve assembly	4-4i	U	
main shaft	4-4b	Universal Joint, Steering	
modulated lockup valve		maintenance	3-28b
assembly	4-4h	troubleshooting	3-27
oil pump and front support	4-41	Unlatch, Fifth Wheel Jaws	
rear cover assembly	4-4k	cylinder	3-33a
second clutch assembly	4-4e	manual release arm	3-33c
third clutch assembly	4-4e	secondary lock handle	3-33c
torque converter	4-3	troubleshooting	3-30
Transmission-Engine Removal	3-4	valve	3-33b
Treadle Valve		Upper Cab Wiring Harness	3-12a(1)
maintenance	3-23	Upper Seat Assembly	3-35i(1)
troubleshooting	3-21		
Troubleshooting		V	
air compressor	3-22	Valve, Brake System	
alternator	3-7	air control	3-24a
body and cab	3-32		
brake controls	3-21		

ALPHABETICAL INDEX - Continued

Subject	Para
V (Cont)	
Valve, Brake System (Cont)	
automatic drain	3-24e
double check	3-24d
PARKING BRAKE	
see Air Control Valve	
quick release	3-24b
ratio reducing	3-24f
relay	3-24g
spitter	
see Automatic Drain Valve	
tractor protection	3-24h
TRAILER AIR SUPPLY	
see Air Control Valve	
trailer hand brake control	3-24c
treadle	3-23
troubleshooting	3-21
Valve, Fifth Wheel	
hydraulic control	3-42c
unlatch	3-33b
Vent Window	3-35h

W

Water Level Warning Kit	3-11
Window Maintenance	
door	3-35b
rear	3-35g
right side	3-35g
vent	3-35h
Windshield Maintenance	3-35f
Wiring Harnesses Maintenance	
engine	3-12d
front chassis	3-12b(1)
front panel	3-12c(1)
lower cab	3-12a(2)
rear chassis	3-12b(2)
right corner panel	3-12c(2)
right panel	3-12c(3)
upper cab	3-12a(1)

By Order of the Secretary of the Army:

Official:

JOHN A. WICKHAM, JR.
General, United States Army
Chief of Staff

MILDRED E. HEDBERG
Brigadier General, United States Army
The Adjutant General

Distribution: To be distributed in accordance with DA Form 12-38, Organizational Direct Support and General Support Maintenance Manual Requirements for Truck, Tractor, Yard Type, 4X2, M878A1 (w/5th wheel).

* U.S. GOVERNMENT PRINTING OFFICE: 1985-554-019/20177




FIGURE FO-1. Electrical Diagram.

FP-1/(FP-2 BLANK)

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
----------	------------	------------	-----------

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

- 1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
- 1 Meter = 100 Centimeters = 1,000 Millimeters = 39.37 Inches
- 1 Kilometer = 1,000 Meters = 0.621 Miles

SQUARE MEASURE

- 1 Sq Centimeter = 100 Sq Millimeters = 0.155 Sq Inches
- 1 Sq Meter = 10,000 Sq Centimeters = 10.76 Sq Feet
- 1 Sq Kilometer = 1,000,000 Sq Meters = 0.386 Sq Miles

CUBIC MEASURE

- 1 Cu Centimeter = 1,000 Cu Millimeters = 0.06 Cu Inches
- 1 Cu Meter = 1,000,000 Cu Centimeters = 35.31 Cu Feet

LIQUID MEASURE

- 1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
- 1 Liter = 1,000 Milliliters = 33.82 Fluid Ounces

TEMPERATURE

- $5/9 (^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
- 212° Fahrenheit is equivalent to 100° Celsius
- 90° Fahrenheit is equivalent to 32.2° Celsius
- 32° Fahrenheit is equivalent to 0° Celsius
- $9/5 \text{ } ^{\circ}\text{C} + 32 = \text{ } ^{\circ}\text{F}$

WEIGHTS

- 1 Gram = 0.001 Kilograms = 1,000 Milligrams = 0.035 Ounces
- 1 Kilogram = 1,000 Grams = 2.2 lb.
- 1 Metric Ton = 1,000 Kilograms = 1 Megagram = 1.1 Short Tons

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds Per Square Inch	Kilopascals	6.895
Miles Per Gallon	Kilometers Per Liter	0.425
Miles Per Hour	Kilometers Per Hour	1.609
TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pound-Feet	0.738
Kilopascals	Pounds Per Square Inch	0.145
Kilometers Per Liter	Miles Per Gallon	2.354
Kilometers Per Hour	Miles Per Hour	0.621

