### ROUTINE

The MWO effective date is 1 December 1997 and the completion date is 30 November 2001.

### **MODIFICATION WORK ORDER**

### MODIFICATION OF HOWITZER, MEDIUM, SELF-PROPELLED: 155MM, M109A6 (NSN 2350-01-305-0028) (EIC: 3FC)

### Headquarters, Department of the Army, Washington, D.C. 1 SEPTEMBER 1998

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS You can help improve this MWO. If you find any mistakes or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028, Recommended Changes to Publications and Blank Forms, direct to Director, Armament and Chemical Acquisition and Logistics Activity, ATTN: AMSTA-AC-NMLI, Rock Island, IL 61299-7630. A reply will be provided to you.

DISTRIBUTION STATEMENT A. This publication is approved for public release; distribution is unlimited.

**1. PURPOSE.** This MWO prescribes procedures for installing a segment board cleaning mechanism. The segment board cleaning mechanism is a permanently installed assembly that makes cleaning the segment board easier.

**2. PRIORITY.** This modification is classified ROUTINE.

3. END ITEM(S) OR SYSTEM(S) TO BE MODIFIED. See Table 1.

Table 1. End Item or System to be Modified.

NOMENCLATURE	NSN	PART NO.	MODEL	CAGEC	SERIAL NO RANGE
Howitzer, Medium, Self-Propelled: 155 MM	2350-01-305-0028	12553195	M109A6	19200	1-645

# **4. MODULE(S) (COMPONENTS, ASSEMBLIES, SUBASSEMBLIES, BOARDS, AND CARD(S) TO BE MODIFIED).** Not applicable.

**5. PARTS TO BE MODIFIED.** The parts listed in Table 2, whether installed or in depot stock, shall be modified. Stocked parts shall be modified prior to issue and shall be marked so that it can be easily determined that modification has been accomplished. The electrical shield part number and NSN change when the electrical shield is modified.

Table 2. Parts to be Modified.

NOMENCLATURE	NSN	CAGEC	PART NO.	ITEM NO.
Shield, Electrical	5999-01-324-2208	19200	12910552	10

### 6. APPLICATION.

a. <u>Time Compliance Schedule</u>: The MWO effective date is 1 December 1997 and the completion date is 30 November 2001.

- b. <u>Level of Maintenance</u>: Unit maintenance is the lowest level of maintenance authorized to apply this MWO.
- c. Work Force and Man-hour Requirements.

### REQUIREMENTS

		MAN-HOUR W/O
WORK FORCE/SKILLS	MAN-HOURS	DISASSEMBLY
Armament Repairer	1.25 hour	1.00 hour
(MOS. 45D)		

- d. MWOs to be Applied Prior to or Concurrently with this MWO. None.
- e. Additional Information. None.

# 7. TECHNICAL PUBLICATIONS AFFECTED/CHANGED.

TM 9-2350-314-10 TM 9-2350-314-20-2 TM 9-2350-314-24P-2

### 8. MWO KIT(S)/PART(S) AND THEIR DISPOSITION.

a. Kit(s)/Part(s) Needed to Apply the MWO. See Table 3.

Table 3.	Kits/Parts Required.
1 4010 01	rato, raito rioquinoui

NOMENCLATURE	NSN	CAGEC	PART NO.	QTY	ITEM NO.
Washer, Lock	5310-00-209-0786	96906	MS35335-33	12	2,5,12
Washer, Lock	5310-00-584-5272	96906	MS35338-48	1	18
Washer, Lock	5310-00-637-9541	96906	MS35338-46	1	26
Lifting Assembly	TBD	19200	12984448	1	32
Shield, Electrical	TBD	19200	12984447	1	33
Screw	5305-01-309-4781	96906	MS24678-42	4	35
Washer, Flat	5310-01-280-5796	96906	MS27183-57	4	36
Cleaning Block Assembly	TBD	19200	12984454	1	37

- b. Contents of MWO Kits. Not applicable.
- c. Bulk and Expendable Material. See Table 4.

# Table 4. Bulk and Expendable Material

NOMENCLATURE	NSN	CAGEC	PART NO.
Alcohol, Isopropyl	6810-01-190-2538	81348	TT-1-735

d. <u>Parts Disposition</u>. Parts that are not used on the modified howitzer are listed in Table 5. Follow special disposition instructions provided by the item manager.

### Table 5. Parts Disposition

NOMENCLATURE	NSN	CAGEC	PART NO.	QTY	ITEM NO.
Washer, Lock	5310-00-209-0786	96906	MS35335-33	12	2,5,12
Shield, Electrical	5999-01-324-2208	19200	12910552	1	10
Washer, Lock	5310-00-584-5272	96906	MS35338-48	1	18
Washer, Lock	5310-00-637-9541	96906	MS35338-46	1	26

# 9. SPECIAL TOOLS; TOOL KITS; JIGS; TEST, MEASUREMENT, AND DIAGNOSTIC EQUIPMENT. None.

# **10. MODIFICATION PROCEDURES.**

# WARNING

Use caution when rotating-the turret to avoid personal injury and/or equipment damage.

a. Setup.


(1) Release the gun tube from the travel lock. Traverse the turret counterclockwise until the traverse lock is positioned directly above the non-hinged edge of the crew compartment door.

(2) Switch the MASTER power switch to the OFF position and disconnect the battery ground leads.

b. Removal of the Electrical Shield.

# WARNING


Verify that the MASTER power switch is in the OFF position and the battery ground leads are disconnected. Failure to switch the MASTER power switch OFF and disconnect the battery ground leads can lead to serious personal injury.



(1) Remove two screws (1), two lock washers (2), and two flat washers (3). Set the two lock washers aside for disposition per paragraph 8.


(2). Remove six screws (4), six lock washers (5), and six flat washers (6) that secure electrical shield (7), electrical shield (8) and three hooks (9) to electrical shield (10). Remove, but do not disassemble electrical shield (7), electrical shield (8), and three hooks (9). Set the six lock washers aside for disposition per paragraph 8.

(3). Remove four screws (11), four lock washers (12), four flat washers (13), electrical shield (10), spacer (14), and spacer (15). The electrical shield slides down from behind mechanical drive guard (16) without removing the mechanical drive guard. Set the four lock washers and the electrical shield aside for disposition per paragraph 8.



(4) Remove nut (17), lock washer (18), two flat washers (19), screw (20), and three electrical leads (21, 22, 23) from brush block #6 (24). Remove nut (25), lock washer (26), flat washer (27), screw (28), and three electrical leads (29, 30, 31) from brush block #6 (24). Set the two lock washers aside for disposition per paragraph 8.


c. Installation of the Seqment Board Cleaning Mechanism.




### NOTE

# When installing lifting assembly (32) on modified electrical shield (33), make sure stop pin (34) is near the bottom of the lifting assembly.

(1) Fasten lifting assembly (32) to modified electrical shield (33) with four screws (35) and four flat washers (36). The modified electrical shield has a rectangular cutout and four extra screw holes to accommodate the lifting assembly.




- (2) Rotate the handle on lifting assembly (32) clockwise so it contacts stop pin (34).
- (3) Insert cleaning block assembly (37) into lifting assembly (32).
- (4) Release the handle on lifting assembly (32). It should rotate counterclockwise; back to its original position.
- d. Installation of the Electrical Shield.




(1) Slide modified electrical shield (33) upward, into place behind mechanical drive guard (16).

(2) Fasten electrical shield (33), spacer (14) and spacer (15) to the cab with four screws (11), four new lock washers (12), and four flat washers (13).



(3) Reconnect three electrical leads (21, 22, 23), to brush block #6 (24) with screw (20), two flat washers (19), new lock washer (18), and nut (17). Reconnect three electrical leads (29, 30, 31), to brush block #6 (24) with screw (28), flat washer (27), new lock washer (26), and nut (25).



(4) Secure electrical shield (7), electrical shield (8), and three hooks (9) to electrical shield (33) with six screws (4), six new lock washers (5), and six flat washers (6). Install two screws (1), two new lock washers (2), and two flat washers (3).

# 11. CALIBRATION REQUIREMENTS. Not applicable.

12. WEIGHT AND BALANCE DATA. Weight and balance are not significantly affected.

### 13. QUALITY ASSURANCE REQUIREMENTS.

# WARNING

# Serious personal injury may result if the segment boards are cleaned with the battery ground leads connected and the MASTER power switch ON.

- a. With the battery ground leads still disconnected and the MASTER power switch still in the OFF position, clear any loose debris from eight brush blocks and two segment boards by hand.
- b. Operate the segment board cleaning mechanism in accordance with TM 9-2350-314-20-2-2, paragraph 23-3.c, steps 22 through 28.
- c. Verify that the cleaning pads contact the segment board when the handle on the lifting assembly is rotated clockwise. Verify that the cleaning pads do not contact or only lightly touch the segment board when the handle on the lifting assembly is released.
- d. Reconnect the battery ground leads.

# 14. RECORDING AND REPORTING OF THE MODIFICATION.

- a. Records and Reports.
  - (1). Record the modification on DA Form 2408-5, Equipment Modification Record, IAW DA Pamphlet 738-750, The Army Maintenance Management System (TAMMS).
  - (2). Complete DA Form 2407, Maintenance Request, IAW DA Pamphlet 738-750, TAMMS. Forward the NMP copy to: Director, Armament and Chemical Acquisition and Logistics Activity, ATTN: AMSTA-AC-NMR, Rock Island, IL 61299-7630. Forward the organizational copy as directed by the local commander.
- b. Marking Equipment. Not applicable.
- c. Identification Data. Not applicable.

15. MATERIEL CHANGE (MC) NUMBER. This MWO is authorized by MC Number 1-81-05-1002.

16. **MODIFICATION IDENTIFICATION.** This modification has been performed if the segment board cleaning mechanism is installed below the traverse lock.

By Order of the Secretary of the Army:

Official: JOEL B. HUDSON

Administrative Assistant to the Secretary of the Army 05029 General, United States Army Chief of Staff

DENNIS J. REIMER

DISTRIBUTION:

To be distributed in accordance with the initial distribution number (IDN) 372489 requirements for MWO 9-2350-314-20-10.

DOPE A CAREF	RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS SOMETHING WRONG WITH PUBLICATION FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) TATE SENT
	PUBLICATION DATE PUBLICATION TITLE
BE EXACT PIN-POINT WHERE IT	IN THIS SPACE, TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT.
PRINTED NAME, GRADE OR TITLE AN	ID TELEPHONE NUMBER SIGN HERE
DA 1 JUL 79 2028-2	PREVIOUS EDITIONSP.SIF YOUR OUTFIT WANTS TO KNOW ABOUT YOURARE OBSOLETE.RECOMMENDATION MAKE A CARBON COPY OF THISAND GIVE IT TO YOUR HEADQUARTERS.

# THE METRIC SYSTEM AND EQUIVALENTS

#### **'NEAR MEASURE**

. Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches

- 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
- 1 Kilometer = 1000 Meters = 0.621 Miles

### **VEIGHTS**

Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces 1 Kilogram = 1000 Grams = 2.2 lb.

1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

### LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces

1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

### APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	
Square Feet	Square Meters	
Square Yards	Square Meters	
Square Miles	Square Kilometers	
Acres	Square Hectometers	
Cubic Feet	Cubic Meters	
Cubic Yards	Cubic Meters	
Fluid Ounces	Milliliters	
its	Liters	
arts	Liters	
_allons	Liters	
Ounces	-	
Pounds	Grams Kilograms	
Short Tons		
Pound-Feet	Metric Tons Newton-Meters	
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Gallon Miles per Hour	Kilometers per Liter Kilometers per Hour	0.425
Miles per Hour	Kilometers per Liter Kilometers per Hour	0.425 1.609 MULTIPLY BY
Miles per Hour	Kilometers per Hour	1.609 Multiply by
Miles per Hour I <b>O CHANGE</b> Centimeters	Kilometers per Hour	1.609 MULTIPLY BY 0.394
Miles per Hour I <b>O CHANGE</b> Centimeters Meters	Kilometers per Hour TO Inches	1.609 <b>MULTIPLY BY</b> 0.394 3.280
Miles per Hour I <b>O CHANGE</b> Centimeters Meters Meters	Kilometers per Hour TO Inches Feet	1.609 MULTIPLY BY 0.394 3.280 1.094
Miles per Hour O CHANGE Centimeters Meters. Meters. Kilometers	Kilometers per Hour TO Inches Feet Yards Miles	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621
Miles per Hour O CHANGE Centimeters Meters Meters Kilometers Square Centimeters	Kilometers per Hour TO Inches Feet Yards Miles Square Inches	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621 0.155
Miles per Hour O CHANGE Centimeters Meters Meters Kilometers Square Centimeters Square Meters	Kilometers per Hour TO Inches Feet Yards Miles Square Inches Square Feet	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621 0.155 10.764
Miles per Hour	Kilometers per Hour TO Inches Feet Yards Miles Square Inches Square Feet Square Yards	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621 0.155 10.764 1.196
Miles per Hour O CHANGE Centimeters Meters. Kilometers Square Centimeters Square Meters Square Meters Square Meters Square Kilometers	Kilometers per Hour TO Inches Feet Yards Miles Square Inches Square Feet Square Yards Square Miles	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621 0.155 10.764 1.196 0.386
Miles per Hour O CHANGE Centimeters Meters. Kilometers Square Centimeters Square Meters Square Meters Square Meters Square Kilometers Square Hectometers	Kilometers per Hour TO Inches Feet Yards Miles Square Inches Square Feet. Square Yards Square Miles. Acres	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621 0.155 10.764 1.196 0.386 2.471
Miles per Hour O CHANGE Centimeters Meters	Kilometers per Hour TO Inches Feet Yards Miles Square Inches Square Feet Square Yards Square Miles. Acres Cubic Feet	1.609 <b>MULTIPLY BY</b> 0.394 3.280 1.094 0.621 0.155 10.764 1.196 0.386 2.471 35.315
Miles per Hour O CHANGE Centimeters Meters	Kilometers per Hour IO Inches Feet Yards Miles Square Inches Square Feet. Square Yards Square Miles. Acres Cubic Feet Cubic Yards	1.609 <b>MULTIPLY BY</b> 
Miles per Hour O CHANGE Centimeters Meters Kilometers Square Centimeters Square Meters Square Meters Square Kilometers Square Hectometers Cubic Meters Milliliters	Kilometers per Hour IO Inches Feet Yards Miles Square Inches Square Feet Square Miles Acres Cubic Feet Cubic Yards Fluid Ounces	1.609    MULTIPLY BY    0.394    3.280    1.094    0.621    10.764    1.196    2.471    35.315    1.308    0.034
Miles per Hour O CHANGE Centimeters Meters Meters Square Centimeters Square Meters Square Meters Square Kilometers Square Hectometers Cubic Meters Cubic Meters Milliliters Liters	Kilometers per Hour IO Inches Feet Yards Miles Square Inches Square Feet Square Yards Square Miles Cubic Feet Cubic Feet Cubic Yards Fluid Ounces Pints	1.609    MULTIPLY BY
Miles per Hour	Kilometers per HourIOInchesFeetYardsMilesSquare InchesSquare FeetSquare YardsSquare YardsSquare MilesAcresCubic FeetCubic YardsFluid OuncesPintsQuarts	1.609    MULTIPLY BY
Miles per Hour	Kilometers per HourIOInchesFeetYardsMilesSquare InchesSquare FeetSquare YardsSquare MilesAcresCubic FeetCubic FeetCubic YardsFluid OuncesPintsQuartsGallons	1.609    MULTIPLY BY
Miles per Hour	Kilometers per HourIOInchesFeetYardsMilesSquare InchesSquare FeetSquare YardsSquare MilesAcresCubic FeetCubic FeetCubic YardsFluid OuncesPintsQuartsGallonsOunces	1.609    MULTIPLY BY
Miles per Hour	Kilometers per HourIOInchesFeetYardsMilesSquare InchesSquare FeetSquare YardsSquare MilesAcresCubic FeetCubic FeetCubic YardsFluid OuncesPintsQuartsGallonsOuncesPounds	1.609    MULTIPLY BY
Miles per Hour	Kilometers per HourTOInchesFeetYardsMilesSquare InchesSquare FeetSquare YardsSquare MilesAcresCubic FeetCubic YardsFluid OuncesPintsQuartsGallonsOuncesPoundsShort Tons	1.609    MULTIPLY BY    0.394    3.280    1.094    0.621    0.155    10.764    1.196    0.386    2.471    35.315    1.308    0.034    1.057    0.264    0.035    2.205    1.102
Miles per Hour	Kilometers per Hour TO Inches Feet	
Miles per Hour	Kilometers per HourIOInchesFeetYardsMilesSquare InchesSquare FeetSquare YardsSquare MilesAcresCubic FeetCubic FeetCubic YardsFluid OuncesPintsQuartsGallonsOuncesPoundsShort TonsPounds per Square Inch	1.609    MULTIPLY BY    0.394    3.280    1.094    0.621    0.155    10.764    2.471    35.315    1.308    0.034    2.113    1.057    0.264    0.035    2.205    1.102    0.738    0.145
.ms	Kilometers per Hour TO Inches Feet	1.609    MULTIPLY BY    0.394    3.280    1.094    0.621    0.155    10.764    2.471    35.315    1.308    0.034    2.113    1.057    0.264    0.035    2.205    1.102    0.738    0.145

### SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches

- 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
- 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

### **CUBIC MEASURE**

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

### TEMPERATURE

 $5/9(^{\circ}F - 32) = ^{\circ}C$ 

212° Fahrenheit is evuivalent to 100° Celsius

90° Fahrenheit is equivalent to 32.2° Celsius

32° Fahrenheit is equivalent to 0° Celsius

 $9/5C^{\circ} + 32 = {}^{\circ}F$ 



PIN: 076728-000