# DEPARTMENT OF THE ARMY TECHNICAL BULLETIN

# CONTINENTAL MODELS AV-1790 AND AO-895 AND GMC MODELS 6V53/6V53T AND 8V71T SERIES ENGINES: REPAIR OF ALUMINUM OIL COOLERS

# Headquarters, Department of the Army, Washington, D. C., 15 March 1971

- **1. Purpose.** This bulletin provides general support, depot, and contractor maintenance personnel with instructions for repair of aluminum oil coolers by welding or brazing.
- **2. Scope.** This bulletin applies to all GS, depot, and contractor repair of Continental Model AV-1790 and AO-895 and GMC 6V53/6V53T and 8V71T engines.
- **3. Equipment required.** *a.* Arc welding machine for inert gas shielded tungsten arc (Heliarc, Argonarc) or inert gas shielded metal arc consuming electrode process.
- *b.* Class 4043 electrode, conforming to specification QQ-R-556A or MIL-E-16053.
  - c. ALCOA No. 33 torch brazing flux or equivalent.
- d. ALCOA No. 718 or 716 brazing alloy or equivalent, 1/16 and 1/8-inch diameter.
- **4. Repair Procedure.** *a.* Degrease coolers, using vapor or liquid solvents. Dry with compressed air.

# **WARNING**

Degrease vapors may produce phosgene gas.

Do not place coolers into alkali strip tanks.

- b. Prepare surface by removing all foreign matter from area to be welded by use of stainless steel wire brush, drill, burring tool, approved chemical process, or steam cleaning.
- c. Preparation of cracks, fractures, and areas having metal missing:
- (1) Use dye method to determine length of crack, if not visible.
- (2) Drill 3/16-inch stop holes at ends of the crack or fracture.
- (3) Mill or grind out cracks to provide a "V" aperture.
  - \*This Bulletin supersedes TB 9-288, 10 November 1959.

d. Housing welding procedure.

# **CAUTION**

Use extreme care in welding aluminum coolers to prevent damage to fins and tubes. Refer to TM 9-237 for preliminary instructions on welding of aluminum.

# **NOTE**

An interpass temperature of 250° F to 395° F, measured two inches from the weld, will be maintained until the joint is completely welded.

- (1) When preheat temperature of 350° F plus or minus 35 F has been reached, position housing in the most advantageous welding position. Cover all but the area to be repaired with asbestos blankets to maintain heat.
- (2) Weld the milled groove, assuring a good root weld; then, apply fillet welds until groove is filled and closed.
- (3) Remove blankets and allow to cool to room temperature.
- e. Machine the repaired surfaces back to original configuration. Repaired bolt holes must be properly located, drilled, and threaded to original size and thread pitch.
- f. Replacement of Header Tube:
  - (1) Clean in accordance with a above.
- (2) Plug all parts to prevent entrance of contaminants.
  - (3) Saw-cut each end of header tank.
  - (4) Saw-cut each end of tube for removal.
  - (5) Remove remainder of tube by reaming.
  - (6) Saw-cut one end, as shown in Figure 1, to

provide clearance to insert new tubes.

(7) Insert new tubes and weld, in accordance with d above, using aluminum alloy 6061, 1100, or 3003.

# **NOTE**

Tube size, material, and configuration must be equal to original.

- g. Repair of leak in tube, using torch brazing process:
  - (1) Using torch, preheat work area to approxi-

mately  $900^{\circ}$  F or until flux melt. Apply flux and continue heating locally until brazing temperature ( $1080^{\circ}$  F) is reached. Apply filler at brazing temperature.

- (2) Apply brazing alloy.
- (3) Immediately after brazing, quench work in water heated to a minimum of 180° F. Additional washing in hot water and acid is necessary to remove corrosive flux.
- **5. Test.** *a.* Using air, nitrogen, or inert gas, test cooler for leaks under water at 400 psi.




Figure 1. Tube replacement details.

- b. Dry thoroughly with compressed air.
- **6. Surface conditioning.** Apply chemical treatment (Alodine).
- 7. Reporting Of Equipumnt Publication Improvements. The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Depots/Arsenals

will submit DA Form 2028 (Recommended Changes to Publications) direct to the Commanding General, U.S. Army Tank-Automotive Command, ATTN: AMSTA-MAP, Warren, Mich. 48090. Contractor will submit a "Report of Shortcoming" to the Contractor Officer or his designated representative.

W. C. WESTMORELAND, General, United States Army, Chief of Staff.

# Official:

KENNETH G. WICKHAM Major General United States Army, The Adjutant General.

# Distribution:

To be distributed in accordance with DA Form 12-37, requirements of two (2) copies to each account for Depot.

# RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

	SOMETHING WRONG WITH PUBLICATION  FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)  THENJOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.  DATE SENT											
	PUBLICATION NUMBER				PUBLICATION D	ATE	PUBLICATION TITLE					
	BE EXAC PAGE NO.	PARA- GRAPH	FIGURE NO.	TABLE NO.	IN THI AND V	S SPACE, TE	LL WHA	AT IS WRONG DONE ABOUT IT.				
I P	RINTED	NAME, GRA	DE OR TITL	E AND TELE	EPHONE NU	JMBER	SIGN HE	RE				

DA 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE. P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

# THE METRIC SYSTEM AND EQUIVALENTS

# **'NEAR MEASURE**

Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches

1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches

1 Kilometer = 1000 Meters = 0.621 Miles

# **YEIGHTS**

Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces

1 Kilogram = 1000 Grams = 2.2 lb.

1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

# LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces

1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

# **SQUARE MEASURE**

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches

1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet

1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

# **CUBIC MEASURE**

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

# **TEMPERATURE**

 $5/9(^{\circ}F - 32) = ^{\circ}C$ 

212° Fahrenheit is evuivalent to 100° Celsius

90° Fahrenheit is equivalent to 32.2° Celsius

32° Fahrenheit is equivalent to 0° Celsius

 $9/5C^{\circ} + 32 = {\circ}F$ 

# APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	
Yards	Meters	
Miles	Kilometers	
Square Inches	Square Centimeters	
Square Feet	Square Meters	
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	
Cubic Feet	Cubic Meters	
Cubic Yards	Cubic Meters	
Fluid Ounces	Milliliters	
nts	Liters	
arts	Liters	
allons	Liters	
Ounces	Grams	
Pounds	Kilograms	
Short Tons	Metric Tons	
Pound-Feet	Newton-Meters	
Pounds per Square Inch	Kilopascals	
Miles per Gallon	Kilometers per Liter	
Miles per Hour	Kilometers per Hour	

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	
Cubic Meters	Cubic Feet	
Cubic Meters	Cubic Yards	
Milliliters	Fluid Ounces	
Liters	Pints	2.113
Liters	Quarts	1.057
`ers	Gallons	
.ms	Ounces	0.035
.ograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pounds-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
ometers per Liter	Miles per Gallon	2.354
meters per Hour	Miles per Hour	0.621



PIN: 010934-000